

PrimeWave™ Design Environment Tcl Reference Manual

Version W-2024.09, September 2024



Copyright and Proprietary Information Notice

© 2024 Synopsys, Inc. This Synopsys software and all associated documentation are proprietary to Synopsys, Inc. and may only be used pursuant to the terms and conditions of a written license agreement with Synopsys, Inc. All other use, reproduction, modification, or distribution of the Synopsys software or the associated documentation is strictly prohibited.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Trademarks

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at <https://www.synopsys.com/company/legal/trademarks-brands.html>. All other product or company names may be trademarks of their respective owners.

Free and Open-Source Licensing Notices

If applicable, Free and Open-Source Software (FOSS) licensing notices are available in the product installation.

Third-Party Links

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

www.synopsys.com

Contents

New in This Release	18
Related Products, Publications, and Trademarks	18
Conventions	19
Customer Support	20
Statement on Inclusivity and Diversity	21
1. Simulation and Analysis Environment Tcl	22
Commands	22
sa::addAimScript	38
sa::addArgumentsToFlowAction	39
sa::addArgumentsToFlowFile	39
sa::addAxisToChart	40
sa::addCorner	41
sa::addCornerToChart	41
sa::addCustomCategories	42
sa::addDeviceParameters	43
sa::addMSIPaceScript	44
sa::addResultFile	44
sa::addStatisticalInfo	45
sa::addSweepFile	45
sa::addTestbenchToChart	46
sa::addToOptionGroup	46
sa::aging_Analysis_Check_Setups	47
sa::annotateInterfaceElements	47
sa::attachToVDRADB	48
sa::autoscaleChart	48
sa::avaSimulationDone	49
sa::backannotateResults	49
sa::backupRunDir	50
sa::cacheTestbenchToSession	51
sa::cancelPick	51
sa::clearAnnotations	52
sa::clearProbes	52

Contents

sa::cloneTestbench	53
sa::cloneTestbenchToTestSuite	54
sa::configureChartsWindow	54
sa::copyCorner	55
sa::copyDesVars	56
sa::copyScriptFromWorkDir	56
sa::copyTestbenchCategories	56
sa::create3DICModelGroup	57
sa::createA2DInterfaceElement	58
sa::createAceScript	60
sa::createActiveNetsAnalysis	60
sa::createActiveNetsFile	61
sa::createAnalysis	62
sa::createAnalysisDef	62
sa::createAttribute	63
sa::createBackAnnotationFile	65
sa::createChainParameter	65
sa::createChartsWindow	66
sa::createConnectionModule	67
sa::createConnectionRule	67
sa::createConnectRuleElement	68
sa::createConvergenceAid	69
sa::createCornerParameterDef	70
sa::createCornersSetup	71
sa::createCustomCommand	72
sa::createD2AInterfaceElement	73
sa::createDataRow	75
sa::createGroupDef	76
sa::createGroupDefItem	77
sa::createGroupSection	78
sa::createDesignParametersSetup	79
sa::createDesignVariable	79
sa::createDeviceCheckElement	80
sa::createDeviceCheckExpression	83
sa::createDeviceCheckOptions	85
sa::createDeviceCheckSize	86
sa::createDeviceCheckSubckt	88
sa::createDigitalAnalyzerOptions	90
sa::createDigitalAnalyzerOptionsGroup	90

Contents

sa::createDigitalFileOptions	91
sa::createDigitalTiming	91
sa::createE2NInterfaceElement	92
sa::createE2RInterfaceElement	93
sa::createEMDB	94
sa::createExpressionDef	95
sa::createExternalImagePath	96
sa::createFlowFile	97
sa::createForceDigitalNet	97
sa::createHistogramChart	98
sa::createIncludeFile	98
sa::createIncludeGroup	99
sa::createLayoutParasitics	100
sa::createMeasurementSummary	101
sa::createMixedSignalOptions	102
sa::createModelFile	102
sa::createModelGroup	103
sa::createModelGroupDef	105
sa::createModelGroupSection	106
sa::createMonteCarlo	107
sa::createN2EInterfaceElement	108
sa::createNetlist	110
sa::createNodeResistanceOverride	110
sa::createObject	111
sa::createOptionDef	112
sa::createOptionGroup	113
sa::createOptionLimit	114
sa::createOrGetDialog	115
sa::createOutput	117
sa::createPair	120
sa::createProbe	120
sa::createQQChart	121
sa::createR2EInterfaceElement	122
sa::createReport	123
sa::createResistanceMapConfig	124
sa::createResultsInfo	124
sa::createResultsMap	125
sa::createResultsXML	125
sa::createRunDir	126

Contents

sa::createRunScript	127
sa::createSaveOptionsInstance	127
sa::createScatterChart	127
sa::createSDFConfig	128
sa::createSelectionDef	129
sa::createSelectionDefGroup	130
sa::createSelectionGroupDef	130
sa::createSession	131
sa::createSignalObj	132
sa::createSimulator	132
sa::createSpecification	133
sa::createStimulusGroup	135
sa::createStringSet	135
sa::createSweep	136
sa::createSweepDir	137
sa::createSweepRange	138
sa::createTBCDPLClass	140
sa::createTestbench	141
sa::createVariableGroup	141
sa::createWorstCaseCornerCondition	142
sa::createVDRADB	143
sa::deleteHistoryPoint	144
sa::deleteJobClass	144
sa::deleteOutput	145
sa::deleteResults	145
sa::deleteSelected	146
sa::deleteTBCDPLClass	146
sa::deleteTestSuiteResults	147
sa::directPlot	147
sa::displayLog	148
sa::displayNetlist	149
sa::DSPFPatch	149
sa::dumpResultsView	150
sa::editDesVars	151
sa::editNetlist	152
sa::editOutputs	153
sa::emitRefreshIterativeResultsTable	153
sa::emitRefreshMeasurementSummaryDialog	154
sa::emitSimulationDone	154

Contents

sa::emitUpdateIterativeResultsWindow	155
sa::evaluateAceScripts	156
sa::evaluateExpressions	156
sa::evaluateMonteCarloScalarExpressions	157
sa::executeFlowAction	157
sa::executeDeviceGroupAction	158
sa::exportAndLaunchVerdiCov	158
sa::exportChart	159
sa::exportChartImage	159
sa::exportCopyNetlist	160
sa::exportCSVFromResultsViewer	160
sa::exportGroupDef	161
sa::exportModelGroupDef	162
sa::exportReportHtml	162
sa::exportResultData	162
sa::exportResultDataBySpec	163
sa::exportResultsViewsToCSV	163
sa::exportScript	164
sa::exportSessionReport	164
sa::exportToCSV	165
sa::exportToVerdiCov	165
sa::showExternalImages	166
sa::findActiveHistoryPoint	166
sa::findActiveTestbench	167
sa::findClosestIterations	167
sa::findDesignVariableGroupDefs	168
sa::findDuplicates	168
sa::findId	169
sa::findIncludeGroupDef	170
sa::findIterations	170
sa::findModelGroupDef	171
sa::findModelLanguage	172
sa::findModuleName	172
sa::findNameMap	173
sa::findSaveSignals	173
sa::findSessionName	174
sa::findSigmaIterations	175
sa::findStimulusGroupDef	175
sa::findVariablesFromNetlist	176

Contents

sa::findWindow	177
sa::findWorstCornerName	177
sa::flattenTestbench	178
sa::formatExpression	178
sa::formatNumeric	179
sa::generateCorners	180
sa::generateReports	181
sa::getAnalyses	181
sa::getAnalysisDefs	182
sa::getBackupRunDirs	183
sa::getCDPLClass	183
sa::getCDPLMember	184
sa::getCornerParameters	184
sa::getCorners	185
sa::getCumulativeFrequency	186
sa::getData	187
sa::getDatabaseDir	189
sa::getDataDir	190
sa::getDesignVariablesGroupVar	190
sa::getDesignWindows	191
sa::getEMNetCurrents	192
sa::getExpressionContext	192
sa::getFailedIterations	193
sa::getFlowFileDependencyTree	193
sa::getFlowFileModificationTime	194
sa::getGoalTypeForSource	194
sa::getHistoryDataTestbench	194
sa::getHistoryResultsDir	195
sa::getMeasurementSets	196
sa::getMeasurementStatistics	196
sa::getMeasuresInfo	197
sa::getMeasureValue	198
sa::getModelGroupDefs	198
sa::getNetlistDir	199
sa::getNetlistIncludeFiles	200
sa::getNetlistModelFiles	200
sa::getNetlistVariables	200
sa::getPickedObjects	201
sa::getRalignedResultTypes	201

Contents

sa::getRefVal	202
sa::getReportElement	202
sa::getReports	203
sa::getResultFiles	204
sa::getResults	204
sa::getResultsDir	205
sa::getResultsViewerData	206
sa::getResultTypes	206
sa::getRunDir	207
sa::getRunScriptPath	207
sa::getScalarValuesData	207
sa::getSelected	208
sa::getSessions	208
sa::getSimulators	209
sa::getSimulatorSweepPoints	210
sa::getSimulatorSweepsInfo	210
sa::getStates	211
sa::getSweepPoints	212
sa::getTerminalInfo	212
sa::getTestbenches	213
sa::getTestSuiteStorage	214
sa::getTopEquivalentNet	215
sa::getVDRCNetVoltages	216
sa::getWindowType	216
sa::hasMonteCarloResults	217
sa::importGroupDef	217
sa::importModelGroupDef	218
sa::initializeAttributes	218
sa::isCornersSetupEnabled	219
sa::isResultAvailable	219
sa::isSweepsEnabled	220
sa::loadCornersSetup	221
sa::loadDesVarsFromText	222
sa::loadObjectFromFile	223
sa::loadOutputs	223
sa::loadResultsDir	224
sa::loadSimOptions	225
sa::loadState	225
sa::loadTestSuite	227

Contents

sa::lockHistoryPoint	228
sa::makePrefLabel	229
sa::makePrefName	229
sa::map	230
sa::mapDesignVariableValue	231
sa::mergeCornersSetup	231
sa::migrateResults	231
sa::netlistAndRun	232
sa::openResultsMap	233
sa::openSimulationConsole	233
sa::openTextFiles	234
sa::openWaveView	234
sa::optAddParameter	235
sa::optGetFinishedSampleReport	236
sa::optGetFailedSampleReport	236
sa::optRegisterResultsTableCSM	237
sa::optRegisterSetupCallback	238
sa::optRun	238
sa::optSetParameterConstraint	239
sa::pick	240
sa::plotExpressions	242
sa::plotOutputs	244
sa::printResults	245
sa::processSigma	246
sa::pushToDesign	246
sa::qfile_system_watcher	247
sa::ralgnoreResultTypes	248
sa::reevaluateAllMeasures	248
sa::renameCornerParameter	249
sa::renameHistoryPoint	249
sa::resolveDesignVariables	250
sa::run	250
sa::runIterations	251
sa::runFailedIterations	252
sa::saveChartImages	252
sa::saveCornersSetup	253
sa::saveDataDir	254
sa::saveDesignParamsSetup	255
sa::saveDesVars	255

Contents

sa::saveDesVarsToText	256
sa::saveHistoryDir	257
sa::saveImages	258
sa::saveObjectToFile	258
sa::saveOutputs	259
sa::saveResultDir	260
sa::saveScript	260
sa::saveSessionSetup	261
sa::saveState	262
sa::saveTestSuite	263
sa::saveTestSuiteAs	264
sa::saveTestSuiteResults	265
sa::sciToEng	265
sa::selectionCancelled	266
sa::selectChartAxes	266
sa::selectChart	267
sa::selectOutputs	268
sa::selectTandemGroup	268
sa::sendMessage	269
sa::setActiveHistoryPoint	269
sa::setActiveTestbench	270
sa::setCornerParamValue	270
sa::setResultsAnalyzerOutputSet	271
sa::setRunDir	272
sa::showAboutPrimeWave	272
sa::showAceScripts	273
sa::showAdvancedAnnotations	273
sa::showAgingSetup	274
sa::showAimScripts	274
sa::showAnalysisOptions	274
sa::showAnalyzeResults	276
sa::showBgNetlistAndRunProgressDialog	277
sa::showChainingSetup	277
sa::showChartAxisDialog	278
sa::showCheckResults	278
sa::showCompareResults	279
sa::showComparisonSetup	280
sa::showConsole	280
sa::showConvergenceAids	281

Contents

sa::showCopyTestbenchCategories	281
sa::showCornersSetup	281
sa::showCreateTestbench	282
sa::showCustomCommands	282
sa::showDesignParametersSetup	283
sa::showDesignWindow	283
sa::showDeviceCheckResults	284
sa::showDeviceCheckSetup	284
sa::showDigitalAnalyzerOptions	285
sa::showDigitalDebugger	285
sa::showDigitalFileOptions	286
sa::showDigitalTiming	286
sa::showEditAnalyses	286
sa::showEditDescription	287
sa::showEditVariables	287
sa::showEnvironmentOptions	288
sa::showExportCorners	289
sa::showExportResultsCompare	289
sa::showExportSessionReport	289
sa::showExtremeCases	290
sa::showGlobalJobOptions	290
sa::showGlobalSimulatorOptions	291
sa::showImportCorners	292
sa::showImportDigitalFiles	292
sa::showIncludeDspfOptions	292
sa::showIncludeFiles	293
sa::showIncludeGroupDef	293
sa::showIncludeIbisEbdPkgOptions	294
sa::showJobMonitor	295
sa::showLoadDesVars	295
sa::showLoadMacros	295
sa::showLoadOutputs	296
sa::showLoadResults	296
sa::showLoadState	297
sa::showLoadStateIntoNewTestbench	297
sa::showLoadStateToComparisonTable	298
sa::showLoadTestSuiteResults	298
sa::showMacros	298
sa::showMigrateResults	299

Contents

sa::showMixedSignalOptions	299
sa::showModelFiles	300
sa::showModelGroupDef	300
sa::showMonteCarlo	301
sa::showMOSRAResults	302
sa::showMOSRASetup	302
sa::showMSIPAceScripts	302
sa::showNoiseSummary	303
sa::showOpenTestSuite	303
sa::showOpPoints	304
sa::showOutputSetup	304
sa::showParametricAnalyses	304
sa::showParasiticBackAnnotation	305
sa::showPlotScalars	306
sa::showPromoteDatabase	306
sa::showPostRunProcs	307
sa::showPreRunProcs	307
sa::showPromptParameters	308
sa::showResultOptions	309
sa::showResultsUpdater	310
sa::showResultsView	310
sa::showSaveDesVars	311
sa::showSaveMacros	311
sa::showSaveOptions	312
sa::showSaveOutputs	312
sa::showSaveResults	312
sa::showSaveScript	313
sa::showSaveState	313
sa::showSaveTestSuiteAs	314
sa::showSaveTestSuiteResults	314
sa::showSelectDesign	315
sa::showSelectSimulator	315
sa::showSessionOptions	316
sa::showSequentialRun	316
sa::showSpfResults	317
sa::showStimulusGenerator	317
sa::showStimulusGroupDef	318
sa::showTerminal	318
sa::showTestList	319

Contents

sa::showTestSuiteOptions	319
sa::showTimestampDashboard	320
sa::showWaveformViewer	320
sa::showWorstCaseAnalysis	321
sa::simulationDone	321
sa::sortResultsViewTree	321
sa::stop	322
sa::syncRemoteResults	323
sa::updateCDPLClass	323
sa::updateCDPLMaster	324
sa::updateResultsViewTitle	324
sa::updateMeasurementSummaries	324
sa::updateProgressBar	325
sa::updateSelectionObj	326
isa::computeInterfaceElements	327
isa::createNetlist	328
isa::deleteResults	328
isa::netlistAndRun	329
isa::run	329
isa::stop	330
Enumerations	331
Objects	331
saAnalysisDef	332
saConvergenceAid	333
saCorner	333
saCornerParamDef	334
saCornersSetup	334
saDesignVariable	335
saExpressionDef	335
saIncludeFile	337
saModelFile	337
saOption	337
saOptionDef	338
saOptionGroup	339
saOutput	340
saOutputs	340
saPair	341
saPair	341

Contents

saResultFile	341
saResults	342
saResultsMap	342
saSelection	343
saSelectionDef	343
saSelectionDefGroup	344
saSession	345
saSimulator	345
saSweep	346
saSweepRange	347
saTestbench	348
wfSignal	348
Preferences	349
Simulation and Analysis Environment Preferences (saA2D* through saFineSimPro*)	350
Simulation and Analysis Environment Preferences (saGen* through saOutput*)	478
Simulation and Analysis Environment Preferences (saParam* through saPrimeSimVCS*)	560
Simulation and Analysis Environment Preferences (saPrimeSimXA* through saSpectre*)	1033
Simulation and Analysis Environment Preferences (saSt* through saXA*) . .	1279
PrimeWave Design Environment Preference Examples	1307
saUseInternalExternalSpec	1307
 2. Waveform Tcl	 1309
Commands	1309
wf::addFunctionsToCategory	1312
wf::appendData	1312
wf::clearStoredExpressionResults	1314
wf::closeFile	1314
wf::closeViewer	1316
wf::closeViewerTabs	1316
wf::createCustomPlotMode	1317
wf::createDataAccessFunctionMapping	1317
wf::createExpression	1319
wf::createExpressionValue	1321
wf::createFunction	1321
wf::createFunctionArgument	1323

Contents

wf::createFunctionArgumentGroup	1324
wf::createFunctionCategory	1325
wf::createMacro	1325
wf::createGraphicalAnnotation	1326
wf::createScan	1327
wf::createSignal	1329
wf::dmMeasure	1330
wf::exportPlots	1332
wf::exportPrefs	1333
wf::expr	1334
wf::extractTrace	1335
wf::findExpressionMappings	1336
wf::findParams	1338
wf::findSignal	1338
wf::findStoredExpressionResult	1340
wf::firstSignal	1341
wf::firstWDF	1341
wf::getAllData	1341
wf::getExpressionInputs	1342
wf::getFileInfo	1343
wf::getFunctionCategories	1343
wf::getFunctions	1344
wf::getMacros	1345
wf::getPrefValue	1345
wf::getSignalAttribute	1346
wf::getViewerGeometry	1346
wf::hspiceMeasureFile	1347
wf::importPrefs	1348
wf::isExpression	1348
wf::isViewerReady	1349
wf::isViewerRunning	1349
wf::launchViewer	1350
wf::loadPrefs	1352
wf::loadSession	1352
wf::loadSignals	1353
wf::nextSignal	1353
wf::nextWDF	1354
wf::openFile	1354
wf::plotExpressions	1357

Contents

wf::plotWaveforms	1358
wf::raiseViewer	1360
wf::redrawViewer	1361
wf::removeFunctionsFromCategory	1361
wf::savePrefs	1362
wf::saveSession	1363
wf::saveSignal	1363
wf::scan	1365
wf::setDataDirectory	1367
wf::setPrefValue	1367
wf::setReaderAPIPrefValue	1368
wf::setSignalAttribute	1368
wf::storeExpressionResult	1369
wf::transformParamValue	1369
wf::unloadSignal	1370
wf::updateViewerKeyBindings	1370
wf::updateViewerPrefs	1371
wf::viewerExited	1371
Enumerations	1371
Objects	1372
wfDataFile	1373
wfFunction	1374
wfFunctionArgument	1374
wfFunctionArgumentGroup	1375
wfFunctionCategory	1376
wfMacro	1376
wfScan	1376
wfSignal	1377
Preferences	1377

About This Manual

The *PrimeWave™ Design Environment Tcl Reference Manual* covers PrimeWave Design Environment Tcl commands, objects, and preferences.

This preface includes the following sections:

- [New in This Release](#)
- [Related Products, Publications, and Trademarks](#)
- [Conventions](#)
- [Customer Support](#)
- [Statement on Inclusivity and Diversity](#)

New in This Release

Information about new features, enhancements, and changes, known limitations, and resolved Synopsys Technical Action Requests (STARs) is available in the PrimeWave Design Environment Release Notes on the SolvNetPlus site.

Related Products, Publications, and Trademarks

For additional information about the PrimeWave Design Environment tool, see the documentation on the Synopsys SolvNetPlus support site at the following address:

<https://solvnetplus.synopsys.com>

You might also want to see the documentation for the following related Synopsys products:

Synopsys® PrimeWave Design Environment

PrimeSim™ Continuum

PrimeSim™

PrimeSim™ Pro

PrimeSim™ SPICE

PrimeSim™ HSPICE®

PrimeSim™ XA

PrimeSim™ CCK
PrimeSim™ MOSRA
PrimeSim™ EMIR
VCS® PrimeSim™ AMS
Synopsys® Custom Router
Synopsys® CustomSim™
Synopsys® CustomSim™ NanoSim®
Synopsys® CustomSim™ XA
Synopsys® Custom WaveView™
Synopsys® IC Compiler™
Synopsys® FineSim®
Synopsys® Fusion Compiler™
Synopsys® HSPICE®
Synopsys® IC Validator
Synopsys® StarRC™
Synopsys® VCS®
Synopsys® Verdi®
Cadence® Spectre® Circuit Simulator
Cadence® Virtuoso® Spectre®
MathWorks® MATLAB
Mentor Graphics® Calibre®
Mentor Graphics® Calibre Interactive®

Conventions

The following conventions are used in Synopsys documentation.

Convention	Description
Courier	Indicates syntax, such as <code>write_file</code> .

Convention	Description
<i>Courier italic</i>	Indicates a user-defined value in syntax, such as <code>write_file design_list</code>
Courier bold	Indicates user input—text you type verbatim—in examples, such as <code>prompt> write_file top</code>
Purple	• Within an example, indicates information of special interest. • Within a command-syntax section, indicates a default, such as <code>include_enclosing = true false</code>
[]	Denotes optional arguments in syntax, such as <code>write_file [-format fmt]</code>
...	Indicates that arguments can be repeated as many times as needed, such as <code>pin1 pin2 ... pinN.</code>
	Indicates a choice among alternatives, such as <code>low medium high</code>
\	Indicates a continuation of a command line.
/	Indicates levels of directory structure.
Bold	Indicates a graphical user interface (GUI) element that has an action associated with it.
Edit > Copy	Indicates a path to a menu command, such as opening the Edit menu and choosing Copy .
Ctrl+C	Indicates a keyboard combination, such as holding down the Ctrl key and pressing C.

Customer Support

Customer support is available through SolvNetPlus.

Accessing SolvNetPlus

The SolvNetPlus site includes a knowledge base of technical articles and answers to frequently asked questions about Synopsys tools. The SolvNetPlus site also gives you access to a wide range of Synopsys online services including software downloads, documentation, and technical support.

To access the SolvNetPlus site, go to the following address:

<https://solvnetplus.synopsys.com>

If prompted, enter your user name and password. If you do not have a Synopsys user name and password, follow the instructions to sign up for an account.

If you need help using the SolvNetPlus site, click REGISTRATION HELP in the top-right menu bar.

Contacting Customer Support

To contact Customer Support, go to <https://solvnetplus.synopsys.com>.

Statement on Inclusivity and Diversity

Synopsys is committed to creating an inclusive environment where every employee, customer, and partner feels welcomed. We are reviewing and removing exclusionary language from our products and supporting customer-facing collateral. Our effort also includes internal initiatives to remove biased language from our engineering and working environment, including terms that are embedded in our software and IPs. At the same time, we are working to ensure that our web content and software applications are usable to people of varying abilities. You may still find examples of non-inclusive language in our software or documentation as our IPs implement industry-standard specifications that are currently under review to remove exclusionary language.

1

Simulation and Analysis Environment Tcl

This chapter lists commands, enumerations, objects, and preferences in the PrimeWave Design Environment Tcl sa namespace. This namespace provides Tcl for PrimeWave Design Environment operations, including design simulation and waveform analysis.

For details, see:

- [Commands](#)
- [Enumerations](#)
- [Objects](#)
- [Preferences](#)

Commands

Interactive commands are listed after non-interactive commands in the Commands section.

The commands covered are:

- [sa::addAimScript](#)
- [sa::addArgumentsToFlowAction](#)
- [sa::addArgumentsToFlowFile](#)
- [sa::addAxisToChart](#)
- [sa::addCorner](#)
- [sa::addCornerToChart](#)
- [sa::addCustomCategories](#)
- [sa::addDeviceParameters](#)
- [sa::addMSIPAceScript](#)
- [sa::addResultFile](#)

- `sa::addStatisticalInfo`
- `sa::addSweepFile`
- `sa::addTestbenchToChart`
- `sa::addToOptionGroup`
- `sa::aging_Analysis_Check_Setups`
- `sa::annotateInterfaceElements`
- `sa::attachToVDRADB`
- `sa::autoscaleChart`
- `sa::avaSimulationDone`
- `sa::backannotateResults`
- `sa::backupRunDir`
- `sa::cacheTestbenchToSession`
- `sa::cancelPick`
- `sa::clearAnnotations`
- `sa::clearProbes`
- `sa::cloneTestbench`
- `sa::cloneTestbenchToTestSuite`
- `sa::configureChartsWindow`
- `sa::copyCorner`
- `sa::copyDesVars`
- `sa::copyScriptFromWorkDir`
- `sa::copyTestbenchCategories`
- `sa::create3DICModelGroup`
- `sa::createA2DInterfaceElement`
- `sa::createAceScript`
- `sa::createActiveNetsAnalysis`
- `sa::createActiveNetsFile`

- [sa::createAnalysis](#)
- [sa::createAnalysisDef](#)
- [sa::createAttribute](#)
- [sa::createBackAnnotationFile](#)
- [sa::createChainParameter](#)
- [sa::createChartsWindow](#)
- [sa::createConnectionModule](#)
- [sa::createConnectionRule](#)
- [sa::createConnectRuleElement](#)
- [sa::createConvergenceAid](#)
- [sa::createCornerParameterDef](#)
- [sa::createCornersSetup](#)
- [sa::createCustomCommand](#)
- [sa::createD2AInterfaceElement](#)
- [sa::createDataRow](#)
- [sa::createGroupDef](#)
- [sa::createGroupDefItem](#)
- [sa::createGroupSection](#)
- [sa::createDesignParametersSetup](#)
- [sa::createDesignVariable](#)
- [sa::createDeviceCheckElement](#)
- [sa::createDeviceCheckExpression](#)
- [sa::createDeviceCheckOptions](#)
- [sa::createDeviceCheckSize](#)
- [sa::createDeviceCheckSubckt](#)
- [sa::createDigitalAnalyzerOptions](#)
- [sa::createDigitalAnalyzerOptionsGroup](#)

- [sa::createDigitalFileOptions](#)
- [sa::createDigitalTiming](#)
- [sa::createE2NInterfaceElement](#)
- [sa::createE2RInterfaceElement](#)
- [sa::createEMDB](#)
- [sa::createExpressionDef](#)
- [sa::createExternalImagePath](#)
- [sa::createFlowFile](#)
- [sa::createForceDigitalNet](#)
- [sa::createHistogramChart](#)
- [sa::createIncludeFile](#)
- [sa::createIncludeGroup](#)
- [sa::createLayoutParasitics](#)
- [sa::createMeasurementSummary](#)
- [sa::createMixedSignalOptions](#)
- [sa::createModelFile](#)
- [sa::createModelGroup](#)
- [sa::createModelGroupDef](#)
- [sa::createModelGroupSection](#)
- [sa::createMonteCarlo](#)
- [sa::createN2EInterfaceElement](#)
- [sa::createNetlist](#)
- [sa::createNodeResistanceOverride](#)
- [sa::createObject](#)
- [sa::createOptionDef](#)
- [sa::createOptionGroup](#)
- [sa::createOptionLimit](#)

- [sa::createOrGetDialog](#)
- [sa::createOutput](#)
- [sa::createPair](#)
- [sa::createProbe](#)
- [sa::createQQChart](#)
- [sa::createR2EInterfaceElement](#)
- [sa::createReport](#)
- [sa::createResistanceMapConfig](#)
- [sa::createResultsInfo](#)
- [sa::createResultsMap](#)
- [sa::createResultsXML](#)
- [sa::createRunDir](#)
- [sa::createRunScript](#)
- [sa::createSaveOptionsInstance](#)
- [sa::createScatterChart](#)
- [sa::createSDFConfig](#)
- [sa::createSelectionDef](#)
- [sa::createSelectionDefGroup](#)
- [sa::createSelectionGroupDef](#)
- [sa::createSession](#)
- [sa::createSignalObj](#)
- [sa::createSimulator](#)
- [sa::createSpecification](#)
- [sa::createStimulusGroup](#)
- [sa::createStringSet](#)
- [sa::createSweep](#)
- [sa::createSweepDir](#)

- [sa::createSweepRange](#)
- [sa::createTBCDPLClass](#)
- [sa::createTestbench](#)
- [sa::createVariableGroup](#)
- [sa::createWorstCaseCornerCondition](#)
- [sa::createVDRADB](#)
- [sa::deleteHistoryPoint](#)
- [sa::deleteJobClass](#)
- [sa::deleteOutput](#)
- [sa::deleteResults](#)
- [sa::deleteSelected](#)
- [sa::deleteTBCDPLClass](#)
- [sa::deleteTestSuiteResults](#)
- [sa::directPlot](#)
- [sa::displayLog](#)
- [sa::displayNetlist](#)
- [sa::DSPFPatch](#)
- [sa::dumpResultsView](#)
- [sa::editDesVars](#)
- [sa::editNetlist](#)
- [sa::editOutputs](#)
- [sa::emitRefreshIterativeResultsTable](#)
- [sa::emitRefreshMeasurementSummaryDialog](#)
- [sa::emitSimulationDone](#)
- [sa::emitUpdateIterativeResultsWindow](#)
- [sa::evaluateAceScripts](#)
- [sa::evaluateExpressions](#)

- `sa::evaluateMonteCarloScalarExpressions`
- `sa::executeFlowAction`
- `sa::executeDeviceGroupAction`
- `sa::exportAndLaunchVerdiCov`
- `sa::exportChart`
- `sa::exportChartImage`
- `sa::exportCopyNetlist`
- `sa::exportCSVFromResultsViewer`
- `sa::exportGroupDef`
- `sa::exportModelGroupDef`
- `sa::exportReportHtml`
- `sa::exportResultData`
- `sa::exportResultDataBySpec`
- `sa::exportResultsViewsToCSV`
- `sa::exportScript`
- `sa::exportSessionReport`
- `sa::exportToCSV`
- `sa::exportToVerdiCov`
- `sa::showExternalImages`
- `sa::findActiveHistoryPoint`
- `sa::findActiveTestbench`
- `sa::findClosestIterations`
- `sa::findDesignVariableGroupDefs`
- `sa::findDuplicates`
- `sa::findId`
- `sa::findIncludeGroupDef`
- `sa::findIterations`

- [sa::findModelGroupDef](#)
- [sa::findModelLanguage](#)
- [sa::findModuleName](#)
- [sa::findNameMap](#)
- [sa::findSaveSignals](#)
- [sa::findSessionName](#)
- [sa::findSignalAlterations](#)
- [sa::findStimulusGroupDef](#)
- [sa::findVariablesFromNetlist](#)
- [sa::findWindow](#)
- [sa::findWorstCornerName](#)
- [sa::flattenTestbench](#)
- [sa::formatExpression](#)
- [sa::formatNumeric](#)
- [sa::generateCorners](#)
- [sa::generateReports](#)
- [sa::getAnalyses](#)
- [sa::getAnalysisDefs](#)
- [sa::getBackupRunDirs](#)
- [sa::getCDPLClass](#)
- [sa::getCDPLMember](#)
- [sa::getCornerParameters](#)
- [sa::getCorners](#)
- [sa::getCumulativeFrequency](#)
- [sa::getData](#)
- [sa::getDatabaseDir](#)
- [sa::getDataDir](#)

- [sa::getDesignVariablesGroupVar](#)
- [sa::getDesignWindows](#)
- [sa::getEMNetCurrents](#)
- [sa::getExpressionContext](#)
- [sa::getFailedIterations](#)
- [sa::getFlowFileDependencyTree](#)
- [sa::getFlowFileModificationTime](#)
- [sa::getGoalTypeForSource](#)
- [sa::getHistoryDataTestbench](#)
- [sa::getHistoryResultsDir](#)
- [sa::getMeasurementSets](#)
- [sa::getMeasurementStatistics](#)
- [sa::getMeasuresInfo](#)
- [sa::getMeasureValue](#)
- [sa::getModelGroupDefs](#)
- [sa::getNetlistDir](#)
- [sa::getNetlistIncludeFiles](#)
- [sa::getNetlistModelFiles](#)
- [sa::getNetlistVariables](#)
- [sa::getPickedObjects](#)
- [sa::getRaiGnoredResultTypes](#)
- [sa::getRefVal](#)
- [sa::getReportElement](#)
- [sa::getReports](#)
- [sa::getResultFiles](#)
- [sa::getResults](#)
- [sa::getResultsDir](#)

- [sa::getResultsViewerData](#)
- [sa::getResultTypes](#)
- [sa::getRunDir](#)
- [sa::getRunScriptPath](#)
- [sa::getScalarValuesData](#)
- [sa::getSelected](#)
- [sa::getSessions](#)
- [sa::getSimulators](#)
- [sa::getSimulatorSweepPoints](#)
- [sa::getSimulatorSweepsInfo](#)
- [sa::getStates](#)
- [sa::getSweepPoints](#)
- [sa::getTerminalInfo](#)
- [sa::getTestbenches](#)
- [sa::getTestSuiteStorage](#)
- [sa::getTopEquivalentNet](#)
- [sa::getVDRCNetVoltages](#)
- [sa::getWindowType](#)
- [sa::hasMonteCarloResults](#)
- [sa::importGroupDef](#)
- [sa::importModelGroupDef](#)
- [sa::initializeAttributes](#)
- [sa::isCornersSetupEnabled](#)
- [sa::isResultAvailable](#)
- [sa::isSweepsEnabled](#)
- [sa::loadCornersSetup](#)
- [sa::loadDesVarsFromText](#)

- `sa::loadObjectFromFile`
- `sa::loadOutputs`
- `sa::loadResultsDir`
- `sa::loadSimOptions`
- `sa::loadState`
- `sa::loadTestSuite`
- `sa::lockHistoryPoint`
- `sa::makePrefLabel`
- `sa::makePrefName`
- `sa::map`
- `sa::mapDesignVariableValue`
- `sa::mergeCornersSetup`
- `sa::migrateResults`
- `sa::netlistAndRun`
- `sa::openResultsMap`
- `sa::openSimulationConsole`
- `sa::openTextFiles`
- `sa::openWaveView`
- `sa::optAddParameter`
- `sa::optGetFinishedSampleReport`
- `sa::optGetFailedSampleReport`
- `sa::optRegisterResultsTableCSM`
- `sa::optRegisterSetupCallback`
- `sa::optRun`
- `sa::optSetParameterConstraint`
- `sa::pick`
- `sa::plotExpressions`

- [sa::plotOutputs](#)
- [sa::printResults](#)
- [sa::processSigma](#)
- [sa::pushToDesign](#)
- [sa::qfile_system_watcher](#)
- [sa::raIgnoreResultTypes](#)
- [sa::reevaluateAllMeasures](#)
- [sa::renameCornerParameter](#)
- [sa::renameHistoryPoint](#)
- [sa::resolveDesignVariables](#)
- [sa::run](#)
- [sa::runIterations](#)
- [sa::runFailedIterations](#)
- [sa::saveChartImages](#)
- [sa::saveCornersSetup](#)
- [sa::saveDataDir](#)
- [sa::saveDesignParamsSetup](#)
- [sa::saveDesVars](#)
- [sa::saveDesVarsToText](#)
- [sa::saveHistoryDir](#)
- [sa::saveImages](#)
- [sa::saveObjectToFile](#)
- [sa::saveOutputs](#)
- [sa::saveResultDir](#)
- [sa::saveScript](#)
- [sa::saveSessionSetup](#)
- [sa::saveState](#)

- [sa::saveTestSuite](#)
- [sa::saveTestSuiteAs](#)
- [sa::saveTestSuiteResults](#)
- [sa::sciToEng](#)
- [sa::selectionCancelled](#)
- [sa::selectChartAxes](#)
- [sa::selectChart](#)
- [sa::selectOutputs](#)
- [sa::selectTandemGroup](#)
- [sa::sendMessage](#)
- [sa::setActiveHistoryPoint](#)
- [sa::setActiveTestbench](#)
- [sa::setCornerParamValue](#)
- [sa::setResultsAnalyzerOutputSet](#)
- [sa::setRunDir](#)
- [sa::showAboutPrimeWave](#)
- [sa::showAceScripts](#)
- [sa::showAdvancedAnnotations](#)
- [sa::showAgingSetup](#)
- [sa::showAimScripts](#)
- [sa::showAnalysisOptions](#)
- [sa::showAnalyzeResults](#)
- [sa::showBgNetlistAndRunProgressDialog](#)
- [sa::showChainingSetup](#)
- [sa::showChartAxisDialog](#)
- [sa::showCheckResults](#)
- [sa::showCompareResults](#)

- [sa::showComparisonSetup](#)
- [sa::showConsole](#)
- [sa::showConvergenceAids](#)
- [sa::showCopyTestbenchCategories](#)
- [sa::showCornersSetup](#)
- [sa::showCreateTestbench](#)
- [sa::showCustomCommands](#)
- [sa::showDesignParametersSetup](#)
- [sa::showDesignWindow](#)
- [sa::showDeviceCheckResults](#)
- [sa::showDeviceCheckSetup](#)
- [sa::showDigitalAnalyzerOptions](#)
- [sa::showDigitalDebugger](#)
- [sa::showDigitalFileOptions](#)
- [sa::showDigitalTiming](#)
- [sa::showEditAnalyses](#)
- [sa::showEditDescription](#)
- [sa::showEditVariables](#)
- [sa::showEnvironmentOptions](#)
- [sa::showExportCorners](#)
- [sa::showExportResultsCompare](#)
- [sa::showExportSessionReport](#)
- [sa::showExtremeCases](#)
- [sa::showGlobalJobOptions](#)
- [sa::showGlobalSimulatorOptions](#)
- [sa::showImportCorners](#)
- [sa::showImportDigitalFiles](#)

- `sa::showIncludeDspfOptions`
- `sa::showIncludeFiles`
- `sa::showIncludeGroupDef`
- `sa::showIncludeIbisEbdPkgOptions`
- `sa::showJobMonitor`
- `sa::showLoadDesVars`
- `sa::showLoadMacros`
- `sa::showLoadOutputs`
- `sa::showLoadResults`
- `sa::showLoadState`
- `sa::showLoadStateIntoNewTestbench`
- `sa::showLoadStateToComparisonTable`
- `sa::showLoadTestSuiteResults`
- `sa::showMacros`
- `sa::showMigrateResults`
- `sa::showMixedSignalOptions`
- `sa::showModelFiles`
- `sa::showModelGroupDef`
- `sa::showMonteCarlo`
- `sa::showMOSRAResults`
- `sa::showMOSRASetup`
- `sa::showMSIPaceScripts`
- `sa::showNoiseSummary`
- `sa::showOpenTestSuite`
- `sa::showOpPoints`
- `sa::showOutputSetup`
- `sa::showParametricAnalyses`

- [sa::showParasiticBackAnnotation](#)
- [sa::showPlotScalars](#)
- [sa::showPromoteDatabase](#)
- [sa::showPostRunProcs](#)
- [sa::showPreRunProcs](#)
- [sa::showPromptParameters](#)
- [sa::showResultOptions](#)
- [sa::showResultsUpdater](#)
- [sa::showResultsView](#)
- [sa::showSaveDesVars](#)
- [sa::showSaveMacros](#)
- [sa::showSaveOptions](#)
- [sa::showSaveOutputs](#)
- [sa::showSaveResults](#)
- [sa::showSaveScript](#)
- [sa::showSaveState](#)
- [sa::showSaveTestSuiteAs](#)
- [sa::showSaveTestSuiteResults](#)
- [sa::showSelectDesign](#)
- [sa::showSelectSimulator](#)
- [sa::showSessionOptions](#)
- [sa::showSequentialRun](#)
- [sa::showSpfResults](#)
- [sa::showStimulusGenerator](#)
- [sa::showStimulusGroupDef](#)
- [sa::showTerminal](#)
- [sa::showTestList](#)

- [sa::showTestSuiteOptions](#)
- [sa::showTimestampDashboard](#)
- [sa::showWaveformViewer](#)
- [sa::showWorstCaseAnalysis](#)
- [sa::simulationDone](#)
- [sa::sortResultsViewTree](#)
- [sa::stop](#)
- [sa::syncRemoteResults](#)
- [sa::updateCDPLClass](#)
- [sa::updateCDPLMaster](#)
- [sa::updateResultsViewTitle](#)
- [sa::updateMeasurementSummaries](#)
- [sa::updateProgressBar](#)
- [sa::updateSelectionObj](#)
- [isa::computeInterfaceElements](#)
- [isa::createNetlist](#)
- [isa::deleteResults](#)
- [isa::netlistAndRun](#)
- [isa::run](#)
- [isa::stop](#)

sa::addAimScript

Description

Adds an Aim script for the given testbench.

Syntax

```
sa::addAimScript <name: string> -testbench <saTestbench> [-enabled <string>]
```

Returns

<saObject> : Aim Script object

Arguments

name

Aim Script path.

-testbench

PrimeWave Design Environment testbench.

-enabled

AIM Script enabled status. Default: true

sa::addArgumentsToFlowAction

Description

Add Tcl arguments to an saFlowAction proc.

Syntax

```
sa::addArgumentsToFlowAction <args: [string]> -to <saFlowAction>
```

Returns

<none>

Arguments

args

Argument collection.

-to

File to which to add the arguments.

sa::addArgumentsToFlowFile

Description

Add Tcl arguments to an saFlowFile filePath procedure.

Syntax

```
sa::addArgumentsToFlowFile <args: [string]> -to <saFlowFile>
```

Returns

<none>

Arguments

args

Argument collection.

-to

File in which to add the arguments.

sa::addAxisToChart

Description

This command adds an axis to a PrimeWave Design Environment data mining charts window.

Syntax

```
sa::addAxisToChart <window: giWindow | int> -testbench <string> -name  
<string> -goalType <string> [-poor <string>] [-spec <string>] [-poorLow  
<string>] [-poorHigh <string>] [-specLow <string>] [-specHigh <string>]
```

Arguments

window

The charts window.

-testbench

The testbench name.

-name

Name of the axis.

-goalType

Axis goal type. Valid values are: "Greater Than", "Less Than", "Range", "Exact".

-poor

Poor value for the axis.

-spec

Spec value for the axis.

-poorLow

Low value for poor (for Range goals only).

`-poorHigh`

High value for poor (for Range goals only).

`-specLow`

Low value for spec (for Range goals only).

`-specHigh`

High value for spec (for Range goals only).

sa::addCorner

Adds a new corner

Syntax

```
sa::addCorner <name: string> -cornersSetup <saCornersSetup> [-index  
  <string>] [-mapInvalidChars <bool>]
```

Returns

`<saCorner>` : Corner

Arguments

`name`

Corner name

`-cornersSetup`

Corners setup

`-index`

Index at which to add the new corner (Currently only '0' or 'end' are supported)
(Default is: end)

`-mapInvalidChars`

Maps all corner name invalid chars to _ (Default is: false)

sa::addCornerToChart

Description

This command adds a corner to a PrimeWave Design Environment data mining charts window.

Syntax

```
sa::addCornerToChart <window: giWindow | int> -testbench <string> -name  
  <string> -dataValues [<string>] -variableValues [<string>]
```

Arguments

window

The charts window.

-testbench

The testbench name.

-name

The corner name.

-dataValues

Data values.

-variableValues

The corner variable name value pairs.

sa::addCustomCategories

Description

Adds custom categories.

Syntax

```
sa::addCustomCategories <customCategories: string> [-simulator  
  <saSimulator>] [-initProc <string>]
```

Arguments

customCategories

List of custom categories.

-simulator

Simulator for custom category.

-initProc

Procedure to initialize custom category.

sa::addDeviceParameters

Adds a new device with parameters

Syntax

```
sa::addDeviceParameters <instance: string> (-designParametersSetup  
  <saDesignParametersSetup> | -testbench <saTestbench> | -session  
  <saSession>) [-cellview <dmCellView>] [-params <string>] [-groupName  
  <string>] [-sync <bool>] [-refresh <bool>]
```

Returns

<saInstanceParameters> : Instance Parameters

Arguments

instance

Instance whose parameters are to be updated

-cellview

Cellview in which the instance parameters are to be added

-params

List of parameter name / value pairs. (Default is:)

-designParametersSetup

Design parameters setup

-testbench

Testbench

-session

Session in which to add device parameters

-groupName

The device group name (Default is:)

-sync

If true, create the variables for the parameters and also synchronize with group
(Default is: false)

-refresh

If true, the design parameterization dialog is refreshed with new device
parameters (Default is: false)

sa::addMSIPAceScript

Add an MSIP ACE Script for given testbench

Syntax

```
sa::addMSIPAceScript <name: string> -testbench <saTestbench> [-enabled  
    <string>] [-gui <string>]
```

Returns

<saObject> : MSIP ACE Script object

Arguments

name

ACE Script path

-testbench

SAE Testbench

-enabled

ACE Script enabled status (Default is: true)

-gui

Run un GUI mode (Default is: true)

sa::addResultFile

Description

Adds a new saResultFile to the saResults.

The integrator will use db::setAttr for specifying the values for the other attributes of the saResultFile.

The integrator will use sa::createAttribute for defining any new attributes to the saResultFile.

Syntax

```
sa::addResultFile <resultfile: string> -type <string> -results  
    <saResults> [-dataType <string>]
```

Returns

New result file object ([saResultFile](#)).

Arguments

`<string>`

The simulation output file name.

`-type <string>`

The result type.

`-results saResults`

The `<saResults>` object corresponds to the simulation results directory.

`-dataType`

The data type.

sa::addStatisticalInfo

Adds a new corner

Syntax

```
sa::addStatisticalInfo -corner <saCorner> -cornersSetup <saCornersSetup>  
-filepath <string> -monteIndex <string>
```

Returns

`<saCorner>` : Corner

Arguments

`-corner`

Corner object

`-cornersSetup`

Corners setup

`-filepath`

path to .mc0

`-monteIndex`

sample id of monte

sa::addSweepFile

Adds sweep file to the saResultFile object

Syntax

```
sa::addSweepFile -sweepFile <string> -resultFile <saResultFile> [-noparam  
    <int>]
```

Returns

<saSweepFile> : Result sweep file object

Arguments

-sweepFile

Sweep Filename

-resultFile

Result file

-noparam

needn't add params field (Default is: 0)

sa::addTestbenchToChart

Description

This command adds a testbench to a PrimeWave Design Environment data mining charts window.

Syntax

```
sa::addTestbenchToChart <window: giWindow | int> -testbench <string>
```

Arguments

window

The charts window.

-testbench

The testbench name.

sa::addToOptionGroup

Description

This command adds children to an option group.

Syntax

```
sa::addToOptionGroup <optionGroup: saOptionGroup> [-optionNames  
  [<string>]] [-optionGroups [<saOptionGroup>]]
```

Returns

Same option group as passed in (saOptionGroup).

Arguments

-optionGroup

Option group to include new items.

-optionNames <string>

Option names to include in new group.

-optionGroups

Option groups to include in new group.

sa::aging_Analysis_Check_Setups

Return true if success, otherwise false

Syntax

```
sa::aging_Analysis_Check_Setups -session <saSession> -of <string>
```

Returns

<string> : true or false

Arguments

-session

session

-of

of

sa::annotateInterfaceElements

Description

Annotates interface elements.

Syntax

```
sa::annotateInterfaceElements (-window <giWindow | int> | -testbench  
    <saTestbench>) [-show <bool>]
```

Returns

<none>

Arguments

-window

PrimeWave Design Environment main window.

-testbench

Testbench.

-show

Show or hide the interface elements.

Default is: 1.

sa::attachToVDRcdb

Description

Attach to the sqlite3 database file specified in the -filePath argument, and return an object which can be used as the -db argument to sa::getVDRcNetVoltages.

Syntax

```
sa::attachToVDRcdb -filePath <string>
```

Returns

<string>: object which can be used as the -db argument to sa::getVDRcNetVoltages

Arguments

-filePath

Path to a vdrc.db sqlite3 database file.

sa::autoscaleChart

Description

This command auto-scales the charts in a PrimeWave Design Environment data mining charts window.

Syntax

```
sa::autoscaleChart <window: giWindow | int> -testbench <string>
```

Arguments

window

The charts window.

-testbench

The testbench name.

sa::avaSimulationDone

Procedure to be executed after an AVA job finishes.

Syntax

```
sa::avaSimulationDone <job: xtJob>
```

Returns

<none>

Arguments

job

AVA simulation job.

sa::backannotateResults

Description

This command backannotates the specified data type onto the design. The design window is opened if it is not already open.

Syntax

```
sa::backannotateResults <displayType: string> -window <string>
```

Arguments

<string>

Data type. The following values are valid:

- Simulation.
- DC Node Voltage.

- Tran Node Voltage.
- DC Oppoint.
- Tran Oppoint.

```
-window giWindow | <int>
```

The PrimeWave Design Environment window object or id.

Errors

- No testbench is defined in this window.
- The window is not a PrimeWave Design Environment window.
- Data for given analysis type is not available.
- Design window cannot be opened.
- Invalid data type specified.

Examples

```
# Backannotate results for PrimeWave Design Environment window 6 for  
  given display type  
# Possible values for displayType:  
# "DC Node Voltage"  
"Tran Node Voltage"  
"DC Oppoint"  
"Tran Oppoint"  
set displayType "DC Oppoint"  
sa::backannotateResults $displayType -window 6  
# This will open PrimeWave Design Environment design in a schematic  
  window and backannotate results.
```

sa::backupRunDir

Description

This command backs up the directory structure for a testbench.

Syntax

```
sa::backupRunDir -of <saTestbench>
```

Arguments

-of

Testbench whose run directory will be backed up.

sa::cacheTestbenchToSession

Description

Finds the testbench in the session from the history.

Syntax

```
sa::cacheTestbenchToSession <testbench: saTestbench>
```

Returns

<none>

Arguments

testbench

Testbench to cache into the session.

sa::cancelPick

Description

Cancels the interactive pick command.

Syntax

```
sa::cancelPick (-window <giWindow | int> | -testbench <saTestbench>)
```

Returns

<none>

Arguments

-window

PrimeWave Design Environment main window.

-testbench

Testbench.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
# Cancels pick object action if there is active one
sa::cancelPick -testbench $tb
```

sa::clearAnnotations

Description

This command clears data annotation from design window.

Syntax

```
sa::clearAnnotations (-window <giWindow | int> | -testbench  
    <saTestbench>)
```

Arguments

`-window` *giWindow* | `<int>`

The PrimeWave Design Environment window object or id.

`-testbench`

Testbench.

Errors

- No testbench is defined in this window.
- The window is not a PrimeWave Design Environment window.

Examples

```
# Get testbench object from active window  
set tb [sa::findActiveTestbench -window 3]  
sa::clearAnnotations -testbench $tb  
or  
sa::clearAnnotations -window 3
```

sa::clearProbes

Description

Removes all PrimeWave Design Environment deposited probes.

Syntax

```
sa::clearProbes [<object: heContext | saTestbench>] [-tool <string>]
```

Returns

`<none>`

Arguments

`object`

If specified, the object to use for clearing the probes.

`-tool`

Optional tool name.

Examples

To clear probes in the Schematic Editor created by the PrimeWave Design Environment:

```
sa::clearProbes [sa::findActiveTestbench -window 4]
```

sa::cloneTestbench

Description

This command creates a new testbench that is a clone of the given saTestbench object.

Syntax

```
sa::cloneTestbench <testbench: saTestbench> [-name <string>] [-useGlobals  
  <bool>]
```

Returns

The new testbench.

Arguments

`<saTestbench>`

Testbench to be cloned.

`-name <string>`

Name of the new testbench.

`-useGlobals`

Resolve inheritance from the Global scope.

Default: false.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
# Returns new testbench with cloned data from source testbench
set tb_cloned [sa::cloneTestbench $tb]

# Give a name to cloned testbench
```

```
set tb_cloned [sa::cloneTestbench $tb -name "Cloned TB"]  
puts [db::getattr tb_cloned.name]
```

sa::cloneTestbenchToTestSuite

Description

This command clones a testbench and adds it to a test suite.

Syntax

```
sa::cloneTestbenchToTestSuite <testbench: saTestbench> [-name <string>]
```

Returns

<saTestbench>: Cloned testbench.

Arguments

testbench

Testbench to be cloned.

-name <string>

Name of the new testbench.

Examples

```
# Clones provided testbench in testsuit  
# MTB session is also opened in window 10  
set tb [sa::findActiveTestbench -window 10]  
sa::cloneTestbenchToTestSuite $tb -name "post_lay"
```

sa::configureChartsWindow

Description

This command configures the charts displayed in a PrimeWave Design Environment charts window.

Syntax

```
sa::configureChartsWindow <window: giWindow | int> -testbench  
  <saTestbench> [-histogramCharts [<saHistogramChart>]] [-qqCharts  
  [<saQQChart>]] [-scatterCharts [<saScatterChart>]] [-params <string>]  
  [-preview <bool>] [-drawSpecRegions [<bool>]]
```

Arguments

window

Charts window.

`-testbench`

Testbench.

`-histogramCharts`

Histogram charts to display.

`-qqCharts`

QQ charts to display.

`-scatterCharts`

Scatter charts to display.

`-params`

Parametric reduction string.

`-preview`

The preview window mode.

`-drawSpecRegions`

Controls whether or not specification regions should be drawn.

sa::copyCorner

Copies one corner to other

Syntax

`sa::copyCorner -of <string> -to <string> -cornersSetup <saCornersSetup>`

Returns

`<saCorner>` : Corner

Arguments

`-of`

Corner name that is to be copied

`-to`

New corner name that gets copied

`-cornersSetup`

Corners setup

sa::copyDesVars

Description

This command copies design variables from the design into the testbench.

Syntax

```
sa::copyDesVars -window <giWindow> | <int> -testbench <saTestbench>
```

Arguments

-window

PrimeWave Design Environment main console window.

-testbench

Testbench.

Errors

- No Testbench is defined in this session.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
sa::copyDesVars -testbench $tb
```

sa::copyScriptFromWorkDir

Copy the scripts from the `lib.defs` file.

Syntax

```
sa::copyScriptFromWorkDir [-clean <bool>]
```

Returns

<none>

Arguments

-clean

Specifies whether to clean up the directory before copying the new scripts into there.

sa::copyTestbenchCategories

Copies selected categories of one testbench to another

Syntax

```
sa::copyTestbenchCategories -of <saTestbench> -to <saTestbench>  
[-categories [<string>]] [-exclude <bool>]
```

Returns

<none>

Arguments

-of

Source testbench

-to

Destination testbench

-categories

Categories of testbench to operate on

-exclude

Indicates if the categories are to be excluded (Default is: false)

sa::create3DICModelGroup

Creates a 3DIC Model Group

Syntax

```
sa::create3DICModelGroup <name: string> (-window <giWindow | int> |  
-session <saSession> | -testbench <saTestbench>) [-nominalSection  
<string>] [-enabled <bool>]
```

Returns

<saModelGroup> : New model group object

Arguments

name

Name of the model group

-window

PrimeWave Window

-session

PrimeWave Session

`-testbench`

PrimeWave Testbench

`-nominalSection`

Nominal section name

`-enabled`

Enable status for the model file (Default is: true)

sa::createA2DInterfaceElement

Description

This command creates an Analog to Digital Interface Element to be automatically inserted where an analog output drives the digital inputs in the co-simulation flow.

Note:

The `elementType` term supports both terminals and instance terminals in this command.

Syntax

```
sa::createA2DInterfaceElement <element: string> -lowThreshold <string>  
-highThreshold <string> [-thresholdUnit <enum>] [-highImpedance <enum>]  
[-elementType <enum>] [-vdd <string>] [-minv <string>] [-minvLogic  
<enum>] [-ceff <string>] [-midvTime <string>] [-midvLogic <enum>]  
[-xband <string>]
```

Returns

<saA2DInterfaceElement>: New saA2DInterfaceElement.

Arguments

`element`

Circuit element(s) to which this interface element applies. You can use `*` as wildcard character to match a range containing any character.

`-lowThreshold`

Low logic level Threshold

`-highThreshold`

High logic level Threshold

`-thresholdUnit`

Unit for threshold ({ % | v }, default is: v)

`-highImpedance`
HiZ state ({ <none> | off | on }, default is: <none>)

`-elementType`
Circuit Element Type ({ net | term }, default is: net)

`-vdd`
Supply net for the dynamic supply feature.

`-minv`
Minimum voltage for vdd that turns off the a2d conversion (default: 100mV).
(Default is: 0.1)

`-minvLogic`
Logic value outputted by the a2d conversion if minv is not met (default: Z). ({ 0 | 1 | X | Z | x | z }, default is: Z)

`-ceff`
Loading capacitance inserted at the a2d interface net.

`-midvTime`
The time when a2d generates an X or Z-state

`-midvLogic`
Logic value outputted by the a2d conversion when midv expires (default: X). ({ 0 | 1 | X | Z | x | z }, default is: X)

`-xband`
Defines X-state bounds for voltage thresholds.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
# Get mixed signal options
set mso [db::getAttr mixedSignalOptions -of $tb]
# Get a2d interface element collection
set a2dElementCollection [db::getAttr mso.a2dInterfaceElements]
# Create a2d interface element
set a2d_ie [sa::createA2DInterfaceElement /I0/netA \
-lowThreshold 0.1 -highThreshold 0.9 -elementType net]
# Add created a2d element to collection
db::add $a2d_ie -to $a2dElementCollection
```

sa::createAceScript

Adds a new attribute to an object

Syntax

```
sa::createAceScript <filePath: string> -enabled <bool> -gui <bool>  
[-evalInc <bool>]
```

Returns

<dbCore> : New ace script

Arguments

filePath

Script file path

-enabled

Enabled

-gui

Run in GUI mode

-evalInc

Evaluate Incrementally (Default is: false)

sa::createActiveNetsAnalysis

Description

Adds an active net analysis to create the active nets file(s) to support the selective net back-annotation. This API creates a new saObject (representing the active nets analysis) and adds it to the layoutParasitics->activeNets->analyses of the given testbench. This API also creates the simulator specific attributes in the saObject. The attributes are defined in sa::<simulator>::layoutParasitics::activeNets::analysis::getAttrs. The db::setAttr command is used for specifying the values for the simulator specific attributes.

Syntax

```
sa::createActiveNetsAnalysis -testbench <saTestbench> [-threshold  
<string>]
```

Returns

<saObject> : Active nets analysis object.

Arguments

`-testbench`

Testbench.

`-threshold`

Threshold of voltage variation.

Errors

- If the simulator for the specified testbench does not support parasitic back-annotation.

sa::createActiveNetsFile

Description

Adds an active netlist file to support the selective net back-annotation. This API creates a new saObject (representing the active nets file) and adds it to layoutParasitics->activeNets->files of the given testbench. This API also creates the simulator specific attributes (defined in sa::<simulator>::layoutParasitics::activeNets::file::getAttrs) in the saObject. The db::setAttr command is used for specifying the values for the simulator specific attributes.

Syntax

```
sa::createActiveNetsFile <filePath: string> -testbench <saTestbench>
```

Returns

<saObject> : An object for including the active nets file for selective net back-annotation.

Arguments

`filePath`

Name of the active nets file.

`-testbench`

Testbench.

Errors

- If the simulator for the specified testbench does not support parasitic back-annotation.

sa::createAnalysis

Description

This command creates a new analysis of specified type. If any names in the map do not match analysis field names, then they are ignored.

Syntax

```
sa::createAnalysis <name: string> -def <saAnalysisDef> -testbench  
    <saTestbench>
```

Returns

The newly created ceAnalysis object (*saAnalysis*).

Arguments

<string>

Analysis name.

-testbench

Testbench object.

-def *saAnalysisDef*

Analysis definition.

Examples

```
# Get testbench object from active window  
set tb [sa::findActiveTestbench -window 3]  
# Creates dc analysis in the testbench  
set a [sa::createAnalysis dc \  
-def [sa::getAnalysisDefs "dc" -of $sim] \  
-testbench $tb]  
db::setAttr a.enabled -value 1  
db::setAttr a.source -value /v3  
db::setAttr a.start -value 0  
db::setAttr a.stop -value 1.2  
db::setAttr a.stepSize -value 0.01  
db::setAttr a.sweep -value "Source"
```

sa::createAnalysisDef

Description

This command registers a new analysis type for a simulator.

Syntax

```
sa::createAnalysisDef <name: string> -title <string> -simulator  
  <saSimulator>
```

Returns

New analysis definition object ([saAnalysisDef](#))

Arguments

<string>

Analysis type.

-simulator [saSimulator](#)

The simulator object to be used for defining the new analysis type.

-title <string>

The title name for the analysis type. If the title is not specified, it will use analysis type.

Examples

```
# Creates new analysis definition.  
# Is used when adding new analysis to simulator integrations.  
set sim [sa::getSimulators "Spectre"]  
set ad [sa::createAnalysisDef hbac -title "Harmonic Balance AC" \  
-simulator $sim]
```

sa::createAttribute

Adds a new attribute to an object

Syntax

```
sa::createAttribute <name: string> -type <enum> [-typeName <enum>] -in  
  <dbCore> [-title <string>] [-save <bool>]
```

Returns

<dbCore> : New attribute value

Arguments

name

Attribute name

-type

Attribute type ({ bool | collection | float | int | object | string })

`-typeName`

Specify type of the object to create ({ ceResultFile | ceResultsInfo |
giBoolean | giInt | giString | saA2DInterfaceElement | saAceScript |
saAgingAnalysisObjective | saAgingAnalysisTBOObjective | saAgingParamDef
| saAnalysis | saApplicableTestbenches | saCellViewParameters |
saConnectRuleElement | saConnectionModule | saConnectionRule |
saConvergenceAid | saCorner | saCornerParamDef | saCornersSetup
| saD2AInterfaceElement | saDataRow | saDesignParametersSetup
| saDesignVariable | saDesignVariableSet | saDesignVariables |
saDeviceCheckElement | saDeviceCheckExpression | saDeviceCheckOptions
| saDeviceCheckRegion | saDeviceCheckSize | saDeviceCheckSubckt
| saDigitalAnalyzerOptionsGroup | saDpoArea | saDpoObjective |
saDpoParam | saE2NInterfaceElement | saE2RInterfaceElement
| saExternalImagePath | saForceDigitalNet | saHistogramChart |
saImportedFile | saIncludeFile | saIncludeFileSetup | saIncludeGroup |
saIncludeGroupDef | saIncludeGroupSection | saInstanceParameters
| saMeasurementSummary | saModelFile | saModelGroup |
saModelGroupDef | saModelGroupSection | saModelSetup | saMonteCarlo |
saN2EInterfaceElement | saNodeResistanceOverride | saObject | saOption
| saOutput | saOutputSet | saOutputs | saPair | saParam | saQQChart
| saR2EInterfaceElement | saRefParamsObjective | saRegMeasure |
saRegTest | saRegTestbench | saResistanceMapConfig | saResultFile |
saResultsInfo | saSDFConfig | saSaveOptions | saSaveOptionsInstance |
saScatterChart | saSpecification | saStimulusGroup | saStimulusGroupDef |
saStimulusGroupSection | saStimulusPort | saStimulusPortSet | saStimulusPorts
| saStimulusSet | saStringSet | saSweep | saSweepFile | saTandemGroup |
saTestbenchInformation | saThreeDimensCellRow | saThreeDimensSetup
| saThreeDimensSetupIntanceNode | saThreeDimensTableRow |
saVariableGroup | saVariableGroupDef | saVariableGroupSection |
saWorstCaseAnalysis | saWorstCaseCornerCondition | wfCustomPlotMode |
wfExpression | wfExpressionValue | xtReport | xtReportElement }

`-in`

Object for new attribute

`-title`

Title for attribute (Default is:)

`-save`

Whether this attribute will be saved to states or not, default is true (Default is:
true)

sa::createBackAnnotationFile

Include a file for back annotation in testbench

Syntax

```
sa::createBackAnnotationFile (-filePath <string> | -cellView <dmCellView  
| string> | -gpd <string> | -eco <string> | -ecoList <string>)  
-testbench <saTestbench>
```

Returns

<saObject> : An object for including the parasitic file for back annotation

Arguments

-testbench

Testbench

-filePath

The parasitic file which will be back annotated

-cellView

Cellview containing a parasitic extracted Spice text file

-gpd

The path to the Galaxy Parasitic Database

-eco

The path to the SPF file

-ecoList

The path to the ECO list file

sa::createChainParameter

Description

Creates a PrimeWave Design Environment Chaining object.

Syntax

```
sa::createChainParameter -session <saSession> -sourceTestbench <string>  
-sourceTBVersion <int> -sourceMeasurement <string> -testbench <string>  
-parameter <string> -parameterType <saChainParameterType>
```

Returns

<saObject> : PrimeWave Design Environment Chaining object

Arguments

-session

Session.

-sourceTestbench

Source testbench name.

-sourceTBVersion

Source testbench version.

-sourceMeasurement

Source measurement name.

-testbench

Destination testbench.

-parameter

Destination parameter name.

-parameterType

Destination parameter type.

sa::createChartsWindow

Description

This command creates a PrimeWave Design Environment charts window.

Syntax

```
sa::createChartsWindow -parent <giWindow | int> [-preview <bool>]
```

Returns

<giWindow> : saChartsWindow

Arguments

-parent

Parent window.

`-preview`

Preview Chart window mode.

sa::createConnectionModule

Description

This command makes a connection module available for use. The connection modules convert the signals between the domains in the Verilog-AMS simulation flow.

Syntax

```
sa::createConnectionModule <fileName: string> [-isUserFile <bool>]
```

Returns

<saConnectionModule>: New saConnectionModule.

Arguments

`fileName`

Connection Module file path.

`-isUserFile`

Specifies whether (true) or not (false) the connection module is a user file
(Default is: false)

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
# Get mixed signal options
set mso [db::getAttr mixedSignalOptions -of $tb]
set conModules [db::getAttr mso.connectionModules]
set cm [sa::createConnectionModule snps_cm_a2d_1.vams]
db::add $cm -to $conModules
db::foreach m $conModules {
  puts "[db::getAttr m.fileName]"
}
```

sa::createConnectionRule

Description

This command uses a given connection rule file to specify the connection modules that are used to convert signals between domains in the Verilog-AMS simulation flow.

Syntax

```
sa::createConnectionRule <fileName: string> [-isUserFile <bool>]
```

Returns

<saConnectionRule>: New saConnectionRule.

Arguments

fileName

Connection Rule file path.

-isUserFile

Specifies whether (true) or not (false) the connection rule is a user file (Default is: false)

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
# Get mixed signal options
set mso [db::getAttr mixedSignalOptions -of $tb]
set conRules [db::getAttr mso.connectionRules]
set cr [sa::createConnectionRule snps_crules_1_18.vams]
db::add $cr -to $conRules
db::foreach conRule $conRules {
puts "[db::getAttr conRule.fileName]"
}
```

sa::createConnectRuleElement

Description

Creates a Connect Rule Element.

Syntax

```
sa::createConnectRuleElement <fileName: string> [-isUserFile <bool>]
[-enabled <bool>] [-scopeType <enum>] [-scope <string>] [-supplyType
<enum>] [-vsup <string>] [-vddNet <string>] [-vssNet <string>]
[-connectMode <enum>] [-params [<string>]]
```

Returns

<saConnectRuleElement> : New saConnectRuleElement

Arguments

fileName

Connect rule file name

`-isUserFile`

Specifies whether (true) or not (false) the connect rule is a user file (Default is: false).

`-enabled`

Specifies whether (true) or not (false) the connect rule element is enabled (Default is: true).

`-scopeType`

Scope type of the connect rule element ({ cell | cellPort | global | inst | instPort | lib | node }, default is: global).

`-scope`

Scope to which the connect rule element applies - can use * as wildcard character to match a range containing any character (Default is:).

`-supplyType`

Supply type of the connect rule element ({ net | voltage }, default is: voltage).

`-vsup`

Supply of the connect rule element (Default is:).

`-vddNet`

Vsdd net of the connect rule element (Default is:).

`-vssNet`

Vss net of the connect rule element (Default is:)

`-connectMode`

Connect mode of the connect rule element ({ merged | split }, default is: merged)

`-params`

Modified parameters of the connect rule element

sa::createConvergenceAid

Description

Creates a new convergence aid setting. Arguments can be used to specify node, type, node voltage and convergence aid enabled status.

Syntax

```
sa::createConvergenceAid <node: string> (-window <giWindow | int> |  
-testbench <saTestbench>) -type <string> -voltage <string> [-enabled  
<bool>]
```

Returns

Convergence aid object that was created.

Arguments

<string>

Name of the node.

-testbench

Testbench object.

-window *giWindow* | <int>

Window Object or id.

-voltage <float>

Include file section.

Default: 0.

-type <string>

Convergence Aid Type.

-enabled <bool>

Enabled status of include file.

Default: true.

Examples

```
# Get testbench object from active window  
set tb [sa::findActiveTestbench -window 3]  
sa::createConvergenceAid I0/nodeA -testbench $tb \  
-type "Initial Condition" -voltage 0  
sa::createConvergenceAid I0/nodeB -testbench $tb \  
-type "Node Set" -voltage 1.2
```

sa::createCornerParameterDef

Creates a corner parameter definition

Syntax

```
sa::createCornerParameterDef [<name: string>] -type [<enum>]  
-cornersSetup <saCornersSetup> [-path <string>] [-startValue <string>]  
[-enabled <bool>] [-incType <string>]
```

Returns

<saCornerParamDef> : Corner Parameter Definition

Arguments

name

Parameter name

-type

Parameter type ({ category | cellView | designVariable | designVariableGroup |
groupChild | includeFile | includeGroup | includeSingle | modelFile | modelGroup
| stimulusGroup | stimulusSet | string | temp | threeDimensModelGroup })

-cornersSetup

Corners setup

-path

Full path of the model file, or base directory for include files

-startValue

Initial value for the parameter

-enabled

Enable status for the parameter (Default is: true)

-incType

Type for include file

sa::createCornersSetup

Description

This command creates a corners setup object for the given testbench. The corners setup object should be created before calling any other corner APIs. The corners setup object can be deleted using db::destroy.

Syntax

```
sa::createCornersSetup (-window <giWindow | int> | -session <saSession> |  
-testbench <saTestbench>) [-type <enum>]
```

Returns

New corners setup object ([saCornersSetup](#))

Arguments

`-window`

The PrimeWave Design Environment window.

`-session`

The PrimeWave Design Environment session.

`-testbench`

The PrimeWave Design Environment testbench.

`-type`

The setup type. Valid values: standard, worstCases.

Default: standard.

Examples

To create an empty corners setup for a session:

```
# Get testbench object from window
set tb [sa::findActiveTestbench -window 2]
# Create empty corner setup for the testbench
set cs [sa::createCornersSetup -testbench $tb];

# Alternatively, you can create cornersSetup for the session
# Get session object from window
set s [sa::getSessions -window 4];
# Create empty corner setup for the session
set cs [sa::createCornersSetup -session $s];
```

This creates an empty corners setup for the specified PrimeWave Design Environment testbench or session. In order to add corners ([sa::addCorner](#)), you must first define corner parameters using [sa::createCornerParameterDef](#).

sa::createCustomCommand

Description

Create a custom command in testbench.

Syntax

```
sa::createCustomCommand <name: string> (-category <string> | -in
<dbCollection>) [-testbench <saTestbench>] -definition <string>
[-simulator <string>]
```

Returns

A Custom Command object (saCustomCommand).

Arguments

<string>

Command name.

-category <string>

Category.

-in

Category object to be added into.

-testbench <saTestBench>

The testbench object.

-definition <string>

Command definition.

-simulator

Simulator.

Examples

The following example creates a custom command named `extraCommand1`.

```
set cmd [sa::createCustomCommand "extraCommand1" \  
-testbench $tb -definition ExtraCommand \  
-in [db::getAttr blockOptions -of $tb] \  
]  
db::setAttr value -of $cmd -value "simulatorOption -arg1 val1"  
db::setAttr command -of $cmd -value " simulatorOption -arg1 val1"
```

sa::createD2AInterfaceElement

Description

Creates a Digital to Analog Interface Element to be automatically inserted where a digital output drives analog inputs in the co-simulation flow.

Note:

The `elementType` term supports both terminals and instance terminals in this command.

Syntax

```
sa::createD2AInterfaceElement <element: string> [-riseTime <string>]  
[-fallTime <string>] -highVoltage <string> -lowVoltage <string>  
[-levelUnit <enum>] [-powerNet <bool>] [-delay <string>] [-logicX  
<enum>] [-elementType <enum>] [-vdd <string>]
```

Returns

<saD2AInterfaceElement>: New saD2AInterfaceElement.

Arguments

`element`

Circuit element(s) to which this interface element applies. You can use * as the wildcard character to match a range containing any characters.

`-riseTime`

The analog rise time.

`-fallTime`

The analog fall time.

`-highVoltage`

Specifies the logic one voltage level.

`-lowVoltage`

Specifies the logic zero voltage level.

`-levelUnit`

Unit for voltage levels ({ % | v }).

Default is: v

`-powerNet`

When true, identifies the d2a node as an ideal voltage source without the resistance map resistor.

Default is: false.

`-delay`

The time delay before the analog transition.

Default is: 0.

`-logicX`

Sets the rule on how a logic X must be translated to voltage level on the analog side ({always0 | always1 | invert | midPoint | previous}).

Default is: midPoint.

-elementType

The type of circuit element to which the unnamed argument refers ({net | term}).

Default is: net.

-vdd

Supply net for the dynamic supply feature.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
# Get mixed signal options
set mso [db::getAttr mixedSignalOptions -of $tb]
# Get d2a interface element collection
set d2aElementCollection [db::getAttr mso.d2aInterfaceElements]
# Create d2a interface element
set d2a_ie [sa::createD2AInterfaceElement /I0/out -lowVoltage 0.01 \
-highVoltage 1.19 -elementType term \
-riseTime 35p -fallTime 35p -delay 12p]]
# Add created d2a element to collection
db::add $d2a_ie -to $d2aElementCollection
```

sa::createDataRow

Description

Appends a new sweep parameter set (*saDataRow*) object to the sweep object. The *saDataRow* object should be further configured using the `db::setAttr` command. The *saDataRow* can be deleted using the `db::destroy` command.

Syntax

```
sa::createDataRow -sweep <saSweep>
```

Returns

<saDataRow> : New sweep data row object.

Arguments

-sweep

The sweep object in which the new data row is defined.

Errors

- If Sweep Object is not data driven type. The Sweep Object must be data driven type.

Examples

The following example demonstrates the usage of `sa::createSweepRange`, `sa::createSweep`, and `sa::createDataRow`.

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set sweepRange [sa::createSweepRange sweepRange1 \
-rangeType Start/Stop \
-linearType StepSize \
-stepSize 0.05 -start 0 -stop 1.2 \
-stepType Linear ]

set sweep1 [sa::createSweep sweep1 -variable vdd \
-sweepType singleVariable \
-testbench $tb \
-useSimulatorSweep true \
-sweepRange $sweepRange]

set sweepVars [list xfreq temp vdc]
set sweepData [list [list 1G 55 1] [list 1.2G -40 1.2] [list 0.9G 125
0.95]]
set dataSweep [sa::createSweep dataSweep -sweepType dataDriven \
-testbench $tb -variable $sweepVars]
foreach data $sweepData {
set row [sa::createDataRow -sweep $dataSweep]
db::setAttr row.values -value $data
}
```

sa::createGroupDef

Creates a Group Definition of design variable or stimulus or include file

Syntax

```
sa::createGroupDef <name: string> [-window <giWindow | int> | -session
<saSession> | -testbench <saTestbench>] [-includePath <string>] [-items
<string>] -type <string> [-createGroup <bool>]
```

Returns

<saIncludeGroupDef | saStimulusGroupDef | saVariableGroupDef> : New group definition object

Arguments

name

Name of the group

-window

PrimeWave Window

`-session`

PrimeWave Session

`-testbench`

PrimeWave Testbench

`-includePath`

Include path

`-items`

Items to add to this group

`-type`

type

`-createGroup`

Also create the matching saVariableGroup/saIncludeGroup/saStimulusGroup,
for STB or MTB Global (Default is: true)

sa::createGroupDefItem

Creates a Group Item

Syntax

```
sa::createGroupDefItem <filePath: string> (-group <saIncludeGroupDef |  
saStimulusGroupDef | saVariableGroupDef> | -window <giWindow | int> |  
-session <saSession> | -testbench <saTestbench>) [-section <string>]  
-type <string>
```

Returns

<saDesignVariable | saIncludeFile | saStimulusSet> : New group def item object

Arguments

`filePath`

Name of the item

`-section`

Model file section

`-type`

type

`-group`
 Group Definition

`-window`
 PrimeWave Window

`-session`
 PrimeWave Session

`-testbench`
 PrimeWave Testbench

sa::createGroupSection

Creates a Group Section

Syntax

```
sa::createGroupSection <name: string> -in <saIncludeGroupDef |  
saStimulusGroupDef | saVariableGroupDef> -sections <string> [-setNominal  
<bool>] -type <string>
```

Returns

<saIncludeGroupSection | saStimulusGroupSection | saVariableGroupSection> : New
group section object

Arguments

`name`
 Name of the group section

`-in`
 Parent group definition

`-sections`
 sections

`-setNominal`
 Set this section as the nominal for the associated testbench/session (Default is:
 false)

`-type`
 type

sa::createDesignParametersSetup

Creates a new design parameters setup

Syntax

```
sa::createDesignParametersSetup (-parent <giWindow | int> | -session  
    <saSession> | -testbench <saTestbench>)
```

Returns

<saDesignParametersSetup> : Design Parameters Setup

Arguments

-parent

PrimeWave Window

-session

PrimeWave Session

-testbench

PrimeWave Testbench

sa::createDesignVariable

Description

Creates a new design variable with specified value. If there is already a design variable with a given name, then the value of the design variable is changed, no error is issued.

Syntax

```
sa::createDesignVariable <name: string> (-variableSet  
    <saDesignVariableSet> | -window <giWindow | int> | -session <saSession>  
    | -testbench <saTestbench>) -value <string> [-local [<bool>]]
```

Returns

<saDesignVariable> : New design variable.

Arguments

name

Name of the design variable.

-value

Value of the design variable.

`-local`

Multiple testbench inheritance mode (0 - inherit, 1 - to use the local value).

`-variableSet`

Design variable set.

`-window`

PrimeWave Design Environment window.

`-session`

PrimeWave Design Environment session.

`-testbench`

PrimeWave Design Environment testbench.

Examples

The following example creates a new design variable `xfreq` in the given testbench.

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set dvar [sa::createDesignVariable xfreq -testbench $tb -value 5G]
puts [db::getAttr dvar.type]
```

sa::createDeviceCheckElement

Description

Creates a Device Check Element.

Syntax

```
sa::createDeviceCheckElement <name: string> [-elementType <enum>]
    -terminalOne <string> -terminalTwo <string> -limit <string> -noise
    <string> -max <string> -min <string> [-selectLimit <bool>] [-analysis
    <enum>] [-monType <enum>] -elements <string> -models <string> -start
    <string> -stop <string> [-autostop <bool>] -except <string> -interval
    <string> -subcircuits <string> -message <string> [-enable <bool>]
```

Returns

<saDeviceCheckElement> : New saDeviceCheckElement

Arguments

`name`

The name for the check.

`-elementType`
The element type ({ BJT | Bipolar | C | Diode | JFET | MOS | MOSlevel57 | MOSlevel58 | MOSlevel59 | NMOS | PMOS | R | Subckt }, default is: MOS)

`-terminalOne`
First Terminal.

`-terminalTwo`
Second Terminal.

`-limit`
The limit value.

`-noise`
The noise voltage.

`-max`
The maximum value.

`-min`
The minimum value.

`-selectLimit`
When true, use limit. When false, use min/max. (Default is: false)

`-analysis`
The analysis type. ({ all | dc | op | tran }, default is: tran)

`-monType`
The monitoring type. ({ current | voltage }, default is: voltage)

`-elements`
The circuit element names.

`-models`
The model names.

`-start`
The start time.

`-stop`
The stop time.

-autostop

When true, a failure on this check stops the simulation. (Default is: false)

-except

Element name to be excluded from check.

-interval

The time interval.

-subcircuits

The subcircuit names.

-message

User-defined message to be added to this check.

-enable

When true, enables netlisting on this check. (Default is: false)

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set dco [db::getAttr deviceCheckOptions -of $tb]
set elems [db::getAttr deviceCheckElements -of $dco]
set exprs [db::getAttr deviceCheckExpressions -of $dco]
set regs [db::getAttr deviceCheckRegions -of $dco]
set sizes [db::getAttr deviceCheckSizes -of $dco]

set elem [sa::createDeviceCheckElement checkName \
-elementType MOS \
-terminalOne nd \
-terminalTwo ng \
-monType voltage \
-elements /I0 \
-limit 1.2 \
-except "" \
-interval 10n \
-max 1.2 \
-min -1.2 \
-message "Violation occurred" \
-models "nch pch" \
-noise 10m \
-start 0 \
-stop 1u \
-subcircuits ""]
db::add $elem -to $elems

set expr [sa::createDeviceCheckExpression expr1 \
-expr "v(/I0/vp)-v(/I0/vm)" \
-interval 100n \
```

```
-limit 50m \
-max 50m \
-min -50m \
-message "Lower than limit" \
-noise 5m \
-start 0 \
-stop 100n]
db::add $expr -to $exprs

set size [sa::createDeviceCheckSize devSize1 -elementType MOS \
-limit 40n \
-min 7n \
-max 14n \
-elements "" \
-exception "" \
-message "Size violation" \
-models "nch pch" \
-start 0 \
-stop 1u \
-subcircuits ""]
db::add $size -to $sizes
```

sa::createDeviceCheckExpression

Description

Creates a Device Check Expression.

Syntax

```
sa::createDeviceCheckExpression <name: string> -expr <string> -limit
<string> -noise <string> -max <string> -min <string> [-selectLimit
<bool>] [-analysis <enum>] -start <string> -stop <string> [-autostop
<bool>] -interval <string> -message <string> [-enable <bool>]
```

Returns

<saDeviceCheckExpression> : New saDeviceCheckExpression

Arguments

name

The name for the check.

-expr

Expression to be checked.

-limit

The limit value.

`-noise`

The noise voltage.

`-max`

The maximum value.

`-min`

The minimum value.

`-selectLimit`

When true, use limit. When false, use min/max. (Default is: false)

`-analysis`

The analysis type. ({ all | dc | op | tran }, default is: tran)

`-start`

The start time.

`-stop`

The stop time.

`-autostop`

When true, a failure on this check stops the simulation. (Default is: false)

`-interval`

The time interval.

`-message`

User-defined message to be added to this check.

`-enable`

When true, enables netlisting on this check. (Default is: false)

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set dco [db::getAttr deviceCheckOptions -of $tb]
set elems [db::getAttr deviceCheckElements -of $dco]
set exprs [db::getAttr deviceCheckExpressions -of $dco]
set regs [db::getAttr deviceCheckRegions -of $dco]
set sizes [db::getAttr deviceCheckSizes -of $dco]

set elem [sa::createDeviceCheckElement checkName \
-elementType MOS \
-terminalOne nd \
-terminalTwo ng \
```



```
-monType voltage \
-elements /I0 \
-limit 1.2 \
-except "" \
-interval 10n \
-max 1.2 \
-min -1.2 \
-message "Violation occurred" \
-models "nch pch" \
-noise 10m \
-start 0 \
-stop 1u \
-subcircuits ""]
db::add $elem -to $elems

set expr [sa::createDeviceCheckExpression expr1 \
-expr "v(/I0/vp)-v(/I0/vm)" \
-interval 100n \
-limit 50m \
-max 50m \
-min -50m \
-message "Lower than limit" \
-noise 5m \
-start 0 \
-stop 100n]
db::add $expr -to $exprs

set size [sa::createDeviceCheckSize devSize1 -elementType MOS \
-limit 40n \
-min 7n \
-max 14n \
-elements "" \
-except "" \
-message "Size violation" \
-models "nch pch" \
-start 0 \
-stop 1u \
-subcircuits ""]
db::add $size -to $sizes
```

sa::createDeviceCheckOptions

Description

Creates an saDeviceCheckOptions.

Syntax

```
sa::createDeviceCheckOptions -testbench <saTestbench>
```

Returns

<saDeviceCheckOptions> : Device Check Options.

Arguments

-testbench

Testbench.

sa::createDeviceCheckSize

Description

Creates a Device Check Size.

Syntax

```
sa::createDeviceCheckSize <name: string> [-elementType <enum>] -limit  
<string> -max <string> -min <string> [-selectLimit <bool>] [-analysis  
<enum>] [-monType <enum>] -elements <string> -models <string> -start  
<string> -stop <string> [-autostop <bool>] -except <string> -subcircuits  
<string> -message <string> [-enable <bool>]
```

Returns

<saDeviceCheckSize> : New saDeviceCheckSize

Arguments

name

The name for the check.

-elementType

The element type ({ BJT | Bipolar | C | Diode | JFET | MOS | MOSlevel57 |
MOSlevel58 | MOSlevel59 | NMOS | PMOS | R | Subckt }, default is: MOS)

-limit

The limit value.

-max

The maximum value.

-min

The minimum value.

-selectLimit

When true, use limit. When false, use min/max. (Default is: false)

`-analysis`

The analysis type. ({ all | dc | op | tran }, default is: tran)

`-monType`

The monitor type. ({ length | width }, default is: length)

`-elements`

The circuit element names.

`-models`

The model names.

`-start`

The start time.

`-stop`

The stop time.

`-autostop`

When true, a failure on this check stops the simulation. (Default is: false)

`-except`

Element name to be excluded from check.

`-subcircuits`

The subcircuit names.

`-message`

User-defined message to be added to this check.

`-enable`

When true, enables netlisting on this check. (Default is: false)

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set dco [db::getAttr deviceCheckOptions -of $tb]
set elems [db::getAttr deviceCheckElements -of $dco]
set exprs [db::getAttr deviceCheckExpressions -of $dco]
set regs [db::getAttr deviceCheckRegions -of $dco]
set sizes [db::getAttr deviceCheckSizes -of $dco]

set elem [sa::createDeviceCheckElement checkName \
-elementType MOS \
-terminalOne nd \
-terminalTwo ng \
```

```

-monType voltage \
-elements /I0 \
-limit 1.2 \
-except "" \
-interval 10n \
-max 1.2 \
-min -1.2 \
-message "Violation occurred" \
-models "nch pch" \
-noise 10m \
-start 0 \
-stop 1u \
-subcircuits ""]
db::add $elem -to $elems

set expr [sa::createDeviceCheckExpression expr1 \
-expr "v(/I0/vp)-v(/I0/vm)" \
-interval 100n \
-limit 50m \
-max 50m \
-min -50m \
-message "Lower than limit" \
-noise 5m \
-start 0 \
-stop 100n]
db::add $expr -to $exprs

set size [sa::createDeviceCheckSize devSize1 -elementType MOS \
-limit 40n \
-min 7n \
-max 14n \
-elements "" \
-except "" \
-message "Size violation" \
-models "nch pch" \
-start 0 \
-stop 1u \
-subcircuits ""]
db::add $size -to $sizes

```

sa::createDeviceCheckSubckt

Creates a Device Check Subckt

Syntax

```

sa::createDeviceCheckSubckt <name: string> -mname <string> -biasparam
<string> -condition <string> -limit <string> -max <string> -min <string>
[-selectLimit <bool>] [-selectExpr <bool>] [-analysis <enum>] [-monType
<enum>] -expr <string> -terminalOne <string> -terminalTwo <string>
-start <string> -stop <string> -interval <string> -message <string>
[-enable <bool>]

```

Returns

<saDeviceCheckSubckt> : New saDeviceCheckSubckt

Arguments

name

The name for the check

-mname

Subcircuit Name

-biasparam

Bias Params

-condition

Condition

-limit

The limit value

-max

The maximum value

-min

The minimum value

-selectLimit

When true, use limit, when false use min/max (Default is: false)

-selectExpr

When true, use expression, when false use terminal (Default is: false)

-analysis

The analysis type ({ all | dc | op | tran }, default is: tran)

-monType

The monitor type ({ current | voltage }, default is: voltage)

-expr

The expression

-terminalOne

First Terminal

`-terminalTwo`

Second Terminal

`-start`

The start time

`-stop`

The stop time

`-interval`

Interval

`-message`

User defined message to be added to this check

`-enable`

When true, enables netlisting on this check (Default is: false)

sa::createDigitalAnalyzerOptions

Description

Creates an saDigitalAnalyzerOptions object.

Syntax

```
sa::createDigitalAnalyzerOptions [-testbench <saTestbench>]
```

Returns

<saDigitalAnalyzerOptions>

The Digital Analyzer options.

Arguments

`-testbench <saTestbench>`

The target testbench.

sa::createDigitalAnalyzerOptionsGroup

Description

Creates an saDigitalAnalyzerOptionsGroup object.

Syntax

```
sa::createDigitalAnalyzerOptionsGroup -name <string> [-inherit <bool>]  
    [-fileNames <string>] [-options <string>]
```

Returns

<saDigitalAnalyzerOptionsGroup>

The Digital Analyzer Options Group record.

Arguments

-name <string>

The Digital Analyzer Options Group name.

-inherit <bool>

Global options inheritance mode for group files (default is `true`).

-fileNames <string>

The Digital Analyzer Options Group modules or files.

-options <string>

The Digital Analyzer Options Group compilation options.

sa::createDigitalFileOptions

Creates an saDigitalFileOptions object

Syntax

```
sa::createDigitalFileOptions [-testbench <saTestbench>]
```

Returns

<saDigitalFileOptions> : Digital File Options

Arguments

-testbench

Target testbench

sa::createDigitalTiming

Description

Creates an saDigitalTiming object.

Syntax

```
sa::createDigitalTiming -testbench <saTestbench>
```

Returns

<saDigitalTiming>: Digital Timing object.

Arguments

-testbench

The PrimeWave Design Environment testbench.

sa::createE2NInterfaceElement

Description

Creates an electrical-to-nettype interface element

Syntax

```
sa::createE2NInterfaceElement <net: string> -netType <string> [-fidelity  
  <string>] [-res <string>] [-gain <string>] [-hizOn <bool>]
```

Returns

<saE2NInterfaceElement> : New saE2NInterfaceElement

Arguments

net

Net(s) to which this interface element applies - can use * as a wildcard character to match a range containing any character.

-netType

Interface element's type.

-fidelity

Voltage threshold value for e2n events in the engineering format. (Default is: 1)

-res

Series resistance in Ohm. (Default is: 1k)

-gain

Multiplier by which the analog value must be multiplied. (Default is: 1)

`-hizOn`

When set, the voltage source ignores highZ states from the VCS tool. (Default is: true)

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
# Get mixed signal options
set mso [db::getAttr mixedSignalOptions -of $tb]
# Get e2n interface element collection
set e2nElementCollection [db::getAttr mso.e2nInterfaceElements]
# Create e2n interface element
set e2n_ie [sa::createE2NInterfaceElement /I0/netA -netType i_wire \
-fidelity 1 -gain 1 -res 1.5k -hizOn true]
# Add created e2n element to collection
db::add $e2n_ie -to $e2nElementCollection
```

sa::createE2RInterfaceElement

Description

Creates an electrical-to-real interface element

Syntax

```
sa::createE2RInterfaceElement <element: string> [-minDelta <string> |
-maxDelta <string>] [-iType <bool>] [-gain <string>] [-res <string>]
[-resNode <string>] [-elementType <enum>]
```

Returns

<saE2RInterfaceElement> : New saE2RInterfaceElement

Arguments

`element`

Circuit element(s) to which this interface element applies - can use * as wildcard character to match a range containing any character

`-iType`

When true, the e2r is converting to current instead of voltage (Default is: false)

`-minDelta`

Absolute threshold value for e2r events in the engineering format (Default is:)

`-maxDelta`

Sets the difference between two e2r events to be less than or equal to the specified value (must be greater than 0) (Default is:)

-gain

Multiplier to use when converting analog values to digital (Default is:)

-res

Resistance to put between the interface's circuit element and ground or 'resNode' to measure the current (when 'iType' is true) (Default is:)

-resNode

SPICE node name, typically used to mimic a pull-up resistor (when 'res' is specified) (Default is:)

-elementType

Circuit Element Type ({ net | term }, default is: net)

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
# Get mixed signal options
set mso [db::getAttr mixedSignalOptions -of $tb]
# Get e2r interface element collection
set e2rElementCollection [db::getAttr mso.e2rInterfaceElements]
# Create e2r interface element
set e2r_ie [sa::createE2RInterfaceElement /I0/out -iType true \
-fidelity 10 -fidelityUnit % -res 50]
# Add created e2r element to collection
db::add $e2r_ie -to $e2rElementCollection
```

sa::createEMDB

Description

Measures terminal currents and stores the data in a database that can be used to annotate schematics and layouts.

Syntax

```
sa::createEMDB <filePath: string> (-resultsDir <string> | -resultFile
<string>) [-netlist <string>] [-nameMap <nlNameMap | string>]
[-startTime <string>] [-stopTime <string>]
```

Returns

<string>: Database name.

Arguments

filePath

Output file name.

`-resultsDir`

The PrimeWave Design Environment results directory.

`-resultFile`

The input simulator waveform file.

`-netlist`

The netlist associated with the specified `-resultFile`.

`-nameMap`

The name map for the specified `-resultFile`. Accepts either a name map object of the directory where name mapping data is stored.

`-startTime`

Compute currents based on given start time.

`-stopTime`

Ignore values after given stop time.

sa::createExpressionDef

Creates an expression definition used by the Plotting Assistant tab of the Results Analyzer

Syntax

```
sa::createExpressionDef <name: string> [-description <string>]  
-analysisDef <saAnalysisDef> -createExpressionProc <string>  
[-checkCustomFieldsProc <string>] [-setupProc <string>]  
[-updateCustomFieldsProc <string>] [-graphTypes [<string>]] [-modifiers  
[<string>]]
```

Returns

<saExpressionDef> : New expression definition

Arguments

`name`

Expression name

`-description`

description of expression

`-analysisDef`

Analysis definition the expression definition pertains to

`-createExpressionProc`

Name of TCL proc which returns the expression string.

`-checkCustomFieldsProc`

Name of TCL proc which returns true if all data is filled in the custom GUI.
Returns a prompt string if more information is required.

`-setupProc`

Name of TCL proc which creates opal widgets for the Arguments section. It should create them in the giGroup found by parameter's opalPanel attribute

`-updateCustomFieldsProc`

Name of TCL proc to be called to update custom opal widgets created by the setupProc. Called whenever a widget value related to the expression (except signal selection) changes.

`-graphTypes`

List of valid graph types for expression

`-modifiers`

List of modifiers for expression

sa::createExternalImagePath

Description

Creates an saExternalImagePath object.

Syntax

```
sa::createExternalImagePath <path: string> -pathType <enum> -title  
    <string> -enabled <bool>
```

Returns

<dbCore> : New saExternalImagePath object

Arguments

path

Filesystem path representing a single image file or a directory having image files of interest.

`-pathType`

Type of provided filesystem path. ({ directory | file })

`-title`

Title for the image(s) stored in the filesystem path.

`-enabled`

Enabled.

sa::createFlowFile

Description

Creates a PrimeWave Design Environment flow file.

Syntax

```
sa::createFlowFile <name: string> [-flowAction <saFlowAction>]  
[-filePathProc <string>] [-filePath <string>]
```

Returns

<saFlowFile> : New PrimeWave Design Environment flow file.

Arguments

`name`

Flow file name (not filename).

`-flowAction`

The flowAction that generates this file. If not given, a new blank flowAction will be created.

`-filePathProc`

The proc to be called for getting the file path. This does not take any arguments.

`-filePath`

Explicit filepath. Will set the filePathProcOverriden flag.

sa::createForceDigitalNet

Description

This command replaces a digital-to-analog interface element with a DC source of the given voltage in the co-simulation flow.

Syntax

```
<saForceDigitalNet> sa::createForceDigitalNet <string> [-dcVoltage  
<stringfloat>]
```

Returns

<saForceDigitalNet>: Created forceDigitalNet object.

Arguments

<string>

Nets for which the override applies. You can use "*" as a wildcard character to match a range containing any character.

dcVoltage

DC voltage to connect at the given net to replace any digital-to-analog interface element.

sa::createHistogramChart

Description

Creates an saHistogramChart object.

Syntax

```
sa::createHistogramChart -enabled <bool> -axisType <enum> -axisName  
  <string> -saveImage <bool>
```

Returns

<dbCore> : New histogram chart

Arguments

-enabled

Enabled.

-axisType

X-axis type. ({ inputParameter | measurement })

-axisName

X-axis name.

-saveImage

Save image.

sa::createIncludeFile

Creates an include file object.

Syntax

```
sa::createIncludeFile <filename: string> (-window <giWindow | int> |  
-session <saSession> | -testbench <saTestbench>) -includeType <string>  
[-enabled <bool>] [-section <string>] [-fromCorner <bool>]
```

Returns

<saIncludeFile> : New include file

Arguments

filename

Include file name

-window

PrimeWave Window

-session

PrimeWave Session

-testbench

PrimeWave Testbench

-includeType

Include file Type

-enabled

Enabled/disabled state (Default is: true)

-section

Include file section (Default is:)

-fromCorner

From Corner or not (Default is: false)

sa::createIncludeGroup

Creates a Include Group

Syntax

```
sa::createIncludeGroup <name: string> (-window <giWindow | int> |  
-session <saSession> | -testbench <saTestbench>) [-nominalSection  
<string>] [-fromCorner <bool>] [-enabled <bool>]
```

Returns

<saIncludeGroup> : New include group object

Arguments

name

Name of the include group

-window

PrimeWave Window

-session

PrimeWave Session

-testbench

PrimeWave Testbench

-nominalSection

Nominal section name

-fromCorner

From Corner or not (Default is: false)

-enabled

Enable status for the include file (Default is: true)

sa::createLayoutParasitics

Description

This API creates a new saObject, representing the setup data of the layout parasitics for the given testbench. This object holds other saObjects representing the parasitic backannotation files, active nets analysis setup, and active nets files. This object can be retrieved by reading the layoutParasitics attribute of the testbench and destroyed by calling the db::destroy command on the layoutParasitics attribute of the testbench.

Syntax

```
sa::createLayoutParasitics -testbench <saTestbench>
```

Returns

<saObject> : A custom parasitic object.

Arguments

-testbench
Testbench.

Errors

- An object representing the layout parasitics, already exists for the given testbench.
- If the simulator for the specified testbench does not support parasitic backannotation.

sa::createMeasurementSummary

Creates an a measurement summary instance for a given measurement

Syntax

```
sa::createMeasurementSummary <name: string> -testbench <saTestbench>  
-analysisType <string> [-goalType <enum>] [-goal <string>] [-goalHigh  
<string>] [-goalLow <string>] [-poor <string>] [-poorHigh <string>]  
[-poorLow <string>]
```

Returns

<saMeasurementSummary> : New measurement summary

Arguments

name
Measurement name

-testbench
Testbench

-analysisType
Analysis Type

-goalType
Goal type ({ >Center< | Exact | Greater Than | Greater Than Equal | Inclusive
Range | Less Than | Less Than Equal | Maximize | Minimize | Range }, default
is: Exact)

-goal
Goal (Default is:)

-goalHigh
Goal High (Default is:)

`-goalLow`

Goal Low (Default is:)

`-poor`

Poor (Default is:)

`-poorHigh`

Poor High (Default is:)

`-poorLow`

Poor Low (Default is:)

sa::createMixedSignalOptions

Description

This command creates a saMixedSignalOptions object.

Syntax

```
sa::createMixedSignalOptions -testbench <saTestbench>
```

Returns

<saMixedSignalOptions>: Mixed Signal Options object.

Arguments

`-testbench`

The PrimeWave Design Environment testbench.

sa::createModelFile

Description

Creates a new model file. Arguments can be used to specify the model file path and model file section.

Syntax

```
sa::createModelFile <filePath: string> (-group <saModelGroupDef>  
| -window <giWindow | int> | -session <saSession> | -testbench  
<saTestbench>) [-section <string>] [-enabled <bool>]
```

Returns

<saModelFile> : New model file object.

Arguments

`<string>`

Model file path.

`-filePath`

Name of the model file.

`-section <string>`

Model file section.

Default: "".

`-enabled <bool>`

Enabled status for the model file.

Default: true.

`-group`

Model Group Definition

`-window`

The PrimeWave Design Environment window.

`-session`

The PrimeWave Design Environment session.

`-testbench`

The PrimeWave Design Environment testbench.

`-group`

The Model Group Definition.

Examples

In this example, `sa::createModelFile` creates a model file for an `saTestbench` object.

```
set saModelFile [sa::createModelFile filePath -section "tt" -enabled true  
-testbench $saTestbench]
```

sa::createModelGroup

Description

Creates a model group within a testbench or session.

Syntax

```
sa::createModelGroup <name: string> (-window <giWindow | int> | -session  
<saSession> | -testbench <saTestbench>) [-nominalSection <string>]  
[-enabled <bool>]
```

Returns

<saModelGroup> : New model group object.

Arguments

name

Name of the model group.

-window

PrimeWave Design Environment window.

-session

PrimeWave Design Environment session.

-testbench

PrimeWave Design Environment testbench.

-nominalSection

Nominal section name.

-enabled

Enable status for the model file (Default is: true).

Errors

- Named model group definition does not exist.

Examples

The following example shows how to export an existing model group definition into a Tcl file.

```
# Get testbench object from active window  
set tb [sa::findActiveTestbench -window 3]  
set mgd [sa::createModelGroupDef project_models \  
-includePath {./models} \  
-files {mos.lib res.lib}]  
set mg [sa::createModelGroup project_models \  
-testbench $tb -nominalSection "TT" -enabled false]  
sa::createModelGroupSection TT -fileSections {mos_tt res_tt} -in $mgd  
sa::createModelGroupSection FF -fileSections {mos_ff res_ff} -in $mgd  
sa::createModelGroupSection SS -fileSections {mos_ss res_ss} -in $mgd  
sa::exportModelGroupDef $mgd -file modelGroup.tcl
```

sa::createModelGroupDef

Description

Creates a new and empty model group definition object. To populate the group with files, the `sa::createModelFile` command should be called with the `-group` option.

Syntax

```
sa::createModelGroupDef <name: string> [-window <giWindow | int> |  
-session <saSession> | -testbench <saTestbench>] [-includePath <string>]  
[-files <string>] [-createGroup <bool>]
```

Returns

<saModelGroup> : New model group definition object.

Arguments

name

Name of the model group.

-window

PrimeWave Design Environment window.

-session

PrimeWave Design Environment session.

-testbench

PrimeWave Design Environment testbench.

-includePath

Include path.

-files

Model files to add to this group.

-createGroup

Also create the matching saModelGroup, for STB or MTB Global (Default is: true).

Errors

- Group name is not unique.

Examples

The following example shows how to export an existing model group definition into a Tcl file.

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set mgd [sa::createModelGroupDef project_models \
-includePath {./models} \
-files {mos.lib res.lib}]
set mg [sa::createModelGroup project_models \
-testbench $tb -nominalSection "TT" -enabled false]
sa::createModelGroupSection TT -fileSections {mos_tt res_tt} -in $mgd
sa::createModelGroupSection FF -fileSections {mos_ff res_ff} -in $mgd
sa::createModelGroupSection SS -fileSections {mos_ss res_ss} -in $mgd
sa::exportModelGroupDef $mgd -file modelGroup.tcl
```

sa::createModelGroupSection

Description

Creates a model group section. Ideally, the group should be populated with files before invoking this command.

Syntax

```
sa::createModelGroupSection <name: string> -in <saModelGroupDef>
-fileSections <string> [-setNominal <bool>]
```

Returns

<saModelGroupSection> : New model group section object.

Arguments

name

Name of the model group section.

-in

Parent model group definition.

-fileSections

Model file sections.

-setNominal

Set this section as the nominal for the associated testbench/session (Default is: false).

Errors

- Section name is not unique.

Examples

The following example shows how to export an existing model group definition into a Tcl file.

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set mgd [sa::createModelGroupDef project_models \
-includePath {./models} \
-files {mos.lib res.lib}]
set mg [sa::createModelGroup project_models \
-testbench $tb -nominalSection "TT" -enabled false]
sa::createModelGroupSection TT -fileSections {mos_tt res_tt} -in $mgd
sa::createModelGroupSection FF -fileSections {mos_ff res_ff} -in $mgd
sa::createModelGroupSection SS -fileSections {mos_ss res_ss} -in $mgd
sa::exportModelGroupDef $mgd -file modelGroup.tcl
```

sa::createMonteCarlo

Description

This command creates a new Monte Carlo set-up object.

Syntax

```
sa::createMonteCarlo -testbench <saTestbench> [-enabled <bool>] [-numIter
<string>] [-startIter <string>] [-multiRuns <bool>] [-multiRunType
<Iterations per run | Number of runs>] [-saveSignalData <bool>]
[-iterationsPerRun <string>] [-totalRuns <string>]
```

Returns

New Monte Carlo object (saMonteCarlo).

Arguments

-testbench

The testbench object.

-enabled <bool>

Whether Monte Carlo is enabled.

Default: true.

-numIter <string>

Number of iterations.

Default: 10.

`-startIter <string>`

Start iteration.

Default: 1.

`-multiRuns <bool>`

Whether iterations are divided into multiple runs.

Default: false.

`-multiRunType <enum>`

Whether to specify number of iterations per run, or number of runs.

Default: Number of runs.

`-saveSignalData <bool>`

Whether signal data is saved.

Default: true.

`-iterationsPerRun <string>`

Number of iterations per run.

Default: 10.

`-totalRuns <string>`

Number of runs.

Default: 1.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
sa::createMonteCarlo -testbench $tb -numIter 1000 \
-enabled true -multiRunType "Iterations per run" \
-multiRuns true -iterationsPerRun 100
```

sa::createN2EInterfaceElement

Description

Creates a nettype-to-electrical interface element

Syntax

```
sa::createN2EInterfaceElement <net: string> -netType <string> [-fidelity  
<string>] [-rfRate <string>] [-res <string>] [-gain <string>] [-rOff  
<string>] [-x2v <string>] [-hizOn <bool>]
```

Returns

<saN2EInterfaceElement> : New saN2EInterfaceElement

Arguments

net

Net(s) to which this interface element applies. You can use * as a wildcard character to match a range containing any character.

-netType

Interface element's type.

-fidelity

Voltage threshold value for n2e events in the engineering format. (Default is: 1)

-rfRate

How fast the voltage changes from the current value to the target value in seconds/volt. (Default is: 10p)

-res

Series resistance in Ohm. (Default is: 50)

-gain

Multiplier by which the analog value must be multiplied. (Default is: 1)

-rOff

Series resistance value in Ohm when the interface element real value is set to hiz. (Default is: 1G)

-x2v

Voltage source value when the interface element real value is set to x.

-hizOn

When set, the voltage source ignores highZ states from the VCS tool. (Default is: true)

Examples

```
# Get testbench object from active window  
set tb [sa::findActiveTestbench -window 3]  
# Get mixed signal options
```

```
set mso [db::getAttr mixedSignalOptions -of $tb]
# Get n2e interface element collection
set n2eElementCollection [db::getAttr mso.n2eInterfaceElements]
# Create n2e interface element
set n2e_ie [sa::createN2EInterfaceElement I0/netA -netType r_wire \
-fidelity 1 -rfRate 10p -gain 2 -res 10 -rOff 1G \
-hizOn true]
# Add created n2e element to collection
db::add $n2e_ie -to $n2eElementCollection
```

sa::createNetlist

Create simulation input file

Syntax

```
sa::createNetlist (-window <giWindow | int> | -testbench <dbCollection
| saTestbench>) [-createStructural <bool>] [-force <bool>] [-allFinal
<bool>]
```

Returns

<bool> : Status of the netlister run

Arguments

-window

PrimeWave main console window

-testbench

Testbench or a collection of testbenches

-createStructural

If set to True, a new structural netlist will be created along with any associated checks. (Default is: 1)

-force

Overwrite hand edited netlists if necessary. (Default is: 0)

-allFinal

If set to True, final netlists for all data points will be created too. (Default is: 0)

sa::createNodeResistanceOverride

Description

Creates a node resistance override to replace the value that specified the resistance maps in the co-simulation flow.

Syntax

```
sa::createNodeResistanceOverride <string> -resistance <string>
```

Returns

<saNodeResistanceOverride>: Node Resistance Override Object

Arguments

-none <string>

Nodes to which the override applies. You can use "*" as a wildcard character to match a range containing any character.

-resistance <string>

Value of the resistance.

sa::createObject

Creates an empty saObject

Syntax

```
sa::createObject [-type <enum>]
```

Returns

<dbCore> : New empty saObject

Arguments

-type

Specify type of the object to create ({ ceResultFile | ceResultsInfo | giBoolean | giInt | giString | saA2DInterfaceElement | saAceScript | saAgingAnalysisObjective | saAgingAnalysisTBOjective | saAgingParamDef | saAnalysis | saApplicableTestbenches | saCellViewParameters | saConnectRuleElement | saConnectionModule | saConnectionRule | saConvergenceAid | saCorner | saCornerParamDef | saCornersSetup | saD2AInterfaceElement | saDataRow | saDesignParametersSetup | saDesignVariable | saDesignVariableSet | saDesignVariables | saDeviceCheckElement | saDeviceCheckExpression | saDeviceCheckOptions | saDeviceCheckRegion | saDeviceCheckSize | saDeviceCheckSubckt | saDigitalAnalyzerOptionsGroup | saDpoArea | saDpoObjective | saDpoParam | saE2NInterfaceElement | saE2RInterfaceElement | saExternallImagePath | saForceDigitalNet | saHistogramChart | saImportedFile | saIncludeFile | saIncludeFileSetup | saIncludeGroup | saIncludeGroupDef | saIncludeGroupSection | saInstanceParameters | saMeasurementSummary | saModelFile | saModelGroup |

saModelGroupDef | saModelGroupSection | saModelSetup | saMonteCarlo |
saN2EInterfaceElement | saNodeResistanceOverride | saObject | saOption
| saOutput | saOutputSet | saOutputs | saPair | saParam | saQQChart
| saR2EInterfaceElement | saRefParamsObjective | saRegMeasure |
saRegTest | saRegTestbench | saResistanceMapConfig | saResultFile |
saResultsInfo | saSDFConfig | saSaveOptions | saSaveOptionsInstance |
saScatterChart | saSpecification | saStimulusGroup | saStimulusGroupDef |
saStimulusGroupSection | saStimulusPort | saStimulusPortSet | saStimulusPorts
| saStimulusSet | saStringSet | saSweep | saSweepFile | saTandemGroup |
saTestbenchInformation | saThreeDimensCellRow | saThreeDimensSetup
| saThreeDimensSetupIntanceNode | saThreeDimensTableRow |
saVariableGroup | saVariableGroupDef | saVariableGroupSection |
saWorstCaseAnalysis | saWorstCaseCornerCondition | wfCustomPlotMode |
wfExpression | wfExpressionValue | xtReport | xtReportElement }

sa::createOptionDef

Description

Creates an option definition from which a simulator option is automatically managed and presented to the user for edit.

Syntax

```
sa::createOptionDef <name: string> [-collectionName <string>]  
[-analysis <string>] -optionType <enum> -simulator <saSimulator>  
[-prefName <string>] [-defaultValue <string>] [-limit <dbObject>]  
[-prompt <string>] [-description <string>] [-mustEnable <enum>]  
[-supportsExpression <bool>]
```

Returns

New option definition ([saOptionDef](#))

Arguments

<string>

Option name.

-collectionName

Name of collection attribute into which the option is added.

Default: optionDefs.

`-analysis <string>`

The name of analysis definition in simulator on which to add the option definition. If blank, the definition is added to the collection of global simulator options.

`-optionType <enum>`

Option type.

`-simulator saSimulator`

Simulator for option definition.

`-prefName <string>`

Name of associated preference.

`-defaultValue <string> | <int> | <float>`

Default value.

`-limit <dbObject>`

Limits for the option value.

`-prompt <string>`

Prompt string.

`-description <string>`

Description.

`-mustEnable <enum>`

Indicates whether the option must be enabled.

`-supportsExpression <bool>`

Expressions are valid values.

Default: false.

sa::createOptionGroup

Description

Creates a grouping of options which is presented to the user by a specific category or tree node on the resulting CDE GUI.

Syntax

```
sa::createOptionGroup <name: string> (-in <saOptionGroup> | -simulator  
  <saSimulator>) [-description <string>] [-expanded <bool>] [-optionNames  
  [<string>]] [-optionGroups [<saOptionGroup>]]
```

Returns

New option group ([saOptionGroup](#))

Arguments

<string>

Group name.

-description <string>

Description of group.

-expanded <bool>

sets the default expanded status of the group in the tree table.

-optionNames {<string>}

Option names to include in new group.

-optionGroups {[saOptionGroup](#)}

Option groups to include in new group.

-in [saOptionGroup](#)

Option group to include this new group.

-simulator

Parent simulator object for this new group.

sa::createOptionLimit

Description

Creates an object that contains limit information to be applied to a target simulator option.

Syntax

```
sa::createOptionLimit <type: enum> [-min <int>] [-dmin <float>] [-max  
<int>] [-dmax <float>] [-increment <int>] [-dincrement <float>] [-values  
[<string>]]
```

Arguments

<string>

type

-min <int>

Minimum integer value.

`-dmin <float>`
Minimum float value.

`-max <int>`
Maximum integer value.

`-dmax <float>`
Maximum float value.

`-increment <int>`
Increment int size.

`-dincrement <float>`
Increment float size.

`-values {<string>}`
Valid values list.

sa::createOrGetDialog

Description

Gets or creates a dialog uniquely scoped to a session or testbench.

Syntax

```
sa::createOrGetDialog [-session <saSession> | -testbench <saTestbench>]  
  [-parent <string>] -rootName <string> -rootTitle <string>  
  -newlyCreatedRef <string> [-showApply <bool>] [-showHelp <bool>]  
  [-execProc <string>] [-closeProc <string>] [-defaultsProc <string>]  
  [-defaultsMenuProc <string>] [-topicId <string>] [-raiseExisting <bool>]  
  [-shown <bool>]
```

Arguments

`-session`
Session.

`-testbench`
Testbench.

`-parent`
Optional parent object. Defaults to window derived from `-testbench` or `-session`.

`-rootName`
Root component of the generated dialog name.

`-rootTitle`

Root component of the generated dialog title.

`-newlyCreatedRef`

Variable name for storing if the dialog was newly created.

`-showApply`

Show an Apply button in the dialog. (Default is: true)

`-showHelp`

Show a Help button in the dialog. (Default is: true)

`-execProc`

Proc to execute when OK or Apply is clicked. Defaults to [uplevel {namespace current}]::execProc

`-closeProc`

Proc to execute when dialog is closed. Defaults to [uplevel {namespace current}]::closeProc

`-defaultsProc`

Proc to execute for customizing dialog "Defaults" button behavior. Defaults to [uplevel {namespace current}]::defaultsProc

`-defaultsMenuProc`

An optional procedure to call when an action of the Defaults button's menu is pressed. Called with the dialog object and the action name.

`-topicId`

Topic Id.

`-raiseExisting`

Raise dialog if it already exists. Default: true

`-shown`

Initial shown state of dialog. Default: true

Examples

The following example creates a dialog from a given active testbench. Use the **Pick** button to select the net from the design.

```
proc pickNetProc {widget pickedObjectInfo} {  
    set dialog [db::getattr widget.root]  
    # Get picket net name  
    set name [lindex $pickedObjectInfo 0 1]
```



```

        set netName [gi::findChild netName -in $dialog]
        db::setAttr netName.value -value $name
    }

    proc pickAborted {widget} {
        # Return focus to PrimeWave window
        set dialog [db::getAttr widget.root]
        gi::setActiveWindow [db::getAttr parent -of $dialog] -raise true
    }

    proc startPick {testbench widget} {
        sa::pick -testbench $testbench \
            -prompt "Pick Net" \
            -oneShot true \
            -objectTypes "net" \
            -pickProc [list pickNetProc $widget] \
            -abortProc [list pickAborted $widget]
    }

    set testbench [ss::getActiveTestbench]
    set dialog [sa::createOrGetDialog \
        -testbench $testbench \
        -rootName "probeNet" \
        -rootTitle "Probe Net" \
        -newlyCreatedRef newlyCreated]
    # Add widgets if newly created dialog
    if {$newlyCreated} {
        set netName [gi::createTextInput netName -parent $dialog -label
            "Net"]
        set pickButton [gi::createPushButton runPick \
            -icon select_design \
            -parent $dialog \
            -execProc [list startPick $testbench]]
        gi::layout $pickButton -rightOf $netName
    }

```

sa::createOutput

Creates an output

Syntax

```

sa::createOutput <name: string> [-dialog <giDialog> | -testbench
<saTestbench>] [-expr <string>] [-description <string>] [-analyses
<string>] [-plot <bool>] [-plotType <enum>] [-save <bool>] [-imageTitle
<string>] [-suffix <string>] [-units <string>] [-importFromNetlist
<string>] [-precision <int>] [-copy_index <int>] [-rowIdx <float>]
[-lineIdx <float>] [-probe <string>] [-outputSet <string>] [-session
<saSession>] [-outputs <saOutputSet>] [-index <int>] [-resultsViewer
<bool>] [-saveImage <bool>] [-logicRadix <enum>] [-valueChangeEnabled
<bool>] [-addDefaultOP <bool>] [-applicableTestbenches <string>]

```

Returns

<saOutput> : New output

Arguments

name

Output name

-expr

Expression (Default is:)

-description

Description (Default is:)

-analyses

Analyses for which output is evaluated (Default is:)

-plot

Should the output be plotted (Default is: true)

-plotType

Choose specific plot type ({ auto | constell | eyediag | histogram | linear | polar | scatter | smith | spectrum | stateye }, default is: auto)

-save

Should the output be saved (Default is: true)

-imageTitle

Pattern to be used as image title in RV (Default is:)

-suffix

Engineering suffix for string formatting (Default is:)

-units

Units (Default is:)

-importFromNetlist

Flag to indicate the output is imported from netlist file (Default is:)

-precision

Precision

-copy_index

Copy Index

`-rowIdx`
 rowIdx

`-lineIdx`
 lineIdx

`-probe`
 Probe color for the output (Default is:)

`-outputSet`
 Output set in which output is created (Default is:)

`-dialog`
 Dialog to which output is to be added

`-testbench`
 Testbench

`-session`
 Session

`-outputs`
 Target output set to create the output

`-index`
 Position in the output set of the new output

`-resultsViewer`
 Show the expression in the RV (Default is: true)

`-saveImage`
 Save image to the RV (Default is: false)

`-logicRadix`
 Logic radix (digital signals only) ({ ascii | auto | binary | decimal | default | hexadecimal | octal | signed }, default is: auto)

`-valueChangeEnabled`
 value is enabled in OPV (Default is: true)

`-addDefaultOP`
 add default op in analyses column (Default is: true)

`-applicableTestbenches`

The testbenches that you want to apply the global outputs to

sa::createPair

Description

Creates a new saPair object which can be used to represent a name value pair.

Syntax

```
sa::createPair <name: string> -value <string>
```

Returns

The saPair Object ().

Arguments

<string>

Name.

`-value <string>`

Value.

sa::createProbe

Description

Creates a new probe object in the design corresponds to the specified testbench.

Syntax

```
sa::createProbe <name: string> -testbench <saTestbench> -type <string>  
[-longDescription <string>] [-descendToContext <bool>] [-cycleColor  
<bool>] [-crossProbe <bool>] [-tool <string>] [-data <string>]
```

Returns

<none>

Arguments

name

Name/identifier to be probed.

`-testbench`

PrimeWave Design Environment Testbench.

`-type`

Type of probe to create: "instance", "net" or "terminal".

`-longDescription`

Optional string describing probe in detail for the cross probed object.

`-descendToContext`

If true, descend into the context. (Default is: 0)

`-cycleColor`

If true, the next available color should be advanced. (Default is: 0)

`-crossProbe`

If true, the probe is created for cross probing from PrimeWave Design Environment. (Default is: 0)

`-tool`

Optional tool name for the cross probed object. The default is PrimeWave Design Environment.

`-data`

Arbitrary string data associated with the cross probed object.

sa::createQQChart

Description

Creates an saQQChart object.

Syntax

```
sa::createQQChart -enabled <bool> -measurementName <string> -saveImage  
                  <bool>
```

Returns

<dbCore> : New QQ chart

Arguments

`-enabled`

Enabled.

`-measurementName`

Measurement name.

-saveImage

Save image.

sa::createR2EInterfaceElement

Description

Creates a real-to-electrical interface element

Syntax

```
sa::createR2EInterfaceElement <element: string> [-iType <bool>]  
[-minDelta <string>] [-gain <string>] [-rfRate <string>] [-elementType  
<enum>]
```

Returns

<saR2EInterfaceElement> : New saR2EInterfaceElement

Arguments

element

Circuit element(s) to which this interface element applies - can use * as wildcard character to match a range containing any character

-iType

When true, the r2e is converting to current instead of voltage (Default is: false)

-minDelta

Absolute threshold value for r2e events in the engineering format (Default is:)

-gain

Multiplier to use when converting analog values to digital (Default is:)

-rfRate

Indicates how fast the voltage changes from the current value to the target value, in s/V (Default is:)

-elementType

Circuit Element Type ({ net | term }, default is: net)

Examples

```
# Get testbench object from active window  
set tb [sa::findActiveTestbench -window 3]  
# Get mixed signal options  
set mso [db::getAttr mixedSignalOptions -of $tb]  
# Get r2e interface element collection
```

```
set r2eElementCollection [db::getattr mso.r2eInterfaceElements]
# Create n2e interface element
set r2e_ie [sa::createR2EInterfaceElement I0/netA -iType false \
-fidelity 10 -fidelityUnit % -gain 0.5 ]
# Add created r2e element to collection
db::add $r2e_ie -to $r2eElementCollection
```

sa::createReport

Description

This command creates an xtReport object in the given session.

Syntax

```
sa::createReport <reportName: string> -session <saSession> [-fileName
<string>] [-fileType <string>] [-recreate <bool>]
```

Returns

<xtReport> : New report object

Arguments

reportName

Name for the new report

-session

Parent session for the new report

-fileName

Output file name (default 'stdout' prints to console) (Default is: stdout)

-fileType

Report format [csv|html|text] (Default is: text)

-recreate

If true, then a new report is created by removing the existing report. (Default is: 0)

Examples

```
sa::createReport consoleReport -session [getActiveSession] -fileType text
-fileName stdout -recreate true
```

sa::createResistanceMapConfig

Description

This command creates a resistance map configuration that specifies the resistance map to use with a given element in the co-simulation flow.

Syntax

```
sa::createResistanceMapConfig <fileName: string> [-category <enum>]  
-elements <string>
```

Returns

<saResistanceMapConfig>: New saResistanceMapConfig.

Arguments

fileName

Resistance map file path.

-category

Type of circuit element or file given by elements. ({inst | instFile | instTerm | lcv | lcvFile | net | netFile | term}).

Default: net.

-elements

Circuit elements to which this resistance map applies. You can use * as wildcard character to match a range containing any character, or a text file containing a list of circuit elements.

sa::createResultsInfo

Description

This command creates a results info for a simulation.

Syntax

```
sa::createResultsInfo -resultsDir <string> -netlistDir <string>
```

Returns

New saResultsInfo object.

Arguments

`-resultsDir <string>`

The results directory.

`-netlistDir`

The netlist directory.

sa::createResultsMap

Description

This command creates the results map object for the specified simulation run directory.

Note:

The creation of `saResults` and `saResultFile` are not exposed at Tcl level because they will be created in C++ code.

Syntax

```
sa::createResultsMap (-resultsDir <string> -testbench  
  <saTestbench>) [-saveToDisk <bool>]
```

Returns

New `saResultsMap` object ([saResultsMap](#)).

Arguments

`-resultsDir <string>`

The simulation run directory.

`-testbench`

The testbench object.

`-saveToDisk`

Saves results map to disk.

Default: true.

sa::createResultsXML

Description

Creates a results XML file.

Syntax

```
sa::createResultsXML <filename: string> -resultsDir <string>  
  -callbackProc [<attrObject>] [-saveToDisk <bool>]
```

Returns

<saResultsMap> : Results XML output file

Arguments

filename

File name.

-resultsDir

Results directory.

-callbackProc

Callback procedure add files to resultsXML.

-saveToDisk

Save results map to disk. (Default is: true)

sa::createRunDir

Description

Creates the directory structure for a testbench.

Syntax

```
sa::createRunDir -of <saTestbench>
```

Returns

<string>

The path to the created directory.

Arguments

-of

Testbench whose run directory is created.

sa::createRunScript

Description

Creates the run script for a simulation job.

Syntax

```
sa::createRunScript -testbench <saTestbench>
```

Arguments

-testbench
Testbench.

sa::createSaveOptionsInstance

Description

This command creates an saSaveOptionsInstance object.

Syntax

```
sa::createSaveOptionsInstance <instance: string> [-instType <enum>]  
-level <string>
```

Returns

<saSaveOptionsInstance>: New saSaveOptionsInstance.

Arguments

instance
Instance-specific save options object.

-instType
Sets the type of signals to save under the instance. ({all | currents | nets | ports}).
Default: all.

-level
Number of levels to save under the instance.

sa::createScatterChart

Description

Creates an saScatterChart object.

Syntax

```
sa::createScatterChart -enabled <bool> -xAxisType <enum> -xAxisName  
  <string> -yAxisType <enum> -yAxisName <string> -saveImage <bool>
```

Returns

<dbCore> : New scatter chart

Arguments

-enabled

Enabled.

-xAxisType

X-axis type. ({ inputParameter | measurement })

-xAxisName

X-axis name.

-yAxisType

Y-axis type. ({ inputParameter | measurement })

-yAxisName

Y-axis name.

-saveImage

Save image.

sa::createSDFConfig

Description

This command creates an SDF configuration file.

Syntax

```
sa::createSDFConfig <instance: string> -fileName <string> [-condition  
  <enum>] [-enabled <bool>]
```

Returns

<saSDFConfig>: New saSDFConfig

Arguments

instance

Instance name.

`-fileName`

SDF file path.

`-condition`

Timing Condition. ({ max | min | typ }). Default is *typ*.

`-enabled`

Specifies whether this line is output. Default is: *true*.

sa::createSelectionDef

Description

Creates the object that defines what signal is derived from your selection on the canvas.

Syntax

```
sa::createSelectionDef <name: string> -in <saSelectionGroupDef>  
  [-objectTypes [<string>]] [-objectFilters [<string>]] [-prompt <string>]  
  [-signalType <string>] [-filterProc <string>] [-promptTitle <string>]
```

Returns

The created saSelectionDef object.

Arguments

`<string>`

Selection name

`-in` [saSelectionDefGroup](#)

Selection group definition the new selection definition will be added to. The order in which an saSelectionDef is added is retained in the saSelectionDefGroup.

`-objectTypes` {<string>}

List of object types allowed for this selection.

Default: {}.

`-objectFilters` {<string>}

List of built-in object filters allowed for this selection.

`-prompt` <string>

Selection prompt.

`-signalType` <string>

Derived signal type.

`-filterProc <string>`

Tcl filter proc name.

Default: "".

`-promptTitle <string>`

User-specified selection prompt.

sa::createSelectionDefGroup

Description

Group of Selection Definitions that compose a sequence of signals to be obtained prior to using in an expression.

Syntax

```
sa::createSelectionGroupDef <name: string> -in <saExpressionDef> -label  
    <string>
```

Returns

A saSelectionDefGroup object.

Arguments

`<string>`

Selection group name.

`-in` [saExpressionDef](#)

Expression definition to which the selection group will be appended.

`-label <string>`

Selection group label.

sa::createSelectionGroupDef

Description

This command creates a selection group definition used by an expression definition on the Results Analyzer.

Syntax

```
sa::createSelectionGroupDef <string> -in <saExpressionDef> -label  
    <string>
```

Returns

A new selection group definitions (saSelectionGroupDef) object.

Arguments

<string>

Selection group name.

-in saExpressionDef

Expression definition to which the selection group will be appended.

-label <string>

Selection group label.

sa::createSession

Description

Creates a new multiple testbench session. The optional argument -name specifies a name for the new session. A name is autogenerated if no name is specified.

Syntax

```
sa::createSession [<name: string>] [-cellView <dmCellView>]  
[-testSuiteMode <bool>] [-addDefaultTestbench <bool>]
```

Returns

<saSession> : Newly created PrimeWave Design Environment session.

Arguments

name

Name of the session.

-cellView dmCellview

Cellview representing the design to be used in the default testbench.

-testSuiteMode

Test suite mode. Default is false.

-addDefaultTestbench

Add a default testbench when not in test suite mode. Default is true.

Examples

This command creates a new PrimeWave Design Environment session for the specified \$dmCellView.

```
set saSession [sa::createSession -cellView $dm]
```

sa::createSignalObj

Description

Creates object representing a signal to use in an expression.

Syntax

```
sa::createSignalObj <name: string> -type <enum> [-outOfContext <bool>]  
[-parentTerminal <string>]
```

Returns

The created saSignalObject.

Arguments

<string>

Signal name (including hierarchy).

-type

The signal type. ({current | derived | instance | logic | power | voltage})

-parentTerminal <string>

Name of optional co-dependent terminal signal (including hierarchy).

-outOfContext

Indicates that the signal is out of context.

Examples

This example creates a signal object with the voltage type.

```
set saSignalObj [sa::createSignalObj signalPath -type voltage]
```

sa::createSimulator

Description

This command registers a simulator for PrimeWave Design Environment application.

Syntax

```
sa::createSimulator <name: string> [-displayName <string>] [-description  
  <string>] [-optionsFile [<string>]] [-integrationVersion <int>]
```

Returns

New simulator object ([saSimulator](#)).

Arguments

<string>

Simulator name.

-displayName <string>

Display name.

-description <string>

A description of the specified simulator.

-optionsFile <string>

Name of the XML file(s) containing the simulator options.

-integrationVersion <int>

The simulator integration version number.

Default: 1.

sa::createSpecification

Creates specification for given output

Syntax

```
sa::createSpecification -output <string> -goalType <enum> [-extGoalType  
  <enum>] [-testbench <saTestbench>] [-goal <string>] [-goalHigh <string>]  
  [-goalLow <string>] [-poor <string>] [-poorHigh <string>] [-poorLow  
  <string>] [-cornerName <string>] [-enabled <bool>] [-tailType <enum>]  
  [-weight <string>] [-isOverride <bool>]
```

Returns

<saSpecification> : New specification

Arguments

-output

Output name

-goalType

Goal type ({ >Center< | Exact | Greater Than | Greater Than Equal | Inclusive Range | Less Than | Less Than Equal | Maximize | Minimize | Range })

-extGoalType

External Goal type ({ >Center< | Exact | Greater Than | Greater Than Equal | Inclusive Range | Less Than | Less Than Equal | Maximize | Minimize | Range }, default is: Greater Than)

-testbench

Testbench

-goal

Goal (Default is:)

-goalHigh

Goal high (Default is:)

-goalLow

Goal low (Default is:)

-poor

Poor (Default is: 0%)

-poorHigh

Poor high (Default is: 0%)

-poorLow

Poor low (Default is: 0%)

-cornerName

cornerName (Default is:)

-enabled

Enabled (Default is: true)

-tailType

Tail ({ Both | Left | Right }, default is: Both)

-weight

Weight (Default is: 1)

-isOverride

is create override spec or not

sa::createStimulusGroup

Creates a Stimulus Group

Syntax

```
sa::createStimulusGroup <name: string> (-window <giWindow | int> |  
-session <saSession> | -testbench <saTestbench>) [-nominalSection  
<string>] [-enabled <bool>]
```

Returns

<saStimulusGroup> : New stimulus group object

Arguments

name

Name of the stimulus group

-window

PrimeWave Window

-session

PrimeWave Session

-testbench

PrimeWave Testbench

-nominalSection

Nominal section name

-enabled

Enable status for the stimulus set (Default is: true)

sa::createStringSet

Description

Creates a named set of strings.

Syntax

```
sa::createStringSet <name: string>
```

Returns

<saStringSet> : New named string set

Arguments

name

Set name.

sa::createSweep

Description

Creates a new sweep on a testbench. The newly created sweep object is always appended to the end of all sweeps in a testbench.

Syntax

```
sa::createSweep <name: string> (-object <saObject> | -window  
<giWindow | int> | -session <saSession> | -testbench <saTestbench>)  
[-useSimulatorSweep <bool>] [-sweepType <enum>] [-variable <string>]  
[-isOpt <bool>] [-sweepRange <saSweepRange>]
```

Returns

New object ([saSweep](#)).

Arguments

-name <string>

Name for the sweep.

-sweepRange [saSweepRange](#)

Sweep range object defined for current sweep.

-variable <string>

The variable or parameter that is being swept.

-isOpt

Is created from optimization results or not.

-window

The PrimeWave Design Environment window.

-session

The PrimeWave Design Environment session.

-testbench

The PrimeWave Design Environment Testbench.

`-useSimulatorSweep`

Enable use of simulator sweep. (Default is: false)

`-sweepType`

Sweep type. ({ *dataDriven* | *singleVariable* }, default is: *singleVariable*)

Errors

- Invalid sweepRange object.
- Invalid testbench object.

Examples

The following example demonstrates the usage of `sa::createSweepRange`, `sa::createSweep`, and `sa::createDataRow`.

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set sweepRange [sa::createSweepRange sweepRange1 \
-rangeType Start/Stop \
-linearType StepSize \
-stepSize 0.05 -start 0 -stop 1.2 \
-stepType Linear ]

set sweep1 [sa::createSweep sweep1 -variable vdd \
-sweepType singleVariable \
-testbench $tb \
-useSimulatorSweep true \
-sweepRange $sweepRange]

set sweepVars [list xfreq temp vdc]
set sweepData [list [list 1G 55 1] [list 1.2G -40 1.2] [list 0.9G 125
0.95]]
set dataSweep [sa::createSweep dataSweep -sweepType dataDriven \
-testbench $tb -variable $sweepVars]
foreach data $sweepData {
set row [sa::createDataRow -sweep $dataSweep]
db::setAttr row.values -value $data
}
```

sa::createSweepDir

Description

This command creates the results sweep directory <name> for a testbench. Note that this command is typically only necessary when integrating a new simulator.

Syntax

```
sa::createSweepDir -name <string> -of <saTestbench>
```

Arguments

`-name <string>`

Name of the directory that will be created.

`-of`

Testbench whose results directory will be created.

sa::createSweepRange

Description

Creates a new sweep range.

Syntax

```
sa::createSweepRange <name: string> -rangeType <enum> [-start <string>]
[-stop <string>] [-center <string>] [-span <string>] [-poi <string>]
[-additionalPoints <string>] [-stepType <enum>] [-linearType <enum>]
[-linearPoints <string>] [-stepSize <string>] [-logType <enum>]
[-logPoints <string>]
```

Returns

New object ([saSweepRange](#)).

Arguments

`<string>`

Sweep range name.

`-rangeType`

Sweeps can be either Start/Stop, Center/Span or POI.

`-start <string>`

The start value for a Start/Stop type of sweep.

Default: "".

`-stop <string>`

The stop value for a Start/Stop type of sweep.

Default: "".

`-center <string>`

The center value for a Center/Span type of sweep.

Default: "".

`-span <string>`

The span value for a Center/Span type of sweep.

Default: "".

`-poi <string>`

A string containing blank separated points.

Default: "".

`-additionalPoints <string>`

Number of points in the range.

Default: "".

`-stepType`

Can be either Linear or Logarithmic.

Default: Linear.

`-stepSize <string>`

Step size in linear sweeps.

`-logType`

Qualifier for the number of points in a Logarithmic type, either per decade or per octave.

Default: Decade.

`-logPoints <string>`

Number of points per decade/octave.

Errors

- Center or span value specified when startStop type is used.
- Start or stop value specified when centerSpan type is used.
- Center, span, start or stop value specified when POI type is used.

Examples

The following example demonstrates the usage of `sa::createSweepRange`, `sa::createSweep`, and `sa::createDataRow`.

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set sweepRange [sa::createSweepRange sweepRange1 \
-rangeType Start/Stop \
```

```
-linearType StepSize \
-stepSize 0.05 -start 0 -stop 1.2 \
-stepType Linear ]

set sweep1 [sa::createSweep sweep1 -variable vdd \
-sweepType singleVariable \
-testbench $tb \
-useSimulatorSweep true \
-sweepRange $sweepRange]

set sweepVars [list xfreq temp vdc]
set sweepData [list [list 1G 55 1] [list 1.2G -40 1.2] [list 0.9G 125
0.95]]
set dataSweep [sa::createSweep dataSweep -sweepType dataDriven \
-testbench $tb -variable $sweepVars]
foreach data $sweepData {
set row [sa::createDataRow -sweep $dataSweep]
db::setAttr row.values -value $data
}
```

sa::createTBCDPLClass

Returns the run mode and history name of the session

Syntax

```
sa::createTBCDPLClass -of <saSession | saTestbench> -type <string> -limit
<string> -jc_name <string> -queue <string> -options <string>
```

Returns

<bool>

Arguments

-of

PrimeWave session or testbench to look for the cdpl job class

-type

job class type

-limit

job limit

-jc_name

jc_name name

-queue

queue

`-options`
`options`

sa::createTestbench

Description

Add a new testbench to the PrimeWave Design Environment session. An error is printed if there is already a testbench created in this session. A name for the testbench is created by appending an integer to "testbench" if no name is provided.

Syntax

```
sa::createTestbench -session <saSession> [-cellView <dmCellView>] [-name  
  <string>] [-simulator <string>]
```

Returns

The newly created saTestbench object.

Arguments

`-session`

The PrimeWave Design Environment session to which the testbench is to be added.

`-cellView dmCellview`

Cellview represents the design to be used in this testbench.

`-name <string>`

Name for the new testbench.

`-simulator <string>`

The simulator name for the testbench.

Examples

In this example, `sa::createTestbench` creates a testbench for the specified `saSession` (`$dmCellView` is optional).

```
set saTestbench [sa::createTestbench -session $saSession -cellview  
  $dmCellview]
```

sa::createVariableGroup

Creates a Variable Group

Syntax

```
sa::createVariableGroup <name: string> (-window <giWindow | int> |  
-session <saSession> | -testbench <saTestbench>) [-nominalSection  
<string>] [-enabled <bool>]
```

Returns

<saVariableGroup> : New variable group object

Arguments

name

Name of the model group

-window

PrimeWave Window

-session

PrimeWave Session

-testbench

PrimeWave Testbench

-nominalSection

Nominal section name

-enabled

Enable status for the model file (Default is: true)

sa::createWorstCaseCornerCondition

Description

Creates a worst case corner condition.

Syntax

```
sa::createWorstCaseCornerCondition <variableName: string> [-values  
<string>] [-nominal <string>]
```

Returns

<saWorstCaseCornerCondition> : New worst case corner condition

Arguments

`variableName`

The variable name.

`-values`

The corner condition values.

`-nominal`

The nominal value.

sa::createVDRcdb

Description

Create a VDRc database.

Syntax

```
sa::createVDRcdb <filePath: string> (-resultsDir <string> |  
-resultFile<string>) [-netlist <string>] [-nameMap <nlNameMap | string>]  
[-startTime <string>] [-stopTime <string>]
```

Returns

`<string>`

Arguments

`filePath`

Output file name.

`-resultsDir`

The PrimeWave Design Environment results directory.

`-resultFile`

The input simulator waveform file.

`-netlist`

The netlist associated with the specified `-resultFile`.

`-nameMap`

The name map for the specified `-resultFile`. Accepts either a name map object or the directory where name mapping is stored.

`-startTime`

Compute voltages based on given start time.

`-stopTime`

Ignore values after given stop time.

sa::deleteHistoryPoint

Description

Deletes the specified history point.

Syntax

```
sa::deleteHistoryPoint -name <string> -session <saSession>
```

Returns

<bool> : True if history point is deleted

Arguments

`-name`

The name of the history point.

`-session`

PrimeWave Design Environment session in which the history point is to be deleted.

Examples

The following example deletes the active history point results directory.

```
set session [ss::getActiveSession]
set activeHP [sa::findActiveHistoryPoint -session $session]
sa::deleteHistoryPoint -name $activeHP -session $session
```

sa::deleteJobClass

Delete Job CClass

Syntax

```
sa::deleteJobClass -jobClassName <string>
```

Returns

<none>

Arguments

`-jobClassName`
`jobClassName`

sa::deleteOutput

Description

Deletes an output from testbench. Output to be deleted can be specified by name and/or expression.

Syntax

```
sa::deleteOutput <name: string> [-testbench <saTestbench> | -dialog  
  <giDialog>] [-expr <string>] [-outputSet <string>]
```

Arguments

`<string>`

Name of the output to be deleted.

`-testbench`

Testbench object (testbench or dialog must be specified).

`-dialog giDialog`

Output Setup dialog from which output is to be deleted.

`-expr <string>`

Expression. In the case of a signal, this is the net or terminal name.

`-outputSet <string>`

Output set from which output is to be deleted.

Examples

This example deletes an output from a testbench.

```
sa::deleteOutput outputName -testbench $saTestbench
```

sa::deleteResults

Deletes the results for a testbench

Syntax

```
sa::deleteResults -of <saTestbench> [-keepNetlistDir <bool>]
```

Returns

<none>

Arguments

-of

Testbench whose corner/sweep directories will be deleted

-keepNetlistDir

Keep netlist dir (Default is: false)

sa::deleteSelected

Description

Deletes variables, outputs, or analyses selected in the PrimeWave Design Environment window.

Syntax

```
sa::deleteSelected -window <giWindow> | <int>
```

Arguments

-window *giWindow* | <int>

PrimeWave Design Environment window object or id.

Examples

The following example deletes selected objects from a given PrimeWave Design Environment window.

```
sa::deleteSelected -window 3
```

sa::deleteTBCDPLClass

Returns the run mode and history name of the session

Syntax

```
sa::deleteTBCDPLClass -of <saSession | saTestbench> [-force <bool>]
```

Returns

<none>

Arguments

`-of`

PrimeWave session or testbench to look for the CDPL job class

`-force`

Force to shutdown (Default is: false)

sa::deleteTestSuiteResults

Description

Deletes the test suite results archived in a path.

Syntax

```
sa::deleteTestSuiteResults -rootPath <string>
```

Arguments

`-rootPath`

Root path from where the test suite results are going to be deleted.

sa::directPlot

Description

This command plots the result for given result type. It prompts the user to select devices, nets, or terminals in the design window and plots the data for selected circuit element. The design window is opened if it is not already open.

Syntax

```
sa::directPlot <type: string> [-modifier <string>] [-dataType <string>]  
[-secondaryResultTypes <string>] -window <giWindow | int>
```

Returns

`<bool>`: Plot the outputs of the probed signal.

Arguments

`<string>`

Result type to plot.

`-Modifier`

Modifier.

`-dataType`

Data type.

`-secondaryResultTypes`

Secondary result types for signal plotting.

`-window giWindow | <int>`

The PrimeWave Design Environment window object or id.

Errors

- No testbench is defined in this window.
- The window is not a PrimeWave Design Environment window.
- Data for given analysis type is not available.
- Invalid result type specified.

sa::displayLog

Description

This command displays the simulation log in a file viewer.

Syntax

`sa::displayLog -window <giWindow> | <int>`

Arguments

`-window giWindow | <int>`

The PrimeWave Design Environment window object or id.

Errors

- No testbench is defined in this window.
- The window is not a PrimeWave Design Environment window.
- Log file not found.

Examples

The following example opens the simulation log file from the specified PrimeWave Design Environment window.

```
set winID 4
sa::displayLog -window $winID
```

sa::displayNetlist

Description

This command displays the final netlist in a file viewer.

Syntax

```
sa::displayNetlist -window <giWindow> | <int>
```

Arguments

```
-window giWindow | <int>
```

The PrimeWave Design Environment window object or id.

Errors

- No testbench is defined in this window.
- The window is not a PrimeWave Design Environment window.
- Netlist not found.

Examples

The following example opens the final netlist file from the specified PrimeWave™ Design Environment window in the internal text viewer.

```
set winID 4
sa::displayNetlist -window $winID
```

sa::DSPFPatch

Create new DSPF file(s) for the given design parameter values

Syntax

```
sa::DSPFPatch -testbench <saTestbench> -directory <string> -parameters  
[<string>] [-uniqueID <string>] [-remoteRunJob <bool>]
```

Returns

<string> : Returns the list of original and updated DSPF file names

Arguments

```
-testbench
```

Testbench

`-directory`

The directory in which DSPF files to be created

`-parameters`

List of design parameter name value pairs

`-uniqueID`

An uniqueID for dspf::ecoUpdateDSPF to naming temparay library (Default is:)

`-remoteRunJob`

Is executing dspf::ecoUpdateDSPF job on remote (Default is: 0)

sa::dumpResultsView

Dump Results View.

Syntax

```
sa::dumpResultsView -testbench <saTestbench> [-history <string>]  
-saveDir <string> [-exportFiltered <string>] [-reportHtml  
<string>] [-filterErrEquation <string>] [-exportCurTable <string>]  
[-exportSelTable <string>] [-verInfo <string>] [-showWaveFormExpr  
<string>]
```

Returns

<none>

Arguments

`-testbench`

Testbench

`-history`

History name

`-saveDir`

Path to save

`-exportFiltered`

Export filtered or not

`-reportHtml`

Dump reportHtml or not

`-filterErrEquation`
Filter error equations or not

`-exportCurTable`
Export current table

`-exportSelTable`
Export selected table

`-verInfo`
Dump version information

`-showWaveFormExpr`
Show wave form expression

sa::editDesVars

Description

Edit the variables.

Syntax

```
sa::editDesVars (-window <giWindow | int> | -testbench <saTestbench>
| -session <saSession>) [-variableSet <string>] [-filePath <string>]
[-allTestbenches <bool>]
```

Returns

<none>

Arguments

`-window`
PrimeWave main console window.

`-testbench`
Testbench

`-session`
Session

`-variableSet`
Name of variable set to load into.

`-filePath`

File path to which to save the design variables.

`-allTestbenches`

Edit all testbench design variables. (Default is: false)

Examples

The following example exports testbench variables into an external file. The file will be automatically imported back to the active session/testbench on close.

```
# Open file, add/delete/modify variables.  
# File will be imported into active testbench/session on close  
set winID 4  
sa::editDesVars -window $winID -filePath designVars.txt
```

sa::editNetlist

Description

This command opens the final netlist for editing in a file editor.

Syntax

```
sa::editNetlist -window <giWindow> | <int>
```

Arguments

`-window giWindow | <int>`

The PrimeWave Design Environment window object or id.

Errors

- No testbench is defined in this window.
- The window is not a PrimeWave Design Environment window.
- Netlist not found.

Examples

The following example opens the final netlist file from the specified PrimeWave Design Environment window in the external text editor.

```
set winID 4  
sa::editNetlist -window $winID
```

sa::editOutputs

Edit the outputs.

Syntax

```
sa::editOutputs (-window <giWindow | int> | -testbench <saTestbench>  
| -session <saSession>) [-outputSet <string>] [-filePath <string>]  
[-allTestbenches <bool>]
```

Returns

<none>

Arguments

-window

PrimeWave main console window

-testbench

Testbench

-session

Session

-outputSet

Name of output set to load into.

-filePath

File path to which to save the outputs.

-allTestbenches

Edit all testbench outputs. (Default is: false)

sa::emitRefreshIterativeResultsTable

Description

This command emits a refreshIterativeResultsTable event.

Syntax

```
sa::emitRefreshIterativeResultsTable -testbench <saTestbench> -resultsDir  
<string> -refresh <enum> [-iteration <string>] [-completion <string>]
```

Arguments

`-testBench`

The testbench object.

`-resultsDir <string>`

The results directory.

`-refresh <enum>`

The refresh action.

`-iteration`

Iteration information.

`completion`

Percentage completion.

sa::emitRefreshMeasurementSummaryDialog

Description

This command emits a refreshMeasurementSummaryDialog event.

Syntax

```
sa::emitRefreshMeasurementSummaryDialog -testbench <saTestbench>
```

Arguments

`-testBench`

The testbench object.

sa::emitSimulationDone

Description

This command emits an onPostSimulationDone event.

Syntax

```
sa::emitSimulationDone <testbench: saTestbench> -status <enum> [-isChild  
<bool>] [-resultsDir <string>]
```

Arguments

`-testBench`

The testbench object.

`-status <enum>`

Status of the simulation job.

`-isChild <bool>`

Specifies whether this is a child simulation.

Default: false.

`-resultsDir <string>`

The results directory.

sa::emitUpdateIterativeResultsWindow

Description

This command emits the updated Iterative Results Window.

Syntax

```
sa::emitUpdateIterativeResultsWindow -testbench <saTestbench> -resultsDir  
<string> -measurement <string> -analysis <string> -action <enum> -value  
<string>
```

Arguments

`-testBench`

The testbench object.

`-resultsDir <string>`

The results directory.

`-measurement <string>`

The measurement name.

`-analysis <string>`

The analysis to be used.

`-action <enum>`

specify the action to be taken.

`-value <string>`

Value.

sa::evaluateAceScripts

Description

This command evaluates ACE scripts.

Syntax

```
sa::evaluateAceScripts <testbench: saTestbench> [-callback  
  [<string>]] [-resultsDir <string>]
```

Returns

<none>

Arguments

testbench

The PrimeWave Design Environment testbench.

-callback

Callback procedure on completion.

-resultsDir

Results directory for procedure execution

sa::evaluateExpressions

Description

Evaluates the output expressions for the Results Viewer.

Syntax

```
sa::evaluateExpressions (-window <giWindow | int> | -session <saSession>)  
  [-update <enum>] [-testbenchNames <string>] [-saveImage <bool>]  
  [-forceAll <bool>]
```

Returns

<none>

Arguments

-window

The PrimeWave Design Environment window.

-session

The PrimeWave Design Environment session.

-update

Update type. ({ completedAndRunningJobs | completedJobs | completedTestbench } Default is: completedAndRunningJobs)

-testbenchNames

Names of testbenches to evaluate. (Default is: all)

-saveImage

Allow saving images (Default is: false)

-forceAll

Force re-evaluate all expressions (Default is: false)

Examples

```
# Get session object from active window
set s [sa::getSessions -window 10]
sa::evaluateExpressions -session $s -update completedJobs
```

sa::evaluateMonteCarloScalarExpressions

Description

Evaluates Monte Carlo Scalar expressions.

Syntax

```
sa::evaluateMonteCarloScalarExpressions -testbench <saTestbench>
```

Arguments

-testbench

Testbench.

sa::executeFlowAction

Description

Execute an PrimeWave Design Environment flow action.

Syntax

```
sa::executeFlowAction <flowAction: saFlowAction>
```

Returns

<saFlowAction> : New PrimeWave Design Environment flow action.

Arguments

`flowAction`

Flow action to execute.

sa::executeDeviceGroupAction

Execute a Device Group Action

Syntax

```
sa::executeDeviceGroupAction [-dialog <giDialog>] [-type <enum>]
```

Returns

<none>

Arguments

`-dialog`

design_param_dialog

`-type`

Device group action type ({ add | addExistingGroup | addNewGroup |
clearGroup | deleteAll | findMatched | promoteAllToGlobal | promoteToGlobal |
refresh | ungroup | unknown }, default is: unknown)

sa::exportAndLaunchVerdiCov

Description

Exports data and launches the Verdi Coverage Tool.

Syntax

```
sa::exportAndLaunchVerdiCov -window <giWindow | int>
```

Returns

<bool> : Status of exported action.

Arguments

`-window`

Main window.

sa::exportChart

Description

Exports a PrimeWave Design Environment data mining chart to an image file.

Syntax

```
sa::exportChart <window: giWindow | int> -chartType <string>  
[-testbenchName <string>]
```

Returns

<none>

Arguments

window

The charts window.

-chartType

The chart type. (measureVsMeasure or parallelAxis)

-testbenchName

The name of the testbench.

sa::exportChartImage

Description

Exports an image of the currently selected chart in the given saChartsWindow to the specified filename.

Syntax

```
sa::exportChartImage <window: giWindow | int> -testbench <saTestbench>  
-chartType <enum> -filename <string>
```

Returns

<none>

Arguments

window

Charts window.

-testbench

Testbench.

`-chartType`

Chart type. ({ histogram | qq | scatter })

`-filename`

Path to save.

sa::exportCopyNetlist

Description

Copy netlist files of an saTestbench.

Syntax

```
sa::exportCopyNetlist <file: string>
```

Returns

<none>

Arguments

`file`

Output file path.

Examples

The following example copies the nominal netlist and related files of the active testbench into the specified directory.

```
sa::exportCopyNetlist ./netlists
```

sa::exportCSVFromResultsViewer

This command exports all results views in the Results Viewer to CSV.

Syntax

```
sa::exportCSVFromResultsViewer <session: saSession> [-exportDir <string>]  
[-exportFiltered <bool>] [-filterErrEquation <bool>] [-showWaveFormExpr  
<bool>]
```

Returns

<none>

Arguments

`session`

Session

`-exportDir`

Base directory under which CSV files will be written (Default is: .)

`-exportFiltered`

Export filtered table content to CSV files (Default is: true)

`-filterErrEquation`

Export filtered error equations in table content to CSV files (Default is: false)

`-showWaveFormExpr`

Show waveform in CSV files (Default is: false)

sa::exportGroupDef

Exports a GroupDef to a Tcl script

Syntax

```
sa::exportGroupDef <def: saIncludeGroupDef | saStimulusGroupDef |  
saVariableGroupDef> -file <string> [-readOnly <bool>] -type <string>
```

Returns

<none>

Arguments

`def`

The group definition.

`-file`

Output file path.

`-readOnly`

Export as a readonly group definition.

`-type`

type of the def

sa::exportModelGroupDef

Description

Exports an saModelGroupDef to a Tcl script.

Syntax

```
sa::exportModelGroupDef <def: saModelGroupDef> -file <string> [-base  
  <bool>] [-readOnly <bool>]
```

Arguments

def

The model group definition.

-file

The output file path.

-base

Specify as base model group definition.

-readOnly

Export as a read-only model group definition.

sa::exportReportHtml

Exports an HTML file report of an saTestbench.

Syntax

```
sa::exportReportHtml <file: string>
```

Returns

<none>

Arguments

file

Output file path.

sa::exportResultData

Exports summary result data of an saTestbench.

Syntax

```
sa::exportResultData <file: string>
```

Returns

<none>

Arguments

file

Output file path.

sa::exportResultDataBySpec

Exports summary result data of an saTestbench by Spec file

Syntax

```
sa::exportResultDataBySpec <file: string>
```

Returns

<none>

Arguments

file

Output file path.

sa::exportResultsViewsToCSV

Description

This command exports one or more Result Views to CSV file(s) format.

Syntax

```
sa::exportResultsViewsToCSV -window <int> [-keepSortOrder <bool>]
```

Arguments

-window

Results View window.

-keepSortOrder <bool>

Specifies whether the sorting order is preserved in the output CSV file (default is true).

Examples

```
# Exports one or more Result Views to CSV file(s).
sa::exportResultsViewsToCSV -window 11
# We recommend using exportCSVFromResultsViewer from scripts
```

sa::exportScript

Exports an saTestbench as a Tcl script.

Syntax

```
sa::exportScript -parent <giWindow | int>
```

Returns

<string> : Script file name

Arguments

-parent
PrimeWave Design Environment main window.

sa::exportSessionReport

Description

Exports session information in HTML format.

Syntax

```
sa::exportSessionReport <session: saSession> [-baseDir
<string>] -contentsSelection [<string>] [-reportType <string>]
[-singleReportFileName <string>]
```

Returns

<none>

Arguments

session
Session

-baseDir
Base directory under which report files will be written (Default is: .)

-contentsSelection
Options to select what contents will be written to report

`-reportType`

Select the way report is written: multiple files or a single file (Default is: Multi-File)

`-singleReportFileName`

Specify filename for the single file (Default is: ./report.html)

Examples

The following example saves the HTML report (Setup, Measurements Summary, and so forth) of the specified session.

```
set session [ss::getActiveSession]
# Save in single file
sa::exportSessionReport $session -baseDir [file join ./reports
[db::getattr session.name]] \
    -contentsSelection {} -singleReportFileName report.html \
    -reportType single
```

sa::exportToCSV

Description

This command exports the table of the given iterative results window to the given file in CSV format.

Syntax

```
sa::exportToCSV -filePath <string> -window <int>
```

Arguments

`-window <int>`

Iterative results window.

`-filePath <string>`

File to which table will be exported in CSV format.

sa::exportToVerdiCov

Description

Exports data to the Verdi Coverage Tool.

Syntax

```
sa::exportToVerdiCov -session <saSession>
```

Returns

<bool> : Status of exported action.

Arguments

-session

Parent session for the export files.

sa::showExternalImages

Description

Shows the **External Images** dialog box.

Syntax

```
sa::showExternalImages -parent <giWindow | int>
```

Returns

<giDialog> : Dialog object

Arguments

-parent

PrimeWave Design Environment main window.

sa::findActiveHistoryPoint

Description

Returns the active history point name.

Syntax

```
sa::findActiveHistoryPoint -session <saSession>
```

Returns

<string> : The name of the active history point

Arguments

-session

The PrimeWave Design Environment session in which to find the active history point.

Examples

```
# Find session object from active window
set session [sa::getSessions -window 4]
# Find active history point name for given session
puts [sa::findActiveHistoryPoint -session $session]
```

sa::findActiveTestbench

Description

Returns the active testbench in a window.

Syntax

```
sa::findActiveTestbench -window <giWindow | int>
```

Arguments

-window

The PrimeWave Design Environment window.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 4]
# Print name of the testbench
puts [db::getattr tb.name]
```

sa::findClosestIterations

Find the closest scalar value's index to the user's input with given corner name

Syntax

```
sa::findClosestIterations -testbench <saTestbench> -input <string>
                           -corner <string> [-debug <bool>]
```

Returns

<none>

Arguments

-testbench

Testbench

-input

Measure name with values groups

`-corner`

Corner name

`-debug`

Enable debug mode (Default is: false)

sa::findDesignVariableGroupDefs

find a variable group

Syntax

```
sa::findDesignVariableGroupDefs <name: string> (-window <giWindow | int>  
| -session <saSession> | -testbench <saTestbench>)
```

Returns

<saVariableGroupDef> : New variable group object

Arguments

name

Name of the group name

`-window`

PrimeWave Window

`-session`

PrimeWave Session

`-testbench`

PrimeWave Testbench

sa::findDuplicates

Description

This command returns a collection of duplicate `saCorner` objects found in the specified `<saCornersSetup>` object. You can use the `db::destroy` command for removing the duplicate corners returned from this command.

Syntax

```
sa::findDuplicates -of <saCornersSetup>
```

Returns

Collection of saCorner ({saCorner}).

Arguments

-of saCorner

The corners setup object.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 4]
# Get corners setup object
set cornersSetup [db::getattr tb.cornersSetup]
# Find duplicate corners. Command returns collection of corner objects
set dupCorners [sa::findDuplicates -of $cornersSetup]
db::foreach c $dupCorners {
  puts [db::getattr c.name]
}
```

sa::findId

Description

Get testbench/session id.

Syntax

```
sa::findId (-session <saSession> | -testbench <saTestbench>)
```

Arguments

-session

The PrimeWave Design Environment session to look for the id.

-testbench

The PrimeWave Design Environment testbench to look for the id.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 4]
# Returns unique ID for the testbench
set id [sa::findId -testbench $tb]
# Setting preference in active testbench
db::setPrefValue saResultsDir -scope [db::getScopes $id] \
-value "./myPath"
```

sa::findIncludeGroupDef

Returns the saIncludeGroupDef from the given testbench or parent session

Syntax

```
sa::findIncludeGroupDef <name: string> [-parent <giWindow | int> |  
-session <saSession> | -testbench <saTestbench>]
```

Returns

<saIncludeGroupDef> : The include group definition object

Arguments

name

Include group definition name

-parent

PrimeWave Window

-session

PrimeWave Session

-testbench

PrimeWave Testbench

sa::findIterations

Find Iterations

Syntax

```
sa::findIterations -testbench <saTestbench> [-allLevels <bool>] [-params  
[<string>]] [-worstCases <bool>] [-debug <bool>]
```

Returns

<none>

Arguments

-testbench

Testbench

-allLevels

allLevels (Default is: false)

-params

Params list

-worstCases

Indicates that it contains worstCases (Default is: false)

-debug

Enable debug mode (Default is: false)

sa::findModelGroupDef

Description

Finds a model group definition object with the given name in the given testbench, or the parent session of a testbench if the session is a test suite. Returns the saModelGroupDef from the given testbench or parent session.

Syntax

```
sa::findModelGroupDef <name: string> [-parent <giWindow | int> | -session  
  <saSession> | -testbench <saTestbench>]
```

Returns

<saModelGroupDef> : The model group definition object.

Arguments

name

Model group definition name.

-parent

The PrimeWave Design Environment window.

-session

The PrimeWave Design Environment session.

-testbench

The PrimeWave Design Environment testbench.

Examples

```
# Get testbench object from active window  
set tb [sa::findActiveTestbench -window 3]  
# Get model group definition, providing group name and testbench object  
set modGroupDef [sa::findModelGroupDef mos_model -testbench $tb]  
# Print model group attributes like Include Path of file names of model  
  files within the group
```

```
puts [db::getAttr modGroupDef.includePath]
> ./models
db::createList [db::getAttr modGroupDef.files.filename]
> mos.lib mos_hv.lib
```

sa::findModelLanguage

Description

This command finds the name of the model language.

Syntax

```
sa::findModelLanguage <filePath: string>
```

Arguments

-string

Name of the model file.

Examples

```
# Returns simulator language for provided model file
puts [sa::findModelLanguage ./models/mos.lib]
> spice
puts [sa::findModelLanguage ./spectre_models/dsv.scs]
> spectre
```

sa::findModuleName

Description

This command finds the subcircuit name for the given instance path.

Syntax

```
sa::findModuleName <name: string> (-netlistDir <string> | -testbench
  <saTestbench>)
```

Arguments

-string

Name of instance path.

-netlistDir <string>

Netlist directory.

-testbench

The testbench object.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
# Get mapped module name for given instance name
puts [sa::findModuleName $instName -testbench $tb]
> opamp
```

sa::findNameMap

Description

This command finds a new Name Map object.

Syntax

```
sa::findNameMap (-netlistDir <string> | -testbench <saTestbench>)
```

Arguments

-netlistDir <string>

Netlist directory.

-testbench

The testbench object.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
# Find name map object
set nm [sa::findNameMap -testbench $tb]
puts [db::getAttr nm.closeBrace]
puts [db::getAttr nm.openBrace]
```

sa::findSaveSignals

Description

This command finds the signals in the schematic namespace to be saved during the simulation.

Syntax

```
sa::findSaveSignals (-expr <string> | -outputSet <saOutputSet | string>)
  [-analysis <string>] -testbench <saTestbench> [-includeProbeNames
  <string>]
```

Returns

<string>: Returns the collection of signal type and names.

Arguments

-expr

Expression.

-outputSet

Output set.

-analysis

Analysis definition name.

-testbench

Testbench.

-includeProbeNames

Include probe names as part of signal info. The default is false.

Examples

```
sa::findSaveSignals -outputSet set1 -testbench [ss::getActiveTestbench]
```

In this example, `sa::findSaveSignals` prints the saved signal names in set1 (output set name).

```
set ssn [sa::getSessions]
set tbs [sa::getTestbenches -of [db::getNext $ssn]]
sa::findSaveSignals -expr falltime(v(/X0/X6/PBIAS),1.1,0.1,1) \
    -testbench $tbs
```

In this example, `sa::findSaveSignals` finds the signal name associated with the written expression in all the output sets.

sa::findSessionName

Description

This command determines the SAE session (saSession) name for the given testbench.

Syntax

```
sa::findSessionName -of <saTestbench>
```

Returns

The session name.

Arguments

-of

Testbench whose session name will be returned.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
# Find session name for given testbench
puts [sa::findSessionName -of $tb]
```

sa::findSigmaIterations

Find the monte index of the closest sigma value to the user's input and the corner name

Syntax

```
sa::findSigmaIterations -testbench <saTestbench> -input <string> [-params  
  <string>] [-debug <bool>]
```

Returns

<none>

Arguments

-testbench

Testbench

-input

Measure name with values groups

-params

Corner name (Default is: false)

-debug

Enable debug mode (Default is: false)

sa::findStimulusGroupDef

Returns the saStimulusGroupDef from the given testbench or parent session

Syntax

```
sa::findStimulusGroupDef <name: string> [-parent <giWindow | int> |  
  -session <saSession> | -testbench <saTestbench>]
```

Returns

<saStimulusGroupDef> : The stimulus group definition object

Arguments

name

Stimulus group definition name

-parent

PrimeWave Window

-session

PrimeWave Session

-testbench

PrimeWave Testbench

sa::findVariablesFromNetlist

Find all variables from netlist if no wildcard is specified, else matching variables

Syntax

```
sa::findVariablesFromNetlist <filePath: string> [<wildcard: string>]  
[<caseSensitive: string>]
```

Returns

<string> : Variables list

Arguments

filePath

Netlist file

wildcard

Wildcard to filter variables

caseSensitive

Option to enable case Sensitivity of wildcard

sa::findWindow

Description

This command finds the PrimeWave Design Environment window that corresponds to testbench/session.

Syntax

```
sa::findWindow -of <saSession | saTestbench>
```

Arguments

-of

The PrimeWave Design Environment session or testbench to look for the window.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
# Get window object for given testbench or session
set win [sa::findWindow -of $tb]
# Get any window attribute latter on
puts [db::getattr win.id]
```

sa::findWorstCornerName

find the worst corner name in specified global equation

Syntax

```
sa::findWorstCornerName -testbench <saTestbench> -meas <string> [-debug  
<bool>]
```

Returns

<none>

Arguments

-testbench

Testbench

-meas

Measure Name

-debug

Enable debug mode (Default is: false)

sa::flattenTestbench

Description

This command identifies the global scope configurations of the testsuite that are inherited by the testbench, and copy them into the testbench. The resulting testbench contains only local configurations and none inherited from the global scope.

Syntax

```
sa::flattenTestbench <testbench: saTestbench> [-to <saTestbench>]  
[-categories [<string>]]
```

Arguments

testbench

Testbench

-to

Destination testbench to receive flattened data.

Default: testbench argument.

-categories

Categories to serialize to destination testbench after flattening operation
(preexisting categories are not purged).

sa::formatExpression

Description

This command converts PrimeWave Design Environment expressions to expressions that are compatible with the target simulator's language. For example in PrimeWave Design Environment the suffix "M" means Mega (1e6). However HSPICE requires "meg" or "x".

Syntax

```
sa::formatExpression <expression: string> -netlister <nlNetlister>
```

Returns

The formatted expression.

Arguments

expression <string>

The expression to format.

`-netlister`

The netlister.

Examples

```
# Formats given expression for specified netlist language
puts [sa::formatExpression (0.5u+a)*scale \
-netlister [nl::getNetlisters Verilog]]
> ((5e-7+`a)*`scale)
puts [sa::formatExpression (0.5u+a)*scale \
-netlister [nl::getNetlisters HSPICE]]
> ((0.5u+a)*scale)
```

sa::formatNumeric

Format numeric with specified style

Syntax

```
sa::formatNumeric <numeric: string> [-notation <enum>] [-precision <int>]
[-suffix <enum>] [-radix <enum>]
```

Returns

<string> : Formatted numeric string

Arguments

`numeric`

Numeric string

`-notation`

Notation ({ engineering | scientific }, default is: engineering)

`-precision`

Precision (Default is: 6)

`-suffix`

Suffix ({ G | K | M | T | g | k | m | n | p | u })

`-radix`

Radix ({ ascii | auto | binary | decimal | default | hexadecimal | octal | signed },
default is: default)

sa::generateCorners

Description

Generates corners by cross-product for the given parameter ranges.

Note:

Design variables and model files must exist as `saCornerParamDefs` before they can be referenced by name in `sa::generateCorners`. The one exception is the `temp` variable which represents the simulation temperature and is always defined as a corners parameter. For more information, see [sa::createCornerParameterDef](#).

Syntax

```
sa::generateCorners [<prefix: string>] -cornersSetup <saCornersSetup>  
  [-params <string>] [-models <string>] [-includes <string>] [-replace  
  <bool>]
```

Arguments

`prefix`

Corner name prefix.

`-cornerSetup`

Corner setup.

`-params`

List of parameter name / range pairs. Requires a tcl list with an even number of elements, consisting of alternating design variable names and values. A value can be a list of values, or a sweep specifier using `start:step:stop` syntax.

`-models`

List of model files or model groups, and optional sections. Requires a list, where each element is a list of one or two elements. If an element is a pair, the first is the model file and the second is a list of the sections to be included.

`-includes`

List of include file parameter names/file names.

`-replace`

Replace existing corners.

Default is: false.

Examples

To generate several corners at once using the given corner parameter conditions:

```
set tb [sa::findActiveTestbench -window 2]
set cs [db::getattr tb.cornersSetup]
sa::generateCorners C -cornersSetup $cs -params {temp {25,125} vdd
{1,1.2}} -models {{reference40_models.lib {TT FF SS}}}
```

This example generates corners using the testbench corners setup. It uses the prefix "C" for the generated corner names. This example generates 12 corners: 2(temp)x2(vdd)x3(model corner).

sa::generateReports

Description

Generates the specified reports in a session.

Prints report matching the given name. If no name is provided, all reports are printed.

Syntax

```
sa::generateReports [<reportName: string>] -session <saSession>
```

Returns

<none>

Arguments

reportName

Name or pattern to match report names (default "" generates all).

-session

Parent session.

Errors

- If a report with the same name as the `-in` argument is not found in the session specified by the `-session` argument, an error will be raised.

sa::getAnalyses

Description

This command returns the collection of analyses for testbench.

Syntax

```
sa::getAnalyses [<pattern: string>] [-filter <string>] -of <saTestbench>
```

Returns

<dbCollection> : Analyses matching search criteria.

Arguments

pattern <string>

Pattern to match object name.

-filter <string>

Standard attribute filter.

-of

The testbench object.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set analyses [sa::getAnalyses -of $tb]
puts [db::getCount $analyses]
> 3 # Number of existing analyses
# List all analyses names
puts [db::createList [db::getattr analyses.name]]
> ac op lstb
```

sa::getAnalysisDefs

Description

This command returns the list of analysis definitions for a given simulator.

Syntax

```
sa::getAnalysisDefs [<pattern: string>] [-filter <string>] -of  
  <saSimulator>
```

Returns

Analysis definitions matching search criteria (dbCollection).

Arguments

pattern <string>

Pattern to match object name.

`-filter <string>`

Standard attribute filter.

`-of`

The testbench object.

Examples

```
#Get all analysis definitions for provided simulator
set defs [sa::getAnalysisDefs -of [sa::getSimulators HSPICE]]
puts [db::createList [db::getAttr defs.name]]
```

sa::getBackupRunDirs

Description

Returns the list of backup directories for a testbench.

Syntax

```
sa::getBackupRunDirs -of <saTestbench>
```

Returns

<string> : Tcl list of backup directories.

Arguments

`-of`

Testbench whose backup directories are listed.

sa::getCDPLClass

Returns the run mode and history name of the session.

Syntax

```
sa::getCDPLClass -of <saSession | saTestbench> -type <string>
```

Returns

<xtJobClass> : xtJobClass object for the job class.

Arguments

`-of`

SAE session or testbench to look for the CDPL job class.

`-type`
Job class type.

sa::getCDPLMember

Get the member in CDPL CLass

Syntax

```
sa::getCDPLMember -member <string>
```

Returns

`<int | string> : cdpl member`

Arguments

`-member`
cdpl member

sa::getCornerParameters

Description

This command returns a collection of saPair objects, defined for the specified corner in the cornersSetup, which match the pattern. Filter option can be used to pare down the returned list.

Syntax

```
sa::getCornerParameters [<pattern: string>] [-filter <string>]  
-cornerName <string> -of <saCornersSetup>
```

Returns

Collection of saPair ({}).

Arguments

`<string>`
Return saPair objects which have names matching this pattern.

`-cornerName <string>`
The corner name in which parameters need to searched.

`-filter <string>`
Standard filter.

-of `saCornersSetup`

The corners setup object.

Examples

If you have a corner name and want to get information for its parameter definitions and their values, you can use following example to get the corner parameters from the specified corner:

```
set tb [sa::findActiveTestbench -window 2]
set cs [db::getattr tb.cornersSetup]
set corParams [sa::getCornerParameters -cornerName C1 -of $cs]
db::foreach corParam $corParams {puts "[db::getattr
  corParam.name]=[db::getattr corParam.value]"}
```

This example gets all the parameters from corner C1, iterates them, and prints the parameter name and its value.

sa::getCorners

Description

This command returns a collection of corner objects defined for a cornersSetup which match the pattern. The -filter option can be used to pare down the returned list.

Syntax

```
sa::getCorners [<pattern: string>] [-filter <string>] -of
  <saCornersSetup>
```

Returns

Collection of saCorner objects ({`saCorner`}).

Arguments

-pattern <string>

Return corners whose names match the pattern.

-filter <string>

Standard attribute filter.

-of `saCornersSetup`

The corners setup object.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set cs [db::getattr tb.cornersSetup]
```

```
set corners [sa::getCorners -of $cs]
db::foreach c $corners {
puts "[db::getattr c.enabled]\t[db::getattr c.name]\t[db::createList
[db::getattr c.parameters.value]]"
}
```

sa::getCumulativeFrequency

Description

Returns the cumulative frequency for given measurement.

Syntax

```
sa::getCumulativeFrequency <measurement: string> (-resultsDir <string>
| -testbench <saTestbench>) [-binCount <int>] [-analysis <string>]
[-parameter <string>] [-paramValue <string>]
```

Returns

<string> : cumulative frequency

Arguments

measurement

Measurement name.

-binCount

Bin count. The default is 20.

-analysis

Analysis name.

-parameter

Parameter name.

-paramValue

Parameter value.

-resultsDir

The results directory.

-testbench

The PrimeWave Design Environment testbench.

sa::getData

Description

Generic API for accessing the waveform signal or scalar value from the simulation output files created from any analysis run. To access the signal, this API does the following:

- Finds the simulator name and the netlist directory using the results map objects which are created from resultsMap.xml and results.xml files in the resultsDir.
- From the results map objects, finds the simulation output file corresponds to the resultsType and analysisName (if specified). If the resultsType is opTran, the value of the time argument is also used for finding the simulation output file.

If the type is not specified, it finds the signal type (net/instance/terminal) only if the signal name is specified and if it is in the schematic namespace.

The signal name is then mapped into the netlister namespace.

If the dataType is not specified, it uses the defaults based on type and resultsType.

Calls the integrator callback procedure sa::<simulator>::<resultsType>::dataMap procedure for getting the signal name to use for accessing the signal.

In addition to the netlist directory, the following values are passed to the dataMap procedure:

- Signal name.
- Data type specified in dataType argument of sa::getData.
- Parameter name specified in the param argument of sa::getData.

Use the signal name returned from the above dataMap procedure and read the signal from the simulation output file.

Syntax

```
sa::getData [<name: string>] [-resultsType <string>] [-resultFile <string>]  
-resultsDir <string> [-param <string>] [-params <string>] [-type  
<string>] [-dataType <string>] [-analysisName <string>] [-requireSig  
<string>] [-time <string>] [-mapContext <bool>] [-hierPath <string>]  
[-native <bool>] [-readNameOnly <bool>] [-isGetDataMapping <bool>]
```

Returns

Returns a scalar or waveform signal ([wfSignal](#)).

Arguments

`name`

Signal name either in schematic namespace like /I5/I8/M0/D or in simulator namespace like i1(xi5.xi8.m0).

`-resultType <string>`

The logical name, defined by the `resultType` tag in Results XML, for the output file. For example, `tran`, `dc`, `ac`, and so forth.

`-resultFile <string>`

The name of the output file. Use this field if you want to access the signal using the file name.

`-resultsDir <string>`

The results directory containing the simulation output files.

`-param <string>`

Parameter name (such as `id`, `vgs`, `beta`, etc.) typically used with op analysis results.

`-params <string>`

The parameter condition in the format "A=1:B=2,3:C=<1:100>:D=<1:100:2>".

`-type <string>`

The signal type (instance/net/terminal).

`-dataType <string>`

The data type (such as input, output, gain, and so forth) that is passed as one of the arguments to the `sa::<simulator>::<resultType>::dataMap` procedure for finding the signal name in the output file.

`-analysisName <string>`

The logical name, defined by the `analysisName` tag in Results XML, for the output file. Use this argument if there are multiple output files with same `resultType`.

`-requireSig`

Require signal instead of scalar value

`-time <string>`

The time point if the `resultType` is `opTran`. For example, this argument will be used for accessing the transient operating points created from transient analysis at multiple time points.

`-mapContext <bool>`

Indicates that the incoming name might be out-of-context and that cross context name mapping is performed if needed.

`-hierPath`

The design namespace hierarchical path starting at the top level that will be appended to name argument if it is relative (no beginning "/").

`-native`

Indicates the signal name is directly found in the simulation results, otherwise an expression is sought.

Default: 0.

`-readNameOnly`

Opens a waveform file in read name only mode.

`-isGetDataMapping <bool>`

Get data mapping.

sa::getDatabaseDir

Returns the location on disk where active history results are stored.

Syntax

```
sa::getDatabaseDir -of <saTestbench> [-historyIdx <string>] [-historyName  
<string>] [-runType <string>]
```

Returns

<string> : History Database Directory

Arguments

`-of`

Testbench in the PrimeWave Design Environment

`-historyIdx`

History index (Default is:)

`-historyName`

History name (Default is:)

`-runType`

Run type (Default is:)

sa::getDataDir

Description

This command returns the directory where the PrimeWave Design Environment looks for results of a given testbench. This is subtly different from the run directory (`sa::getRunDir`), which determines where the PrimeWave Design Environment will write new results.

Syntax

```
sa::getDataDir -of <saTestbench>
```

Returns

<string> : Data directory.

Arguments

-of

Testbench whose data directory is returned.

Examples

The following example prints the top directory where the netlist and results files of the active testbench were saved.

```
set dataDir [sa::getDataDir -of [ss::getActiveTestbench]]
puts $dataDir
```

sa::getDesignVariablesGroupVar

Get a collection of the variables to be included in the netlist

Syntax

```
sa::getDesignVariablesGroupVar -testbench <saTestbench> -name <string>
                                -value <string>
```

Returns

<none>

Arguments

-testbench

Testbench

-name

Name of the group

-value

Value of the group

sa::getDesignWindows

Description

This command returns the list of design windows currently associated with the given PrimeWave Design Environment window or testbench.

Syntax

```
sa::getDesignWindows (-window <giWindow | int> | -testbench
    <saTestbench>)
```

Arguments

-window <giwindow | int>

The PrimeWave Design Environment window.

-testbench

The parameter conditions.

Examples

```
##### This examples adds "Plot transient waveform" action to Schematic
Editor standard toolbar
##### This shows use of sa::getDesignWindows command
proc _getAssociatedSAEWindow {schWindow} {
    if { ![db::isObject $schWindow] } {
        set schWID $schWindow
    } else {
        set schWID [db::getattr schWindow.id]
    }
    db::foreach w [gi::getWindows] {
        if { [regexp {saConsole*} [db::getattr w.windowType.name]] } {
            db::foreach designW [sa::getDesignWindows -window $w] {
                if { [db::getattr designW.id] == $schWID } {
                    return $w
                }
            }
        }
    }
    return {}
}

# Start direct plot command based on the passed in SCH window
proc directPlotTran {schWindow} {
    set saeWindow [_getAssociatedSAEWindow $schWindow]
    if { {} != $saeWindow } {
```

```
sa::directPlot tran -window $saeWindow
}
}

gi::createAction directPlotTran -title "Plot transient waveform" \
-command "directPlotTran %w" -prompt "Plot transient waveform" \
-icon plot_waveforms
gi::addActions directPlotTran -to [gi::getToolbars seSchStandard]

#####
```

sa::getEMNetCurrents

Description

Gets the terminal current data from the specified database. If multiple occurrences of the design appear in the database, the worst case value is returned.

Syntax

```
sa::getEMNetCurrents <net: string> -db <string> -design <oaDesign>
```

Returns

<string> : The list of instance term currents in the format: {instanceName termName iMax iRMS iAverage}

Arguments

net

The net name.

-db

The current database (return value of command sa::createEMDB).

-design

The design.

sa::getExpressionContext

Description

Returns information about the current expression context.

Syntax

```
sa::getExpressionContext
```

Returns

<string> : Returns a list of key/values containing the current expression context, such as resultType, resultsDir, params, timePt, and so forth.

sa::getFailedIterations

Description

Gets failed Monte Carlo iterations.

Syntax

```
sa::getFailedIterations (-window <giWindow | int> | -testbench  
    <saTestbench>) [-allLevels <bool>] [-params <string>]
```

Arguments

-window

The PrimeWave Design Environment main console window.

-testbench

Testbench.

-allLevels

Separates results based on all levels of parametric information, otherwise just across Monte Carlo iterations.

-params

Parametric reduction string.

sa::getFlowFileDependencyTree

Description

Gets the dependency tree of a file.

Syntax

```
sa::getFlowFileDependencyTree -of <saFlowFile>
```

Returns

<tcl | list> : A Tcl list containing the tree in pairs [indentation level (integer), file object (saFlowFile)]. Each nested level has one more indentation level than its parent. The first entry is indentation level 0.

Arguments

`-of`

The file from which to create a dependency tree.

sa::getFlowFileModificationTime

Description

Gets the modification time (UNIX mtime) of the file.

Syntax

```
sa::getFlowFileModificationTime -of <saFlowFile>
```

Returns

<none>

Arguments

`-of`

A file with which to check the modification time.

sa::getGoalTypeForSource

Get goal type for source

Syntax

```
sa::getGoalTypeForSource -testbench <saTestbench>
```

Returns

<none>

Arguments

`-testbench`

Testbench

sa::getHistoryDataTestbench

Description

Finds the testbench in the session from the history.

Syntax

```
sa::getHistoryDataTestbench -session <saSession> -tbName <string> [-his  
toryIdx <string>] [-historyName <string>]
```

Returns

<saTestbench> : The current testbench.

Arguments

-session

SAE session to look for the testbench.

-tbName

The name of the testbench.

-historyIdx

Specify the history index.

-historyName

Specify the history name. Default:

sa::getHistoryResultsDir

Returns the location on disk where active history results are stored.

Syntax

```
sa::getHistoryResultsDir -of <saSession | saTestbench> [-historyIdx  
<string>] [-historyName <string>]
```

Returns

<string> : History Results Directory

Arguments

-of

Testbench/Session in the PrimeWave Design Environment.

-historyIdx

History index (Default is:)

-historyName

History name (Default is:)

Examples

The following example prints the directory path for active history point results.

```
set session [ss::getActiveSession]
set activeHP [sa::findActiveHistoryPoint -session $session]
puts [sa::getHistoryResultsDir -of $session -historyName $activeHP]
```

sa::getMeasurementSets

Description

Returns the collection of measurement sets.

Syntax

```
sa::getMeasurementSets [<pattern: string>] [-filter <string>] -of
<saTestbench>
```

Returns

Measurement Sets matching search criteria (dbCollection).

Arguments

<string>

Pattern to match object name.

-filter <string>

Standard attribute filter.

-of

The testbench.

sa::getMeasurementStatistics

Description

Returns measurement statistics.

Syntax

```
sa::getMeasurementStatistics <measurement: string> (-resultsDir <string>
| -testbench <saTestbench>) [-analysis <string>] [-parameter <string>]
[-paramValue <string>]
```

Returns

<string> : A list of key/values containing measurement statistics.

Arguments

measurement

Measurement name.

-analysis

Analysis name.

-parameter

Parameter name.

-paramValue

Parameter value.

-resultsDir

The results directory.

-testbench

The PrimeWave Design Environment testbench.

sa::getMeasuresInfo

Get Measurement Information

Syntax

```
sa::getMeasuresInfo -testbench <saTestbench> -meas <string> [-debug  
    <bool>]
```

Returns

<none>

Arguments

-testbench

Testbench

-meas

Measure Name

-debug

Enable debug mode (Default is: false)

sa::getMeasureValue

Get scalar value data

Syntax

```
sa::getMeasureValue -testbench <saTestbench> [-meas <string>]  
[-returnParams <string>]
```

Returns

<none>

Arguments

-testbench

Testbench

-meas

Measure Name (Default is: false)

-returnParams

Return Params: -returnParams <none/cornerNameOnly/all> (Default is: false)

sa::getModelGroupDefs

Description

Returns the PrimeWave Design Environment Model Group Defs.

Syntax

```
sa::getModelGroupDefs [<pattern: string>] [-window <giWindow | int> |  
-session <saSession> | -testbench <saTestbench>] [-filter <string>]
```

Returns

<dbCollection> : Model Group Defs matching search criteria.

Arguments

pattern

Pattern to match object name.

-filter

The standard attribute filter.

`-window`

The PrimeWave Design Environment window.

`-session`

The PrimeWave Design Environment session.

`-testbench`

The PrimeWave Design Environment testbench.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
puts [db::createList [db::getAttr name -of \
[sa::getModelGroupDefs -testbench $tb]]]
```

sa::getNetlistDir

Description

Returns the netlist directory location of the testbench on disk.

Syntax

```
sa::getNetlistDir -of <saTestbench> [-type <enum>]
```

Returns

<string> : Netlist directory.

Arguments

`-of`

Testbench whose netlist directory is returned.

`-type`

Netlist type. ({ commonStructural | final | nominal | structural }, default is: final)

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
# Get netlist directory by netlist type (final nominal structural)
set netlistDir [sa::getNetlistDir -of $tb -type nominal]
puts $netlistDir
```

sa::getNetlistIncludeFiles

Get a collection of the include files to be included in the netlist

Syntax

```
sa::getNetlistIncludeFiles -testbench <saTestbench> [-type <string>]
```

Returns

<none>

Arguments

-testbench

Testbench

-type

Specify the Include File Type

sa::getNetlistModelFiles

Description

Get a collection of the model files to be included in the netlist.

Syntax

```
sa::getNetlistModelFiles -testbench <saTestbench>
```

Arguments

-testbench

Testbench.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set modelFiles [sa::getNetlistModelFiles -testbench $tb]
puts [db::createList [db::getAttr filename -of $modelFiles]]
puts [db::createList [db::getAttr section -of $modelFiles]]
```

sa::getNetlistVariables

Get a collection of the variables to be included in the netlist

Syntax

```
sa::getNetlistVariables -testbench <saTestbench>
```

Returns

<none>

Arguments

-testbench

Testbench

sa::getPickedObjects

Description

Returns the picked design objects from the last interactive pick.

Syntax

```
sa::getPickedObjects (-window <giWindow | int> | -testbench  
  <saTestbench>)
```

Returns

<string> : The collection of picked design objects (object type, name, in-context name, probe color, and out-of-context name).

Arguments

-window

The PrimeWave Design Environment main console window.

-testbench

The testbench.

sa::getRalignedResultTypes

Description

Query simulator to retrieve ignored result types from RA.

Syntax

```
sa::getRaIgnoredResultTypes -simulator <saSimulator>
```

Returns

<none>

Arguments

`-simulator`

Simulator to be queried.

sa::getRefVal

Get reference value

Syntax

```
sa::getRefVal -measName <string> -configName <string> -currentParams  
  <string> -tb <saTestbench>
```

Returns

<none>

Arguments

`-measName`

Measure Name

`-configName`

Config Name

`-currentParams`

Current Params

`-tb`

Testbench

sa::getReportElement

Description

Gets the specified element from the given report.

Returns an `xtReportElement` object named as `elementName` that is part of the report specified by `-in` in the session specified by `-session`. Optionally, to unambiguously identify `reportElement`, you can fully qualify its name by giving values to the `-testbench` and `-parameter` arguments.

Syntax

```
sa::getReportElement <elementName: string> -in <string> -session  
  <saSession> [-testbench <string>] [-parameter <string>]
```

Returns

<none>

Arguments

`elementName`

Name of the report element to get.

`-in`

Parent report.

`-session`

Parent session containing the report.

`-testbench`

Testbench of the report element.

`-parameter`

Parameter of the report element.

Errors

- If a report with the same name as the `-in` argument is not found in session specified by the `-session` argument, an error will be raised.
- If report element does not exist, an error will be raised.

sa::getReports

Description

Returns a collection of reports matching a given name or pattern.

Syntax

```
sa::getReports <reportName: string> -session <saSession>
```

Returns

<dbCollection> : Collection of reports matching name or pattern specified by `reportName`.

Arguments

`reportName`

Name or pattern of the reports to get.

`-session`

Parent session to look for reports.

Errors

- If a report with the same name as the `-in` argument is not found in the session specified by the `-session` argument, an error will be raised.
- If an update procedure is not given and the report element does not exist, an error will be raised.

sa::getResultFiles

Description

Get the saResultFile objects given the result type.

Syntax

```
sa::getResultFiles <type: string> (-resultsMap <saResultsMap> | -results  
<saResults>) [-filter <string>]
```

Returns

Collection of result file objects ({saResultFile}).

Arguments

`<string>`

The result type.

`-resultsMap <saResultsMap>`

The saResultsMap object.

`-results <saResults>`

The saResults object.

`-filter <string>`

Standard attribute filter.

sa::getResults

Description

Get all saResults objects in the given saResultsMap.

Note:

Additional arguments will be added when advanced analysis tools are implemented.

Syntax

```
sa::getResults [-filter <string>] -of <saResultsMap>
```

Returns

Collection of saResults objects ([saResults](#)).

Arguments

-filter <string>

Standard attribute filter.

-of [saResultsMap](#)

The saResultsMap object.

sa::getResultsDir

Description

Returns the location on disk where the current simulation results are stored.

Syntax

```
sa::getResultsDir -of <saTestbench | xtJob>
```

Returns

<string> : Results directory.

Arguments

-of

The PrimeWave Design Environment testbench or the job object.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
puts [sa::getResultsDir -of $tb]
> /
SCRATCH/projects/simulation/cornerAnalysis,Opamp_OpenLoop,schematic/histo
ry_1/simulation/OpenLoopMeasure/HSPICE/extreme_cases/results
```

sa::getResultsViewerData

Description

Gets simulation results. Execute a database query to retrieve the results as in the Results Viewer.

Syntax

```
sa::getResultsViewerData -session <saSession> -query <string>
```

Returns

<none>

Arguments

-session

Session.

-query

The name of the database query to retrieve.

sa::getResultTypes

Description

Get the list of the result types.

Syntax

```
sa::getResultTypes (-resultsMap <saResultsMap> | -results <saResults>)  
[-filter <string>]
```

Returns

Collection of result types ({<string>}).

Arguments

-resultsMap [saResultsMap](#)

The saResultsMap object.

-results [saResults](#)

The saResults object.

-filter <string>

Standard attribute filter.

sa::getRunDir

Description

Returns the location on disk of the testbench's run directory.

Syntax

```
sa::getRunDir -of <saTestbench>
```

Returns

<string> : Run directory.

Arguments

-of

Testbench whose run directory is returned.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
puts [sa::getRunDir -of $tb]
```

sa::getRunScriptPath

Description

This command returns the runSimulation script path of the given testbench.

Syntax

```
sa::getRunScriptPath -of <saTestbench>
```

Arguments

-of

Testbench of run script.

sa::getScalarValuesData

Get scalar value data

Syntax

```
sa::getScalarValuesData -testbench <saTestbench>
```

Returns

<none>

Arguments

-testbench

Testbench

sa::getSelected

Description

Gets the selected objects from a PrimeWave Design Environment window.

Syntax

```
sa::getSelected -window <giWindow | int>
```

Arguments

-window

Window id.

sa::getSessions

Description

Get all PrimeWave Design Environment sessions in the PrimeWave Design Environment session. The window argument can be specified to get a session associated with a PrimeWave Design Environment window.

Syntax

```
sa::getSessions [<pattern: string>] [-window <giWindow | int> |  
-testbench <saTestbench>] [-filter <string>]
```

Returns

A collection of found ceSession objects ({}).

Arguments

<string>

Pattern to match object name.

-window *giWindow* | <int>

The PrimeWave Design Environment window.

```
-filter <string>
```

Standard attribute filter.

```
-testbench
```

Return parent session for this testbench.

Examples

```
# Get all PrimeWave Design Environment sessions
set ss [sa::getSessions]
puts [db::createList [db::getAttr ss.name]]
> saeSession0 saeSession1 MTB
# Get session with filter
set mtbSession [sa::getSessions -filter {%name=="MTB"} ]
set cs [db::getAttr mtbSession.cornersSetup]
set corners [sa::getCorners -of $cs]
db::foreach c $corners {
puts "[db::getAttr c.enabled]\t[db::getAttr c.name]\t[db::createList
[db::getAttr c.parameters.value]]"
}
```

sa::getSimulators

Description

Get simulators registered in PrimeWave Design Environment.

Syntax

```
sa::getSimulators [<pattern: string>] [-filter <string>]
```

Returns

Collection of simulators ([saSimulator](#)).

Arguments

```
<string>
```

Pattern to match object name.

```
-filter <string>
```

Standard argument filter.

Examples

```
puts [db::createList [db::getAttr name -of [sa::getSimulators]]]
```

See Also

- [sa::getAnalysisDefs](#) for an example of `sa::getSimulators`

sa::getSimulatorSweepPoints

Description

Returns the collection of simulator sweep points that is defined on the testbench.

Syntax

```
sa::getSimulatorSweepPoints -of <saTestbench>
```

Returns

<dbCollection> : Simulator sweep points defined on testbench.

Arguments

-of

Testbench where sweeps are defined.

Errors

- Invalid testbench object.
- Parameter with name %s is already defined and enabled in sweeps.
- Cannot create more than %d sweep points.
- Multiple data driven sweeps are not supported.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set sweepPoints [sa::getSimulatorSweepPoints -of $tb]
```

sa::getSimulatorSweepsInfo

Description

Returns the information about the simulator sweeps.

Syntax

```
sa::getSimulatorSweepsInfo <filePath: string>
```

Returns

<string> : Returns a list of key/values containing sweep index and their parameter details.

Arguments

`filePath`

Results directory.

sa::getStates

Description

Returns a list of states available at a specified storage location.

Syntax

```
sa::getStates [<name: string>] [-cell <dmCell> | -view <dmCellView>]  
[-use <enum>] [-simulator <string>] [-rootPath <string>] [-filter  
<string>]
```

Returns

Collection of PrimeWave Design Environment state objects (*{saStateData}*).

Arguments

`<string>`

State name filter.

`-cell dmCell`

dmCell to use to identify state.

`-view`

dmCellView containing state as a child.

`-use`

Storage policy. Valid values include directory, openaccess, and statesDirectory.

`-simulator <string>`

Simulator name.

`-rootPath <string>`

Root directory.

`-filter <string>`

State collection filter.

Examples

```
set cell [dm::findCell opamp_mctb -libName opampLib]
set states [sa::getStates -cell $cell -use openaccess]
puts [db::createList [db::getattr states.name]]
```

sa::getSweepPoints

Description

Returns a collection of points, each of which is a collection of cePairs that represents a name and a value.

Syntax

```
sa::getSweepPoints -of <saSession | saTestbench>
```

Returns

<dbCollection> : Sweep points defined on testbench.

Arguments

-of

The testbench or session object containing the sweep points.

Errors

Invalid testbench object.

sa::getTerminalInfo

Description

Returns the information about the given terminal.

Syntax

```
sa::getTerminalInfo <name: string> (-netlistDir <string> | -testbench  
  <saTestbench>) -simulator <string> [-plot <bool>]
```

Returns

<string> : Returns a list of keys/values containing terminal information like path, primitiveName, terminalName, index.

Arguments

name

Terminal name.

`-netlistDir`

Netlist directory name.

`-testbench`

Testbench.

`-simulator`

Simulator Name.

`-plot`

Terminal information for plotting. (Default is: 1)

Examples

```
# Returns list with even number of elements, associated as key and value
# Typically set to array so can access later by key
set tb [sa::findActiveTestbench -window 3]
set netlistDir [sa::getNetlistDir -of $tb]
array set data [sa::getTerminalInfo /I0/Vout -netlistDir $netlistDir \
-simulator HSPICE]
parray data
```

The above example returns the following list of terminal information:

```
data(index) = 1
data(leaf) = 1
data(netlistDir)
= /
remote/am04home2/simulation/testLib,tb_linTest,schematic/history_1/simula
tion/HSPICE_default/HSPICE/nominal/netlist
data(path) =
data(primitiveName) = v0
data(subType) = deviceCurrent
data(terminalName) = plus_1
```

Note:

`subType` can have following values: `nodeVoltage`, `subcktCurrent`, `deviceCurrent`, `branchCurrent`, `verilogaCurrent`, and `unknown`.

sa::getTestbenches

Returns a collection of testbenches

Syntax

```
sa::getTestbenches [<pattern: string>] [-filter <string>] -of <saSession
| xtJob> [-historyIdx <string>]
```

Returns

<none>

Arguments

pattern

Pattern to match object name.

-filter

Standard attribute filter.

-of

PrimeWave session or job object

-historyIdx

get testbenches from history cache by history index

sa::getTestSuiteStorage

Description

Returns list of test suite storage objects found on disk.

Syntax

```
sa::getTestSuiteStorage [<name: string>] [-filter <string>] -storageType  
  <enum> [-rootPath <string>] [-lib <string>] [-cell <string>] [-session  
  <saSession>]
```

Returns

<dbCollection>: Test suites matching search criteria.

Arguments

name

Test suite name pattern.

-filter

Standard attribute filter.

-storageType

Storage type ({directory | openaccess | session}).

`-rootPath`

The root directory containing test suite(s). Required when `-storageType` option is set to *directory*.

`-lib`

Name of library containing test suite(s). Required when `-storageType` option is set to *openaccess*.

`-cell`

Name of cell containing test suite(s). Used when `-storageType` option is set to *openaccess*. If blank, test suite name is used for the cell level.

`-session`

PrimeWave Design Environment session to retrieve its storage information from. Required when `-storageType` option is set to *session*.

Examples

```
set mtbCellName "MTB"
set libName "myLib"
# Get testsuite storage object
set tss [sa::getTestSuiteStorage $mtbCellName -storageType openaccess
    -lib $libName]
puts [db::listAttrs -of $tss]
> category cell comment directory lastModified library name storageType
    supportsGlobalScope testbenchNames this type version
```

sa::getTopEquivalentNet

Description

Gets top equivalent net on the given instance name.

Syntax

```
sa::getTopEquivalentNet <instName: string>
```

Returns

<string> : Top equivalent net name string.

Arguments

`instName`

Instance name.

sa::getVDRNetVoltages

Description

Gets voltage extremes for the given net. If multiple occurrences of the design are in the database and the -occurrence path is not set, the worst case (maximum/minimum value as appropriate) is returned. Otherwise, the value for the given occurrence path is returned.

Syntax

```
sa::getVDRNetVoltages <net: string> -db <string> -design <oaDesign>  
[-occurrence <string>]
```

Returns

<string> : The list of voltage extremes in the format: {netName vMax vMin}

Arguments

net

The net name.

-db

The VDRC voltage database (return value of command sa::createVDRADB).

-design

The design.

-occurrence

Occurrence path.

sa::getWindowType

Description

Returns the window type used to display the given object.

Syntax

```
ssa::getWindowType [-simulator <saSimulator | string> | -testbench  
<saTestbench>]
```

Returns

The window type used to display the given object (giWindowType).

Arguments

`-simulator saSimulator | <string>`

The simulator or simulator name.

`-testbench`

The testbench object.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set wt [sa::getWindowType -testbench $tb]
puts [db::getattr wt.name]
```

sa::hasMonteCarloResults

Description

Check whether the simulation results have Monte Carlo data.

Syntax

```
sa::hasMonteCarloResults <resultsDir: string>
```

Arguments

`resultsDir`

Results directory.

Examples

The following example checks whether the simulation results of the active testbench have Monte Carlo data.

```
puts [sa::hasMonteCarloResults [sa::getDataDir -of
    [ss::getActiveTestbench]]]
```

sa::importGroupDef

Imports an TCL script having one group definition into a saVariableGroupDef, saStimulusGroupDef or saIncludeGroupDef

Syntax

```
sa::importGroupDef <filename: string> -type <string>
```

Returns

<saVariableGroupDef | saStimulusGroupDef | saIncludeGroupDef> : Imported Group Definition

Arguments

filename

Input file path.

-type

Type of the def

sa::importModelGroupDef

Description

Imports a Tcl script having one model group definition into a saModelGroupDef.

Syntax

```
sa::importModelGroupDef <filename: string>
```

Returns

<saModelGroupDef> : Imported Model Group Definition

Arguments

filename

Input file path.

sa::initializeAttributes

Description

Create and initialize object attributes. Typically called from sa::<simulator>::*:initialize.

Syntax

```
sa::initializeAttributes <attributes: string> -of <saAnalysis |  
saEnvironmentOptions | saMonteCarlo | saObject | saSaveOptions>  
-simulator <saSimulator| string> [-scope <dbScopeType | string>]
```

Arguments

attributes

Attributes formatted as a list of lists.

`-of`

The the object attributes are added to.

`-simulator`

The simulator name used for preference name generation.

`-scope`

Scope used for preference value lookups.

sa::isCornersSetupEnabled

Description

Checks to determine whether corners setup is enabled for the testbench / result.

Syntax

```
sa::isCornersSetupEnabled <object: saResultsMap | saTestbench> [-name  
    <string>]
```

Returns

True, if corners setup is enabled (<bool>).

Arguments

`<saResultsMap | saTestbench>`

The testbench / resultsmap object to check.

`-name`

Setup name. If blank, all setups are checked.

Examples

To check whether the corner setup is enabled for a given testbench:

```
sa::isCornersSetupEnabled [sa::findActiveTestbench -window 4]
```

This example gets the testbench in window 4 and checks whether it has corners setup enabled.

sa::isResultAvailable

Description

Check if the specified result type is available from the simulation.

Syntax

```
sa::isResultAvailable <resultType: string> (-window <giWindow | int> |  
-testbench <saTestbench>)
```

Returns

True, if return type is available (<bool>).

Arguments

resultType

The result type to check.

-window

The PrimeWave Design Environment main console window.

-testbench

Testbench.

Examples

```
sa::isResultAvailable FallTime -window 4
```

In this example, `sa::isResultAvailable` verifies whether the `FallTime` (output name) is available for the active PrimeWave Design Environment window.

sa::isSweepsEnabled

Description

Returns a Boolean indicating whether sweeps have been enabled in a testbench / result.

Syntax

```
sa::isSweepsEnabled <object: saResultsMap | saTestbench>
```

Returns

True if sweeps have been enabled for this testbench / result, false otherwise (<bool>).

Arguments

<saResultsMap | saTestbench>

The testbench / resultsmap object to check.

Errors

Invalid testbench object.

sa::loadCornersSetup

Description

Load corners from an external file.

Syntax

```
sa::loadCornersSetup (-dialog <giDialog> | -window <giWindow | int> |  
-session <saSession> | -testbench <saTestbench>) -filePath <string>  
[-mergeMode <enum>]
```

Returns

<none>

Arguments

-dialog

Corners Setup Dialog into which to load new corners.

-window

The PrimeWave Design Environment Window

-session

The PrimeWave Design Environment Session

-testbench

The PrimeWave Design Environment Testbench

-filePath

XML file from which to load the new corners.

-mergeMode

How loaded corners should be merged ({ append | replace }, default is: append)

Examples

The following example opens MTB states and copies corners setup from one MTB session to another.

```
set session1 [sa::createSession -testSuiteMode true]  
sa::loadTestSuite mtb \  
-session $session1 \  
-storageType openaccess \  
-lib topLib \  
-cell ring_osc_mtb  
  
# Open session in GUI
```

```
sa::showConsole -session $session1

set session2 [sa::createSession -testSuiteMode true]
sa::loadTestSuite rc_tb_mtb \
    -session $session2 \
    -storageType openaccess \
    -lib topLib \
    -cell rc_tb

# Open session in GUI
sa::showConsole -session $session2

sa::saveCornersSetup -session $session1 -filePath corners.xml -overwrite
true
sa::loadCornersSetup -session $session2 -filePath corners.xml -mergeMode
replace

sa::saveTestSuite -session $session1
```

sa::loadDesVarsFromText

Description

Load variables from a file.

Syntax

```
sa::loadDesVarsFromText (-window <giWindow | int> | -testbench
    <saTestbench> | -session <saSession>) -filePath <string> [-variableSet
    <string>] [-format [<string>]] [-delimiter <string>] [-overwrite <bool>]
```

Returns

<none>

Arguments

-filePath

File path from which to read the list.

-window

SAE main console window

-testbench

Testbench

-session

Session

`-variableSet`

Name of variable set to load into ("" = current). (Default is:)

`-format`

The list of column headers and attribute names for formatting.

`-delimiter`

Column header delimiter character. (Default is: ;)

`-overwrite`

Overwrite existing design variables (false = append). (Default is: false)

sa::loadObjectFromFile

load the xml file of a object

Syntax

```
sa::loadObjectFromFile -object <dbObject> -path <string>
```

Returns

<bool> : True if succeed

Arguments

`-object`

Object to save

`-path`

Specify where to load the object

sa::loadOutputs

Load outputs from a file.

Syntax

```
sa::loadOutputs (-window <giWindow | int> | -testbench <saTestbench> |  
-session <saSession>) -filePath <string> [-outputSet <string>] [-format  
[<string>]] [-delimiter <string>] [-overwrite <bool>]
```

Returns

<none>

Arguments

`-filePath`

File path from which to read the list.

`-window`

PrimeWave main console window

`-testbench`

Testbench

`-session`

Session

`-outputSet`

Name of output set to load into ("" = current). (Default is:)

`-format`

The list of column headers and attribute names for formatting.

`-delimiter`

Column header delimiter character.

`-overwrite`

Overwrite existing outputs, preserving specs if possible (false = append).
(Default is: false)

sa::loadResultsDir

Description

Changes where results are found for plotting, printing, and post-simulation commands.

Syntax

```
sa::loadResultsDir <filePath: string> -to <saTestbench> [-restoreSession  
  <string>]
```

Arguments

`<string>`

The file path name of the run directory whose results are used.

`-to <saTestbench>`

The testbench for which the results are loaded.

`-restoreSession <string>`

Indicates whether the session settings are changed to match the session settings that are used when the results are produced.

sa::loadSimOptions

Description

Loads simulator option definition XML files into a specific simulator.

Syntax

```
sa::loadSimOptions <name: [string]> -simulator <saSimulator>
[-collectionName <string>]
```

Arguments

`<string>`

Names of XML files containing simulator option definitions.

`-simulator <saSimulator>`

The simulator object to be used for loading options definitions.

`-collectionName`

Name of collection attribute into which options will be loaded.

Default: optionDefs.

sa::loadState

Description

Loads the state data from the disk to a testbench.

Syntax

```
sa::loadState <name: string> -testbench <saTestbench> [-cell <dmCell>
| -view <dmCellView>] [-use <enum>] [-simulator <string>] [-rootPath
<string>] [-categories [<string>]] [-exclude <bool>] [-reset <bool>]
[-loadSimulator <bool>] [-loadDesign <bool>] [-setTestbenchName <bool>]
```

Arguments

`<string>`

The state name.

`window`

PrimeWave Design Environment Window.

`-session`

PrimeWave Design Environment Session.

`-testbench <saTestbench>`

PrimeWave Design Environment Testbench.

`-cell <dmCell>`

The dmCell to use to identify the state.

`-view`

dmCellView containing state as a child.

`-use <enum>`

The storage policy ({directory | openaccess | statesDirectory}).

`-simulator <string>`

The simulator name. (Default is: "").

`-rootPath <string>`

The root directory. (Default is: "").

`-categories {<string>}`

The categories of testbenches to operate on.

`-exclude <bool>`

Indicates whether the categories are excluded. (Default is: false).

`-reset`

Reset all the categories back to the simulator integration defaults. (Default is: false).

`-loadSimulator <bool>`

Sets the testbench simulator to the same simulator that is specified in the state (default is false).

`-loadDesign <bool>`

Sets the testbench design to the same design that is specified in the state (default is false).

`-setTestbenchName`

Set testbench name to that declared in the state. (Default is: false)

Examples

```
set cellName "curref_tb_cal"
set libName "demo_snps"
set stateName "sa_e_default"
set newTNOMValue "27"
set cell [dm::getCells $cellName -libName $libName]
set session [sa::createSession -addDefaultTestbench false ]
sa::loadState $stateName -cell $cell -session $session -use openaccess
set tb [db::getNext [sa::getTestbenches -of $session]]
set optTNOM [db::filter [db::getAttr tb.options] \
-filter {%name=="TNOM"}]
db::setAttr value -of $optTNOM -value $newTNOMValue
db::setAttr localized -of $optTNOM -value 1
sa::saveState $stateName -testbench $tb -use openaccess
```

sa::loadTestSuite

Description

Loads the on-disk test suite into an saSession.

Syntax

```
sa::loadTestSuite <name: string> -session <saSession> -storageType <enum>
[-rootPath <string>] [-lib <string>] [-cell <string>] [-testbenchNames
<string>]]
```

Arguments

name

The Test suite.

-session

The PrimeWave Design Environment session to save.

-storageType

Storage type ({directory | openaccess}).

-rootPath

The root directory containing test suite(s). Required when -storageType option is set to directory.

-lib

Name of library containing test suite(s). Required when -storageType option is set to openaccess.

`-cell`

Name of cell containing test suite(s). Used when '-storageType' option is set to 'openaccess'. If blank, test suite name is used for the cell level.

`-testbenchNames`

Names of testbenches to load.

Default: all.

Examples

The following example opens MTB states and copies corners setup from one MTB session to another.

```
set session1 [sa::createSession -testSuiteMode true]
sa::loadTestSuite mtb \
    -session $session1 \
    -storageType openaccess \
    -lib topLib \
    -cell ring_osc_mtb

# Open session in GUI
sa::showConsole -session $session1

set session2 [sa::createSession -testSuiteMode true]
sa::loadTestSuite rc_tb_mtb \
    -session $session2 \
    -storageType openaccess \
    -lib topLib \
    -cell rc_tb

# Open session in GUI
sa::showConsole -session $session2

sa::saveCornersSetup -session $session1 -filePath corners.xml -overwrite
true
sa::loadCornersSetup -session $session2 -filePath corners.xml -mergeMode
replace

sa::saveTestSuite -session $session1
```

sa::lockHistoryPoint

Description

Set or release the lock on the given history point.

Syntax

```
sa::lockHistoryPoint -name <string> [-value <bool>] -session <saSession>
```


Returns

<bool> : True if the history point is locked

Arguments

-name

The name of the history point.

-value

Specifies whether the history point be locked. (Default is: true)

-session

The PrimeWave Design Environment session in which the history point is to be locked.

Examples

The following example locks the active history point.

```
set session [ss::getActiveSession]
set activeHP [sa::findActiveHistoryPoint -session $session]
sa::lockHistoryPoint -name $activeHP -value true -session $session
```

sa::makePrefLabel

Description

Generates the preference label for a given simulator.

Syntax

```
sa::makePrefLabel <simulator: saSimulator | string>
```

Arguments

-simulator

Simulator or simulator name.

sa::makePrefName

Description

Generates a suitable preference name from list of name parts.

Syntax

```
sa::makePrefName <words: [string]> -simulator <saSimulator | string>
[-analysis <saAnalysis | saAnalysisDef | string>]
```

Arguments

words

Words to construct preference name from.

-simulator

The simulator name.

-analysis

The analysis type name.

sa::map

Description

Maps identifiers between database and simulator names.

Syntax

```
sa::map <name: string> (-netlistDir <string> | -testbench <saTestbench>)  
-type <string> [-mapContext <bool>] [-to <string>]
```

Arguments

name

Name/identifier to map.

-type

Identifier type: "Instance", "Net", or "Terminal".

-netlistDir

Netlist directory.

-testbench

Testbench.

-mapContext

Check for out of context paths.

Default: true.

-to

Direction of mapping: "Schematic" or "Netlist".

Default: Netlist.

sa::mapDesignVariableValue

Description

Maps the getVal() expression for Sequential Testbench simulation.

Syntax

```
sa::mapDesignVariableValue <expression: string> -testbench <saTestbench>
```

Returns

<string> :

Arguments

expression

Specifies the expression to be mapped.

-testbench

Testbench.

sa::mergeCornersSetup

Merge two corners setup

Syntax

```
sa::mergeCornersSetup -of <saCornersSetup> -to <saCornersSetup>  
[-enable_all <bool>]
```

Returns

<saCornersSetup> : the merged corner setup

Arguments

-to

target corners setup to merge in

-enable_all

Specify where to save the object (Default is: true)

sa::migrateResults

Description

Migrates the simulations from the old directory model to a new common data model.

Syntax

```
sa::migrateResults (-testbench <saTestbench> | -resultsDir <string>)  
  [-name <string>] [-index <int>]
```

Returns

<none>

Arguments

-testbench

Testbench.

-resultsDir

Results directory.

-name

State or testbench name in which to migrate the simulations.

-index

The history index in which to migrate the simulations.

sa::netlistAndRun

Description

This command creates a new structural netlist, a new final netlist, and starts a simulation run if the netlist was successfully created.

Syntax

```
sa::netlistAndRun (-window <giWindow | int> | -testbench <dbCollection |  
  saTestbench>)
```

Returns

Status of the simulation run. (<bool>)

Arguments

-window *giWindow* | <int>

The PrimeWave Design Environment window object or id.

-testbench

Testbench or a collection of testbenches.

Errors

- No testbench is defined in this window.
- The window is not a PrimeWave Design Environment window.
- Errors during netlisting.
- Errors in simulation setup.
- A netlist job is already running.
- A simulation is already running.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
sa::netlistAndRun -testbench $tb
```

sa::openResultsMap

Description

This command creates the results map object by reading the persistence data (resultsMap.xml and results.xml) on disk. If this API is called during simulation run, results map object is created based on the simulation output files created at that moment.

Syntax

```
sa::openResultsMap <resultsDir: string> [-useCached <bool>]
```

Returns

New saResultsMap object ([saResultsMap](#)).

Arguments

<string>

The simulation results directory.

-useCached

If true, return the cached results map if available. (Default is: 1)

sa::openSimulationConsole

Description

Open a console for simulation setup.

Syntax

```
sa::openSimulationConsole
```

sa::openTextFiles

Description

View text file(s) associated with a PrimeWave Design Environment Session or Testbench.

Syntax

```
sa::openTextFiles (-session <saSession> | -testbench <saTestbench> |  
-window <giWindow | int>) -files [<string>] [-purpose <string>]
```

Arguments

-files

File(s) to display.

-purpose

Purpose to identify with the given file(s).

-session

Session.

-testbench

Testbench.

-window

PrimeWave Design Environment main console window.

sa::openWaveView

Description

Open WaveView

Syntax

```
sa::openWaveView
```

Returns

<none>

sa::optAddParameter

Creates an optimization parameter

Syntax

```
sa::optAddParameter <name: string> [-initValue <string>] -range <string>  
-type <enum> [-step <string>] -session <saSession>
```

Returns

<saDpoParam> : New optimization parameter

Arguments

name

Optimization parameter name

-initValue

Optimization parameter initial value (Default is:)

-range

Optimization parameter range

-type

Optimization parameter type ({ discrete | enumerated })

-step

Optimization parameter step, must be set for type 'discrete' (Default is:)

-session

Session

Examples

```
sa::optAddParameter M1_W -range "1u,10u" -type discrete -step 1u -session  
[ss::getActiveSession]
```

Sets parameter M1_W type as discrete and range value from 1u to 10u with a 1u step size in the current active session.

```
sa::optAddParameter M1_W -initValue 0 -range "1u,10u" -type discrete  
-step 1u -session [ss::getActiveSession]
```

Sets parameter M1_W type as discrete and range value from 1u to 10u with a 1u step size with an initial value of 0 in the current active session.

```
sa::optAddParameter M1_NF -range "2, 4, 6, 8, 10" -type enumerated  
-session [ss::getActiveSession]
```

Sets parameter M1_NF type as enumerated with 2,4,6,8,10 as the values in the current active session.

sa::optGetFinishedSampleReport

Get the optimization finished sample(s) report

Syntax

```
sa::optGetFinishedSampleReport -session <saSession> -history <string>  
[-sample <string>]
```

Returns

<string> : Returns the finished sample(s) report

Arguments

-session

Session

-history

Optimization history name

-sample

Sample index

sa::optGetFailedSampleReport

Description

Get the optimization failed report.

Syntax

```
sa::optGetFailedSampleReport -session <saSession> -history <string>  
[-sample <string>] [-testbenchName <string>] [-corner <string>]
```

Returns

<string>

Returns the failed report

Arguments

-session

Session

`-history`
Optimization history name.

`-sample`
Sample index.

`-testbenchName`
Testbench name.

`-corner`
Corner name.

Examples

The following example returns the finished report.

```
sa::optGetFailedSampleReport -session [ss::getActiveSession] -history
opt_demo_1 -sample 60 -corner corner
Sample 60:
  Testbench 'OpenLoopMeasure':
    calculation error (1): corner
      objective = { PM }    error = { [Error]: phase_m() argument 1
"v(/out)": Waveform gain does not go through 0dB }
      objective = { UnGain }    error = { [Error]: gain1_f()
argument 1 "v(/out)": Waveform gain does not go through 0dB }
```

sa::optRegisterResultsTableCSM

Register CSM in Optimization Results Table

Syntax

```
sa::optRegisterResultsTableCSM -menu <string> -procedure <string> -script
<string>
```

Returns

<bool> : True if CSM action setup success

Arguments

`-menu`
Action Name of CSM

`-procedure`
Tcl procedure to call when executing the callback

`-script`

The script file to be sourced in optimization flow

sa::optRegisterSetupCallback

Registers a user callback for optimization setup

Syntax

```
sa::optRegisterSetupCallback -procedure <string> [-script <string>]
```

Returns

<none>

Arguments

`-procedure`

Tcl procedure to call when executing the callback

`-script`

The script file to be sourced in optimization flow

sa::optRun

Running the optimization

Syntax

```
sa::optRun -session <saSession> -engine <string> -jobClass <string>  
[-initWithHistory <string>] [-maxIter <int>] [-maxRunTime <float>]  
[-topResults <int>] [-goodDesignNum <int>] [-noImproveIter <int>]  
-runName <string>
```

Returns

<bool> : True if optimization register setup successfully

Arguments

`-session`

Session

`-engine`

Optimization engine

`-jobClass`

Job class name

`-initWithHistory`

The history name used for initial guess (Default is:)

`-maxIter`

Maximum iteration number (Default is: 0)

`-maxRunTime`

Maximum run time (hours) (Default is: 0)

`-topResults`

Top sample results number

`-goodDesignNum`

Optimization stops when reaching the number of design meet all specs

`-noImproveIter`

Optimization stops when there is no improvement after # iterations

`-runName`

Optimization history name

sa::optSetParameterConstraint

Set parameter constraint for optimization setup

Syntax

```
sa::optSetParameterConstraint -session <saSession> -order <string>  
[-group <string>]
```

Returns

<string> : Returns the group name

Arguments

`-session`

Session

`-order`

The parameter constraint order

`-group`

The parameter constraint group name

sa::pick

Description

Performs an interactive pick for design objects.

Syntax

```
sa::pick (-window <giWindow | int> | -testbench <saTestbench>) -prompt  
  <string> [-oneShot <bool>] [-objectTypes <string>] -pickProc <string>  
  [-unpickProc <string>] [-abortProc <string>] [-cancelProc <string>]  
  [-initialPicks <string>] [-tool <string>]
```

Returns

<none>

Arguments

-window

PrimeWave Design Environment main console window.

-testbench

Testbench.

-prompt

Prompt text for design editor status bar.

-oneShot

Terminate command after single pick. (Default is: false).

-objectTypes

List of selectable object types.

-pickProc

The procedure to be triggered when an object is picked.

-unpickProc

The procedure to be triggered when an object is Ctrl-picked.

-abortProc

The procedure to be triggered when the command is aborted.

-cancelProc

The procedure to be triggered when the command is cancelled.

`-initialPicks`

Initial objects (type/name pairs) to be shown as already picked.

`-tool`

Optional tool name.

Examples

The following example creates a dialog from the active testbench. Use the **Pick** icon to select the net from the design.

```
proc pickNetProc {widget pickedObjectInfo} {
    set dialog [db::getAttr widget.root]
    # Get picket net name
    set name [lindex $pickedObjectInfo 0 1]
    set netName [gi::findChild netName -in $dialog]
    db::setAttr netName.value -value $name
}

proc pickAborted {widget} {
    # Return focus to PrimeWave window
    set dialog [db::getAttr widget.root]
    gi::setActiveWindow [db::getAttr parent -of $dialog] -raise true
}

proc startPick {testbench widget} {
    sa::pick -testbench $testbench \
        -prompt "Pick Net" \
        -oneShot true \
        -objectTypes "net" \
        -pickProc [list pickNetProc $widget] \
        -abortProc [list pickAborted $widget]
}

set testbench [ss::getActiveTestbench]
set dialog [sa::createOrGetDialog \
    -testbench $testbench \
    -rootName "probeNet" \
    -rootTitle "Probe Net" \
    -newlyCreatedRef newlyCreated]
# Add widgets if newly created dialog
if {$newlyCreated} {
    set netName [gi::createTextInput netName -parent $dialog -label
        "Net"]
    set pickButton [gi::createPushButton runPick \
        -icon select_design \
        -parent $dialog \
        -execProc [list startPick $testbench]]
    gi::layout $pickButton -rightOf $netName
}
```

sa::plotExpressions

Plots all of the expressions given as saOutputs

Syntax

```
sa::plotExpressions <outputs: dbCollection> -mode <string |  
wfCustomPlotMode> -resultsDir <string> [-resultType <string>]  
[-analysisName <string>] [-params <string>] [-modifier <string>]  
[-doneProc [<string>]] [-bins <int>] [-testbench <saTestbench>] [-job  
<string | xtJob>] [-jobGroup <string | xtJobGroup>] [-historyIndex  
<int>] [-historyName <string>] [-handler <dbInterruptHandler>]  
[-scalarsOnly <bool>] [-plotSelected <bool>] [-allowCustomPlotMode  
<bool>] [-printErrors <bool>] [-noPlot <bool>] [-reCal <string>]  
[-addDeps <bool>] [-invokeFrom <string>] [-incompleteType <string>]
```

Returns

<none>

Arguments

outputs

Output expressions to be plotted

-mode

Plotting mode (new, append, replace, newPanel, active, or custom)

-resultsDir

Default results directory

-resultType

Default result type

-analysisName

Default analysis name

-params

Parametric reduction conditions

-modifier

Modifier function (db20, mag, etc.)

-doneProc

Tcl procedure to call when evaluation is done

`-bins`
Number of bins used for plotting histogram (Default is: 10)

`-testbench`
Testbench

`-job`
Viewer job

`-jobGroup`
Parent job group for waveform viewer job

`-historyIndex`
SAE history index number (Default is: -1)

`-historyName`
SAE history name (Default is:)

`-handler`
Interrupt handler

`-scalarsOnly`
If true, only compute scalar values (Default is: false)

`-plotSelected`
If true, only compute and plot eqn no matter the plot option is TRUE or FALSE
(Default is: false)

`-allowCustomPlotMode`
If true, allow custom plot mode usage (Default is: false)

`-printErrors`
If true, print scalar value database errors (Default is: false)

`-noPlot`
If true, allow Waveviewer to plot waveform (Default is: false)

`-reCal`
If true, Re-calculate expressions (Default is: update)

`-addDeps`
If true, need to add dependences to the outputs (Default is: false)

`-invokeFrom`

Invocation source (Default is: SIM_DONE)

`-incompleteType`

The reason for incomplete simulation results

sa::plotOutputs

Plots all outputs for which the "plot" boolean is set

Syntax

```
sa::plotOutputs (-window <giWindow | int> | -testbench <saTestbench>
| -session <saSession>) [-outputs <dbCollection>] [-paramConditions
<dbCollection>] [-plotMode <string>] [-noPlot <bool>] [-historyIndex
<string>] [-historyName <string>] [-reCal <string>] [-invokeFrom
<string>] [-resultsDir <string>] [-incompleteType <string>]
```

Returns

<none>

Arguments

`-window`

PrimeWave main console window

`-testbench`

Testbench

`-session`

Session

`-outputs`

Outputs to be plotted

`-paramConditions`

parameter conditions

`-plotMode`

Plot mode

`-noPlot`

Open Waveviewer to plot waveform (Default is: false)


```
-historyIndex
    historyIndex (Default is: )

-historyName
    historyName (Default is: )

-reCalc
    Re-calculate expressions (Default is: update)

-invokeFrom
    source of invokation (Default is: SIM_DONE)

-resultsDir
    resultsDir (Default is: )

-incompleteType
    The reason for incomplete simulation results
```

sa::printResults

Description

This command prints the result for given result type. It prompts the user to select devices, nets or terminals in the design window and prints the data for selected circuit element. The design window is opened if it is not already open.

Note:

If the results are from an iterative run, you are prompted for corner or sweep values.

Syntax

```
sa::printResults <type: string> -window <giWindow | int>
```

Returns

<bool>: Status of the print results.

Arguments

<string>

The result type for which data is printed. The following result types are valid:

- dcNode
- tranNode

- dcOp
- tranOp
- mcRes

```
-window giWindow | <int>
```

The PrimeWave Design Environment window object or id.

Errors

- No Testbench is defined in this window.
- The window is not a PrimeWave Design Environment window.
- Data for given analysis type is not available.
- Invalid result type specified.

sa::processSigma

Multiply all the values in the source file with sigma, and output to the target file

Syntax

```
sa::processSigma -sigma <string> -targetPath <string> -sourcePath  
  <string>
```

Returns

<none>

Arguments

```
-sigma  
  sigma value  
  
-targetPath  
  path to .mc0  
  
-sourcePath  
  path to .mc0
```

sa::pushToDesign

Push the parameter values into design

Syntax

```
sa::pushToDesign (-parameters <string> | -resultsDir <string>) -testbench  
  <saTestbench> [-useCopy <bool>] [-preview <bool>]
```

Returns

<bool> : Status

Arguments

-testbench

Testbench containing the design parameterization setup

-parameters

The list of parameter name and value pairs

-resultsDir

The child results directory whose trace parameter values are pushed into the design

-useCopy

If set to true, creates a copy of the design with the new parameter values
(Default is: 1)

-preview

If set to true, show preview dialog before pushing the values into design (Default
is: 1)

sa::qfile_system_watcher

Return true if success, otherwise false

Syntax

```
sa::qfile_system_watcher -of <string> -dir <string> -module <string>
```

Returns

<bool> : true or false

Arguments

-of

add_file/show_file/remove file

-dir

directory

```
-module  
    rv/wv
```

sa::raIgnoreResultTypes

Description

Specifies result types to be ignored by Results Analyzer.

Syntax

```
sa::raIgnoreResultTypes -simulator <saSimulator> -resultTypes <string>  
    [-override <bool>]
```

Returns

<none>

Arguments

-simulator

Simulator for which result types should be ignored.

-resultTypes

List of result types to be ignored.

-override

Override already set result types. The default is false.

sa::reevaluateAllMeasures

Description

Reevaluates all measures.

Syntax

```
sa::reevaluateAllMeasures <testbench: saTestbench> -callback [<string>]
```

Returns

<none>

Arguments

testbench

PrimeWave Design Environment testbench

`-callback`

Callback procedure on completion.

sa::renameCornerParameter

Rename a corner parameter

Syntax

```
sa::renameCornerParameter -of <string> -to <string> [-path <string>]  
-cornersSetup <saCornersSetup>
```

Returns

<none>

Arguments

`-of`

Parameter name that is to be renamed

`-to`

New name for the corner parameter

`-path`

New path to the model file

`-cornersSetup`

Corners setup

sa::renameHistoryPoint

Rename a history point

Syntax

```
sa::renameHistoryPoint -of <string> -to <string> [-parentName <string>]  
-session <saSession>
```

Returns

<none>

Arguments

`-of`

The history point name that is to be renamed

`-to`

New name for the history point

`-parentName`

Parent history point name (Default is:)

`-session`

PrimeWave Session in which to rename the history point

sa::resolveDesignVariables

Description

This command evaluates the expression based on values in the current testbench or design variable set.

Syntax

```
sa::resolveDesignVariables <expr: string> (-testbench <saTestbench> |  
-designVariables <saDesignVariableSet> | -parameters <string>)
```

Returns

Resolved expression value.

Arguments

`<string>`

Expression to be evaluated.

`-testbench`

The testbench object.

`-designVariables`

The design variables set.

`-parameters`

List of parameter name and value pairs.

sa::run

Description

This command runs a simulation with an existing structural netlist. It prints an error if a structural netlist does not exist.

Syntax

```
sa::run (-window <giWindow | int> | -testbench <dbCollection |  
saTestbench>)
```

Returns

Status of the simulation run (<bool>).

Arguments

`-window` *giWindow* | <int>

The PrimeWave Design Environment window object or id.

`-testbench`

Testbench or a collection of testbenches.

Examples

In the following example, `sa::run` runs a simulation for the PrimeWave Design Environment window.

```
sa::run -window 2
```

In the following example, `sa::run` runs a simulation for the `saTestbench` object.

```
sa::run -testbench $saTestbench
```

The following example shows the usage of `sa::run` and `sa::stop`.

```
# Get testbench object from active window  
set tb [sa::findActiveTestbench -window 3]  
sa::run -testbench $tb  
sa::stop -testbench $tb
```

sa::runIterations

Description

Reruns the iterations non-interactively.

Syntax

```
sa::runIterations (-window <giWindow | int> | -testbench <saTestbench>)  
[-failed <bool>] [-killed <bool>] [-paths <string>]
```

Returns

<none>

Arguments

`-window`

PrimeWave Design Environment main console window.

`-testbench`

Testbench.

`-failed`

Rerun all the failed iterations. (Default is: 0.)

`-killed`

Rerun all the killed iterations. (Default is: 0.)

`-paths`

List of iterative results directories to rerun.

sa::runFailedIterations

Description

This command runs failed iterations non-interactively.

Syntax

```
sa::runFailedIterations -window <giWindow | int>
```

Arguments

`-window`

Iterative results window.

sa::saveChartImages

Description

Creates an saCharts object and saves it to the results dir as `charts.xml`.

Syntax

```
sa::saveChartImages -testbench <saTestbench>
```

Returns

<saCharts> : New charts object

Arguments

`-testbench`
Testbench.

sa::saveCornersSetup

Description

Save corners to an external file.

Syntax

```
sa::saveCornersSetup (-dialog <giDialog> | -window <giWindow | int> |  
-session <saSession> | -testbench <saTestbench>) -filePath <string>  
[-overwrite <bool>] [-combined <bool>]
```

Returns

<none>

Arguments

`-dialog`
Corners Setup dialog box from which to save corners.

`-window`
PrimeWave Design Environment Window

`-session`
PrimeWave Design Environment Session

`-testbench`
PrimeWave Design Environment Testbench

`-filePath`
XML file into which the corners should be saved.

`-overwrite`
If true, an existing file is silently overwritten. (Default is: false)

`-combined`
If true, the csv format will merge parameter and corner tables into one. (Default is: false)

Examples

The following example opens MTB states and copies corners setup from one MTB session to another.

```
set session1 [sa::createSession -testSuiteMode true]
sa::loadTestSuite mtb \
    -session $session1 \
    -storageType openaccess \
    -lib topLib \
    -cell ring_osc_mtb

# Open session in GUI
sa::showConsole -session $session1

set session2 [sa::createSession -testSuiteMode true]
sa::loadTestSuite rc_tb_mtb \
    -session $session2 \
    -storageType openaccess \
    -lib topLib \
    -cell rc_tb

# Open session in GUI
sa::showConsole -session $session2

sa::saveCornersSetup -session $session1 -filePath corners.xml -overwrite
true
sa::loadCornersSetup -session $session2 -filePath corners.xml -mergeMode
replace

sa::saveTestSuite -session $session1
```

sa::saveDataDir

Description

Makes a copy of the testbench data directory.

Syntax

```
sa::saveDataDir -of <saTestbench> -to <string> [-block <bool>]
```

Returns

<none>

Arguments

-of

The testbench whose dataDir is to be saved.

`-to`

Name of directory in which to save data results.

`-block`

Run in blocking mode. (Default is: false)

sa::saveDesignParamsSetup

Save Design Parameters Setup to xml

Syntax

```
sa::saveDesignParamsSetup (-parent <giWindow | int> | -testbench  
    <saTestbench>) -filepath <string>
```

Returns

<none>

Arguments

`-parent`

PrimeWave Window

`-testbench`

PrimeWave Testbench

`-filepath`

File path

sa::saveDesVars

Description

Saves the design variables to a design.

Syntax

```
sa::saveDesVars (-window <giWindow | int> | -testbench <saTestbench>)
```

Returns

<none>

Arguments

`-window`

PrimeWave Design Environment main console window.

`-testbench`
Testbench.

Examples

The following example saves design variables of the active testbench in the top design cell DM file.

```
sa::saveDesVars -testbench [ss::getActiveTestbench]
```

sa::saveDesVarsToText

Description

List the variables.

Syntax

```
sa::saveDesVarsToText (-window <giWindow | int> | -testbench  
<saTestbench> | -session <saSession>) [-variableSet <string>] [-format  
[<string>]] [-delimiter <string>] [-filePath <string>] [-allTestbenches  
<bool>]
```

Returns

<none>

Arguments

`-window`
SAE main console window.

`-testbench`
Testbench

`-session`
Session

`-variableSet`
Name of variable set to load into. ("" = current). (Default is:)

`-format`
The list of column headers and attribute names for formatting.

`-delimiter`
Column header delimiter character.

`-filePath`

File path to which to save the list.

`-allTestbenches`

Save variables for all testbenches. (Default is: false)

Examples

The following example saves design variables to an external file from the active testbench.

```
sa::saveDesVarsToText -testbench [ss::getActiveTestbench] -delimiter ","  
-filePath designVars.txt  
xt::openTextViewer -files designVars.txt
```

sa::saveHistoryDir

Makes a copy of the testbench data directory

Syntax

```
sa::saveHistoryDir [-of <saSession>] [-uniqueName <string>] -history  
<string> -includeSimulation <bool> -to <string> [-appendName  
<string>] [-summary <bool>] [-rename <string>]
```

Returns

<none>

Arguments

`-of`

The session whose history is to be saved

`-uniqueName`

The unique name used to find the session

`-history`

The history to be saved

`-includeSimulation`

If the simulation data is included

`-to`

The location to save for the cloned history

`-appendName`

The directory name will be appended to location path

`-summary`

If the summary file storing the session name, history list is required to be saved to '-to' location (Default is: true)

`-rename`

The renamed history map. (Default is:)

sa::saveImages

Description

Plots and saves outputs where the `saveImage` Boolean is set.

Syntax

```
sa::saveImages (-window <giWindow | int> | -testbench <saTestbench>)
[-callback <string>] [-blocking <bool>]
```

Returns

<none>

Arguments

`-window <giWindow | int>`

The PrimeWave Design Environment main console window.

`-testbench <saTestbench>`

The testbench.

`-callback <string>`

The callback when finished.

`-blocking`

Command does not return until all processing is complete. (Default is: false)

sa::saveObjectToFile

Save the object as an xml file

Syntax

```
sa::saveObjectToFile -object <dbObject> [-attributes <string>] -path
<string>
```

Returns

<bool> : True if succeed

Arguments

-object

Object to save

-attributes

Name of object attributes to save

-path

Specify where to save the object

sa::saveOutputs

List the outputs.

Syntax

```
sa::saveOutputs (-window <giWindow | int> | -testbench <saTestbench>  
| -session <saSession>) [-outputSet <string>] [-format [<string>]]  
[-delimiter <string>] [-filePath <string>] [-allTestbenches <bool>]
```

Returns

<none>

Arguments

-window

PrimeWave main console window

-testbench

Testbench

-session

Session

-outputSet

Name of output set to load into ("" = current). (Default is:)

-format

The list of column headers and attribute names for formatting.

`-delimiter`

Column header delimiter character.

`-filePath`

File path to which to save the list.

`-allTestbenches`

Save outputs for all testbenches. (Default is: false)

sa::saveResultDir

Save results directory of an saTestbench

Syntax

```
sa::saveResultDir <dir: string>
```

Returns

<none>

Arguments

`dir`

Directory of saved path.

Examples

The following example saves the simulation results of the active testbench or active MTB session to the specified directory.

```
sa::saveResultDir ./results_backup
```

sa::saveScript

Description

Saves a script containing second-level commands. The script can be used to replicate the current simulation setup and run simulation in batch (non-GUI) mode.

Syntax

```
sa::saveScript <file: string> (-testbench <saTestbench> | -session  
<saSession>) [-run <bool>] [-plot <bool>] [-generateTextOutput <bool>]  
[-useSavedState <bool>] [-traceabilityExport <bool>]
```

Returns

<none>

Arguments

`file`

Output file path.

`-testbench`

The testbench to save to script.

`-session`

The session to save to script.

`-run`

The script will run the simulations.

Default is: 1.

`-plot`

The script will plot the waveforms.

Default is: 1.

`-generateTextOutput`

The script will generate text reports. (Default is: 1)

`-useSavedState`

The script will use saved state instead of atomic commands to create the session. (Default is: 0)

`-traceabilityExport`

The script will be used for traceability Export. (Default is: 0)

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set filePath ~/session.tcl
sa::saveScript $filePath -generateTextOutput true -plot true \
-run true -testbench $tb
```

sa::saveSessionSetup

Saves test suite to disk according to configuration stored in session.

Syntax

```
sa::saveSessionSetup <name: string> -session <saSession> [-categories  
[<string>]] -saveTestbench <bool> [-toHistory <bool>] [-saveDir  
<string>]
```

Returns

<none>

Arguments

name

Session setup name

-session

PrimeWave session to save

-categories

Categories of session to operate on

-saveTestbench

Save testbench or not

-toHistory

Save session setup to minor history check point (Default is: false)

-saveDir

Location to save the setup (Default is:)

sa::saveState

Description

Saves testbench data to a state on disk.

Syntax

```
sa::saveState <name: string> -testbench <saTestbench> [-cell <dmCell>]  
[-use <enum>] [-rootPath <string>] [-categories [<string>]] [-exclude  
<bool>] [-comment <string>]
```

Arguments

<string>

The state name.

-testbench <saTestbench>

The testbench to save.

-cell <dmCell>

The dmCell containing state as a child.

`-use <enum>`

The storage policy (`{directory | openaccess | statesDirectory}`).

`-simulator <string>`

Simulator name.

`-rootpath <string>`

The root directory.

`-categories {<string>}`

The categories of testbenches on which to operate.

`-exclude <bool>`

Indicates whether the categories are excluded. Default value is false.

`-comment <string>`

The state comment.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
set stateName opamp_ac
set libName cornerAnalysis
set cellName Opamp_OpenLoop
sa::saveState $stateName -testbench $tb -use openaccess \
-cell [dm::findCell $cellName -libName $libName]
```

sa::saveTestSuite

Description

Saves test suite to disk according to configuration stored in session.

Syntax

```
sa::saveTestSuite (-window <giWindow | int> | -session <saSession>)
```

Arguments

`-window`

The PrimeWave Design Environment window.

`-session`

The PrimeWave Design Environment window.

Examples

```
# Get MTB session
set session [sa::getSessions -window 3]
set destLibName cornerAnalysis
sa::saveTestSuiteAs mtb_new_name -session $session \
-storageType openaccess -lib $destLibName -comment re-saving
sa::saveTestSuite -session $session
```

sa::saveTestSuiteAs

Description

Saves test suite to disk.

Syntax

```
sa::saveTestSuiteAs <name: string> (-window <giWindow | int> | -session  
<saSession>) -storageType <enum> [-rootPath <string>] [-lib <string>]  
[-cell <string>] [-category <string>] -comment <string> [-moveTo <bool>]  
[-checkIn <bool>]
```

Arguments

-window

The PrimeWave Design Environment window.

-session

The PrimeWave Design Environment session.

-storageType

Storage type ({directory | openaccess})

-cell

Name of cell containing test suite(s). Used when -storageType option is set to openaccess. If blank, test suite name is used for the cell level.

-category

Test suite category.

-rootPath

The root directory containing test suite(s). Required when -storageType option is set to directory.

-lib

Name of library containing test suite(s). Required when -storageType option is set to openaccess.

`-comment`

Test suite comment.

`-moveTo`

Move current session to new storage configuration.

`-checkIn`

Check in the openaccess cellviews when finished saving.

Examples

```
# Get MTB session
set session [sa::getSessions -window 3]
set destLibName cornerAnalysis
sa::saveTestSuiteAs mtb_new_name -session $session \
-storageType openaccess -lib $destLibName -comment re-saving
sa::saveTestSuite -session $session
```

sa::saveTestSuiteResults

Description

Archive the results directory structure for a test suite.

Syntax

```
sa::saveTestSuiteResults -session <saSession> [-rootPath <string>]
```

Arguments

`-session`

The PrimeWave Design Environment session to save.

`-rootPath`

The root directory containing test suite(s). Required when `-storageType` option is set to `directory`.

Examples

```
# Get MTB session
set session [sa::getSessions -window 3]
sa::saveTestSuiteResults -session $session -rootPath ~/mtb_saved_res
```

sa::sciToEng

Convert double/string values to engineering notation.

Syntax

```
sa::sciToEng <value: string> [-precision <int>] [-suffix <string>]  
[-trimZero <bool>]
```

Returns

<string> :

Arguments

value

Input number or string.

-precision

Precision used for result.

-suffix

Suffix for the converted value.

-trimZero

If the zeros after decimal point will to be trimmed. (Default is: 1)

sa::selectionCancelled

Description

Requests a cancellation of the `ide::pick` working on an `saSelection`. Can be called within the Tcl callbacks.

Syntax

```
sa::selectionCancelled -in <saSelection>
```

Arguments

-in `saSelection`

Selection Object associated with `ide::pick` whose cancellation is being requested.

sa::selectChartAxes

Description

Select the axes in an PrimeWave Design Environment data mining chart.

Syntax

```
sa::selectChartAxes <window: giWindow | int> -testbenchName <string>  
-chartType <string> -axisNames [<string>]
```

Returns

<none>

Arguments

window

The charts window.

-testbenchName

The testbench name.

-chartType

The chart type (measureVsMeasure or parallelAxis).

-axisNames

Axis names.

sa::selectChart

Description

Selects the current chart from the gallery in the given saChartsWindow.

Syntax

```
sa::selectChart <window: giWindow | int> -testbench <saTestbench>  
-chartType <enum> -xAxisName <string> [-yAxisName <string>]
```

Returns

<none>

Arguments

window

Chart window.

-testbench

Testbench.

-chartType

Chart Type. ({ histogram | qq | scatter })

`-xAxisName`

X Axis name.

`-yAxisName`

Y Axis name.

sa::selectOutputs

Start a command to select outputs

Syntax

```
sa::selectOutputs [-window <giWindow | int>] [-testbench <saTestbench>]  
                  [-dialog <giDialog>] [-outputs <saOutputSet>] [-outputIndex <int>]
```

Returns

<none>

Arguments

`-window`

PrimeWave main console window

`-testbench`

Testbench

`-dialog`

PrimeWave Outputs Setup Dialog

`-outputs`

PrimeWave Outputs Collection

`-outputIndex`

Output Index

sa::selectTandemGroup

Returns the current output set of Outputs dialog box.

Syntax

```
sa::selectTandemGroup [-dialog <giDialog>] -value <string>
```

Returns

<none>

Arguments

`-dialog`
 `generate_corners_dialog`

`-value`
 Tandem Group Name

sa::sendMessage

Sends an informational, warning or error message to the console.

Syntax

```
sa::sendMessage -id <string> [-severity <string>] [-args <string>]
```

Returns

<none>

Arguments

`-id`
 Message ID for a specific error or warning

`-severity`
 Message severity i.e. error, warning... (Default is: info)

`-args`
 Argument(s) that are required for a specific error message id

sa::setActiveHistoryPoint

Description

Sets the active history point for a session.

Syntax

```
sa::setActiveHistoryPoint -name <string> -session <saSession>
```

Returns

<none>

Arguments

-name

History point name

-session

PrimeWave Design Environment Session

Examples

In the following example, note that the history name must be history_<index>, even if it is renamed after creation.

```
# Get MTB session
set session [sa::getSessions -window 3]
sa::setActiveHistoryPoint -name history_1 -session $session
```

sa::setActiveTestbench

Description

Returns the active testbench in a window.

Syntax

```
sa::setActiveTestbench <testbench: saTestbench | string> -window
<giWindow | int>
```

Arguments

testbench <saTestbench>

A PrimeWave Design Environment testbench.

-window <giWindow | int>

A PrimeWave Design Environment window.

Examples

```
sa::setActiveTestbench tb2 -window 3
sa::setActiveTestbench $tb_obj -window 3
```

sa::setCornerParamValue

Description

This command sets the corner parameter value for the specified corner.

Syntax

```
sa::setCornerParamValue <name: string> -cornerName <string> -value  
    <string> -cornersSetup <saCornersSetup>
```

Arguments

<string>

Name of the corner parameter.

-cornerName <string>

Name of the corner.

-value <string>

Section name in the model file if the corner parameter is a model file design variable value if the corner parameter is a model file value of the temperature if the corner parameter is temperature.

-cornersSetup [saCornersSetup](#)

Corners setup object which contains the corner parameter definitions.

Errors

- The corner parameter name does not exist.
- The corner name does not exist.

Examples

To set the corner parameters' values in a newly added corner:

```
set tb [sa::findActiveTestbench -window 2]  
set cs [db::getattr tb.cornersSetup]  
sa::setCornerParamValue temp -cornerName C1 -value 25 -cornersSetup $cs  
sa::setCornerParamValue vdd -cornerName C1 -value 0.95 -cornersSetup $cs  
sa::setCornerParamValue reference40_models.lib -cornerName C1 -value FF  
    -cornersSetup $cs
```

This example sets the values for temp, vdd, and reference40_models.lib corner parameters for the corner named "C1".

sa::setResultsAnalyzerOutputSet

Description

Changes output set to which the ResultsAnalyzer adds outputs.

Syntax

```
sa::setResultsAnalyzerOutputSet -of <giWindow | int> [-to <saOutputSet>]
```

Arguments

`-of`

Analyze Results Window.

`-to`

Output set in which to add outputs.

Examples

```
sa::setResultsAnalyzerOutputSet -to set1
```

In this example, `sa::setResultsAnalyzerOutputSet` sets the output set name as `set1` for the ResultsAnalyzer output.

sa::setRunDir

Description

By default, PrimeWave Design Environment stores netlists and results in a directory structure under the root directory defined by the preference `saResultsDir`.

`sa::setRunDir` can be used to override this behavior on a per testbench basis.

Syntax

```
sa::setRunDir -value <string> -of <saTestbench>
```

Arguments

`-value <string>`

Path.

`-of`

The testbench object.

Examples

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
sa::setRunDir -of $tb -value ~/sim_dir
puts [sa::getRunDir -of $tb]
```

sa::showAboutPrimeWave

Shows PrimeWave Version

Syntax

```
sa::showAboutPrimeWave
```

Returns

<none>

Arguments

<none>

sa::showAceScripts

Description

Show the ACE scripts dialog box.

Syntax

```
sa::showAceScripts -parent <giWindow | int>
```

Returns

<giDialog> : Dialog object.

Arguments

-parent

PrimeWave Design Environment main console window.

Examples

```
sa::showAceScripts -parent 3
```

sa::showAdvancedAnnotations

Description

Opens the **Advanced Annotation** dialog box.

Syntax

```
sa::showAdvancedAnnotations [-parent <giWindow | int>]
```

Arguments

-parent

PrimeWave Design Environment main console window.

Examples

```
sa::showAdvancedAnnotations -parent 3
```

sa::showAgingSetup

Description

Show Aging setup dialog

Syntax

```
sa::showAgingSetup (-parent <giWindow | int> | -testbench <saTestbench>)
```

Returns

<none>

Arguments

-parent

SAE Window

-testbench

SAE Testbench

sa::showAimScripts

Opens the Aim Scripts Dialog

Syntax

```
sa::showAimScripts -parent <giWindow | int>
```

Returns

<giDialog> : Dialog object

Arguments

-parent

SAE main console window

sa::showAnalysisOptions

Description

Displays the analysis options dialog box.

Syntax

```
sa::showAnalysisOptions <name: string> (-parent <giWindow | int> |  
-testbench <saTestbench>) [-directEdit <bool>] [-consoleTestbench  
<saTestbench>] [-parentDialog <giDialog>]
```

Returns

<giDialog>

The simulator options dialog object.

Arguments

name <string>

The name of the analysis from the provided testbench that has its options edited.

-parent <giWindow|int>

The PrimeWave Design Environment Window object or ID.

-testbench <saTestbench>

The testbench object.

-directEdit <bool>

Indicates that the values you change in the GUI table directly change the target analysis object without needing to click **OK** or **Apply**.

-consoleTestbench <saTestbench>

Specifies the PrimeWave Design Environment testbench with a main console on which this GUI is managed and stored. This argument is used for cases where the primary testbench argument is for a temporary testbench that is associated with a primary testbench with a main console.

-parentDialog

The parent to be set for the analysis options dialog

Errors

1. No Testbench is defined in this window.
2. The window is not a PrimeWave Design Environment window.
3. The analysis does not exist.

Examples

```
# Analysis option dialog is relevant for PrimeWave Design  
Environment-Spectre integration
```

```
sa::showAnalysisOptions dc -testbench $tb  
# or  
sa::showAnalysisOptions dc -parent 3
```

sa::showAnalyzeResults

Shows the Analyze Results window

Syntax

```
sa::showAnalyzeResults -testbench <saTestbench> [-parent <giWindow  
| int>] [-tool <enum>] [-expression <string>] [-paramCond <string>]  
[-selectedStart <int>] [-selectedEnd <int>] [-outputSet <saOutputSet>]  
[-filterAnalyses <enum>] [-resultType <string>] [-analysisName <string>]  
[-global <bool>]
```

Returns

<giWindow> : saAnalyzeResults window

Arguments

-testbench

Testbench associated with AnalyzeResults

-parent

Parent window, on whose closure the AnalyzeResults window will close

-tool

Which tool tab to show ({ calculator | plotAssist })

-expression

Expression to put in expression buffer

-paramCond

Parameter condition in the reduction pane

-selectedStart

Selected text start index in the expression pane

-selectedEnd

Selected text end index in the expression pane

-outputSet

Output Set to add outputs to

`-filterAnalyses`

Which Filter Analyses option to select ({ all | auto | withData })

`-resultType`

ResultType to select in the analysis tree

`-analysisName`

AnalysisName to select in the analysis tree

`-global`

Is for global outputs or not (Default is: false)

sa::showBgNetlistAndRunProgressDialog

Create background netlist and run progress dialog

Syntax

```
sa::showBgNetlistAndRunProgressDialog [-parent <giDialog | giWindow |  
    string>] [-title <string>] [-message <string>] [-execProc <string>]
```

Returns

<giDialog> : Dialog object

Arguments

`-parent`

Parent window or dialog

`-title`

Window title

`-message`

Window message

`-execProc`

Proc to be executed after saving settings in this dialog.

sa::showChainingSetup

Description

Opens the PrimeWave Design Environment Testbench Chaining dialog.

Syntax

```
sa::showChainingSetup (-parent <giWindow | int> | -testbench  
    <saTestbench>)
```

Returns

<giDialog> : Dialog object

Arguments

-parent

The PrimeWave Design Environment main console window.

-testbench

Testbench.

sa::showChartAxisDialog

Description

Show the PrimeWave Design Environment data mining chart axis selection dialog box.

Syntax

```
sa::showChartAxisDialog -parent <giWindow | int>
```

Arguments

-parent

The charts window.

sa::showCheckResults

Description

Opens a window with Bias/Circuit Check results in the given directory.

Syntax

```
sa::showCheckResults -dataDir <string>
```

Arguments

-dataDir

Path to directory containing Bias/Circuit Check results.

sa::showCompareResults

Description

Creates a PrimeWave Design Environment Compare Results window.

Syntax

```
sa::showCompareResults <session: saSession> [-reference <string>]  
[-current <string>] [-testbench <string>] [-reference_testbench  
<string>] [-measurementName <string>] [-iteration1 <string>]  
[-iteration2 <string>] [-mode <enum>]
```

Returns

<giWindow> : saResultsCompare.

Arguments

`session`

PrimeWave Design Environment Session.

`-reference`

Reference history point name.

`-current`

Current history point name.

`-testbench`

The name of the testbench for comparison ("measurement" mode only).

`-reference_testbench`

The name of the reference testbench for the comparison ("measurement" mode only)

`-measurementName`

The name of the measurement for comparison ("measurement" mode only).

`-iteration1`

The name of the first iteration ("iteration" mode only).

`-iteration2`

The name of the second iteration ("iteration" mode only).

`-mode`

View mode. ({ summary | measurement | iteration | details }) ({ details | iteration | measurement | summary }).

sa::showComparisonSetup

Shows the corners setup dialog

Syntax

```
sa::showComparisonSetup (-parent <giWindow | int> | -session <saSession>
| -testbench <saTestbench>)
```

Returns

<none>

Arguments

-parent

SAE Window

-session

SAE Session

-testbench

SAE Testbench

sa::showConsole

Description

This command opens the PrimeWave Design Environment window. If the session argument is specified, the window will use the provided session object, or else a new session is created.

Syntax

```
sa::showConsole (-session <saSession> | -context <deContext>)
```

Returns

PrimeWave Design Environment main window (*giWindow*).

Arguments

-session <saSession>

PrimeWave Design Environment session with which to initialize the console.

-context <deContext>

Design context representing the design to be used in the default testbench.

sa::showConvergenceAids

Description

This command displays the **Convergence Aids** dialog box.

Syntax

```
sa::showConvergenceAids (-parent <giWindow | int> | -testbench  
    <saTestbench>)
```

Arguments

`-parent` *giWindow* | *<int>*

The PrimeWave Design Environment window object or id.

`-testbench`

The testbench object.

sa::showCopyTestbenchCategories

Description

Opens the **Copy Testbench Categories** dialog box.

Syntax

```
sa::showCopyTestbenchCategories [-parent <giWindow | int>]
```

Returns

<giDialog>: Dialog object.

Arguments

`-parent`

The PrimeWave Design Environment main console window.

sa::showCornersSetup

Description

This command displays the **Corners** setup dialog box.

Syntax

```
sa::showCornersSetup (-parent <giWindow | int> | -session <saSession>  
    | -testbench <saTestbench>)
```

Arguments

`-parent giWindow | <int>`

The PrimeWave Design Environment window object or id.

`-session`

The PrimeWave Design Environment session.

`-testbench`

The testbench object.

sa::showCreateTestbench

Description

This command opens the PrimeWave Design Environment **Create Testbench** dialog box.

Syntax

```
sa::showCreateTestbench -parent <giWindow | int>
```

Returns

`<giDialog>` : Dialog object.

Arguments

`-parent`

The PrimeWave Design Environment main window.

sa::showCustomCommands

Description

This command opens the PrimeWave Design Environment custom commands dialog box.

Syntax

```
sa::showCustomCommands (-parent <giWindow | int> | -testbench  
  <saTestbench>) -categoryName <string>
```

Returns

The dialog object (`giDialog`).

Arguments

`-parent` *giWindow* | `<int>`

The PrimeWave Design Environment main console window.

`-testbench`

The testbench object.

`-categoryName`

Specify the Category Name.

sa::showDesignParametersSetup

Show design parameterization dialog

Syntax

```
sa::showDesignParametersSetup (-parent <giWindow | int> | -session  
    <saSession> | -testbench <saTestbench>)
```

Returns

`<none>`

Arguments

`-parent`

PrimeWave Window

`-session`

PrimeWave Session

`-testbench`

PrimeWave Testbench

sa::showDesignWindow

Description

Shows the main design window that is associated with the given testbench.

Syntax

```
sa::showDesignWindow (-parent <giWindow | int> | -testbench  
    <saTestbench>) [-readOnly <bool>]
```

Returns

The design window (giWindow).

Arguments

`-parent`

PrimeWave Design Environment main window.

`-testbench`

Testbench.

`-readOnly`

Opens the design in read-only mode. (Default is: 1)

Examples

The following example opens the main design associated with the active testbench.

```
sa::showDesignWindow -testbench [ss::getActiveTestbench]
```

sa::showDeviceCheckResults

Description

Opens the dialog for setting up Device Check Options.

Syntax

```
sa::showDeviceCheckResults [-parent <giWindow | int>]
```

Returns

<giDialog> : Dialog object.

Arguments

`-parent`

The PrimeWave Design Environment main window.

sa::showDeviceCheckSetup

Description

Opens the dialog for setting up Device Check Options.

Syntax

```
sa::showDeviceCheckSetup [-parent <giWindow | int>]
```


Returns

<giDialog> : Dialog object.

Arguments

-parent

The PrimeWave Design Environment main window.

sa::showDigitalAnalyzerOptions

Description

Opens the dialog for updating options for digital files.

Syntax

```
sa::showDigitalAnalyzerOptions -parent <giDialog> [-language <string>]
```

Returns

<none>

Arguments

-parent <giDialog>

The PrimeWave Design Environment **Digital Analyzer Options** dialog box.

-language <string>

The selected digital language (the default is Verilog).

sa::showDigitalDebugger

Description

Shows the digital debugger.

Syntax

```
sa::showDigitalDebugger -parent <giWindow | int>
```

Arguments

-parent

The PrimeWave Design Environment main console window.

sa::showDigitalFileOptions

Opens the dialog for setting up digital file options

Syntax

```
sa::showDigitalFileOptions -parent <giDialog>
```

Returns

<giDialog> : Dialog object

Arguments

-parent
Mixed Signal Options dialog

sa::showDigitalTiming

Description

Opens the dialog for setting up Digital Timing.

Syntax

```
sa::showDigitalTiming [-parent <giWindow | int>]
```

Returns

<giDialog>: Dialog object.

Arguments

-parent
The PrimeWave Design Environment main window.

sa::showEditAnalyses

Description

This command displays the **Edit Analysis** dialog box.

Syntax

```
sa::showEditAnalyses (-parent <giWindow | int> | -testbench  
  <saTestbench>) -analysisName <string>
```

Returns

The dialog object (*giDialog*).

Arguments

`window`

PrimeWave Design Environment main window.

`-parent giWindow | <int>`

The PrimeWave Design Environment window object or id.

`-testbench giWindow | <int>`

Testbench.

`-analysisName <string>`

Analysis name.

sa::showEditDescription

Description

Opens the **Edit Description** dialog box

Syntax

```
sa::showEditDescription -window <giWindow | int>
```

Returns

<giDialog> : Dialog object

Arguments

`-window`

PrimeWave Design Environment main window.

sa::showEditVariables

Description

This command displays the **Edit Variables** dialog box.

Syntax

```
sa::showEditVariables (-parent <giWindow | int> | -session <saSession> |  
-testbench <saTestbench>)
```

Returns

The dialog object. (*giDialog*).

Arguments

`-parent giWindow | <int>`

The PrimeWave Design Environment window object or id.

`-session`

PrimeWave Design Environment session.

`-testbench`

The PrimeWave Design Environment testbench object.

Errors

No testbench is defined in this window.

sa::showEnvironmentOptions

Description

This command displays the **Environment Options** dialog box.

Syntax

```
sa::showEnvironmentOptions (-parent <giWindow | int> | -testbench  
    <saTestbench>)
```

Returns

The **Environment Options** dialog box (*giDialog*).

Arguments

`window`

PrimeWave Design Environment main window.

`-parent giWindow | <int>`

The PrimeWave Design Environment window object or id.

`-testbench`

The testbench object.

Errors

No testbench is defined in this session.

sa::showExportCorners

Description

Opens the PrimeWave Design Environment **Export Corners** dialog box.

Syntax

```
sa::showExportCorners -parent <string>
```

Returns

<giDialog> : Dialog object

Arguments

-parent

Parent corners setup dialog.

sa::showExportResultsCompare

Opens the Export Results Compare dialog

Syntax

```
sa::showExportResultsCompare -parent <string>
```

Returns

<giDialog> : Dialog object

Arguments

-parent

Parent Results Compare window.

sa::showExportSessionReport

Description

Shows **Export HTML Report** dialog box.

Syntax

```
sa::showExportSessionReport (-window <int> | -session <saSession>)  
[-baseDir <string>]
```

Returns

<none>

Arguments

`-window`

Results Viewer Window.

`-session`

PrimeWave Design Environment Session.

`-baseDir`

Base directory under which report files will be written.

sa::showExtremeCases

Description

Opens the SAE **Extract Extreme Cases** dialog box.

Syntax

```
sa::showExtremeCases (-parent <giWindow | int> | -testbench  
    <saTestbench>)
```

Returns

<giDialog> : Dialog object.

Arguments

`-parent`

PrimeWave Design Environment main window.

`-testbench`

Testbench.

sa::showGlobalJobOptions

Description

Opens the PrimeWave Design Environment **Global Job Options** dialog box.

Syntax

```
sa::showGlobalJobOptions -parent <giWindow | int>
```

Returns

<giDialog> : Dialog object

Arguments

`-parent`

PrimeWave Design Environment main window.

sa::showGlobalSimulatorOptions

Description

This command displays the simulator options dialog box.

Syntax

```
sa::showGlobalSimulatorOptions (-parent <giWindow | int> | -testbench  
    <saTestbench>) [-optionsAttribute <string>] [-optionGroup <string>]  
    [-title <string>]
```

Returns

Simulator options dialog object (*giDialog*).

Arguments

`-parent` *giWindow* | `<int>`

The PrimeWave Design Environment window object or id.

`-testbench`

The testbench object.

`-optionsAttribute`

Options Attribute Name.

Default:.

`-optionGroup`

Option Group Name.

`-title`

Dialog title.

Errors

- No Testbench is defined in this window.
- The window is not a PrimeWave Design Environment window.

sa::showImportCorners

Description

Opens the PrimeWave Design Environment **Import Corners** dialog box.

Syntax

```
sa::showImportCorners -parent <string>
```

Returns

<giDialog> : Dialog object

Arguments

-parent

Parent corners setup dialog box.

sa::showImportDigitalFiles

Description

Opens the dialog box for importing digital files.

Syntax

```
sa::showImportDigitalFiles -parent <giDialog>
```

Returns

<none>

Arguments

-parent <giDialog>

The PrimeWave Design Environment **Import Digital Files** dialog box.

sa::showIncludeDspfOptions

Opens the dialog box to specify the DSPF include options.

Syntax

```
sa::showIncludeDspfOptions (-parent <giWindow | int> | -testbench  
    <saTestbench>) -includeFileName <string> -index <string> [-section  
    <string>]
```


Returns

<giDialog> : Dialog object

Arguments

-parent

PrimeWave Design Environment main window

-testbench

Testbench

-includeFileName

Specifies the Include File Name

-index

Specifies the Include File Index

-section

Specifies the Include File Section

sa::showIncludeFiles

Description

This command displays the **Include Files** dialog box.

Syntax

```
sa::showIncludeFiles (-parent <giWindow | int> | -session <saSession> |  
-testbench <saTestbench>)
```

Returns

N/A.

Arguments

-parent *giWindow* | <int>

The PrimeWave Design Environment window object or id.

-testbench

The testbench object.

sa::showIncludeGroupDef

Shows the include group dialog

Syntax

```
sa::showIncludeGroupDef [-parent <giWindow | int>] [-def  
  <saIncludeGroupDef>] [-defName <string>]
```

Returns

<none>

Arguments

-parent

Parent window

-def

Model group definition

-defName

Name for the new definition

sa::showIncludeIbisEbdPkgOptions

Opens the dialog to specify the IBIS/EBD/PKG included options.

Syntax

```
sa::showIncludeIbisEbdPkgOptions (-parent <giWindow | int> | -testbench  
  <saTestbench>) -includeFileName <string> -index <string> -type <string>
```

Returns

<giDialog> : Dialog object

Arguments

-parent

SAE main console window.

-testbench

Testbench.

-includeFileName

Specify the Include File Name.

-index

Specify the Include File Index.

`-type`

Specify the Include File Type.

sa::showJobMonitor

Description

Opens the Job Monitor. The Job Monitor is a filtered view of the jobs associated with the given PrimeWave Design Environment session.

Syntax

```
sa::showJobMonitor (-parent <giWindow | int> | -testbench <saTestbench>)
```

Returns

<giWindow> : Window object.

Arguments

`-parent`

PrimeWave Design Environment main Testbench.

sa::showLoadDesVars

Description

Opens the dialog for loading design variables.

Syntax

```
sa::showLoadDesVars -parent <giWindow | int>
```

Arguments

`-parent`

Parent SAE console window.

sa::showLoadMacros

Description

Opens the dialog box for loading macros.

Syntax

```
sa::showLoadMacros [-parent <giDialog | giWindow | int>]
```

Returns

<giDialog>

The dialog box object.

Arguments

-parent <giDialog | giWindow | int>

The parent window or dialog box.

sa::showLoadOutputs

Description

Opens the dialog box for loading outputs.

Syntax

```
sa::showLoadOutputs -parent <giWindow | int [-overwrite <bool>]]>
```

Returns

<none>

Arguments

-parent <giDialog | giWindow | int>

The parent window or dialog box.

-overwrite

If the current outputs will be overwritten or not (Default is: false)

sa::showLoadResults

Description

This command displays the PrimeWave Design Environment **Load Results** dialog box.

Syntax

```
sa::showLoadResults (-parent <giWindow | int> | -testbench <saTestbench>)
```

Returns

The dialog object. (*giDialog*)

Arguments

`-parent giWindow | <int>`

The PrimeWave Design Environment main window.

`-testbench`

The testbench object.

sa::showLoadState

Description

This command displays the **Load State** dialog box.

Syntax

```
sa::showLoadState -parent <giWindow | int>
```

Returns

The dialog object. (*giDialog*).

Arguments

`-window`

PrimeWave Design Environment main window.

`-parent giWindow | <int>`

The PrimeWave Design Environment main window.

sa::showLoadStateIntoNewTestbench

Description

Opens the dialog box for loading a state into a new testbench.

Syntax

```
sa::showLoadStateIntoNewTestbench -parent <giWindow | int>
```

Returns

<giDialog>: Dialog object.

Arguments

`-parent`

The PrimeWave Design Environment main window.

sa::showLoadStateToComparisonTable

Opens the SAE save state dialog

Syntax

```
sa::showLoadStateToComparisonTable -parent <giWindow | int>
```

Returns

<giDialog> : Dialog object

Arguments

-parent

PrimeWave main console window

sa::showLoadTestSuiteResults

Description

Opens the dialog box for loading a state into a new testbench.

Syntax

```
sa::showLoadTestSuiteResults (-parent <giWindow | int> | -testbench  
    <saTestbench>)
```

Returns

<giDialog>: Dialog object.

Arguments

-parent

The PrimeWave Design Environment main window.

-testbench

Testbench.

sa::showMacros

Description

Opens the dialog box for macros.

Syntax

```
sa::showMacros [-parent <giDialog | giWindow | int>]
```

Returns

<giDialog>

The dialog box object.

Arguments

`-parent <giDialog | giWindow | int>`

The parent window or dialog box.

sa::showMigrateResults

Description

Migrates the single testbench simulations from the old directory structure to a new model.

Syntax

```
sa::showMigrateResults (-parent <giWindow | int> | -testbench  
    <saTestbench>) [-modal <bool>]
```

Returns

<none>

Arguments

`-parent`

PrimeWave Design Environment main console window.

`-testbench`

The testbench in which to migrate the old simulations.

`-modal`

Make dialog modal. (Default is: 0)

sa::showMixedSignalOptions

Description

Opens the dialog for setting up mixed-signal options.

Syntax

```
sa::showMixedSignalOptions [-parent <giWindow | int>]
```

Returns

<giDialog>: Dialog object.

Arguments

-parent

The PrimeWave Design Environment main window.

sa::showModelFiles

Description

This command displays the **Model Files** dialog box.

Syntax

```
sa::showModelFiles (-parent <giWindow | int> | -session <saSession> |  
-testbench <saTestbench>)
```

Returns

N/A.

Arguments

-parent *giWindow* | <int>

The PrimeWave Design Environment window object or id.

-session

The PrimeWave Design Environment session.

-testbench

The testbench object.

Errors

No testbench is defined in this session.

sa::showModelGroupDef

Description

Displays the model group dialog box.

Syntax

```
sa::showModelGroupDef [-parent <giWindow | int>] [-def <saModelGroupDef>]  
[-defName <string>]
```


Returns

<none>

Arguments

-parent

The parent window.

-def

Model group definition.

-defName

Name for the new definition.

sa::showMonteCarlo

Description

This command displays Monte Carlo analysis dialog box.

Syntax

```
sa::showMonteCarlo (-parent <giWindow | int> | -testbench <saTestbench>)
```

Returns

Dialog object (giDialog).

Arguments

-window

PrimeWave Design Environment main console window.

-parent *giWindow* | <int>

The PrimeWave Design Environment main console window.

-testbench

The testbench object.

Errors

No testbench is defined in this session.

sa::showMOSRAResults

Description

Show MOSRA results.

Syntax

```
sa::showMOSRAResults -parent <giWindow | int>
```

Returns

<none>

Arguments

-parent

PrimeWave Design Environment main console window.

sa::showMOSRASetup

Description

Show MOSRA setup.

Syntax

```
sa::showMOSRASetup -parent <giWindow | int>
```

Returns

<none>

Arguments

-parent

PrimeWave Design Environment main console window.

sa::showMSIPAceScripts

Opens the MSIP ACE Scripts Dialog

Syntax

```
sa::showMSIPAceScripts -parent <giWindow | int>
```

Returns

<giDialog> : Dialog object

Arguments

`-parent`

PW main console window

sa::showNoiseSummary

Description

This command opens the PrimeWave Design Environment noise summary dialog box.

Syntax

```
sa::showNoiseSummary -parent <giWindow | int> [-showSimSweeps <bool>]
```

Returns

Dialog object (giDialog).

Arguments

`-window`

PrimeWave Design Environment main window.

`-parent` *giWindow* | <int>

The PrimeWave Design Environment main window.

`-showSimSweeps`

Include simulator swept parameters. The default is true.

sa::showOpenTestSuite

Description

Opens the PrimeWave Design Environment open test suite dialog box.

Syntax

```
sa::showOpenTestSuite
```

Returns

<giDialog>: Dialog object.

sa::showOpPoints

Description

Opens a dialog box with OP Points results.

Syntax

```
sa::showOpPoints [-parent <giWindow | int>]
```

Returns

<none>

Arguments

-parent

PrimeWave Design Environment main window.

sa::showOutputSetup

Description

This command displays the **Outputs** setup dialog box.

Syntax

```
sa::showOutputSetup (-parent <giWindow | int> | -testbench <saTestbench>)
```

Returns

The dialog object. (*giDialog*)

Arguments

-parent *giWindow* | <int>

The PrimeWave Design Environment window object or id.

-testbench

The testbench object.

sa::showParametricAnalyses

Description

Displays the **Parametric Analyses** dialog box.

Syntax

```
sa::showParametricAnalyses (-parent <giWindow | int> | -testbench  
    <saTestbench>) [-session <saSession>] [-selectedIndex <int>]
```

Returns

<giDialog> : Dialog object.

Arguments

-parent *giWindow* | <int>

The PrimeWave Design Environment window object or id.

-session

The PrimeWave Design Environment session.

-testbench

The PrimeWave Design Environment testbench.

-selectedIndex <int>

Index of the selected sweep.

Errors

- No testbench is defined in this window.
- The window is not a PrimeWave Design Environment window.

Examples

```
sa::showParametricAnalyses -window 2
```

In this example, `sa::showParametricAnalyses` displays the **Parametric Analyses** dialog box in the PrimeWave Design Environment main window.

sa::showParasiticBackAnnotation

Description

Shows the dialog box for configuring parasitic full back-annotation and also selective backannotation.

Syntax

```
sa::showParasiticBackAnnotation (-parent <giWindow | int> | -testbench  
    <saTestbench>)
```

Returns

<giDialog> : Dialog object.

Arguments

-parent

PrimeWave Design Environment main console window.

-testbench

Testbench.

Errors

- If the simulator for the specified testbench does not support parasitic backannotation.
- If the passed-in window is not a PrimeWave Design Environment window.
- If neither the window nor the testbench is specified.

sa::showPlotScalars

Description

Shows the **Plot Scalars** dialog box.

Syntax

```
sa::showPlotScalars [-parent <giWindow | int>] -testbench <saTestbench>
```

Returns

<giDialog> : Dialog object

Arguments

-parent

The parent window.

-testbench

Testbench.

sa::showPromoteDatabase

Description

Opens the tool's **Promote Results Database** dialog box.

Syntax

```
sa::showPromoteDatabase (-parent <giWindow | int> | -testbench  
    <saTestbench>)
```

Returns

<giDialog>

The dialog box object.

Arguments

-parent <giWindow | int>

The PrimeWave Design Environment main window.

-testbench <saTestbench>

The testbench.

sa::showPostRunProcs

Description

Shows the **Post Run Procs** dialog box.

Syntax

```
sa::showPostRunProcs -parent <giWindow | int>
```

Returns

<giDialog> :

Arguments

-parent

PrimeWave Design Environment main window.

sa::showPreRunProcs

Description

Shows the **Pre Run Procs** dialog box.

Syntax

```
sa::showPreRunProcs -parent <giWindow | int>
```

Returns

<giDialog> :

Arguments

-parent

PrimeWave Design Environment main window

sa::showPromptParameters

Description

This command opens a dialog box to prompt the user for the parameters.

Syntax

```
sa::showPromptParameters <name: string> -parent <giWindow | int>  
[-topicId <string>] -resultType <string> [-extraAttribute <string>]  
-execProc <string> [-cancelProc <string>] [-singleRun <bool>] [-title  
<string>] [-showMonteCarlo <bool>]
```

Returns

The dialog object. (*giDialog*)

Arguments

<string>

The prefix name for the dialog box.

-parent *giWindow* | <int>

The PrimeWave Design Environment main window.

-topicId

The topicId for the dialog box.

-resultType <string>

Result type.

-extraAttribute <string>

The additional attribute in saResultFile object to prompt.

-execProc <string>

The procedure to be called on **OK/Apply** button click. Called with the four arguments (the dialog, the result directories, the parameters, and the result file names).

`-cancelProc <string>`

The optional procedure to be called on **Cancel** button click. Called with the prefix name of the dialog box.

`-singleRun <bool>`

Parameters for single or multiple iterative runs.

Default: false.

`-title <string>`

The dialog box title.

`-showMonteCarlo`

Specifies whether the Monte Carlo parameter should be shown.

Default: true.

`-showSimSweeps`

Specifies whether parameters swept by the simulator should be shown. Default: false.

sa::showResultOptions

Description

This command displays the PrimeWave Design Environment **Result Options** dialog box.

Syntax

```
sa::showResultOptions (-parent <giWindow | int> | -testbench  
  <saTestbench>) [-outputPlot <bool>]
```

Returns

The dialog object. (*giDialog*)

Arguments

`-parent giWindow | <int>`

The PrimeWave Design Environment window object or id.

`-testbench`

The testbench object.

`-outputPlot`

Active the Output Plot tab or not.

sa::showResultsUpdater

Description

Opens the dialog for showing an import dashboard for a testbench.

Syntax

```
sa::showResultsUpdater -testbench <saTestbench>
```

Returns

<none>

Arguments

-testbench

PrimeWave Design Environment Timestamp Dashboard dialog box.

sa::showResultsView

Description

This command displays Results Viewer.

Syntax

```
sa::showResultsView (-parent <giWindow | int> | -resultsDatabase  
<string>) [-checkPoint <string>] [-title <string>] [-invokeFrom  
<string>] [-selectionCallback <string>] [-testbenchName <string>]  
[-autoReevaluate <string>]
```

Returns

<giWindow>: Results View.

Arguments

-parent

Parent id.

-resultsDatabase

Results database.

-checkPoint

Checkpoint name.

-title

Window title.

`-invokeFrom`

Source of the command invocation. (Default is:)

`-selectionCallback`

Callback for row selection.

`-testbenchName`

Testbench name.

`-autoReevaluate`

Auto reevaluate (Default is:)

sa::showSaveDesVars

Description

Opens the dialog for saving design variables.

Syntax

```
sa::showSaveDesVars -parent <giWindow | int>
```

Arguments

`-parent`

Parent SAE console window.

sa::showSaveMacros

Description

Opens the dialog box for saving macros.

Syntax

```
sa::showSaveMacros [-parent <giDialog | giWindow | int>]
```

Returns

`<giDialog>`

The dialog box object.

Arguments

`-parent <giDialog | giWindow | int>`

The parent window or dialog box.

sa::showSaveOptions

Description

This command displays the **Save Options** dialog box.

Syntax

```
sa::showSaveOptions (-parent <giWindow | int> | -testbench <saTestbench>)
```

Returns

The dialog object. (*giDialog*)

Arguments

`-parent` *giWindow* | `<int>`

The PrimeWave Design Environment main console window.

`-testbench`

The testbench object.

Errors

No testbench is defined in this session.

sa::showSaveOutputs

Description

Opens the dialog for saving outputs.

Syntax

```
sa::showSaveOutputs -parent <giWindow | int>
```

Arguments

`-parent` `<giWindow | int>`

The parent PrimeWave Design Environment window.

sa::showSaveResults

Description

This command displays the PrimeWave Design Environment **Save Results** dialog box.

Syntax

```
sa::showSaveResults (-parent <giWindow | int> | -testbench <saTestbench>)
```

Returns

The dialog object. (*giDialog*)

Arguments

`-parent` *giWindow* | `<int>`

The PrimeWave Design Environment window.

`-testbench`

The testbench object.

Errors

No testbench is defined in this session.

sa::showSaveScript

Description

This command displays the dialog box for saving a `saSession` to a Tcl script.

Syntax

```
sa::showSaveScript -parent <giWindow | int>
```

Returns

The dialog object. (*giDialog*)

Arguments

`-parent` *giWindow* | `<int>`

The PrimeWave Design Environment main console window.

sa::showSaveState

Description

This command displays the **Save State** dialog box.

Syntax

```
sa::showSaveState -parent <giWindow | int>
```

Returns

The dialog object. (*giDialog*)

Arguments

`-parent giWindow | <int>`

The PrimeWave Design Environment main window.

sa::showSaveTestSuiteAs

Description

Opens the PrimeWave Design Environment **Save Test Suite** dialog box.

Syntax

```
sa::showSaveTestSuiteAs -parent <giWindow | int> [-modal <bool>]
```

Returns

<giDialog>: Dialog object.

Arguments

`-parent`

The PrimeWave Design Environment main window.

`-modal`

Make dialog modal.

Default is: 0.

sa::showSaveTestSuiteResults

Description

Opens the PrimeWave Design Environment **Save Test Suite Results** dialog box.

Syntax

```
sa::showSaveTestSuiteAs -parent <giWindow | int> [-modal <bool>]
```

Returns

<giDialog>: Dialog object.

Arguments

`-parent`

PrimeWave Design Environment main console window.

`-modal`

Make dialog modal.

Default is: 0.

sa::showSelectDesign

Description

This command displays the **Select Design** dialog box.

Syntax

```
sa::showSelectDesign (-parent <giWindow | int> | -testbench  
    <saTestbench>)
```

Arguments

`-parent` *giWindow* | *<int>*

The PrimeWave Design Environment window object or id.

`-testbench`

The testbench object, window, or testbench must be provided.

sa::showSelectSimulator

Description

This command displays the **Select Simulator** dialog box.

Syntax

```
sa::showSelectSimulator (-parent <giWindow | int> | -testbench  
    <saTestbench>)
```

Returns

The select simulator dialog (*giDialog*).

Arguments

`-parent`

PrimeWave Design Environment main window.

`-testbench`

The testbench.

Errors

No testbench is defined in this session.

sa::showSessionOptions

Description

This command displays the **Session Options** dialog box.

Syntax

```
sa::showSessionOptions (-parent <giWindow | int> | -testbench  
    <saTestbench>)
```

Returns

The session options dialog (*giDialog*).

Arguments

`-parent` *giWindow* | `<int>`

The PrimeWave Design Environment main window.

`-testbench`

The testbench object.

sa::showSequentialRun

Description

Shows the **Sequential Run** dialog box.

Syntax

```
sa::showSequentialRun -parent <giWindow | int>
```

Returns

`<giDialog>` :

Arguments

`-parent`

PrimeWave Design Environment main window.

sa::showSpfResults

Shows the SPF annotation result dialog

Syntax

```
sa::showSpfResults (-parent <giWindow | int> | -session <saSession> |  
-testbench <saTestbench>)
```

Returns

<none>

Arguments

-parent

SAE Window

-session

SAE Session

-testbench

SAE Testbench

sa::showStimulusGenerator

Description

This command displays the **Stimulus Generator** dialog box in the given PrimeWave Design Environment main window or saTestbench object.

Syntax

```
sa::showStimulusGenerator (-parent <giWindow | int> | -testbench  
<saTestbench>)
```

Returns

The dialog object (*giDialog*).

Arguments

-parent *giWindow* | <int>

The PrimeWave Design Environment main window.

-testbench

The testbench object.

sa::showStimulusGroupDef

Shows the stimulus group dialog

Syntax

```
sa::showStimulusGroupDef [-parent <giWindow | int>] [-dialog <giDialog>]  
  [-def <saStimulusGroupDef>] [-defName <string>] [-stimulusSets  
  <saStimulusSets>]
```

Returns

<none>

Arguments

-parent

Parent window

-dialog

Dialog in which stimulus groups are defined

-def

Stimulus group definition

-defName

Name for the new definition

-stimulusSets

Stimulus sets definition

sa::showTerminal

Description

This command opens an xterm with the CWD set to the results directory of given testbench.

Syntax

```
sa::showTerminal (-directory <string> | -parent <giWindow | int>)
```

Returns

<none>

Arguments

`-directory`

Directory where the terminal will be opened.

`-parent`

PrimeWave Design Environment main window.

Errors

- No testbench is defined in this window.
- The window is not a PrimeWave Design Environment window.
- Results directory for the testbench is not a valid directory.

sa::showTestList

Opens the dialog box for showing the scripts in the specific directory.

Syntax

```
sa::showTestList [-update <bool>]
```

Returns

<none>

Arguments

`-update`

update the test list or not.

sa::showTestSuiteOptions

Description

Opens the PrimeWave Design Environment **Test Suite Options** dialog box.

Syntax

```
sa::showTestSuiteOptions -parent <giWindow | int>
```

Returns

<giDialog>: Dialog object.

Arguments

`-parent`

PrimeWave Design Environment main window.

sa::showTimestampDashboard

Description

Opens the dialog box for showing an import dashboard for a testbench.

Syntax

```
sa::showTimestampDashboard -testbench <saTestbench>
```

Returns

<none>

Arguments

`-testbench`

PrimeWave Design Environment Timestamp Dashboard dialog

sa::showWaveformViewer

Description

This command opens the waveform viewer.

Syntax

```
sa::showWaveformViewer -parent <giWindow | int>
```

Arguments

`-parent` *giWindow* | <int>

The PrimeWave Design Environment main window.

Errors

- Waveform viewer could not be opened.
- The window is not a PrimeWave Design Environment window.

sa::showWorstCaseAnalysis

Description

Shows the sweeps setup for parametric analyses.

Syntax

```
sa::showWorstCasesAnalyses (-parent <giWindow | int> | -testbench  
    <saTestbench>) [-session <saSession>]
```

Returns

<giDialog> : Dialog object

Arguments

-parent

PrimeWave Design Environment main window.

-session

Session.

-testbench

Testbench.

sa::simulationDone

Description

Procedure to be executed after a simulation job finishes.

Syntax

```
sa::simulationDone <job: xtJob>
```

Arguments

job

Simulation job.

sa::sortResultsViewTree

Description

Sorts the Results View tree.

Syntax

```
sa::sortResultsViewTree -window <giWindow | int> -order <enum>
```

Returns

<none>

Arguments

-window

The Results Viewer window.

-order

Sorting order. (ascending, descending, or default) ({ ascending | default | descending }).

sa::stop

Description

This command will attempt to stop a running simulation by sending a kill signal to the simulation job in the Job Monitor.

Syntax

```
sa::stop (-window <giWindow | int> | -testbench <dbCollection |  
saTestbench>) [-force <bool>]
```

Returns

Status of the simulation interrupt (<bool>).

Arguments

-window *giWindow* | <int>

The PrimeWave Design Environment window object or id.

-testbench

Testbench or a collection of testbenches.

-force

Force status reset if no simulations are found running.

Default: 0.

Errors

- No testbench is defined in this window.
- The window is not a PrimeWave Design Environment window.
- Job could not be stopped.

Examples

The following example shows the usage of `sa::run` and `sa::stop`.

```
# Get testbench object from active window
set tb [sa::findActiveTestbench -window 3]
sa::run -testbench $tb
sa::stop -testbench $tb
```

sa::syncRemoteResults

Description

Syncs the remote simulation results to a local site.

Syntax

```
sa::syncRemoteResults (-window <giWindow | int> | -testbench  
  <saTestbench>) [-subDirs [<string>]]
```

Returns

<none>

Arguments

`-window <giWindow | int>`

The PrimeWave Design Environment main window.

`-testbench <saTestbench>`

The testbench.

`-subDirs [<string>]`

The list of subdirectories to include in synchronization.

sa::updateCDPLClass

Returns the run mode and history name of the session

Syntax

```
sa::updateCDPLClass -of <saSession> -type <string>
```

Returns

<none>

Arguments

-of

Session

-type

Job class type

sa::updateCDPLMaster

Description

Returns the run mode and history name of the session

Syntax

```
sa::updateCDPLMaster
```

sa::updateResultsViewTitle

Update the title of the ResultsView when the sessionName changed.

Syntax

```
sa::updateResultsViewTitle <index: int> -sessionName <string>
```

Returns

<bool> : If the mapped RV is found and modified successfully

Arguments

index

The window id of the session

-sessionName

The new name to be set for ResultsView

sa::updateMeasurementSummaries

Description

Creates the measurement summary collection.

Syntax

```
sa::updateMeasurementSummaries [-testbench <saTestbench | string>]
```

Returns

<none>

Arguments

-testbench

Testbench or name pattern for creating measurement summary.

Examples

The following command can be used to create a measurement summary.

```
set summaries [sa::updateMeasurementSummaries -testbench $tb]
db::foreach m $summaries {
    puts [db::getAttr mean -of $m]
}
```

sa::updateProgressBar

Update WV Calculation Progress Information into RV Progress Bar

Syntax

```
sa::updateProgressBar [<pattern: string>] (-window <giWindow | int> |
    -session <saSession> | -testbench <saTestbench>) [-filter <string>]
    [-option <string>] [-calculatedJobs <string>] [-totalJobs <string>]
    [-messageOnly <bool>] [-resultViewOnly <bool>] [-getFinishJobs <bool>]
    [-issimserver <bool>]
```

Returns

<string> : Done Jobs

Arguments

pattern

Pattern to match object name.

-filter

Standard attribute filter.

-window

PrimeWave Window

```
-session
    PrimeWave Session

-testbench
    PrimeWave Testbench

-option
    Caculated option (Default is: 0)

-calculatedJobs
    Caculated jobs (Default is: 0)

-totalJobs
    Total jobs (Default is: 0)

-messageOnly
    Message Only (Default is: false)

-resultViewOnly
    Result View only (Default is: false)

-getFinishJobs
    Get Finish Jobs (Default is: false)

-issimserver
    is simserver (Default is: false)
```

sa::updateSelectionObj

Description

Updates a Results Analyzer-based selection object with its derived signals.

Syntax

```
sa::updateSelectionObj [-in <saSelectionObject>] -objectName <string>
    -objectType <enum> [-context <deContext>] [-outOfContext <bool>]
    [-instTerm <string>] [-filter <bool>]
```

Returns

<bool> : Returns status of object passing filter.

Arguments

`-in`

Selection object to assign `ide::pick` proc objects.

`-objectName`

Selected object name returned by `ide::pick`.

`-objectType`

Selected object type. ({ instTerm | instance | net | object | terminal })

`-context`

Design Context of selected object returned by `ide::pick`.

`-outOfContext`

Indicates that this selection object is out-of-context.

`-instTerm`

The name of an instance terminal (/localInstName/terminalName) associated with a selected out-of-context net.

`-filter`

Indicates that this assignment is for pre-filtering purposes.

isa::computeInterfaceElements

Description

Computes the interface elements interactively.

Syntax

```
isa::computeInterfaceElements (-window <giWindow | int> | -testbench  
    <dbCollection | saTestbench>)
```

Returns

<bool> : Status of the simulation run

Arguments

`-window`

PrimeWave Design Environment main console window.

`-testbench`

Testbench or a collection of testbenches.

isa::createNetlist

Create simulation input file

Syntax

```
isa::createNetlist (-window <giWindow | int> | -testbench <dbCollection |  
saTestbench>) [-createStructural <bool>] [-allFinal <bool>]
```

Returns

<bool> : Status of the netlister run

Arguments

-window

PrimeWave main console window

-testbench

Testbench or a collection of testbenches

-createStructural

If set to True, a new structural netlist will be created along with any associated checks. (Default is: 1)

-allFinal

If set to True, final netlists for all data points will be created too. (Default is: 0)

isa::deleteResults

Description

Cleans out testbench results directory.

Syntax

```
isa::deleteResults (-window <giWindow | int> | -testbench <saTestbench>)
```

Returns

<none>

Arguments

-window

The PrimeWave Design Environment main console window.

```
-testbench
```

Testbench.

Examples

The following example deletes simulation results for the active testbench.

```
set testbench [ss::getActiveTestbench]
isa::deleteResults -testbench $testbench
```

isa::netlistAndRun

Description

Netlist and run the simulation interactively.

Syntax

```
isa::netlistAndRun (-window <giWindow | int> | -testbench <dbCollection |
saTestbench>)
```

Returns

<bool>: Status of the simulation run.

Arguments

`-window` *giWindow* | <int>

The PrimeWave Design Environment main console window.

`-testbench`

The testbench or a collection of testbenches.

isa::run

Description

Interactive version of `sa::run`. This command runs a simulation with an existing structural netlist. It prompts the user if structural netlist does not exist.

Syntax

```
isa::run -window <giWindow> | <int> -testbench <saTestbench>
```

Returns

Simulation status. (<bool>)

Arguments

`-window giWindow | <int>`

The PrimeWave Design Environment window object or id.

`-testbench`

The testbench object.

Examples

The following example gets the testbench object from the active window, then runs the testbench in that window.

```
set tb [sa::findActiveTestbench -window 3]
isa::run -testbench $tb
# OR
isa::run -window 3
```

isa::stop

Description

Stops the running simulation interactively.

Syntax

```
isa::stop (-window <giWindow | int> | -testbench <dbCollection |
saTestbench>)
```

Returns

<bool>: Status of the simulation interrupt.

Arguments

`-window giWindow | <int>`

The PrimeWave Design Environment main console window.

`-testbench`

The testbench or a collection of testbenches.

Examples

The following example gets the testbench object from the active window, then stops running the testbench in that window.

```
set tb [sa::findActiveTestbench -window 3]
isa::stop -testbench $tb
# OR
isa::stop -window 3
```

Enumerations

Table 1 Enumerations

Name	Values	Description
enEnableMode	no on off	Specifies whether an option requires an enable Boolean for activating the option.
enGraphType	rectangular polar zsmith ysmith	Waveform graph type.
enLinearSweepType	points step_size	Type of linear sweep.
enLogSweepType		
enOptionType	bool integer float string file directory	Option type.
enOutputType	net terminal expression	Output type.
enSelectionObjectType	object net terminal instance instTerm	Types of objects that can be picked from the schematic.
enSignalObjectType	current derived instance power voltage	Types of signals finally obtained during signals selection.
enSweepRangeStepType	linear logarithmic	Step type for sweep range.
enSweepRangeType	startStop centerSpan points	Type for sweep range.

Objects

This section covers the following:

- [saAnalysisDef](#)
- [saConvergenceAid](#)
- [saCorner](#)
- [saCornerParamDef](#)
- [saCornersSetup](#)
- [saDesignVariable](#)
- [saExpressionDef](#)
- [saIncludeFile](#)

- [saModelFile](#)
- [saOption](#)
- [saOptionDef](#)
- [saOptionGroup](#)
- [saOutput](#)
- [saOutputs](#)
- [saPair](#)
- [saPair](#)
- [saResultFile](#)
- [saResults](#)
- [saResultsMap](#)
- [saSelection](#)
- [saSelectionDef](#)
- [saSelectionDefGroup](#)
- [saSession](#)
- [saSimulator](#)
- [saSweep](#)
- [saSweepRange](#)
- [saTestbench](#)
- [wfSignal](#)

saAnalysisDef

The saAnalysisDef object is created for each analysis type supported by the simulator.

Table 2 *Attributes*

Name	Type	Access	Description
name	string	Read-only	Name of the integrator-defined analysis type like tran, dc, and so forth.

Table 2 *Attributes (Continued)*

Name	Type	Access	Description
simulator	string	Read-only	Name of the simulator.
title	string	Read-only	Title for the analysis like "Transient Analysis" for the analysis type "tran".
options	<i>saOptionDef</i>	Read/Write	Collection of saOptionDef.
expressionDefinitions	<i>saExpressionDef</i>	Read/Write	Collection of saExpressionDef.

saConvergenceAid

This object is a collection of convergence aids, initial conditions, node sets and force nodes. Each of these is a collection of name value pairs.

Table 3 *Attributes*

Name	Type	Access	Description
enabled	bool	Read/Write	Enabled status.
nodeType	string	Read/Write	Node type (node set, initial condition or force node).
node	string	Read/Write	Name of the circuit node.
voltage	string	Read/Write	Voltage to be applied.

saCorner

The saCorner object represents a column in the corners setup table. The attributes of the object are described in the table below and can be retrieved or set by `db::getAttribute` and `db:setAttribute` commands.

Table 4 *Attributes*

Name	Type	Access	Description
name	string	Read/Write	The corner name.

Table 4 Attributes (Continued)

Name	Type	Access	Description
parameters	<code>{saPair}</code>	Read/Write	The collection of saPair. Each saPair represents a design variable or model file or temperature and its value for the corner.
enabled	bool	Read/Write	The enable and disable status of the corner.

saCornerParamDef

This object represents a corner parameter to be used in the corners analysis. Each object represents a row header in the corners setup table. The attributes of the object are described in the table below and can be retrieved or set by `db::getAttribute` and `db:setAttribute` commands.

Table 5 Attributes

Name	Type	Access	Description
name	string	Read-only	The corner parameter name.
parameterType	<code>enCornerParameterType</code>	Read-only	The type of the corner parameter.
path	string	Read/Write	The path to the model file if the parameterType is model file.
startValue	string	Read/Write	seed value.
enabled	bool	Read/Write	Whether or not the parameter is enabled.

saCornersSetup

The saCornersSetup object represents the setup data of the corners analysis tool. The attributes of the object are described in the table below and can be retrieved or set by `db::getAttribute` and `db:setAttribute` commands.

Table 6 *Attributes*

Name	Type	Access	Description
paramDefs	{saCornerParamDef}	Read/Write	The collection of corner parameter definitions.
corners	{saCorner}	Read/Write	The collection of corner objects.
enabled	bool	Read/Write	The enable and disable status of the corner analysis tool. Modifying the value of this attribute does not change the enable/disable status of the individual corners.

saDesignVariable

This object represents design variable defined in a testbench.

Table 7 *Attributes*

Name	Type	Access	Description
name	string	Read/Write	Design Variable Name.
value	string	Read/Write	Design variable value.

saExpressionDef

The definition of an entry into the Plotting Assistant's expression list. This object contains the plans for how to generate a family of expressions for one particular simulator/analysis/ expression.

Table 8 *Attributes*

Name	Type	Access	Description
name	string	Read-only	Name (usually of a function) that identifies the set of expressions that can be generated. Uniquely identifies a PAFFunction.

Table 8 *Attributes (Continued)*

Name	Type	Access	Description
description	string	Read/Write	Description of the expression(s) that are defined by this expression builder.
selectionDefGroups	{saSelectionDefGroup}	Read/Write	Collection of valid selection methods for this saExpressionDef.
setupProc	string	Read/Write	Name of Tcl function to create any additional fields/widgets in the GUI. Also can do preprocessing of results if required.
graphTypes	[string]	Read/Write	List of graph types which can be requested for the plot.
modifiers	[string]	Read/Write	List of one-option operator names that can be used to modify the generated expression. If a modifier is chosen, the contents of the rest of the expression will be wrapped in a call to that operator.
updateCustomFieldsProc	string	Read/Write	Name of optional Tcl function for updating widgets in the Plot Assistant after results files have changed.
checkCustomFieldsProc	string	Read/Write	Name of optional Tcl function for determining if selection can now start. Must be provided only if the expressionDef has custom fields.
createExpressionProc	string	Read/Write	Name of Tcl function to generate and return the expression.

saIncludeFile

This object represents an include file. The attributes are include file path, include file type and the enabled status of the include file.

Table 9 Attributes

Name	Type	Access	Description
file	string	Read/Write	Include file path.
type	string	Read/Write	Include file type.
enabled	bool	Read/Write	Enabled status of the include file.

saModelFile

saModelFile represent a model file that user has specified. The filename field is an absolute or relative path to the model file to be included. section field specifies a section or library within the model file, may be empty.

Table 10 Attributes

Name	Type	Access	Description
filename	string	Read/Write	Path to model file.
section	string	Read/Write	Model file section.
enabled	bool	Read/Write	Enabled status of the model file.

saOption

This object will describe a specific option on a testbench.

Table 11 Attributes

Name	Type	Access	Description
name	string	Read-only	The name of the option.
simulator	string	Read-only	The name of the simulator. Used to retrieve the option definition.

Table 11 Attributes (Continued)

Name	Type	Access	Description
value	string	Read/Write	The get method for this attribute calls a method that resolves the current value of the option. The set method for this attribute both saves a value and sets the localized flag to true.
localized	bool	Read/Write	Indicates whether the value in this object is the effective value. If false, then the value will be searched for upward.
simDefault	string	Read-only	The get method for this attribute calls a method that resolves (including conditional defaults) the current simulator default value.
state	<i>enOptionConditionState</i>	Read-only	The get method for this attribute calls a method that resolves the <i>enOptionConditionState</i> from the conditional defaults.
enabled	bool	Read/Write	If applicable, specifies if the option is enabled.

saOptionDef

This object will describe a specific option definition.

Table 12 Attributes

Name	Type	Access	Description
name	string	Read-only	User-visible name used to identify this option.
simulator	string	Read-only	The name of the simulator.
optionType	<i>enOptionType</i>	Read-only	Option type.
defaultValue	bool int float string	Read-only	Default value.

Table 12 Attributes (Continued)

Name	Type	Access	Description
conditionalDefaults	<i>saOptionConditionalDefaults</i>	Read-only	Specifies the conditions from which to extract a derived simulator default value.
prompt	string	Read-only	Optional string which is presented to the user instead of the name.
description	string	Read-only	Optional long description of the option.
limit	<i>saOptionLimit</i>	Read-only	Limits on the valid values for this option.
mustEnable	<i>enEnableMode</i>	Read-only	Indicates the option must be enabled in order to have a value.
supportsExpressions	bool	Read-only	Indicates whether an expression can be given in lieu of an explicit value.

saOptionGroup

This object will describe a collection of options and groups.

Table 13 Attributes

Name	Type	Access	Description
name	string	Read-only	The name of the grouping.
description	string	Read/Write	A description of the group.
expanded	bool	Read/Write	Indicates whether the group is to initially appear expanded on the GUI.
children	<i>saOptionName</i> <i>saOptionGroup</i>	Read/Write	A collection with option names and/or option groups.

saOutput

This Object represents an entry in the outputs table in main PrimeWave Design Environment window.

Table 14 Attributes

Name	Type	Access	Description
name	string	Read/Write	Name given to the output.
expr	string	Read/Write	Expression. When the output is a signal, expression would be the net or terminal name.
analyses	{string}	Read/Write	The analyses for which this output is evaluated/plotted.
plot	bool	Read/Write	Specifies whether the output should be plotted when simulation is complete.
save	bool	Read/Write	Specifies whether the output should be saved by the simulator. This will work with the simulation save options to create <code>.probe</code> (or simulator-equivalent) commands.
value	string <i>wfSignal</i>	Read-only	Value of the expression.
outputType	<i>enOutputType</i>	Read/Write	Output type (net, terminal or expression).
probe	string	Read/Write	Display packet name to be used in cross-probing.

saOutputs

This object represents the outputs and measurement setup defined for the testbench. It has two attributes. `outputSet` is the name of current `outputSet`. `outputSets` is a collection of `saOutputSet` objects.

Table 15 Attributes

Name	Type	Access	Description
outputSet	string	Read/Write	Name of current output set.

Table 15 *Attributes (Continued)*

Name	Type	Access	Description
outputSets	{saOutputSet}	Read/Write	Collection of output sets.

saPair

The saPair object contains either corner parameter name or measurement name and its value used in the corner analysis. The attributes of the object are described in the table below and can be retrieved or set by db::getAttribute and db:setAttribute commands.

Table 16 *Attributes*

Name	Type	Access	Description
name	string	Read-only	The name of the design variable, model file or measurement.
value	string	Read/Write	The value for the above.

saPair

This is a generic name value pair object. A future enhancement to this object would be to add an attribute that controls if the name and value attributes are read/write or read-only. This is needed for corners setup objects.

Table 17 *Attributes*

Name	Type	Access	Description
name	string	Read/Write	Name.
value	string	Read/Write	Value.

saResultFile

The saResultFile is created for each simulation output file.

Table 18 Attributes

Name	Type	Access	Description
filename	string	Read-only	Simulation output file name.
resultType	string	Read-only	Result type like tran, opBegin, opTran, and so forth.
analysisName	string	Read-only	Analysis name like tranA, tranB, and so forth.
format	string	Read-only	Output file format like psf, wdf, and so forth.

saResults

The saResults is created at the end of a (successful or failed) simulation run. Note: The parametric, corners, and statistical analysis tools can run multiple simulations. In that case, there will be multiple saResults objects.

Table 19 Attributes

Name	Type	Access	Description
name	string	Read-only	results.xml
version	string	Read-only	Version number.
simulator	string	Read-only	Simulator name.
netlistDir	string	Read-only	The netlist directory.
resultsDir	string	Read-only	The simulation result directory where the simulation output files are created.
runTime	string	Read-only	The simulation completion date.
resultFiles	{saResultFile}	Read-only	The collection of saResultFile objects.

saResultsMap

The saResultsMap is created for each testbench at the end of the successful simulation run.

Table 20 *Attributes*

Name	Type	Access	Description
name	string	Read-only	resultsMap.xml
resultsInfo	<i>{saResultsInfo}</i>	Read-only	Collection of saResultsInfo objects.
timestamp	string	Read-only	Creation time of resultsMap.xml.
resultsMapDir	string	Read-only	The directory where resultsMap.xml is created.

saSelection

This object represents an actual user selection during `ide::pick`, which can be used by a `saExpressionDef`'s Tcl procs.

Table 21 *Attributes*

Name	Type	Access	Description
name	string	Read-only	Name identifying selection object.
objectName	string	Read/Write	Name of the OA object selected (during <code>ide::pick</code>).
objectType	<i>enSelectionObjectType</i>	Read-only	Type of object selected (during <code>ide::pick</code>).
context	<i>deContext</i>	Read/Write	Design context.
selectionDefinition	<i>saSelectionDef</i>	Read-only	<code>saSelectionDef</code> defining the type of selection this represents.
extractedSignals	<i>{saExtractedSignal}</i>	Read-only	Signals derived from object based on methodology given by the selectionDefinition.

saSelectionDef

Encompasses the information needed to make one signal selection. A signal selection is the process by which a user will select something on the design and it will get translated into a signal or signals.

Table 22 Attributes

Name	Type	Access	Description
name	string	Read-only	Name of selection def object. Must be unique in a saSelectionDefGroup.
label	string	Read/Write	Description of the signal being selected.
prompt	string	Read/Write	Description of object to prompt selection of in design window.
objectTypes	[enSelectionObjectType]	Read/Write	List of object types allowed to pick on the schematic.
extractedSignal Type	enSelectionDefSignalType	Read/Write	Type of extracted signal that will be created from a picked object.
filterProc	string	Read/Write	Name of Tcl proc to be used to filter objects during picking from the schematic.

saSelectionDefGroup

Defines a sequence of signal selections required to create an expression.

Table 23 Attributes

Name	Type	Access	Description
name	string	Read-only	Name identifying group of signals. Unique in a saExpressionDef.
label	string	Read/Write	Small description that will be displayed in Plot Assist Selection list.
selectionDefs	{saSelectionDef}	Read-only	The ordered list of saSelectionDef objects which will be requested from the user if this selection Method is chosen.

saSession

saSession object represents one invocation of PrimeWave Design Environment in a session. Session name can be specified by user or is auto generated by appending an integer to saSession. For example "saSession1", "saSession2", and so forth. resultsDir is the root directory of the results directory structure. statesDir is the root directory of the states directory structure.

Table 24 *Attributes*

Name	Type	Access	Description
name	string	Read/Write	Unique string identifier for this session.
resultsDir	string	Read/Write	Results directory for PrimeWave Design Environment session.
statesDir	string	Read/Write	States directory for PrimeWave Design Environment session.
testbenches	{saTestbench}	Read/Write	Testbenches in the ceSession.

saSimulator

The saSimulator object is created for each simulator integrated into the PrimeWave Design Environment.

Table 25 *Attributes*

Name	Type	Access	Description
name	string	Read-only	The name of the simulator.
finalNetlist	string	Read/Write	The name of the final netlist file. The default value is finalNetlist.
structuralNetlist	string	Read/Write	The name of the structural netlist. The default value is netlist.
languages	{string}	Read/Write	Collection netlist formats (languages). The default netlist format is <simulator_name>.

Table 25 Attributes (Continued)

Name	Type	Access	Description
includeTypes	{string}	Read/Write	The external file types supported in the Include Files dialog for the simulator integration.
logFile	string	Read/Write	The name of the simulator log file. The default log file name is <simulator_name>.out.
netlistTemplate	string	Read/Write	Name of the template file containing the overall structure of the final netlist. The include files in the template are specified relative to the netlist directory.
analysisDefs	{saAnalysisDef}	Read/Write	Collection of saAnalysisDef objects.
integrationVersion	int	Read/Write	The field for the integrator to specify the integration version.
optionsDef	{saOptions}	Read/Write	Collection of saOptions.
optionGroup	saOptionGroup	Read/Write	saOptionGroup.

saSweep

An saSweep represents a sweep specification.

Table 26 Attributes

Name	Type	Access	Description
name	string	Read-only	Name of the sweep.
variable	string	Read/Write	The variable or parameter that is being swept.
enabled	bool	Read/Write	Whether current sweep is enabled.
sweepRange	saSweep	Read-only	The sweep range object that the sweep is specified with.

saSweepRange

A saSweepRange represents the range of sweep. The sweep range object has three different types: Start/Stop, Center/Span, or Point of Interest (POI). A Start/Stop range type has the start value and stop value specified. A Center/Span range object will have the center value and span value specified. The POI sweep type has poi value specified. For Start/Stop or Center/Span sweep ranges, either step size or number of points can be specified. The sweep object steps can be either linear or logarithmic. This object can be also destroyed with `db::destroy`.

Table 27 *Attributes*

Name	Type	Access	Description
rangeType	<i>enSweepRangeType</i>	Read/Write	Start/Stop, Center/Span, POI.
start	string	Read/Write	Start value, only valid for Start/Stop type.
stop	string	Read/Write	Stop value, only valid for Start/Stop type.
center	string	Read/Write	Center value, only valid for Center/Span type.
span	string	Read/Write	Span value, only valid for Center/Span type.
poi	string	Read/Write	String containing blank separated point values.
exclusiveList	string	Read/Write	String containing blank separated point values that will be excluded from the run.
stepType	<i>enSweepRangeStepType</i>	Read/Write	The type for this range, either Linear or Logarithmic.
points	string	Read/Write	Number of points for this range.
stepSize	string	Read/Write	For Linear range types, the size of each step within the range.
logType	<i>enLogSweepType</i>	Read/Write	For Logarithmic ranges, the step type, either per decade or per octave.

saTestbench

saTestbench object represents a testbench defined in a saSession. It is owned by the saSession. It contains a reference to the design to be simulated, name of the simulator and the simulation setup to be used.

Table 28 Attributes

Name	Type	Access	Description
name	string	Read/Write	Testbench name.
design	dmCellview	Read/Write	The design to be simulated.
simulator	string	Read/Write	Name of the simulator.
temperature	saTemperature	Read/Write	The global temperature for simulation.
options	{saOption}	Read/Write	Collection of simulation options.
designVariables	{saDesignVariables}	Read/Write	Design variable sets defined for this testbench.
convergenceAids	{saConvergenceAid}	Read/Write	Convergence aids defined for this testbench.
analyses	{saAnalysis}	Read/Write	Collection of analyses added to the testbench.
models	saModelSetup	Read/Write	Collection of model files.
environment Options	saEnvironmentOptions	Read/Write	These are simulator independent options.
outputs	saOutputs	Read/Write	Collection of output sets.
includeFiles	{saIncludeFile}	Read/Write	Include files.
saveOptions	saSaveOptions	Read/Write	Output save options.
cornersSetup	saCornersSetup	Read/Write	Corners Setup.
sweeps	{saSweep}	Read/Write	saSweep object.

wfSignal

A wfSignal represents a signal in a waveform file.

Table 29 *Attributes*

Name	Type	Access	Description
name	string	Read-only	Signal name identifier.
signalType	<i>enWFSigType</i>	Read-only	Signal type.
file	<i>wfDataFile</i>	Read-only	Parent file.
width	int	Read-only	Number of bits for real or logic bus.
alias	string	Read/Write	Signal name alias.
nSweeps	int	Read-only	Number of sweeps.
variableNames	{string}	Read-only	List of variable names.
variableConditions	{string}	Read-only	List of variable conditions, one string for each sweep trace.
unit	string	Read-only	Unit of signal values.
xUnit	string	Read-only	Unit of x-axis of signal.

Preferences

The following section lists PrimeWave Design Environment sa general preferences. Preferences use camelBack notation, where the first character is always a lowercase character.

- [Simulation and Analysis Environment Preferences \(saA2D* through saFineSimPro*\)](#)
- [Simulation and Analysis Environment Preferences \(saGen* through saOutput*\)](#)
- [Simulation and Analysis Environment Preferences \(saParam* through saPrimeSimVCS*\)](#)
- [Simulation and Analysis Environment Preferences \(saPrimeSimXA* through saSpectre*\)](#)
- [Simulation and Analysis Environment Preferences \(saSt* through saXA*\)](#)
- [PrimeWave Design Environment Preference Examples](#)

Simulation and Analysis Environment Preferences (saA2D* through saFineSimPro*)

Table 30 lists PrimeWave Design Environment sa general preferences (saA2D* through saFineSimPro*).

Table 30 Simulation and Analysis Environment Preferences

Name	Type	Scope	Default	Description
saA2DInterfaceElementDefault	string	user	{1.0 2.0 v off net}	Default low threshold, high threshold, units and high impedance flag for a2d elements.
saA2DThresholdDefaultDefault	float	user	1	Threshold used by the "I()" function to convert analog signals to digital, if no threshold parameter is given
saAgingShowOMI	bool	user	false	Enable OMI in the Aging Setup Form
saAlwaysCreateNominalCorner	bool	user	false	When creating a corners setup, always create a nominal corner. Valid values: true, false
saAlwaysCreateVariablesForVarExpressions	bool	user	true	Controls whether to always create a variable for the names found in the VAR() expressions.
saAlwaysGenerateDigitalDebugInfo	bool	user	false	Allow gathering of additional digital debug information Valid values: true, false
saAlwaysIncludeTempAsCornerParameterDef	bool	user	true	When creating a corner, always include temperature as a corner parameter definition Valid values: true, false
saAlwaysRefreshConnectRuleAndModuleForMSV	bool	user	false	When set to <code>true</code> : - When you click OK in the Connect Module dialog box, connect rule and modules will be updated accordingly. - If you did not make any updates to the settings in the Connect Modules dialog box, when doing Netlist and Run, PrimeWave writes out wildcard connect module and connect rule files to the <code>runSimulation</code> file. The tool will use all the connect module and connect rule files in the install directory.
saAlwaysResetModelWhenSwitchingSimulator	bool	saSession	false	Always reset model according to new simulator preference when switching simulator

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saAlwaysWriteProbeCommandsForMSV	bool	user	false	Controls whether to always write <code>.probe</code> commands into the final netlist for mixed-signal verification.
saAnalyzeResultsAddAnalysisName	bool	saTestbench	false	Add <code>analysisName</code> parameter to expressions generated by Plot Assist. Valid values: true, false
saAnalyzeResultsAddResultsDir	bool	saTestbench	false	Add <code>resultsDir</code> parameter to expressions generated by Plot Assist. Valid values: true, false
saAnalyzeResultsAddResultType	bool	saTestbench	false	Add <code>resultType</code> parameter to expressions generated by Plot Assist. Valid values: true, false
saAnalyzeResultsFilterAnalysis	string	saTestbench	Auto	State of RA Analyses with Data checkbox
saAnalyzeResultsGraphType	string	saTestbench	linear	Graph type for waveform tool.
saAnalyzeResultsPlotExpressions	bool	saTestbench	true	Annotate graphs associated with functions in Expressions. Valid values: true, false
saAnalyzeResultsPlotMode	string	saTestbench	replace	Plot mode for waveform tool.
saAnnotateDcNodeVoltages	bool	user	false	Back-annotate DC node voltages. Valid values: true, false
saAnnotateDcOpValues	bool	user	false	Back-annotate DC operating values. Valid values: true, false
saAnnotateMOSCutoffRegion	bool	user	false	Highlight MOS devices in Cutoff region. Valid values: true, false
saAnnotateMOSLinearRegion	bool	user	false	Highlight MOS devices in Linear region. Valid values: true, false
saAnnotateMOSReverseRegion	bool	user	false	Highlight MOS devices in Reverse region. Valid values: true, false
saAnnotateMOSSaturationRegion	bool	user	false	Highlight MOS devices in Saturation region. Valid values: true, false
saAnnotateMOSSubthresholdRegion	bool	user	false	Highlight MOS devices in Subthreshold region. Valid values: true, false
saAnnotateSimNames	bool	user	false	Back-annotate Simulation Names. Valid values: true, false

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saAnnotateTranNodeVoltages	bool	user	false	Back-annotate transient node voltages Valid values: true, false
saAnnotateTranOpValues	bool	user	false	Back-annotate transient operating values Valid values: true, false
saAppendPlotFromDiffSTBStates	bool	user	true	Support append plot mode for signals from different STB states.
saApplyHarmonicOnOutputAndInput	string	user	false	Apply Harmonic on Both Input and Output.
saAutoCheckMTBModified	bool	user	saExportForSourcefile	Whether to automatically check MTB setup change and enable/disable save icon
saAutoConvertTemperature	bool	user	false	Convert temperature value when unit is changed. Valid values: true, false
saAutoDeleteDesignParameterVariables	bool	user	false	If true, the design parameter variables will be auto deleted if they do not exist in the design parameterization setup.
saAutoDisableDuplicatedCorners	bool	user	true	Whether to automatically disable duplicated corners when a corner parameter is disabled.
saAutoMigrateResults	bool	user	true	Auto Migrate STB results in old directory structure. Valid values: true, false
saAutoOpenWaveViewerWhenNoOutput	bool	user	false	Auto Open WaveViewer and load results when there is no output entry
saAutoPlot	bool	user	true	Auto Plot Outputs after simulation. Valid values: true, false
saAutoPlotOnlyIfSingleDataPointRun	bool	user	false	Plot signal only if a single data point was run.
saAutoResultsView	bool	user	true	Auto show Results Viewer after simulation. Valid values: true, false
saAutoSaveLoadWVSession	bool	user	false	Auto Save/Load Waveform Viewer session.
saAutoSimulationCheckViewer	bool	user	false	Automatically displays the Simulation Check Viewer. Valid values: true, false
saBackannotationNoResultValue	string	user	"(n/a)"	Value to show when a device annotation fails evaluation. Blank will hide entire label.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saBackannotationNoWarnings	bool	user	false	Blocks display of warnings when a device annotation fails evaluation. Valid values: true, false
saBackgroundImportNetlist	bool	user	false	Import netlist in background
saBackgroundNetlist	bool	user	true	Netlist In background. Valid values: true, false
saBackgroundSaeShellMode	string	saSession	server	Background pw_shell jobs mode. Valid values: Server, Jobs
saBackupPostProcessLogFile	bool	user	true	If true, PrimeWave will backup old WaveView/ResultsView/CalculateEngine's log file when launch new process.
saBlockOptionsLoadVectorFileCtl	string	saTestbench		Control attribute for command load_vector_file.
saBlockOptionsLoadVectorFileFile	string	saTestbench		File attribute for command load_vector_file.
saBlockOptionsLoadVectorFileFormat	string	saTestbench	VEC	Format attribute for command load_vector_file.
saBlockOptionsPrimesimNoiseOffAll	string	saTestbench	true	all attribute for command primesim_noise_off
saBlockOptionsPrimesimNoiseOffEnable	string	saTestbench	true	enable attribute for command primesim_noise_off
saBlockOptionsPrimesimNoiseOffFlicker	string	saTestbench	false	flicker attribute for command primesim_noise_off
saBlockOptionsPrimesimNoiseOffIgn	string	saTestbench	false	ign attribute for command primesim_noise_off
saBlockOptionsPrimesimNoiseOffNone	string	saTestbench	false	none attribute for command primesim_noise_off
saBlockOptionsPrimesimNoiseOffScope	string	saTestbench	false	scope attribute for command primesim_noise_off
saBlockOptionsPrimesimNoiseOffShot	string	saTestbench	false	shot attribute for command primesim_noise_off
saBlockOptionsPrimesimNoiseOffThermal	string	saTestbench	false	thermal attribute for command primesim_noise_off
saBlockOptionsPrimesimNoiseOnAll	string	saTestbench	true	all attribute for command primesim_noise_on

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saBlockOptionsPrimesimNoiseOn Enable	string	saTestbench	true	enable attribute for command primesim_noise_on
saBlockOptionsPrimesimNoiseOn Flicker	string	saTestbench	false	flicker attribute for command primesim_noise_on
saBlockOptionsPrimesimNoiseOn Ign	string	saTestbench	false	ign attribute for command primesim_noise_on
saBlockOptionsPrimesimNoiseOn None	string	saTestbench	false	none attribute for command primesim_noise_on
saBlockOptionsPrimesimNoiseOn Scope	string	saTestbench	false	scope attribute for command primesim_noise_on
saBlockOptionsPrimesimNoiseOn Shot	string	saTestbench	false	shot attribute for command primesim_noise_on
saBlockOptionsPrimesimNoiseOn Thermal	string	saTestbench	false	thermal attribute for command primesim_noise_on
saBlockOptionsSetMonteCarloOptionsDumpWaveform	string	saTestbench	false	Report attribute for command set_resistor_option.
saBlockOptionsSetMonteCarloOptionsEnable	string	saTestbench	true	Rule attribute for command set_resistor_option.
saBlockOptionsSetMonteCarloOptionsParameterFile	string	saTestbench	false	Match attribute for command set_wildcard_rule.
saBlockOptionsSetMonteCarloOptionsSampleOutput	string	saTestbench	none	sampleOutput attribute for command set_monte_carlo_option.
saBlockOptionsSetMonteCarloOptionsSampleOutputOptions	string	saTestbench	none	Filter out PrimeWave Design Environment testbench categories that are not fully compatible between simulator integrations.
saBlockOptionsSetMonteCarloOptionsSimulateNominal	string	saTestbench	1	Filter out PrimeWave Design Environment testbench categories that are not configured differently from the simulator integration default.
saBlockOptionsSetResistorOption Report	string	saTestbench	0	Report attribute for command set_resistor_option.
saBlockOptionsSetResistorOption Rule	string	saTestbench	1	Rule attribute for command set_resistor_option.
saBlockOptionsSetSimLevelScope	string	saTestbench	Instance	Scope attribute for command set_sim_level
saBlockOptionsSetWildcardRuleMatch	string	saTestbench	all	Match attribute for command set_wildcard_rule.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saBlockOptionsSetWildcardRuleNodeAlias	string	saTestbench	0	nodeAlias attribute for command set_wildcard_rule.
saCheckInMode	string	user	promptOnSave	Control when the Check In Test Suite prompt appears when saving an PrimeWave Design Environment state to OpenAccess under revision control. Valid values: • promptOnSave (displays the prompt) • alwaysOnSave (checks in the cellviews without prompting) • never (neither prompts nor checks in the cellviews)
saCheckOpenDesigns	string	user	all	Perform a hierarchical check for open designs when netlisting
saChecksClusterAlgorithm	string	user	MiniBatchKMeans	Cluster analysis algorithm to use for circuit/device check violations
saChecksClusterAnalysisEnabled	bool	user	false	Enable machine-Learning based cluster analysis of circuit/device check violations Valid values: true, false
saChecksInitialViolationsPerCluster	int	user	10	Specify the number of items per cluster to initially display for circuit/device check violations
saChecksNumClusters	int	user	10	Specify the number of clusters to generate for circuit/device check violations
saCheckViewerAutoLoad	bool	user	true	Enable auto loading of Device/Bias check results dialog Valid values: true, false
saClearMeasurementOnAdd	bool	user	false	Clear measurements after adding the outputs to the outputs table.
saCommonMonteCarloBins	string	saTestbench		Use Sigma Scaling or not
saCommonMonteCarloEnableAll	string	saTestbench	false	Enable all tbs or not
saCommonMonteCarloEnableTB	string	saTestbench	false	
saCommonMonteCarloIntervals	string	saTestbench	1	Intervals
saCommonMonteCarloIterList	string	saTestbench		Number of iterations

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saCommonMonteCarloNumIter	string	saTestbench	10	Number of iterations
saCommonMonteCarloOneSided	string	saTestbench	true	
saCommonMonteCarloOneSidedValue	string	saTestbench	0.5	
saCommonMonteCarloReplicates	string	saTestbench	1	Number of runs
saCommonMonteCarloSampleSize	string	saTestbench	10	Sample size
saCommonMonteCarloSamplingMethod	string	saTestbench	SRS	Sampling methods
saCommonMonteCarloSeed	string	saTestbench	1	Random Seed
saCommonMonteCarloStartIter	string	saTestbench	1	Start Iteration
saCommonMonteCarloUserList	string	saTestbench	false	Variation
saCommonMonteCarloUseRandomSeed	string	saTestbench	true	Use Random Seed or not
saCommonMonteCarloUseSigmaScaling	string	saTestbench	false	Use Sigma Scaling or not
saCommonMonteCarloVariations	string	saTestbench	All	Variation
saCommonRegressionDir	string	user		Location to save the default Regression library.
saCommonResultsDir	string	user		Location to save the shard results.
saComputeSimulationJobs	bool	user	true	Compute and display the simulation jobs information before running the simulation in append mode Valid values: true, false
saConfirmOverwritePlotMode	bool	user	false	Ask for confirmation when overwriting a custom plot mode Valid values: true, false

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saCopyCategoriesExcludePartiallyCompatibleCategories	bool	saSession	false	Filter out PrimeWave Design Environment testbench categories that are not fully compatible between simulator integrations. Valid values: true, false
saCopyCategoriesExcludeUnmodifiedCategories	bool	saSession	true	Filter out PrimeWave Design Environment testbench categories that are not configured differently from the simulator integration default. Valid values: true, false
saCopyDesVarsOnNetlist	saCopyDesVarsWhenEnum	user	never	Copy design variables when generating the structural netlist. Valid values: always, never, onFirstNetlist
saCopyTableEditorSelectiontoClipboard	bool	user	true	Copy table line editor selection content to clipboard
saCornerParameterDelimiter	string	user	@	Default delimiter for the corner parameter appended to corners name
saCornerParameterTypeOrderPattern	string	user	%T%V%P	Corner parameter type order pattern
saCornerPrefix	string	user	corner	The prefix for newly added corners.
saCornerVariableModelCount	bool	saSession	false	Count variables and models in corners
saCreateConsolidatedSummaryView	bool	user	false	Show expanded summary view with all corners. The consolidated view provides a combined view of all measurements for all testbenches in a single table. Each measurement shows: • Min/Max/Mean/StdDev columns • Value of measurement for each Corner/Sweep point • If there are multiple Corners and Sweeps present, then multiple rows for each measurement similar to the folded view are shown You can control the folded variable using the Folded Variable drop-down menu. Sorting and filtering are also supported. Valid values: true, false
saCreateResultsXMLOnSimulationStart	bool	user	false	Controls whether results XML file(s) should be created in all simulation results directories before running the simulations. Valid values: true, false
saCreateTestbenchSimulator	string	saSession	PrimeSim	Simulator of PrimeWave state being loaded in test suite.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saD2AInterfaceElementDefault	string	user	{false 1n 1n 0.1n midPoint 3.0 0 net}	Default power net flag, rise time, fall time, delay, logic-X action, high voltage and low voltage for d2a elements.
saDefaultCornersSetup	string	user		Specifies external files for corner setup. One or more files can be specified using Tcl list syntax. For example: db::setPrefValue saDefaultCornersSetup -value {file#1.xml} {file 2.xml} "./dir_0,12\}/file 3.xml" In the above example, the first file name is file#1.xml, the second is file 2.xml, and the third is ./dir_0,12\}/file 3.xml.
saDefaultIncludeFiles	string	user		Specifies default include files. Use to point to an XML file containing include file setup. For example: db::setPrefValue saDefaultIncludeFiles \ -value defaultIncludeFiles.xml
saDefaultNetlistFormat	saDefault NetlistFor matEnum	user	HSPICE	Default netlist format to be used among multiple simulators. Valid values: HSPICE Spectre Eldo Third-party
saDefaultSharedSetupState	string	saSession		Default shared setup state
saDefaultSpecificationMaginalValue	string	user	0%	Default specification maginal value
saDefaultSpecificationType	string	user	>	Default specification goal type Valid values: >, >=, <, <=, =, range, inclusiveRange, Greater Than, Greater Than Equal, Less Than, Less Than Equal, Range, Inclusive Range, Exact
saDefaultSpecificationValue	string	user		Default specification goal value

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saDefaultStateName	string	saSession	%s_%n (The simulator name is substituted for the %s and the testbench name is substituted for the %n)	Default name of the newly created states. In STB the default testbench name is "default" and for HSPICE simulator, the default state name is "HSPICE_default".
saDefaultVoltage	string	saTestbench	0	Default voltage for Convergence Aids.
saDesignParameterizationShowAllParameters	bool	user	false	If true, show all parameters of instances in design parameterization. If false, the design parameterization device properties match the Schematic Editor properties.
saDesignVariableParamIgnoreList	string	user	model macro macroArgumentStyle	List of parameters to ignore when scanning for design variables.
saDefaultSpecificationMarginalValue	String	user	0%	Sets the default of marginal high/low in percentage in Specification Tab of Outputs pane.
saDigitalDebugger	saDigitalDebuggerEnum	user	verdi	Name of the selected digital debugger. Valid values: verdi
saDisableAllTbsUseGlobalResource	bool	ser	true	Set all testbenches' Use Global Resource option value to off.
saDisableSchematicEditMode	bool	user	false	Disable to open the schematic in edit mode, used only in standalone mode
saDisplayNetlist	bool	user	false	Display Netlist File after Netlister Run. Valid values: true, false
saDisplayOptimizerLog	bool	user	true	Display log files during Optimizer run. Valid values: true, false
saDisplaySimulationLog	bool	user	false	Display simulation log during Simulation run. Valid values: true, false

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saDisplayType	string	xtJobClass	Current	Display to use for measurement calculations. Options include: Current, Specific, and Wrapper Script. Valid values: Current, Specific, Wrapper, Script
saDisplayWrapper	string	user		Script to run a sub-command with a virtual display.
saDistributeCustomFunc	bool	user	false	Distribute custom function calculation
saDoubleClickToEdit	bool	user	false	Double-click to edit the cells in the table. When <code>saDoubleClickToEdit</code> is true, you can select cells with a single click without immediately editing them, and double-click to edit the text in the cells. This feature is available in the following areas: Outputs table (all cells in Output and Expression columns) Model Files (all cells in Model File and Section columns) Variables pane (all cells in Variable and Value columns) Corners Setup and Extreme Cases (all cells in the corners setup table) dialog boxes Convergence Setup (all cells in Node and Voltage columns) Note: The behavior of Click to add in these tables is not changed. Valid values: true, false
saDoubleClickToEditOutputExpression	bool	user	false	Double-click to edit output expression. Valid values: true, false
saEnableAllTbsUseGlobalResource	bool	user	false	Set all testbenches 'Use Global Resource' option value to on
saEnableCompareHistory	bool	user	true	Control compare testsuite setup with the setup of latest history point, if it's the same , highlight the history point
saEnableDeviceTerminalVoltageProbing	bool	user	false	Controls whether to enable device terminal voltage probing. Valid values: true, false
saEnableDigitalRunStepAnalyze	bool	user	true	Enable digital analyze run step in AMS simulations Valid values: true, false

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saEnableGlobalScopeInNetlistImportFlow	bool	user	false	Enable the support of global scope in the netlist import flow.
saEnableHistogramPrompt	string	user	false	Enable prompting if the number of histogram exceeds the limit.
saEnableHistoryPointsDeletionPrompt	bool	saSession	false	Prompt for deleting History Points with Results beyond the maximum allowed. Valid values: true, false
saEnableLongEqn	int	user	8192	Used to set equation length. Default 8192
saEnableNominalCorner	bool	user	false	Enable status when the nominal corner is created. Valid values: true, false
saEnablePlotScalarValueInWV	string	user	false	Plot scalar value as signal in Waveform Viewer. Valid values: true, false
saEnablePrimeSimXAEldo	bool	user	false	If true, will enable Eldo format for PrimeSim XA engine.
saExportCornersFormat	bool	saSession	false	Format of the output csv
saEnableReEvaluateOnRemote	bool	user	false	If true, will launch measurement job on remote to do re-evaluation. Valid values: true, false
saEnableResultsHistory	bool	saSession	false	Enable Results History. Valid values: true, false
saEnableSaveDefaultTestbenchSetupPrompt	bool	user	false	Prompt the user to save the default testbench before running the netlister or simulation from main console. Valid values: true, false
saEnableTestSuiteResultsHistory	bool	saSession	true	Enable TestSuite Results History. Valid values: true, false
saEnvOptsResolveIncludePaths	bool	user	true	Resolve environment variables in include path. Valid values: true, false
saEvaluateKillSimulationResults	bool	user	false	When a simulation job killed, evaluate results base on killed simulation results. Valid values: true, false
saExpandHistoryPoints	bool	user	true	If expand history points when active history point changed/added
saExportCornersFilePath	string	saSession		Default path for corners export to file

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saExportCornersFormat	bool	saSession	false	Format of the output csv
saExportCornersName	string	saSession		Default state for corners export
saExportCornersShowInfo	bool	saSession	false	Shows state info in the Export Corners dialog box. Valid values: true, false
saExportCornersShowOptions	bool	saSession	false	Show options fields in the Export Corners dialog box. Valid values: true, false
saExportCornersTo	string	saSession	File	Default storage for corners export
saExportCsvFilesCustomizedName	bool	user	false	Controls whether customize CSV files prefix name when export CSV files
saExportCsvFilesPrefix	string	user	{}	Controls customize files prefix name when export CSV files
saExportCsvFilesRemoveTimestamp	bool	user	false	Controls whether remove timestamp when export CSV files
saExportCurPrecision	bool	user	true	Keep current table precisions. Valid values: true, false
saExportDefaultPath	string	user	.	Used to set export files default path.
saExportEngNotation	bool	user	true	Use engineering notation when exporting results to a CSV or HTML file.
saExportFilteredErrEquation	bool	user	false	Export filtered error equation
saExportFilteredTable	bool	user	true	Export filtered table content. Valid values: true, false
saExportImageSize	string	user	636*254	Export images size
saExportProbe	bool	user	false	Export signals in the ResultsView table
saExportProbe	bool	user	false	Export probe signals in the ResultsView table.
saExportResultsCompareFilePath	string	saSession		Default path for results compare export to file
saFineSimProACSweep	string	saTestbench	Frequency (Hz)	FineSimPro AC sweep type.
saFineSimProAnalysesImport	string	saTestbench	Import	FineSimPro analyses Import Setting.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProBlockOptionsCategories	string	saTestbench	All	Categories.
saFineSimProBlockOptionsSummary	string	saTestbench		Custom commands contents holder
saFineSimProConvergenceAidsImport	string	saTestbench	Import	FineSimPro convergenceAids Import Setting.
saFineSimProDataImport	string	saTestbench	Include	FineSimPro data Import Setting.
saFineSimProDCHysteresis	bool	saTestbench	false	FineSimPro DC hysteresis sweep Valid values: true, false
saFineSimProDefaultCornersSetup	string	saTestbench		FineSimPro default corners setup
saFineSimProDefaultIncludeFiles	string	saTestbench		FineSimPro default include files
saFineSimProDefaultModelFiles	string	saTestbench		FineSimPro default model files to be loaded
saFineSimProEnableSimulatorResultsXML	bool	user	false	Enables FineSimPro to write the resulting XML file. Valid values: true, false
saFineSimProEnvOptsOutputDataFormat	string	saTestbench	wdf	Output data format.
saFineSimProEnvOptsProjCfg	string	saTestbench		Project Config File
saFineSimProEnvOptsUseCacheDirInCommandLine	bool	user	false	Add pva_output_dir and s_elem_cache_dir in command line option
saFineSimProExportCircuitCheckSetupAnode	bool	saSession	true	Active/Inactive Nodes. Valid values: true, false
saFineSimProExportCircuitCheckSetupBlkPwr	bool	saSession	true	Block Power
saFineSimProExportCircuitCheckSetupDcPath	bool	saSession	true	DC Path
saFineSimProExportCircuitCheckSetupDcsub	bool	saSession	true	Device Check - Subckt. Valid values: true, false
saFineSimProExportCircuitCheckSetupDevcur	bool	saSession	true	Device Current. Valid values: true, false

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProExportCircuitCheckSetupDevOp	bool	saSession	true	High Impedance State Node
saFineSimProExportCircuitCheckSetupExpr	bool	saSession	true	Expression
saFineSimProExportCircuitCheckSetupFilePath	string	saSession		Default path for circuit check setup export to file
saFineSimProExportCircuitCheckSetupRfTime	bool	saSession	true	Rise/Fall Transition Time
saFineSimProExportCircuitCheckSetupTiming	bool	saSession	true	Timing Setup/Hold/Delay/Width
saFineSimProExportCircuitCheckSetupToggle	bool	saSession	true	Check and Report Toggle Count
saFineSimProExportCircuitCheckSetupZGate	bool	saSession	true	Device Operating Point
saFineSimProForceToGenerateNoiseSummary	bool	user	true	Force Noise Analysis to produce binary files.
saFineSimProHBACNumPoints	string	saTestbench		FineSimPro HBAC sweep number of points.
saFineSimProHBACPOI	string	saTestbench		FineSimPro HBAC sweep points.
saFineSimProHBACStart	string	saTestbench		FineSimPro HBAC sweep start.
saFineSimProHBACStop	string	saTestbench		FineSimPro HBAC sweep stop.
saFineSimProHBACSweepType	string	saTestbench	Linear	FineSimPro HBAC sweep Increment Type.
saFineSimProHBDesignVar	string	saTestbench		FineSimPro Harmonic Balance sweep design variable.
saFineSimProHBDesignVarUnits	string	saTestbench	dBm	FineSimPro Harmonic Balance sweep design variable unit.
saFineSimProHBFund1	string	saTestbench		FineSimPro Harmonic balance fundamental tone 1.
saFineSimProHBFund2	string	saTestbench		FineSimPro Harmonic balance fundamental tone 2.
saFineSimProHBFund3	string	saTestbench		FineSimPro Harmonic balance fundamental tone 3.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProHBFund4	string	saTestbench		FineSimPro Harmonic balance fundamental tone 4.
saFineSimProHBFund5	string	saTestbench		FineSimPro Harmonic balance fundamental tone 5.
saFineSimProHBFund6	string	saTestbench		FineSimPro Harmonic balance fundamental tone 6.
saFineSimProHBFund7	string	saTestbench		FineSimPro Harmonic balance fundamental tone 7.
saFineSimProHBIntmodmax	string	saTestbench	5	FineSimPro Harmonic balance intmodmax.
saFineSimProHBNOISEIFBCoeff	string	saTestbench	-1	FineSimPro Harmonic Balance Noise IFB Coefficient for OFB.
saFineSimProHBNOISENumFunds	string	saTestbench	1	FineSimPro Harmonic Balance Noise Number of fundamental tones for OFB.
saFineSimProHBNOISENumPoints	string	saTestbench		FineSimPro Harmonic Balance Noise sweep number of points.
saFineSimProHBNOISEOFB	string	saTestbench	0	FineSimPro Harmonic Balance Noise Output Band Frequency defined.
saFineSimProHBNOISEOutputType	string	saTestbench	Voltage	FineSimPro Harmonic Balance Noise Output Type.
saFineSimProHBNOISEPOI	string	saTestbench		FineSimPro Harmonic Balance Noise sweep points.
saFineSimProHBNOISEStart	string	saTestbench		FineSimPro Harmonic Balance Noise sweep start.
saFineSimProHBNOISEStop	string	saTestbench		FineSimPro Harmonic Balance Noise sweep stop.
saFineSimProHBNOISESweepType	string	saTestbench	Linear	FineSimPro Harmonic Balance Noise sweep Increment Type.
saFineSimProHBNOISEToneCoeff1	string	saTestbench	1	FineSimPro Harmonic balance noise OFB coefficient for tone 1.
saFineSimProHBNOISEToneCoeff2	string	saTestbench	1	FineSimPro Harmonic balance noise OFB coefficient for tone 2.
saFineSimProHBNOISEToneCoeff3	string	saTestbench	1	FineSimPro Harmonic balance noise OFB coefficient for tone 3.
saFineSimProHBNOISEToneCoeff4	string	saTestbench	1	FineSimPro Harmonic balance noise OFB coefficient for tone 4.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProHBNOISetToneCoeff5	string	saTestbench	1	FineSimPro Harmonic balance noise OFB coefficient for tone 5.
saFineSimProHBNOISetToneCoeff6	string	saTestbench	1	FineSimPro Harmonic balance noise OFB coefficient for tone 6.
saFineSimProHBNOISetToneCoeff7	string	saTestbench	1	FineSimPro Harmonic balance noise OFB coefficient for tone 7.
saFineSimProHBNumFunds	string	saTestbench	2	FineSimPro Harmonic balance number of fundamental tones.
saFineSimProHBNumHarm1	string	saTestbench		FineSimPro Harmonic balance number of harmonics 1.
saFineSimProHBNumHarm2	string	saTestbench		FineSimPro Harmonic balance number of harmonics 2.
saFineSimProHBNumHarm3	string	saTestbench		FineSimPro Harmonic balance number of harmonics 3.
saFineSimProHBNumHarm4	string	saTestbench		FineSimPro Harmonic balance number of harmonics 4.
saFineSimProHBNumHarm5	string	saTestbench		FineSimPro Harmonic balance number of harmonics 5.
saFineSimProHBNumHarm6	string	saTestbench		FineSimPro Harmonic balance number of harmonics 6.
saFineSimProHBNumHarm7	string	saTestbench		FineSimPro Harmonic balance number of harmonics 7.
saFineSimProHBNumPoints	string	saTestbench		FineSimPro Harmonic Balance sweep number of points.
saFineSimProHBOSCDesignVar	string	saTestbench		FineSimPro Harmonic Balance oscillator sweep design variable.
saFineSimProHBOSCDesignVarUnits	string	saTestbench	dBm	FineSimPro Harmonic Balance oscillator sweep design variable unit.
saFineSimProHBOSCFSP	string	saTestbench	false	FineSimPro Harmonic Balance oscillator frequency search points.
saFineSimProHBOSCFSPMax	string	saTestbench		FineSimPro Harmonic Balance oscillator maximum frequency for search points.
saFineSimProHBOSCFSPMin	string	saTestbench		FineSimPro Harmonic Balance oscillator minimum frequency for search points.
saFineSimProHBOSCFSPNum	string	saTestbench	1	FineSimPro Harmonic Balance oscillator number of frequency search points.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProHBOSCFSPStab	string	saTestbench		FineSimPro Harmonic Balance oscillator stability.
saFineSimProHBOSCNsubharm	string	saTestbench	0	FineSimPro Harmonic Balance oscillator number of subharmonics.
saFineSimProHBOSCNnumHarms	string	saTestbench		FineSimPro Harmonic Balance oscillator number of harmonics.
saFineSimProHBOSCNnumPoints	string	saTestbench		FineSimPro Harmonic Balance oscillator sweep number of points .
saFineSimProHBOSCPOI	string	saTestbench		FineSimPro Harmonic Balance oscillator sweep points.
saFineSimProHBOSCStart	string	saTestbench		FineSimPro Harmonic Balance oscillator sweep start.
saFineSimProHBOSCStop	string	saTestbench		FineSimPro Harmonic Balance oscillator sweep stop.
saFineSimProHBOSCSweep	string	saTestbench	false	FineSimPro Harmonic Balance oscillator sweep.
saFineSimProHBOSCSweepType	string	saTestbench	Linear	FineSimPro Harmonic Balance oscillator sweep Increment Type.
saFineSimProHBOSCTone	string	saTestbench		FineSimPro Harmonic Balance approx. oscillation frequency.
saFineSimProHBOSCVp	string	saTestbench		FineSimPro Harmonic Balance oscillator initial probe voltage.
saFineSimProHBPOI	string	saTestbench		FineSimPro Harmonic Balance sweep points.
saFineSimProHBStart	string	saTestbench		FineSimPro Harmonic Balance sweep start.
saFineSimProHBStop	string	saTestbench		FineSimPro Harmonic Balance sweep stop.
saFineSimProHBSweep	string	saTestbench	false	FineSimPro Harmonic Balance sweep.
saFineSimProHBSweepType	string	saTestbench	Linear	FineSimPro Harmonic Balance sweep Increment Type.
saFineSimProHBUseIntmodmax	string	saTestbench	true	HSPICE use the Harmonic balance intmodmax option.
saFineSimProHBXFNumPoints	string	saTestbench		FineSimPro HBXF sweep number of points.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProHBXFOutputType	string	saTestbench	Voltage	FineSimPro HBXF Output Type.
saFineSimProHBXFPOI	string	saTestbench		FineSimPro HBXF sweep points.
saFineSimProHBXFStart	string	saTestbench		FineSimPro HBXF sweep start.
saFineSimProHBXFStop	string	saTestbench		FineSimPro HBXF sweep stop.
saFineSimProHBXFSweepType	string	saTestbench	Linear	FineSimPro HBXF sweep Increment Type.
saFineSimProHFLCAGui	bool	user	false	Enable the loading and showing of the HF analyses in the GUI Valid values: true, false
saFineSimProImportCircuitCheckSetupFilePath	string	saSession		Default path for circuit check setup import from file
saFineSimProImportCircuitCheckSetupFrom	string	saSession	File	Default storage for circuit check setup import
saFineSimProImportCircuitCheckSetupName	string	saSession		Default state for circuit check setup import
saFineSimProImportCircuitCheckSetupShowInfo	bool	saSession	false	Show state info on the import circuit check setup dialog
saFineSimProImportCircuitCheckSetupShowOptions	bool	saSession	false	Show options fields on the import circuit check setup dialog
saFineSimProIncludeSchematicNetlist	bool	user	true	Copy (true) or .include (false) the structural netlist in the final netlist. Valid values: true, false
saFineSimProLibrariesImport	string	saTestbench	Import	FineSimPro libraries Import Setting.
saFineSimProLSTBMode	string	user	Single	FineSimPro LSTB Mode.
saFineSimProLSTBVsource1	string	user		FineSimPro LSTB Source 1.
saFineSimProLSTBVsource2	string	user		FineSimPro LSTB Source 2.
saFineSimProMeasuresImport	string	saTestbench	Import	FineSimPro measures Import Setting.
saFineSimProModelGroups	string	saTestbench		Model groups for FineSimPro

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProModelGroupsCheck Box	bool	saTestbench	false	Visibility of Model Groups table for FineSimPro Valid values: true, false
saFineSimProModelsImport	string	saTestbench	Import	FineSimPro models Import Setting.
saFineSimProMonteCarloLHSReplicates	string	saTestbench	1	Runs replicates of Latin Hypercube samples.
saFineSimProMonteCarloNumlp	string	saTestbench	1	Number of Independent parallel simulation processes.
saFineSimProMonteCarloOFATIntervals	string	saTestbench	1	Generate 2n+1 equally spaced samples for each OFAT variable.
saFineSimProMonteCarloOFATOnOneSided	bool	saTestbench	false	Enable/disable one-sided intervals.
saFineSimProMonteCarloOFATOnOneSidedValue	string	saTestbench	0.5	Generate 2n+1 equally spaced samples for each OFAT variable.
saFineSimProMonteCarloSigmaScale	string	saTestbench	2.0	Sigma Scale Factor for High Sigma Applications.
saFineSimProMonteCarloUseRandomSeed	string	saTestbench	0	Use random seed for random-number generator in Monte Carlo analysis.
saFineSimProMonteCarloUseSigmaScaling	string	saTestbench	0	Uses Sigma Scaling for High Sigma Applications.
saFineSimProMonteCarloVariationIncludeOrExclude	string	saTestbench	Include	Whether statistical variation is to be applied or not applied to the specified instances/cells.
saFineSimProMonteCarloVariationInstanceOrCellList	string	saTestbench		List of instances or cells for which statistical variation is to be applied/not applied.
saFineSimProMonteCarloVariationObjectType	string	saTestbench	Instances	Object type (instances or cells) for which statistical variation is to be applied/not applied.saFineSimProNOISEListCount
saFineSimProNOISEListCount	string	saTestbench		FineSimPro NOISE List Count
saFineSimProNOISEListFloor	string	saTestbench	1e-50	FineSimPro NOISE List Floor
saFineSimProNOISEListFreq	string	saTestbench		FineSimPro NOISE List Freq
saFineSimProNOISEListFreqType	string	saTestbench	all	FineSimPro NOISE List Freq Type

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProNOISEListShare	string	saTestbench		FineSimPro NOISE List Share
saFineSimProNOISEListSources	string	saTestbench	1	FineSimPro NOISE List Sources
saFineSimProNoiseSummaryAbsoluteThreshold	string	user	0	Noise Summary Truncate Absolute Threshold
saFineSimProNoiseSummaryIncludeBreakdown	string	user	0	Noise Summary Include Noise Breakdown
saFineSimProNoiseSummaryNoiseCategory	string	user	Total	Noise Summary Results To Be Shown
saFineSimProNoiseSummaryNoiseOption	saFineSimProNoiseSummaryNoiseOptionEnum	user	Spot Noise	Noise Summary Option Valid values: {Spot Noise} {Integrated Noise}
saFineSimProNoiseSummaryRelativeThreshold	string	user	0	Noise Summary Truncate Relative Threshold
saFineSimProNoiseSummarySumIteratedInstances	string	user	true	Noise Summary Sum Iterated Instances
saFineSimProNoiseSummaryTopContributors	string	user	100	Noise Summary Truncate Top Contributors
saFineSimProNoiseSummaryTruncateType	string	user	By Contribution	Noise Summary Truncate Type
saFineSimProNoiseSummaryUnit	string	user	<file path>	Noise Summary Unit
saFineSimProOPTimes	string	saTestbench		FineSimPro Operating point save time.
saFineSimProOptionagepwinteg	string	saTestbench	0	FineSimPro option age_pw_integ: Controls new mosramt0.
saFineSimProOptionagepwintegUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionagepwinteg is loaded.
saFineSimProOptionagepwintegUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionASPEC	string	custom	0	FineSimPro option ASPEC: Sets ASPEC compatibility mode for spice characterization.
saFineSimProOptionASPECUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionASPEC is loaded.
saFineSimProOptionASPECUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionAUTOSTOP	string	custom	0	FineSimPro option AUTOSTOP: Stops a transient analysis.
saFineSimProOptionAUTOSTOPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionAUTOSTOP is loaded.
saFineSimProOptionAUTOSTOPUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionCAPTAB	string	custom	0	FineSimPro option CAPTAB: Add up all the capacitances attached to a node and outputs a .cap file.
saFineSimProOptionCAPTABUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionCAPTAB is loaded.
saFineSimProOptionCAPTABUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionCSHUNT	string	custom	0	FineSimPro option CSHUNT: Add capacitance from each node to ground.
saFineSimProOptionCSHUNTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionCSHUNT is loaded.
saFineSimProOptionCSHUNTUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionDCAP	string	custom	2	FineSimPro option DCAP: Specifies equations used to calculate depletion capacitance for Level 1 and 3 diodes and BJTs.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionDCAPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionDCAP is loaded.
saFineSimProOptionDCAPUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionDCIC	string	custom	1	FineSimPro option DCIC: Controls whether or not .IC is used for DC analysis.<
saFineSimProOptionDCICUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionDCIC is loaded.
saFineSimProOptionDCICUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionDEFAD	string	custom	0	FineSimPro option DEFAD: Sets the default value for MOSFET drain diffusion area.
saFineSimProOptionDEFADUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionDEFAD is loaded.
saFineSimProOptionDEFADUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionDEFAS	string	custom	0	FineSimPro option DEFAS: Sets the default value for MOSFET source diffusion area.
saFineSimProOptionDEFASUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionDEFAS is loaded.
saFineSimProOptionDEFASUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionDEFL	string	custom	1e-4m	FineSimPro option DEFL: Sets the default value for MOS channel length.
saFineSimProOptionDEFLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionDEFL is loaded.
saFineSimProOptionDEFLUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionDEFNRD	string	custom	0	FineSimPro option DEFNRD: Sets the number of squares for the drain resistor on a MOSFET.
saFineSimProOptionDEFNRDUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionDEFNRD is loaded.
saFineSimProOptionDEFNRDUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionDEFNRS	string	custom	0	FineSimPro option DEFNRS: Sets the number of squares for the source resistor on a MOSFET.
saFineSimProOptionDEFNRSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionDEFNRS is loaded.
saFineSimProOptionDEFNRSUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionDEFDPD	string	custom	0	FineSimPro option DEFDPD: Sets the default value for the MOSFET drain diffusion perimeter.
saFineSimProOptionDEFDPDUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionDEFDPD is loaded.
saFineSimProOptionDEFDPDUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionDEFPS	string	custom	0	FineSimPro option DEFPS: Sets the default value for the MOSFET source diffusion perimeter.
saFineSimProOptionDEFPSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionDEFPS is loaded.
saFineSimProOptionDEFPSUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionDEFW	string	custom	1e-4m	FineSimPro option DEFW: Sets default value for MOS channel width.

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProOptionDEFWUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionDEFW is loaded.
saFineSimProOptionDEFWUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionerrpreset	string	custom	donotoverride	FineSimPro option errpreset: Selects a reasonable collection of parameter settings: liberal, moderate, or conservative.
saFineSimProOptionerrpresetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionerrpreset is loaded.
saFineSimProOptionerrpresetUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimacatdiff	string	custom	0	FineSimPro option finesim_ac_at_diff_t: Determines whether or not small signal analyses like ac and noise are run at times specified in .OP statement
saFineSimProOptionfinesimacatdiffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimacatdiff is loaded.
saFineSimProOptionfinesimacatdiffUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimaccelerateromUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimacceleraterom is loaded.
saFineSimProOptionfinesimaccelerateromUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimallowdupportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimallowdupport is loaded.
saFineSimProOptionfinesimallowdupportUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimassert	string	saTestbench	0	FineSimPro option finesim_assert: Control the effort applied to assert checks
saFineSimProOptionfinesimassertUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimassert is loaded.
saFineSimProOptionfinesimbisectionoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimbisectionoutput is loaded.
saFineSimProOptionfinesimbisectionoutputUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimbisectionsummaryUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimbisectionsummary is loaded.
saFineSimProOptionfinesimbisectionsummaryUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimbytolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimbytol is loaded.
saFineSimProOptionfinesimbytolUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimcheckmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimcheckmodel is loaded.
saFineSimProOptionfinesimcheckmodelUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimcheckvthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimcheckvth is loaded.
saFineSimProOptionfinesimcheckvthUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimchgtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimchgtol is loaded.
saFineSimProOptionfinesimchgtolUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimchkdevportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimchkdevport is loaded.
saFineSimProOptionfinesimchkdevportUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimchkdiskspaceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimchkdiskspace is loaded.
saFineSimProOptionfinesimchkdiskspaceUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimchkexprprintall	string	saTestbench	0	FineSimPro option finesim_chkexpr_print_all: When set to 1, invalid assert checks are also dumped into csv file
saFineSimProOptionfinesimchkexprprintallUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimchkexprprintall is loaded.
saFineSimProOptionfinesimchkznodevthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimchkznodevth is loaded.
saFineSimProOptionfinesimchkznodevthUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimclampVerilogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimclampVerilog is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimclampVerilogUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimcmodeIUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimcmode is loaded.
saFineSimProOptionfinesimcmodeIUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimconvlevelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimconvlevel is loaded.
saFineSimProOptionfinesimconvlevelUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdcalgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdcalg is loaded.
saFineSimProOptionfinesimdcalgUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdceffortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdceffort is loaded.
saFineSimProOptionfinesimdceffortUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdelmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdelmax is loaded.
saFineSimProOptionfinesimdelmaxUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdetectlvddstaticUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdetectlvddstatic is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimdetectlvddstaticUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdiagba	string	saTestbench	0	FineSimPro option finesim_diag_ba: When set to 1, parastic back annotation log file will separate for better diagnostics.
saFineSimProOptionfinesimdiagbaUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdiagba is loaded.
saFineSimProOptionfinesimdiagbaUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdoubleprecisionoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdoubleprecisionoutput is loaded.
saFineSimProOptionfinesimdoubleprecisionoutputUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdpf	string	custom		FineSimPro option finesim_dpf: Specifies the DPF file that contains the extracted device parameter data.
saFineSimProOptionfinesimdpfadddevUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdpfadddev is loaded.
saFineSimProOptionfinesimdpfadddevUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdpfhdivUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdpfhdiv is loaded.
saFineSimProOptionfinesimdpfhdivUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdpfmodule	string	custom		FineSimPro option finesim_dpftime: Specifies the module for DPF back-annotation.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimdpfmoduleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdpfmodule is loaded.
saFineSimProOptionfinesimdpfmoduleUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdpfmosonly	string	custom		FineSimPro option finesim_dpf_mos_only: Specifies whether to back-annotate all devices or only MOSFET devices.
saFineSimProOptionfinesimdpfmosonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdpfmosonly is loaded.
saFineSimProOptionfinesimdpfmosonlyUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdpfprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdpfprefix is loaded.
saFineSimProOptionfinesimdpfprefixUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdpfscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdpfscale is loaded.
saFineSimProOptionfinesimdpfscaleUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdpfsuffixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdpfsuffix is loaded.
saFineSimProOptionfinesimdpfsuffixUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdpfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdpf is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimdpfUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimdvmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimdvmax is loaded.
saFineSimProOptionfinesimdvmaxUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimfcapminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimfcapmin is loaded.
saFineSimProOptionfinesimfcapminUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimfcapmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimfcapmodel is loaded.
saFineSimProOptionfinesimfcapmodelUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimflatsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimflatsize is loaded.
saFineSimProOptionfinesimflatsizeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimfloatinggategshuntUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimfloatinggategshunt is loaded.
saFineSimProOptionfinesimfloatinggategshuntUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimfscautodetectUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimfscautodetect is loaded.

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimfscautoDetectUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimfscvddUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimfscvdd is loaded.
saFineSimProOptionfinesimfscvddUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimfsdblimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimfsdblimit is loaded.
saFineSimProOptionfinesimfsdblimitUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimfsdbsplittime	string	custom		FineSimPro option finesim_fsdb_split_time: Specifies to split FSDB based on the time values.
saFineSimProOptionfinesimfsdbsplittimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimfsdbsplittime is loaded.
saFineSimProOptionfinesimfsdbsplittimeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimgenacop	string	custom	1	FineSimPro option finesim_gen_ac_op: Determines if binary files or ASCII .ic files are generated for each time point in .OP statement
saFineSimProOptionfinesimgenacopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimgenacop is loaded.
saFineSimProOptionfinesimgenacopUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimgenicopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimgenicop is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimgenicopUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimgicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimgic is loaded.
saFineSimProOptionfinesimgicUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimgmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimgmax is loaded.
saFineSimProOptionfinesimgmaxUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimgoffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimgoff is loaded.
saFineSimProOptionfinesimgoffUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimhstolscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimhstolscale is loaded.
saFineSimProOptionfinesimhstolscaleUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimidenticalmcinstancefileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimidenticalmcinstancefile is loaded.
saFineSimProOptionfinesimidenticalmcinstancefileUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimignorechkfuncerrorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimignorechkfuncerror is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimignorechkfuncerrorUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimignoresubblkoptionerrorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimignoresubblkoptionerror is loaded.
saFineSimProOptionfinesimignoresubblkoptionerrorUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimiovecabsvalueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimiovecabsvalue is loaded.
saFineSimProOptionfinesimiovecabsvalueUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimiovecvihUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimiovecvih is loaded.
saFineSimProOptionfinesimiovecvihUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimiovecvivilUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimiovecvivil is loaded.
saFineSimProOptionfinesimiovecvivilUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimiprbtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimiprbtol is loaded.
saFineSimProOptionfinesimiprbtolUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimiremrmUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimiremrm is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimremm sUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimkeep0 vdcvs	string	custom	0	FineSimPro option finesim_keep_0v_dcvs: Keeps 0v DC voltage sources in the simulation database.
saFineSimProOptionfinesimkeep0 vdcvsop	string	custom	0	FineSimPro option finesim_keep_0v_dcvs_op: Keeps 0v DC voltage sources for .op analysis.
saFineSimProOptionfinesimkeep0 vdcvsopUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimkeep0vdcvsop is loaded.
saFineSimProOptionfinesimkeep0 vdcvsopUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimkeep0 vdcvsUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimkeep0vdcvs is loaded.
saFineSimProOptionfinesimkeep0 vdcvsUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimkeepz eroparmsUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimkeepzeroparms is loaded.
saFineSimProOptionfinesimkeepz eroparmsUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimleakag emodeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimleakagemode is loaded.
saFineSimProOptionfinesimleakag emodeUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimloadm odelUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimloadmodel is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimloadmodelUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimmaxicutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimmaxicut is loaded.
saFineSimProOptionfinesimmaxicutUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimmaxwidthtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimmaxwidthtol is loaded.
saFineSimProOptionfinesimmaxwidthtolUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimmcbriefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimmcbrief is loaded.
saFineSimProOptionfinesimmcbriefUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimmcnominalsimulation	string	saTestbench		FineSimPro option finesim_mc_nominal_simulation: Sets the behavior of simple random sampling (SRS) for the first Monte Carlo sweep.
saFineSimProOptionfinesimmcnominalsimulationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimmcnominalsimulation is loaded.
saFineSimProOptionfinesimmeasoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimmeasout is loaded.
saFineSimProOptionfinesimmeasoutUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimmethod	string	custom	TRAP	FineSimPro option finesim_method: Sets the numerical integration method used during a transient analysis.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimmethod is loaded.
saFineSimProOptionfinesimmethodUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimmode	string	custom	spicead	FineSimPro option finesim_mode: Sets the Simulation mode.
saFineSimProOptionfinesimmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimmodel is loaded.
saFineSimProOptionfinesimmodelUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimmodelverificationmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimmodelverificationmode is loaded.
saFineSimProOptionfinesimmodelverificationmodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimmode is loaded.
saFineSimProOptionfinesimmodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimmparcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimmparcheck is loaded.
saFineSimProOptionfinesimmparcheckUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimnegres	string	custom	1	FineSimPro option finesim_negres: Keeps negative resistors in the netlist.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimnegresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimnegres is loaded.
saFineSimProOptionfinesimnegresUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimnoiseoff	string	custom	0	FineSimPro option finesim_noise_off: Disable noise generation.
saFineSimProOptionfinesimnoiseoffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimnoiseoff is loaded.
saFineSimProOptionfinesimnoiseoffUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimnoiseon	string	custom	0	FineSimPro option finesim_noise_on: Enable noise generation.
saFineSimProOptionfinesimnoiseonUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimnoiseon is loaded.
saFineSimProOptionfinesimnoiseonUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimnummeaslogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimnummeaslog is loaded.
saFineSimProOptionfinesimnummeaslogUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimnummeasperlineUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimnummeasperline is loaded.
saFineSimProOptionfinesimnummeasperlineUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimoutputfnameTypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimoutputfnameType is loaded.
saFineSimProOptionfinesimoutputfnameTypeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimoutputrangeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimoutputrange is loaded.
saFineSimProOptionfinesimoutputrangeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimpartitionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimpartition is loaded.
saFineSimProOptionfinesimpartitionUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimpostl	string	custom	0	FineSimPro option finesim_postl: Sets the level of acceleration to use when performing post-layout analog simulation on RC-extracted circuits.
saFineSimProOptionfinesimpostlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimpostl is loaded.
saFineSimProOptionfinesimpostlUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimprbexprvarUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimprbexprvar is loaded.
saFineSimProOptionfinesimprbexprvarUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimprbportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimprbport is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimprbportUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimprelayoutmodelsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimprelayoutmodels is loaded.
saFineSimProOptionfinesimprelayoutmodelsUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimprintmaxconnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimprintmaxconnode is loaded.
saFineSimProOptionfinesimprintmaxconnodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimprintperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimprintperiod is loaded.
saFineSimProOptionfinesimprintperiodUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimprinttoprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimprinttoprobe is loaded.
saFineSimProOptionfinesimprinttoprobeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimprobepassivedeviceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimprobepassivedevice is loaded.
saFineSimProOptionfinesimprobepassivedeviceUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimprofileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimprofile is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimprofileUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimpwrblock	string	custom	1	FineSimPro option finesim_pwrblock: Detects the parasitics in the power network.
saFineSimProOptionfinesimpwrblockUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimpwrblock is loaded.
saFineSimProOptionfinesimpwrblockUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimpwrtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimpwrtol is loaded.
saFineSimProOptionfinesimpwrtolUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimqllevelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimqllevel is loaded.
saFineSimProOptionfinesimqllevelUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimrcred	string	custom	0	FineSimPro option finesim_rcred: Sets the level of acceleration to use when performing post-layout analog simulation with RC reduction.
saFineSimProOptionfinesimrcredUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimrcred is loaded.
saFineSimProOptionfinesimrcredUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimremoveprobeprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimremoveprobeprefix is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimremoveprefixUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimresmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimresmax is loaded.
saFineSimProOptionfinesimresmaxUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimresmin	string	custom	0.001	FineSimPro option finesim_resmin: Sets minimum value for a resistor to be considered in simulation. The default value is dependent on finesim_mode.
saFineSimProOptionfinesimresminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimresmin is loaded.
saFineSimProOptionfinesimresminUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimreusemosmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimreusemosmodel is loaded.
saFineSimProOptionfinesimreusemosmodelUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimrpittftmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimrpittftmode is loaded.
saFineSimProOptionfinesimrpittftmodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimsetcpu timeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimsetcpu time is loaded.
saFineSimProOptionfinesimsetcpu timeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimsetspecialcharUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimsetspecialchar is loaded.
saFineSimProOptionfinesimsetspecialcharUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimsinglebinmodelcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimsinglebinmodelcheck is loaded.
saFineSimProOptionfinesimsinglebinmodelcheckUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimskipunusedparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimskipunusedparam is loaded.
saFineSimProOptionfinesimskipunusedparamUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimskipwarnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimskipwarn is loaded.
saFineSimProOptionfinesimskipwarnUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimsoamaxwarns	string	custom	5	FineSimPro option finesim_soa_maxwarns: Specifies maximum number of SOA warning messages.
saFineSimProOptionfinesimsoamaxwarnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimsoamaxwarns is loaded.
saFineSimProOptionfinesimsoamaxwarnsUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimsoawarn	string	custom	0	FineSimPro option finesim_soa_warn: Enables or turns off safe operating area (SOA) voltage warning message.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimsoawarnformat	string	custom	0	FineSimPro option finesim_soa_warn_format: Format of SOA check output.
saFineSimProOptionfinesimsoawarnformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimsoawarnformat is loaded.
saFineSimProOptionfinesimsoawarnformatUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimsoawarnlogfile	string	custom	0	FineSimPro option finesim_soa_warn_to_file: Print result of SOA checks to separate file (tsoa).
saFineSimProOptionfinesimsoawarnlogfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimsoawarnlogfile is loaded.
saFineSimProOptionfinesimsoawarnlogfileUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimsoawarnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimsoawarn is loaded.
saFineSimProOptionfinesimsoawarnUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspeedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspeed is loaded.
saFineSimProOptionfinesimspeedUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspf2eqrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspf2eqr is loaded.
saFineSimProOptionfinesimspf2eqrUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimspfallowerrorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfallowerror is loaded.
saFineSimProOptionfinesimspfallowerrorUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfallowmissinginstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfallowmissinginstance is loaded.
saFineSimProOptionfinesimspfallowmissinginstanceUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfallowfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfallowfile is loaded.
saFineSimProOptionfinesimspfallowfileUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfallowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfallow is loaded.
saFineSimProOptionfinesimspfallowUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfallownUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfallown is loaded.
saFineSimProOptionfinesimspfallownUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfallowfirstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfallowfirst is loaded.
saFineSimProOptionfinesimspfallowfirstUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimspfkee phierUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfkeephier is loaded.
saFineSimProOptionfinesimspfkee phierUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfmat cheffortUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfmatcheffort is loaded.
saFineSimProOptionfinesimspfmat cheffortUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfmer geportUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfmergeport is loaded.
saFineSimProOptionfinesimspfmer geportUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfprb modeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfprbmode is loaded.
saFineSimProOptionfinesimspfprb modeUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfprb UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfprb is loaded.
saFineSimProOptionfinesimspfprb UncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfpref ixUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfprefix is loaded.
saFineSimProOptionfinesimspfpref ixUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimspfired UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfired is loaded.
saFineSimProOptionfinesimspfired UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfired lastUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfiredlast is loaded.
saFineSimProOptionfinesimspfired lastUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfired maxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfiredmax is loaded.
saFineSimProOptionfinesimspfired maxUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfired minUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfiredmin is loaded.
saFineSimProOptionfinesimspfired minUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfired ptrmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfiredptrmax is loaded.
saFineSimProOptionfinesimspfired ptrmaxUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfired1 UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfired1 is loaded.
saFineSimProOptionfinesimspfired1 UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimspftrc2 UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspftrc2 is loaded.
saFineSimProOptionfinesimspftrc2 UncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfscal eUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfscale is loaded.
saFineSimProOptionfinesimspfscal eUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfspic enamesUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfspicenames is loaded.
saFineSimProOptionfinesimspfspic enamesUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfsplit netUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfsplitnet is loaded.
saFineSimProOptionfinesimspfsplit netUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspfssuffi xUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfssuffix is loaded.
saFineSimProOptionfinesimspfssuffi xUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspftrcU ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspftrc is loaded.
saFineSimProOptionfinesimspftrcU ncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimspfrefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspfref is loaded.
saFineSimProOptionfinesimspfrefUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimspredUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimspred is loaded.
saFineSimProOptionfinesimspredUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimsubcktdupruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimsubcktduprule is loaded.
saFineSimProOptionfinesimsubcktdupruleUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimtf flushUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimtf flush is loaded.
saFineSimProOptionfinesimtf flushUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimtolscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimtolscale is loaded.
saFineSimProOptionfinesimtolscaleUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimtsc	string	saTestbench	lte1	FineSimPro option finesim_tsc: Sets the algorithm mode for time-step control during transient analysis.
saFineSimProOptionfinesimtscUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimtsc is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimtsUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimtunit	string	custom	0.01p	FineSimPro option finesim_tunit: Defines the base time unit of the simulation.
saFineSimProOptionfinesimtunitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimtunit is loaded.
saFineSimProOptionfinesimtunitUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimuseoldtroutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimuseoldtrout is loaded.
saFineSimProOptionfinesimuseoldtroutUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimutfmode	string	saTestbench	fast	FineSimPro option finesim_utf_mode: Outputs compressed UTF for Veritools.
saFineSimProOptionfinesimutfmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimutfmode is loaded.
saFineSimProOptionfinesimutfmodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimvddUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimvdd is loaded.
saFineSimProOptionfinesimvddUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimvectormodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimvectormode is loaded.
saFineSimProOptionfinesimvectormodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimvprbtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimvprbtol is loaded.
saFineSimProOptionfinesimvprbtolUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimvsrchn	string	saTestbench	1	FineSimPro option finesim_vsrchn: When set to 1, voltage sources are non-ideal and modeled by Norton equivalents, with parallel resistance equal to 1mOhm.
saFineSimProOptionfinesimvsrchnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimvsrchn is loaded.
saFineSimProOptionfinesimvsrchnUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimwarnlimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimwarnlimit is loaded.
saFineSimProOptionfinesimwarnlimitUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimwdflimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimwdflimit is loaded.
saFineSimProOptionfinesimwdflimitUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimwdfmode	string	saTestbench	loseless	FineSimPro option finesim_wdf_mode: Controls the amount of compression for wdf output file.
saFineSimProOptionfinesimwdfmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimwdfmode is loaded.
saFineSimProOptionfinesimwdfmodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionfinesimwriteinstancetableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimwriteinstancetable is loaded.
saFineSimProOptionfinesimwriteinstancetableUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionfinesimwritemcparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionfinesimwritemcparam is loaded.
saFineSimProOptionfinesimwritemcparamUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionGEOSHRINK	string	custom	0	FineSimPro option GEOSHRINK: Sets scale factor for shrinking device geometry.
saFineSimProOptionGEOSHRINKUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionGEOSHRINK is loaded.
saFineSimProOptionGEOSHRINKUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionGMIN	string	custom	1e-12	FineSimPro option GMIN: Minimum conductance added to all PN junctions for a time sweep in transient analysis.
saFineSimProOptionGMINDC	string	custom	1e-12	FineSimPro option GMINDC: Sets the minimum conductance places in parallel with all PN junctions and all MOSFET nodes except the gate for DC analysis
saFineSimProOptionGMINDCUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionGMINDC is loaded.
saFineSimProOptionGMINDCUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionGMINUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionGMIN is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionGMINUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionGRAMP	string	custom	0	FineSimPro option GRAMP: Sets the conductance range over which GMINDC is to be swept during a DC operating point analysis.
saFineSimProOptionGRAMPUndeckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionGRAMP is loaded.
saFineSimProOptionGRAMPUndeckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionGSHUNT	string	custom	0	FineSimPro option GSHUNT: Helps DC/Tran convergence for some kinds of circuits.
saFineSimProOptionGSHUNTUndeckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionGSHUNT is loaded.
saFineSimProOptionGSHUNTUndeckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionHBACKRYLOVDIM	string	custom	300	FineSimPro option HBACKRYLOVDIM: Specifies the dimension of the Krylov subspace used by the Krylov solver.
saFineSimProOptionHBACKRYLOVITER	string	custom	1000	FineSimPro option HBACKRYLOVITER: Specifies the number of GMRES solver iterations performed by the HB engine.
saFineSimProOptionHBACTOL	string	custom	1.e-8	FineSimPro option HBACTOL: Specifies the absolute error tolerance for determining convergence.
saFineSimProOptionHBCONTINUE	string	custom	1	FineSimPro option HBCONTINUE: Specifies whether to use the sweep solution from the previous simulation as the initial guess for the present simulation.
saFineSimProOptionHBFREQABSTOL	string	custom	1.0	FineSimPro option HBFREQABSTOL: Specifies the maximum absolute change in frequency between solver iterations for convergence.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionHBFREQREL TOL	string	custom	1.e-9	FineSimPro option HBFREQRELTOL: Specifies the maximum relative change in frequency between solver iterations for convergence.
saFineSimProOptionHBGIBBS	string	custom	0	FineSimPro option HB_GIBBS: Option for HBTRAN output to minimize Gibbs phenomena.
saFineSimProOptionHBJREUSE	string	custom		FineSimPro option HBJREUSE: Controls when to recalculate the Jacobson matrix.
saFineSimProOptionHBJREUSE TOL	string	custom	0.05	FineSimPro option HBJREUSETOL: Determines when to recalculate Jacobian matrix if HBJREUSE=1.0.
saFineSimProOptionHBKRYLOV DIM	string	custom	40	FineSimPro option HBKRYLOVDIM: Specifies the dimension of the subspace used by the Krylov solver.
saFineSimProOptionHBKRYLOVM AXITER	string	custom	500	FineSimPro option HBKRYLOVMAXITER: Specifies the maximum number of GMRES solver iterations performed by the HB engine.
saFineSimProOptionHBKRYLOV TOL	string	custom	0.01	FineSimPro option HBKRYLOVTOL: Specifies the error tolerance for the Krylov solver.
saFineSimProOptionHBLINESEAR CHFAC	string	custom	0.35	FineSimPro option HBLINESEARCHFAC: Specifies the line search factor.
saFineSimProOptionHBMAXITER	string	custom	1000	FineSimPro option HBMAXITER: Specifies the maximum number of Newton-Raphson iterations performed by the HB engine.
saFineSimProOptionHBOSCMAXI TER	string	custom	10000	FineSimPro option HBOSCMAXITER: Specifies the maximum number of outer-loop iterations for oscillator analysis.
saFineSimProOptionHBPROBE TOL	string	custom	1.e-9	FineSimPro option HBPROBETOL: Searches for a probe voltage at which the probe current is less than the specified value.
saFineSimProOptionHBSOLVER	string	custom	1	FineSimPro option HBSOLVER: Specifies a preconditioner for solving nonlinear circuits.
saFineSimProOptionHBTOL	string	custom	1.e-9	FineSimPro option HBTOL: Specifies the absolute error tolerance for determining convergence.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionHBTRANFRE QSEARCH	string	custom	1	FineSimPro option HBTRANFREQSEARCH: Specifies the frequency source for the HB analysis of a ring oscillator.
saFineSimProOptionHBTRANINIT	string	custom	0	FineSimPro option HBTRANINIT: Selects transient analysis for initializing all state variables for HB analysis of a ring oscillator.
saFineSimProOptionHBTRANPTS	string	custom		FineSimPro option HBTRANPTS: Specifies the number of points per period for converting time-domain data results into the frequency domain for HB analysis of a ring oscillator.
saFineSimProOptionHBTRANST STEP	string	custom		FineSimPro option HBTRANSTEP: Specifies transient analysis step size for the HB analysis of a ring oscillator.
saFineSimProOptionHIERSCALE	string	custom	0	FineSimPro option HIER_SCALE: Sets a scale parameter with a value determined by the scale option.
saFineSimProOptionHIERSCALE UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionHIERSCALE is loaded.
saFineSimProOptionHIERSCALE UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionIMAX	string	custom	8.0	FineSimPro option IMAX: Sets the upper limit of iterations in transient analysis.
saFineSimProOptionIMAXUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionIMAX is loaded.
saFineSimProOptionIMAXUncheck Localized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionIMIN	string	custom	3.0	FineSimPro option IMIN: Sets the lower limit of iterations in transient analysis.
saFineSimProOptionIMINUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionIMIN is loaded.
saFineSimProOptionIMINUncheck Localized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProOptionINTERP	string	custom	0	FineSimPro option INTERP: If 1, sets the simulations output to be in the increment defined by timestep in .tran analysis.
saFineSimProOptionINTERPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionINTERP is loaded.
saFineSimProOptionINTERPUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionITL1	string	custom	200	FineSimPro option ITL1: Sets the maximum number of DC iterations.
saFineSimProOptionITL1UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionITL1 is loaded.
saFineSimProOptionITL1UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionLOADHB	string	custom		FineSimPro option LOADHB: Loads state variable information from a specified file.
saFineSimProOptionLOADSNINIT	string	custom		FineSimPro option LOADSNINIT: Loads the operating point saved at the end of Shooting Newton analysis initialization.
saFineSimProOptionMACMOD	string	custom	0	FineSimPro option MACMOD: To access the subcircuit definition when there is no matching model reference.
saFineSimProOptionMACMOD	string	custom	0	FineSimPro option MACMOD: To access the subcircuit definition when there is no matching model reference.
saFineSimProOptionMACMODUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionMACMOD is loaded.
saFineSimProOptionMACMODUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionMAXWARNS	string	custom	5	FineSimPro option MAXWARNS: Specifies maximum number of SOA warning messages (equivalent to finesim_soa_maxwarns).

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionMAXWARNS	string	custom	5	FineSimPro option MAXWARNS: Specifies maximum number of SOA warning messages (equivalent to finesim_soa_maxwarns).
saFineSimProOptionMAXWARNS UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionMAXWARNS is loaded.
saFineSimProOptionMAXWARNS UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionMEASDGT	string	custom	4	FineSimPro option MEASDGT: Sets the number of significant digits for results in .measure file.
saFineSimProOptionMEASDGTUn checkLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionMEASDGT is loaded.
saFineSimProOptionMEASDGTUn checkLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionNEWSOA	string	custom	0	FineSimPro option NEW_SOA: Print result of SOA checks to separate file (.tsoa) (NEW_SOA=1 is equivalent to finesim_soa_warn_to_file=1 and finesim_soa_warn_format=4).
saFineSimProOptionNEWSOA	string	custom	0	FineSimPro option NEW_SOA: Print result of SOA checks to separate file (tsoa) (NEW_SOA=1 is equivalent to finesim_soa_warn_to_file=1 and finesim_soa_warn_format=4).
saFineSimProOptionNEWSOAUnc heckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionNEWSOA is loaded.
saFineSimProOptionNEWSOAUnc heckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionNUMDGT	string	custom	4	FineSimPro option NUMDGT: Sets the number of significant digits for output results in .ic, .prt, and .pd# files.
saFineSimProOptionNUMDGTUnc heckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionNUMDGT is loaded.

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProOptionNUMDGTUnc heckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionotherOptions UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionotherOptions is loaded.
saFineSimProOptionotherOptions UncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionPARHIER	string	saTestbe nch	GLOBAL	FineSimPro option PARHIER: Sets the parameter passing rules to control the evaluation order of subcircuit parameters
saFineSimProOptionPARHIERUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionPARHIER is loaded.
saFineSimProOptionPOSTVERS ION	string	custom	9601	FineSimPro option POST_VERSION: Selects the Spice 2001 output format during the generation of a .tr0 file.
saFineSimProOptionPOSTVERSI ONUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionPOSTVERSION is loaded.
saFineSimProOptionPOSTVERSI ONUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionpvaoutputdir	string	saTestbe nch	<file path>	FineSimPro option pva_output_dir: Controls pva cache directory.
saFineSimProOptionpvaoutputdirU ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionpvaoutputdir is loaded.
saFineSimProOptionreplicates	string	custom		FineSimPro option replicates: Runs replicates of Latin Hypercube samples.
saFineSimProOptionRISETIME	string	custom		FineSimPro option RISETIME: Sets the smallest rise time of the signal used only in transmission kine models.
saFineSimProOptionRISETIMEUn checkLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionRISETIME is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionRISETIMEUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionrunlvl	string	custom	5	FineSimPro option runlvl: Controls runtime speed and simulation accuracy.
saFineSimProOptionrunlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionrunlvl is loaded.
saFineSimProOptionrunlvlUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionsaetablefmt	string	custom	1	FineSimPro option saetablefmt: Format of SOA check output. If true, SOA results are returned in TSV files.
saFineSimProOptionsaetablefmtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionsaetablefmt is loaded.
saFineSimProOptionsaetablefmtUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionSAVEHB	string	custom		FineSimPro option SAVEHB: Saves the final-state variable values from an HB simulation.
saFineSimProOptionSAVESNINIT	string	custom		FineSimPro option SAVESNINIT: Saves the operating point at the end of Shooting Newton initialization (sninit).
saFineSimProOptionSCALE	string	custom	1.00	FineSimPro option SCALE: Sets the element scaling factor.
saFineSimProOptionSCALEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionSCALE is loaded.
saFineSimProOptionSCALEUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionSCALM	string	custom	1	FineSimPro option SCALM: Sets the model scaling factor.
saFineSimProOptionSCALMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionSCALM is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionSCALMUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionselemcachedir	string	saTestbench	<file path>	FineSimPro option s_elem_cache_dir: Controls s-parameter cache directory.
saFineSimProOptionselemcachedirUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionselemcachedir is loaded.
saFineSimProOptionSNACCURACY	string	custom	10	FineSimPro option SNACCURACY: Sets and modifies the size of timesteps.
saFineSimProOptionSNMAXITER	string	custom	40	FineSimPro option SNMAXITER: Sets the maximum number of iterations for a Shooting Newton analysis.
saFineSimProOptionTNOM	string	custom	25	FineSimPro option TNOM: Sets the reference temperature for the simulation.
saFineSimProOptionTNOMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionTNOM is loaded.
saFineSimProOptionTNOMUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionTRANFORHB	string	custom		FineSimPro option TRANFORHB: Forces HB analysis to recognize or ignore specific V/I sources.
saFineSimProOptionUNWRAP	string	custom	0	FineSimPro option UNWRAP: Sets all phase results in AC analysis to be calculated in unwrapped form.
saFineSimProOptionUNWRAPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionUNWRAP is loaded.
saFineSimProOptionUNWRAPUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOptionWARN	string	custom	0	FineSimPro option WARN: Enables or turns off SOA voltage warning message (equivalent to finesim_soa_warn)
saFineSimProOptionWARN	string	custom	0	FineSimPro option WARN: Enables or turns off SOA voltage warning message (equivalent to finesim_soa_warn).

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProOptionWARNUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProOptionWARN is loaded.
saFineSimProOptionWARNUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProOutputControlImport	string	saTestbench	Import	FineSimPro outputControl Import Setting.
saFineSimProParasiticBackAnnotationTableColumnsShown	string	user	Enabled { Type } {Format} {Back Annotate} {Skip Nets} {Min R} {Other Options} {Instance Section}	Saves columns shown in the Parasitic Back Annotation table.
saFineSimProPHASENOISEAlgorithm	string	saTestbench	Periodic AC	FineSimPro PHASENOISE method algorithm.
saFineSimProPHASENOISECarrier	string	saTestbench	1	FineSimPro PHASENOISE carrier index.
saFineSimProPHASENOISESweepPoints	string	saTestbench		FineSimPro PHASENOISE sweep number of points.
saFineSimProPHASENOISEOutputType	string	saTestbench	Voltage	FineSimPro PHASENOISE Output Type.
saFineSimProPHASENOISESweepPoints	string	saTestbench		FineSimPro PHASENOISE sweep points.
saFineSimProPHASENOISESpurious	string	saTestbench	0	FineSimPro PHASENOISE spurious analysis.
saFineSimProPHASENOISEStart	string	saTestbench		FineSimPro PHASENOISE sweep start.
saFineSimProPHASENOISEStop	string	saTestbench		FineSimPro PHASENOISE sweep stop.
saFineSimProPHASENOISESweepType	string	saTestbench	Decade	FineSimPro PHASENOISE sweep Increment Type.
saFineSimProSaveOptionsEnableEM	string	saTestbench	false	Save currents for in-design layout automation

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProSaveOptionsEnable VDRC	string	saTestbench	false	Save voltage extremes to enable V-DRC flow
saFineSimProSaveOptionsPower	string	saTestbench	0	FineSimPro: Save power signals for each device
saFineSimProSaveOptionsSave	string	saTestbench	level	FineSimPro: Save net voltages.
saFineSimProSaveOptionsSubckt Currents	string	saTestbench	selected	FineSimPro: Save subckt port currents
saFineSimProSaveOptionsSubckt CurrentsLevel	string	saTestbench	1	FineSimPro: Save subckt port currents level
saFineSimProSaveOptionsTerminalCurrents	string	saTestbench	selected	FineSimPro: Save device terminal currents
saFineSimProSaveOptionsTerminalCurrentsLevel	string	saTestbench	1	FineSimPro: Save device terminal currents level
saFineSimProSaveOptionsTerminalVoltages	string	saTestbench	selected	FineSimPro: Save device terminal voltages
saFineSimProSaveOptionsTerminalVoltagesLevel	string	saTestbench	1	FineSimPro: Save device terminal voltages level
saFineSimProSaveOptionsTotalPower	string	saTestbench	0	FineSimPro: Save total power
saFineSimProSaveOptionsVdrcTS start	string	saTestbench		Start time for VDRC voltage analysis
saFineSimProSaveOptionsVdrcTS stop	string	saTestbench		Stop time for VDRC voltage analysis
saFineSimProShowModelGroups	bool	saTestbench	false	Visibility of Model Groups table for FineSim. Valid values: true, false
saFineSimProSimulationCommand Prefix	string	user		An environment initialization command to be added to simulation commands.
saFineSimProSimulatorOptionsImport	string	saTestbench	Import	FineSimPro simulatorOptions Import Setting.
saFineSimProSNACNumPoints	string	saTestbench		FineSimPro Shooting Newton AC sweep number of points.
saFineSimProSNACPOI	string	saTestbench		FineSimPro Shooting Newton AC sweep points.
saFineSimProSNACStart	string	saTestbench		FineSimPro Shooting Newton AC sweep start.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProSNACStop	string	saTestbench		FineSimPro Shooting Newton AC sweep stop.
saFineSimProSNACSweepType	string	saTestbench	Linear	FineSimPro Shooting Newton AC sweep Increment Type.
saFineSimProSNDesignVar	string	saTestbench		FineSimPro Shooting Newton sweep design variable.
saFineSimProSNDesignVarUnits	string	saTestbench	dBm	FineSimPro Shooting Newton sweep design variable unit.
saFineSimProSNDomain	string	saTestbench	Frequency	FineSimPro Shooting Newton domain.
saFineSimProSNMaxCycles	string	saTestbench		FineSimPro Shooting Newton maximum transient init cycles.
saFineSimProSNNOISEHarmMult	string	saTestbench	1	FineSimPro Shooting Newton Noise Harmonic multiplier for Output Frequency Band.
saFineSimProSNNOISENumPoints	string	saTestbench		FineSimPro Shooting Newton Noise sweep number of points.
saFineSimProSNNOISEOFB	string	saTestbench	0	FineSimPro Shooting Newton Noise Output Band Frequency defined.
saFineSimProSNNOISEOFBCoef	string	saTestbench	-1	FineSimPro Shooting Newton Noise IFB Coefficient for OBF.
saFineSimProSNNOISEOutputType	string	saTestbench	Voltage	FineSimPro Shooting Newton Noise Output Type.
saFineSimProSNNOISEPOI	string	saTestbench		FineSimPro Shooting Newton Noise sweep points.
saFineSimProSNNOISEStart	string	saTestbench		FineSimPro Shooting Newton Noise sweep start.
saFineSimProSNNOISEStop	string	saTestbench		FineSimPro Shooting Newton Noise sweep stop.
saFineSimProSNNOISESweepType	string	saTestbench	Linear	FineSimPro Shooting Newton Noise sweep Increment Type.
saFineSimProSNNumHarms	string	saTestbench		FineSimPro Shooting Newton number of harmonics.
saFineSimProSNNumPoints	string	saTestbench		FineSimPro Shooting Newton sweep number of points.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProSNOSCDesignVar	string	saTestbench		FineSimPro Shooting Newton oscillator sweep design variable.
saFineSimProSNOSCDesignVarUnits	string	saTestbench	dBm	FineSimPro Shooting Newton oscillator sweep design variable units.
saFineSimProSNOSCDomain	string	saTestbench	Frequency	FineSimPro Shooting Newton oscillator domain.
saFineSimProSNOSCMaxCycles	string	saTestbench		FineSimPro Shooting Newton oscillator maximum transient init cycles.
saFineSimProSNOSCNHarms	string	saTestbench		FineSimPro Shooting Newton oscillator number of harmonics.
saFineSimProSNOSCNPoints	string	saTestbench		FineSimPro Shooting Newton oscillator sweep number of points.
saFineSimProSNOSCOscNode	string	saTestbench		FineSimPro Shooting Newton oscillator node.
saFineSimProSNOSCPPeriod	string	saTestbench		FineSimPro Shooting Newton oscillator time period.
saFineSimProSNOSCPPoints	string	saTestbench		FineSimPro Shooting Newton oscillator sweep points.
saFineSimProSNOSCRResolution	string	saTestbench		FineSimPro Shooting Newton Oscillator time resolution.
saFineSimProSNOSCSStart	string	saTestbench		FineSimPro Shooting Newton oscillator sweep start.
saFineSimProSNOSCStop	string	saTestbench		FineSimPro Shooting Newton oscillator sweep stop.
saFineSimProSNOSCSweep	string	saTestbench	false	FineSimPro Shooting Newton oscillator sweep.
saFineSimProSNOSCSweepType	string	saTestbench	Linear	FineSimPro Shooting Newton oscillator sweep Increment Type.
saFineSimProSNOSCTone	string	saTestbench		FineSimPro Shooting Newton approx. oscillation frequency.
saFineSimProSNOSCTrinit	string	saTestbench		FineSimPro Shooting Newton oscillator transient init time.
saFineSimProSNPeriod	string	saTestbench		FineSimPro Shooting Newton time period.
saFineSimProSNPoints	string	saTestbench		FineSimPro Shooting Newton sweep points.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProSNResolution	string	saTestbench		FineSimPro Shooting Newton time resolution.
saFineSimProSNStart	string	saTestbench		FineSimPro Shooting Newton sweep start.
saFineSimProSNStop	string	saTestbench		FineSimPro Shooting Newton sweep stop.
saFineSimProSNSweep	string	saTestbench	false	FineSimPro Shooting Newton sweep.
saFineSimProSNSweepType	string	saTestbench	Linear	FineSimPro Shooting Newton sweep Increment Type.
saFineSimProSNTone	string	saTestbench		FineSimPro Shooting Newton fundamental frequency.
saFineSimProSNTrinit	string	saTestbench		FineSimPro Shooting Newton transient init time.
saFineSimProSNXFNumPoints	string	saTestbench		FineSimPro SNXF sweep number of points.
saFineSimProSNXFOutputType	string	saTestbench	Voltage	FineSimPro SNXF Output Type.
saFineSimProSNXFPOI	string	saTestbench		FineSimPro SNXF sweep points.
saFineSimProSNXFStart	string	saTestbench		FineSimPro SNXF sweep start.
saFineSimProSNXFStop	string	saTestbench		FineSimPro SNXF sweep stop.
saFineSimProSNXFSweepType	string	saTestbench	Linear	FineSimPro SNXF sweep Increment Type.
saFineSimProSpectreEnvOptsUseCacheDirInCommandLine	bool	user	false	Add pva_output_dir and s_elem_cache_dir in command line option.
saFineSimProSpectreOptionpvaoutputdir	string	saTestbench	<file path>	FineSimProSpectre option pva_output_dir: Controls pva cache directory.
saFineSimProSpectreOptionselemcachedir	string	saTestbench	<file path>	FineSimProSpectre option s_elem_cache_dir: Controls s-parameter cache directory.
saFineSimProTemperatureImport	string	saTestbench	Import	FineSimPro temperature Import Setting.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProTRANAdvanced	string	saTestbench	false	FineSimPro Transient Advanced Settings
saFineSimProTRANFmax	string	saTestbench	0	FineSimPro Transient Noise Maximum Frequency
saFineSimProTRANFmin	string	saTestbench		FineSimPro Transient Noise Minimum Frequency
saFineSimProTRANMethod	string	saTestbench	Temp Sweep	FineSimPro Transient Advanced Method
saFineSimProTRANNOISEAutocorrelation	string	saTestbench	0	FineSimPro TRANNOISE Autocorrelation.
saFineSimProTRANNOISEDev	string	saTestbench		FineSimPro TRANNOISE Output Instance.
saFineSimProTRANNOISEFmax	string	saTestbench		FineSimPro TRANNOISE Maximum Frequency.
saFineSimProTRANNOISEFmin	string	saTestbench		FineSimPro TRANNOISE Minimum Frequency.
saFineSimProTRANNOISEMethod	string	saTestbench	SDE	FineSimPro TRANNOISE Method.
saFineSimProTRANNOISENegNode	string	saTestbench		FineSimPro TRANNOISE Output Negative Node.
saFineSimProTRANNOISEOutputType	string	saTestbench	Node	FineSimPro TRANNOISE Output Type.
saFineSimProTRANNOISEPosNode	string	saTestbench		FineSimPro TRANNOISE Output Positive Node.
saFineSimProTRANNOISESamples	string	saTestbench	1	FineSimPro TRANNOISE Number of Monte Carlo Samples.
saFineSimProTRANNOISEScale	string	saTestbench	1.0	FineSimPro TRANNOISE Scale factor.
saFineSimProTRANNOISESeed	string	saTestbench	2	FineSimPro TRANNOISE Monte Carlo Seed.
saFineSimProTRANNOISETime	string	saTestbench	All	FineSimPro TRANNOISE Time Points.
saFineSimProTRANNOISETimeval	string	saTestbench		FineSimPro TRANNOISE Time Point Value.
saFineSimProTRANScale	string	saTestbench	1.0	FineSimPro Transient Noise Scale Noise Scale

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProTRANSeed	string	saTestbench		FineSimPro Transient Noise Random Seed
saFineSimProTRANSimStart	string	saTestbench	0	FineSimPro Transient Simulation Start Time.
saFineSimProTRANStrobedelay	string	saTestbench	0	FineSimPro Transient Noise Strobe Delay
saFineSimProTRANStrobeperiod	string	saTestbench		FineSimPro Transient Noise Strobe Period
saFineSimProTRANTempValues	string	saTestbench		FineSimPro Transient Temperature
saFineSimProTRANTranNoise	string	saTestbench	0	FineSimPro Transient Noise Enable
saFineSimProVCSAnalogSimulatorPath	string	user		Path to the analog simulator executable for FineSimProVCS
saFineSimProVCSAnalysesImport	string	saTestbench	Import	FineSimProVCS analyses Import Setting.
saFineSimProVCSBlockOptionsSummary	string	saTestbench		Custom commands contents holder.
saFineSimProVCSConvergenceAidsImport	string	saTestbench	Import	FineSimProVCS convergenceAids Import Setting.
saFineSimProVCSDataImport	string	saTestbench	Include	FineSimProVCS data Import Setting.
saFineSimProVCSDefaultCornersSetup	string	saTestbench		FineSimProVCS default corners setup.
saFineSimProVCSDefaultIncludeFiles	string	saTestbench		FineSimProVCS default include files.
saFineSimProVCSDefaultModelFiles	string	saTestbench		FineSimProVCS default model files to be loaded.
saFineSimProVCSDigitalOptionbase_time	string	custom	ns	FineSimProVCS option base_time: Overrides the default TIMEBASE value in the synopsys_sim.setup file
saFineSimProVCSDigitalOptionbase_timeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionbase_time is loaded.

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProVCSDigitalOptionba setimeUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionbo undscheck	string	custom	false	FineSimProVCS option boundscheck: Does a bounds check on fixed size arrays and issues an error at compile-time
saFineSimProVCSDigitalOptionbo undscheckUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionboundsch eck is loaded.
saFineSimProVCSDigitalOptionbo undscheckUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionde bug	string	custom	post-proc ess	FineSimProVCS option debug: Specifies the debugging level for performance/control trade-offs (in order of decreasing performance and increasing control)
saFineSimProVCSDigitalOptionde bugUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptiondebug is loaded.
saFineSimProVCSDigitalOptionde bugUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptiondu mpvars	string	custom	false	FineSimProVCS option dumpvars: A substitute for entering the \$dumpvars system task, without arguments, in your Verilog code
saFineSimProVCSDigitalOptiondu mpvarsUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptiondumpvars is loaded.
saFineSimProVCSDigitalOptiondu mpvarsUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionela borationverbosity	string	custom		FineSimProVCS option elaboration_verbosity: Specifies notice, quiet or verbose mode for elaboration output file

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSDigitalOptionelaborationverbosityUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionelaborationverbosity is loaded.
saFineSimProVCSDigitalOptionelaborationverbosityUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionnoerrorOPCWM	string	custom	false	FineSimProVCS option noerrorOPCWM: Changes the inout port connection width mismatch error condition to a warning condition
saFineSimProVCSDigitalOptionnoerrorOPCWMUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionnoerrorOPCWM is loaded.
saFineSimProVCSDigitalOptionnoerrorOPCWMUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionnofalseneg	string	custom	false	FineSimProVCS option nofalseneg: Suppress the xzcheck warning message unless the value of a conditional expression ends a simulation time step with an X or Z value
saFineSimProVCSDigitalOptionnofalsenegUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionnofalseneg is loaded.
saFineSimProVCSDigitalOptionnofalsenegUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionoverride_timescale_time_precision	string	custom		FineSimProVCS option override_timescale_time_precision: Specifies the time precision portion of the override timescale (overrides `timescale compiler directives)
saFineSimProVCSDigitalOptionoverride_timescale_time_precisionUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionoverride_timescale_time_precision is loaded.
saFineSimProVCSDigitalOptionoverride_timescale_time_precisionUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSDigitalOptionoverride_timescale_time_unit	string	custom		FineSimProVCS option <code>override_timescale_time_unit</code> : Specifies the time unit portion of the override timescale (overrides <code>`timescale`</code> compiler directives)
saFineSimProVCSDigitalOptionoverride_timescale_time_unitUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference <code>saFineSimProVCSDigitalOptionoverride_timescale_time_unit</code> is loaded.
saFineSimProVCSDigitalOptionoverride_timescale_time_unitUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionplusargs	string	custom		FineSimProVCS option <code>plusargs</code> : Options for specifying user defined plusargs in a file
saFineSimProVCSDigitalOptionplusargsUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference <code>saFineSimProVCSDigitalOptionplusargs</code> is loaded.
saFineSimProVCSDigitalOptionplusargsUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionsimulation_verbosity	string	custom		FineSimProVCS option <code>simulation_verbosity</code> : Specifies quiet or verbose mode for simulation output file
saFineSimProVCSDigitalOptionsimulation_verbosityUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference <code>saFineSimProVCSDigitalOptionsimulation_verbosity</code> is loaded.
saFineSimProVCSDigitalOptionsimulation_verbosityUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptiontime_resolution	string	custom		FineSimProVCS option <code>time_resolution</code> : Overrides the default <code>TIME_RESOLUTION</code> value in the <code>synopsys_sim.setup</code> file
saFineSimProVCSDigitalOptiontime_resolutionUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference <code>saFineSimProVCSDigitalOptiontime_resolution</code> is loaded.
saFineSimProVCSDigitalOptiontime_resolutionUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProVCSDigitalOptiontimescaletimeprecision	string	custom		FineSimProVCS option timescale_time_precision: Specifies the time precision portion of the timescale for source files that do not contain the `timescale compiler directive
saFineSimProVCSDigitalOptiontimescaletimeprecisionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptiontimescaletimeprecision is loaded.
saFineSimProVCSDigitalOptiontimescaletimeprecisionUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptiontimescaletimeunit	string	custom		FineSimProVCS option timescale_time_unit: Specifies the time unit portion of the timescale for source files that do not contain the `timescale compiler directive
saFineSimProVCSDigitalOptiontimescaletimeunitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptiontimescaletimeunit is loaded.
saFineSimProVCSDigitalOptiontimescaletimeunitUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionunitimescaletimeprecision	string	custom		FineSimProVCS option unit_timescale_time_precision: Specifies the time precision portion of the default timescale (used for the compilation-unit scope)
saFineSimProVCSDigitalOptionunitimescaletimeprecisionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionunitimescaletimeprecision is loaded.
saFineSimProVCSDigitalOptionunitimescaletimeprecisionUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionunitimescaletimeunit	string	custom		FineSimProVCS option unit_timescale_time_unit: Specifies the time unit portion of the default timescale (used for the compilation-unit scope)

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSDigitalOptionunitimescaletimeunitUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionunitimescaletimeunit is loaded.
saFineSimProVCSDigitalOptionunitimescaletimeunitUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionvcsflushall	string	custom	false	FineSimProVCS option vcs_flush_all: Increases the frequency of dumping all log file, vcd files and files opened by \$fopen
saFineSimProVCSDigitalOptionvcsflushallUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionvcsflushall is loaded.
saFineSimProVCSDigitalOptionvcsflushallUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionvcsflushdump	string	custom	false	FineSimProVCS option vcs_flush_dump: Increases the frequency of dumping all vcd files
saFineSimProVCSDigitalOptionvcsflushdumpUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionvcsflushdump is loaded.
saFineSimProVCSDigitalOptionvcsflushdumpUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionvcsflushfopen	string	custom	false	FineSimProVCS option vcs_flush_fopen: Increases the frequency of dumping all files opened by \$fopen
saFineSimProVCSDigitalOptionvcsflushfopenUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionvcsflushfopen is loaded.
saFineSimProVCSDigitalOptionvcsflushfopenUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionvcsflushlog	string	custom	false	FineSimProVCS option vcs_flush_log: Increases the frequency of dumping compilation and simulation log file

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSDigitalOptionvcs flushlogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionvcsflushlog is loaded.
saFineSimProVCSDigitalOptionvcs flushlogUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionvcs initreg	string	custom		FineSimProVCS option vcs_initreg: Initialize all state variables to random values
saFineSimProVCSDigitalOptionvcs initregseed	string	custom		FineSimProVCS option vcs_initreg_seed: Seed value for vcs_initreg
saFineSimProVCSDigitalOptionvcs initregseedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionvcsinitregseed is loaded.
saFineSimProVCSDigitalOptionvcs initregseedUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionvcs initregUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionvcsinitreg is loaded.
saFineSimProVCSDigitalOptionvcs initregUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionvp dnocompress	string	custom	false	FineSimProVCS option vpdnocompress: Do not compress data written to VPD File
saFineSimProVCSDigitalOptionvp dnocompressUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionvpdnocompress is loaded.
saFineSimProVCSDigitalOptionvp dnocompressUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionvp dnostrengths	string	custom	false	FineSimProVCS option vpdnostrengths: Do not write signal strength data to VPD File
saFineSimProVCSDigitalOptionvp dnostrengthsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionvpdnostrengths is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSDigitalOptionvp dnostrengthsUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSDigitalOptionxz check	string	custom	false	FineSimProVCS option xzcheck: Displays a warning message every time VCS evaluates a conditional expression to have an X or Z value
saFineSimProVCSDigitalOptionxz checkUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSDigitalOptionxzcheck is loaded.
saFineSimProVCSDigitalOptionxz checkUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSEnableSimulato rResultsXML	bool	user	false	Enables FineSimProVCS to write the resulting XML file. Valid values: true, false
saFineSimProVCSEnvOptsDigital OutputDataFormat	string	saTestbe nch	fsdb	Digital output data format.
saFineSimProVCSEnvOptsMerged File	bool	saTestbe nch	true	Enable merged results file.
saFineSimProVCSEnvOptsNumPr ocesses	string	saTestbe nch	1	Number of threads
saFineSimProVCSEnvOptsProjCfg	string	saTestbe nch		Project Config File
saFineSimProVCSEnvOptsStopVi ewList	string	saTestbe nch	hspice hspiceD functional behavioral symbol	FineSimProVCS Stop View List for netlister.
saFineSimProVCSEnvOptsSwitch ViewList	string	saTestbe nch	hspice hspiceD schematic verilog functional behavioral vhdl_config vhdl_spice veriloga verilogams	FineSimProVCS Switch View List for netlister.
saFineSimProVCSEnvOptsUseCa cheDirInCommandLine	bool	user	false	Add pva_output_dir and s_elem_cache_dir in command line option.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSIncludeSchematicNetlist	bool	user	true	Copy (true) or .include (false) the structural netlist in the final netlist. Valid values: true, false
saFineSimProVCSLibrariesImport	string	saTestbench	Import	FineSimProVCS libraries Import Setting.
saFineSimProVCSMeasuresImport	string	saTestbench	Import	FineSimProVCS measures Import Setting.
saFineSimProVCSModelGroups	string	saTestbench		Model groups for FineSimProVCS
saFineSimProVCSModelGroupsCheckBox	bool	saTestbench	false	Visibility of Model Groups table for FineSimProVCS Valid values: true, false
saFineSimProVCSModelsImport	string	saTestbench	Import	FineSimProVCS models Import Setting.
saFineSimProVCSMonteCarloIop	string	saTestbench	0	Use independent parallel simulation.
saFineSimProVCSMonteCarloIterList	string	saTestbench	???	List of iterations.
saFineSimProVCSMonteCarloLHSReplicates	string	saTestbench	1	Runs replicates of Latin Hypercube samples.
saFineSimProVCSMonteCarloLHSSampleSize	string	saTestbench	???	LHS sampling method sample size.
saFineSimProVCSMonteCarloNumPl	string	saTestbench	1	Number of Independent parallel simulation processes.
saFineSimProVCSMonteCarloNumIter	string	saTestbench	10	Number of iterations for Monte Carlo analysis.
saFineSimProVCSMonteCarloOFATIntervals	string	saTestbench	1	Generate 2n+1 equally spaced samples for each OFAT variable.
saFineSimProVCSMonteCarloOFATOneSided	bool	saTestbench	false	Enable/disable one-sided intervals
saFineSimProVCSMonteCarloOFATOneSidedValue	string	saTestbench	0.5	Generate 2n+1 equally spaced samples for each OFAT variable
saFineSimProVCSMonteCarloSamplingMethod	string	saTestbench	Sobol	Enables advanced sampling methods.
saFineSimProVCSMonteCarloSeed	string	saTestbench	1	Starting seed for the random-number generator in Monte Carlo analysis.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSMonteCarloSigmaScale	string	saTestbench	2.0	Sigma Amplification Factor for High Sigma Applications
saFineSimProVCSMonteCarloStarIter	string	saTestbench	1	Starting iteration number for Monte Carlo analysis.
saFineSimProVCSMonteCarloUseIterList	string	saTestbench	0	Use iteration list.
saFineSimProVCSMonteCarloUseRandomSeed	string	saTestbench	0	Starting seed for the random-number generator in Monte Carlo analysis.
saFineSimProVCSMonteCarloUseSigmaScaling	string	saTestbench	0	Uses Sigma Amplification for High Sigma Applications
saFineSimProVCSMonteCarloVariationIncludeOrExclude	string	saTestbench	Include	Whether statistical variation is to be applied or not applied to the specified instances/cells
saFineSimProVCSMonteCarloVariationInstanceOrCellList	string	saTestbench		List of instances or cells for which statistical variation is to be applied/not applied
saFineSimProVCSMonteCarloVariationObjectType	string	saTestbench	Instances	Object type (instances or cells) for which statistical variation is to be applied/not applied
saFineSimProVCSOptionfinesimmcnominalsimulation	string	saTestbench		FineSimProVCS option finesim_mc_nominal_simulation: Sets the behavior of simple random sampling (SRS) for the first Monte Carlo sweep.
saFineSimProVCSOptionfinesimmcnominalsimulationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimmcnominalsimulation is loaded.
saFineSimProVCSMsOptsConnectModulesInstallDirFilePatterns	string	user	snps_cm_*.vams	Installed Connect Modules File Patterns for FineSimProVCS.
saFineSimProVCSMsOptsConnectModulesUserDir	string	user		User Connect Modules and Rules Directory for FineSimProVCS.
saFineSimProVCSMsOptsConnectModulesUserDirFilePatterns	string	user		User Connect Modules File Patterns for FineSimProVCS.
saFineSimProVCSMsOptsConnectRuleDefault	string	user	1 global {} voltage {}	Connect Rule Default for FineSimProVCS.
saFineSimProVCSMsOptsConnectRulesInstallDirFilePatterns	string	user	snps_cr_*.vams	Installed Connect Rules File Patterns for FineSimProVCS.
saFineSimProVCSMsOptsConnectRulesUserDirFilePatterns	string	user		User Connect Rules File Patterns for FineSimProVCS.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSMsOptsD2AInterfaceElementDefault	string	user	false {} {} 0.1n midPoint 3.0 0 v net	D2A Interface Element Default for FineSimProVCS.
saFineSimProVCSMsOptsDisciplineResolutionDefault	string	user	basic	Net Discipline Resolution Default for FineSimProVCS
saFineSimProVCSMsOptsE2NInterfaceElementDefault	string	user	th_wire {} 1 1 1k 1 {}	D2A Interface Element Default for FineSimProVCS.
saFineSimProVCSMsOptsE2RInterfaceElementDefault	string	user	false "" "" 1 "" "" net	E2R Interface Element Default for FineSimProVCS.
saFineSimProVCSMsOptsEnableAMSIEReport	bool	user	false	Enables printing the connect module report into the log file for FineSimProVCS. Valid values: true, false
saFineSimProVCSMsOptsN2EInterfaceElementDefault	string	user	th_wire {} 1 10p 1 50 1G {} 1	E2R Interface Element Default for FineSimProVCS.
saFineSimProVCSMsOptsNetDisciplineDefault	string	user	ddiscrete	Net Discipline Default for FineSimProVCS
saFineSimProVCSMsOptsR2EInterfaceElementDefault	string	user	false "" 1 "" net	R2E Interface Element Default for FineSimProVCS.
saFineSimProVCSOptionagepwinteg	string	saTestbench	0	FineSimProVCS option age_pw_integ: Controls new mosramt0.
saFineSimProVCSOptionagepwintegUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionagepwinteg is loaded.
saFineSimProVCSOptionagepwintegUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionASPEC	string	custom	0	FineSimProVCS option ASPEC: Sets ASPEC compatibility mode for spice characterization.
saFineSimProVCSOptionASPECUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionASPEC is loaded.
saFineSimProVCSOptionASPECUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionAUTOSTOP	string	custom	0	FineSimProVCS option AUTOSTOP: Stops a transient analysis.
saFineSimProVCSOptionAUTOSTOPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionAUTOSTOP is loaded.
saFineSimProVCSOptionAUTOSTOPUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionCAPTAB	string	custom	0	FineSimProVCS option CAPTAB: Add up all the capacitances attached to a node and outputs a .cap file.
saFineSimProVCSOptionCAPTABUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionCAPTAB is loaded.
saFineSimProVCSOptionCAPTABUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionCSHUNT	string	custom	0	FineSimProVCS option CSHUNT: Add capacitance from each node to ground.
saFineSimProVCSOptionCSHUNTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionCSHUNT is loaded.
saFineSimProVCSOptionCSHUNTUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionDCAP	string	custom	2	FineSimProVCS option DCAP: Specifies equations used to calculate depletion capacitance for Level 1 and 3 diodes and BJTs.
saFineSimProVCSOptionDCAPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionDCAP is loaded.
saFineSimProVCSOptionDCAPUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionDCIC	string	custom	1	FineSimProVCS option DCIC: Controls whether or not .IC is used for DC analysis.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionDCICUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionDCIC is loaded.
saFineSimProVCSOptionDCICUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionDEFAD	string	custom	0	FineSimProVCS option DEFAD: Sets the default value for MOSFET drain diffusion area.
saFineSimProVCSOptionDEFADUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionDEFAD is loaded.
saFineSimProVCSOptionDEFADUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionDEFAS	string	custom	0	FineSimProVCS option DEFAS: Sets the default value for MOSFET source diffusion area.
saFineSimProVCSOptionDEFASUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionDEFAS is loaded.
saFineSimProVCSOptionDEFASUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionDEFL	string	custom	1e-4m	FineSimProVCS option DEFL: Sets the default value for MOS channel length.
saFineSimProVCSOptionDEFLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionDEFL is loaded.
saFineSimProVCSOptionDEFLUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionDEFNRD	string	custom	0	FineSimProVCS option DEFNRD: Sets the number of squares for the drain resistor on a MOSFET.
saFineSimProVCSOptionDEFNRDUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionDEFNRD is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionDEFNRD UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionDEFNRS	string	custom	0	FineSimProVCS option DEFNRS: Sets the number of squares for the source resistor on a MOSFET.
saFineSimProVCSOptionDEFNRS UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionDEFNRS is loaded.
saFineSimProVCSOptionDEFNRS UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionDEFDPD	string	custom	0	FineSimProVCS option DEFDPD: Sets the default value for the MOSFET drain diffusion perimeter.
saFineSimProVCSOptionDEFDPD ncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionDEFDPD is loaded.
saFineSimProVCSOptionDEFDPD ncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionDEFPS	string	custom	0	FineSimProVCS option DEFPS: Sets the default value for the MOSFET source diffusion perimeter.
saFineSimProVCSOptionDEFPSU ncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionDEFPS is loaded.
saFineSimProVCSOptionDEFPSU ncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionDEFW	string	custom	1e-4m	FineSimProVCS option DEFW: Sets default value for MOS channel width.
saFineSimProVCSOptionDEFWUn checkLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionDEFW is loaded.
saFineSimProVCSOptionDEFWUn checkLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProVCSOptionerrpreset	string	custom	donotoverride	FineSimProVCS option errpreset: Selects a reasonable collection of parameter settings: liberal, moderate, or conservative.
saFineSimProVCSOptionerrpresetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionerrpreset is loaded.
saFineSimProVCSOptionerrpresetUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimacatdiff	string	custom	0	FineSimProVCS option finesim_ac_at_diff_t: Determines whether or not small signal analyses like ac and noise are run at times specified in .OP statement.
saFineSimProVCSOptionfinesimacatdiffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimacatdiff is loaded.
saFineSimProVCSOptionfinesimacatdiffUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimacceleraterom	string	custom	0	FineSimProVCS option finesim_accelerate_rom: Improves performance for the simulation of ROM circuits.
saFineSimProVCSOptionfinesimaccelerateromUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimaccelerate rom is loaded.
saFineSimProVCSOptionfinesimaccelerateromUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimallowdupport	string	custom	1	FineSimProVCS option finesim_allow_dup_port: When set to 1, allows duplicated ports.
saFineSimProVCSOptionfinesimallowdupportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimallowdup port is loaded.
saFineSimProVCSOptionfinesimallowdupportUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimassert	string	saTestbench	0	FineSimProVCS option finesim_assert: Control the effort applied to assert checks
saFineSimProVCSOptionfinesimassertUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimassert is loaded.
saFineSimProVCSOptionfinesimbisectionoutput	string	custom	1	FineSimProVCS option finesim_bisection_output: When set to 1 FinesimPro will merge all output data of one complete bisection progress to one file.
saFineSimProVCSOptionfinesimbisectionoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimbisectionoutput is loaded.
saFineSimProVCSOptionfinesimbisectionoutputUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimbisectionsummary	string	custom	1	FineSimProVCS option finesim_bisection_summary
saFineSimProVCSOptionfinesimbisectionsummaryUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimbisectionsummary is loaded.
saFineSimProVCSOptionfinesimbisectionsummaryUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimbytol	string	custom	1mV	FineSimProVCS option finesim_bytol: Sets the voltage value to use in determining whether a MOS is latent. The default value is dependent on finesim_mode.
saFineSimProVCSOptionfinesimbytolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimbytol is loaded.
saFineSimProVCSOptionfinesimbytolUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimcheckmodel	string	custom	0	FineSimProVCS option finesim_check_model

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimcheckmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimcheckmodel is loaded.
saFineSimProVCSOptionfinesimcheckmodelUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimcheckvth	string	custom	1	FineSimProVCS option finesim_check_vth: Specifies whether to use finesim_goff (0) or vth (1) to determine the ON/OFF state.
saFineSimProVCSOptionfinesimcheckvthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimcheckvth is loaded.
saFineSimProVCSOptionfinesimcheckvthUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimchgtol	string	custom	1e-15	FineSimProVCS option finesim_chgtol: Sets absolute charge tolerance during charge-based 1teq time step algorithm.
saFineSimProVCSOptionfinesimchgtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimchgtol is loaded.
saFineSimProVCSOptionfinesimchgtolUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimchkdevport	string	custom	0	FineSimProVCS option finesim_chk_devport: Checks device port name during wildcard matching of .probe statement.
saFineSimProVCSOptionfinesimchkdevportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimchkdevport is loaded.
saFineSimProVCSOptionfinesimchkdevportUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimchkdiskpace	string	custom	0	FineSimProVCS option finesim_chk_disk_space: Checks and reports available disk space in every tflush time period.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimchkdiskspaceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimchkdiskspace is loaded.
saFineSimProVCSOptionfinesimchkdiskspaceUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimchkexprprintall	string	saTestbench	0	FineSimProVCS option finesim_chkexpr_print_all: When set to 1, invalid assert checks are also dumped into csv file
saFineSimProVCSOptionfinesimchkexprprintallUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimchkexprprintall is loaded.
saFineSimProVCSOptionfinesimchkznodenvth	string	custom	0	FineSimProVCS option finesim_chkznodenvth: Sets the Vth value in calculating the ON/OFF state of MOSFET.
saFineSimProVCSOptionfinesimchkznodenvthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimchkznodenvth is loaded.
saFineSimProVCSOptionfinesimchkznodenvthUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimclampVerilog	string	custom	0	FineSimProVCS option finesim_clampVerilog: Clamps stamped conductance value to finesim_gmax.
saFineSimProVCSOptionfinesimclampVerilogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimclampVerilog is loaded.
saFineSimProVCSOptionfinesimclampVerilogUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimcmodel	string	custom		FineSimProVCS option finesim_c_model: Specifies a C Model.
saFineSimProVCSOptionfinesimcmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimcmodel is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimc modelUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimco nvlevel	string	custom	0	FineSimProVCS option finesim_convlevel: Determines how FineSim attempts to solve the "time step too small" error.
saFineSimProVCSOptionfinesimco nvlevelUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimconvlevel is loaded.
saFineSimProVCSOptionfinesimco nvlevelUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimdc alg	string	custom	0	FineSimProVCS option finesim_dcalg: Sets algorithm for DC convergence.
saFineSimProVCSOptionfinesimdc algUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdcalg is loaded.
saFineSimProVCSOptionfinesimdc algUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimdc effort	string	custom	1	FineSimProVCS option finesim_dceffort: Controls effort applied for DC convergence.
saFineSimProVCSOptionfinesimdc effortUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdceffort is loaded.
saFineSimProVCSOptionfinesimdc effortUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimde lmax	string	custom		FineSimProVCS option finesim_delmax: Sets maximum value of internal time step in simulation.
saFineSimProVCSOptionfinesimde lmaxUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdelmax is loaded.
saFineSimProVCSOptionfinesimde lmaxUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimdetectlvddstatic	string	custom		FineSimProVCS option finesim_detect_lvdd_static: Clamps stamped conductance value to finesim_gmax.
saFineSimProVCSOptionfinesimdetectlvddstaticUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdetectlvddstatic is loaded.
saFineSimProVCSOptionfinesimdetectlvddstaticUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimdiagba	string	saTestbench	0	FineSimProVCS option finesim_diag_ba: When set to 1, parastic back annotation log file will separate for better diagnostics.
saFineSimProVCSOptionfinesimdiagbaUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdiagba is loaded.
saFineSimProVCSOptionfinesimdiagbaUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimdoubleprecisionoutput	string	custom	0	FineSimProVCS option finesim_double_precision_output: Changes output file value from 4 bytes to 8 bytes.
saFineSimProVCSOptionfinesimdoubleprecisionoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdoubleprecisionoutput is loaded.
saFineSimProVCSOptionfinesimdoubleprecisionoutputUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimdpf	string	custom		FineSimProVCS option finesim_dpf: Specifies the DPF file that contains the extracted device parameter data.
saFineSimProVCSOptionfinesimdpfadddevUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdpfadddev is loaded.
saFineSimProVCSOptionfinesimdpfadddevUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimdp fhdivUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdpfhdiv is loaded.
saFineSimProVCSOptionfinesimdp fhdivUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimdp fmodule	string	custom		FineSimProVCS option finesim_dpffmodule: Specifies the module for DPF back-annotation.
saFineSimProVCSOptionfinesimdp fmoduleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdpfmodule is loaded.
saFineSimProVCSOptionfinesimdp fmoduleUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimdp fmosonly	string	custom		FineSimProVCS option finesim_dpffmos_only: Specifies whether to back-annotate all devices or only MOSFET devices.
saFineSimProVCSOptionfinesimdp fmosonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdpfmosonly is loaded.
saFineSimProVCSOptionfinesimdp fmosonlyUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimdp fprefix	string	custom		FineSimProVCS option finesim_dpffprefix: Lists the prefixes that should be removed from DPF device names.
saFineSimProVCSOptionfinesimdp fprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdpffprefix is loaded.
saFineSimProVCSOptionfinesimdp fprefixUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimdp fscale	string	custom	1	FineSimProVCS option finesim_dpffscale: Sets the scale for devices in the DPF file.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimdpfscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdpfscale is loaded.
saFineSimProVCSOptionfinesimdpfscaleUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimdpfsuffix	string	custom		FineSimProVCS option finesim_dpfsuffix: Defines the suffix in a DPF file.
saFineSimProVCSOptionfinesimdpfsuffixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdpfsuffix is loaded.
saFineSimProVCSOptionfinesimdpfsuffixUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimdpfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdpf is loaded.
saFineSimProVCSOptionfinesimdpfUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimdvmx	string	custom		FineSimProVCS option finesim_dvmx: Sets the maximum voltage change of a node in a single time step.
saFineSimProVCSOptionfinesimdvmxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimdvmx is loaded.
saFineSimProVCSOptionfinesimdvmxUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimfcapmin	string	custom	0	FineSimProVCS option finesim_fcamin: Converts a small coupling capacitance into two grounded capacitance values.
saFineSimProVCSOptionfinesimfcapminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimfcapmin is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimfcapminUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimfcapmodel	string	custom	1	FineSimProVCS option finesim_fcmodel: Controls the modeling of floating capacitances.
saFineSimProVCSOptionfinesimfcapmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimfcapmodel is loaded.
saFineSimProVCSOptionfinesimfcapmodelUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimflatsize	string	custom	7	FineSimProVCS option finesim_flatsize: Sets a threshold to flatten subcircuits before partitioning starts.
saFineSimProVCSOptionfinesimflatsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimflatsize is loaded.
saFineSimProVCSOptionfinesimflatsizeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimfloatinggategshunt	string	custom	0	FineSimProVCS option finesim_floating_gate_gshunt: Adds a conductance between floating gate node and ground.
saFineSimProVCSOptionfinesimfloatinggategshuntUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimfloatinggategshunt is loaded.
saFineSimProVCSOptionfinesimfloatinggategshuntUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimfscauto detect	string	custom		FineSimProVCS option finesim_fsc_auto_detect: Voltage levels corresponding to logic levels or setting the VDD for a model will be handled automatically using this option.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimfscautodetectUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimfscautodetect is loaded.
saFineSimProVCSOptionfinesimfscautodetectUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimfscvdd	string	custom		FineSimProVCS option finesim_fsc_vdd: Specifies the supply voltage for the C-model interface.
saFineSimProVCSOptionfinesimfscvddUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimfscvdd is loaded.
saFineSimProVCSOptionfinesimfscvddUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimfsdblimit	string	custom	0	FineSimProVCS option finesim_fsdb_limit: Specifies a size limit for fsdb files.
saFineSimProVCSOptionfinesimfsdblimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimfsdblimit is loaded.
saFineSimProVCSOptionfinesimfsdblimitUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimfsdbsplittime	string	custom		FineSimProVCS option finesim_fsdb_split_time: Specifies to split FSDB based on the time values.
saFineSimProVCSOptionfinesimfsdbsplittime	string	custom		FineSimProVCS option finesim_fsdb_split_time: Specifies to split FSDB based on the time values.
saFineSimProVCSOptionfinesimfsdbsplittimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimfsdbsplittime is loaded.
saFineSimProVCSOptionfinesimfsdbsplittimeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimge nacop	string	custom	1	FineSimProVCS option finesim_gen_ac_op: Determines if binary files or ASCII .ic files are generated for each time point in .OP statement.
saFineSimProVCSOptionfinesimge nacop	string	custom	1	FineSimProVCS option finesim_gen_ac_op: Determines if binary files or ASCII .ic files are generated for each time point in .OP statement
saFineSimProVCSOptionfinesimge nacopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimgenacop is loaded.
saFineSimProVCSOptionfinesimge nacopUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimge nicop	string	custom	0	FineSimProVCS option finesim_gen_ic_op: Generates the .op file when it is not created by default.
saFineSimProVCSOptionfinesimge nicopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimgenicop is loaded.
saFineSimProVCSOptionfinesimge nicopUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesim gic	string	custom	1e10	FineSimProVCS option finesim_gic: Sets conductance value of the resistor in the Norton-type voltage source.
saFineSimProVCSOptionfinesimgi cUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimgic is loaded.
saFineSimProVCSOptionfinesimgi cUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimg max	string	custom	100	FineSimProVCS option finesim_gmax: Clamps the stamped conductance value to finesim_gmax.
saFineSimProVCSOptionfinesimg maxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimgmax is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimg maxUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimg off	string	custom		FineSimProVCS option finesimg_goff: Works with the .CHKZNODE statement to determine if a MOSFET is on or off.
saFineSimProVCSOptionfinesimgo ffUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimgoff is loaded.
saFineSimProVCSOptionfinesimgo ffUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimhs tolscale	string	custom	1	FineSimProVCS option finesim_hstolscale: Sets a multiplier applied to all internal tolerance values for subcircuits that will be simulated with the hiersim method.
saFineSimProVCSOptionfinesimhs tolscaleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimhstolscale is loaded.
saFineSimProVCSOptionfinesimhs tolscaleUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimid enticalmcinstancefile	string	custom		FineSimProVCS option finesim_identical_mc_instance_file: Generate the same random number sequence for the Monte Carlo Simulation.
saFineSimProVCSOptionfinesimid enticalmcinstancefileUncheckLocal ized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimidenticalmcinstancefile is loaded.
saFineSimProVCSOptionfinesimid enticalmcinstancefileUncheckLocal ized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimig norechkfuncerror	string	custom	0	FineSimProVCS option finesim_ignore_chkfunc_error: Continues the simulation with a warning instead of an error and exiting.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimignorechkfuncerrorUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimignorechkfuncerror is loaded.
saFineSimProVCSOptionfinesimignorechkfuncerrorUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimignoresubblkoptionerror	string	custom	0	FineSimProVCS option finesim_ignore_subblk_option_error:
saFineSimProVCSOptionfinesimignoresubblkoptionerrorUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimignoresubblkoptionerror is loaded.
saFineSimProVCSOptionfinesimignoresubblkoptionerrorUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimiovecabsvalue	string	custom	0	FineSimProVCS option finesim_iovec_abs_value: Treats all the time values in the vector file as absolute time.
saFineSimProVCSOptionfinesimiovecabsvalueUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimiovecabsvalue is loaded.
saFineSimProVCSOptionfinesimiovecabsvalueUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimiovecvih	string	custom		FineSimProVCS option finesim_iovec_vih: Sets the logiclv outside of a vector file.
saFineSimProVCSOptionfinesimiovecvihUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimiovecvih is loaded.
saFineSimProVCSOptionfinesimiovecvihUncheckedLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimiovecvil	string	custom		FineSimProVCS option finesim_iovec_vil: Sets the logiclv outside of a vector file.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimiovecvilUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimiovecvil is loaded.
saFineSimProVCSOptionfinesimiovecvilUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimiprbtol	string	custom	1e-12	FineSimProVCS option finesim_iprbtol: Sets the current tolerance for the current print out.
saFineSimProVCSOptionfinesimiprbtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimiprbtol is loaded.
saFineSimProVCSOptionfinesimiprbtolUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimiremrms	string	custom	0	FineSimProVCS option finesim_irem_rms: Calculate RMS value of the current and report it as AC current.
saFineSimProVCSOptionfinesimiremrmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimiremrms is loaded.
saFineSimProVCSOptionfinesimiremrmsUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimkeep0vdcvs	string	custom	0	FineSimProVCS option finesim_keep_0v_dcvs: Keeps 0v DC voltage sources in the simulation database.
saFineSimProVCSOptionfinesimkeep0vdcvsop	string	custom	0	FineSimProVCS option finesim_keep_0v_dcvs_op: Keeps 0v DC voltage sources for .op analysis.
saFineSimProVCSOptionfinesimkeep0vdcvsopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimkeep0vdcvsop is loaded.
saFineSimProVCSOptionfinesimkeep0vdcvsopUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimkeep0vdcvsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimkeep0vdcvs is loaded.
saFineSimProVCSOptionfinesimkeep0vdcvsUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimkeepzeroparms	string	custom	0	FineSimProVCS option finesim_keepzeroparms: Use zero values for PS, PD, AS, and AD parameters for BSIM models.
saFineSimProVCSOptionfinesimkeepzeroparmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimkeepzeroparms is loaded.
saFineSimProVCSOptionfinesimkeepzeroparmsUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimleakagemode	string	custom	0	FineSimProVCS option finesim_leakage_mode: Uses more conservative leakage tolerances for better accuracy
saFineSimProVCSOptionfinesimleakagemodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimleakagemode is loaded.
saFineSimProVCSOptionfinesimleakagemodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimloadmodel	string	custom	<file path>	FineSimProVCS option finesim_loadmodel: Sets the capacitive load model that a partition output drives.
saFineSimProVCSOptionfinesimloadmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimloadmodel is loaded.
saFineSimProVCSOptionfinesimloadmodelUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimmaxicout	string	custom	1000000	FineSimProVCS option finesim_maxicout: Sets maximum number of node voltages included in the .ic file.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimm axicoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimmmaxicout is loaded.
saFineSimProVCSOptionfinesimm axicoutUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimm axwidthtol	string	custom		FineSimProVCS option finesim_max_width_tol: Sets tolerance range for transistor width when it exceeds max. defined width.
saFineSimProVCSOptionfinesimm axwidthtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimmmaxwidthtol is loaded.
saFineSimProVCSOptionfinesimm axwidthtolUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimm cbrief	string	custom	1	FineSimProVCS option finesim_mcbrief: Limits Monte Carlo information in log file.
saFineSimProVCSOptionfinesimm cbriefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimmcbrief is loaded.
saFineSimProVCSOptionfinesimm cbriefUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimm easout	string	custom	0	FineSimProVCS option finesim_measout: Controls the measurement file format.
saFineSimProVCSOptionfinesimm easoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimmeasout is loaded.
saFineSimProVCSOptionfinesimm easoutUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimm ethod	string	custom	TRAP	FineSimProVCS option finesim_method: Sets the numerical integration method used during a transient analysis.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimmethod is loaded.
saFineSimProVCSOptionfinesimmethodUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimmode	string	custom	spicead	FineSimProVCS option finesim_mode: Sets the Simulation mode.
saFineSimProVCSOptionfinesimodel	string	custom	2	FineSimProVCS option finesim_model: Sets the modeling method of the MOSFETs.
saFineSimProVCSOptionfinesimodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimodel is loaded.
saFineSimProVCSOptionfinesimodelUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimodelverificationmode	string	custom	0	FineSimProVCS option finesim_model_verification_mode: Use tighter simulation settings for simulations with model qualification.
saFineSimProVCSOptionfinesimodelverificationmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimodelverificationmode is loaded.
saFineSimProVCSOptionfinesimodelverificationmodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimode is loaded.
saFineSimProVCSOptionfinesimodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimmparcheck	string	custom	0	FineSimProVCS option finesim_mparcheck: Determines if MOSFET model parameters will be checked.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimmparcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimmparcheck is loaded.
saFineSimProVCSOptionfinesimmparcheckUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimnegres	string	custom	1	FineSimProVCS option finesim_negres: Keeps negative resistors in the netlist.
saFineSimProVCSOptionfinesimnegres	string	custom	1	FineSimProVCS option finesim_negres: Keeps negative resistors in the netlist.
saFineSimProVCSOptionfinesimnegresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimnegres is loaded.
saFineSimProVCSOptionfinesimnegresUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimnoiseoff	string	custom	0	FineSimProVCS option finesim_noise_off: Disable noise generation
saFineSimProVCSOptionfinesimnoiseoff	string	custom	0	FineSimProVCS option finesim_noise_off: Disable noise generation.
saFineSimProVCSOptionfinesimnoiseoffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimnoiseoff is loaded.
saFineSimProVCSOptionfinesimnoiseoffUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimnoiseon	string	custom	0	FineSimProVCS option finesim_noise_on: Enable noise generation
saFineSimProVCSOptionfinesimnoiseon	string	custom	0	FineSimProVCS option finesim_noise_on: Enable noise generation.
saFineSimProVCSOptionfinesimnoiseonUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimnoiseon is loaded.
saFineSimProVCSOptionfinesimnoiseonUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimnummeaslog	string	custom		FineSimProVCS option finesim_num_meas_log: Limits number of measurement results output to the screen and log file.
saFineSimProVCSOptionfinesimnummeaslogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimnummeaslog is loaded.
saFineSimProVCSOptionfinesimnummeaslogUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimnummeasperline	string	custom	0	FineSimProVCS option finesim_num_meas_per_line: Outputs measurement values on multiple lines.
saFineSimProVCSOptionfinesimnummeasperlineUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimnummeasperline is loaded.
saFineSimProVCSOptionfinesimnummeasperlineUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimoutputframetype	string	custom	1	FineSimProVCS option finesim_output_frame_type: Defines the naming convention for output files with the netlist has an .alter and/or .temp sweep parameter.
saFineSimProVCSOptionfinesimoutputframetypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimoutputframetype is loaded.
saFineSimProVCSOptionfinesimoutputframetypeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimoutputrange	string	custom		FineSimProVCS option finesim_output_range: Limits output of transient results of waveforms to the waveform file.
saFineSimProVCSOptionfinesimoutputrangeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimoutputrange is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimoutputrangeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimpartition	string	custom		FineSimProVCS option finesim_partition: Specifies how partitioning is done.
saFineSimProVCSOptionfinesimpartitionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimpartition is loaded.
saFineSimProVCSOptionfinesimpartitionUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimpostl	string	custom	0	FineSimProVCS option finesim_postl: Sets the level of acceleration to use when performing post-layout analog simulation on RC-extracted circuits.
saFineSimProVCSOptionfinesimpostl	string	custom	0	FineSimProVCS option finesim_postl: Sets the level of acceleration to use when performing post-layout analog simulation on RC-extracted circuits.
saFineSimProVCSOptionfinesimpostlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimpostl is loaded.
saFineSimProVCSOptionfinesimpostlUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimprbexprvar	string	custom	1	FineSimProVCS option finesim_prbexprvar: Determines whether to make any signals in the expression of .probe out.
saFineSimProVCSOptionfinesimprbexprvarUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimprbexprvar is loaded.
saFineSimProVCSOptionfinesimprbexprvarUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimprbport	string	custom	1	FineSimProVCS option finesim_prbport: Determines whether port voltages will be probed, depending on tolerance.

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimprbportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimprbport is loaded.
saFineSimProVCSOptionfinesimprbportUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimprlayoutmodels	string	custom	0	FineSimProVCS option finesim_prelayout_models: Sets which model FineSim should use.
saFineSimProVCSOptionfinesimprlayoutmodelsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimprlayoutmodels is loaded.
saFineSimProVCSOptionfinesimprlayoutmodelsUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimprintmaxconnode	string	custom	20	FineSimProVCS option finesim_print_max_con_node: Identifies nodes with greatest number of connections for connectivity report.
saFineSimProVCSOptionfinesimprintmaxconnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimprintmaxconnode is loaded.
saFineSimProVCSOptionfinesimprintmaxconnodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimprintperiod	string	custom		FineSimProVCS option finesim_print_period: Defines the fixed interval at which the .print command will print to the output file.
saFineSimProVCSOptionfinesimprintperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimprintperiod is loaded.
saFineSimProVCSOptionfinesimprintperiodUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimprinttoprobe	string	custom	0	FineSimProVCS option finesim_print_to_probe: Converts all .print statements to .probe statements.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimpri nttoprobeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimpri nttoprobe is loaded.
saFineSimProVCSOptionfinesimpri nttoprobeUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimpr obepassivedevice	string	custom	0	FineSimProVCS option finesim_probe_passive_device: Probes passive devices like R/C..
saFineSimProVCSOptionfinesimpr obepassivedeviceUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimpr obepassivedevice is loaded.
saFineSimProVCSOptionfinesimpr obepassivedeviceUncheckLocali zed	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimpr ofile	string	custom	1	FineSimProVCS option finesim_profile: Generates profile data in a file after transient analysis..
saFineSimProVCSOptionfinesimpr ofileUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimpr ofile is loaded.
saFineSimProVCSOptionfinesimpr ofileUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimp wrblock	string	custom	1	FineSimProVCS option finesim_pwrblock: Detects the parasitics in the power network.
saFineSimProVCSOptionfinesimp wrblock	string	custom	1	FineSimProVCS option finesim_pwrblock: Detects the parasitics in the power network.
saFineSimProVCSOptionfinesimp wrblockUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimp wrblock is loaded.
saFineSimProVCSOptionfinesimp wrblockUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimpwrtol	string	custom	3mV	FineSimProVCS option finesim_pwrtol: Specifies the voltage tolerance to control an event between a power block partition and the other partitions.
saFineSimProVCSOptionfinesimpwrtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimpwrtol is loaded.
saFineSimProVCSOptionfinesimpwrtolUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimqllevel	string	custom	1	FineSimProVCS option finesim_qlevel: Controls the tolerance of the signal level accuracy.
saFineSimProVCSOptionfinesimqllevelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimqllevel is loaded.
saFineSimProVCSOptionfinesimqllevelUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimrcrc	string	custom	0	FineSimProVCS option finesim_rcrc: Sets the level of acceleration to use when performing post-layout analog simulation with RC reduction.
saFineSimProVCSOptionfinesimrcrc	string	custom	0	FineSimProVCS option finesim_rcrc: Sets the level of acceleration to use when performing post-layout analog simulation with RC reduction.
saFineSimProVCSOptionfinesimrcrcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimrcrc is loaded.
saFineSimProVCSOptionfinesimrcrcUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimremoveprobe	string	custom	0	FineSimProVCS option finesim_remove_probe_prefix: Removes prefix from output signal.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimremoveprobeprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimremoveprobeprefix is loaded.
saFineSimProVCSOptionfinesimremoveprobeprefixUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimresmax	string	custom	1T	FineSimProVCS option finesim_resmax: Sets maximum value for a resistor to be considered in simulation.
saFineSimProVCSOptionfinesimresmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimresmax is loaded.
saFineSimProVCSOptionfinesimresmaxUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimresmin	string	custom	0.001	FineSimProVCS option finesim_resmin: Sets minimum value for a resistor to be considered in simulation. The default value is dependent on finesim_mode.
saFineSimProVCSOptionfinesimresmin	string	custom	0.001	FineSimProVCS option finesim_resmin: Sets minimum value for a resistor to be considered in simulation. The default value is dependent on finesim_mode.
saFineSimProVCSOptionfinesimresminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimresmin is loaded.
saFineSimProVCSOptionfinesimresminUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimreusemosmodel	string	custom	1	FineSimProVCS option finesim_reuse_mos_model: Reuses MOSFET models built in the previous iteration.
saFineSimProVCSOptionfinesimreusemosmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimreusemosmodel is loaded.

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimreusemosmodelUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimrpitftmode	string	custom	0	FineSimProVCS option finesim_rpitft_mode: Enables FineSim support for SmartSpice TFT Model correlation.
saFineSimProVCSOptionfinesimrpitftmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimrpitftmode is loaded.
saFineSimProVCSOptionfinesimrpitftmodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsetcputime	string	custom		FineSimProVCS option finesim_set_cpu_time
saFineSimProVCSOptionfinesimsetcputimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimsetcputime is loaded.
saFineSimProVCSOptionfinesimsetcputimeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsetspecialchar	string	custom		FineSimProVCS option finesim_set_special_char: Appends a "\" before special characters during PSF output.
saFineSimProVCSOptionfinesimsetspecialcharUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimsetspecialchar is loaded.
saFineSimProVCSOptionfinesimsetspecialcharUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsinglebinmodelcheck	string	custom	0	FineSimProVCS option finesim_single_bin_model_check: Apply a similar model binning check for non-binning models.
saFineSimProVCSOptionfinesimsinglebinmodelcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimsinglebinmodelcheck is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimsinglebinmodelcheckUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimskipunusedparam	string	custom	0	FineSimProVCS option finesim_skip_unused_param: Ignores HSIM-specific parameters to avoid ineffective warning messages.
saFineSimProVCSOptionfinesimskipunusedparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimskipunusedparam is loaded.
saFineSimProVCSOptionfinesimskipunusedparamUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimskipwarn	string	custom		FineSimProVCS option finesim_skipwarn: Determines amount and type of information output to the log file.
saFineSimProVCSOptionfinesimskipwarnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimskipwarn is loaded.
saFineSimProVCSOptionfinesimskipwarnUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsoamaxwarns	string	custom	5	FineSimProVCS option finesim_soa_maxwarns: Specifies maximum number of SOA warning messages.
saFineSimProVCSOptionfinesimsoamaxwarns	string	custom	5	FineSimProVCS option finesim_soa_maxwarns: Specifies maximum number of SOA warning messages.
saFineSimProVCSOptionfinesimsoamaxwarnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimsoamaxwarns is loaded.
saFineSimProVCSOptionfinesimsoamaxwarnsUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsoamaxwarn	string	custom	0	FineSimProVCS option finesim_soa_warn: Enables or turns off safe operating area (SOA) voltage warning message.

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimso awarn	string	custom	1	FineSimProVCS option finesim_soa_warn: Enables or turns off safe operating area (SOA) voltage warning message.
saFineSimProVCSOptionfinesimso awarn	string	custom	0	FineSimProVCS option finesim_soa_warn: Enables or turns off safe operating area (SOA) voltage warning message.
saFineSimProVCSOptionfinesimso awarnformat	string	custom	0	FineSimProVCS option finesim_soa_warn_format: Format of SOA check output.
saFineSimProVCSOptionfinesimso awarnformat	string	custom	0	FineSimProVCS option finesim_soa_warn_format: Format of SOA check output.
saFineSimProVCSOptionfinesimso awarnformatUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimsoawarnfor mat is loaded.
saFineSimProVCSOptionfinesimso awarnformatUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimso awarntofile	string	custom	0	FineSimProVCS option finesim_soa_warn_to_file: Print result of SOA checks to separate file (.tsoa).
saFineSimProVCSOptionfinesimso awarntofile	string	custom	0	FineSimProVCS option finesim_soa_warn_to_file: Print result of SOA checks to separate file (tsoa).
saFineSimProVCSOptionfinesimso awarntofileUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimsoawarntof ile is loaded.
saFineSimProVCSOptionfinesimso awarntofileUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimso awarnUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimsoawarn is loaded.
saFineSimProVCSOptionfinesimso awarnUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsp eed	string	custom	2	FineSimProVCS option finesim_speed: Sets the speed level of the simulation.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimsp eedUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimsp speed is loaded.
saFineSimProVCSOptionfinesimsp eedUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsp f2eqr	string	custom		FineSimProVCS option finesim_spf2eqr: Extract equivalent resistors from port-to-port in addition to port-to-pin
saFineSimProVCSOptionfinesimsp f2eqrUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspf2eqr is loaded.
saFineSimProVCSOptionfinesimsp f2eqrUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsp fallowerror	string	custom	0	FineSimProVCS option finesim_spfallowerror: Continue simulation on SPF parser error.
saFineSimProVCSOptionfinesimsp fallowerrorUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfallowerror is loaded.
saFineSimProVCSOptionfinesimsp fallowerrorUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsp fallowmissinginstance	string	custom	1	FineSimProVCS option finesim_spfallowmissinginstance: Annotates the net to which the missing device was attached as an RC net.
saFineSimProVCSOptionfinesimsp fallowmissinginstanceUncheckLoc alized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfallowmi ssinstance is loaded.
saFineSimProVCSOptionfinesimsp fallowmissinginstanceUncheckLoc alized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsp feqr	string	custom		FineSimProVCS option finesim_spfeqr: Extract equivalent resistors from port-to-pin

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimsp feqrfilename	string	custom		FineSimProVCS option finesim_spfeqrfilename: Output file name for the equivalent resistor analysis
saFineSimProVCSOptionfinesimsp feqrfilenameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfeqrfilename is loaded.
saFineSimProVCSOptionfinesimsp feqrfilenameUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsp feqrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfeqr is loaded.
saFineSimProVCSOptionfinesimsp feqrUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsp ffcmin	string	custom	0	FineSimProVCS option finesim_spfffcmin: Sets minimum floating capacitor value allowed for back-annotation
saFineSimProVCSOptionfinesimsp ffcminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfffcmin is loaded.
saFineSimProVCSOptionfinesimsp ffcminUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsp finst	string	custom	0	FineSimProVCS option finesim_spfinst: Control whether the instance section of the DSPF file is used for annotation.
saFineSimProVCSOptionfinesimsp finstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfinst is loaded.
saFineSimProVCSOptionfinesimsp finstUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsp fkeephier	string	custom	0	FineSimProVCS option finesim_spf_keep_hier: Reduce the memory foot print for C annotation.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimspfkeephierUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfkeephier is loaded.
saFineSimProVCSOptionfinesimspfkeephierUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspfmatcheffort	string	custom	0	FineSimProVCS option finesim_spf_matcheffort: Perform more rigorous naming matching for SPF net and devices.
saFineSimProVCSOptionfinesimspfmatcheffortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfmatcheffort is loaded.
saFineSimProVCSOptionfinesimspfmatcheffortUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspfmergeport	string	custom	0	FineSimProVCS option finesim_spfmergeport: Allow ports merge in DSPF net
saFineSimProVCSOptionfinesimspfmergeportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfmergeport is loaded.
saFineSimProVCSOptionfinesimspfmergeportUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspfprb	string	custom	0	FineSimProVCS option finesim_spfprb: Sets the probe mode for DSPF nodes.
saFineSimProVCSOptionfinesimspfprbmode	string	custom	0	FineSimProVCS option finesim_spfprb_mode: Use proper hierarchy for the spf-annotated node name
saFineSimProVCSOptionfinesimspfprbmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfprbmode is loaded.
saFineSimProVCSOptionfinesimspfprbmodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimspfprbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfprb is loaded.
saFineSimProVCSOptionfinesimspfprbUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspfprefix	string	custom		FineSimProVCS option finesim_spfprefix: Lists the prefixes that should be removed from device names.
saFineSimProVCSOptionfinesimspfprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfprefix is loaded.
saFineSimProVCSOptionfinesimspfprefixUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspfired	string	custom	0	FineSimProVCS option finesim_spfired: Sets whether to reduce RC reduction during SPF back-annotation stage.
saFineSimProVCSOptionfinesimspfiredUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfired is loaded.
saFineSimProVCSOptionfinesimspfiredUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspfpreplast	string	custom	0	FineSimProVCS option finesim_spfpreplast: Controls how the representative node is chosen when annotating DSPF
saFineSimProVCSOptionfinesimspfpreplastUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfpreplast is loaded.
saFineSimProVCSOptionfinesimspfpreplastUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspfmax	string	custom	1.0e8	FineSimProVCS option finesim_spfmax: Sets maximum resistor value allowed for back-annotation.

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimsp frmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfrmax is loaded.
saFineSimProVCSOptionfinesimsp frmaxUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsp frmin	string	custom	0.01	FineSimProVCS option finesim_spfrmin: Sets minimum resistor value allowed for back-annotation.
saFineSimProVCSOptionfinesimsp frminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfrmin is loaded.
saFineSimProVCSOptionfinesimsp frminUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsp frptrmax	string	custom	2000	FineSimProVCS option finesim_spfrptrmax: Warning threshold number (per net) for SPF resistors
saFineSimProVCSOptionfinesimsp frptrmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfrptrmax is loaded.
saFineSimProVCSOptionfinesimsp frptrmaxUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsp frtc1	string	custom	0	FineSimProVCS option finesim_spfrtc1: TC1 parameter for DSPF resistors
saFineSimProVCSOptionfinesimsp frtc1UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfrtc1 is loaded.
saFineSimProVCSOptionfinesimsp frtc1UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsp frtc2	string	custom	0	FineSimProVCS option finesim_spfrtc2: TC2 parameter for DSPF resistors

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimspfrtc2UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfrtc2 is loaded.
saFineSimProVCSOptionfinesimspfrtc2UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspfscale	string	custom	1	FineSimProVCS option finesim_spfscale: Sets the scale for devices in the DSPF file.
saFineSimProVCSOptionfinesimspfscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfscale is loaded.
saFineSimProVCSOptionfinesimspfscaleUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspfspicenames	string	custom	1	FineSimProVCS option finesim_spf_spice_names: Specifies whether the instance names in the DSPF file include the SPICE type prefix.
saFineSimProVCSOptionfinesimspfspicenamesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfspicenames is loaded.
saFineSimProVCSOptionfinesimspfspicenamesUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspfsplitnet	string	custom	1	FineSimProVCS option finesim_spfsplitnet: Back annotate split nets.
saFineSimProVCSOptionfinesimspfsplitnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfsplitnet is loaded.
saFineSimProVCSOptionfinesimspfsplitnetUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspfsuffix	string	custom		FineSimProVCS option finesim_spfsuffix: Defines the suffix in a DSPF file.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimspfsuffixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspfsuffix is loaded.
saFineSimProVCSOptionfinesimspfsuffixUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspftc	string	custom	0.1ps	FineSimProVCS option finesim_spftc: Time constant value for RC reduction.
saFineSimProVCSOptionfinesimspftcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspftc is loaded.
saFineSimProVCSOptionfinesimspftcUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspftref	string	custom		FineSimProVCS option finesim_spftref: Reference temperature for DSPF resistors.
saFineSimProVCSOptionfinesimspftrefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspftref is loaded.
saFineSimProVCSOptionfinesimspftrefUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimspred	string	custom	2	FineSimProVCS option finesim_spred: Level of RC reduction.
saFineSimProVCSOptionfinesimspredUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimspred is loaded.
saFineSimProVCSOptionfinesimspredUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimsubcktduprule	string	custom	0	FineSimProVCS option finesim_subckt_dup_rule: Selects which sub-circuit definition to use in simulation.
saFineSimProVCSOptionfinesimsubcktdupruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimsubcktduprule is loaded.

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimsu bcktdupruleUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimtf ush	string	custom		FineSimProVCS option finesim_tf flush: Flushes output files at time interval x.
saFineSimProVCSOptionfinesimtf ushUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimtf ush is loaded.
saFineSimProVCSOptionfinesimtf ushUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimtol scale	string	custom	5	FineSimProVCS option finesim_tol scale: Sets a multiplier applied to all internal tolerance values.
saFineSimProVCSOptionfinesimtol scaleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimtol scale is loaded.
saFineSimProVCSOptionfinesimtol scaleUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesim tsc	string	saTestbe nch	lte1	FineSimProVCS option finesim_t sc: Sets the algorithm mode for time-step control during transient analysis.
saFineSimProVCSOptionfinesim tsc	string	custom	"lte"	FineSimProVCS option finesim_t sc: Sets the algorithm mode for time-step control during transient analysis.
saFineSimProVCSOptionfinesimts cUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimts c is loaded.
saFineSimProVCSOptionfinesimts cUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimtu nit	string	custom	0.01p	FineSimProVCS option finesim_t unit: Defines the base time unit of the simulation.
saFineSimProVCSOptionfinesimtu nit	string	custom	0.01p	FineSimProVCS option finesim_t unit: Defines the base time unit of the simulation.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimunitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimunit is loaded.
saFineSimProVCSOptionfinesimunitUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimuseoldtrout	string	custom	0	FineSimProVCS option finesim_use_old_trout: Determines whether to use new or previous output file name extensions for .print and .measure.
saFineSimProVCSOptionfinesimuseoldtroutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimuseoldtrout is loaded.
saFineSimProVCSOptionfinesimuseoldtroutUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimutfmode	string	saTestbench	fast	FineSimProVCS option finesim_utf_mode: Outputs compressed UTF for Veritools.
saFineSimProVCSOptionfinesimutfmode	string	custom	"fast"	FineSimProVCS option finesim_utf_mode: Outputs compressed UTF for Veritools.
saFineSimProVCSOptionfinesimutfmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimutfmode is loaded.
saFineSimProVCSOptionfinesimutfmodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimvdd	string	custom		FineSimProVCS option finesim_vdd: Sets the VDD value used for MOS table generation.
saFineSimProVCSOptionfinesimvddUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimvdd is loaded.
saFineSimProVCSOptionfinesimvddUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimvectormode	string	custom	0	FineSimProVCS option finesim_vector_mode: Sets the I/O vector file format for bus signals.
saFineSimProVCSOptionfinesimvectormodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimvectormode is loaded.
saFineSimProVCSOptionfinesimvectormodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimvprbtl	string	custom	0.1mV	FineSimProVCS option finesim_vprbtl: Sets the voltage tolerance for voltage print out.
saFineSimProVCSOptionfinesimvprbtlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimvprbtl is loaded.
saFineSimProVCSOptionfinesimvprbtlUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimvsrchn	string	saTestbench	1	FineSimProVCS option finesim_vsrchn: When set to 1, voltage sources are non-ideal and modeled by Norton equivalents, with parallel resistance equal to 1mOhm.
saFineSimProVCSOptionfinesimvsrchnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimvsrchn is loaded.
saFineSimProVCSOptionfinesimvsrchnUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimwarnlimit	string	custom	0	FineSimProVCS option finesim_warn_limit: Sets the number of all warning messages to a specific number of lines.
saFineSimProVCSOptionfinesimwarnlimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimwarnlimit is loaded.
saFineSimProVCSOptionfinesimwarnlimitUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimwdflimit	string	custom		FineSimProVCS option finesim_wdf_limit: Sets the number of warning messages to a number of specified lines.
saFineSimProVCSOptionfinesimwdflimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimwdflimit is loaded.
saFineSimProVCSOptionfinesimwdflimitUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimwdfmode	string	saTestbench	loseless	FineSimProVCS option finesim_wdf_mode: Controls the amount of compression for wdf output file.
saFineSimProVCSOptionfinesimwdfmode	string	custom	"loseless"	FineSimProVCS option finesim_wdf_mode: Controls the amount of compression for wdf output file.
saFineSimProVCSOptionfinesimwdfmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimwdfmode is loaded.
saFineSimProVCSOptionfinesimwdfmodeUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimwrinstanceinstancefile	string	custom	0	FineSimProVCS option finesim_write_instance_table: Generates an instance file.
saFineSimProVCSOptionfinesimwrinstanceinstancefileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimwriteinstanceinstancefile is loaded.
saFineSimProVCSOptionfinesimwrinstanceinstancefileUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionfinesimwrinstanceinstancefilemcp	string	custom	0	FineSimProVCS option finesim_write_mcp: Saves the generated parameters in each run to a file.
saFineSimProVCSOptionfinesimwrinstanceinstancefilemcpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionfinesimwriteinstanceinstancefilemcp is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionfinesimwr itemcparamUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionGEOSHRINK	string	custom	0	FineSimProVCS option GEOSHRINK: Sets scale factor for shrinking device geometry.
saFineSimProVCSOptionGEOSHRINK UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionGEOSHRINK is loaded.
saFineSimProVCSOptionGEOSHRINK UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionGMIN	string	custom	1e-12	FineSimProVCS option GMIN: Minimum conductance added to all PN junctions for a time sweep in transient analysis.
saFineSimProVCSOptionGMINDC	string	custom	1e-12	FineSimProVCS option GMINDC: Sets the minimum conductance places in parallel with all PN junctions and all MOSFET nodes except the gate for DC analysis.
saFineSimProVCSOptionGMINDC UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionGMINDC is loaded.
saFineSimProVCSOptionGMINDC UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionGMINUn checkLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionGMIN is loaded.
saFineSimProVCSOptionGMINUn checkLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionGRAMP	string	custom	0	FineSimProVCS option GRAMP: Sets the conductance range over which GMINDC is to be swept during a DC operating point analysis.
saFineSimProVCSOptionGRAMP UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionGRAMP is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionGRAMP UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionGSHUNT	string	custom	0	FineSimProVCS option GSHUNT: Helps DC/Tran convergence for some kinds of circuits.
saFineSimProVCSOptionGSHUNT UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionGSHUNT is loaded.
saFineSimProVCSOptionGSHUNT UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionHIERSC ALE	string	custom	0	FineSimProVCS option HIER_SCALE: Sets a scale parameter with a value determined by the scale option.
saFineSimProVCSOptionHIERSC ALEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionHIERSCALE is loaded.
saFineSimProVCSOptionHIERSC ALEUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionIMAX	string	custom	8.0	FineSimProVCS option IMAX: Sets the upper limit of iterations in transient analysis.
saFineSimProVCSOptionIMAXUnc heckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionIMAX is loaded.
saFineSimProVCSOptionIMAXUnc heckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionIMIN	string	custom	3.0	FineSimProVCS option IMIN: Sets the lower limit of iterations in transient analysis.
saFineSimProVCSOptionIMINUnc heckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionIMIN is loaded.
saFineSimProVCSOptionIMINUnc heckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProVCSOptionINTERP	string	custom	0	FineSimProVCS option INTERP: If 1, sets the simulations output to be in the increment defined by timestep in .tran analysis.
saFineSimProVCSOptionINTERP UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionINTERP is loaded.
saFineSimProVCSOptionINTERP UncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionITL1	string	custom	200	FineSimProVCS option ITL1: Sets the maximum number of DC iterations.
saFineSimProVCSOptionITL1Unc heckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionITL1 is loaded.
saFineSimProVCSOptionITL1Unc heckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionMAC MOD	string	custom	0	FineSimProVCS option MACMOD: To access the subcircuit definition when there is no matching model reference.
saFineSimProVCSOptionMAC MOD	string	custom	0	FineSimProVCS option MACMOD: To access the subcircuit definition when there is no matching model reference.
saFineSimProVCSOptionMACMO DUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionMACMOD is loaded.
saFineSimProVCSOptionMACMO DUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionMAXWA RNS	string	custom	5	FineSimProVCS option MAXWARNS: Specifies maximum number of SOA warning messages (equivalent to finesim_soa_maxwarns).
saFineSimProVCSOptionMAXWA RNS	string	custom	5	FineSimProVCS option MAXWARNS: Specifies maximum number of SOA warning messages (equivalent to finesim_soa_maxwarns).

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionMAXWARNSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionMAXWARNS is loaded.
saFineSimProVCSOptionMAXWARNSUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionMEASDGT	string	custom	4	FineSimProVCS option MEASDGT: Sets the number of significant digits for results in .measure file.
saFineSimProVCSOptionMEASDGTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionMEASDGT is loaded.
saFineSimProVCSOptionMEASDGTUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionNEW_SOA	string	custom	0	FineSimProVCS option NEW_SOA: Print result of SOA checks to separate file (.tsoa) (NEW_SOA=1 is equivalent to finesim_soa_warn_to_file=1 and finesim_soa_warn_format=4).
saFineSimProVCSOptionNEW_SOA	string	custom	0	FineSimProVCS option NEW_SOA: Print result of SOA checks to separate file (tsoa) (NEW_SOA=1 is equivalent to finesim_soa_warn_to_file=1 and finesim_soa_warn_format=4).
saFineSimProVCSOptionNEWSOAUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionNEWSOA is loaded.
saFineSimProVCSOptionNEWSOAUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionNUMDGT	string	custom	4	FineSimProVCS option NUMDGT: Sets the number of significant digits for output results in .ic, .prt, and .pd# files.
saFineSimProVCSOptionNUMDGTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionNUMDGT is loaded.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionNUMDGTUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionotherOptions	string	custom		FineSimProVCS option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)]
saFineSimProVCSOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionotherOptions is loaded.
saFineSimProVCSOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionPARHIER	string	saTestbench	GLOBAL	FineSimProVCS option PARHIER: Sets the parameter passing rules to control the evaluation order of subcircuit parameters
saFineSimProVCSOptionPARHIERUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionPARHIER is loaded.
saFineSimProVCSOptionPOSTVERSION	string	custom	9601	FineSimProVCS option POST_VERSION: Selects the Spice 2001 output format during the generation of a .tr0 file.
saFineSimProVCSOptionPOSTVERSIONUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionPOSTVERSION is loaded.
saFineSimProVCSOptionPOSTVERSIONUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionpvaoutputdir	string	saTestbench	<file path>	FineSimProVCS option pva_output_dir: Controls pva cache directory.
saFineSimProVCSOptionpvaoutputdirUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionpvaoutputdir is loaded.
saFineSimProVCSOptionreplicates	string	custom	0	FineSimProVCS option replicates: Runs replicates of Latin Hypercube samples.

Table 30 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saFineSimProVCSOptionRISETIME	string	custom		FineSimProVCS option RISETIME: Sets the smallest rise time of the signal used only in transmission kine models.
saFineSimProVCSOptionRISETIMEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionRISETIME is loaded.
saFineSimProVCSOptionRISETIMEUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionrunlvl	string	custom	5	FineSimProVCS option runlvl: Controls runtime speed and simulation accuracy.
saFineSimProVCSOptionrunlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionrunlvl is loaded.
saFineSimProVCSOptionrunlvlUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionsaetablefmt	string	custom	1	FineSimProVCS option saetablefmt: Format of SOA check output. If true, SOA results are returned in TSV files.
saFineSimProVCSOptionsaetablefmtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionsaetablefmt is loaded.
saFineSimProVCSOptionsaetablefmtUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionSCALE	string	custom	1.00	FineSimProVCS option SCALE: Sets the element scaling factor.
saFineSimProVCSOptionSCALEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionSCALE is loaded.
saFineSimProVCSOptionSCALEUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionSCALM	string	custom	1	FineSimProVCS option SCALM: Sets the model scaling factor.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSOptionSCALMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionSCALM is loaded.
saFineSimProVCSOptionSCALMUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionselemcachedir	string	saTestbench	<file path>	FineSimProVCS option s_elem_cache_dir: Controls s-parameter cache directory.
saFineSimProVCSOptionselemcachedirUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionselemcachedir is loaded.
saFineSimProVCSOptionTNOM	string	custom	25	FineSimProVCS option TNOM: Sets the reference temperature for the simulation.
saFineSimProVCSOptionTNOMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionTNOM is loaded.
saFineSimProVCSOptionTNOMUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionUNWRAP	string	custom	0	FineSimProVCS option UNWRAP: Sets all phase results in AC analysis to be calculated in unwrapped form.
saFineSimProVCSOptionUNWRAPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionUNWRAP is loaded.
saFineSimProVCSOptionUNWRAPUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saFineSimProVCSOptionWARN	string	custom	1	FineSimProVCS option WARN: Enables or turns off SOA voltage warning message (equivalent to finesim_soa_warn).
saFineSimProVCSOptionWARNUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saFineSimProVCSOptionWARN is loaded.
saFineSimProVCSOptionWARNUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSSaveOptionsEMImport	string	saTestbench	Import	FineSimProVCS outputControl Import Setting.
saFineSimProVCSSaveOptionsEMTStart	string	saTestbench		Start time for electromigration current analysis.
saFineSimProVCSSaveOptionsEMTStop	string	saTestbench		Stop time for electromigration current analysis.
saFineSimProVCSSaveOptionsEnableEM	string	saTestbench	false	Save currents for in-design layout automation.
saFineSimProVCSSaveOptionsEnableVDRC	string	saTestbench	false	Save voltage extremes to enable VDRC flow.
saFineSimProVCSSaveOptionsPower	string	saTestbench	0	FineSimProVCS: Save power signals for each device
saFineSimProVCSSaveOptionsSave	string	saTestbench	selected	FineSimProVCS: Save net voltages.
saFineSimProVCSSaveOptionsSaveDigital	string	saTestbench	selected	FineSimProVCS: Save digital signals.
saFineSimProVCSSaveOptionsSaveDigitalLevel	string	saTestbench	0	FineSimProVCS: Save digital signals level
saFineSimProVCSSaveOptionsSaveDigitalPorts	string	saTestbench	selected	FineSimProVCS: Save digital ports
saFineSimProVCSSaveOptionsSaveDigitalPortsLevel	string	saTestbench	0	FineSimProVCS: Save digital ports level
saFineSimProVCSSaveOptionsSaveEMCurrents	string	saTestbench	false	FineSimProVCS: Save currents for in-design layout automation
saFineSimProVCSSaveOptionsSaveIEPortsAll	string	saTestbench	false	Save Options save interface element/connect module ports
saFineSimProVCSSaveOptionsSaveIEPortsLevel	string	saTestbench	0	Save Options save interface element/connect module ports level
saFineSimProVCSSaveOptionsSaveNetLevel	string	saTestbench	0	FineSimProVCS: Save net voltages level
saFineSimProVCSSaveOptionsSaveOptionsInstances	string	saTestbench		FineSimProVCS: Save instance-specific signals
saFineSimProVCSSaveOptionsSaveVerilogABranchCurrentsAll	string	saTestbench	false	Save Options save Verilog-A branch currents
saFineSimProVCSSaveOptionsSaveVerilogABranchCurrentsLevel	string	saTestbench	0	Save Options save Verilog-A branch currents level

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSSaveOptionsSaveVerilogABranchVoltagesAll	string	saTestbench	false	Save Options save Verilog-A branch voltages
saFineSimProVCSSaveOptionsSaveVerilogABranchVoltagesLevel	string	saTestbench	0	Save Options save Verilog-A branch voltages level
saFineSimProVCSSaveOptionsSaveVerilogAVarsAll	string	saTestbench	false	Save Options save Verilog-A variables
saFineSimProVCSSaveOptionsSaveVerilogAVarsLevel	string	saTestbench	0	Save Options save Verilog-A variables level
saFineSimProVCSSaveOptionsSubcktCurrents	string	saTestbench	selected	FineSimProVCS: Save subckt port currents
saFineSimProVCSSaveOptionsSubcktCurrentsLevel	string	saTestbench	0	FineSimProVCS: Save subckt port currents level
saFineSimProVCSSaveOptionsTerminalCurrents	string	saTestbench	selected	FineSimProVCS: Save device terminal currents
saFineSimProVCSSaveOptionsTerminalCurrentsLevel	string	saTestbench	0	FineSimProVCS: Save device terminal currents level
saFineSimProVCSSaveOptionsTerminalVoltages	string	saTestbench	selected	FineSimProVCS: Save device terminal voltages
saFineSimProVCSSaveOptionsTerminalVoltagesLevel	string	saTestbench	0	FineSimProVCS: Save device terminal voltages level
saFineSimProVCSSaveOptionsTotalPower	string	saTestbench	0	FineSimProVCS: Save total power
saFineSimProVCSSaveOptionsVdrcStart	string	saTestbench		Start time for VDRC voltage analysis.
saFineSimProVCSSaveOptionsVdrcStop	string	saTestbench		Stop time for VDRC voltage analysis.
saFineSimProVCSShowModelGroups	bool	saTestbench	false	Visibility of Model Groups table for FineSimProVCS. Valid values: true, false
saFineSimProVCSSimulationCommandPrefix	string	user		An environment initialization command to be added to simulation commands.
saFineSimProVCSSimulatorOptionsImport	string	saTestbench	Import	FineSimProVCS simulatorOptions Import Setting.
saFineSimProVCSSpectreEnvOptionsUseCacheDirInCommandLine	bool	user	false	Add pva_output_dir and s_elem_cache_dir in command line option.

Table 30 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saFineSimProVCSSpectreOptionpvaoutputdir	string	saTestbench	<file path>	FineSimProVCSSpectre option pva_output_dir: Controls pva cache directory.
saFineSimProVCSSpectreOptionselemcachedir	string	saTestbench	<file path>	FineSimProVCSSpectre option s_elem_cache_dir: Controls s-parameter cache directory.
saFineSimProVCSTemperatureImport	string	saTestbench	Import	FineSimProVCS temperature Import Setting.
saFineSimProVCSTRANAdvanced	string	saTestbench	false	FineSimProVCS Transient Advanced Settings
saFineSimProVCSTRANFmax	string	saTestbench	0	FineSimProVCS Transient Noise Maximum Frequency
saFineSimProVCSTRANFmin	string	saTestbench		FineSimProVCS Transient Noise Minimum Frequency
saFineSimProVCSTRANMethod	string	saTestbench	Temp Sweep	FineSimProVCS Transient Advanced Method
saFineSimProVCSTRANSscale	string	saTestbench	1.0	FineSimProVCS Transient Noise Scale Noise Scale
saFineSimProVCSTRANSeed	string	saTestbench		FineSimProVCS Transient Noise Random Seed
saFineSimProVCSTRANTempValues	string	saTestbench		FineSimProVCS Transient Temperature
saFineSimProVCSTRANTranNoise	string	saTestbench	0	FineSimProVCS Transient Noise Enable
saFineSimProVCSTRANUIC	string	saTestbench	0	FineSimProVCS Transient setting for Use Initial Conditions
saFineSimProVCSVectorImport	string	saTestbench	Include	FineSimProVCS vector Import Setting.
saFineSimProVectorImport	string	saTestbench	Include	FineSimPro vector Import Setting.

See Also

- [Simulation and Analysis Environment Preferences \(saGen* through saOutput*\)](#)
- [Simulation and Analysis Environment Preferences \(saParam* through saPrimeSimVCS*\)](#)

- [Simulation and Analysis Environment Preferences \(saPrimeSimXA* through saSpectre*\)](#)
- [Simulation and Analysis Environment Preferences \(saSt* through saXA*\)](#)

Simulation and Analysis Environment Preferences (saGen* through saOutput*)

[Table 31](#) lists continuation of PrimeWave Design Environment sa general preferences (saGen* through saOutput*).

Table 31 *Simulation and Analysis Environment Preferences*

Name	Type	Scope	Default	Description
saExportForSource	bool	saSession	false	Exports the model group definition for sourcing the export file. If set to true the model files can be exported for sourcing. Valid values: true, false
saExportShowWaveFrom	bool	user	false	Export Wave for waveform expressions in CSV Files
saGenOpPointsMode	saGenOpPointsModeEnum	user	Foreground	Generation Operating Point Report in [Foreground Background].
saGlobalDefaultModelFiles	string	user		Default model files to be loaded into the test suite global scope.
saGlobalExpression	bool	saSession	false	Control Global Expression On/Off
saGlobalModelGroups	string	user		The models groups specified at the test suite global scope
saGlobalModelGroupsCheckBox	bool	user	false	The model groups table checkbox used for controlling visibility of such table at the test suite global scope. Valid values: true, false
saGlobalShowModelGroups	bool	user	false	Displays the Model Groups table at the test suite global scope. Valid values: true, false
saGuiGenerateReports	bool	user	false	If enabled, running a PrimeWave Design Environment simulation in the GUI automatically produces a report upon completion. Valid values: true, false
saHideAboutSigmaAmplification	bool	user	false	Hide About Sigma Amplification text in Sigma Amplification Calculator. Valid values: true, false

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHideShowDesignDialog New in U-2023.03-SP1 for Jira P90060183-26668	bool	user	false	Hide the Show Design dialog box. Valid values: true, false
saHighlightProbesEnabledForSaving	bool	user	false	Controls highlighting of probes selected for saving Valid values: true, false
saHistogramLimit	string	user	50	Limit for number of histograms to trigger prompting.
saHistoryDirPrefix	string	user	history	The prefix for the directory name of the history points.
saHSIMHSPICEBlockOptionsSummary	string	saTestbench		Custom commands contents holder.
saHSIMHSPICECommands	string	saTestbench	HSIMCC	HSIMHSPICE commands selection.
saHSIMHSPICEDCDesignVar	string	saTestbench		HSIMHSPICE DC sweep Design Variable.
saHSIMHSPICEDCNumPoints	string	saTestbench		HSIMHSPICE DC sweep number of points.
saHSIMHSPICEDCPOI	string	saTestbench		HSIMHSPICE DC sweep poi.
saHSIMHSPICEDCStart	string	saTestbench		HSIMHSPICE DC sweep start.
saHSIMHSPICEDCStepSize	string	saTestbench		HSIMHSPICE DC sweep stepSize.
saHSIMHSPICEDCStop	string	saTestbench		HSIMHSPICE DC sweep stop.
saHSIMHSPICEDCSweep	string	saTestbench	Source	HSIMHSPICE DC sweep type.
saHSIMHSPICEDCSweepType	string	saTestbench	Linear Steps	HSIMHSPICE DC sweep Increment Type.
saHSIMHSPICEDefaultCornersSetup	string	saTestbench		HSIMHSPICE default corners setup.
saHSIMHSPICEDefaultIncludeFiles	string	saTestbench		HSIMHSPICE default include files.
saHSIMHSPICEDefaultModelFiles	string	saTestbench		HSIMHSPICE default model files to be loaded.

Table 31 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saHSIMHSPICEEnableSimulatorResultsXML	bool	user	false	Enables HSPICE to write the resulting XML file. Valid values: true, false
saHSIMHSPICEEnvOptionsCommandLineOptions	string	saTestbench		Additional command line options for the HSPICE.
saHSIMHSPICEEnvOptionsIncludePath	string	saTestbench		Search path for HSPICE include files.
saHSIMHSPICEEnvOptionsNetlistLanguage	string	user	HSPICE	Netlist language for the HSPICE.
saHSIMHSPICEEnvOptionsOutputDataFormat	string	saTestbench	wdf	Output data format.
saHSIMHSPICEEnvOptionsStopViewList	string	saTestbench	hspice hspiceD veriloga	Stop View List for netlister.
saHSIMHSPICEEnvOptionsSwitchViewList	string	saTestbench	hspice hspiceD cmos.sch cmos_sch schematic veriloga	Switch View List for netlister.
saHSIMHSPICEEnvOptionsUse64Bit	string	saTestbench	0	64-bit simulation.
saHSIMHSPICEFFTAlfa	string	saTestbench	3	HSPICE FFT Alfa.
saHSIMHSPICEFFTfmax	string	saTestbench		HSPICE FFT Maximum Frequency (Hz).
saHSIMHSPICEFFTfmin	string	saTestbench		HSPICE FFT Minimum Frequency (Hz).
saHSIMHSPICEFFTFormat	string	saTestbench	NORM	HSPICE FFT Format.
saHSIMHSPICEFFTfreq	string	saTestbench		HSPICE FFT Analysis Frequency (Hz).
saHSIMHSPICEFFTNumPoints	string	saTestbench		HSPICE FFT number of points.
saHSIMHSPICEFFTOutputType	string	saTestbench	Voltage	HSPICE FFT Output Variable.
saHSIMHSPICEFFTStart	string	saTestbench		HSPICE FFT start Time.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICEFFTStop	string	saTestbench		HSIMHSPICE FFT top Time.
saHSIMHSPICEFFTWindow	string	saTestbench	RECT	HSIMHSPICE FFT Window Type.
saHSIMHSPICEModelGroups	string	saTestbench		Model groups for HSIMHSPICE
saHSIMHSPICEModelGroupsCheckBox	bool	saTestbench	false	Visibility of Model Groups table for HSIMHSPICE. Valid values: true, false
saHSIMHSPICEModelsIncludePath	string	saTestbench		Search path for HSIMHSPICE model files.
saHSIMHSPICEMonteCarloNumIter	string	saTestbench	10	Number of iterations for Monte Carlo analysis.
saHSIMHSPICEMonteCarloStartIter	string	saTestbench	1	Starting iteration for Monte Carlo analysis.
saHSIMHSPICEOPTimes	string	saTestbench	0	HSIMHSPICE Operating point save time.
saHSIMHSPICEOptionGENK	string	custom	1	HSIMHSPICE option GENK: Automatically computes second-order mutual inductance for several coupled inductors.
saHSIMHSPICEOptionGENKUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionGENK is loaded.
saHSIMHSPICEOptionHSIMABMOS	string	custom	0	HSIMHSPICE option HSIMABMOS: Sets the Precise Model on the coupling effect between Mosfets terminals
saHSIMHSPICEOptionHSIMABMOSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMABMOS is loaded.
saHSIMHSPICEOptionHSIMABSVOLTOL	string	custom		HSIMHSPICE option HSIMABSVOLTOL: Sets the absolute voltage tolerance
saHSIMHSPICEOptionHSIMABSVOLTOLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMABSVOLTOL is loaded.
saHSIMHSPICEOptionHSIMALLOWEDDV	string	custom	0.3	HSIMHSPICE option HSIMALLOWEDDV: Dynamically adjusts the time step size

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMALLOWEDDVUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMALLOWEDDV is loaded.
saHSIMHSPICEOptionHSIMAMOS	string	custom	0	HSIMHSPICE option HSIMAMOS: Sets the Precise Model on coupling effect for Mosfets located within sub-circuit definition
saHSIMHSPICEOptionHSIMAMOSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMAMOS is loaded.
saHSIMHSPICEOptionHSIMANALOG	string	custom	1.0	HSIMHSPICE option HSIMANALOG: Controls the complexity of analog simulation algorithm
saHSIMHSPICEOptionHSIMANALOGUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMANALOG is loaded.
saHSIMHSPICEOptionHSIMASIM	string	custom	0	HSIMHSPICE option HSIMASIM: Invokes a conservative analog simulation algorithm
saHSIMHSPICEOptionHSIMASIMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMASIM is loaded.
saHSIMHSPICEOptionHSIMAUTOVDD	string	custom	0	HSIMHSPICE option HSIMAUTOVDD: Traces a design and automatically identifies multiple power supplies
saHSIMHSPICEOptionHSIMAUTOVDDUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMAUTOVDD is loaded.
saHSIMHSPICEOptionHSIMBJTCC	string	custom	0	HSIMHSPICE option HSIMBJTCC: Invokes the exact charge conservation model for the charge stored by the BJT capacitors
saHSIMHSPICEOptionHSIMBJTCCUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMBJTCC is loaded.
saHSIMHSPICEOptionHSIMBJTTCV	string	custom	0	HSIMHSPICE option HSIMBJTTCV: Invokes the approximate charge conservation model for the charge stored by the BJT capacitors

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMBJTCVUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMBJTCV is loaded.
saHSIMHSPICEOptionHSIMBMOS	string	custom	0	HSIMHSPICE option HSIMBMOS: Enables the Precise Model on Mosfets terminals
saHSIMHSPICEOptionHSIMBMOSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMBMOS is loaded.
saHSIMHSPICEOptionHSIMBUSDELIMITER	string	custom	null	HSIMHSPICE option HSIMBUSDELIMITER: Specifies the bus notation used in a SPICE netlist
saHSIMHSPICEOptionHSIMBUSDELIMITERUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMBUSDELIMITER is loaded.
saHSIMHSPICEOptionHSIMCAPFILE	string	custom	null	HSIMHSPICE option HSIMCAPFILE: Controls adding capacitance to previously back-annotated nodes
saHSIMHSPICEOptionHSIMCAPFILEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMCAPFILE is loaded.
saHSIMHSPICEOptionHSIMCC	string	custom	0	HSIMHSPICE option HSIMCC: Enables the charge-conservation model for Mosfets
saHSIMHSPICEOptionHSIMCCUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMCC is loaded.
saHSIMHSPICEOptionHSIMCMIN	string	custom		HSIMHSPICE option HSIMCMIN: Sets the minimum capacitance value
saHSIMHSPICEOptionHSIMCMINUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMCMIN is loaded.
saHSIMHSPICEOptionHSIMCOILIB	string	custom		HSIMHSPICE option HSIMCOILIB: Specifies the full path of the waveform file generator library

Table 31 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMCOILIBUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMCOILIB is loaded.
saHSIMHSPICEOptionHSIMCONNCHECK	string	custom	1	HSIMHSPICE option HSIMCONNCHECK: Controls connectivity checking
saHSIMHSPICEOptionHSIMCONNCHECKUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMCONNCHECK is loaded.
saHSIMHSPICEOptionHSIMDCI	string	custom	5e-7	HSIMHSPICE option HSIMDCI: Specifies the current change
saHSIMHSPICEOptionHSIMDCINIT	string	custom	1	HSIMHSPICE option HSIMDCINIT: Controls the initialization of DC analysis
saHSIMHSPICEOptionHSIMDCINITUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMDCINIT is loaded.
saHSIMHSPICEOptionHSIMDCITER	string	custom	250	HSIMHSPICE option HSIMDCITER: Limits the number of DC iteration steps
saHSIMHSPICEOptionHSIMDCITERUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMDCITER is loaded.
saHSIMHSPICEOptionHSIMDCIUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMDCI is loaded.
saHSIMHSPICEOptionHSIMDCSTEP	string	custom	1000	HSIMHSPICE option HSIMDCSTEP: Sets the DC initialization time step in pico seconds
saHSIMHSPICEOptionHSIMDCSTEPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMDCSTEP is loaded.
saHSIMHSPICEOptionHSIMDCV	string	custom	0.001	HSIMHSPICE option HSIMDCV: Controls the DC convergent state threshold for each DC iteration
saHSIMHSPICEOptionHSIMDCVUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMDCV is loaded.

Table 31 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMDIOCC	string	custom	0	HSIMHSPICE option HSIMDIOCC: Invokes the exact charge conservation model for the charge stored by the diode capacitors
saHSIMHSPICEOptionHSIMDIOCCUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMDIOCC is loaded.
saHSIMHSPICEOptionHSIMDIOCV	string	custom	0	HSIMHSPICE option HSIMDIOCV: Invokes the approximate charge conservation model for the charge stored by the diode capacitors
saHSIMHSPICEOptionHSIMDIOCVUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMDIOCV is loaded.
saHSIMHSPICEOptionHSIMDPFHIERID	string	custom	.	HSIMHSPICE option HSIMDPFHIERID: Specifies the hierarchical separator used in DPF file
saHSIMHSPICEOptionHSIMDPFHIERIDUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMDPFHIERID is loaded.
saHSIMHSPICEOptionHSIMDPFPFX	string	custom	m_	HSIMHSPICE option HSIMDPFPFX: Specifies the DPF prefix string
saHSIMHSPICEOptionHSIMDPFPFXUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMDPFPFX is loaded.
saHSIMHSPICEOptionHSIMDPFSCALE	string	custom	1	HSIMHSPICE option HSIMDPFSCALE: Specifies the scale factor for device parameters in the DPF file
saHSIMHSPICEOptionHSIMDPFSCALEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMDPFSCALE is loaded.
saHSIMHSPICEOptionHSIMDPFSFX	string	custom	@	HSIMHSPICE option HSIMDPFSFX: Specifies delimiter the delimiter character used on fingered devices in the DPF file
saHSIMHSPICEOptionHSIMDPFSFXUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMDPFSFX is loaded.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMENHANCEDC	string	custom	0	HSIMHSPICE option HSIMENHANCEDC: Determines DC initialization algorithm
saHSIMHSPICEOptionHSIMENHANCEDCUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMENHANCEDC is loaded.
saHSIMHSPICEOptionHSIMFCAP	string	custom	1e-13	HSIMHSPICE option HSIMFCAP: Determines the ungrounded capacitance model
saHSIMHSPICEOptionHSIMFCAPR	string	custom	0.5	HSIMHSPICE option HSIMFCAPR: Determines the ungrounded capacitance model
saHSIMHSPICEOptionHSIMFCAPRUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMFCAPR is loaded.
saHSIMHSPICEOptionHSIMFCAPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMFCAP is loaded.
saHSIMHSPICEOptionHSIMFCM	string	custom	3	HSIMHSPICE option HSIMFCM: Global parameter to select ungrounded capacitance model
saHSIMHSPICEOptionHSIMFCMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMFCM is loaded.
saHSIMHSPICEOptionHSIMFLAT	string	custom	0	HSIMHSPICE option HSIMFLAT: Selects a flat or a hierarchical simulation
saHSIMHSPICEOptionHSIMFLATUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMFLAT is loaded.
saHSIMHSPICEOptionHSIMGCAP	string	custom	1e-15	HSIMHSPICE option HSIMGCAP: Determines the ungrounded capacitance model
saHSIMHSPICEOptionHSIMGCAPR	string	custom	0.02	HSIMHSPICE option HSIMGCAPR: Determines the ungrounded capacitance model

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMGCAP RUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMGCAPR is loaded.
saHSIMHSPICEOptionHSIMGCAP UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMGCAP is loaded.
saHSIMHSPICEOptionHSIMG CSC	string	custom	1	HSIMHSPICE option HSIMGCSC: Controls the calculation of Mosfet gate and junction diode capacitances
saHSIMHSPICEOptionHSIMGCS CUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMGCSC is loaded.
saHSIMHSPICEOptionHSIMHIE RID	string	custom	.	HSIMHSPICE option HSIMHIERID: Specifies the hierarchical separator character
saHSIMHSPICEOptionHSIMHIERI DUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMHIERID is loaded.
saHSIMHSPICEOptionHSIMHZ	string	custom	0	HSIMHSPICE option HSIMHZ: Performs Hi-Z node checking
saHSIMHSPICEOptionHSIMHZ ALL	string	custom	0	HSIMHSPICE option HSIMHZALL: Overwrites the HSIMHZ default behavior
saHSIMHSPICEOptionHSIMHZAL LUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMHZALL is loaded.
saHSIMHSPICEOptionHSIMHZFA NOUT	string	custom	0	HSIMHSPICE option HSIMHZFANOUT: Limits high impedance state checks to those driver nodes with fan-outs
saHSIMHSPICEOptionHSIMHZFA NOUTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMHZFANOUT is loaded.
saHSIMHSPICEOptionHSIMHZST ART	string	custom		HSIMHSPICE option HSIMHZSTART: Start the check at the specified start time value

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMHZSTARTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMHZSTART is loaded.
saHSIMHSPICEOptionHSIMHZSTOP	string	custom		HSIMHSPICE option HSIMHZSTOP: Stops the check at the specified stop time value
saHSIMHSPICEOptionHSIMHZSTOPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMHZSTOP is loaded.
saHSIMHSPICEOptionHSIMHZTIME	string	custom	5	HSIMHSPICE option HSIMHZTIME: Threshold time for a specified node staying in the high-impedance state to be reported
saHSIMHSPICEOptionHSIMHZTIMEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMHZTIME is loaded.
saHSIMHSPICEOptionHSIMHZUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMHZ is loaded.
saHSIMHSPICEOptionHSIMIDDQ	string	custom	1	HSIMHSPICE option HSIMIDDQ: Tightens the simulation accuracy criteria for steady state current
saHSIMHSPICEOptionHSIMIDDQUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMIDDQ is loaded.
saHSIMHSPICEOptionHSIMKEEPNODESET	string	custom	0	HSIMHSPICE option HSIMKEEPNODESET: Keep all the nodeset values
saHSIMHSPICEOptionHSIMKEEPNODESETUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMKEEPNODESET is loaded.
saHSIMHSPICEOptionHSIMLUMPCAP	string	custom	1	HSIMHSPICE option HSIMLUMPCAP: Keeps all the capacitors as regular elements
saHSIMHSPICEOptionHSIMLUMPCAPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMLUMPCAP is loaded.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMMONTECARLO	string	custom	1	HSIMHSPICE option HSIMMONTECARLO: Sets the Monte Carlos analysis mode
saHSIMHSPICEOptionHSIMMONTECARLOINST	string	custom		HSIMHSPICE option HSIMMONTECARLOINST: Prints the device instance parameter variations
saHSIMHSPICEOptionHSIMMONTECARLOINSTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMMONTECARLOINST is loaded.
saHSIMHSPICEOptionHSIMMONTECARLOSAVEOUT	string	custom	0	HSIMHSPICE option HSIMMONTECARLOSAVEOUT: Keeps all Monte Carlo iteration files
saHSIMHSPICEOptionHSIMMONTECARLOSAVEOUTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMMONTECARLOSAVEOUT is loaded.
saHSIMHSPICEOptionHSIMMONTECARLOUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMMONTECARLO is loaded.
saHSIMHSPICEOptionHSIMMQS	string	custom	1	HSIMHSPICE option HSIMMQS: Controls dynamic time step adjustment during transient simulation
saHSIMHSPICEOptionHSIMMQSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMMQS is loaded.
saHSIMHSPICEOptionHSIMMULTIDC	string	custom	1	HSIMHSPICE option HSIMMULTIDC: Enables multi-rate time step algorithm to improve up DC convergence
saHSIMHSPICEOptionHSIMMULTIDCUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMMULTIDC is loaded.
saHSIMHSPICEOptionHSIMNODECAP	string	custom		HSIMHSPICE option HSIMNODECAP: Controls how to report average capacitance
saHSIMHSPICEOptionHSIMNODECAPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMNODECAP is loaded.
saHSIMHSPICEOptionHSIMNVBS	string	custom	200	HSIMHSPICE option HSIMNVBS: Specifies the grid resolution

Table 31 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMNVBS UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMNVBS is loaded.
saHSIMHSPICEOptionHSIMNVDS	string	custom	60	HSIMHSPICE option HSIMNVDS: Specifies grid numbers in the VDS dimension
saHSIMHSPICEOptionHSIMNVDS UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMNVDS is loaded.
saHSIMHSPICEOptionHSIMNVGS	string	custom	60	HSIMHSPICE option HSIMNVGS: Specifies grid numbers in the VGS dimension
saHSIMHSPICEOptionHSIMNVGS UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMNVGS is loaded.
saHSIMHSPICEOptionHSIMOUTP UTFLUSH	string	custom	-1	HSIMHSPICE option HSIMOUTPUTFLUSH: Forces simulation data from memory to the disk file according to the specified time period
saHSIMHSPICEOptionHSIMOUTP UTFLUSHUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMOUTPUTFLUSH is loaded.
saHSIMHSPICEOptionHSIMOUTP UTIRES	string	custom	1e-9	HSIMHSPICE option HSIMOUTPUTIRES: Controls the waveform output resolution
saHSIMHSPICEOptionHSIMOUTP UTIRESUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMOUTPUTIRES is loaded.
saHSIMHSPICEOptionHSIMOUTP UTTRES	string	custom	1e-12	HSIMHSPICE option HSIMOUTPUTTRES: Controls the output time resolution
saHSIMHSPICEOptionHSIMOUTP UTTRESUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMOUTPUTTRES is loaded.
saHSIMHSPICEOptionHSIMOUTP UTVRES	string	custom	1e-3	HSIMHSPICE option HSIMOUTPUTVRES: Controls output voltage resolution

Table 31 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMOUTPUTVRESUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMOUTPUTVRES is loaded.
saHSIMHSPICEOptionHSIMPORTTCR	string	custom	0.01	HSIMHSPICE option HSIMPORTCR: Controls the subcircuit capacitance ratio for isomorphic matching
saHSIMHSPICEOptionHSIMPORTCRUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMPORTCR is loaded.
saHSIMHSPICEOptionHSIMPORTV	string	custom	0.001	HSIMHSPICE option HSIMPORTV: Defines port voltage tolerance
saHSIMHSPICEOptionHSIMPORTVUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMPORTV is loaded.
saHSIMHSPICEOptionHSIMPOSTL	string	custom	0	HSIMHSPICE option HSIMPOSTL: Controls the RC reduction method
saHSIMHSPICEOptionHSIMPOSTLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMPOSTL is loaded.
saHSIMHSPICEOptionHSIMPREFLAT	string	custom	0	HSIMHSPICE option HSIMPREFLAT: Controls the netlist flattening before or after partitioning>
saHSIMHSPICEOptionHSIMPREFLATUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMPREFLAT is loaded.
saHSIMHSPICEOptionHSIMRCRIO	string	custom	0	HSIMHSPICE option HSIMRCRIO: Controls how to preserve nodes specified in .ic/.nodeset/.print statements
saHSIMHSPICEOptionHSIMRCRIOUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMRCRIO is loaded.
saHSIMHSPICEOptionHSIMRCRKEEPELEM	string	custom	null	HSIMHSPICE option HSIMRCRKEEPELEM: Preserves elements in RC reduction if they match the specified pattern

Table 31 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMRCRK EEPELEMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMRCRKEEPELEM is loaded.
saHSIMHSPICEOptionHSIMRCRK EEMODEL	string	custom	null	HSIMHSPICE option HSIMRCRKEEMODEL: Preserves the specified model in RC reduction
saHSIMHSPICEOptionHSIMRCRK EEMODELUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMRCRKEEPMODEL is loaded.
saHSIMHSPICEOptionHSIMRCRK EENODE	string	custom	null	HSIMHSPICE option HSIMRCRKEENODE: Preserves nodes in RC reduction if they match the specified pattern
saHSIMHSPICEOptionHSIMRCRK EENODEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMRCRKEEPNODE is loaded.
saHSIMHSPICEOptionHSIMREDE FSUB	string	custom		HSIMHSPICE option HSIMREDEFSUB: Allows a simulation to continue when there are duplicate subcircuit names
saHSIMHSPICEOptionHSIMREDE FSUBUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMREDEFSUB is loaded.
saHSIMHSPICEOptionHSIMRELC URTOL	string	custom		HSIMHSPICE option HSIMRELCURTOL: Sets the relative current tolerance
saHSIMHSPICEOptionHSIMRELC URTOLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMRELCURTOL is loaded.
saHSIMHSPICEOptionHSIMRMIN	string	custom	0.1	HSIMHSPICE option HSIMRMIN: Sets the minimum resistor value
saHSIMHSPICEOptionHSIMRMIN UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMRMIN is loaded.
saHSIMHSPICEOptionHSIMSNCS	string	custom	1	HSIMHSPICE option HSIMSNCS: Bypasses idle subcircuit elements to speed up simulation

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMSNCSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSNCS is loaded.
saHSIMHSPICEOptionHSIMSP EED	string	custom	3	HSIMHSPICE option HSIMSPEED: Sets the simulation speed in relation to precision
saHSIMHSPICEOptionHSIMSPEEDUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSPEED is loaded.
saHSIMHSPICEOptionHSIMSPFCHLEVEL	string	custom		HSIMHSPICE option HSIMSPFCHLEVEL: Specifies the hierarchical level to back annotate capacitance
saHSIMHSPICEOptionHSIMSPFCHLEVELUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSPFCHLEVEL is loaded.
saHSIMHSPICEOptionHSIMSPFCMIN	string	custom		HSIMHSPICE option HSIMSPFCMIN: Controls whether to perform RC or capacitance only back annotation
saHSIMHSPICEOptionHSIMSPFCMINUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSPFCMIN is loaded.
saHSIMHSPICEOptionHSIMSPFCNET	string	custom		HSIMHSPICE option HSIMSPFCNET: Back annotates capacitance only by net name
saHSIMHSPICEOptionHSIMSPFCNETUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSPFCNET is loaded.
saHSIMHSPICEOptionHSIMSPFCHLEVEL	string	custom		HSIMHSPICE option HSIMSPFCHLEVEL: Controls RC back-annotation according to the hierarchy level
saHSIMHSPICEOptionHSIMSPFCHLEVELUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSPFCHLEVEL is loaded.
saHSIMHSPICEOptionHSIMSPFKS	string	custom	0	HSIMHSPICE option HSIMSPFKS: Keeps backslash characters (\) in names in the DSPF/SPEF file

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMSPFKSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSPFKS is loaded.
saHSIMHSPICEOptionHSIMSPFNETPIN	string	custom		HSIMHSPICE option HSIMSPFNETPIN: Connects power voltage sources to a sub-node or instance pin in the DSPF power net
saHSIMHSPICEOptionHSIMSPFNETPINUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSPFNETPIN is loaded.
saHSIMHSPICEOptionHSIMSPFPLX	string	custom	0	HSIMHSPICE option HSIMSPFPLX: To activate PLX option
saHSIMHSPICEOptionHSIMSPFPLXUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSPFPLX is loaded.
saHSIMHSPICEOptionHSIMSPFPWNET	string	custom	-1	HSIMHSPICE option HSIMSPFPWNET: Invokes power net reduction
saHSIMHSPICEOptionHSIMSPFPWNETUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSPFPWNET is loaded.
saHSIMHSPICEOptionHSIMSPFPWRMIN	string	custom	0.01	HSIMHSPICE option HSIMSPFPWRMIN: Pre-filters small resistors in power nets
saHSIMHSPICEOptionHSIMSPFPWRMINUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSPFPWRMIN is loaded.
saHSIMHSPICEOptionHSIMSPFRCNET	string	custom		HSIMHSPICE option HSIMSPFRCNET: Runs back-annotation for the specified nets
saHSIMHSPICEOptionHSIMSPFRCNETUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSPFRCNET is loaded.
saHSIMHSPICEOptionHSIMSPICE	string	custom	0	HSIMHSPICE option HSIMSPICE: Controls simulation precision for Mosfets

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMSPICEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSPICE is loaded.
saHSIMHSPICEOptionHSIMSTEADYCURRENT	string	custom	1e-8	HSIMHSPICE option HSIMSTEADYCURRENT: Skips the simulation of idle subcircuits
saHSIMHSPICEOptionHSIMSTEADYCURRENTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMSTEADYCURRENT is loaded.
saHSIMHSPICEOptionHSIMTAUMAX	string	custom	2e-9	HSIMHSPICE option HSIMTAUMAX: Defines an upper bound for the time stepsize
saHSIMHSPICEOptionHSIMTAUMAXUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMTAUMAX is loaded.
saHSIMHSPICEOptionHSIMTIMESCALE	string	custom	1	HSIMHSPICE option HSIMTIMESCALE: Adjusts the time unit in pico seconds
saHSIMHSPICEOptionHSIMTIMESCALEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMTIMESCALE is loaded.
saHSIMHSPICEOptionHSIMTLINEDV	string	custom	1.0	HSIMHSPICE option HSIMTLINEDV: Controls the simulation time step for transmission lines
saHSIMHSPICEOptionHSIMTLINEDVUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMTLINEDV is loaded.
saHSIMHSPICEOptionHSIMTRAPEZOIDAL	string	custom	0	HSIMHSPICE option HSIMTRAPEZOIDAL: Enables the numerical integration algorithm to simulate oscillators with inductors
saHSIMHSPICEOptionHSIMTRAPEZOIDALUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMTRAPEZOIDAL is loaded.
saHSIMHSPICEOptionHSIMTSTEP2TAUMAX	string	custom	0	HSIMHSPICE option HSIMTSTEP2TAUMAX: Sets the HSIMTAUMAX value as tstep value of .tran command

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMTSTEP2TAUMAXUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMTSTEP2TAUMAX is loaded.
saHSIMHSPICEOptionHSIMVBSEND	string	custom	4.0	HSIMHSPICE option HSIMVBSEND: Specifies the VBS ending value
saHSIMHSPICEOptionHSIMVBSENDUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMVBSEND is loaded.
saHSIMHSPICEOptionHSIMVDD	string	custom	3.0	HSIMHSPICE option HSIMVDD: Influences supply voltage control
saHSIMHSPICEOptionHSIMVDDUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMVDD is loaded.
saHSIMHSPICEOptionHSIMVDS	string	custom	4.0	HSIMHSPICE option HSIMVDS: Specifies the VDS ending value
saHSIMHSPICEOptionHSIMVDSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMVDS is loaded.
saHSIMHSPICEOptionHSIMVERILOGA	string	custom		HSIMHSPICE option HSIMVERILOGA: Specifies a Verilog-A modules file
saHSIMHSPICEOptionHSIMVERILOGAUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMVERILOGA is loaded.
saHSIMHSPICEOptionHSIMVGSEND	string	custom	4.0	HSIMHSPICE option HSIMVGSEND: Specifies the VGS ending value
saHSIMHSPICEOptionHSIMVGSENDUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMVGSEND is loaded.
saHSIMHSPICEOptionHSIMVHTH	string	custom	0.7*VDD	HSIMHSPICE option HSIMVHTH: Specifies the voltage threshold for the HIGH logic state
saHSIMHSPICEOptionHSIMVHTHUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMVHTH is loaded.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionHSIMVLTH	string	custom	0.3*VDD	HSIMHSPICE option HSIMVLTH: Specifies the ratio for the voltage threshold for the LOW logic state
saHSIMHSPICEOptionHSIMVLTHUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMVLTH is loaded.
saHSIMHSPICEOptionHSIMVSRCDV	string	custom		HSIMHSPICE option HSIMVSRCDV: Adjusts simulation time step on the primary input voltage source nodes
saHSIMHSPICEOptionHSIMVSRCDVUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMVSRCDV is loaded.
saHSIMHSPICEOptionHSIMVSRRCRMIN	string	custom	0.1	HSIMHSPICE option HSIMVSRRCRMIN: Shorts any resistor that connects to a voltage source and is smaller than the specified value
saHSIMHSPICEOptionHSIMVSRRCRMINUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionHSIMVSRRCRMIN is loaded.
saHSIMHSPICEOptionSCALE	string	custom	1.00	HSIMHSPICE option SCALE: Sets the element scaling factor.
saHSIMHSPICEOptionSCALEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionSCALE is loaded.
saHSIMHSPICEOptionSCALM	string	custom	1	HSIMHSPICE option SCALM: Sets the model scaling factor.
saHSIMHSPICEOptionSCALMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionSCALM is loaded.
saHSIMHSPICEOptionSCALMUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saHSIMHSPICEOptionSEED	string	custom		HSIMHSPICE option SEED: Specifies the starting seed for the random number generator
saHSIMHSPICEOptionSEEDUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionSEED is loaded.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICEOptionTNOM	string	custom	25	HSIMHSPICE option TNOM: Sets the reference temperature for the simulation.
saHSIMHSPICEOptionTNOMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionTNOM is loaded.
saHSIMHSPICEOptionWL	string	custom	0	HSIMHSPICE option WL: Reverses the order of the VSIZE MOS element.
saHSIMHSPICEOptionWLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSIMHSPICEOptionWL is loaded.
saHSIMHSPICESaveOptionsPrefix	string	saTestbench	hsim	HSIMHSPICE Save Options Prefix.
saHSIMHSPICESaveOptionsRepeat	string	saTestbench		HSIMHSPICE Save Options Repeat.
saHSIMHSPICESaveOptionsRestoreFile	string	saTestbench		HSIMHSPICE Save Options Restore File.
saHSIMHSPICESaveOptionsRestoreTime	string	saTestbench		HSIMHSPICE Save Options Restore Time.
saHSIMHSPICESaveOptionsSave	string	saTestbench	selected	HSIMHSPICE Save Options save.
saHSIMHSPICESaveOptionsSaveLevel	string	saTestbench	1	HSIMHSPICE Save Options Save Level.
saHSIMHSPICESaveOptionsSplit	string	saTestbench	0	HSIMHSPICE Save Options Split.
saHSIMHSPICESaveOptionsStoreRestoreMode	string	saTestbench	off	HSIMHSPICE Save Options Store Restore Mode.
saHSIMHSPICESaveOptionsTerminalCurrents	string	saTestbench	selected	HSIMHSPICE Save Options Terminal Currents.
saHSIMHSPICESaveOptionsTerminalCurrentsLevel	string	saTestbench	1	HSIMHSPICE Save Options Terminal Currents Level.
saHSIMHSPICESaveOptionsTimes	string	saTestbench		HSIMHSPICE Save Options Times.
saHSIMHSPICEShowModelGroups	bool	saTestbench	false	Display the Model Groups table for HSIMHSPICE. Valid values: true, false
saHSIMHSPICESimulationCommandPrefix	string	user		An environment initialization command to be added to simulation commands.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSIMHSPICETRANStep	string	saTestbench		HSIMHSPICE Transient time step.
saHSIMHSPICETRANStop	string	saTestbench		HSIMHSPICE Transient stop time.
saHSIMHSPICETRANUIC	string	saTestbench	0	HSIMHSPICE Transient setting for Use Initial Conditions.
saHSPICEACDesignVar	string	saTestbench		HSPICE AC sweep design Variable.
saHSPICEACFreqPoint	string	saTestbench		HSPICE AC freqPoint.
saHSPICEACMATCHInterval	string	saTestbench		HSPICE ACmatch Interval.
saHSPICEACMATCHSensNodes	string	saTestbench		HSPICE ACmatch Sensitivity Nodes.
saHSPICEACMATCHSensThreshold	string	saTestbench	1.00E-06	HSPICE ACmatch Threshold.
saHSPICEACMATCHThreshold	string	saTestbench	0.01	HSPICE ACmatch Threshold.
saHSPICEACMATCHVirtSens	string	saTestbench	0	HSPICE ACmatch Virtual Sensitivity.
saHSPICEACNumPoints	string	saTestbench		HSPICE AC sweep number of points.
saHSPICEACPOI	string	saTestbench		HSPICE AC sweep points.
saHSPICEACStart	string	saTestbench		HSPICE AC sweep start.
saHSPICEACStop	string	saTestbench		HSPICE AC sweep stop.
saHSPICEACSweep	string	saTestbench	Frequency (Hz)	HSPICE AC sweep type.
saHSPICEACSweepType	string	saTestbench	Linear	HSPICE AC sweep Increment Type.
saHSPICEAdditionalLogFiles	string	user		HSPICE additional log files.
saHSPICEAnalysesImport	string	saTestbench	Import	HSPICE analyses Import Setting

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEConvergenceAidsImport	string	saTestbench	Import	HSPICE convergenceAids Import Setting.
saHSPICEDataImport	string	saTestbench	Include	HSPICE data Import Setting.
saHSPICEDCDesignVar	string	saTestbench		HSPICE DC sweep Design Variable.
saHSPICEDCHysteresis	bool	saTestbench	false	HSPICE DC hysteresis sweep Valid values: true, false
saHSPICEDCMATCHInterval	string	saTestbench		HSPICE Dcmatch Interval.
saHSPICEDCMATCHThreshold	string	saTestbench	0.01	HSPICE Dcmatch Threshold.
saHSPICEDCNumPoints	string	saTestbench		HSPICE DC sweep number of points
saHSPICEDCPOI	string	saTestbench		HSPICE DC sweep poi.
saHSPICEDCStart	string	saTestbench		HSPICE DC sweep start.
saHSPICEDCStepSize	string	saTestbench		HSPICE DC sweep stepSize.
saHSPICEDCStop	string	saTestbench		HSPICE DC sweep stop.
saHSPICEDCSweep	string	saTestbench	Source	HSPICE DC sweep type.
saHSPICEDCSweepType	string	saTestbench	Linear Steps	HSPICE DC sweep Increment Type.
saHSPICEDefaultCornersSetup	string	saTestbench		HSPICE default corners setup.
saHSPICEDefaultIncludeFiles	string	saTestbench		HSPICE default include files.
saHSPICEDefaultModelFiles	string	saTestbench		HSPICE default model files to be loaded.
saHSPICEEnableSimulatorResultsXML	bool	user	false	Enables HSPICE to write the resulting XML file. Valid values: true, false

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEEnvOptsAccuracyLevel	string	saTestbench	runlvl	Accuracy Level
saHSPICEEnvOptsCommandLineOptions	string	saTestbench		Additional command-line options for the HSPICE.
saHSPICEEnvOptsEnableMultiThreading	string	saTestbench	false	Enable Multi Threading.
saHSPICEEnvOptsHPP	string	saTestbench	false	HPP.
saHSPICEEnvOptsIncludePath	string	saTestbench		Search path for HSPICE include files.
saHSPICEEnvOptsNetlistLanguage	string	user	HSPICE	Netlist language for the HSPICE.
saHSPICEEnvOptsNumThreads	string	saTestbench	1	Number of threads.
saHSPICEEnvOptsOutputDataFormat	string	saTestbench	wdf	Output data format.
saHSPICEEnvOptsStopViewList	string	saTestbench	hspice hspiceD veriloga	Stop View List for netlister.
saHSPICEEnvOptsSwitchViewList	string	saTestbench	hspice hspiceD cmos.sch cmos_sch schematic veriloga	Switch View List for netlister.
saHSPICEEnvOptsUse64Bit	string	saTestbench	0	64-bit simulation.
saHSPICEFFTAlfa	string	saTestbench	3	HSPICE FFT Alfa.
saHSPICEFFTfmax	string	saTestbench		HSPICE FFT Maximum Frequency (Hz).
saHSPICEFFTfmin	string	saTestbench		HSPICE FFT Minimum Frequency (Hz).
saHSPICEFFTFormat	string	saTestbench	NORM	HSPICE FFT Format.
saHSPICEFFTFreq	string	saTestbench		HSPICE FFT Analysis Frequency (Hz).

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEFFTNumPoints	string	saTestbench		HSPICE FFT Number of Points.
saHSPICEFFTOutputType	string	saTestbench	Voltage	HSPICE FFT Output Variable.
saHSPICEFFTStart	string	saTestbench		HSPICE FFT Start Time.
saHSPICEFFTStop	string	saTestbench		HSPICE FFT Stop Time.
saHSPICEFFTWindow	string	saTestbench	RECT	HSPICE FFT Window Type.
saHSPICEHBACNumPoints	string	saTestbench		HSPICE HBAC sweep number of points.
saHSPICEHBACPOI	string	saTestbench		HSPICE HBAC sweep points.
saHSPICEHBACStart	string	saTestbench		HSPICE HBAC sweep start.
saHSPICEHBACStop	string	saTestbench		HSPICE HBAC sweep stop.
saHSPICEHBACSweepType	string	saTestbench	Linear	HSPICE HBAC sweep Increment Type.
saHSPICEHBDesignVar	string	saTestbench		HSPICE Harmonic Balance sweep design variable.
saHSPICEHBDesignVarUnits	string	saTestbench	dBm	HSPICE Harmonic Balance sweep design variable unit.
saHSPICEHBFund1	string	saTestbench		HSPICE Harmonic balance fundamental tone 1.
saHSPICEHBFund2	string	saTestbench		HSPICE Harmonic balance fundamental tone 2.
saHSPICEHBFund3	string	saTestbench		HSPICE Harmonic balance fundamental tone 3.
saHSPICEHBFund4	string	saTestbench		HSPICE Harmonic balance fundamental tone 4.
saHSPICEHBFund5	string	saTestbench		HSPICE Harmonic balance fundamental tone 5.
saHSPICEHBFund6	string	saTestbench		HSPICE Harmonic balance fundamental tone 6.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEHBFund7	string	saTestbench		HSPICE Harmonic balance fundamental tone 7.
saHSPICEHBIntmodmax	string	saTestbench	5	HSPICE Harmonic balance intmodmax.
saHSPICEHBNOISEIFBCoeff	string	saTestbench	-1	HSPICE Harmonic Balance Noise IFB Coefficient for OFB.
saHSPICEHBNOISEListCount	string	saTestbench	20	HSPICE HBNOISE List Count.
saHSPICEHBNOISEListFloor	string	saTestbench		HSPICE HBNOISE List Floor.
saHSPICEHBNOISEListFreq	string	saTestbench		HSPICE HBNOISE List Freq.
saHSPICEHBNOISEListFreqType	string	saTestbench	none	HSPICE HBNOISE List Freq Type.
saHSPICEHBNOISEListSources	string	saTestbench	0	HSPICE HBNOISE List Sources.
saHSPICEHBNOISENumFunds	string	saTestbench	1	HSPICE Harmonic Balance Noise Number of fundamental tones for OFB.
saHSPICEHBNOISENumPoints	string	saTestbench		HSPICE Harmonic Balance Noise sweep number of points.
saHSPICEHBNOISEOFB	string	saTestbench	0	HSPICE Harmonic Balance Noise Output Band Frequency defined.
saHSPICEHBNOISEOutputType	string	saTestbench	Voltage	HSPICE Harmonic Balance Noise Output Type.
saHSPICEHBNOISEPOI	string	saTestbench		HSPICE Harmonic Balance Noise sweep points.
saHSPICEHBNOISEStart	string	saTestbench		HSPICE Harmonic Balance Noise sweep start.
saHSPICEHBNOISEStop	string	saTestbench		HSPICE Harmonic Balance Noise sweep stop.
saHSPICEHBNOISESweepType	string	saTestbench	Linear	HSPICE Harmonic Balance Noise sweep Increment Type.
saHSPICEHBNOISEToneCoeff1	string	saTestbench	1	HSPICE Harmonic balance noise OFB coefficient for tone 1.
saHSPICEHBNOISEToneCoeff2	string	saTestbench	1	HSPICE Harmonic balance noise OFB coefficient for tone 2.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEHBNOISEToneCoeff3	string	saTestbench	1	HSPICE Harmonic balance noise OFB coefficient for tone 3.
saHSPICEHBNOISEToneCoeff4	string	saTestbench	1	HSPICE Harmonic balance noise OFB coefficient for tone 4.
saHSPICEHBNOISEToneCoeff5	string	saTestbench	1	HSPICE Harmonic balance noise OFB coefficient for tone 5.
saHSPICEHBNOISEToneCoeff6	string	saTestbench	1	HSPICE Harmonic balance noise OFB coefficient for tone 6.
saHSPICEHBNOISEToneCoeff7	string	saTestbench	1	HSPICE Harmonic balance noise OFB coefficient for tone 7.
saHSPICEHBNumFunds	string	saTestbench	2	HSPICE Harmonic balance number of fundamental tones.
saHSPICEHBNumHarm1	string	saTestbench		HSPICE Harmonic balance number of harmonics 1.
saHSPICEHBNumHarm2	string	saTestbench		HSPICE Harmonic balance number of harmonics 2.
saHSPICEHBNumHarm3	string	saTestbench		HSPICE Harmonic balance number of harmonics 3.
saHSPICEHBNumHarm4	string	saTestbench		HSPICE Harmonic balance number of harmonics 4.
saHSPICEHBNumHarm5	string	saTestbench		HSPICE Harmonic balance number of harmonics 5.
saHSPICEHBNumHarm6	string	saTestbench		HSPICE Harmonic balance number of harmonics 6.
saHSPICEHBNumHarm7	string	saTestbench		HSPICE Harmonic balance number of harmonics 7.
saHSPICEHBNumPoints	string	saTestbench		HSPICE Harmonic Balance sweep number of points.
saHSPICEHBOSCDesignVar	string	saTestbench		HSPICE Harmonic Balance oscillator sweep design variable.
saHSPICEHBOSCDesignVarUnits	string	saTestbench	dBm	HSPICE Harmonic Balance oscillator sweep design variable unit.
saHSPICEHBOSCFSP	string	saTestbench	false	HSPICE Harmonic Balance oscillator frequency search points.
saHSPICEHBOSCFSPMax	string	saTestbench		HSPICE Harmonic Balance oscillator maximum frequency for search points.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEHBOSCFSPMin	string	saTestbench		HSPICE Harmonic Balance oscillator minimum frequency for search points.
saHSPICEHBOSCFSPNum	string	saTestbench	1	HSPICE Harmonic Balance oscillator number of frequency search points.
saHSPICEHBOSCFSPStab	string	saTestbench		HSPICE Harmonic Balance oscillator stability.
saHSPICEHBOSCNSubharm	string	saTestbench	0	HSPICE Harmonic Balance oscillator number of subharmonics.
saHSPICEHBOSCNumHarms	string	saTestbench		HSPICE Harmonic Balance oscillator number of harmonics.
saHSPICEHBOSCNumPoints	string	saTestbench		HSPICE Harmonic Balance oscillator sweep number of points.
saHSPICEHBOSCPOI	string	saTestbench		HSPICE Harmonic Balance oscillator sweep points.
saHSPICEHBOSCStart	string	saTestbench		HSPICE Harmonic Balance oscillator sweep start.
saHSPICEHBOSCStop	string	saTestbench		HSPICE Harmonic Balance oscillator sweep stop.
saHSPICEHBOSC Sweep	string	saTestbench	false	HSPICE Harmonic Balance oscillator sweep.
saHSPICEHBOSC SweepType	string	saTestbench	Linear	HSPICE Harmonic Balance oscillator sweep Increment Type.
saHSPICEHBOSCTone	string	saTestbench		HSPICE Harmonic Balance approximately. oscillation frequency.
saHSPICEHBOSCTrinit	string	saTestbench		HSPICE Harmonic Balance oscillator transient init time.
saHSPICEHBOSCUseic	string	saTestbench	0	HSPICE Harmonic Balance oscillator transient init time.
saHSPICEHBOSCVp	string	saTestbench		HSPICE Harmonic Balance oscillator initial probe voltage.
saHSPICEHBPOI	string	saTestbench		HSPICE Harmonic Balance sweep points.
saHSPICEHBStart	string	saTestbench		HSPICE Harmonic Balance sweep start.
saHSPICEHBStop	string	saTestbench		HSPICE Harmonic Balance sweep stop.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEHBSweep	string	saTestbench	false	HSPICE Harmonic Balance sweep.
saHSPICEHBSweepType	string	saTestbench	Linear	HSPICE Harmonic Balance sweep Increment Type.
saHSPICEHBUseIntmodmax	string	saTestbench	true	HSPICE use the Harmonic balance intmodmax option.
saHSPICEHBXFNumPoints	string	saTestbench		HSPICE HBXF sweep number of points.
saHSPICEHBXFOutputType	string	saTestbench	Voltage	HSPICE HBXF Output Type.
saHSPICEHBXFPOI	string	saTestbench		HSPICE HBXF sweep points.
saHSPICEHBXFStart	string	saTestbench		HSPICE HBXF sweep start.
saHSPICEHBXFStop	string	saTestbench		HSPICE HBXF sweep stop.
saHSPICEHBXFSweepType	string	saTestbench	Linear	HSPICE HBXF sweep Increment Type.
saHSPICEImportFileMasks	string	user	"SPICE (*.sp *.spi)" "Circuit (*.cir *.ckt)" "All Files (*)"	List of import file mask patterns.
saHSPICEIncludeSchematicNetlist	bool	user	true	Copy (true) or .include (false) the structural netlist in the final netlist. Valid values: true, false
saHSPICELibrariesImport	string	saTestbench	Import	HSPICE libraries Import Setting.
saHSPICELINDataFormat	string	saTestbench		HSPICE LIN Data Format.
saHSPICELINFormat	string	saTestbench	selem	HSPICE LIN Format.
saHSPICELINFreqDigit	string	saTestbench		HSPICE LIN Frequency Precision.
saHSPICELINGroupDelay	string	saTestbench	0	HSPICE LIN Group Delay.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICELINLevel	string	saTestbench	Two Port (1)	HSPICE LIN Noise Level.
saHSPICELINListCount	string	saTestbench		HSPICE LIN List Count.
saHSPICELINListFloor	string	saTestbench	0	HSPICE LIN List Floor.
saHSPICELINListFreq	string	saTestbench		HSPICE LIN List Freq.
saHSPICELINListFreqType	string	saTestbench	all	HSPICE LIN List Freq Type.
saHSPICELINListSources	string	saTestbench	0	HSPICE LIN List Sources.
saHSPICELINMixedMode	string	saTestbench		HSPICE LIN Mixed Mode Data Map.
saHSPICELINModel	string	saTestbench		HSPICE LIN Model Name.
saHSPICELINNoise	string	saTestbench	0	HSPICE LIN Perform Noise Analysis.
saHSPICELINParams	string	saTestbench	1	HSPICE LIN Extract S Parameters.
saHSPICELINSparDigit	string	saTestbench		HSPICE LIN S Parameter Precision.
saHSPICELINUseDataFormat	string	saTestbench	1	HSPICE LIN Use Simulator Default for Data Format.
saHSPICELSTBMode	string	user	Single	HSPICE LSTB Mode.
saHSPICELSTBVsource1	string	user		HSPICE LSTB Source 1.
saHSPICELSTBVsource2	string	user		HSPICE LSTB Source 2.
saHSPICEMeasuresImport	string	saTestbench	Import	HSPICE measures Import Setting.
saHSPICEModelGroups	string	saTestbench		Model groups for HSPICE
saHSPICEModelGroupsCheckBox	bool	saTestbench	false	Visibility of Model Groups table for HSPICE. Valid values: true, false
saHSPICEModelsFiles	string	saTestbench		Model files for HSPICE.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEModelsImport	string	saTestbench	Import	HSPICE models Import Setting.
saHSPICEModelsIncludePath	string	saTestbench		Search path for HSPICE model files.
saHSPICEMonteCarloIterList	string	saTestbench		List of iterations.
saHSPICEMonteCarloLHSReplicas	string	saTestbench	1	Runs replicates of Latin Hypercube samples
saHSPICEMonteCarloNumIter	string	saTestbench	10	Number of iterations for Monte Carlo analysis.
saHSPICEMonteCarloOFATIntervals	string	saTestbench	1	Generate 2n+1 equally spaced samples for each OFAT variable
saHSPICEMonteCarloOFATOneSided	bool	saTestbench	false	Enable/disable one-sided intervals
saHSPICEMonteCarloOFATOneSidedValue	string	saTestbench	0.5	Generate 2n+1 equally spaced samples for each OFAT variable
saHSPICEMonteCarloSamplingMethod	string	saTestbench	SRS	Enables advanced sampling methods.
saHSPICEMonteCarloSaveBinaryOpFiles	string	saTestbench	0	Save Operation Points as PSF/WDF files.
saHSPICEMonteCarloSeed	string	saTestbench	1	Starting seed for the random-number generator in Monte Carlo analysis.
saHSPICEMonteCarloSigmaScale	string	saTestbench	2.0	Sigma Scale Factor for High Sigma Applications.
saHSPICEMonteCarloStartIter	string	saTestbench	1	Starting iteration for Monte Carlo analysis.
saHSPICEMonteCarloUserIterList	string	saTestbench	0	Use iteration list.
saHSPICEMonteCarloUseRandomSeed	string	saTestbench	0	Overrides seed value and uses a random number.
saHSPICEMonteCarloUseSigmaScaling	string	saTestbench	0	Uses Sigma Scaling for High Sigma Applications.
saHSPICEMonteCarloVariationIncludeOrExclude	string	saTestbench	Include	Whether statistical variation is to be applied or not applied to the specified instances/cells.

Table 31 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saHSPICEMonteCarloVariationInstanceOrCellList	string	saTestbench		List of instances or cells for which statistical variation is to be applied/not applied.
saHSPICEMonteCarloVariationObjectType	string	saTestbench	Instances	Object type (instances or cells) for which statistical variation is to be applied/not applied.
saHSPICENOISEInterval	string	saTestbench		HSPICE NOISE Frequency Interval.
saHSPICENOISEListCkt	string	saTestbench	0	HSPICE NOISE List Subcircuits.
saHSPICENOISEListCount	string	saTestbench	20	HSPICE NOISE List Count.
saHSPICENOISEListFloor	string	saTestbench		HSPICE NOISE List Floor.
saHSPICENOISEListFreqType	string	saTestbench	all	HSPICE NOISE List Freq Type.
saHSPICENOISEListType	string	saTestbench	0	HSPICE NOISE List Noise Type.
saHSPICENOISEOutputType	string	saTestbench	Voltage	HSPICE NOISE Output Type.
saHSPICENOISEPortNoise	string	saTestbench	1	HSPICE NOISE Port Noise.
saHSPICENoiseSummaryAbsoluteThreshold	string	user	0	Noise Summary Truncate Absolute Threshold.
saHSPICENoiseSummaryIncludeBreakdown	string	user	0	Noise Summary Include Noise Breakdown.
saHSPICENoiseSummaryIncludeDeviceParameters	string	user	false	Noise Summary Include Device Parameters.
saHSPICENoiseSummaryNoiseCategory	string	user	Total	Noise Summary Results To Be Shown.
saHSPICENoiseSummaryNoiseOption	saHSPICENOISESummaryNoiseOptionEnum	user	Spot Noise	Noise Summary Option. Valid values: {Spot Noise} {Integrated Noise}
saHSPICENoiseSummaryRelativeThreshold	string	user	0	Noise Summary Truncate Relative Threshold.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICENoiseSummarySumIteratedInstances	string	user	true	Noise Summary Sum Iterated Instances.
saHSPICENoiseSummaryTopContributors	string	user	5	Noise Summary Truncate Top Contributors.
saHSPICENoiseSummaryTruncateType	string	user	None	Noise Summary Truncate Type.
saHSPICENoiseSummaryUnit	string	user	V/sqrt(Hz)	Noise Summary Unit.
saHSPICEOPFormat	string	saTestbench	All	HSPICE Operating point analysis format option.
saHSPICEOPFormat2	string	saTestbench	All	HSPICE Operating point analysis format2 option.
saHSPICEOPFormat3	string	saTestbench	All	HSPICE Operating point analysis format3 option.
saHSPICEOPFormat4	string	saTestbench	All	HSPICE Operating point analysis format4 option.
saHSPICEOPFormat5	string	saTestbench	All	HSPICE Operating point analysis format5 option.
saHSPICEOPFormat6	string	saTestbench	All	HSPICE Operating point analysis format6 option.
saHSPICEOPInterpolation	string	saTestbench	false	HSPICE Operating point interpolation.
saHSPICEOPNumFormats	string	saTestbench	1	HSPICE Operating point numFormats.
saHSPICEOPTime	string	saTestbench	0	HSPICE Operating point save time.
saHSPICEOPTime2	string	saTestbench	0	HSPICE Operating point save time2.
saHSPICEOPTime3	string	saTestbench	0	HSPICE Operating point save time3.
saHSPICEOPTime4	string	saTestbench	0	HSPICE Operating point save time4.
saHSPICEOPTime5	string	saTestbench	0	HSPICE Operating point save time5.
saHSPICEOPTime6	string	saTestbench	0	HSPICE Operating point save time6.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionABSH	string	custom	0.0	HSPICE option ABSH: Absolute current change through voltage-defined branches.
saHSPICEOptionABSHUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionABSH is loaded.
saHSPICEOptionABSI	string	custom	1e-9	HSPICE option ABSI: Absolute error tolerance for branch circuits in diodes, BJT's and JFETs in DC or tran.
saHSPICEOptionABSIUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionABSI is loaded.
saHSPICEOptionABSMOS	string	custom	1e-6	HSPICE option ABSMOS:
saHSPICEOptionABSMOSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionABSMOS is loaded.
saHSPICEOptionABSTOL	string	custom	1e-9	HSPICE option ABSTOL: Absolute error tolerance for branch currents in DC or tran.
saHSPICEOptionABSTOLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionABSTOL is loaded.
saHSPICEOptionABSV	string	custom	50u	HSPICE option ABSV:
saHSPICEOptionABSVAR	string	custom	0.5	HSPICE option ABSVAR: Absolute limit for maximum voltage change between time points.
saHSPICEOptionABSVARUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionABSVAR is loaded.
saHSPICEOptionABSVDC	string	custom	50u	HSPICE option ABSVDC: Minimum voltage in DC or tran.
saHSPICEOptionABSVDCUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionABSVDC is loaded.
saHSPICEOptionABSVUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionABSV is loaded.
saHSPICEOptionACCT	string	custom	1	HSPICE option ACCT: Generates a detailed accounting report.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionACCTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionACCT is loaded.
saHSPICEOptionACCURATE	string	custom	0	HSPICE option ACCURATE: Selects a time algorithm for circuits.
saHSPICEOptionACCURATEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionACCURATE is loaded.
saHSPICEOptionagepwinteg	string	saTestbench	0	HSPICE option age_pw_integ: Controls new mosra measure result.
saHSPICEOptionagepwintegUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionagepwinteg is loaded.
saHSPICEOptionALTCC	string	custom	0	HSPICE option ALTCC: Option to enable HSPICE to read the input netlist only once for multiple .ALTER commands.
saHSPICEOptionALTCCUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionALTCC is loaded.
saHSPICEOptionALTCHK	string	custom	0	HSPICE option ALTCHK: Disables (or re-enables) topology checking in redefined elements.
saHSPICEOptionALTCHKUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionALTCHK is loaded.
saHSPICEOptionAUTOFLAT	string	custom	0	HSPICE option AUTOFLAT: Auto promotion of operating point data to subcircuit if only one subcircuit instance, like .FLAT.
saHSPICEOptionAUTOFLATUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionAUTOFLAT is loaded.
saHSPICEOptionAUTOSTOP	string	custom	0	HSPICE option AUTOSTOP: Stops a transient analysis
saHSPICEOptionAUTOSTOPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionAUTOSTOP is loaded.
saHSPICEOptionBAACTIVEHIER	string	custom	0	HSPICE option BA_ACTIVEHIER: Flag for specifying if full hierarchical net names should be annotated.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionBAACTIVEHIERUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBAACTIVEHIER is loaded.
saHSPICEOptionBAADDPARAM	string	custom		HSPICE option BA_ADDPARAM: List parameters that are to be scaled, linearly and quadratically, respectively.
saHSPICEOptionBAADDPARAMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBAADDPARAM is loaded.
saHSPICEOptionBACOUPLING	string	custom	0	HSPICE option BA_COUPLING: Treatment method about coupling capacitors.
saHSPICEOptionBACOUPLINGUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBACOUPLING is loaded.
saHSPICEOptionBADPFPPFX	string	custom		HSPICE option BA_DPFPFX: Extra prefix to add when searching ideal netlist for instances referenced by the parasitic file
saHSPICEOptionBADPFPPFXUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBADPFPPFX is loaded.
saHSPICEOptionBAERROR	string	custom	1	HSPICE option BA_ERROR: Method to handle an error on nets.
saHSPICEOptionBAERRORUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBAERROR is loaded.
saHSPICEOptionBAFINGERDELIM	string	custom		HSPICE option BA_FINGERDELIM: Character specified for finger device
saHSPICEOptionBAFINGERDELIMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBAFINGERDELIM is loaded.
saHSPICEOptionBAGEOSHRINK	string	custom		HSPICE option BA_GEOSHRINK: Scaling factor for geometric parameters of element instances in DPF file
saHSPICEOptionBAGEOSHRINKUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBAGEOSHRINK is loaded.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionBAHIERDELIM	string	custom		HSPICE option BA_HIERDELIM: Character specified for hierarchical separator in DPF file
saHSPICEOptionBAHIERDELIMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBAHIERDELIM is loaded.
saHSPICEOptionBAIDEALPFX	string	custom		HSPICE option BA_IDEALPFX: Extra prefix to add a second prefix when searching ideal netlist
saHSPICEOptionBAIDEALPFXUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBAIDEALPFX is loaded.
saHSPICEOptionBAMERGEPORT	string	custom	1	HSPICE option BA_MERGEPORT: Decide whether to merge net ports into one node.
saHSPICEOptionBAMERGEPORTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBAMERGEPORT is loaded.
saHSPICEOptionBAPRINT	string	custom	IDEAL	HSPICE option BA_PRINT: Control whether to output nodes and resistors/capacitors introduced by back-annotation
saHSPICEOptionBAPRINTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBAPRINT is loaded.
saHSPICEOptionBASCALE	string	custom		HSPICE option BA_SCALE: Element scaling factor for instances in DPF file
saHSPICEOptionBASCALEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBASCALE is loaded.
saHSPICEOptionBATERMINAL	string	custom		HSPICE option BA_TERMINAL: Mapping characters for parameters for back annotation terminal name
saHSPICEOptionBATERMINALUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBATERMINAL is loaded.
saHSPICEOptionBIASINTERVAL	string	custom	0	HSPICE option BIASINTERVAL: Controls the level of information output during transient analysis.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionBIASINTERVAL UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBIASINTERVAL is loaded.
saHSPICEOptionBIASNODE	string	custom	0	HSPICE option BIASNODE: Specifies whether to use node names or port names in element commands.
saHSPICEOptionBIASNODEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBIASNODE is loaded.
saHSPICEOptionBIASPARALLEL	string	custom	0	HSPICE option BIASPARALLEL: Controls whether .BIASCHK sweeps the parallel elements being monitored.
saHSPICEOptionBIASPARALLEL UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBIASPARALLEL is loaded.
saHSPICEOptionBIAWARN	string	custom	0	HSPICE option BIAWARN: Outputs warning messages when local max bias voltage exceeds limit during transient analysis.
saHSPICEOptionBIAWARNUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBIAWARN is loaded.
saHSPICEOptionBPNMATCHTOL	string	custom	0.5	HSPICE option BPNMATCHTOL: Determines the minimum required match between the NLP and PAC phase noise algorithms in HSPICE RF.
saHSPICEOptionBPNMATCHTOL UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBPNMATCHTOL is loaded.
saHSPICEOptionBRIEF	string	custom	0	HSPICE option BRIEF: Terminate echoing (printback) of the data file to stdout until HSPICE finds an .OPTION BRIEF=0 or the .END command.
saHSPICEOptionBRIEFUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBRIEF is loaded.
saHSPICEOptionBYPASS	string	custom		HSPICE option BYPASS: Bypasses model evaluations if the terminal voltages stay constant.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionBYPASSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBYPASS is loaded.
saHSPICEOptionBYTOL	string	custom	100e-6	HSPICE option BYTOL: Voltage tolerance at which a MOSFET, MESFET, JFET, BJT, or diode becomes latent.
saHSPICEOptionBYTOLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionBYTOL is loaded.
saHSPICEOptionCAPTAB	string	custom	0	HSPICE option CAPTAB: Print a compiled table of single-plate node capacitances for diodes, BJTs, MOSFETs, JFETs, and passive capacitors at each operating point.
saHSPICEOptionCAPTABUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionCAPTAB is loaded.
saHSPICEOptionCMIFLAG	string	custom	0	HSPICE option CMIFLAG: Loads and links the dynamically linked Common Model Interface (CMI) library.
saHSPICEOptionCMIFLAGUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionCMIFLAG is loaded.
saHSPICEOptionCMIVTH	string	custom	0	HSPICE option CMIVTH: Enables invocation of one additional CMI model function call when convergence criteria is met.
saHSPICEOptionCMIVTHUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionCMIVTH is loaded.
saHSPICEOptionCONVERGE	string	custom	0	HSPICE option CONVERGE: Methods for solving nonconvergence problems.
saHSPICEOptionCONVERGEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionCONVERGE is loaded.
saHSPICEOptionCSHDC	string	custom	1.00p	HSPICE option CSHDC: Capacitance from each node to ground; used only with the CONVERGENCE option.
saHSPICEOptionCSHDCUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionCSHDC is loaded.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionCSHUNT	string	custom	0	HSPICE option CSHUNT: Add capacitance from each node to ground.
saHSPICEOptionCSHUNTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionCSHUNT is loaded.
saHSPICEOptionCUSTCMI	string	custom	0	HSPICE option CUSTCMI: Turns on gate direct tunneling current modeling and instance parameter support.
saHSPICEOptionCUSTCMIUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionCUSTCMI is loaded.
saHSPICEOptionDCCAP	string	custom	0	HSPICE option DCCAP: Generates C-V plots.
saHSPICEOptionDCCAPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionDCCAP is loaded.
saHSPICEOptionDCIC	string	custom	1	HSPICE option DCIC: Specifies whether to use or ignore .IC commands in the netlist.
saHSPICEOptionDCICUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionDCIC is loaded.
saHSPICEOptionDCON	string	custom	0	HSPICE option DCON: Disables autoconvergence (when DCON=-1 and CONVERGENCE=-1).
saHSPICEOptionDCONUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionDCON is loaded.
saHSPICEOptionDCSTEP	string	custom	0	HSPICE option DCSTEP: Converts DC model and element capacitors to a conductance to enhance DC convergence properties.
saHSPICEOptionDCSTEPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionDCSTEP is loaded.
saHSPICEOptionDELMAX	string	custom		HSPICE option DELMAX: Maximum allowable step size of the timesteps taken during transient analysis.
saHSPICEOptionDELMAXUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionDELMAX is loaded.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionDIAGNOSTIC	string	custom	1	HSPICE option DIAGNOSTIC: Logs the occurrence of negative model conductances.
saHSPICEOptionDIAGNOSTICUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionDIAGNOSTIC is loaded.
saHSPICEOptionDIBIS	string	custom		HSPICE option D_IBIS: Specifies the directory containing the IBIS files.
saHSPICEOptionDIBISUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionDIBIS is loaded.
saHSPICEOptionDV	string	custom	1000	HSPICE option DV: Maximum iteration to iteration voltage change for all circuit nodes.
saHSPICEOptionDVDT	string	custom	4	HSPICE option DVDT: Adjusts the timestep based on rates of change for node voltage.
saHSPICEOptionDVDTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionDVDT is loaded.
saHSPICEOptionDVUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionDV is loaded.
saHSPICEOptionengine	string	custom	PrimeSim HSPICE	HSPICE option engine: Simulation Engine
saHSPICEOptionengineUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionengine is loaded.
saHSPICEOptionEXTOP	string	custom	0	HSPICE option EXT_OP: Controls set of operating points saved.
saHSPICEOptionEXTOPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionEXTOP is loaded.
saHSPICEOptionFFTOUT	string	custom	0	HSPICE option FFTOUT: Prints 30 harmonic fundamentals.
saHSPICEOptionFFTOUTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionFFTOUT is loaded.
saHSPICEOptionFMAX	string	custom	1e12	HSPICE option FMAX: Maximum Frequency.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionFMAXUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionFMAX is loaded.
saHSPICEOptionGDCPATH	string	custom	1e-15	HSPICE option GDCPATH: Adds conductance to nodes having no dc path to ground.
saHSPICEOptionGDCPATHUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionGDCPATH is loaded.
saHSPICEOptionGENK	string	custom	1	HSPICE option GENK: Automatically computes second-order mutual inductance for several coupled inductors.
saHSPICEOptionGENKUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionGENK is loaded.
saHSPICEOptionGMIN	string	custom	1e-12	HSPICE option GMIN: Minimum conductance added to all PN junctions for a time sweep in transient analysis.
saHSPICEOptionGMINDC	string	custom	1e-12	HSPICE option GMINDC: Conductance in parallel for PN junctions and MOSFET nodes in DC.
saHSPICEOptionGMINDCUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionGMINDC is loaded.
saHSPICEOptionGMINUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionGMIN is loaded.
saHSPICEOptionGRAMP	string	custom	0	HSPICE option GRAMP: Conductance range over which DC operating point analysis sweeps GMINDC.
saHSPICEOptionGRAMPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionGRAMP is loaded.
saHSPICEOptionGSHDC	string	custom	0	HSPICE option GSHDC: Conductance from each node to ground when calculating the DC operating point.
saHSPICEOptionGSHDCUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionGSHDC is loaded.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionGSHUNT	string	custom	0	HSPICE option GSHUNT: Add conductance from each node to ground.
saHSPICEOptionGSHUNTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionGSHUNT is loaded.
saHSPICEOptionHBACKRYLOVDIM	string	custom	300	HSPICE option HBACKRYLOVDIM: Specifies the dimension of the Krylov subspace used by the Krylov solver.
saHSPICEOptionHBACKRYLOVDIMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBACKRYLOVDIM is loaded.
saHSPICEOptionHBACKRYLOVITER	string	custom	1000	HSPICE option HBACKRYLOVITER: Specifies the number of GMRES solver iterations performed by the HB engine.
saHSPICEOptionHBACKRYLOVITERUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBACKRYLOVITER is loaded.
saHSPICEOptionHBACTOL	string	custom	1.e-8	HSPICE option HBACTOL: Specifies the absolute error tolerance for determining convergence.
saHSPICEOptionHBACTOLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBACTOL is loaded.
saHSPICEOptionHBCONTINUE	string	custom	1	HSPICE option HBCONTINUE: Specifies whether to use the sweep solution from the previous simulation as the initial guess for the present simulation.
saHSPICEOptionHBCONTINUEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBCONTINUE is loaded.
saHSPICEOptionHBFREQABSTOL	string	custom	1.0	HSPICE option HBFREQABSTOL: Specifies the maximum absolute change in frequency between solver iterations for convergence.
saHSPICEOptionHBFREQABSTOLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBFREQABSTOL is loaded.

Table 31 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saHSPICEOptionHBFREQREL TOL	string	custom	1.e-9	HSPICE option HBFREQREL TOL: Specifies the maximum relative change in frequency between solver iterations for convergence.
saHSPICEOptionHBFREQREL TOLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBFREQREL TOL is loaded.
saHSPICEOptionHBGIBBS	string	custom	0	HSPICE option HB_GIBBS: Option for HBTRAN output to minimize Gibbs phenonema.
saHSPICEOptionHBGIBBSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBGIBBS is loaded.
saHSPICEOptionHBJREUSE	string	custom		HSPICE option HBJREUSE: Controls when to recalculate the Jacobson matrix.
saHSPICEOptionHBJREUSE TOL	string	custom	0.05	HSPICE option HBJREUSE TOL: Determines when to recalculate Jacobian matrix if HBJREUSE=1.0.
saHSPICEOptionHBJREUSE TOLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBJREUSE TOL is loaded.
saHSPICEOptionHBJREUSEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBJREUSE is loaded.
saHSPICEOptionHBKRYLOVDIM	string	custom	40	HSPICE option HBKRYLOVDIM: Specifies the dimension of the subspace used by the Krylov solver.
saHSPICEOptionHBKRYLOVDIMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBKRYLOVDIM is loaded.
saHSPICEOptionHBKRYLOVMAX ITER	string	custom	500	HSPICE option HBKRYLOVMAX ITER: Specifies the maximum number of GMRES solver iterations performed by the HB engine.
saHSPICEOptionHBKRYLOVMAX ITERUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBKRYLOVMAX ITER is loaded.
saHSPICEOptionHBKRYLOVTOL	string	custom	0.01	HSPICE option HBKRYLOVTOL: Specifies the error tolerance for the Krylov solver.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionHBKRYLOVTOL UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBKRYLOVTOL is loaded.
saHSPICEOptionHBLINESEARCH FAC	string	custom	0.35	HSPICE option HBLINESEARCHFAC: Specifies the line search factor.
saHSPICEOptionHBLINESEARCH FACUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBLINESEARCHFAC is loaded.
saHSPICEOptionHBMAXITER	string	custom	10000	HSPICE option HBMAXITER: Specifies the maximum number of Newton-Raphson iterations performed by the HB engine.
saHSPICEOptionHBMAXITERUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBMAXITER is loaded.
saHSPICEOptionHBOSCMAXITER	string	custom	10000	HSPICE option HBOSCMAXITER: Specifies the maximum number of outer-loop iterations for oscillator analysis.
saHSPICEOptionHBOSCMAXITERUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBOSCMAXITER is loaded.
saHSPICEOptionHBPROBETOL	string	custom	1.e-9	HSPICE option HBPROBETOL: Searches for a probe voltage at which the probe current is less than the specified value.
saHSPICEOptionHBPROBETOLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBPROBETOL is loaded.
saHSPICEOptionHBSOLVER	string	custom	1	HSPICE option HBSOLVER: Specifies a preconditioner for solving nonlinear circuits.
saHSPICEOptionHBSOLVERUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBSOLVER is loaded.
saHSPICEOptionHBTOL	string	custom	1.e-9	HSPICE option HBTOL: Specifies the absolute error tolerance for determining convergence.
saHSPICEOptionHBTOLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBTOL is loaded.

Table 31 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saHSPICEOptionHBTRANFREQSEARCH	string	custom	1	HSPICE option HBTRANFREQSEARCH: Specifies the frequency source for the HB analysis of a ring oscillator.
saHSPICEOptionHBTRANFREQSEARCHUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBTRANFREQSEARCH is loaded.
saHSPICEOptionHBTRANINIT	string	custom	0	HSPICE option HBTRANINIT: Selects transient analysis for initializing all state variables for HB analysis of a ring oscillator.
saHSPICEOptionHBTRANINITUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBTRANINIT is loaded.
saHSPICEOptionHBTRANPTS	string	custom		HSPICE option HBTRANPTS: Specifies the number of points per period for converting time-domain data results into the frequency domain for HB analysis of a ring oscillator.
saHSPICEOptionHBTRANPTSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBTRANPTS is loaded.
saHSPICEOptionHBTRANSTEP	string	custom		HSPICE option HBTRANSTEP: Specifies transient analysis step size for the HB analysis of a ring oscillator.
saHSPICEOptionHBTRANSTEPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHBTRANSTEP is loaded.
saHSPICEOptionHIERSCALE	string	custom	0	HSPICE option HIER_SCALE: Uses S-parameters to scale subcircuits.
saHSPICEOptionHIERSCALEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionHIERSCALE is loaded.
saHSPICEOptionICSWEEP	string	custom	1	HSPICE option ICSWEEP: Saves the current analysis result of a parameter or temperature sweep as the starting point in the next analysis.
saHSPICEOptionICSWEEPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionICSWEEP is loaded.
saHSPICEOptionIGNOREGLOBALVARIATION	string	custom	0	HSPICE option IGNORE_GLOBAL_VARIATION: Exclude effects of global variations in simulation.

Table 31 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saHSPICEOptionIGNOREGLOBALVARIATIONUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionIGNOREGLOBALVARIATION is loaded.
saHSPICEOptionIGNOREINTERCONNECTVARIATION	string	custom	0	HSPICE option IGNORE_INTERCONNECT_VARIATION: Exclude effects of interconnect variations in simulation.
saHSPICEOptionIGNOREINTERCONNECTVARIATIONUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionIGNOREINTERCONNECTVARIATION is loaded.
saHSPICEOptionIGNORELOCALVARIATION	string	custom	0	HSPICE option IGNORE_LOCAL_VARIATION: Exclude effects of local variations in simulation.
saHSPICEOptionIGNORELOCALVARIATIONUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionIGNORELOCALVARIATION is loaded.
saHSPICEOptionIGNORESPATIALVARIATION	string	custom	0	HSPICE option IGNORE_SPATIAL_VARIATION: Exclude effects of spatial variations in simulation.
saHSPICEOptionIGNORESPATIALVARIATIONUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionIGNORESPATIALVARIATION is loaded.
saHSPICEOptionIGNOREVARIATIONBLOCK	string	custom	0	HSPICE option IGNORE_VARIATION_BLOCK: Ignore the variation block and execute a previous style Monte Carlo analysis.
saHSPICEOptionIGNOREVARIATIONBLOCKUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionIGNOREVARIATIONBLOCK is loaded.
saHSPICEOptionINGOLD	string	custom	0	HSPICE option INGOLD: Controls whether HSPICE prints output in exponential form or engineering notation.
saHSPICEOptionINGOLDUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionINGOLD is loaded.
saHSPICEOptionITL1	string	custom	200	HSPICE option ITL1: Maximum DC iteration limit.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionITL1UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionITL1 is loaded.
saHSPICEOptionITL2	string	custom	50	HSPICE option ITL2: Iteration limit for the DC transfer curve.
saHSPICEOptionITL2UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionITL2 is loaded.
saHSPICEOptionITL3	string	custom	3	HSPICE option ITL3: Minimum timestep in timestep algorithms.
saHSPICEOptionITL3UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionITL3 is loaded.
saHSPICEOptionITL4	string	custom	8	HSPICE option ITL4: Maximum timestep in timestep algorithms.
saHSPICEOptionITL4UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionITL4 is loaded.
saHSPICEOptionITLPTRAN	string	custom	30	HSPICE option ITLPTRAN: Iteration limit used in final try of pseudo-transient method.
saHSPICEOptionITLPTRANUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionITLPTRAN is loaded.
saHSPICEOptionITLPZ	string	custom	100	HSPICE option ITLPZ: Iteration limit for pole/zero analysis.
saHSPICEOptionITLPZUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionITLPZ is loaded.
saHSPICEOptionIVTH	string	saTestbench		HSPICE option IVTH: Invokes a constant-current threshold voltage probing and characterization function for nmos and pmos.
saHSPICEOptionIVTHN	string	saTestbench		HSPICE option IVTHN: Invokes a constant-current threshold voltage probing and characterization function for nmos.
saHSPICEOptionIVTHNUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionIVTHN is loaded.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionIVTHP	string	saTestbench	0	HSPICE option IVTHP: Invokes a constant-current threshold voltage probing and characterization function for pmos.
saHSPICEOptionIVTHPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionIVTHP is loaded.
saHSPICEOptionIVTHUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionIVTH is loaded.
saHSPICEOptionKCLTEST	string	custom	0	HSPICE option KCLTEST: Activates KCL test.
saHSPICEOptionKCLTESTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionKCLTEST is loaded.
saHSPICEOptionLAFREQ	string	custom	1e9	HSPICE option LA_FREQ: Upper frequency for which accuracy must be preserved..
saHSPICEOptionLAFREQUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionLAFREQ is loaded.
saHSPICEOptionLAMAXR	string	custom	1e15	HSPICE option LA_MAXR: Maximum resistance for linear matrix reduction.
saHSPICEOptionLAMAXRUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionLAMAXR is loaded.
saHSPICEOptionLAMINC	string	custom	1e-16	HSPICE option LA_MINC: Minimum capacitance for linear matrix reduction.
saHSPICEOptionLAMINCUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionLAMINC is loaded.
saHSPICEOptionLATIME	string	custom	1e-09	HSPICE option LA_TIME: Minimum time for which accuracy must be preserved.
saHSPICEOptionLATIMEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionLATIME is loaded.
saHSPICEOptionLATOL	string	custom	0.05	HSPICE option LA_TOL: Error tolerance for the PACT and LNE algorithms.
saHSPICEOptionLATOLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionLATOL is loaded.

Table 31 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saHSPICEOptionLENNAM	string	custom	16	HSPICE option LENNAM: Maximum name length for printing operating point analysis results.
saHSPICEOptionLENNAMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionLENNAM is loaded.
saHSPICEOptionLISNEW	string	custom	0	HSPICE option LIS_NEW: Activate several streamlining improvements to the *.lis file..
saHSPICEOptionLISNEWUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionLISNEW is loaded.
saHSPICEOptionLIST	string	custom	0	HSPICE option LIST: Prints a list of netlist elements, node connections, and more.
saHSPICEOptionLISTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionLIST is loaded.
saHSPICEOptionLOADHB	string	custom		HSPICE option LOADHB: Loads state variable information from a specified file.
saHSPICEOptionLOADHBUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionLOADHB is loaded.
saHSPICEOptionLOADSNINIT	string	custom		HSPICE option LOADSNINIT: Loads the operating point saved at the end of Shooting Newton analysis initialization.
saHSPICEOptionLOADSNINITUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionLOADSNINIT is loaded.
saHSPICEOptionLVLTIM	string	custom	1	HSPICE option LVLTIM: Timestep algorithm for transient analysis.
saHSPICEOptionLVLTIMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionLVLTIM is loaded.
saHSPICEOptionMACMOD	string	custom	0	HSPICE option MACMOD: To access the subcircuit definition when there is no matching model reference
saHSPICEOptionMACMODUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionMACMOD is loaded.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionMAXORD	string	custom	2	HSPICE option MAXORD: Specifies the maximum order of integration for the GEAR method.
saHSPICEOptionMAXORDUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionMAXORD is loaded.
saHSPICEOptionMAXWARNS	string	custom	5	HSPICE option MAXWARNS: Specifies maximum number of safe operating area (SOA) warning messages.
saHSPICEOptionMAXWARNSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionMAXWARNS is loaded.
saHSPICEOptionMCBRIEF	string	custom	2	HSPICE option MCBRIEF: Controls how HSPICE outputs Monte Carlo parameters.
saHSPICEOptionMCBRIEFUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionMCBRIEF is loaded.
saHSPICEOptionMCFILEONLY	string	custom	0	HSPICE option MC_FILE_ONLY: Generates a random number sample file (*.mc0) without invoking any analysis.
saHSPICEOptionMCFILEONLYUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionMCFILEONLY is loaded.
saHSPICEOptionMEASDGT	string	custom	4	HSPICE option MEASDGT: Controls the listing printout accuracy.
saHSPICEOptionMEASDGTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionMEASDGT is loaded.
saHSPICEOptionMEASFILE	string	custom	0	HSPICE option MEASFILE: Controls whether measure information outputs to single or multiple files when an .ALTER command is present in the netlist.
saHSPICEOptionMEASFILEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionMEASFILE is loaded.
saHSPICEOptionMEASOUT	string	custom	0	HSPICE option MEASOUT: Outputs .MEASURE command values and sweep parameters into an ASCII file.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionMEASOUTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionMEASOUT is loaded.
saHSPICEOptionMETHOD	string	custom	TRAP	HSPICE option METHOD: Sets the numerical integration method.
saHSPICEOptionMETHODUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionMETHOD is loaded.
saHSPICEOptionMODMONTE	string	custom	0	HSPICE option MODMONTE: Controls whether all instances of a device get the same or unique model parameters.
saHSPICEOptionMODMONTE	bool	saTestbench	0	Controls whether all instances of a device get the same or unique model parameters. Valid values: true, false
saHSPICEOptionMODMONTEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionMODMONTE is loaded.
saHSPICEOptionMODSRH	string	custom	0	HSPICE option MODSRH: Control whether HSPICE loads or references a model described in a .MODEL command, but is not used in the netlist.
saHSPICEOptionMODSRHUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionMODSRH is loaded.
saHSPICEOptionMONTECON	string	custom	1	HSPICE option MONTECON: Continues a Monte Carlo analysis by retrieving the next random value, even if non-convergence occurs.
saHSPICEOptionMONTECONUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionMONTECON is loaded.
saHSPICEOptionNEWSOA	string	custom	0	HSPICE option NEW_SOA: Print result of SOA checks to separate file (.tsoa).
saHSPICEOptionNEWSOAUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionNEWSOA is loaded.
saHSPICEOptionNODE	string	custom	0	HSPICE option NODE: Prints a node cross-reference table.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionNODEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionNODE is loaded.
saHSPICEOptionNOMOD	string	custom	0	HSPICE option NOMOD: Suppresses the printout of model parameters.
saHSPICEOptionNOMODUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionNOMOD is loaded.
saHSPICEOptionNORMALLIMIT	string	custom	4	HSPICE option NORMAL_LIMIT: Limit the range for the numbers generated by the random number generator for Normal distributions.
saHSPICEOptionNORMALLIMITUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionNORMALLIMIT is loaded.
saHSPICEOptionNUMDGT	string	custom	4	HSPICE option NUMDGT: Controls the listing printout accuracy.
saHSPICEOptionNUMDGTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionNUMDGT is loaded.
saHSPICEOptionOPFILE	string	custom	1	HSPICE option OPFILE: Output the operating point information to a file.
saHSPICEOptionOPFILEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionOPFILE is loaded.
saHSPICEOptionotherOptions	string	custom		HSPICE option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)]
saHSPICEOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionotherOptions is loaded.
saHSPICEOptionOUTPUTSIGMAVALUE	string	custom	1	HSPICE option OUTPUT_SIGMA_VALUE: Sigma value of the results.
saHSPICEOptionOUTPUTSIGMAVALUEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionOUTPUTSIGMAVALUE is loaded.
saHSPICEOptionPARHIER	string	saTestbench	GLOBAL	HSPICE option PARHIER: Sets the parameter passing rules to control the evaluation order of subcircuit parameters

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionPARHIERUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionPARHIER is loaded.
saHSPICEOptionPHASENOISEKRYLOVDIM	string	custom	500	HSPICE option PHASENOISEKRYLOVDIM: Specifies the dimension of the Krylov subspace that the Krylov solver uses.
saHSPICEOptionPHASENOISEKRYLOVDIMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionPHASENOISEKRYLOVDIM is loaded.
saHSPICEOptionPHASENOISEKRYLOVITER	string	custom	1000	HSPICE option PHASENOISEKRYLOVITER: Specifies the maximum number of Krylov iterations that the phase noise Krylov solver takes.
saHSPICEOptionPHASENOISEKRYLOVITERUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionPHASENOISEKRYLOVITER is loaded.
saHSPICEOptionPHASENOISETOL	string	custom	1e-8	HSPICE option PHASENOISETOL: Specifies the error tolerance for the phase noise solver.
saHSPICEOptionPHASENOISETOLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionPHASENOISETOL is loaded.
saHSPICEOptionPHNOISEAMPM	string	custom		HSPICE option PHNOISEAMPM: Allows you to separate amplitude modulation and phase modulation components in a phase noise simulation.
saHSPICEOptionPHNOISEAMPMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionPHNOISEAMPM is loaded.
saHSPICEOptionPHNOISELORENTZ	string	custom	1	HSPICE option PHNOISELORENTZ: Turns on a Lorentzian model for the phase noise analysis.
saHSPICEOptionPHNOISELORENTZUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionPHNOISELORENTZ is loaded.
saHSPICEOptionPIVOT	string	custom	0	HSPICE option PIVOT: Pivot algorithm.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionPIVOTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionPIVOT is loaded.
saHSPICEOptionPORTVOLTAGESCALETO2X	string	custom	0	HSPICE option PORT_VOLTAGE_SCALE_TO_2X: In voltage mode, the internal port voltage will be 2X the specified value. PrimeWave Design Environment overrides default to on.
saHSPICEOptionPORTVOLTAGESCALETO2XUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionPORTVOLTAGESCALETO2X is loaded.
saHSPICEOptionPORTVOLTAGESCALETO2XUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saHSPICEOptionPOSTVERSION	string	custom	9601	HSPICE option POST_VERSION: Specifies the post-processing output version for HSPICE/HSPICE RF.
saHSPICEOptionPOSTVERSIONUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionPOSTVERSION is loaded.
saHSPICEOptionPURETP	string	custom	0	HSPICE option PURETP: Specifies the integration method to use for reversal time point.
saHSPICEOptionPURETPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionPURETP is loaded.
saHSPICEOptionPUTMEAS	string	custom	1	HSPICE option PUTMEAS: Controls the output variables listed in the .MEASURE command.
saHSPICEOptionPUTMEASUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionPUTMEAS is loaded.
saHSPICEOptionPVAOUTPUTDIR	string	saTestbench	<file path>	HSPICE option PVA_OUTPUT_DIR: Controls pva cache directory.
saHSPICEOptionPVAOUTPUTDIRUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionPVAOUTPUTDIR is loaded.
saHSPICEOptionRANDOMGENERATOR	string	saTestbench	Default	HSPICE option RANDOM_GENERATOR: Random number generator type.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionRANDOMGENE RATORUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionRANDOMGENERATOR is loaded.
saHSPICEOptionRELH	string	custom	50e-3	HSPICE option RELH: Relative current tolerance from iteration to iteration through voltage defined branches.
saHSPICEOptionRELHUncheckLo calized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionRELH is loaded.
saHSPICEOptionRELI	string	custom	10e-3	HSPICE option RELI: Relative error/tolerance change from iteration to iteration.
saHSPICEOptionRELIUncheckLoc alized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionRELI is loaded.
saHSPICEOptionRELMOS	string	custom	50e-3	HSPICE option RELMOS: Relative error/tolerance change from iteration to iteration.
saHSPICEOptionRELMOSUnchec kLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionRELMOS is loaded.
saHSPICEOptionRELTOL	string	custom	1e-3	HSPICE option RELTOL: Relative error tolerance for voltages from iteration to iteration.
saHSPICEOptionRELTOLUncheck Localized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionRELTOL is loaded.
saHSPICEOptionRELV	string	custom	1e-3	HSPICE option RELV: Relative error tolerance for voltages from iteration to iteration.
saHSPICEOptionRELVDC	string	custom	1e-3	HSPICE option RELVDC: Relative error/tolerance change for LVTIM=1 or 3 from iteration to iteration.
saHSPICEOptionRELVDCUnchec kLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionRELVDC is loaded.
saHSPICEOptionRELVUncheckLo calized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionRELV is loaded.

Table 31 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saHSPICEOptionRESMIN	string	custom	10e-6	HSPICE option RESMIN: Specifies the minimum resistance for all resistors.
saHSPICEOptionRESMINUncheck Localized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionRESMIN is loaded.
saHSPICEOptionRUNLVL	string	custom	3	HSPICE option RUNLVL: Controls runtime speed and simulation accuracy.
saHSPICEOptionRUNLVUncheck Localized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionRUNLVL is loaded.
saHSPICEOptionsaetablefmt	string	custom	1	HSPICE option saetablefmt: Format of SOA check output. If true, SOA results are returned in TSV files.
saHSPICEOptionsaetablefmtUnch eckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionsaetablefmt is loaded.
saHSPICEOptionSAVEHB	string	custom		HSPICE option SAVEHB: Saves the final-state variable values from an HB simulation.
saHSPICEOptionSAVEHBUnchec kLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionSAVEHB is loaded.
saHSPICEOptionSAVESNINIT	string	custom		HSPICE option SAVESNINIT: Saves the operating point at the end of Shooting Newton initialization (sninit).
saHSPICEOptionSAVESNINITUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionSAVESNINIT is loaded.
saHSPICEOptionSCALE	string	custom	1.00	HSPICE option SCALE: Sets the element scaling factor.
saHSPICEOptionSCALEUncheckL ocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionSCALE is loaded.
saHSPICEOptionSCALM	string	custom	1	HSPICE option SCALM: Sets the model scaling factor.
saHSPICEOptionSCALMUncheck Localized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionSCALM is loaded.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionSELEMCACHE DIR	string	saTestbench	<file path>	HSPICE option S_ELEM_CACHE_DIR: Controls s-parameter cache directory.
saHSPICEOptionSELEMCACHEDIRUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionSELEMCACHEDIR is loaded.
saHSPICEOptionSENSITIVITYANALYSIS	string	custom	1	HSPICE option SENSITIVITY_ANALYSIS: Controls the generation of a sensitivity table in the .mpp0 file.
saHSPICEOptionSENSITIVITYANALYSISUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionSENSITIVITYANALYSIS is loaded.
saHSPICEOptionSIMACCURACY	string	custom		HSPICE option SIM_ACCURACY: The size of timesteps in HSPICE RF.
saHSPICEOptionSIMACCURACYUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionSIMACCURACY is loaded.
saHSPICEOptionSIMLA	string	custom	1	HSPICE option SIM_LA: Activate linear matrix reduction.
saHSPICEOptionSIMLAUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionSIMLA is loaded.
saHSPICEOptionSNACCURACY	string	custom	10	HSPICE option SNACCURACY: Sets and modifies the size of timesteps.
saHSPICEOptionSNACCURACYUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionSNACCURACY is loaded.
saHSPICEOptionSNMAXITER	string	custom	40	HSPICE option SNMAXITER: Sets the maximum number of iterations for a Shooting Newton analysis.
saHSPICEOptionSNMAXITERUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionSNMAXITER is loaded.
saHSPICEOptionSPLITDP	string	custom	1	HSPICE option SPLIT_DP: Enables the writing of multiple operating points in separate files.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionSPLITDPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionSPLITDP is loaded.
saHSPICEOptionSTREAM	string	custom	Default	HSPICE option STREAM: Integer stream number for the random number generator.
saHSPICEOptionSTREAMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionSTREAM is loaded.
saHSPICEOptionSYMB	string	custom	0	HSPICE option SYMB: Use a symbolic operating point algorithm to get initial guesses before calculating operating points.
saHSPICEOptionSYMBUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionSYMB is loaded.
saHSPICEOptionTNOM	string	custom	25	HSPICE option TNOM: Sets the reference temperature for the simulation.
saHSPICEOptionTNOMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionTNOM is loaded.
saHSPICEOptionTRANFORHB	string	custom		HSPICE option TRANFORHB: Forces HB analysis to recognize or ignore specific V/I sources.
saHSPICEOptionTRANFORHBUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionTRANFORHB is loaded.
saHSPICEOptionTRTOL	string	custom	7.00	HSPICE option TRTOL: Estimates the amount of error introduced when the timestep algorithm truncates the Taylor series expansion.
saHSPICEOptionTRTOLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionTRTOL is loaded.
saHSPICEOptionUNWRAP	string	custom	0	HSPICE option UNWRAP: Displays phase results for AC analysis in unwrapped form.
saHSPICEOptionUNWRAPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionUNWRAP is loaded.
saHSPICEOptionWACC	string	custom		HSPICE option WACC: Dynamic step control algorithm for a W element transient analysis.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEOptionWACCUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionWACC is loaded.
saHSPICEOptionWARN	string	custom	0	HSPICE option WARN: Enables or turns off SOA voltage warning message
saHSPICEOptionWARNUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionWARN is loaded.
saHSPICEOptionWL	string	custom	0	HSPICE option WL: Reverses the order of the VSIZE MOS element.
saHSPICEOptionWLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionWL is loaded.
saHSPICEOptionWNFLAG	string	custom	1	HSPICE option WNFLAG: Controls whether bin is selected based on w or w/nf.
saHSPICEOptionWNFLAGUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionWNFLAG is loaded.
saHSPICEOptionXDTEMP	string	custom	0	HSPICE option XDTEMP: Defines how HSPICE interprets the DTEMP parameter.
saHSPICEOptionXDTEMPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saHSPICEOptionXDTEMP is loaded.
saHSPICEOutputControlImport	string	saTestbench	Import	HSPICE outputControl Import Setting.
saHSPICEParasiticBackAnnotationTableColumnsShown	string	user	Enabled { Type } {Back Annotate}	Saves columns shown in the Parasitic Back Annotation table.
saHSPICEPHASENOISEAlgo	string	saTestbench		HSPICE PHASENOISE method algorithm.
saHSPICEPHASENOISECarrier	string	saTestbench	1	HSPICE PHASENOISE carrier index.
saHSPICEPHASENOISEListcount	string	saTestbench	20	HSPICE PHASENOISE List Count.
saHSPICEPHASENOISEListfloor	string	saTestbench	-300	HSPICE PHASENOISE List Floor.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEPHASENOISEListfreq	string	saTestbench		HSPICE PHASENOISE List Freq.
saHSPICEPHASENOISEListfreqType	string	saTestbench	all	HSPICE PHASENOISE List Freq Type.
saHSPICEPHASENOISEListsources	string	saTestbench	on	HSPICE PHASENOISE List Sources.
saHSPICEPHASENOISEMethod	string	saTestbench	1	HSPICE PHASENOISE method.
saHSPICEPHASENOISENumPoints	string	saTestbench		HSPICE PHASENOISE sweep number of points.
saHSPICEPHASENOISEOutputType	string	saTestbench	Voltage	HSPICE PHASENOISE Output Type.
saHSPICEPHASENOISEPOI	string	saTestbench		HSPICE PHASENOISE sweep points.
saHSPICEPHASENOISESpurious	string	saTestbench	0	HSPICE PHASENOISE spurious analysis.
saHSPICEPHASENOISEStart	string	saTestbench		HSPICE PHASENOISE sweep start.
saHSPICEPHASENOISEStop	string	saTestbench		HSPICE PHASENOISE sweep stop.
saHSPICEPHASENOISESweepType	string	saTestbench	Decade	HSPICE PHASENOISE sweep Increment Type.
saHSPICEPortType	string	saTestbench	Incident	HSPICE Stateye port type.
saHSPICEPTDNOISEAddMeasure	string	saTestbench	1	HSPICE PTDNOISE Add Measure.
saHSPICEPTDNOISEDelta	string	saTestbench		HSPICE PTDNOISE Delta.
saHSPICEPTDNOISEListCount	string	saTestbench	20	HSPICE PTDNOISE List Count.
saHSPICEPTDNOISEListFloor	string	saTestbench		HSPICE PTDNOISE List Floor.
saHSPICEPTDNOISEListFreq	string	saTestbench		HSPICE PTDNOISE List Freq.
saHSPICEPTDNOISEListFreqType	string	saTestbench	none	HSPICE PTDNOISE List Freq Type.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICEPTDNOISEListSources	string	saTestbench	0	HSPICE PTDNOISE List Sources.
saHSPICEPTDNOISENumPoints	string	saTestbench		HSPICE PTDNOISE sweep number of points.
saHSPICEPTDNOISEOutputType	string	saTestbench	Voltage	HSPICE PTDNOISE Output Type.
saHSPICEPTDNOISEPOI	string	saTestbench		HSPICE PTDNOISE sweep points.
saHSPICEPTDNOISERfEdge	string	saTestbench	Rise	HSPICE PTDNOISE rfEdge.
saHSPICEPTDNOISESideband	string	saTestbench		HSPICE PTDNOISE SideBand.
saHSPICEPTDNOISEStart	string	saTestbench		HSPICE PTDNOISE sweep start.
saHSPICEPTDNOISEStop	string	saTestbench		HSPICE PTDNOISE sweep stop.
saHSPICEPTDNOISESweepType	string	saTestbench	Linear	HSPICE PTDNOISE sweep Increment Type.
saHSPICEPTDNOISETime	string	saTestbench		HSPICE PTDNOISE Time.
saHSPICEPTDNOISETimeValueType	string	saTestbench	Time	HSPICE PTDNOISE Time Value Type.
saHSPICEPTDNOISETnumPoints	string	saTestbench		HSPICE PTDNOISE sweep number of points.
saHSPICEPTDNOISETstart	string	saTestbench		HSPICE PTDNOISE sweep tstart.
saHSPICEPTDNOISETstop	string	saTestbench		HSPICE PTDNOISE sweep tstop.
saHSPICEPTDNOISETsweepType	string	saTestbench	Linear	HSPICE PTDNOISE sweep Increment Type.
saHSPICEQuantileAnalysisPanelTableAttributes	string	saTestbench		Saved attributes of the Quantile Analysis Panel Table
saHSPICERandomJitter	string	saTestbench		HSPICE Stateye random jitter.
saHSPICESaveOptionsAllAnalogTC	string	saTestbench	0	HSPICE Save Options save all currents.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICESaveOptionsEnableEM	string	saTestbench	false	Save currents for in-design layout automation.
saHSPICESaveOptionsEnableVDRC	string	saTestbench	false	Save voltage extremes to enable VDRC flow.
saHSPICESaveOptionsPostLevel	string	saTestbench		HSPICE Save Options post level.
saHSPICESaveOptionsPostTop	string	saTestbench	1	HSPICE Save Options post top.
saHSPICESaveOptionsPower	string	saTestbench	0	HSPICE Save Options power.
saHSPICESaveOptionsSave	string	saTestbench	level	HSPICE Save Options save.
saHSPICESaveOptionsSaveVDR CVoltages	string	saTestbench	false	Save voltage extremes to enable VDRC flow.
saHSPICESaveOptionsSubcktCurrent	string	saTestbench	0	HSPICE Save Options save subckt current.
saHSPICESaveOptionsTotalPower	string	saTestbench	0	HSPICE Save Options save total power.
saHSPICESaveOptionsVdrcTStart	string	saTestbench		Start time for VDRC voltage analysis.
saHSPICESaveOptionsVdrcTStop	string	saTestbench		Stop time for VDRC voltage analysis.
saHSPICESensitivityAnalysisPanelTableAttributes	string	saTestbench		Saved attributes of the Sensitivity Analysis Panel Table.
saHSPICEShowModelGroups	bool	saTestbench	false	Display the Model Groups table for HSPICE. Valid values: true, false
saHSPICESimulationCommandPrefix	string	user		An environment initialization command to be added to simulation commands.
saHSPICESimulatorOptionsImport	string	saTestbench	Import	HSPICE simulatorOptions Import Setting.
saHSPICESNACNumPoints	string	saTestbench		HSPICE Shooting Newton AC sweep number of points.
saHSPICESNACPOI	string	saTestbench		HSPICE Shooting Newton AC sweep points.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICESNACStart	string	saTestbench		HSPICE Shooting Newton AC sweep start.
saHSPICESNACStop	string	saTestbench		HSPICE Shooting Newton AC sweep stop.
saHSPICESNACSweepType	string	saTestbench	Linear	HSPICE Shooting Newton AC sweep Increment Type.
saHSPICESNDesignVar	string	saTestbench		HSPICE Shooting Newton sweep design variable.
saHSPICESNDesignVarUnits	string	saTestbench	dBm	HSPICE Shooting Netwon sweep design variable unit.
saHSPICESNDomain	string	saTestbench	Frequency	HSPICE Shooting Newton domain.
saHSPICESNFTAlfa	string	saTestbench	3	HSPICE SNFT Alfa.
saHSPICESNFTFmax	string	saTestbench		HSPICE SNFT Maximum Frequency (Hz).
saHSPICESNFTFmin	string	saTestbench		HSPICE SNFT Minimum Frequency (Hz).
saHSPICESNFTFormat	string	saTestbench	NORM	HSPICE SNFT Format.
saHSPICESNFTFreq	string	saTestbench		HSPICE SNFT Analysis Frequency (Hz).
saHSPICESNFTNumPoints	string	saTestbench		HSPICE SNFT Number of Points.
saHSPICESNFTOutputType	string	saTestbench	Voltage	HSPICE SNFT Output Variable.
saHSPICESNFTStart	string	saTestbench		HSPICE SNFT Start Time.
saHSPICESNFTStop	string	saTestbench		HSPICE SNFT Stop Time.
saHSPICESNFTWindow	string	saTestbench	RECT	HSPICE SNFT Window Type.
saHSPICESNMaxCycles	string	saTestbench		HSPICE Shooting Newton maximum transient init cycles.
saHSPICESNNOISEHarmMult	string	saTestbench	1	HSPICE Shooting Newton Noise Harmonic multiplier for Output Frequency Band.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICESNNOISEListCount	string	saTestbench	20	HSPICE SNNOISE List Count.
saHSPICESNNOISEListFloor	string	saTestbench		HSPICE SNNOISE List Floor.
saHSPICESNNOISEListFreq	string	saTestbench		HSPICE SNNOISE List Freq.
saHSPICESNNOISEListFreqType	string	saTestbench	none	HSPICE SNNOISE List Freq Type.
saHSPICESNNOISEListSources	string	saTestbench	0	HSPICE SNNOISE List Sources.
saHSPICESNNOISENumPoints	string	saTestbench		HSPICE Shooting Newton Noise sweep number of points.
saHSPICESNNOISEOFB	string	saTestbench	0	HSPICE Shooting Newton Noise Output Band Frequency defined.
saHSPICESNNOISEOFBCoef	string	saTestbench	-1	HSPICE Shooting Newton Noise IFB Coefficient for OBF.
saHSPICESNNOISEOutputType	string	saTestbench	Voltage	HSPICE Shooting Newton Noise Output Type.
saHSPICESNNOISEPOI	string	saTestbench		HSPICE Shooting Newton Noise sweep points.
saHSPICESNNOISEStart	string	saTestbench		HSPICE Shooting Newton Noise sweep start.
saHSPICESNNOISEStop	string	saTestbench		HSPICE Shooting Newton Noise sweep stop.
saHSPICESNNOISESweepType	string	saTestbench	Linear	HSPICE Shooting Newton Noise sweep Increment Type.
saHSPICESNNumHarms	string	saTestbench		HSPICE Shooting Newton number of harmonics.
saHSPICESNNumPoints	string	saTestbench		HSPICE Shooting Newton sweep number of points.
saHSPICESNOSCDesignVar	string	saTestbench		HSPICE Shooting Newton oscillator sweep design variable.
saHSPICESNOSCDesignVarUnits	string	saTestbench	dBm	HSPICE Shooting Newton oscillator sweep design variable units.
saHSPICESNOSCDomain	string	saTestbench	Frequency	HSPICE Shooting Newton oscillator domain.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICESNOSCMaXcycles	string	saTestbench		HSPICE Shooting Newton oscillator maximum transient init cycles.
saHSPICESNOSCNumHarms	string	saTestbench		HSPICE Shooting Newton oscillator number of harmonics.
saHSPICESNOSCNumPoints	string	saTestbench		HSPICE Shooting Newton oscillator sweep number of points.
saHSPICESNOSCOscNode	string	saTestbench		HSPICE Shooting Newton oscillator node.
saHSPICESNOSCPeriod	string	saTestbench		HSPICE Shooting Newton oscillator time period.
saHSPICESNOSCPOI	string	saTestbench		HSPICE Shooting Newton oscillator sweep points.
saHSPICESNOSCResolution	string	saTestbench		HSPICE Shooting Newton Oscillator time resolution.
saHSPICESNOSCStart	string	saTestbench		HSPICE Shooting Newton oscillator sweep start.
saHSPICESNOSCStop	string	saTestbench		HSPICE Shooting Newton oscillator sweep stop.
saHSPICESNOSCSweep	string	saTestbench	false	HSPICE Shooting Newton oscillator sweep.
saHSPICESNOSCSweepType	string	saTestbench	Linear	HSPICE Shooting Newton oscillator sweep Increment Type.
saHSPICESNOSCTone	string	saTestbench		HSPICE Shooting Newton approximately. oscillation frequency.
saHSPICESNOSCTrinit	string	saTestbench		HSPICE Shooting Newton oscillator transient init time.
saHSPICESNPeriod	string	saTestbench		HSPICE Shooting Newton time period.
saHSPICESNPOI	string	saTestbench		HSPICE Shooting Newton sweep points.
saHSPICESNResolution	string	saTestbench		HSPICE Shooting Newton time resolution.
saHSPICESNStart	string	saTestbench		HSPICE Shooting Newton sweep start.
saHSPICESNStop	string	saTestbench		HSPICE Shooting Newton sweep stop

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICESNSweep	string	saTestbench	false	HSPICE Shooting Newton sweep.
saHSPICESNSweepType	string	saTestbench	Linear	HSPICE Shooting Newton sweep Increment Type.
saHSPICESNTone	string	saTestbench		HSPICE Shooting Newton fundamental frequency.
saHSPICESNTrinit	string	saTestbench		HSPICE Shooting Newton transient init time.
saHSPICESNXFNumPoints	string	saTestbench		HSPICE SNXF sweep number of points.
saHSPICESNXFOutputType	string	saTestbench	Voltage	HSPICE SNXF Output Type.
saHSPICESNXFPOI	string	saTestbench		HSPICE SNXF sweep points.
saHSPICESNXFStart	string	saTestbench		HSPICE SNXF sweep start.
saHSPICESNXFStop	string	saTestbench		HSPICE SNXF sweep stop.
saHSPICESNXFSweepType	string	saTestbench	Linear	HSPICE SNXF sweep Increment Type.
saHSPICESTATEYEAdditionalOptions	string	saTestbench		HSPICE Stateye Additional Keywords.
saHSPICESTATEYEAddMeasureOutputs	string	saTestbench	true	HSPICE Stateye add measure outputs.
saHSPICESTATEYEAddProbeOutputs	string	saTestbench	true	HSPICE Stateye add probe outputs.
saHSPICESTATEYEEEdge	string	saTestbench	1	HSPICE Stateye setting for number of edges.
saHSPICESTATEYEEEdgeType	string	saTestbench	Symmetrical	HSPICE Stateye setting for Edge Type.
saHSPICESTATEYEEEyeWidth	string	saTestbench		HSPICE Stateye eye width.
saHSPICESTATEYEIgnoreBits	string	saTestbench		HSPICE Stateye Ignore_Bits.
saHSPICESTATEYEImpulseNorm	string	saTestbench		HSPICE Stateye Impulse_Norm.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICESTATEYEInitialLow	string	saTestbench		HSPICE Stateye Initial_Low.
saHSPICESTATEYEInitialZero	string	saTestbench		HSPICE Stateye Initial_Zero.
saHSPICESTATEYEIsiDepth	string	saTestbench		HSPICE Stateye ISI_Depth.
saHSPICESTATEYEMode	string	saTestbench	EDGE	HSPICE Stateye Mode.
saHSPICESTATEYEPatternMax	string	saTestbench	0	HSPICE Stateye max LFSR/PAT size.
saHSPICESTATEYEPatternRepeat	string	saTestbench		HSPICE Stateye Pattern_repeat
saHSPICESTATEYEShowEdgeResponseWaveformControl	string	saTestbench	0	HSPICE Stateye Edge Response Wavefrom Control
saHSPICESTATEYEShowImpulseResponseControl	string	saTestbench	0	HSPICE Stateye IBIS-AMI and Impulse Response Control
saHSPICESTATEYEShowInputPatternControl	string	saTestbench	0	HSPICE Stateye Input Pattern Control
saHSPICESTATEYEShowSimulationModeAndAccuracyControl	string	saTestbench	0	HSPICE Stateye Simulation Mode and Accuracy Control
saHSPICESTATEYETdNUI	string	saTestbench	2	HSPICE Stateye TD_NUI
saHSPICESTATEYETdProbeAMI	string	saTestbench	0	HSPICE Stateye TD_Probe_AMI
saHSPICESTATEYETf	string	saTestbench		HSPICE Stateye fall time of incident pulse.
saHSPICESTATEYETr	string	saTestbench		HSPICE Stateye rise time of incident pulse.
saHSPICESTATEYETranBitSeg	string	saTestbench		HSPICE Stateye Tran_Bit_Seg
saHSPICESTATEYETranInit	string	saTestbench	60	HSPICE Stateye TRAN_Init
saHSPICESTATEYETres	string	saTestbench	200	HSPICE Stateye time axis resolution.
saHSPICESTATEYETresAMI	string	saTestbench		HSPICE Stateye AMI_T_Resolution

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICESTATEYETrf	string	saTestbench		HSPICE Stateye rise and fall time of incident pulse.
saHSPICESTATEYETwAbstol	string	saTestbench		HSPICE Stateye TW_Abstol
saHSPICESTATEYETwReltol	string	saTestbench	0.1	HSPICE Stateye TW_Reltol
saHSPICESTATEYEUnfoldLength	string	saTestbench	100	HSPICE Stateye Unfold_Length
saHSPICESTATEYEUseImpulseAMI	string	saTestbench	1	HSPICE Stateye AMIInit_Use_Impulse
saHSPICESTATEYEVdrange	string	saTestbench	0	HSPICE Stateye voltage display range.
saHSPICESTATEYEVhigh	string	saTestbench		HSPICE Stateye high voltage level of the incident pulse.
saHSPICESTATEYEVlow	string	saTestbench		HSPICE Stateye low voltage level of the incident pulse.
saHSPICESTATEYEVres	string	saTestbench	200	HSPICE Stateye voltage axis resolution.
saHSPICESTATEYEXtalkType	string	saTestbench	SYNC	HSPICE Stateye Xtalk_Type
saHSPICETemperatureImport	string	saTestbench	Import	HSPICE temperature Import Setting.
saHSPICETRANDoBisection	string	saTestbench	0	HSPICE tran show/hide bisection parameters
saHSPICETRANNOISEAutocorrelation	string	saTestbench	Disabled	HSPICE TRANNOISE Autocorrelation.
saHSPICETRANNOISEDev	string	saTestbench		HSPICE TRANNOISE Output Instance.
saHSPICETRANNOISEFirstrun	string	saTestbench	1	HSPICE TRANNOISE First simulation run.
saHSPICETRANNOISEFmax	string	saTestbench		HSPICE TRANNOISE Maximum Frequency.
saHSPICETRANNOISEFmaxAuto	string	saTestbench	0	HSPICE TRANNOISE Auto.
saHSPICETRANNOISEFmin	string	saTestbench		HSPICE TRANNOISE Minimum Frequency.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICETRANNOISEJitter	string	saTestbench	Disabled	HSPICE TRANNOISE Jitter.
saHSPICETRANNOISEMcList	string	saTestbench	1	HSPICE TRANNOISE Monte Carlo List.
saHSPICETRANNOISEMcnum	string	saTestbench	1	HSPICE TRANNOISE Number of Monte Carlo Simulations.
saHSPICETRANNOISEMethod	string	saTestbench		HSPICE TRANNOISE Method.
saHSPICETRANNOISENegNode	string	saTestbench		HSPICE TRANNOISE Output Negative Node.
saHSPICETRANNOISEOutputType	string	saTestbench	Node	HSPICE TRANNOISE Output Type.
saHSPICETRANNOISEPhasenoise	string	saTestbench	Disabled	HSPICE TRANNOISE Phase Noise.
saHSPICETRANNOISEPosNode	string	saTestbench		HSPICE TRANNOISE Output Positive Node.
saHSPICETRANNOISEPsd	string	saTestbench	0	HSPICE TRANNOISE Power Spectral Density.
saHSPICETRANNOISERef	string	saTestbench		HSPICE TRANNOISE Noise Reference.
saHSPICETRANNOISESamplesList	string	saTestbench		HSPICE TRANNOISE List of Seed values or ranges.
saHSPICETRANNOISESamplesNum	string	saTestbench	1	HSPICE TRANNOISE Number of Monte Carlo Samples.
saHSPICETRANNOISESamplesType	string	saTestbench	Value	HSPICE TRANNOISE Sampling Type.
saHSPICETRANNOISEScale	string	saTestbench		HSPICE TRANNOISE Scale factor.
saHSPICETRANNOISEStart	string	saTestbench	0	HSPICE TRANNOISE Start Time.
saHSPICETRANNOISETime	string	saTestbench	All	HSPICE TRANNOISE Time Points.
saHSPICETRANNOISETimeval	string	saTestbench		HSPICE TRANNOISE Time Point Value.
saHSPICETRANNOISEUseListSyntax	string	saTestbench	0	HSPICE TRANNOISE Use List Syntax.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saHSPICETRANNumIntervals	string	saTestbench	1	HSPICE Transient setting for Number Of Steps.
saHSPICETRANOptMethod	string	saTestbench	BISECTION	HSPICE tran optimization method
saHSPICETRANOptModelOthers	string	saTestbench		HSPICE tran optimization other model options
saHSPICETRANResults	string	saTestbench		HSPICE tran optimization results
saHSPICETRANStart	string	saTestbench	0	HSPICE Transient start time.
saHSPICETRANStep	string	saTestbench		HSPICE Transient time step.
saHSPICETRANStep2	string	saTestbench		HSPICE Transient time step2.
saHSPICETRANStep3	string	saTestbench		HSPICE Transient time step3.
saHSPICETRANStep4	string	saTestbench		HSPICE Transient time step4.
saHSPICETRANStep5	string	saTestbench		HSPICE Transient time step5.
saHSPICETRANStop	string	saTestbench		HSPICE Transient stop time.
saHSPICETRANStop2	string	saTestbench		HSPICE Transient stop2 time.
saHSPICETRANStop3	string	saTestbench		HSPICE Transient stop3 time.
saHSPICETRANStop4	string	saTestbench		HSPICE Transient stop4 time.
saHSPICETRANStop5	string	saTestbench		HSPICE Transient stop5 time.
saHSPICETRANUIC	string	saTestbench	0	HSPICE Transient setting for Use Initial Conditions.
saHSPICEVariationImport	string	saTestbench	Include	HSPICE variation Import Setting.

Table 31 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saHSPICEVCSEnvOptsStopViewList	string	saTestbench	hspice hspiceD functional behavioral symbol	HSPICE Stop View List for netlister.
saHSPICEVCSEnvOptsSwitchViewList	string	saTestbench	hspice hspiceD schematic verilog functional behavioral vhdl_config vhdl_spice veriloga verilogams	HSPICE Switch View List for netlister.
saHSPICEVCSMsOptsE2RInterfaceElementDefault	string	user	false	E2R Interface Element Default for HSPICEVCS.
saHSPICEVCSMsOptsR2EInterfaceElementDefault	string	user	false	R2E Interface Element Default for HSPICEVCS.
saHSPICEVectorImport	string	saTestbench	Include	HSPICE vector Import Setting.
saHSPICEYieldAnalysisPanelTableAttributes	string	saTestbench		Saved attributes of the Yield Analysis Panel Table
saldleServerJobTimeout	int	saSession	120	Idle background pw_shell server job timeout.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
salgnoreModelSectionsRegexp	string	user		The PrimeWave Design Environment ignores model sections whose names match this regular expression. When scanning model files for section names, those names are matched against the regular expression (a string) in this preference. If it matches, the section is ignored by the PrimeWave Design Environment; it will not be presented as an option in the Model Files dialog box or the Corners Setup dialog box. The expression is matched to the whole section name, so: • "BIP" filters out the section "BIP" only, it does not filter out "BIP_12" • "MOS.*" filters out section "MOS_25" but does not filter out "NMOS" • ".*_20" filters out section "DIO_20" but does not filter out "DIO_20x" To specify multiple expressions, separate them with bars (). For example, "BIP MOS.*" filters out section "BIP" and any sections that start with "MOS".
salgnoreParasiticDevices	bool	user	false	Controls Pwhether to ignore the parasitic Devices or not.
salmageTitlePattern	string	user	%e %c %s %m %t	Default pattern for generating image titles for an output.
salmporConvergenceAidsLimit	string	user	100	Controls how many convergence aids are imported during netlist import.
salmporCornersFilePath	string	saSession		Default path for corners import from file.
salmporCornersFrom	string	saSession	File	Default storage for corners import.
salmporCornersName	string	saSession		Default state for corners import.
salmporCornersShowInfo	bool	saSession	false	Shows state info in the Import Corners dialog box. Valid values: true, false
salmporCornersShowOptions	bool	saSession	false	Show options fields in the Import Corners dialog box. Valid values: true, false
salmporDesignVariablesLimit	string	user	100	Controls how many design variables are imported during netlist import.
salmporLibFileExtensions	string	user	.v	Import Digital directories lib file extensions.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
salImportMeasures	bool	saTestbench	true	Import Measures in Output table
salImportModelsLimit	string	user	100	Controls how many models are imported during netlist import.
salImportOutputsLimit	int	user	10000	Maximum number of outputs in the GUI when importing
salImportPlotProbeOutputs	bool	user	true	Set default value of plot attribute for probe outputs Valid values: true, false
salImportSpiceParser	string	user	tnlib	Netlist Spice Parser
salImportTextLoadStateDeviceMapping	string	user	{}	Device Map when loading state along with import text action
salImportSimulatorName	string	user	HSPICE	Simulator Name for Import Text.
salImportTextAnnotateDesign	bool	user	false	Annotate the design with Import Actions. Valid values: true, false
salImportTopLevelOnly	bool	user	false	If true, import only top-level design into OA.
salIncludeGlobalIncludes	bool	user	true	Flag for a testbench to include the global scope include files
salIncludeGlobalVariables	bool	saTestbench	true	Flag for a testbench to include the global scope variables
salIncludeStructuralNetlist	bool	user	false	Controls whether the structural netlist should be included into final netlist or copied inside it. Valid values: true, false
salIncludesSearchPath	string	user		Flag for a testbench set search directory
salIncrementalWaveformLoading	bool	user	false	If true, WaveView incrementally loads waveform data during simulation running.
salIndependentProcessesDistributionJobClass	string	user		Distributed independent processes remote interactive farm job class name
salIndependentProcessesDistributionMode	string	user	LocalHost	Distributed independent processes on localhost (LocalHost) or remote interactive farm (RemoteInteractive)
salInitAllSimulatorAtStart	bool	user	false	Initialize all supported simulator at start
salInteractivePickType	string	user	Voltage	Pick type.
salsLoadStateThreadEnabled	bool	user	true	Use thread to load state or not

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
salsShowRunConfirmationDialog	bool	user	false	It supports a new mode to name a new history point before running simulation (The default is false). If it is set to true, a dialog pops up.
salterativeResultsAutoRefresh	bool	user	false	Controls auto refresh of results in iterative results table. Valid values: true, false
saJobSpecificFile	string	xtJobClass		Specifies path(s) to a file or files containing job class definition information. For more details see Defining and Managing Jobs in the Job Definition and Management Dialog Box.
saLoadHistoryAutoShowResults	bool	user	false	Whether to automatically show results when load history point.
saLoadStateCell	string	saSession		Name of cell containing PrimeWave Design Environment state to be loaded
saLoadStateChangeDesign	bool	saSession	false	Change design of PrimeWave Design Environment testbench to match that of state being loaded. Valid values: true, false
saLoadStateChangeResultsDir	bool	saSession	false	Change testbench's results directory to match that of state being loaded. Valid values: true, false
saLoadStateChangeSim	bool	saSession	true	Change simulator of the PrimeWave Design Environment testbench to match that of state being loaded. Valid values: true, false
saLoadStateChangeTestbenchName	bool	saSession	true	Change testbench's name to match that of state being loaded. Valid values: true, false
saLoadStateDmCell	string	saSession		DmCall under which is stored the PrimeWave Design Environment state to be loaded.
saLoadStateFrom	string	saSession	OpenAccess	Storage mechanism holding the PrimeWave Design Environment state.
saLoadStateInfo	bool	session	true	Default value for whether the States Info groupbox in the load state dialog is expanded. Valid values: true, false
saLoadStateLib	string	saSession		Name of library containing PrimeWave Design Environment state to be loaded.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saLoadStateName	string	saSession		Name of state being loaded into PrimeWave Design Environment.
saLoadStateOptions	bool	session	true	Default value for whether the Options groupbox in the load state dialog is expanded. Valid values: true, false
saLoadStateReset	bool saModels SearchPath	saSession	false	Reset PrimeWave Design Environment testbench before state is loaded. Valid values: true, false
saLoadStateShowInfo	bool	saSession	false	Show state information on the PrimeWave Design Environment state loading dialog. Valid values: true, false
saLoadStateShowOptions	bool	saSession	false	Show options fields on the PrimeWave Design Environment state loading dialog. Valid values: true, false
saLoadStateSim	string	saSession		Name of simulator under which is stored PrimeWave Design Environment state to be loaded.
saLoadingStateMaxThreadCount	int	user	-1	Number of threads use for loading MTB states. Set to -1 for automatic determine the optimal value.
saMaxDepthForEquivalentNetsDownHierarchy	int	user	0	Maximum levels to search below the given context
saMaxIdleServerJobs	int	saSession	2	Maximum allowed idle background pw_shell server jobs.
saMaxNumOfMatchedSignals	string	user	100	Maximum Number of Matched Signals for Probing with Wildcard
saMaxServerJobs	int	saSession	8	Maximum background pw_shell server jobs.
saMaxTestbenchCountForComputeSimulationJobs	int	user	1	Maximum number of testbenches for which simulation jobs are computed before running the simulation in append mode
saMaxTestbenchCountForComputeSimulationJobs	int	ser	1	Maximum number of testbenches for which simulation jobs are computed before running the simulation in append mode.
saMeasurementJobClass	string	xtJobClass	Shell	Measurement job class name.
saMeasurementsCalculationMode	string	saTestbench	Background	Measurement calculation mode. Valid values: Foreground, Background, Auto

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saMeasurementsCommandPrefix	string	user		An environment initialization command to be added to measurement commands.
saMeasurementsEngNotation	bool	user	true	Use Engineering Notation when displaying measurement values. See also SolvNetPlus article #000042270 "How to display measurement values in scientific notation in the PrimeWave Design Environment?" Valid values: true, false
saMeasurementSummaryAutoUpdate	bool	user	false	Controls auto update of the contents of the measurements summary table
saMeasurementSummaryAutoUpdate	bool	user	false	Controls auto update of the contents of the measurements summary table. Valid values: true, false
saMeasurementSummaryShowAll	bool	user	false	Option to show all the measurement results in the measurements summary table
saMeasurementSummaryShowPassed	bool	user	false	Option to show the measurement results that passed or met their goals in the measurements summary table
saMeasurementSummaryShowViolations	bool	user	false	Option to show the measurement results that failed to meet their goals in the measurements summary table
saMigrationResultsType	enMigrationType	user	Symbolic Link	Migration type{Symbolic Link} Copy.
saMinDiskSpaceNeeded	int	user	0	Minimum disk space needed to run PrimeWave Design Environment
saModelsSearchPath	string	user		Flag for a testbench set search directory
saMonteCarloAutoValidation	string	saTestbench	0	Auto Validation
saMonteCarloDoNominal	string	saTestbench	0	Do Nominal or not
saMonteCarloCriticalSweepExt	string	saTestbench	1	Output Critical Point External Sampling File
saMonteCarloCriticalSweepWaveform	string	saTestbench	0	Output Simulation of Critical Points to Obtain the Waveforms
saMonteCarloDetailed	string	saTestbench	1	Output Detail Files
saMonteCarloEnabled	string	saTestbench	0	Whether Monte Carlo analysis is enabled.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saMonteCarloFastSensitivity	string	saTestbench	0	Use Fast Sensitivity Method in Data Mining
saMonteCarloGoldenRefFile	string	saTestbench		Golden Reference Result File
saMonteCarloFullSensTable	string	saTestbench	0	List All Contributors
saMonteCarloHSMCCC	string	saTestbench	1	High Sigma Monte Carlo Component Count
saMonteCarloHSMCCLS	string	saTestbench	3.5	High Sigma Monte Carlo Chip Level Sigma
saMonteCarloHSMCNum	string	saTestbench	67759	HSMC Number of iterations per run
saMonteCarloHSMCSU	string	saTestbench	4.0	High Sigma Monte Carlo Statistical Uncertainty
saMonteCarloHSMCUseNumber	string	saTestbench	Uncertainty	High Sigma Monte Carlo use number as input
saMonteCarloHyperParameters	string	saTestbench		Additional Hyper-Parameters
saMonteCarloInputMode	string	saTestbench	Sigma	Input Mode of Iterations
saMonteCarloIterationsPerRun	string	saTestbench	10	Number of iterations per run.
saMonteCarloMultipleRun	bool	saTestbench	false	Use multi-run mode. Valid values: true, false
saMonteCarloMultipleRuns	string	saTestbench	0	Whether simulation is broken into multiple runs.
saMonteCarloMultiRunType	string	saTestbench	Number of runs	Whether to specify no of runs or iterations per run.
saMonteCarloNominal	string	saTestbench	1	Output Nominal Simulation Files
saMonteCarloNumIter	int	saTestbench	10	int
saMonteCarloPYESU	string	saTestbench	4.0	Parametric Yield Estimation Statistical Uncertainty
saMonteCarloQqPlot	string	saTestbench	1	Output Q-Q Plot

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saMonteCarloSensitivity	string	saTestbench	1	Show Sensitivity Section in ava.report File
saMonteCarloSensitivityDetailedFile	string	saTestbench	1	Output Detailed Sensitivity File
saMonteCarloSensitivityHideIrvLevel	string	saTestbench	0	Hide Parameter Level Sensitivity Report
saMonteCarloSensitivityOutputCsv	string	saTestbench	0	Output Sensitivity Table in CSV Format
saMonteCarloSensitivityScreeningMethod	string	saTestbench	Pearson	Calculates the variables screened by importance with different algorithm
saMonteCarloSigmaAmp	string	saTestbench	0	Sigma Amplification
saMonteCarloSigmaCC	string	saTestbench	1	Sigma Component Count
saMonteCarloSigmaCLS	string	saTestbench	2.5	Sigma Chip Level Sigma
saMonteCarloSigmaNum	string	saTestbench	618	Sigma Number of iterations per run
saMonteCarloSigmaStart	string	saTestbench	1	Sigma Start iterations
saMonteCarloSigmaSU	string	saTestbench	16.0	Sigma Statistical Uncertainty
saMonteCarloStartIter	int	saTestbench	1	int
saMonteCarloTotalRuns	string	saTestbench	1	Number of runs.
saMOSCutoffColor	string	user	density100	Highlight color MOS devices in cutoff region.
saMOSLinearColor	string	user	density46	Highlight color MOS devices in linear region.
saMOSRADIdThresh	string	saSession	10	Delta Id threshold as a percentage for MOSRA flow results highlighting.
saMOSRADTempThresh	string	saSession	10	Delta Temperature threshold in degrees for MOSRA flow results highlighting.
saMOSRADVtThresh	string	saSession	20	Delta Vt threshold in milliVolts for MOSRA flow results highlighting.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saMOSRAShowUMC	bool	user	false	Enable UMC Specific Setting for MOSRA
saMOSReverseColor	string	user	density32	Highlight color of MOS devices in Reverse region.
saMOSSaturationColor	string	user	density66	Highlight color MOS devices in saturation region.
saMOSSubthresholdColor	string	user	density0	Highlight color of MOS devices in subthreshold region.
saMSVUsetTopDesignForSpiceTop Name	bool	user	false	Use top design cell name for spice top name in mixed-signal dialog
saMTBTabNamePattern	string	user	%l%c%d	Default MTB tab name pattern which defines the order appended behind to the MTB name
saNetlistIncludesBeforeGUI	bool	user	true	Set to false if pre-201712 final netlist ordering is required. Valid values: true, false
saNetlistingJobClass	string	xtJobClass	Netlisting	Netlisting job class name.
saNetlistingProbeAlias	bool	user	false	Controls whether create probe alias in netlist .probe statement
saNoPlot	bool	user	false	Skip Plotting when Evaluating Expression
saNoiseSummaryHierarchy	string	user	all	Noise summary report by hierarchy or by level
saNoiseSummaryHierarchyLevel	int	user	1	Noise summary report hierarchy level
saNotEvalWithSaveOnly	bool	user	false	Do not evaluate if only "save" is selected in Output pane. Valid values: true, false
saNoPostProcess	bool	user	false	Skip Post Processing After Simulation.
saOpPointsActiveTab	string	saTestbench		Save Op Point Report active tab.
saOpPointsAppendMode	bool	user	false	Op Point report only displays instances/nets that are manually picked. Valid values: true, false
saOpPointsAutoGenerateReport	bool	user	false	Enables autogeneration of sqlData. Valid values: true, false

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saOpPointsCellNameMap	string	user	"" (empty string)	Allows you to set the names of the OP Points Results table tabs to user-defined or SPICE device types. For example, setting <code>saOpPointsDeviceTypeMap</code> to <code>{m MOSFET c CAPACITANCE q Bipolar}</code> will display data for device type 'm' under the 'MOSFET' tab, data for device type 'c' under the 'CAPACITANCE' tab, and device type 'q' under the 'BIPOLAR' tab. Note that <code>saOpPointsCellNameMap</code> takes precedence over <code>saOpPointsDeviceTypeMap</code> when cell or device types of the same name are mapped.
saOpPointsCellsToFlatten	string	user		List of cell names that identify macro devices for flattening.
saOpPointsDeviceTypeMap	string	user	"" (empty string)	List of device types and their corresponding mapped values for display. Allows you to set the names of the OP Points Results table tabs as device types you select. For example, setting <code>saOpPointsDeviceTypeMap</code> to <code>{p PMOS n NMOS}</code> will display data for device type 'p' under the 'PMOS' tab, and data for device type 'n' under the 'NMOS' tab.
saOpPointsDisplayPrecision	int	user	5	OpPoints Display Precision in Gradient Editor.
saOpPointsExprSetup	string	user		Save Op Point Heat Map setup in the form of a Tcl list.
saOpPointsFlattenEnabled	bool	user	false	Enable flattening macro devices in the Operating Point Report. Valid values: true, false
saOpPointsFlattenUsingPDK	bool	user	false	Use PDK expressions to get macro devices' data for the Operating Point Report. Valid values: true, false
saOpPointsInlineDevicesToFlatten	string	user		List of inline device names that identify macro devices for flattening.
saOpPointsOpensIn	string	user	tab	OP Points Report window open default [tab window].
saOpPointsPreferences	string	saTestbench		Save Op Point Report display preferences in the form of a TCL dictionary.
saOpPointsSelectedAnalysis	string	saTestbench	DC	Selected analysis type for OpPoints color annotation.

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saOpPointsSelectedIteration	string	saTestbench		Save selected parameters in in the form of a Tcl dictionary.
saOpPointsSelectedTimePoint	string	saTestbench	0	Time point selected for OpPoints color annotation for the transient analysis.
saOptimizerAllowAllVariableTypes	bool	user	false	If true, allow both variables and design parameter variables to ASO.ai setup.
saOptimizerBatchSize	int	user	16	The sample size for each iteration
saOptimizerDisableLibraryLocking	bool	user	true	If true, disables library locking.
saOptimizerEnableKeepDesignOpen	bool	user	true	If true, keeps all designs in memory in the background process, The maximum number of open designs is 10,000
saOptimizerEngine	saOptimizerEngineEnum saHSPICEOptionag epwinteg	user	Unified	Used to set the optimizer engine
saOptimizerShowFirstSampleResults	bool	user	false	Controls whether to show the first sample results in ResultsView
saOptimizerMimicStartup	bool	user	false	If true, Mimic settings in background process by loading startup files of foreground process
saOptimizerInitialBatchSize	int	user	24	The sample size in the first iteration
saOptimizerOMPNumThreads	int	user	0	Number of threads used by OMP by the background process
saOptimizerSaveSimulationData	bool	user	false	Controls whether to save simulation results (waveform files) during optimization
saOptimizerStartupMode	saOptimizerStartupModeEnum	user	GUI	Used to set the optimization startup mode
saOptimizerSynchronizeAllParametersWithASOSetup	bool	user	true	Synchronize all design parameter variables with ASO.ai setup
saOptimizerStopIfAllSamplesFailed	bool	user	false	Controls whether to stop optimization if all samples failed

Table 31 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saOptimizerUnifiedEngineFlow	saOptimizerUnifiedEngineFlowEnum	user	Flow2	Used to set the optimizer unified engine flow
saOutputColumnOrder	string	custom	name expr value analyses save plot plotType plotColor resultsViewer saveImage suffix units Tail Weight description	Order of columns in outputs table with names displayed from left to right.

See Also

- [Simulation and Analysis Environment Preferences \(saA2D* through saFineSimPro*\)](#)
- [Simulation and Analysis Environment Preferences \(saParam* through saPrimeSimVCS*\)](#)
- [Simulation and Analysis Environment Preferences \(saPrimeSimXA* through saSpectre*\)](#)
- [Simulation and Analysis Environment Preferences \(saSt* through saXA*\)](#)

Simulation and Analysis Environment Preferences (saParam* through saPrimeSimVCS*)

Table 32 lists continuation of PrimeWave Design Environment sa general preferences (saParam* through saPrimeSimVCS*).

Table 32 Simulation and Analysis Environment Preferences

Name	Type	Scope	Default	Description
saPaspectreramDisplayEngNotation	bool	user	true	Display notation (true = engineering, false = scientific) for engineering notation. Valid values: true, false
saParamDisplayPrecision	int	user	6	Display precision for engineering notation.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saParasiticBackAnnotationFilesViewTypes	string	user	SPICEText externalNet list	Supported view types for the parasitic back-annotation files.
saParHierMode	string	user	LOCAL	Used to set the netlist parameter scoping priority to "LOCAL" or "GLOBAL". Use caution when using a value other than LOCAL.
saPercentageOfDiskSpaceNeeded	int	user	0	Percentage of minimum disk space needed to run the PrimeWave Design Environment to issue a warning.
saPlotAfterEsc	bool	user	false	Plot after all selections are made. Valid values: true, false
saPlotMode	string	saTestbench	replace	Plot mode for waveform tool.
saPostProcessMeasures	bool	user	false	When set to true measures will be evaluated only in post process mode. May be used by third party simulators. Valid values: true, false
saPostRunProcNamespace	string	user	sa::postRun	Name space for post run procs.
saPreRunProcNamespace	string	user	sa::preRun	Name space for pre-run procs.
saPrimeSimACCenter	string	saTestbench		PrimeSim AC: Center point of sweep limits.
saPrimeSimACDec	string	saTestbench		PrimeSim AC: Number of logarithmic steps per decade.
saPrimeSimACDesignVar	string	saTestbench		PrimeSim AC: Design variable being swept.
saPrimeSimACDev	string	saTestbench		PrimeSim AC: Instance with parameter being swept.
saPrimeSimACFreq	string	saTestbench		PrimeSim AC: Single value to hold frequency while other aspect is being swept.
saPrimeSimACLin	string	saTestbench		PrimeSim AC: Number of linear steps.
saPrimeSimACLog	string	saTestbench		PrimeSim AC: Total number of logarithmic steps.
saPrimeSimACMATCHCenter	string	saTestbench		PrimeSim ACMATCH: Center point of sweep limits.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimACMATCHDec	string	saTestbench		PrimeSim ACMATCH: Number of logarithmic steps per decade.
saPrimeSimACMATCHLin	string	saTestbench		PrimeSim ACMATCH: Number of linear steps.
saPrimeSimACMATCHLog	string	saTestbench		PrimeSim ACMATCH: Total number of logarithmic steps.
saPrimeSimACMATCHNegNode	string	saTestbench		PrimeSim AC Match sweep: Negative output node.
saPrimeSimACMATCHNode	string	saTestbench		PrimeSim AC Match sweep: Positive output node.
saPrimeSimACMATCHOprobe	string	saTestbench		PrimeSim AC Match: Compute mismatch at the output defined by this component.
saPrimeSimACMATCHOptionannotate	string	custom	sweep	PrimeSim option annotate: Degree of annotation. Possible values are no, title, sweep, status, and steps.
saPrimeSimACMATCHOptionfile	string	saTestbench		PrimeSim option file: filename to write result
saPrimeSimACMATCHOptionfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACMATCHOptionfile is loaded.
saPrimeSimACMATCHOptionforce	string	custom	none	PrimeSim option force: The set of initial conditions to use. Possible values are none, node, dev, and all.
saPrimeSimACMATCHOptiongroupby	string	saTestbench	param	PrimeSim option groupby: how to group the output data
saPrimeSimACMATCHOptiongroupby	string	custom	param	PrimeSim option groupby: Choose the way of how to group the total sigma. Total sigma of each contributor can be grouped either by statistics parameters or by subckt instances. Possible values are param and inst.
saPrimeSimACMATCHOptiongroupbyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACMATCHOptiongroupby is loaded.
saPrimeSimACMATCHOptionname	string	saTestbench		PrimeSim option name: analysis name

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimACMATCHOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACMATCHOptionname is loaded.
saPrimeSimACMATCHOptionoppoint	string int	custom	no	PrimeSim option oppoint: Determines whether operating point information should be computed. If yes, specifies where should it be printed (screen or file). Operating point information is not printed if the operating point computed in the previous analysis remains unchanged. Possible values are no, screen, logfile, and rawfile.
saPrimeSimACMATCHOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimACMATCHOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACMATCHOptionotherOptions is loaded.
saPrimeSimACMATCHOptionprevoppoint	string	custom	no	PrimeSim option prevoppoint: Determines whether to use the operating point computed in the previous analysis. Possible values are no and yes.
saPrimeSimACMATCHOptionreadforce	string	custom		PrimeSim option readforce: File that contains the initial conditions.
saPrimeSimACMATCHOptionreadic	string	saTestbench		PrimeSim option read_ic: read file for .ic
saPrimeSimACMATCHOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACMATCHOptionreadic is loaded.
saPrimeSimACMATCHOptionreadns	string	saTestbench		PrimeSim option read_ns: read file for .nodeset
saPrimeSimACMATCHOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACMATCHOptionreadns is loaded.
saPrimeSimACMATCHOptionrestart	string	custom	yes	PrimeSim option restart: Restart the DC solution from scratch if any condition has changed. If not, use the previous solution as an initial guess. Possible values are no and yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimACMATCHOptionsave	string	custom		PrimeSim option save: Signal levels in output. Possible values are all, lvl, allpub, lvlpub, selected, none, and nooutput.
saPrimeSimACMATCHOptionskipdc	string	custom	no	PrimeSim option skipdc: Skip DC analysis. Possible values are no and yes.
saPrimeSimACMATCHOptiontitle	string	custom		PrimeSim option title: Analysis title.
saPrimeSimACMATCHOptionuseprevic	string	custom	no	PrimeSim option useprevic: If set to yes or ns, use the converged initial condition from the previous analysis as ic or ns. Possible values are no, yes, and ns.
saPrimeSimACMATCHOptionvaluesfile	string	custom		PrimeSim option valuesfile: Name of the file containing the sweep values.
saPrimeSimACMATCHOptionwrite	string	saTestbench		PrimeSim option write: write file at the first point
saPrimeSimACMATCHOptionwrite	string	custom		PrimeSim option write: DC operating point output file at the first step of the sweep.
saPrimeSimACMATCHOptionwritefinal	string	saTestbench		PrimeSim option write_final: write file at the last point
saPrimeSimACMATCHOptionwritefinal	string	custom		PrimeSim option writefinal: DC operating point output file at the last step of the sweep.
saPrimeSimACMATCHOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACMATCHOptionwritefinal is loaded.
saPrimeSimACMATCHOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACMATCHOptionwrite is loaded.
saPrimeSimACMATCHOutputType	string	saTestbench	Voltage	PrimeSim AC MATCH: Output Type.
saPrimeSimACMATCHSpan	string	saTestbench		PrimeSim ACMATCH: Span between sweep limits.
saPrimeSimACMATCHStart	string	saTestbench		PrimeSim ACMATCH: Starting point of sweep limits.
saPrimeSimACMATCHStep	string	saTestbench		PrimeSim ACMATCH: Linear step size.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimACMATCHStepSpecLin	string	saTestbench	Number of Steps	PrimeSim ACMATCH: Method of specifying linear stepping ("Step Size" "Number of Steps").
saPrimeSimACMATCHStepSpecLog	string	saTestbench	Points per Decade	PrimeSim ACMATCH: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saPrimeSimACMATCHStop	string	saTestbench		PrimeSim ACMATCH: Stopping point of sweep limits.
saPrimeSimACMATCHSweep	string	saTestbench	Logarithmic	PrimeSim ACMATCH: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saPrimeSimACMATCHSweepSpec	string	saTestbench	<file path>	PrimeSim ACMATCH: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saPrimeSimACMATCHThreshold	string	saTestbench		PrimeSim AC Match : Threshold.
saPrimeSimACMATCHValues	string	saTestbench		PrimeSim ACMATCH: Individual values, also known as points of interest.
saPrimeSimACMod	string	saTestbench		PrimeSim AC: Model with parameter being swept.
saPrimeSimACOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimACOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACOptionname is loaded.
saPrimeSimACOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saPrimeSimACOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACOptionotherOptions is loaded.
saPrimeSimACOptionreadic	string	saTestbench		PrimeSim option read_ic: read file for .ic
saPrimeSimACOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACOptionreadic is loaded.
saPrimeSimACOptionreadns	string	custom		PrimeSim option read_ns: File that contains an estimate of the DC solution (nodeset).

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimACOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACOptionreadns is loaded.
saPrimeSimACOptionwrite	string	saTestbench		PrimeSim option write: write file at the first point
saPrimeSimACOptionwritefinal	string	saTestbench		PrimeSim option write_final: write file at the last point
saPrimeSimACOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACOptionwritefinal is loaded.
saPrimeSimACOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimACOptionwrite is loaded.
saPrimeSimACParam	string	saTestbench		PrimeSim AC: Parameter being swept.
saPrimeSimACSpan	string	saTestbench		PrimeSim AC: Span between sweep limits.
saPrimeSimACStart	string	saTestbench		PrimeSim AC: Starting point of sweep limits.
saPrimeSimACStep	string	saTestbench		PrimeSim AC: Linear step size.
saPrimeSimACStepSpecLin	string	saTestbench	Number of Steps	PrimeSim AC: Method of specifying linear stepping ("Step Size" "Number of Steps").
saPrimeSimACStepSpecLog	string	saTestbench	Points per Decade	PrimeSim AC: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saPrimeSimACStop	string	saTestbench		PrimeSim AC: Stopping point of sweep limits.
saPrimeSimACSub	string	saTestbench		PrimeSim AC: Subcircuit with parameter being swept.
saPrimeSimACSweep	string	saTestbench	Logarithmic	PrimeSim AC: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saPrimeSimACSweepSpec	string	saTestbench	<file path>	PrimeSim AC: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saPrimeSimACSweepVar	string	saTestbench	Frequency (Hz)	PrimeSim AC: Specifies what will be swept ("Frequency (Hz)" "Design Variable" "Temperature" "None").

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimACTextParam	string	saTestbench		PrimeSim AC: Parameter being swept
saPrimeSimActiveNetsAnalysisFileName	string	saTestbench	primesim.s pf_inactive	Active Nets File Name.
saPrimeSimActiveNetsAnalysisReuse	string	saTestbench	1	Reuse active nets file.
saPrimeSimActiveNetsAnalysisSaveIn	string	saTestbench	Netlist Directory	Save Active Nets File.
saPrimeSimActiveNetsAnalysisThreshold	string	saTestbench	0.1	Voltage Threshold.
saPrimeSimActiveNetsEnabled	string	saTestbench	0	Enable Active Nets Flow.
saPrimeSimACValues	string	saTestbench		PrimeSim AC: Individual values, also known as points of interest.
saPrimeSimAlwaysSaveSelectedOutputs	bool	user	false	Always write the save statement for saving the selected signals.
saPrimeSimBlockOptionsCategories	string	saTestbench	All	Categories.
saPrimeSimBlockOptionsSummary	string	saTestbench		Custom commands contents holder.
saPrimeSimCommands	string	user	commands	PrimeSim command selection.
saPrimeSimDCCenter	string	saTestbench		PrimeSim DC: Center point of sweep limits.
saPrimeSimDCDec	string	saTestbench		PrimeSim DC: Number of logarithmic steps per decade.
saPrimeSimDCDesignVar	string	saTestbench		PrimeSim DC: Design variable being swept.
saPrimeSimDCDev	string	saTestbench		PrimeSim DC: Instance with parameter being swept.
saPrimeSimDCDoSweep	string	saTestbench	0	PrimeSim DC: Flag indicating a sweep is to be performed.
saPrimeSimDCLin	string	saTestbench		PrimeSim DC: Number of linear steps.
saPrimeSimDCLog	string	saTestbench		PrimeSim DC: Total number of logarithmic steps.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimDCMATCHCenter	string	saTestbench		PrimeSim DCMATCH: Center point of sweep limits.
saPrimeSimDCMATCHDec	string	saTestbench		PrimeSim DCMATCH: Number of logarithmic steps per decade.
saPrimeSimDCMATCHDesignVar	string	saTestbench		PrimeSim DCMATCH: Design variable being swept.
saPrimeSimDCMATCHDev	string	saTestbench		PrimeSim DCMATCH: Instance with parameter being swept.
saPrimeSimDCMATCHDoSweep	string	saTestbench	1	PrimeSim DCMATCH: Flag indicating a sweep is to be performed.
saPrimeSimDCMATCHLin	string	saTestbench		PrimeSim DCMATCH: Number of linear steps.
saPrimeSimDCMATCHLog	string	saTestbench		PrimeSim DCMATCH: Total number of logarithmic steps.
saPrimeSimDCMATCHMod	string	saTestbench		PrimeSim DCMATCH: Model with parameter being swept.
saPrimeSimDCMATCHNegNode	string	saTestbench		PrimeSim DC Match: Negative output node.
saPrimeSimDCMATCHNode	string	saTestbench		PrimeSim DC Match: Positive output node.
saPrimeSimDCMATCHNumsigma	string	saTestbench		PrimeSim DC Match : Number of Sigma.
saPrimeSimDCMATCHOprobe	string	saTestbench		PrimeSim DC Match: Compute mismatch at the output defined by this component.
saPrimeSimDCMATCHOptionannotate	string	custom	sweep	PrimeSim option annotate: Degree of annotation. Possible values are no, title, sweep, status, and steps.
saPrimeSimDCMATCHOptionfile	string	saTestbench		PrimeSim option file: filename to write result
saPrimeSimDCMATCHOptionfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCMATCHOptionfile is loaded.
saPrimeSimDCMATCHOptionname	string	saTestbench		PrimeSim option name: analysis name

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimDCMATCHOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCMATCHOptionname is loaded.
saPrimeSimDCMATCHOptionnestlvl	string	custom		PrimeSim option nestlvl: Levels of subcircuits to output.
saPrimeSimDCMATCHOptionnumsigmas	string	saTestbench		PrimeSim option num_sigmas: multipliers of sigma
saPrimeSimDCMATCHOptionnumsigmasUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCMATCHOptionnumsigmas is loaded.
saPrimeSimDCMATCHOptionoppoint	string	custom	no	PrimeSim option oppoint: Determines whether the operating point information should be computed. If yes, where should it be printed (screen or file). Operating point information is not printed in case of the following conditions: (1) operating point is computed in the previous analysis and is unchanged (2) sweep parameter param is set. Possible values are no, screen, logfile, and rawfile.
saPrimeSimDCMATCHOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saPrimeSimDCMATCHOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCMATCHOptionotherOptions is loaded.
saPrimeSimDCMATCHOptionport	string	custom		PrimeSim option port: Current through this probe port is output of the analysis.
saPrimeSimDCMATCHOptionportv	string	custom		PrimeSim option portv: Voltage across this probe port is output of the analysis.
saPrimeSimDCMATCHOptionprevoppoint	string	custom	no	PrimeSim option prevoppoint: Use operating point computed on the previous analysis. Possible values are no and yes.
saPrimeSimDCMATCHOptionreadic	string	saTestbench		PrimeSim option read_ic: read file for .ic

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimDCMATCHOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCMATCHOptionreadic is loaded.
saPrimeSimDCMATCHOptionreadns	string	saTestbench		PrimeSim option read_ns: read file for .nodeset
saPrimeSimDCMATCHOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCMATCHOptionreadns is loaded.
saPrimeSimDCMATCHOptionrestart	string	custom	yes	PrimeSim option restart: Restart the DC solution from scratch if any condition has changed. If not, use the previous solution as initial guess. Possible values are no and yes.
saPrimeSimDCMATCHOptionsave	string	custom		PrimeSim option save: Signals to output. Possible values are all, lvi, allpub, lvi pub, selected, none, and nooutput.
saPrimeSimDCMATCHOptiontitle	string	custom		PrimeSim option title: Analysis title.
saPrimeSimDCMATCHOptionuseprevic	string	custom	no	PrimeSim option useprevic: If set to yes or ns, use the converged initial condition from previous analysis as ic or ns. Possible values are no, yes, and ns.
saPrimeSimDCMATCHOptionvaluesfile	string	custom		PrimeSim option valuesfile: Name of the file containing the sweep values.
saPrimeSimDCMATCHOptionvariations	string	custom	all	PrimeSim option variations: Selects the type of statistical parameters that are involved in dcmatch. The option is valid only if method=statistics. Possible values are process, mismatch, and all.
saPrimeSimDCMATCHOptionvariationsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCMATCHOptionvariations is loaded.
saPrimeSimDCMATCHOptionversion	string	custom	0	PrimeSim option version: Use BSIM short-channel mismatch equation for BSIM3 and BSIM4 devices, if the value is set to 1 and 3. If set to 0 and 2, do not use BSIM short-channel mismatch equation. Values 2 and 3 are compatible with Monte Carlo analysis while 0 and 1 are not. This option works only when method=standard. Possible values are 0 to 3.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimDCMATCHOptionwrite	string	saTestbench		PrimeSim option write: write file at the first point
saPrimeSimDCMATCHOptionwritefinal	string	saTestbench		PrimeSim option write_final: write file at the last point
saPrimeSimDCMATCHOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCMATCHOptionwritefinal is loaded.
saPrimeSimDCMATCHOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCMATCHOptionwrite is loaded.
saPrimeSimDCMATCHOutputType	string	saTestbench	Voltage	PrimeSim DC MATCH: Output Type.
saPrimeSimDCMATCHParam	string	saTestbench		PrimeSim DCMATCH: Parameter being swept.
saPrimeSimDCMATCHSpan	string	saTestbench		PrimeSim DCMATCH: Span between sweep limits.
saPrimeSimDCMATCHStart	string	saTestbench		PrimeSim DCMATCH: Starting point of sweep limits.
saPrimeSimDCMATCHStep	string	saTestbench		PrimeSim DCMATCH: Linear step size.
saPrimeSimDCMATCHStepSpecLin	string	saTestbench	Number of Steps	PrimeSim DCMATCH: Method of specifying linear stepping ("Step Size" "Number of Steps").
saPrimeSimDCMATCHStepSpecLog	string	saTestbench	Points per Decade	PrimeSim DCMATCH: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saPrimeSimDCMATCHStop	string	saTestbench		PrimeSim DCMATCH: Stopping point of sweep limits.
saPrimeSimDCMATCHSub	string	saTestbench		PrimeSim DCMATCH: Subcircuit with parameter being swept.
saPrimeSimDCMATCHSweep	string	saTestbench	Linear	PrimeSim DCMATCH: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saPrimeSimDCMATCHSweepSpec	string	saTestbench	<file path>	PrimeSim DCMATCH: Method of specifying sweep limits ("Start/Stop" "Center/Span").

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimDCMATCHSweepVar	string	saTestbench	Temperature	PrimeSim DCMATCH: Specifies what will be swept ("Design Variable" "Temperature").
saPrimeSimDCMATCHTextParam	string	saTestbench		PrimeSim DCMATCH: Parameter being swept.
saPrimeSimDCMATCHThreshold	string	saTestbench		PrimeSim DC Match : Threshold.
saPrimeSimDCMATCHValues	string	saTestbench		PrimeSim DCMATCH: Individual values, also known as points of interest.
saPrimeSimDCMod	string	saTestbench		PrimeSim DC: Model with parameter being swept.
saPrimeSimDCOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimDCOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCOptionname is loaded.
saPrimeSimDCOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saPrimeSimDCOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCOptionotherOptions is loaded.
saPrimeSimDCOptionreadic	string	saTestbench		PrimeSim option read_ic: read file for .ic
saPrimeSimDCOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCOptionreadic is loaded.
saPrimeSimDCOptionreadns	string	custom		PrimeSim option read_ns: File that contains an estimate of the DC solution (nodeset).
saPrimeSimDCOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCOptionreadns is loaded.
saPrimeSimDCOptionwrite	string	custom		PrimeSim option write: File to which solution at first step in sweep is written.
saPrimeSimDCOptionwritefinal	string	custom		PrimeSim option write_final: File to which solution at last step in sweep is written.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimDCOptionwritefinalUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCOptionwritefinal is loaded.
saPrimeSimDCOptionwriteUnchec kLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimDCOptionwrite is loaded.
saPrimeSimDCParam	string	saTestbe nch		PrimeSim DC: Parameter being swept.
saPrimeSimDCSaveOP	string	saTestbe nch	1	PrimeSim DC sweep: Save DC Operating Point.
saPrimeSimDCSpan	string	saTestbe nch		PrimeSim DC: Span between sweep limits.
saPrimeSimDCStart	string	saTestbe nch		PrimeSim DC: Starting point of sweep limits.
saPrimeSimDCStep	string	saTestbe nch		PrimeSim DC: Linear step size.
saPrimeSimDCStepSpecLin	string	saTestbe nch	Number of Steps	PrimeSim DC: Method of specifying linear stepping ("Step Size" "Number of Steps").
saPrimeSimDCStepSpecLog	string	saTestbe nch	Points per Decade	PrimeSim DC: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saPrimeSimDCStop	string	saTestbe nch		PrimeSim DC: Stopping point of sweep limits.
saPrimeSimDCSub	string	saTestbe nch		PrimeSim DC: Subcircuit with parameter being swept.
saPrimeSimDCSweep	string	saTestbe nch	Linear	PrimeSim DC: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saPrimeSimDCSweepSpec	string	saTestbe nch	<file path>	PrimeSim DC: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saPrimeSimDCSweepVar	string	saTestbe nch	Temperat ure	PrimeSim DC: Specifies what will be swept ("Design Variable" "Temperature").
saPrimeSimDCTextParam	string	saTestbe nch		PrimeSim DC: Parameter being swept.
saPrimeSimDCValues	string	saTestbe nch		PrimeSim DC: Individual values, also known as points of interest.
saPrimeSimDefaultCornersSetup	string	saTestbe nch		PrimeSim default corners setup.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimDefaultIncludeFiles	string	saTestbench		PrimeSim default include files.
saPrimeSimDefaultModelFiles	string	saTestbench		PrimeSim default model files to be loaded.
saPrimeSimEnableCSVCheckExpressionOutputFormat	bool	user	true	Enable CSV output format for the check expression
saPrimeSimEngineSelection	string	user	{PrimeSim SPICE} {PrimeSim Pro} {PrimeSim HSPICE} {PrimeSim XA}	Engine selection on Simulation Options Dialog
saPrimeSimENVClockname	string	saTestbench		PrimeSim ENV: Clock Name.
saPrimeSimENVDec	string	saTestbench		PrimeSim ENV: Fast Mode Noise Sweep Points Per Decade.
saPrimeSimENVEngine	string	saTestbench	Shooting Newton	PrimeSim ENV: Which engine to run.
saPrimeSimENVEnvelopenstep	string	saTestbench		PrimeSim ENV: Envelope number of step.
saPrimeSimENVEnvelopestep	string	saTestbench		PrimeSim ENV: Envelope step.
saPrimeSimENVFastmethod	string	saTestbench	passband	PrimeSim ENV: Fast Method.
saPrimeSimENVFastmode	string	saTestbench	0	PrimeSim ENV: Invoke fast mode.
saPrimeSimENVFixstepmode	string	saTestbench	Envelope Step	PrimeSim ENV: Fixstep Mode.
saPrimeSimENVFixstepsize	string	saTestbench	0	PrimeSim ENV: Fixed Time-Step Mode.
saPrimeSimENVFreqdivider	string	saTestbench		PrimeSim ENV: Large Signal freqdivide Ratio.
saPrimeSimENVFreqMode	string	saTestbench	Specify	PrimeSim ENV: Tone mode for netlisting.
saPrimeSimENVFreqPeriod	string	saTestbench	Beat Frequency	PrimeSim ENV: Declaring the Frequency or Period.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimENVFrequency	string	saTestbench		PrimeSim ENV: Beat Frequency.
saPrimeSimENVFstart	string	saTestbench		PrimeSim ENV: Fast Mode Noise Starting Frequency.
saPrimeSimENVHarms	string	saTestbench	1	PrimeSim ENV: Maximum Number of Harmonics
saPrimeSimENVHarmsMode	string	saTestbench	Maximum	PrimeSim ENV: Harmonics Mode
saPrimeSimENVHarmsvec	string	saTestbench		PrimeSim ENV: Harmonics Vector
saPrimeSimENVLin	string	saTestbench		PrimeSim ENV: Fast Mode Noise Sweep Linear Steps
saPrimeSimENVMaxharm	string	saTestbench	2	PrimeSim ENV: Tones Table 'Harms' Column
saPrimeSimENVNoisemethod	string	saTestbench	off	PrimeSim ENV: Fast Mode Noise Mode
saPrimeSimENVNoiseSweepType	string	saTestbench	Lin	PrimeSim ENV: Fast Mode Noise Sweep Type
saPrimeSimENVOptionenvdelmax	string	custom		PrimeSim option env_delmax: Maximum outer envelope step size. Default is derived from `errpreset`.
saPrimeSimENVOptionenvdelmax UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimENVOptionenvdelmax is loaded.
saPrimeSimENVOptionenviterlimit	string	custom		PrimeSim option env_iterlimit: Maximum number of Newton iterations per envelope step. For time domain Shooting envelope, the default is 3. For Harmonic Balance Envelope, the default is 40.
saPrimeSimENVOptionenviterlimit UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimENVOptionenviterlimit is loaded.
saPrimeSimENVOptionenvnstep	string	saTestbench		PrimeSim option env_nstep: the fixed envelop step by number of cycles
saPrimeSimENVOptionenvnstepU ncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimENVOptionenvnstep is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimENVOptionenvstep	string	saTestbench		PrimeSim option env_step: the fixed envelop step
saPrimeSimENVOptionenvstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimENVOptionenvstep is loaded.
saPrimeSimENVOptionenvstop	string	saTestbench		PrimeSim option env_stop: simulation time
saPrimeSimENVOptionenvstopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimENVOptionenvstop is loaded.
saPrimeSimENVOptionkrylovtol	string	custom	1e-2	PrimeSim option krylovtol: Relative tolerance for linear solver.
saPrimeSimENVOptionkrylovtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimENVOptionkrylovtol is loaded.
saPrimeSimENVOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimENVOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimENVOptionname is loaded.
saPrimeSimENVOptionnharms	string	saTestbench		PrimeSim option nharms: number of harmonics to use for each tone
saPrimeSimENVOptionnharmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimENVOptionnharms is loaded.
saPrimeSimENVOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimENVOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimENVOptionotherOptions is loaded.
saPrimeSimENVOptionprobenode	string	saTestbench		PrimeSim option probenode: specify the node to detect oscillation
saPrimeSimENVOptionprobenodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimENVOptionprobenode is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimENVOptionreadic	string	custom		PrimeSim option read_ic: File that contains initial condition.
saPrimeSimENVOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimENVOptionreadic is loaded.
saPrimeSimENVOptionreadns	string	custom		PrimeSim option read_ns: File that contains an estimate of the initial transient solution.
saPrimeSimENVOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimENVOptionreadns is loaded.
saPrimeSimENVOptiontones	string	saTestbench		PrimeSim option tones: Fundamental frequencies
saPrimeSimENVOptiontonesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimENVOptiontrinit	string	saTestbench		PrimeSim option trinit: Transient initialization time
saPrimeSimENVOptiontrinitmethod	string	saTestbench	trap	PrimeSim option trinit_method: Sets the numerical integration method used during a transient analysis.
saPrimeSimENVOptiontrinitmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimENVOptiontrinitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimENVOptionuic	string	custom	no	PrimeSim option uic: If set to yes, there is no DC analysis for initial transient. Possible values are no, yes.
saPrimeSimENVOptionuicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimENVOptionwrite	string	custom		PrimeSim option write: File to which solution at first step in sweep is written.
saPrimeSimENVOptionwritefinal	string	saTestbench		PrimeSim option write_final: write file at the last point
saPrimeSimENVOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimENVOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimEnvOptsAccuracyLevel	string	saTestbench	Default	Accuracy Level
saPrimeSimEnvOptsAuto	string	saTestbench	0	Automatically Determine Number of processes
saPrimeSimEnvOptsCaseSensitive	string	saTestbench	Lower	Case Sensitive
saPrimeSimEnvOptsCommandLineOptions	string	saTestbench		Additional command line options for the PrimeSim
saPrimeSimEnvOptsEnableGPU	string	saTestbench	0	Enable GPU
saPrimeSimEnvOptsEnableParallelSim	string	saTestbench	0	Enable Parallel Simulation
saPrimeSimEnvOptsHSPICEStopViewList	string	saTestbench	hspice hspiceD	Stop View List for HSPICE netlister
saPrimeSimEnvOptsHSPICESwitchViewList	string	saTestbench	hspice hspiceD schematic spice veriloga	Switch View List for HSPICE netlister
saPrimeSimEnvOptsIncludePath	string	saTestbench		Search path for PrimeSim include files
saPrimeSimEnvOptsIP	string	saTestbench	0	Independent Parallel Simulation
saPrimeSimEnvOptsNetlistLanguage	saPrimeSimNetlistLanguageEnum	user	Third-Party	Netlist language for PrimeSim
saPrimeSimEnvOptsNetlistLanguage	string	user	HSPICE	Netlist language for PrimeSim
saPrimeSimEnvOptsNumGPUProcesses	string	saTestbench	1	Number of GPU Processes
saPrimeSimEnvOptsNumProcesses	string	saTestbench	1	Number of threads
saPrimeSimEnvOptsOutputDataFormat	string	saTestbench	wdf	Output data format

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimEnvOptsProjCfg	string	saTestbench		Project Config File
saPrimeSimEnvOptsStopViewList	string	saTestbench	spectre	Stop View List for netlister
saPrimeSimEnvOptsStopViewList	string	saTestbench	hspice hspiceD	Stop View List for netlister
saPrimeSimEnvOptsSwitchViewList	string	saTestbench	spectre schematic veriloga	Switch View List for netlister
saPrimeSimEnvOptsSwitchViewList	string	saTestbench	hspice hspiceD schematic spice veriloga	Switch View List for netlister
saPrimeSimEnvOptsThirdPartyStopViewList	string	saTestbench	spectre	Stop View List for ThirdParty netlister
saPrimeSimEnvOptsThirdPartySwitchViewList	string	saTestbench	spectre schematic veriloga	Switch View List for ThirdParty netlister
saPrimeSimEnvOptsUse64Bit	string	saTestbench	1	64-bit simulation
saPrimeSimEnvOptsUseCacheDirInCommandLine	bool	user	false	Add pva_output_dir and s_elem_cache_dir in command line option.
saPrimeSimENVOscic	string	saTestbench	default	PrimeSim ENV: Oscillator IC method
saPrimeSimENVOscillator	string	saTestbench	0	PrimeSim ENV: Design is oscillator
saPrimeSimENVOOutputallharms	string	saTestbench	0	PrimeSim ENV: Output Time-Domain Waveform and All Harmonics
saPrimeSimENVOOutputharmonic	string	saTestbench	1	PrimeSim ENV: Frequency
saPrimeSimENVOversample	string	saTestbench	1	PrimeSim ENV: Tones Table 'Oversample' Column
saPrimeSimENVPeriod	string	saTestbench		PrimeSim ENV: Beat Period
saPrimeSimENVSaveinit	string	saTestbench	0	PrimeSim ENV: Save Initial Transient Results

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimENVSignal	string	saTestbench	Moderate	PrimeSim ENV: Tones Table 'Signal' Column
saPrimeSimENVStop	string	saTestbench		PrimeSim ENV: Stop Time
saPrimeSimENVTonesMode	string	saTestbench	Frequencies	PrimeSim ENV: Tone mode for netlisting
saPrimeSimFixedNetlistFormat	string	user		Fixed netlist format on Simulation Options Dialog
saPrimeSimHBACCenter	string	saTestbench		PrimeSim HBAC: Center point of sweep limits
saPrimeSimHBACCrossdirection	string	saTestbench	all	PrimeSim HBAC: Crossing direction
saPrimeSimHBACDec	string	saTestbench		PrimeSim HBAC: Number of logarithmic steps per decade
saPrimeSimHBACLin	string	saTestbench		PrimeSim HBAC: Number of linear steps
saPrimeSimHBACLinearFout	string	saTestbench		PrimeSim HBAC: Frequency of Linear Output Signal
saPrimeSimHBACLog	string	saTestbench		PrimeSim HBAC: Total number of logarithmic steps
saPrimeSimHBACMaxsamples	string	saTestbench		PrimeSim HBAC: Maximum number of sampled events
saPrimeSimHBACMaxsideband	string	saTestbench	1	PrimeSim HBAC: Maximum sideband
saPrimeSimHBACNonlinearFout	string	saTestbench		PrimeSim HBAC: Frequency of IM Output Signal
saPrimeSimHBACOptionkryloviter	string	custom	200	PrimeSim option kryloviter: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*kryloviter iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the kryloviter if the simulation reports insufficient norm reduction errors in GMRES.
saPrimeSimHBACOptionkryloviter UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimHBACOptionkrylovrestart	string	saTestbench		PrimeSim option krylovrestart: iteration to restart for the krylov subspace algorithm
saPrimeSimHBACOptionkrylovrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBACOptionlinearfout	string	saTestbench		PrimeSim option linear_fout: specify the linear output frequency
saPrimeSimHBACOptionlinearfoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBACOptionmaxsideband	string	saTestbench		PrimeSim option maxsideband: the max sidebands in the output
saPrimeSimHBACOptionmaxsidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBACOptionnonlinearfout	string	saTestbench		PrimeSim option nonlinear_fout: specify the nonlinear output frequency
saPrimeSimHBACOptionnonlinearfoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBACOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimHBACOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBACOptionoutput1	string	saTestbench		PrimeSim option output1: specify the output source
saPrimeSimHBACOptionoutput1UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBACOptionoutput2	string	saTestbench		PrimeSim option output2: specify the output source
saPrimeSimHBACOptionoutput2UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBACOptionperturbation	string	saTestbench		PrimeSim option perturbation: if set, ip2 or ip3 is computed

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimHBACOptionperturbati onUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimImportHSPICEFileMa sks	string	user	"SPICE (*.*.sp *.spi)" "Spectre (*.*.scs)" "All Files (*)"	List of import file mask patterns
saPrimeSimImportThirdPartyFileM asks	string	user	"Spectre (*.*.scs)" "SPICE (*.*.sp *.spi)" "All Files (*.)"	List of import file mask patterns
saPrimeSimOptionprimesimIteratio scale	string	saTestbe nch	1.0	PrimeSim option primesim_iteratio_scale: Multiplier for time-step local truncation error tolerance. Larger value means larger time step. Possible values are normally between 0.1 and 10
saPrimeSimOptionprimesimIteratio scaleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimIteratioScale is loaded.
saPrimeSimOptionprimesimAutore start	string	saTestbe nch		PrimeSim option primesim_auto_restart: Allow to create snapshots during transient simulation that can be used in conjunction with the -auto_restart command-line option.
saPrimeSimOptionprimesimAutore startUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimAutorestart is loaded.
saPrimeSimHBACOptionrfinput1	string	saTestbe nch		PrimeSim option rf_input1: specify the input source
saPrimeSimHBACOptionrfinput1U ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBACOptionrfinput2	string	saTestbe nch		PrimeSim option rf_input2: specify the input source
saPrimeSimHBACOptionrfinput2U ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBACOptionrfinputmag	string	saTestbench		PrimeSim option rf_input_mag: specify the input magnitude
saPrimeSimHBACOptionrfinputmagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBACOptionrfinputpwr	string	saTestbench		PrimeSim option rf_input_pwr: specify the input power
saPrimeSimHBACOptionrfinputpwrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBACOptionsampledef	string	saTestbench		PrimeSim option sample_def: specify the measurement name to do the sample analysis
saPrimeSimHBACOptionsampledefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBACOptionsidebands	string	saTestbench		PrimeSim option sidebands: specify the sidebands in the output
saPrimeSimHBACOptionsidebandsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBACOptiontolerance	string	custom		PrimeSim option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saPrimeSimHBACOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBACRelharms	string	saTestbench	1	PrimeSim HBAC: Harmonic index number for relative sweep
saPrimeSimHBACRfInputMag	string	saTestbench		PrimeSim HBAC: Input Magnitude
saPrimeSimHBACRfInputPwr	string	saTestbench		PrimeSim HBAC: Input Power (dbm)
saPrimeSimHBACRfInputPwrOrMag	string	saTestbench	Input Power (dbm)	PrimeSim HBAC: Input Power or Magnitude
saPrimeSimHBACSampled	string	saTestbench	0	PrimeSim HBAC: PTV analysis type

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimHBACSampleType	string	saTestbench	Probe	PrimeSim HBAC: The type of sampling trigger to use (Probe or Voltage)
saPrimeSimHBACSanalysisType	string	saTestbench	none	PrimeSim HBAC: Specialized Analyses
saPrimeSimHBACSidebands	string	saTestbench	1	PrimeSim HBAC: Sidebands array
saPrimeSimHBACSidebandType	string	saTestbench	Unspecified	PrimeSim HBAC: Sideband type
saPrimeSimHBACSpan	string	saTestbench		PrimeSim HBAC: Span between sweep limits
saPrimeSimHBACSstart	string	saTestbench		PrimeSim HBAC: Start Frequency for specialized analyses
saPrimeSimHBACSstop	string	saTestbench		PrimeSim HBAC: Stopp Frequency for specialized analyses
saPrimeSimHBACStart	string	saTestbench		PrimeSim HBAC: Starting point of sweep limits
saPrimeSimHBACStep	string	saTestbench		PrimeSim HBAC: Linear step size
saPrimeSimHBACStepSpecLin	string	saTestbench	Number of Steps	PrimeSim HBAC: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimHBACStepSpecLog	string	saTestbench	Points per Decade	PrimeSim HBAC: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimHBACStop	string	saTestbench		PrimeSim HBAC: Stopping point of sweep limits
saPrimeSimHBACSweep	string	saTestbench	Logarithmic	PrimeSim HBAC: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimHBACSweepSpec	string	saTestbench	<file path>	PrimeSim HBAC: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimHBACSweeptype	string	saTestbench	Default	PrimeSim HBAC: Frequency sweep type
saPrimeSimHBACTime	string	saTestbench		PrimeSim HBAC: Extra sample time points
saPrimeSimHBACVal	string	saTestbench		PrimeSim HBAC: Threshold value

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBACValues	string	saTestbench		PrimeSim HBAC: Individual values, also known as points of interest
saPrimeSimHBAutoharms	string	saTestbench	0	PrimeSim HB: Perform automatic harmonic number calculation
saPrimeSimHBCenter	string	saTestbench		PrimeSim HB: Center point of sweep limits
saPrimeSimHBCompress	string	saTestbench	0	PrimeSim HB: Turn on compression analysis
saPrimeSimHBCompressGain	string	saTestbench	power	PrimeSim HB: Determine how gain is defined, either voltage gain or power gain
saPrimeSimHBCompressHarm	string	saTestbench	1	PrimeSim HB: The parameter to set the harmonic index
saPrimeSimHBCompressLevel	string	saTestbench	1	PrimeSim HB: Compress Level (dB)
saPrimeSimHBCompressLoad	string	saTestbench		PrimeSim HB: The parameter to set the instance name of the load element to calculate the power of load
saPrimeSimHBCompressNnode	string	saTestbench		PrimeSim HB: The parameter to set negative node to measure voltage
saPrimeSimHBCompressPnode	string	saTestbench		PrimeSim HB: The parameter to set positive node to measure voltage
saPrimeSimHBCompressRef	string	saTestbench	linear	PrimeSim HB: The parameter to define the reference for gain compression calculation
saPrimeSimHBCompressRefnode	string	saTestbench		PrimeSim HB: The parameter to set the reference circuit node when compress_load is a current probe
saPrimeSimHBCompressSource	string	saTestbench		PrimeSim HB: The parameter to set the instance name of the excitation source
saPrimeSimHBDataformat	string	saTestbench	magphase	PrimeSim HB: data format or the large-signal S-parameter output: realimag, magphase and phase
saPrimeSimHBDec	string	saTestbench		PrimeSim HB: Number of logarithmic steps per decade
saPrimeSimHBDesignVar	string	saTestbench		PrimeSim HB: Design variable being swept
saPrimeSimHBDetectsteady	string	saTestbench	0	PrimeSim HB: Run automatic steady state detection during initial transient (tstab)

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBDev	string	saTestbench		PrimeSim HB: Instance with parameter being swept
saPrimeSimHBDoLoadPull	string	saTestbench	0	PrimeSim HB: Flag indicating a load pull sweep is to be performed
saPrimeSimHBDoLoadPullPort	string	saTestbench	1	PrimeSim HB: Flag indicating a port will serve as the load
saPrimeSimHBDoIssp	string	saTestbench	0	PrimeSim HB: Enable/disable Issp widgets group
saPrimeSimHBDoSweep	string	saTestbench	0	PrimeSim HB: Flag indicating a sweep is to be performed
saPrimeSimHBMethod	string	saTestbench	Vector	PrimeSim hb parameter values in file/vector
saPrimeSimHBDynamicParameters	bool	saTestbench	false	PrimeSim hb show/hide dynamic parameters
saPrimeSimHBFilename	string	saTestbench		PrimeSim HB: the file name for large-signal S-parameter output
saPrimeSimHBFormat	string	saTestbench	touchstone	PrimeSim HB: file format of the large-signal S-parameter output: touchstone and spectre
saPrimeSimHBFrequencyDivider	string	saTestbench		PrimeSim HB: Large Signal frequencyDivider Ratio
saPrimeSimHBHarmonicCut	string	saTestbench	diamond	PrimeSim HB: Intermodulation selection mode for harmonics
saPrimeSimHBHarmsType	string	Default	Select	PrimeSim HB: Harmonics Specification Type
saPrimeSimHBIntmodmax	string	saTestbench		PrimeSim HB: Maximum intermodulation order of harmonics
saPrimeSimHBLin	string	saTestbench		PrimeSim HB: Number of linear steps
saPrimeSimHBLINCenter	string	saTestbench		PrimeSim HBLIN: Center point of sweep limits
saPrimeSimHBLINDec	string	saTestbench		PrimeSim HBLIN: Number of logarithmic steps per decade
saPrimeSimHBLINFreqAxis	string	saTestbench	in	PrimeSim HBLIN: Freq Axis
saPrimeSimHBLINLin	string	saTestbench		PrimeSim HBLIN: Number of linear steps

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBLINLog	string	saTestbench		PrimeSim HBLIN: Total number of logarithmic steps
saPrimeSimHBLINMaxSideband	string	saTestbench	1	PrimeSim HBLIN: Maximum Side Band
saPrimeSimHBLINNoisecalc	string	saTestbench	0	PrimeSim HBLIN: Do Noise
saPrimeSimHBLINOptiondataformat	string	saTestbench		PrimeSim option dataformat: format of values
saPrimeSimHBLINOptiondataformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBLINOptionfilename	string	saTestbench		PrimeSim option filename: filename to write result
saPrimeSimHBLINOptionfilenameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBLINOptioniport	string	saTestbench	0	PrimeSim option iport: input port
saPrimeSimHBLINOptioniportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBLINOptionkryloviter	string	custom	200	PrimeSim option kryloviter: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*kryloviter iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the kryloviter if the simulation reports insufficient norm reduction errors in GMRES.
saPrimeSimHBLINOptionkryloviterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBLINOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimHBLINOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBLINOptionnoisecalc	string	saTestbench	0	PrimeSim option noisecalc: if 1, compute noise parameters

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBLINOptionnoisecalcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBLINOptionoport	string	saTestbench	1	PrimeSim option oport: output port
saPrimeSimHBLINOptionoportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBLINOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimHBLINOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBLINOptionports	string	saTestbench		PrimeSim option ports: array of p elements
saPrimeSimHBLINOptionportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBLINOptionspcalc	string	saTestbench	1	PrimeSim option spcalc: if 1, compute scattering parameters
saPrimeSimHBLINOptionspcalcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBLINOptionsprobes	string	saTestbench		PrimeSim option sprobes: array of probes
saPrimeSimHBLINOptionsprobesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBLINOptiontolerance	string	custom		PrimeSim option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saPrimeSimHBLINOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBLINSpan	string	saTestbench		PrimeSim HBLIN: Span between sweep limits

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBLINStart	string	saTestbench		PrimeSim HBLIN: Starting point of sweep limits
saPrimeSimHBLINStep	string	saTestbench		PrimeSim HBLIN: Linear step size
saPrimeSimHBLINStepSpecLin	string	saTestbench	Number of Steps	PrimeSim HBLIN: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimHBLINStepSpecLog	string	saTestbench	Points per Decade	PrimeSim HBLIN: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimHBLINStop	string	saTestbench		PrimeSim HBLIN: Stopping point of sweep limits
saPrimeSimHBLINSweep	string	saTestbench	Logarithmic	PrimeSim HBLIN: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimHBLINSweepSpec	string	saTestbench	<file path>	PrimeSim HBLIN: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimHBLINSweepType	string	saTestbench	Default	PrimeSim HBLIN: Frequency sweep type
saPrimeSimHBLINValues	string	saTestbench		PrimeSim HBLIN: Individual values, also known as points of interest
saPrimeSimHBLLoadstate	string	saTestbench		PrimeSim HB: Load state file
saPrimeSimHBLog	string	saTestbench		PrimeSim HB: Total number of logarithmic steps
saPrimeSimHBLp2Param	string	saTestbench		PrimeSim HB: Ip2Param parameter being swept
saPrimeSimHBLp2Paramlin	string	saTestbench		PrimeSim HB: Number of Ip2Param linear steps
saPrimeSimHBLp2Paramstart	string	saTestbench		PrimeSim HB: Starting point of Ip2Param sweep limits
saPrimeSimHBLp2Paramstep	string	saTestbench		PrimeSim HB: Linear Ip2Param step size
saPrimeSimHBLp2ParamStepSpecLin	string	saTestbench	Number of Steps	PrimeSim HB: Method of specifying Ip2Param linear stepping ("Step Size" "Number of Steps")

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBLp2Paramstop	string	saTestbench		PrimeSim HB: Stopping point of lp2Param sweep limits
saPrimeSimHBLp2ParamSweep	string	saTestbench	Linear	PrimeSim HB: Method of sweeping lp2Param values ("Linear" "Points of Interest")
saPrimeSimHBLp2Paramvalues	string	saTestbench		PrimeSim HB: Individual lp2Param values, also known as points of interest
saPrimeSimHBLpinst	string	saTestbench		PrimeSim HB: Port that loads the amplifier (hb only)
saPrimeSimHBLpParam	string	saTestbench		PrimeSim HB: lpParam parameter being swept
saPrimeSimHBLpParamlin	string	saTestbench		PrimeSim HB: Number of lpParam linear steps
saPrimeSimHBLpParamstart	string	saTestbench		PrimeSim HB: Starting point of lpParam sweep limits
saPrimeSimHBLpParamstep	string	saTestbench		PrimeSim HB: Linear lpParam step size
saPrimeSimHBLpParamStepSpecLin	string	saTestbench	Number of Steps	PrimeSim HB: Method of specifying lpParam linear stepping ("Step Size" "Number of Steps")
saPrimeSimHBLpParamstop	string	saTestbench		PrimeSim HB: Stopping point of lpParam sweep limits
saPrimeSimHBLpParamSweep	string	saTestbench	Linear	PrimeSim HB: Method of sweeping lpParam values ("Linear" "Points of Interest")
saPrimeSimHBLpParamvalues	string	saTestbench		PrimeSim HB: Individual lpParam values, also known as points of interest
saPrimeSimHBLpz0	string	saTestbench	50	PrimeSim HB: Port impedance (hb only)
saPrimeSimHBMod	string	saTestbench		PrimeSim HB: Model with parameter being swept
saPrimeSimHBNOISECenter	string	saTestbench		PrimeSim HBNOISE: Center point of sweep limits
saPrimeSimHBNOISEDec	string	saTestbench		PrimeSim HBNOISE: Number of logarithmic steps per decade
saPrimeSimHBNOISELin	string	saTestbench		PrimeSim HBNOISE: Number of linear steps

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimHBNOISELog	string	saTestbench		PrimeSim HBNOISE: Total number of logarithmic steps
saPrimeSimHBNOISEMaxsideband	string	saTestbench	1	PrimeSim HBNOISE: Maximum sideband
saPrimeSimHBNOISENoiseout	string	saTestbench	usb	PrimeSim HBNOISE: Noise Out
saPrimeSimHBNOISEOptionfullspectrum	string	saTestbench		PrimeSim option fullspectrum: if yes, the sampled noise is computed on full spectrum.
saPrimeSimHBNOISEOptionfullspectrumUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOptionkryloviter	string	custom	200	PrimeSim option kryloviter: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*kryloviter iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the kryloviter if the simulation reports insufficient norm reduction errors in GMRES.
saPrimeSimHBNOISEOptionkryloviterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOptionkrylovrestart	string	saTestbench		PrimeSim option krylovrestart: iteration to restart for the krylov subspace algorithm
saPrimeSimHBNOISEOptionkrylovrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOptionlistcount	string	saTestbench	1	PrimeSim option listcount: For example, listcount=5 means that only the top 5 noise contributors are printed
saPrimeSimHBNOISEOptionlistcountUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOptionlistfloor	string	saTestbench	1.0e-14	PrimeSim option listfloor: defines a minimum meaningful noise value (in V/Hz ^{1/2} units).
saPrimeSimHBNOISEOptionlistfloorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBNOISEOptionlistfreq	string	saTestbench		PrimeSim option listfreq: specify at which frequencies the element noise value is printed.
saPrimeSimHBNOISEOptionlistfreqUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOptionlistsources	string	saTestbench	1	PrimeSim option listsources: specify if prints the contribution from each noise source
saPrimeSimHBNOISEOptionlistsourcesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOptionmaxsideband	string	saTestbench		PrimeSim option maxsideband: the max sidebands in the output
saPrimeSimHBNOISEOptionmaxsidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimHBNOISEOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOptionnoiseoutput	string	saTestbench	usb	PrimeSim option noise_output: noise type
saPrimeSimHBNOISEOptionnoiseoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimHBNOISEOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOptionoutputxf	string	custom	no	PrimeSim option output_xf: If set to no, there are no xf results output in hbnoise. Possible values are no and yes.
saPrimeSimHBNOISEOptionoutputxfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBNOISEOptionreference_sideband	string	saTestbench		PrimeSim option reference_sideband: the reference sideband to compute input noise
saPrimeSimHBNOISEOptionreference_sidebandUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOptionsample_def	string	saTestbench		PrimeSim option sample_def: specify the measurement name to do the sample analysis
saPrimeSimHBNOISEOptionsample_defUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOptionsidebands	string	saTestbench		PrimeSim option sidebands: specify the sidebands in the output
saPrimeSimHBNOISEOptionsidebandsUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOptiontolerance	string	custom		PrimeSim option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saPrimeSimHBNOISEOptiontoleranceUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBNOISEOutputType	string	saTestbench	Voltage	PrimeSim HBNOISE: Output type
saPrimeSimHBNOISERefsideband	string	saTestbench		PrimeSim HBNOISE: Conversion gain sideband
saPrimeSimHBNOISERelharms	string	saTestbench	1	PrimeSim HBNOISE: Harmonic index number for relative sweep
saPrimeSimHBNOISESampled	string	saTestbench	0	PrimeSim HBNOISE: Noise Type
saPrimeSimHBNOISESampleratio	string	saTestbench		PrimeSim SNNOISE: Sample Ratio
saPrimeSimHBNOISESidebands	string	saTestbench	1	PrimeSim HBNOISE: Sidebands array
saPrimeSimHBNOISESidebandType	string	saTestbench	Unspecified	PrimeSim HBNOISE: Sideband type

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimHBNOISESpan	string	saTestbench		PrimeSim HBNOISE: Span between sweep limits
saPrimeSimHBNOISEStart	string	saTestbench		PrimeSim HBNOISE: Starting point of sweep limits
saPrimeSimHBNOISEStep	string	saTestbench		PrimeSim HBNOISE: Linear step size
saPrimeSimHBNOISEStepSpecLin	string	saTestbench	Number of Steps	PrimeSim HBNOISE: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimHBNOISEStepSpecLog	string	saTestbench	Points per Decade	PrimeSim HBNOISE: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimHBNOISEStop	string	saTestbench		PrimeSim HBNOISE: Stopping point of sweep limits
saPrimeSimHBNOISESweep	string	saTestbench	Logarithmic	PrimeSim HBNOISE: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimHBNOISESweepSpec	string	saTestbench	<file path>	PrimeSim HBNOISE: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimHBNOISESweeptype	string	saTestbench	Default	PrimeSim HBNOISE: Frequency sweep type
saPrimeSimHBNOISEValues	string	saTestbench		PrimeSim HBNOISE: Individual values, also known as points of interest
saPrimeSimHBOptionautotrinit	string	saTestbench	0	PrimeSim option autotrinit: automatically stop in the initial tran
saPrimeSimHBOptionautotrinitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptioncompressmaxsteps	string	saTestbench	100	PrimeSim option compress_maxsteps: The parameter to set the maximum sweep steps in sweeping to search the compression point.
saPrimeSimHBOptioncompressmaxstepsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimHBOptioncompressmaxsteps is loaded.
saPrimeSimHBOptioncompressstart	string	saTestbench		PrimeSim option compress_start: The parameter to set the starting value of power or voltage in sweep.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimHBOptioncompressstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimHBOptioncompressstart is loaded.
saPrimeSimHBOptioncompressstop	string	saTestbench	30	PrimeSim option compress_stop: The parameter to set the upper limit of power or voltage in sweep.
saPrimeSimHBOptioncompressstopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimHBOptioncompressstop is loaded.
saPrimeSimHBOptioncompressstol	string	saTestbench	0.01	PrimeSim option compress_tol: The parameter to set the tolerance for compression point calculation and compression curve fitting.
saPrimeSimHBOptioncompressstolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimHBOptioncompressstol is loaded.
saPrimeSimHBOptiondetectharms	string	saTestbench		PrimeSim option detect_harms: detect harms automatically
saPrimeSimHBOptiondetectharmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptiondetectsteady	string	saTestbench	0	PrimeSim option detect_steady: detect the steady state in the given time region
saPrimeSimHBOptiondetectsteadyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionfrequencydivider	string	saTestbench		PrimeSim option frequency_divider: option divide frequency for better accuracy
saPrimeSimHBOptionfrequencydividerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionfspts	string	saTestbench		PrimeSim option fspts: FSPTS=NUM, MIN, MAX specify the frequency search
saPrimeSimHBOptionfsptsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimHBOptionfunds	string	saTestbench		PrimeSim option funds: names array for fundamental frequency
saPrimeSimHBOptionfundsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionharmoniccut	string	saTestbench		PrimeSim option harmonic_cut: method to cut harmonics
saPrimeSimHBOptionharmoniccutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionharmsarray	string	saTestbench		PrimeSim option harmsarray: harms to output in the file
saPrimeSimHBOptionharmsarrayUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionhbmode	string	custom	tone	PrimeSim option hbmode: Name of Harmonic Balance hb_mode selection methods. Possible values are tstab, tone.
saPrimeSimHBOptionhbmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionintmodmax	string	saTestbench		PrimeSim option intmodmax: the maximum intermodulation product order that you can specify in the analysis spectrum
saPrimeSimHBOptionintmodmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionkryloviter	string	custom	10	PrimeSim option kryloviter: The minimum iteration count of the linear matrix solver used in HB large-signal analysis. After reaching kryloviter iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase kryloviter if the simulation reports insufficient norm reduction errors in GMRES.
saPrimeSimHBOptionkryloviterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionkrylovrestart	string	saTestbench		PrimeSim option krylovrestart: iteration to restart for the krylov subspace algorithm

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBOptionkrylovrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionkrylovtol	string	custom	1e-4	PrimeSim option krylovtol: Controls the residual for iterative solution of linearized matrix equation at each Newton iteration. Tightening the parameter can help with the Newton convergence, but does not affect the result accuracy. The value should be between [0, 1].
saPrimeSimHBOptionkrylovtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionloadstate	string	saTestbench		PrimeSim option loadstate: load state file to initialize analyses
saPrimeSimHBOptionloadstateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionlp2param	string	saTestbench		PrimeSim option lp2_param: the second parameters to sweep for load pull analysis
saPrimeSimHBOptionlp2paramUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionlpinst	string	saTestbench		PrimeSim option lp_inst: element name to sweep for load pull analysis
saPrimeSimHBOptionlpinstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionlpparam	string	saTestbench		PrimeSim option lp_param: the first parameters to sweep for load pull analysis
saPrimeSimHBOptionlpparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionlpz0	string	saTestbench		PrimeSim option lp_z0: the characteristic impedance to sweep for load pull analysis
saPrimeSimHBOptionlpz0UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBOptionmaxiter	string	custom		PrimeSim option maxiter: Maximum number of iterations allowed before convergence is reached in shooting or harmonic balance Newton iteration. For SN, the default is 20 for driven circuits, and 50 for oscillators; For HB, the default is 100.
saPrimeSimHBOptionmaxiterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionmaxsideband	string	saTestbench		PrimeSim option maxsideband: the max sidebands in the output
saPrimeSimHBOptionmaxsidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimHBOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionnharms	string	saTestbench		PrimeSim option nharms: number of harmonics to use for each tone
saPrimeSimHBOptionnharmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionosr	string	saTestbench		PrimeSim option osr: factor to oversample the signals
saPrimeSimHBOptionosrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimHBOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionparam	string	saTestbench		PrimeSim option param: option name to change in tran
saPrimeSimHBOptionparamdata	string	saTestbench		PrimeSim option param_data: value array to change the option specified by "param"

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimHBOptionparamdataUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionperiod	string	saTestbench		PrimeSim option period: fundamental period
saPrimeSimHBOptionperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionpreconditioner	string	saTestbench		PrimeSim option preconditioner: type of preconditioner
saPrimeSimHBOptionpreconditionerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionprobenode	string	saTestbench		PrimeSim option probenode: specify the node to detect oscillation
saPrimeSimHBOptionprobenodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionreadic	string	custom		PrimeSim option read_ic: File that contains initial condition.
saPrimeSimHBOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionreadns	string	custom		PrimeSim option read_ns: File that contains an estimate of the initial transient solution.
saPrimeSimHBOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionrestart	string	custom	no	PrimeSim option restart: Restart the DC/SN solution if set to 'yes'; if set to 'no', reuse the previous solution as an initial guess; if set to 'firstonly', restart if it is the first point of sweep (supported only in HB). The default value is 'no' for HB and 'yes' for shooting. Possible values are no, yes, and firstonly.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBOptionrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionsavestate	string	saTestbench		PrimeSim option savestate: save state to a file
saPrimeSimHBOptionsavestateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionsavetrinit	string	saTestbench	0	PrimeSim option save_trinit: if yes, save the waveform of initial tran
saPrimeSimHBOptionsavetrinitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionsubharms	string	saTestbench		PrimeSim option subharms: Allows subharmonics in the analysis spectrum. The minimum non-DC frequency in the analysis spectrum is f/subharms, where f is the frequency of oscillation
saPrimeSimHBOptionsubharmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptiontones	string	saTestbench		PrimeSim option tones: Fundamental frequencies
saPrimeSimHBOptiontonesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptiontrinit	string	saTestbench		PrimeSim option trinit: Transient initialization time
saPrimeSimHBOptiontrinitmethod	string	saTestbench	trap	PrimeSim option trinit_method: Sets the numerical integration method used during a transient analysis.
saPrimeSimHBOptiontrinitmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptiontrinitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionuic	string	custom	no	PrimeSim option uic: If set to yes, there is no DC analysis for initial transient. Possible values are no, yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBOptionuicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionwrite	string	saTestbench		PrimeSim option write: write file at the first point
saPrimeSimHBOptionwritefinal	string	saTestbench		PrimeSim option write_final: write file at the last point
saPrimeSimHBOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBOscillator	string	saTestbench	0	PrimeSim HB: Design is oscillator
saPrimeSimHBOutharms	string	saTestbench		PrimeSim HB: Output harmonic for large-signal S-parameter calculations
saPrimeSimHBParam	string	saTestbench		PrimeSim HB: Parameter being swept
saPrimeSimHBParamdata	string	saTestbench		PrimeSim hb parameter data
saPrimeSimHBParamfile	string	saTestbench		PrimeSim hb parameter file
saPrimeSimHBParamname	string	saTestbench		PrimeSim hb parameter
saPrimeSimHBPorts	string	saTestbench		PrimeSim HB: List of ports on which the large-signal 2-port S-parameters are calculated
saPrimeSimHBRunTran	string	saTestbench	No	PrimeSim HB: Specifies to run transient
saPrimeSimHBSavestate	string	saTestbench		PrimeSim HB: Save state file
saPrimeSimHBSavetrinit	string	saTestbench	0	PrimeSim HB: Save initial transient results
saPrimeSimHBSpan	string	saTestbench		PrimeSim HB: Span between sweep limits

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimHBStart	string	saTestbench		PrimeSim HB: Starting point of sweep limits
saPrimeSimHBSTBCenter	string	saTestbench		PrimeSim HBSTB: Center point of sweep limits
saPrimeSimHBSTBDec	string	saTestbench		PrimeSim HBSTB: Number of logarithmic steps per decade
saPrimeSimHBSTBLin	string	saTestbench		PrimeSim HBSTB: Number of linear steps
saPrimeSimHBSTBLog	string	saTestbench		PrimeSim HBSTB: Total number of logarithmic steps
saPrimeSimHBSTBModeType	string	saTestbench	differential	PrimeSim HBSTB: Mode Type for diffstbprobe element
saPrimeSimHBSTBOptionkryloviter	string	saTestbench		PrimeSim option kryloviter: max iteration for the krylov subspace algorithm
saPrimeSimHBSTBOptionkryloviterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBSTBOptionkrylovrestart	string	saTestbench		PrimeSim option krylovrestart: iteration to restart for the krylov subspace algorithm
saPrimeSimHBSTBOptionkrylovrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBSTBOptionmaxsideband	string	saTestbench		PrimeSim option maxsideband: the max sidebands in the output
saPrimeSimHBSTBOptionmaxsidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBSTBOptionmode	string	saTestbench	single	PrimeSim option mode: If the feedback loop has a differential amplifier, then there are two signal
saPrimeSimHBSTBOptionmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBSTBOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimHBSTBOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBSTBOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimHBSTBOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBSTBOptiontolerance	string	custom		PrimeSim option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saPrimeSimHBSTBOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBSTBOptionvsource	string	saTestbench		PrimeSim option vsource: The 0V voltage source(s) indicating the insertion point of test circuit. Note that the direction of Vxxx is of significance in diff/comm mode analysis.
saPrimeSimHBSTBOptionvsourceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBSTBSpan	string	saTestbench		PrimeSim HBSTB: Span between sweep limits
saPrimeSimHBSTBStart	string	saTestbench		PrimeSim HBSTB: Starting point of sweep limits
saPrimeSimHBSTBStep	string	saTestbench		PrimeSim HBSTB: Linear step size
saPrimeSimHBSTBStepSpecLin	string	saTestbench	Number of Steps	PrimeSim HBSTB: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimHBSTBStepSpecLog	string	saTestbench	Points per Decade	PrimeSim HBSTB: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimHBSTBStop	string	saTestbench		PrimeSim HBSTB: Stopping point of sweep limits
saPrimeSimHBSTBSweep	string	saTestbench	Logarithmic	PrimeSim HBSTB: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimHBSTBSweepSpec	string	saTestbench	<file path>	PrimeSim HBSTB: Method of specifying sweep limits ("Start/Stop" "Center/Span")

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBSTBValues	string	saTestbench		PrimeSim HBSTB: Individual values, also known as points of interest
saPrimeSimHBSTBVsource	string	saTestbench		PrimeSim HBSTB: oprobe instance around which the loop gain is calculated
saPrimeSimHBStep	string	saTestbench		PrimeSim HB: Linear step size
saPrimeSimHBStepSpecLin	string	saTestbench	Number of Steps	PrimeSim HB: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimHBStepSpecLog	string	saTestbench	Points per Decade	PrimeSim HB: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimHBStop	string	saTestbench		PrimeSim HB: Stopping point of sweep limits
saPrimeSimHBSub	string	saTestbench		PrimeSim HB: Subcircuit with parameter being swept
saPrimeSimHBSweep	string	saTestbench	Linear	PrimeSim HB: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimHBSweepSpec	string	saTestbench	<file path>	PrimeSim HB: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimHBSweepVar	string	saTestbench	Temperature	PrimeSim HB: Specifies what will be swept ("Design Variable" "Temperature")
saPrimeSimHBTextParam	string	saTestbench		PrimeSim HB: Parameter being swept.
saPrimeSimHBTrinit	string	saTestbench		PrimeSim HB: Additional time for stabilization
saPrimeSimHBValues	string	saTestbench		PrimeSim HB: Individual values, also known as points of interest
saPrimeSimHBXFCenter	string	saTestbench		PrimeSim HBXF: Center point of sweep limits
saPrimeSimHBXFCrossdirection	string	saTestbench	all	PrimeSim HBXF: Crossing direction
saPrimeSimHBXFDec	string	saTestbench		PrimeSim HBXF: Number of logarithmic steps per decade
saPrimeSimHBXFLin	string	saTestbench		PrimeSim HBXF: Number of linear steps

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBXFLog	string	saTestbench		PrimeSim HBXF: Total number of logarithmic steps
saPrimeSimHBXFMaxsamples	string	saTestbench		PrimeSim HBXF: Maximum number of sampled events
saPrimeSimHBXFMaxsideband	string	saTestbench	1	PrimeSim HBXF: Maximum sideband
saPrimeSimHBXFOptionkryloviter	string	custom	200	PrimeSim option kryloviter: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*kryloviter iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the kryloviter if the simulation reports insufficient norm reduction errors in GMRES.
saPrimeSimHBXFOptionkryloviterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBXFOptionkrylovrestart	string	saTestbench		PrimeSim option krylovrestart: iteration to restart for the krylov subspace algorithm
saPrimeSimHBXFOptionkrylovrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBXFOptionmaxsideband	string	saTestbench		PrimeSim option maxsideband: the max sidebands in the output
saPrimeSimHBXFOptionmaxsidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBXFOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimHBXFOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBXFOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimHBXFOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBXFOptionsampledef	string	saTestbench		PrimeSim option sample_def: specify the measurement name to do the sample analysis
saPrimeSimHBXFOptionsampledefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBXFOptionsidebands	string	saTestbench		PrimeSim option sidebands: specify the sidebands in the output
saPrimeSimHBXFOptionsidebandsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBXFOptionstimuli	string	custom	sources	PrimeSim option stimuli: Stimuli used for XF analysis in hbnoise. Possible values are sources and nodes_and_terminals.
saPrimeSimHBXFOptionstimuliUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBXFOptiontolerance	string	custom		PrimeSim option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saPrimeSimHBXFOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimHBXFOutputType	string	saTestbench	Voltage	PrimeSim HBXF: Output type
saPrimeSimHBXFRelharms	string	saTestbench	1	PrimeSim HBXF: Harmonic index number for relative sweep
saPrimeSimHBXFSampled	string	saTestbench	0	PrimeSim HBXF: PTV analysis type
saPrimeSimHBXFSampleType	string	saTestbench	Probe	PrimeSim HBXF: The type of sampling trigger to use (Probe or Voltage)
saPrimeSimHBXFSidebands	string	saTestbench	1	PrimeSim HBXF: Sidebands array
saPrimeSimHBXFSidebandType	string	saTestbench	Unspecified	PrimeSim HBXF: Sideband type
saPrimeSimHBXFSPAN	string	saTestbench		PrimeSim HBXF: Span between sweep limits

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimHBXFStart	string	saTestbench		PrimeSim HBXF: Starting point of sweep limits
saPrimeSimHBXFStep	string	saTestbench		PrimeSim HBXF: Linear step size
saPrimeSimHBXFStepSpecLin	string	saTestbench	Number of Steps	PrimeSim HBXF: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimHBXFStepSpecLog	string	saTestbench	Points per Decade	PrimeSim HBXF: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimHBXFStop	string	saTestbench		PrimeSim HBXF: Stopping point of sweep limits
saPrimeSimHBXFSweep	string	saTestbench	Logarithmic	PrimeSim HBXF: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimHBXFSweepSpec	string	saTestbench	<file path>	PrimeSim HBXF: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimHBXFSweepType	string	saTestbench	Default	PrimeSim HBXF: Frequency sweep type
saPrimeSimHBXFTime	string	saTestbench		PrimeSim HBXF: Extra sample time points
saPrimeSimHBXFVal	string	saTestbench		PrimeSim HBXF: Threshold value
saPrimeSimHBXFValues	string	saTestbench		PrimeSim HBXF: Individual values, also known as points of interest
saPrimeSimHSPICEDiffStbProbeFile	string	user	default	PrimeSim HSPIICE format diffstbprobe file path
saPrimeSimHysteresis	bool	saTestbench	false	PrimeSim DC hysteresis sweep
saPrimeSimINCLUDEFile	string	saTestbench		The include file containing the analyses statements
saPrimeSimINCLUDEOptionOtherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimLINCenter	string	saTestbench		PrimeSim LIN: Center point of sweep limits

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimLINDataformat	string	saTestbench	ri	PrimeSim LIN: Data Format
saPrimeSimLINDec	string	saTestbench		PrimeSim LIN: Number of logarithmic steps per decade
saPrimeSimLINDesignVar	string	saTestbench		PrimeSim LIN: Design variable being swept
saPrimeSimLINDev	string	saTestbench		PrimeSim LIN: Instance with parameter being swept
saPrimeSimLINFilename	string	saTestbench		PrimeSim LIN: S-parameter output filename
saPrimeSimLINFormat	string	saTestbench	touchstone	PrimeSim LIN: Format
saPrimeSimLINFreq	string	saTestbench		PrimeSim LIN: Single value to hold frequency while other aspect is being swept
saPrimeSimLINLin	string	saTestbench		PrimeSim LIN: Number of linear steps
saPrimeSimLINLog	string	saTestbench		PrimeSim LIN: Total number of logarithmic steps
saPrimeSimLINMod	string	saTestbench		PrimeSim LIN: Model with parameter being swept
saPrimeSimLINMode	string	saTestbench	ss	PrimeSim LIN: Mode
saPrimeSimLINModeOther	string	saTestbench		PrimeSim LIN: Mode other
saPrimeSimLINNoiseCalc	string	saTestbench	0	PrimeSim LIN: Do Noise Analysis
saPrimeSimLINOptiondataformat	string	saTestbench		PrimeSim option dataformat: format of values
saPrimeSimLINOptiondataformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINOptionfile	string	custom		PrimeSim option file: Output file name.
saPrimeSimLINOptionfilename	string	saTestbench		PrimeSim option filename: filename to write result

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimLINOOptionfilenameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINOOptionfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINOoptioniport	string	saTestbench	0	PrimeSim option iport: input port
saPrimeSimLINOoptioniportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINOoptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimLINOoptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINOoptionnoisecalc	string	saTestbench	0	PrimeSim option noisecalc: if 1, compute noise parameters
saPrimeSimLINOoptionnoisecalcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINOoptionoport	string	saTestbench	1	PrimeSim option oport: output port
saPrimeSimLINOoptionoportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINOoptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimLINOoptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINOoptionports	string	saTestbench		PrimeSim option ports: array of p elements
saPrimeSimLINOoptionportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimLINOOptionreadic	string	saTestbench		PrimeSim option read_ic: read file for .ic
saPrimeSimLINOOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINOOptionreadns	string	saTestbench		PrimeSim option read_ns: read file for .nodeset
saPrimeSimLINOOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINOOptionspcalc	string	saTestbench	1	PrimeSim option spcalc: if 1, compute scattering parameters
saPrimeSimLINOOptionspcalcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINOOptionprobes	string	saTestbench		PrimeSim option sprobes: array of probes
saPrimeSimLINOOptionprobesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINOOptionwrite	string	saTestbench		PrimeSim option write: write file at the first point
saPrimeSimLINOOptionwritefinal	string	saTestbench		PrimeSim option write_final: write file at the last point
saPrimeSimLINOOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINOOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLINParam	string	saTestbench		PrimeSim LIN: Parameter being swept
saPrimeSimLINTextParam	string	saTestbench		PrimeSim LIN: Parameter being swept
saPrimeSimLINSpan	string	saTestbench		PrimeSim LIN: Span between sweep limits
saPrimeSimLINStart	string	saTestbench		PrimeSim LIN: Starting point of sweep limits

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimLINStep	string	saTestbench		PrimeSim LIN: Linear step size
saPrimeSimLINStepSpecLin	string	saTestbench	Number of Steps	PrimeSim LIN: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimLINStepSpecLog	string	saTestbench	Points per Decade	PrimeSim LIN: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimLINStop	string	saTestbench		PrimeSim LIN: Stopping point of sweep limits
saPrimeSimLINSub	string	saTestbench		PrimeSim LIN: Subcircuit with parameter being swept
saPrimeSimLINSweep	string	saTestbench	Logarithmic	PrimeSim LIN: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimLINSweepSpec	string	saTestbench	<file path>	PrimeSim LIN: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimLINSweepVar	string	saTestbench	Frequency (Hz)	PrimeSim LIN: Specifies what will be swept ("Frequency (Hz)" "Design Variable" "Temperature")
saPrimeSimLINValues	string	saTestbench		PrimeSim LIN: Individual values, also known as points of interest
saPrimeSimLSTBCenter	string	saTestbench		PrimeSim LSTB: Center point of sweep limits
saPrimeSimLSTBDec	string	saTestbench		PrimeSim LSTB: Number of logarithmic steps per decade
saPrimeSimLSTBDesignVar	string	saTestbench		PrimeSim LSTB: Design variable being swept
saPrimeSimLSTBDev	string	saTestbench		PrimeSim LSTB: Instance with parameter being swept
saPrimeSimLSTBFreq	string	saTestbench		PrimeSim LSTB: Single value to hold frequency while other aspect is being swept
saPrimeSimLSTBLin	string	saTestbench		PrimeSim LSTB: Number of linear steps
saPrimeSimLSTBLog	string	saTestbench		PrimeSim LSTB: Total number of logarithmic steps
saPrimeSimLSTBMod	string	saTestbench		PrimeSim LSTB: Model with parameter being swept

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimLSTBModeType	string	saTestbench	single	PrimeSim LSTB: Mode Type for diffstbprobe element
saPrimeSimLSTBOptionlocgnd	string	saTestbench		PrimeSim option locgnd: This is a parameter for stb analysis. It provides a local ground reference to probed vsource.
saPrimeSimLSTBOptionlocgndUnc heckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLSTBOptionmode	string	saTestbench	single	PrimeSim option mode: If the feedback loop has a differential amplifier, then there are two signal
saPrimeSimLSTBOptionmodeUnc heckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLSTBOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimLSTBOptionnameUnc heckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLSTBOptionotherOpti ons	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimLSTBOptionotherOptio nsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLSTBOptionreadic	string	saTestbench		PrimeSim option read_ic: read file for .ic
saPrimeSimLSTBOptionreadicUnc heckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLSTBOptionreadns	string	custom		PrimeSim option read_ns: File that contains an estimate of the DC solution (nodeset).
saPrimeSimLSTBOptionreadnsUn checkLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLSTBOptionvsource	string	saTestbench		PrimeSim option vsource: The 0V voltage source(s) indicating the insertion point of test circuit. Note that the direction of Vxxx is of significance in diff/comm mode analysis.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimLSTBOptionvsourcencheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLSTBOptionwrite	string	saTestbench		PrimeSim option write: write file at the first point
saPrimeSimLSTBOptionwritefinal	string	saTestbench		PrimeSim option write_final: write file at the last point
saPrimeSimLSTBOptionwritefinalU ncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLSTBOptionwriteUnch eckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimLSTBParam	string	saTestbench		PrimeSim LSTB: Parameter being swept
saPrimeSimLSTBSpan	string	saTestbench		PrimeSim LSTB: Span between sweep limits
saPrimeSimLSTBStart	string	saTestbench		PrimeSim LSTB: Starting point of sweep limits
saPrimeSimLSTBStep	string	saTestbench		PrimeSim LSTB: Linear step size
saPrimeSimLSTBStepSpecLin	string	saTestbench	Number of Steps	PrimeSim LSTB: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimLSTBStepSpecLog	string	saTestbench	Points per Decade	PrimeSim LSTB: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimLSTBStop	string	saTestbench		PrimeSim LSTB: Stopping point of sweep limits
saPrimeSimLSTBSub	string	saTestbench		PrimeSim LSTB: Subcircuit with parameter being swept
saPrimeSimLSTBSweep	string	saTestbench	Logarithmic	PrimeSim LSTB: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimLSTBSweepSpec	string	saTestbench	<file path>	PrimeSim LSTB: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimLSTBSweepVar	string	saTestbench	Frequency (Hz)	PrimeSim LSTB: Specifies what will be swept ("Frequency (Hz)" "Design Variable" "Temperature")

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimLSTBTextParam	string	saTestbench		PrimeSim LSTB: Parameter being swept
saPrimeSimLSTBValues	string	saTestbench		PrimeSim LSTB: Individual values, also known as points of interest
saPrimeSimLSTBVsource	string	saTestbench		PrimeSim LSTB: oprobe instance around which the loop gain is calculated
saPrimeSimLSTBVsource2	string	saTestbench		PrimeSim LSTB: oprobe instance 2 around which the loop gain is calculated
saPrimeSimModelGroups	string	saTestbench		Model groups for PrimeSim
saPrimeSimModelsFiles	string	saTestbench		Model files for PrimeSim
saPrimeSimModelsIncludePath	string	saTestbench		Search path for PrimeSim model files
saPrimeSimMonteCarloIterList	string	saTestbench		list of iterations
saPrimeSimMonteCarloLHSReplicates	string	saTestbench	1	Runs replicates of Latin Hypercube samples
saPrimeSimMonteCarloLHSSampleSize	string	saTestbench		LHS sampling method sample size
saPrimeSimMonteCarloNumIter	string	saTestbench	10	Number of iterations for montecarlo analysis
saPrimeSimMonteCarloOFATIntervals	string	saTestbench	1	Generate 2n+1 equally spaced samples for each OFAT variable
saPrimeSimMonteCarloOFATOneSided	bool	saTestbench	false	Enable/disable one-sided intervals
saPrimeSimMonteCarloOFATOneSidedValue	string	saTestbench	0.5	Generate 2n+1 equally spaced samples for each OFAT variable
saPrimeSimMonteCarloSamplingMethod	string	saTestbench	Sobol	Enables advanced sampling methods
saPrimeSimMonteCarloSeed	string	saTestbench	1	Starting seed for the random-number generator in montecarlo analysis
saPrimeSimMonteCarloSigmaScale	string	saTestbench	2.0	Sigma Amplification Factor for High Sigma Applications
saPrimeSimMonteCarloStartIter	string	saTestbench		Starting iteration number for montecarlo analysis

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimMonteCarloUserIterationList	string	saTestbench	0	Use iteration list
saPrimeSimMonteCarloUseRandomSeed	string	saTestbench	0	Use random seed for random-number generator in montecarlo analysis
saPrimeSimMonteCarloUseSigmaScaling	string	saTestbench	0	Uses Sigma Amplification for High Sigma Applications
saPrimeSimMonteCarloVariationIncludeOrExclude	string	saTestbench	Include	Whether statistical variation is to be applied or not applied to the specified instances/cells
saPrimeSimMonteCarloVariationInstanceOrCellList	string	saTestbench		List of instances or cells for which statistical variation is to be applied/not applied
saPrimeSimMonteCarloVariationObjectType	string	saTestbench	Instances	Object type (instances or cells) for which statistical variation is to be applied/not applied
saPrimeSimMonteCarloVariations	string	saTestbench	All	Statistical variation for montecarlo analysis
saPrimeSimNOISECenter	string	saTestbench		PrimeSim NOISE: Center point of sweep limits
saPrimeSimNOISEDec	string	saTestbench		PrimeSim NOISE: Number of logarithmic steps per decade
saPrimeSimNOISEDesignVar	string	saTestbench		PrimeSim NOISE: Design variable being swept
saPrimeSimNOISEDev	string	saTestbench		PrimeSim NOISE: Instance with parameter being swept
saPrimeSimNOISEFreq	string	saTestbench		PrimeSim NOISE: Single value to hold frequency while other aspect is being swept
saPrimeSimNoiseIprobe	string	saTestbench		PrimeSim Noise sweep: Input Probe: Refer the output noise to this component
saPrimeSimNOISELin	string	saTestbench		PrimeSim NOISE: Number of linear steps
saPrimeSimNOISELog	string	saTestbench		PrimeSim NOISE: Total number of logarithmic steps
saPrimeSimNOISEMod	string	saTestbench		PrimeSim NOISE: Model with parameter being swept
saPrimeSimNoiseNegNode	string	saTestbench		PrimeSim Noise sweep: Negative output node

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimNoiseNode	string	saTestbench		PrimeSim Noise sweep: Positive output node
saPrimeSimNoiseOprobe	string	saTestbench		PrimeSim Noise sweep: Compute total noise output at this component
saPrimeSimNOISEOptionlistcount	string	saTestbench	1	PrimeSim option listcount: For example, listcount=5 means that only the top 5 noise contributors are printed
saPrimeSimNOISEOptionlistcountUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimNOISEOptionlistfloor	string	saTestbench	1.0e-14	PrimeSim option listfloor: defines a minimum meaningful noise value (in V/Hz ^{1/2} units).
saPrimeSimNOISEOptionlistfloorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimNOISEOptionlistfreq	string	saTestbench		PrimeSim option listfreq: specify at which frequencies the element noise value is printed.
saPrimeSimNOISEOptionlistfreqUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimNOISEOptionlistsources	string	saTestbench	1	PrimeSim option listsources: specify if prints the contribution from each noise source
saPrimeSimNOISEOptionlistsourcesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimNOISEOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimNOISEOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimNOISEOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimNOISEOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimNOISEOptionreadic	string	saTestbench		PrimeSim option read_ic: read file for .ic
saPrimeSimNOISEOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimNOISEOptionreadns	string	custom		PrimeSim option read_ns: File that contains an estimate of the DC solution (nodeset).
saPrimeSimNOISEOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimNOISEOptionwrite	string	saTestbench		PrimeSim option write: write file at the first point
saPrimeSimNOISEOptionwritefinal	string	saTestbench		PrimeSim option write_final: write file at the last point
saPrimeSimNOISEOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimNOISEOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimNoiseOutputType	string	saTestbench	Voltage	PrimeSim Noise sweep: Output Type
saPrimeSimNOISEParam	string	saTestbench		PrimeSim NOISE: Parameter being swept
saPrimeSimNOISESpan	string	saTestbench		PrimeSim NOISE: Span between sweep limits
saPrimeSimNOISEStart	string	saTestbench		PrimeSim NOISE: Starting point of sweep limits
saPrimeSimNOISEStep	string	saTestbench		PrimeSim NOISE: Linear step size
saPrimeSimNOISEStepSpecLin	string	saTestbench	Number of Steps	PrimeSim NOISE: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimNOISEStepSpecLog	string	saTestbench	Points per Decade	PrimeSim NOISE: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimNOISEStop	string	saTestbench		PrimeSim NOISE: Stopping point of sweep limits

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimNOISESub	string	saTestbench		PrimeSim NOISE: Subcircuit with parameter being swept
saPrimeSimNOISETextParam		saTestbench		PrimeSim NOISE: Parameter being swept
saPrimeSimNoiseSummaryAbsoluteThreshold	string	user	0	Noise Summary Truncate Absolute Threshold
saPrimeSimNoiseSummaryIncludeBreakdown	string	user	0	Noise Summary Include Noise Breakdown
saPrimeSimNoiseSummaryNoiseCategory	string	user	Total	Noise Summary Results To Be Shown
saPrimeSimNoiseSummaryNoiseOption	saPrimeSimNoiseSummaryNoiseOptionEnum	user	Spot Noise	Noise Summary Option
saPrimeSimNoiseSummaryRelativeThreshold	string	user	0	Noise Summary Truncate Relative Threshold
saPrimeSimNoiseSummarySumIteratedInstances	string	user	true	Noise Summary Sum Iterated Instances
saPrimeSimNoiseSummaryTopContributors	string	user	100	Noise Summary Truncate Top Contributors
saPrimeSimNoiseSummaryTruncateType	string	user	By Contribution	Noise Summary Truncate Type
saPrimeSimNoiseSummaryUnit	string	user	<file path>	Noise Summary Unit
saPrimeSimNOISESweep	string	saTestbench	Logarithmic	PrimeSim NOISE: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimNOISESweepSpec	string	saTestbench	<file path>	PrimeSim NOISE: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimNOISESweepVar	string	saTestbench	Frequency (Hz)	PrimeSim NOISE: Specifies what will be swept ("Frequency (Hz)" "Design Variable" "Temperature")
saPrimeSimNOISEValues	string	saTestbench		PrimeSim NOISE: Individual values, also known as points of interest
saPrimeSimOPFormat	string	saTestbench	All	PrimeSim Operating point analysis format option

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOPFormat2	string	saTestbench	All	PrimeSim Operating point analysis format2 option
saPrimeSimOPInterpolation	string	saTestbench	false	PrimeSim Operating point interpolation
saPrimeSimOPNumFormats	string	saTestbench	1	PrimeSim Operating point numFormats
saPrimeSimOPOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimOPTime	string	saTestbench	0	PrimeSim Operating point save time
saPrimeSimOPTime2	string	saTestbench	0	PrimeSim Operating point save time2
saPrimeSimOptionabstol	string	custom		PrimeSim option abstol: Sets the absolute error tolerance for branch currents in DC and transient analysis.
saPrimeSimOptionagepwinteg	string	saTestbench	0	PrimeSim option age_pw_integ: Controls new mosra measure file format.
saPrimeSimOptionagepwintegUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionageskipfinalsim	string	saTestbench		PrimeSim option age_skip_final_sim:
saPrimeSimOptionageskipfinalsimUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionagevariationcorner	string	saTestbench		PrimeSim option age_variation_corner:
saPrimeSimOptionagevariationcornerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionahdldomainerror	string	custom	warning	PrimeSim option ahldldomainerror: AHDL domain error handling selector. If ahldldomainerror=error, incorrect AHDL domain input is treated as an error; If ahldldomainerror=warning, incorrect AHDL domain input is treated as warning; If ahldldomainerror=none, AHDL domain error is ignored. Possible values are error, warning, none, erroriter, and warniter.
saPrimeSimOptionalterselect	string	custom		PrimeSim option alter_select: Enables selection of one or more alters from a list of alters
saPrimeSimOptionalterselectUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionamsaddfilesinlib	string	saTestbench		PrimeSim option ams_add_files_in_lib:
saPrimeSimOptionamsaddfilesinlibUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionamsdefaultspicelib	string	saTestbench		PrimeSim option ams_default_spice_lib:
saPrimeSimOptionamsdefaultspicelibUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionamsinstlibbindfile	string	saTestbench		PrimeSim option ams_inst_lib_bind_file:
saPrimeSimOptionamsinstlibbindfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionamsiprobes	string	custom	no	PrimeSim option amsiprobes: Insert iprobes when computing MDL-related terminal currents. Possible values are no and yes.
saPrimeSimOptionamsmergesubforcm	string	saTestbench		PrimeSim option ams_merge_sub_for_cm:
saPrimeSimOptionamsmergesubforcmUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionamsspicechildchangelamap	string	saTestbench		PrimeSim option ams_spice_child_change_map:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionamsspicechildc hangemapUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionamsspiceparam eterpartitionfile	string	saTestbe nch		PrimeSim option ams_spice_parameter_partition_file:
saPrimeSimOptionamsspiceparam eterpartitionfileUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionannotateonalter	string	custom	yes	PrimeSim option annotateonalter: Annotate on all alter statements. Possible values are no and yes.
saPrimeSimOptionapprox	string	custom	no	PrimeSim option approx: Use approximate models. Difference between approximate and exact models is generally less public. Possible values are no and yes.
saPrimeSimOptionaspec	string	custom		PrimeSim option aspec: ASPEC-compatibility mode
saPrimeSimOptionaspecUncheckL ocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionassertssilentinit	string	custom	[...]	PrimeSim option asserts_silent_init: Array of asserts or assert groups which don't generate message during initializing.
saPrimeSimOptionatxlvl	string	saTestbe nch		PrimeSim option atxlvl:
saPrimeSimOptionatxlvl	string	custom	4	PrimeSim option atxlvl: Controls runtime speed and simulation accuracy.
saPrimeSimOptionatxlvlUncheckL ocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionaudit	string	custom	detailed	PrimeSim option audit: Print time required by various parts of the simulator. Possible values are no, brief, detailed, and full.
saPrimeSimOptionautominductor	string	custom	no	PrimeSim option auto_minductor: Automatic insertion of missing mutual inductor coupling. For more information, see detailed description below the parameter descriptions. Possible values are no and yes.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionautosavecurvolt	string	custom	no	PrimeSim option autosavecurvolt: Automatically save terminal currents and node voltage. Possible values are no and yes.
saPrimeSimOptionautostop	string	custom	no	PrimeSim option autostop: If yes, tran analysis is terminated when all event-type measurement expressions have been evaluated. Event-type expressions use thresholding, event, or delay type functions. If the value is spice, autostop is consistent with spice simulator. Possible values are no, yes, and spice.
saPrimeSimOptionautostopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionBHTNewEval	string	custom	1	PrimeSim option BHT_New_Eval: Option to choose which kind of evaluate function to use, 0 for old version with Vciei derivatives and 1 for new one without Vciei derivatives.
saPrimeSimOptionbiaschkenable	string	saTestbench	0	PrimeSim option biaschk_enable:
saPrimeSimOptionbiaschkenableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionbiasfile	string	saTestbench		PrimeSim option biasfile:
saPrimeSimOptionbiasfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionbiasfmt	string	saTestbench	0	PrimeSim option biasfmt:
saPrimeSimOptionbiasfmtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionbinrelref	string	custom	no	PrimeSim option bin_relref: When a global relref is used, signals share a common reference value for convergence checks. If there is a large voltage in the circuit this can artificially relax convergence checks for other signals. This option creates voltage bins so that large voltages do not impact nodes with small voltage swings. Possible values are no and yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionblockname	string	saTestbench		PrimeSim option block_name:
saPrimeSimOptionblocknameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptioncapicop	string	saTestbench		PrimeSim option cap_ic_op:
saPrimeSimOptioncapicopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptioncapicop is loaded.
saPrimeSimOptioncaptop	string	custom		PrimeSim option captop: Adds up all the capacitances attached to a node and prints a table of single-plate node capacitances
saPrimeSimOptioncaptopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptioncclamp	string	custom	0.0	PrimeSim option cclamp: All capacitors with C<=cclamp are clamped to 'cclamp'.
saPrimeSimOptionccut	string	custom	-infinity	PrimeSim option ccut: Capacitors with C<=ccut are replaced by open. ccut can additionally be applied to variable capacitors using the option 'short_cut_var_elem=yes'.
saPrimeSimOptioncfprobemosstate	string	saTestbench		PrimeSim option cf_probe_mos_state:
saPrimeSimOptioncfprobemosstateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptioncgnd	string	custom	-infinity	PrimeSim option cgnd: Coupling capacitors with C<=cgnd are split into 2 grounded capacitors with same C value.
saPrimeSimOptionchargeabstol	string	custom	1.0e-21	PrimeSim option chargeabstol: Charge absolute tolerance convergence criterion.
saPrimeSimOptioncheckformat	string	custom	xml	PrimeSim option check_format: Determine the format of the checker violation report. Possible values are xml, text, and sql.
saPrimeSimOptionchecklimitdest	string	custom	sqldb	PrimeSim option checklimitdest: Destination(s) where violations are written. Possible values are file, psf, sqldb, and both.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionchecklimitdetails	string	custom	no	PrimeSim option checklimitdetails: Print detailed information of expression. Possible values are no and yes.
saPrimeSimOptionchecklimitfile	string	custom		PrimeSim option checklimitfile: File to which assert violations are written public.
saPrimeSimOptionchecklimitfullduration	string	custom	no	PrimeSim option checklimit_full_duration: If set to yes, assert violation includes the duration for which the violation takes place, and uses interpolation when the value exceeds the max/min bound value. Possible values are no and yes.
saPrimeSimOptionchecklimitskipfile	string	custom		PrimeSim option checklimit_skip_file: File which contains the subcircuit masters or subcircuit master patterns to be skipped in device checking. Patterns can have any wildcard symbols.
saPrimeSimOptionchecklimitskipieconnectdevices	string	custom	no	PrimeSim option checklimit_skip_ie_connect_devices: If set to yes, all devices connected to AMS IE elements will be skipped in device checking. Possible values are no and yes.
saPrimeSimOptionchecklimitskipinsts	string	custom	[...]	PrimeSim option checklimit_skip_insts: Array of instances to be skipped in device checking. Instances can have any wildcard symbols.
saPrimeSimOptionchecklimitskipinstsfile	string	custom		PrimeSim option checklimit_skip_insts_file: File which contains the instances to be skipped in device checking. Instances can have any wildcard symbols.
saPrimeSimOptionchecklimitskipsubs	string	custom	[...]	PrimeSim option checklimit_skip_subs: Array of subcircuit masters or subcircuit master patterns to be skipped in device checking. Patterns can have any wildcard symbols.
saPrimeSimOptionckptclock	string	custom		PrimeSim option ckptclock: Clock time checkpoint period. Default is 1800s for Spectre.
saPrimeSimOptioncmax	string	custom	infinity	PrimeSim option cmax: All capacitors with C>=cmax are clamped to 'cmax'.
saPrimeSimOptioncmiflag	string	custom		PrimeSim option cmiflag: Loads and links the dynamically linked Common Model Interface (CMI) library

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptioncmiflagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptioncmiopts	string	custom	[...]	PrimeSim option cmi_opts: The option for customer cmi.
saPrimeSimOptioncmipath	string	custom		PrimeSim option cmipath: Specify the path to the Custom CMI .so library
saPrimeSimOptioncmipathUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptioncmiusrflag	string	custom		PrimeSim option cmiusrflag: Flag to control .OPTION SCALE parsing into the External Common Model Interface (CMI) invokes one additional CMI model function call when convergence criteria is met
saPrimeSimOptioncmiusrflagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptioncmivth	string	custom		PrimeSim option cmivth: For Custom CMI MOSFET model only
saPrimeSimOptioncmivthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptioncols	string	custom	80	PrimeSim option cols: Width of screen in characters.
saPrimeSimOptioncolslog	string	custom	80	PrimeSim option colslog: Width of log-file in characters.
saPrimeSimOptioncompatible	string	custom	spectre	PrimeSim option compatible: Encourage device equations to be compatible with a foreign simulator. This option does not affect input syntax. Possible values are spectre, spice2, spice3, cdsspice, hspice, spiceplus, and eldo.
saPrimeSimOptioncrdpar	string	saTestbench		PrimeSim option crdpar:
saPrimeSimOptioncrdparmod	string	saTestbench	0	PrimeSim option crdparmod:
saPrimeSimOptioncrdparmodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptioncrdparUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptioncscalefactor	string	custom	1e-3	PrimeSim option cscalefactor: Scaling factor for very large capacitor.
saPrimeSimOptioncshunt	string	custom	0	PrimeSim option cshunt: Minimum capacitance from each node to ground.
saPrimeSimOptioncshuntUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptioncthresh	string	custom	1e38	PrimeSim option cthresh: Large capacitors can cause transient convergence problems, especially as the time-step shrinks. This is similar to the issues that small resistors cause. There is an alternative exact representation of a capacitor, which does not suffer from this problem, but can introduce an equation to be solved. If a capacitance is greater than cthresh, then the alternative formulation is used. Accuracy is not impacted by the change. The 'cthresh' option has lower priority than 'cthresh' parameter on the capacitor instance definition.
saPrimeSimOptiondcap	string	custom		PrimeSim option dcap: Specifies equations used to calculate depletion capacitance for Level 1 and 3 diodes and BJTs
saPrimeSimOptiondcapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiondcdiagnoseelements	string	custom	10	PrimeSim option dc_diagnose_elements: Number of elements connected to non-converge nodes in printing diagnose information in DC simulation.
saPrimeSimOptiondcdiagnosetime	string	custom	1800	PrimeSim option dc_diagnose_time: Time interval for printing out diagnose information in DC simulation.
saPrimeSimOptiondcic	string	custom		PrimeSim option dcic: Specifies whether to use or ignore .IC commands in the netlist
saPrimeSimOptiondcicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptiondcmxiter	string	custom	5	PrimeSim option dcmxiter: Maximum number of Newton iterations in DC simulation.
saPrimeSimOptiondcmmod	string	custom	0	PrimeSim option dcmmod: DCMismatch analysis version selector. If set to 1 or 3, uses Bsim short-channel mismatch equation for BSIM3 and BSIM4 devices; if set to 2 or 3, provides compatibility with Monte Carlo analysis.
saPrimeSimOptiondcoptic	string	custom	aps1	PrimeSim option dcoptic: Initial condition for dcopt in DC simulation. Possible values are no, aps1, aps2, and xps.
saPrimeSimOptiondcoptictype	string	custom	nodeset	PrimeSim option dcoptictype: Initial condition type for dcopt in DC simulation. Possible values are nodeset and ic.
saPrimeSimOptiondcoptmaxsteps	string	custom	300	PrimeSim option dcoptmaxsteps: Maximum number of steps for dcopt in DC simulation.
saPrimeSimOptiondcopttol	string	custom	1e-8	PrimeSim option dcopttol: Tolerance used for dcopt DC analysis..
saPrimeSimOptiondcpivotcheck	string	custom	no	PrimeSim option dc_pivot_check: During DC analysis, the numeric pivoting is only performed when bad pivot is detected. Possible values are no and yes.
saPrimeSimOptiondcut	string	custom	[...]	PrimeSim option dcut: Replaces all diode instances using the specified model definitions with an open. dcut=all cuts all diode elements.
saPrimeSimOptiondebug	string	custom	no	PrimeSim option debug: Give debugging messages. Possible values are no and yes.
saPrimeSimOptiondebugstepdrop	string	custom	no	PrimeSim option debugstepdrop: Generates warnings on dramatic step size drop and notices when step size is recovered. Possible values are no and yes.
saPrimeSimOptiondefad	string	custom		PrimeSim option defad: Sets the default MOSFET drain diode area
saPrimeSimOptiondefadUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiondefas	string	custom		PrimeSim option defas: Sets the default MOSFET source diode area

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptiondefasUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiondefl	string	custom		PrimeSim option defl: Sets the default MOSFET channel length.
saPrimeSimOptiondeflUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiondefnrd	string	custom		PrimeSim option defnrd: Sets the default number of squares for the drain resistor on a MOSFET
saPrimeSimOptiondefnrdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiondefnrs	string	custom		PrimeSim option defnrs: Sets the default number of squares for the source resistor on a MOSFET
saPrimeSimOptiondefnrsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiondefpd	string	custom		PrimeSim option defpd: Sets the default MOSFET drain diode perimeter
saPrimeSimOptiondefpdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiondefps	string	custom		PrimeSim option defps: Sets the default MOSFET source diode perimeter
saPrimeSimOptiondefpsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiondefw	string	custom		PrimeSim option defw: Sets the default MOSFET channel width
saPrimeSimOptiondefwUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiondetailedcorrelationfile	string	saTestbench		PrimeSim option detailed_correlation_file:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptiondetailedcorrelationfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiondevcheckstat	string	custom	yes	PrimeSim option devcheck_stat: Enable or disable output device-checking statistics. Possible values are no and yes.
saPrimeSimOptiondevropt	string	custom	none	PrimeSim option devropt: If set to all, diode, or mosfet, connected resisotrs will be folded to related instances.. Possible values are none, all, diode, and mosfet.
saPrimeSimOptiondiagnose	string	custom	no	PrimeSim option diagnose: Print additional information that might help diagnose accuracy and convergence problems. Possible values are no, yes, and detailed.
saPrimeSimOptiondiagnosedumptopnum	string	custom	5	PrimeSim option diagnose_dump_topnum: Top number to dump single device netlist.
saPrimeSimOptiondiagnoseend	string	custom		PrimeSim option diagnose_end: End time to enable the detailed diagnosis mode. Default is transient stop time.
saPrimeSimOptiondiagnosestart	string	custom	0	PrimeSim option diagnose_start: Start time to enable the detailed diagnosis mode.
saPrimeSimOptiondigits	string	custom	5	PrimeSim option digits: Number of digits used when printing numbers.
saPrimeSimOptiondioallowscaling	string	custom	no	PrimeSim option dio_allow_scaling: Use this flag to enable SCALE parameter for diode mode. Possible values are no and yes.
saPrimeSimOptiondisablesavepreserve	string	custom	no	PrimeSim option disable_save_preserve: Disables preserve by save statements. If no, does not disable the save preserve. If yes, disables the save preserve. Possible values are no and yes.
saPrimeSimOptiondiskcheckautoresume	string	custom	no	PrimeSim option disk_check_autoresume: Automatically resume the simulation once the available disk space is larger than the specified threshold. Possible values are no and yes.
saPrimeSimOptiondiskcheckthresh	string	custom	1E8	PrimeSim option disk_check_thresh: The threshold of disk space check.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptiondochecklimit	string	custom	yes	PrimeSim option dochecklimit: Check asserts in the netlist. Possible values are no and yes.
saPrimeSimOptiondotprobefmt	string	custom	flat	PrimeSim option dotprobefmt: Print .probe signal with original name or hierarchical name. Possible values are flat and hier.
saPrimeSimOptiondpf	string	custom		PrimeSim option dpf: This option specifies DPF file to be stitched and its stitching scope. The syntax is dpf="scope filename". The scope can be a subcircuit or an instance. Use "spectre -h stitch" for more information.
saPrimeSimOptiondptranmethod	string	custom	node	PrimeSim option dptran_gmethod: Stamp gdev, gnode, or both in the dptran (homotopy) methods. Possible values are dev, node, and both.
saPrimeSimOptiondptranmaxsteps	string	custom	300	PrimeSim option dptranmaxsteps: Maximum number of steps for dptran in fast DC simulation.
saPrimeSimOptiondspfnodename	string	custom	original	PrimeSim option dspf_nodename: When original, The current behavior, .connect is created for nodes cut by DSPF translator. When net_only, it is the only net name in DSPF file that is used to match the wild card in .probe/.ic statements. The hierarchical structure of the net name is restored like pre-layout netlist. When all, the net name in DSPF file is stored as pre-layout node name, and the nodes in DSPF file are preserved like the current behavior. The wild card in .probe/.ic will match all the nodes and net names. Possible values are original, net_only, and all.
saPrimeSimOptiondumpglobaloptions	string	custom	0	PrimeSim option dump_global_options: Internal option for RelXpert to dump all the global options . By default it is closed.
saPrimeSimOptiondumpwildcardinfo	string	custom	no	PrimeSim option dump_wildcard_info: Dump wildcard matching details in save statement into a single file. Possible values are no and yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionduplicateinstance	string	custom	error	PrimeSim option duplicateinstance: Specify whether duplicate instance definitions are allowed. When set to warning or ignore, the simulator allows duplicate instance definitions. However, it honors only the last instance definition. Depending on the value that is set, the simulator displays warning messages for the duplicate instance definitions or does not display any message. When set to error, the simulator does not allow duplicate instance definitions and displays an error message. Possible values are error, ignore, and warning.
saPrimeSimOptionduplicatemodel	string	custom	error	PrimeSim option duplicatemodel: Specify whether duplicate model definitions are allowed. When set to warning or ignore, the simulator allows duplicate model definitions. However, it honors only the last model definition. Depending on the value that is set, the simulator displays warning messages for the duplicate model definitions or does not display any message. When set to error, the simulator does not allow duplicate model definitions and displays an error message. Possible values are error, ignore, and warning.
saPrimeSimOptionduplicatemodule	string	custom	error	PrimeSim option duplicate_module: Specifies whether the duplicate module definitions are allowed. When set to warning or ignore, the simulator allows duplicate module definitions. However, it honors only the last module definition. Depending on the value that is set, the simulator decides whether to display warning messages for the duplicate module definitions or not. When set to error, the simulator does not allow the duplicate module definitions and displays an error message. Possible values are error, ignore, and warning.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionduplicateports	string	custom	error	PrimeSim option duplicateports: Specify whether duplicate ports are allowed in the definition of the subcircuit. When set to warning or ignore, the duplicate ports are shorted. Depending on the value that is set, the simulator displays warning messages for the duplicate ports or does not display any message. When set to error, the simulator does not allow duplicate ports in the definition of the subcircuit and displays an error message. Possible values are error, ignore, and warning.
saPrimeSimOptionduplicatesubckt	string	custom	error	PrimeSim option duplicate_subckt: Specify whether duplicate subcircuit definitions are allowed. When set to warning or ignore, the simulator allows duplicate subcircuit definitions. However, it honors only the last subcircuit definition. Depending on the value that is set, the simulator displays warning messages for the duplicate subcircuit definitions or does not display any message. When set to error, the simulator does not allow duplicate subcircuit definitions and displays an error message. Possible values are error, ignore, and warning.
saPrimeSimOptionengine	string	custom	PrimeSim SPICE	PrimeSim option engine: Simulation Engine
saPrimeSimOptionengineUncheck Localized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionerror	string	custom	yes	PrimeSim option error: Generate error messages. Possible values are no and yes.
saPrimeSimOptionetmiagechk	string	saTestbe nch	0	PrimeSim option etmiagechk:
saPrimeSimOptionetmiagechkUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionetmiallinst	string	saTestbe nch	0	PrimeSim option etmiallinst:
saPrimeSimOptionetmiallinstUnch eckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionetmicoredata	string	saTestbench	0	PrimeSim option etmicoredata:
saPrimeSimOptionetmicoredataUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionetmifnosharesubckt	string	saTestbench		PrimeSim option etmif_noshare_subckt:
saPrimeSimOptionetmifnosharesubcktUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionetmifsharemod	string	saTestbench	0	PrimeSim option etmif_sharemod:
saPrimeSimOptionetmifsharemodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionetmiidsmod	string	saTestbench	0	PrimeSim option etmiidsmod:
saPrimeSimOptionetmildsMod	string	custom	0	PrimeSim option etmildsMod: Switch to select ids or total DC drain current for TMI core data ids.
saPrimeSimOptionetmiidsmodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionetmimasterprocessend	string	saTestbench	0	PrimeSim option etmimasterprocessend:
saPrimeSimOptionetmimasterprocessendUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionetmiprint	string	saTestbench	0	PrimeSim option etmiprint:
saPrimeSimOptionetmiprintUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionetmiprintfd	string	custom	0	PrimeSim option etmiprintfd: Output the TMI result file. By default it is closed.
saPrimeSimOptionetmisoa	string	saTestbench	0	PrimeSim option etmi_soa:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionetmisoaUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionetmiusrinput	string	custom		PrimeSim option etmiusrinput: This option can be set in model files or netlists.
saPrimeSimOptionetmiusrinputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionetmiusrstring	string	saTestbench		PrimeSim option etmiusrstring:
saPrimeSimOptionetmiusrstringUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionexportfile	string	custom		PrimeSim option exportfile: oceanEval output file name.
saPrimeSimOptionextdatapath	string	saTestbench		PrimeSim option extdatapath:
saPrimeSimOptionextdatapathUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionexternalfile	string	saTestbench		PrimeSim option external_file:
saPrimeSimOptionexternalfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionfastsensmethod	string	saTestbench		PrimeSim option fast_sens_method:
saPrimeSimOptionfastsensmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionfixsingularmatrix	string	custom	no	PrimeSim option fix_singular_matrix: Fix matrix singular issue by inserting gmin. Possible values are no, yes, print, and both.
saPrimeSimOptionflow	string	custom	1	PrimeSim option flow: Default flow quantity.
saPrimeSimOptiongdcpath	string	custom		PrimeSim option gdcpath: Adds conductance to nodes having no DC path to ground

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptiongdcpathUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiongencurpol	string	custom		PrimeSim option gen_cur_pol: Specifies whether the generic current polarity maintains backward compatibility with PrimeSim simulation files.
saPrimeSimOptiongencurpolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiongennetlistdir	string	custom	no	PrimeSim option gennetlistdir: Output netlist directory in logfile. Possible values are no and yes.
saPrimeSimOptiongeoshrink	string	custom		PrimeSim option geoshrink: Some of the latest process models have a new scale factor called geoshrink to shrink device geometry.
saPrimeSimOptiongeoshrinkUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiongerationalfunc	string	custom		PrimeSim option ge_rational_func: Specifies the method used for Laplace transform source convolution
saPrimeSimOptiongerationalfuncUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiongformvcr	string	custom		PrimeSim option gform_vcr: Use Gform for VCR device. Specify 1 for yes and 0 for no. Default is no.
saPrimeSimOptiongmethod	string	custom	dev	PrimeSim option gmethod: Stamp gdev, gnode, or both in the homotopy methods (other than dptran). See the detailed description below the parameter descriptions for more information. Possible values are dev, node, and both.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptiongmin	string	custom	1e-12	PrimeSim option gmin: gmin (conductance) is added to each nonlinear branch of the device to prevent simulation non-convergence. Large gmin impacts accuracy of current probe, small gmin may cause circuit convergence issue. For circuit that is sensitive to leakage current, it is recommended to set gmin to a small value or zero.
saPrimeSimOptiongmincheck	string	custom	max_v_only	PrimeSim option gmin_check: Specifies that effect of 'gmin' should be reported if significant. Possible values are no, max_v_only, max_only, and all.
saPrimeSimOptiongmindc	string	custom	1e-12	PrimeSim option gmindc: Minimum conductance across each non-linear device in DC analysis. Default value is 1.0e-12.
saPrimeSimOptiongmindcmax	string	custom		PrimeSim option gmindcmax: The maximum value that gmindc can be increased to during the automatically increasing gmindc method for convergence. The default value is gmindc.
saPrimeSimOptiongmindcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiongminstart	string	custom	1.0	PrimeSim option gmin_start: Initial gmin in gmin-stepping (homotopy) methods.
saPrimeSimOptiongminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiongramp	string	custom		PrimeSim option gramp: Sets the conductance range over which gmindc is to be swept during the gmin ramping mechanism of the DC convergence assist algorithm
saPrimeSimOptiongrampUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiongshdc	string	saTestbench		PrimeSim option gshdc:
saPrimeSimOptiongshdc	string	custom	0.0	PrimeSim option gshdc: Minimum conductance added for all nodes in dc analysis.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptiongshdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiongshunt	string	custom	0.0	PrimeSim option gshunt: Minimum conductance added for all nodes in tran analysis.
saPrimeSimOptiongshuntUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionhierambiguity	string	custom	strict	PrimeSim option hier_ambiguity: The default value is strict. When set to lower, the simulator will partially flatten the hier name from the back to check if an object can be found. Lower is not recommended. Possible values are strict and lower.
saPrimeSimOptionhierdelimiter	string	custom	.	PrimeSim option hier_delimiter: Used to set hierarchical delimiter. Length of hier_delimiter should not be longer than 1, except the leader escape character.
saPrimeSimOptionhierprobe	string	custom	hier	PrimeSim option hierprobe: Print .probe signal hierarchically or flatten. Possible values are flat and hier.
saPrimeSimOptionhighvoltage	string	custom	no	PrimeSim option highvoltage: Enable optimized Spectre settings for high voltage designs including voltage, and current binning, excluding VerilogA and dangling nodes from convergence checks, and optimized large capacitance handling. Possible values are no and yes.
saPrimeSimOptionhomotopy	string	custom	all	PrimeSim option homotopy: Method used when there is no convergence on initial attempt of DC analysis. You can specify methods and their orders by defining vector setting such as homotopy=[source ptran gmin]. Possible values are none, gmin, source, dptran, ptran, arclength, tranrampup, and all.
saPrimeSimOptionhsmhvext	string	saTestbench	0	PrimeSim option hsmhvext:
saPrimeSimOptionhsmhvextUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptioniabstol	string	custom	1.0e-12	PrimeSim option iabstol: Convergence criterion for absolute current tolerance.
saPrimeSimOptioniccapcheck	string	custom	yes	PrimeSim option iccapcheck: Check if nodes with initial conditions have capacitive path to ground. IC for the node without capacitance is treated as nodeset. Possible values are no and yes.
saPrimeSimOptionicpriority	string	custom	netlist	PrimeSim option icpriority: Set the ic priority order. If set to netlist, the order from lowest to highest is readNS, netlist NS, readIC, netlist IC. If set to file, the order from lowest to highest is netlist NS, readNS, netlist IC readIC. Possible values are file and netlist.
saPrimeSimOptionicsweep	string	custom		PrimeSim option icsweep: Saves the current analysis result of a parameter or temperature sweep as the starting point in the next analysis.
saPrimeSimOptionicsweepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionicversion	string	custom	1	PrimeSim option icversion: Convert initial condition to initial guess, when .ic statements exist in the netlist and there are no other options to set IC or nodeset.
saPrimeSimOptionignoreagingvariation	string	saTestbench		PrimeSim option ignore_aging_variation:
saPrimeSimOptionignoreagingvariationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionignoreglobalvariation	string	saTestbench		PrimeSim option ignore_global_variation:
saPrimeSimOptionignoreglobalvariationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionignoreinterconnectvariation	string	saTestbench		PrimeSim option ignore_interconnect_variation:
saPrimeSimOptionignoreinterconnectvariationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionignorelocalvariation	string	saTestbench		PrimeSim option ignore_local_variation:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionignorelocalvariationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionignorevariation	string	saTestbench		PrimeSim option ignore_variation:
saPrimeSimOptionignorevariationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionignshorts	string	custom	no	PrimeSim option ignshorts: Silently ignore shorted components. Possible values are no and yes.
saPrimeSimOptionimax	string	custom		PrimeSim option imax: Sets the upper limit of iterations at a time point in transient analysis. (or itl4)
saPrimeSimOptionimaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionimin	string	custom		PrimeSim option imin: Sets the lower limit of iterations at a time point in transient analysis. (or itl3)
saPrimeSimOptioniminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionimplicitsubcktparam	string	custom	no	PrimeSim option implicit_subckt_param: Allows the implicit parameter to be declared for the spectre format. Possible values are no and yes.
saPrimeSimOptioninfo	string	custom	yes	PrimeSim option info: Give informational messages. Possible values are no and yes.
saPrimeSimOptioningold	string	custom		PrimeSim option ingold: Controls whether to prints *.lis file output in exponential form or engineering notation in HSPICE
saPrimeSimOptioningoldUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptioninlinesubcktcurrent	string	custom	subckt	PrimeSim option inlinesubcktcurrent: Save inline subcircuit terminal current as inline device current or subcircuit current. By default, inline subckt current is saved. Possible values are device and subckt.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptioninterp	string	custom		PrimeSim option interp: Sets the output to be updated on the time interval defined by .tran's timestep
saPrimeSimOptioninterpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptioninventory	string	custom	detailed	PrimeSim option inventory: Print summary of components used. Possible values are no, brief, detailed, and full.
saPrimeSimOptionirefbins	string	custom	[...]	PrimeSim option irefbins: Specifies the current bins when bin_irelref=yes is used. Default setting is irefbins=[1e-6 1e-5 1e-4 1e-3 1e-2 1e-1].
saPrimeSimOptionishrink	string	custom	1.0	PrimeSim option ishrink: Lshrink factor.
saPrimeSimOptionitl1	string	custom	200	PrimeSim option itl1: Maximum DC iteration limit.
saPrimeSimOptionitl1UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionitl3	string	custom	3	PrimeSim option itl3: Minimum timestep in timestep algorithms.
saPrimeSimOptionitl4	string	custom	8	PrimeSim option itl4: Maximum timestep in timestep algorithms.
saPrimeSimOptionivthl	string	custom	0.0	PrimeSim option ivthl: Length offset for constant current Vth.
saPrimeSimOptionivthlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionivthn	string	custom	0.0	PrimeSim option ivthn: NMOS Vth current parameter.
saPrimeSimOptionivthnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionivthp	string	custom	0.0	PrimeSim option ivthp: PMOS Vth current parameter.
saPrimeSimOptionivthpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionivthvdsmin	string	custom	0.05	PrimeSim option ivth_vdsmin: Minimum Vds in constant current Vth calculation public.
saPrimeSimOptionivthvdsminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionivthw	string	custom	0.0	PrimeSim option ivthw: Width offset for constant current Vth.
saPrimeSimOptionivthwUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionkcut	string	custom	0.0	PrimeSim option kcut: Fixed value mutual inductors with absolute value of $K \leq kcut$ are replaced by an open. kcut can additionally be applied to variable value mutual inductors using the option 'short_cut_var_elem=yes'. Default value is 0 in Spectre, and 1m in APS.
saPrimeSimOptionkmax	string	custom	no	PrimeSim option kmax: Sets 1.0 as the maximum absolute value for coupling co-efficient of mutual inductors. Possible values are no and yes.
saPrimeSimOptionleakitimes	string	custom	[...]	PrimeSim option leaki_times: Specifies input-steady state time points.
saPrimeSimOptionlimit	string	custom	dev	PrimeSim option limit: Limiting algorithms to aid DC convergence. Possible values are delta, log, dev, l2, and newton.
saPrimeSimOptionlimitdiagpivot	string	custom	yes	PrimeSim option limit_diag_pivot: If set to yes, there is a limit on the number of matrix fill-ins when selecting a pivot from a diagonal. For backward compatibility, set this option to no. Possible values are no and yes.
saPrimeSimOptionlocalmeas	string	custom	no	PrimeSim option local_meas: Specify whether local measurements definitions are allowed. When set to ignore, the simulator allows local measurements definitions. Depending on the value that is set, the simulator displays warning messages for the local measurements definitions or does not display any message. When set to warning, the simulator does not allow and ignores the local measurement definitions with a warning message. Possible values are no and yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionlshort	string	custom	0	PrimeSim option lshort: Fixed value inductors with L<=lshort are shorted. lshort can additionally be applied to variable value inductors using the option 'short_cut_var_elem=yes'.
saPrimeSimOptionmacmod	string	custom		PrimeSim option macmod: subcircuit definition
saPrimeSimOptionmacmodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionmacromos	string	custom	[...]	PrimeSim option macro_mos: The list of subcircuit names, which is a macro model.
saPrimeSimOptionmaxapproachminstep	string	custom	300	PrimeSim option max_approach_minstep: The maximum number of times allowed to approach minstep within 5% of stop time.
saPrimeSimOptionmaxconsecutiveminstep	string	custom	1000	PrimeSim option max_consecutive_minstep: The maximum number of consecutive steps allowed to be less than 10*minstep.
saPrimeSimOptionmaxdeltav	string	custom	0.3	PrimeSim option maxdeltav: Maximum change in voltage allowed per Newton iteration when limit=delta (default 0.3 V) or limit=I2 (default 10 V).
saPrimeSimOptionmaxminstepnonconv	string	custom	200	PrimeSim option max_minstep_nonconv: The maximum number of convergence failures allowed below minstep within 5% of stop time.
saPrimeSimOptionmaxnotes	string	custom	5	PrimeSim option maxnotes: Maximum number of times a notice is issued per analysis. Note that this option has no effect on notices issued as part of parsing the netlist. Use the -maxnotes command-line option to control the number of all notices issued.
saPrimeSimOptionmaxnotestologfile	string	custom	5	PrimeSim option maxnotestologfile: Maximum number of times a notice message is printed to the log file per analysis. Note that this option has no effect on notices printed as part of parsing the netlist. Use the -maxnotestolog command-line option to control the number of all notices printed to the log file.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionmaxphysicalflux	string	custom	infinity	PrimeSim option maxphysicalflux: Maximum physical flux allowed in solution.
saPrimeSimOptionmaxphysicali	string	custom	infinity	PrimeSim option maxphysicali: Maximum physical current allowed in solution.
saPrimeSimOptionmaxphysicalmmf	string	custom	infinity	PrimeSim option maxphysicalmmf: Maximum physical magnetomotive force allowed in solution.
saPrimeSimOptionmaxphysicalunitless	string	custom	infinity	PrimeSim option maxphysicalunitless: Maximum physical unitless signals allowed in solution.
saPrimeSimOptionmaxphysicalv	string	custom	infinity	PrimeSim option maxphysicalv: Maximum physical voltage allowed in solution.
saPrimeSimOptionmaxwarns	string	custom	5	PrimeSim option maxwarns: Maximum number of times a warning message is issued per analysis. Note that this option has no effect on warnings issued as part of parsing the netlist. Use the -maxwarns command-line option to control the number of all warnings issued.
saPrimeSimOptionMAXWARNS	string	custom	5	PrimeSim option MAXWARNS: Specifies maximum number of SOA warning messages (equivalent to primesim_soa_maxwarns).
saPrimeSimOptionmaxwarnstologfile	string	custom	5	PrimeSim option maxwarnstologfile: Maximum number of times a warning message is printed to the log file per analysis. Note that this option has no effect on warnings printed as part of parsing the netlist. Use the -maxwarnstolog command-line option to control the number of all warnings printed to the log file.
saPrimeSimOptionmaxwarnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionmcfileonly	string	saTestbench		PrimeSim option mc_file_only:
saPrimeSimOptionmcfileonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionmdlanalysisnames	string	custom	rename	PrimeSim option mdlanalysisnames: Flag to indicate whether or not to keep spectre analysis name in MDL flow. Possible values are rename and original.
saPrimeSimOptionmdlthresholds	string	custom	exact	PrimeSim option mdlthresholds: When set to exact, certain functions in MDL, for example, cross(), control the transient time-step to place a time-point at a threshold crossing. This can improve accuracy. However for applications such as cell characterization an interpolated value can give the required accuracy with better performance. Valid values: exact, interpolated.
saPrimeSimOptionmdltrigtargmode	string	custom	cross	PrimeSim option mdltrigtargmode: This option specifies how to evaluate the trig and targ of the hspice and the output format. If mdltrigtargmode = deltax, we will use the deltax function to evaluate the trig and targ function. If mdltrigtargmode = cross, we will use the cross function to evaluate the trig and targ function. If mdltrigtargmode = details, we will output the trig and targ middle results. Valid values: deltax, cross, details.
saPrimeSimOptionmeasdgt	string	custom	0	PrimeSim option measdgt: Number of decimal digits (in floating point numbers) in measurement output in mt0 format.
saPrimeSimOptionmeasdgtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionmeaslabel	string	custom		PrimeSim option measlabel: Specifies a label that appears in the header of the .mt0 file
saPrimeSimOptionmeaslabelonly	string	saTestbench		PrimeSim option meas_label_only:
saPrimeSimOptionmeaslabelonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionmeaslabelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionmextramcmiva	string	saTestbench		PrimeSim option mextram_cmi_va:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionmextramcmivaUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionminexp	string	custom		PrimeSim option m_in_exp: Allows the M-factor of X-elements to appear on the right side of expressions for backward compatibility. (or xmult_in_exp)
saPrimeSimOptionminexpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionminr	string	custom	0.0	PrimeSim option minr: All parasitic resistors inside devices less than global minr will be removed. The order of checking devices is the follows: 1. Check if resistors are smaller than local minr. If yes, check if it is a MOSFET or BJT. If it is a MOSFET, drop the resistor, if it is BJT, clamp to the minr value, and give a warning message for both cases. 2. Check global minr, All Parasitic resistors less than global minr are removed and a warning message is issued. 3. If the resistor is not removed and is smaller than 0.001, issue a warning.
saPrimeSimOptionminrmfactor	string	custom	scaled	PrimeSim option minr_mfactor: whether minr will be scaled. Possible values are scaled and ignore.
saPrimeSimOptionminstepversion	string	custom	1	PrimeSim option minstepversion: Minstep algorithm flow control. If minstepversion=0, desperate big jump is taken when minstep is reached. If minstepversion=1, a forward/backward search algorithm is taken to find a converged solution at small step size. By default, minstepversion=1.
saPrimeSimOptionmismatchlevel	string	custom	0	PrimeSim option mismatchlevel: With default, mismatch parameter is defined based on parameter scope concept: mismatch parameter can only have one value in one scope. For example, if a mismatch parameter appears multiple times in a subckt of the netlist, that mismatch parameter has a unique value in that subckt for each Monte Carlo run. With mismatchlevel=1, the mismatch parameter is allowed to have a different value for each appearance in the same scope. Possible values are 0 and 1.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionmontecon	string	custom		PrimeSim option montecon: Specifies whether to retrieve the next random value and continue a Monte Carlo analysis
saPrimeSimOptionmonteconUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionmspartreport	string	custom	0	PrimeSim option ms_part_report: Depth of the ms partition report, default is 0, disabled..
saPrimeSimOptionmsvgnd	string	custom		PrimeSim option ms_vgnd: The virtual ground node names, globally.
saPrimeSimOptionmsvgndv	string	custom	0	PrimeSim option ms_vgndv: The voltage value for the virtual power network grounds in scope.
saPrimeSimOptionmsvpn	string	custom		PrimeSim option ms_vpn: The virtual power node names, globally.
saPrimeSimOptionmsvpnistart	string	custom	0.0	PrimeSim option ms_vpni_start: MS mode start time to have accurate currents. enable vpn current feedback after this time..
saPrimeSimOptionmsvpnistop	string	custom	0.0	PrimeSim option ms_vpni_stop: MS mode stop time to have accurate currents. disable vpn current feedback after this time..
saPrimeSimOptionmsvpnv	string	custom	0	PrimeSim option ms_vpnv: The voltage value for the virtual power network sources in scope.
saPrimeSimOptionmtlinecachedir	string	custom		PrimeSim option mtlinecachedir: The directory in which the mtline RLGC data file will be written. If an absolute path is not given, the file will be written to /home/<username>/.cadence/mmsim/.
saPrimeSimOptionmtlineemsolver	string	custom	cpl	PrimeSim option mtlineemsolver: EM 2D solver for transmission line. Possible values are lmg and cpl.
saPrimeSimOptionmtlinereuse	string	custom	yes	PrimeSim option mtlinereuse: This parameter defines whether to reuse RLGC data for all mtline instances. If no, this feature is disabled. Possible values are no and yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionmultithread	string	custom	off	PrimeSim option multithread: Enable or disable multithreading capability. When multithreading is enabled but the number of threads (nThreads) is not specified, Spectre will automatically detect the number of processors and select the proper number of threads to use. (See important note about using multithreading in the detailed description below the parameter descriptions). Possible values are off and on.
saPrimeSimOptionmultmosdiffdata	string	saTestbench	0	PrimeSim option multmosdiffdata:
saPrimeSimOptionmultmosdiffdataUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionnarrate	string	custom	yes	PrimeSim option narrate: Narrate the simulation. Possible values are no, yes, and compact.
saPrimeSimOptionnewsoa	string	custom	0	PrimeSim option new_soa: Print result of SOA checks to separate file (.tsoa) (new_soa=1 is equivalent to primesim_soa_warn_to_file=1 and primesim_soa_warn_format=4).
saPrimeSimOptionNEWSOA	string	custom	0	PrimeSim option NEW_SOA: Print result of SOA checks to separate file (.tsoa) (NEW_SOA=1 is equivalent to primesim_soa_warn_to_file=1 and primesim_soa_warn_format=4).
saPrimeSimOptionnewsoaUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionnewton	string	custom	normal	PrimeSim option newton: Method used on DC analysis. You can specify methods newton=[none normal], and the default value is normal.. Possible values are none and normal.
saPrimeSimOptionnoiseoffinst	string	custom	[...]	PrimeSim option noiseoff_inst: The list of instances not to be considered as noisy throughout noise analyses, which include noise, sp noise, pnoise and tran noise.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionnoiseofftype	string	custom	all	PrimeSim option noiseoff_type: The noiseoff_type defines the noise sources which are disabled by the noiseon/off_inst option. The default value is all. Possible values are thermal, flicker, shot, ign, and all.
saPrimeSimOptionnoiseoninst	string	custom	[...]	PrimeSim option noiseon_inst: The list of instances to be considered as noisy throughout noise analysis, which include, noise, sp noise, pnoise and tran noise.
saPrimeSimOptionnoiseontype	string	custom	all	PrimeSim option noiseon_type: The noiseon_type defines the noise sources which are enabled by the noiseon/off_inst option. The default value is all. Possible values are thermal, flicker, shot, ign, and all.
saPrimeSimOptionnonconvtopnum	string	custom	10	PrimeSim option nonconv_topnum: Top number of non-convergence nodes to be printed public.
saPrimeSimOptionnotation	string	custom	eng	PrimeSim option notation: The notation to be used to display real numbers to the screen. Possible values are eng, sci, and float.
saPrimeSimOptionnote	string	custom	yes	PrimeSim option note: Give notice messages. Possible values are no and yes.
saPrimeSimOptionnportbbsfittedfiledir	string	custom		PrimeSim option nportbbsfittedfiledir: The directory to which the BBSpice fitted S-Parameter file will be put. If it is not specified, the file will be in directory named as 'BBSpiceOutput'. If a relative path is specified, the path is relative to the current working directory.
saPrimeSimOptionnportcompress	string	custom	yes	PrimeSim option nportcompress: Nport compression improves the efficiency of S-parameter simulation of large nport files when a certain percentage of the ports is unused, i.e., open or short circuited. Nport compression does not impact simulation accuracy. This option turns off compression if set to no and attempts to force compression if set to yes. If left unspecified, compression is on if $N \geq 10$ and the ratio of used ports is less than or equal to 0.8. Possible values are no, yes and unspecified.. Possible values are no and yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionnportcompressfi ledir	string	custom		PrimeSim option nportcompressfiledir: The directory where the compressed nport S-parameter file is written to. If unspecified, it is stored in outdir.
saPrimeSimOptionnportdefaultpas sivity	string	custom	disable	PrimeSim option nport_default_passivity: Check and enforce passivity of S-parameter for all nport instances. Default is `disable`, which means this global option has no effect. If set to a value other than `disable`, all nport elements in the netlist without a value for `passivity` explicitly set, will have their `passivity` argument set to the same value as specified in this global option. If an nport instance already has the `passivity` option specified, the instance option will take priority if both are present. Possible values are no, check, enforce, fit_weak_enforce, fit_enforce, and disable.
saPrimeSimOptionnportirfiledir	string	custom		PrimeSim option nportirfiledir: The directory to which the nport impulse response file will be written. If it is not specified, the file will be written to /home/<username>/cadence/mmsim/. If a relative path is specified, the path is relative to the current working directory.
saPrimeSimOptionnportirreuse	string	custom	yes	PrimeSim option nportirreuse: Reuse impulse responses data for all nport instances. If no, disable this feature. Possible values are no and yes.
saPrimeSimOptionnportunusedpor tgmin	string	custom	0.0	PrimeSim option nportunusedportgmin: Default is 0, which leaves the port open-circuited. A small value loads open-circuited ports with a finite but large resistance. This introduces a small error in the response, but it induces losses which help obtain a passive response.
saPrimeSimOptionnportunusedpor tmin	string	custom	0.0	PrimeSim option nportunusedportmin: Default is 0, which leaves the port short-circuited. A small value will insert a small resistance in place of short circuited ports. This introduces a small error in the response, but it induces losses which help obtain a passive response.
saPrimeSimOptionnthreads	string	custom		PrimeSim option nthreads: Specifies the number of threads for multithreading.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionnumdgt	string	custom	4	PrimeSim option numdgt: Controls the listing printout accuracy.
saPrimeSimOptionnumdgtUncheck Localized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionomiage	string	saTestbe nch	0	PrimeSim option omiage:
saPrimeSimOptionomiagemode	string	saTestbe nch	0	PrimeSim option omiagemode:
saPrimeSimOptionomiagemodeUn checkLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionomiageUncheck Localized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionomiflag	string	saTestbe nch		PrimeSim option omiflag:
saPrimeSimOptionomiflagUncheck Localized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionomiinput	string	saTestbe nch		PrimeSim option omiinput:
saPrimeSimOptionomiinputUnchec kLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionomipath	string	saTestbe nch		PrimeSim option omipath:
saPrimeSimOptionomipathUnchec kLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionomisave	string	saTestbe nch	0	PrimeSim option omisave:
saPrimeSimOptionomisaveUnchec kLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionomisort	string	saTestbe nch		PrimeSim option omisort:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionomisortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionopptcheck	string	custom	yes	PrimeSim option opptcheck: Check operating point parameters against soft limits. Possible values are no and yes.
saPrimeSimOptionopticaloutput	string	saTestbench		PrimeSim option optical_output:
saPrimeSimOptionopticaloutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionopticaloutput is loaded.
saPrimeSimOptionopticalport	string	saTestbench	0	PrimeSim option optical_port:
saPrimeSimOptionopticalportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionoptimizebsimcmg	string	custom	no	PrimeSim option optimize_bsimg: Enable the optimization in bsimg evaluation. Possible values are no and yes.
saPrimeSimOptionoptimizebsource	string	custom	no	PrimeSim option optimize_bsource: Enable the optimization in bsource evaluation. Possible values are no and yes.
saPrimeSimOptionoptimizediode	string	custom	no	PrimeSim option optimize_diode: Enable the optimization in diode evaluation. Possible values are no and yes.
saPrimeSimOptionoscoutputport	string	custom		PrimeSim option osc_output_port: Output raw data file name.
saPrimeSimOptionoserandommod	string	custom	0	PrimeSim option ose_random_mod: Use OSE Random Method. Possible values are 0 and 1.
saPrimeSimOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)]
saPrimeSimOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionoutputcompactmapping	string	custom	0	PrimeSim option output_compact_mapping: Internal option for RelXpert to output compact mapping file. By default it is closed.
saPrimeSimOptionoutputsigmavalue	string	saTestbench		PrimeSim option output_sigma_value:
saPrimeSimOptionoutputsigmavalueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionparamrangefile	string	custom		PrimeSim option paramrangefile: Parameter range file.
saPrimeSimOptionparamtopchange	string	custom	yes	PrimeSim option param_topchange: If set to yes, Spectre will support parametric topology change caused by device internal node changes when the device, model, or netlist parameter value is altered.. Possible values are no and yes.
saPrimeSimOptionparasitics	string	custom		PrimeSim option parasitics: Set parasitics for RC reduction. When used as the scoped option, specify the "+mts" command line option. The option has higher priority than the value from the command line option, "+parasitics". When used as a global option, the value from the command line, "+parasitics", has a higher priority.
saPrimeSimOptionparhier	string	custom		PrimeSim option parhier: Sets the parameter passing rules to control the evaluation order of subcircuit parameters
saPrimeSimOptionparhierUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionpassfailreverselogic	string	custom	no	PrimeSim option passfail_reverse_logic: Pass fail bisection treats NaN as PASS, while not NaN value as FAIL. Possible values are no and yes.
saPrimeSimOptionpivabs	string	custom	0	PrimeSim option pivabs: Absolute pivot threshold.
saPrimeSimOptionpivotdc	string	custom	no	PrimeSim option pivotdc: Use numeric pivoting on every iteration of DC analysis. Possible values are no and yes.
saPrimeSimOptionpivrel	string	custom	0.001	PrimeSim option pivrel: Relative pivot threshold.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionportelementvoltage matchload	string	saTestbench	1	PrimeSim option port_element_voltage_matchload:
saPrimeSimOptionportelementvoltage matchloadUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionportelementvoltage matchload is loaded.
saPrimeSimOptionportmismatchse verity	string	custom	error	PrimeSim option portmismatch_severity: If set ignore/warn/error out when ports number mismatch for subckt.. Possible values are error, ignore, and warning.
saPrimeSimOptionpost	string	custom		PrimeSim option post: This option saves results in fsdb binary format
saPrimeSimOptionpostUncheckLo calized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionpostversion	string	custom		PrimeSim option post_version: Specifies the version of the output format during the generation of a .tr0 output file
saPrimeSimOptionpostversionUnc heckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprecision	string	custom	%g	PrimeSim option precision: Format specification of double for psfascii. Example: "%15.12g" outputs 12 decimal digits in mantissa. The default value "%g" prints 6 decimal digits.
saPrimeSimOptionpreorder	string	custom	partial	PrimeSim option preorder: Try this option when simulation runs out of memory or if the simulation is unreasonably slow for the size of your design. It controls the amount of matrix pre-ordering that is done and may lead to much fewer matrix fill-ins in some cases. Known cases include designs with very large number of small resistors and large number of behavioral instances containing voltage based equations. Possible values are partial, full, and limited.
saPrimeSimOptionpreserveassert	string	custom	lazy	PrimeSim option preserve_assert: Whether to execute the preservation for voltage check for assert statements. If the value is lazy, only execute the preservation for current checking; otherwise it will execute complete preservation. Possible values are lazy and force.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionpreserveinst	string	custom		PrimeSim option preserve_inst: Preserve the instances specified in the vector. Use 'preserve_inst=all' to preserve all instances.
saPrimeSimOptionpreservemaster	string	custom	[...]	PrimeSim option preserve_master: Preserve all instances of the masters specified.
saPrimeSimOptionpreservenode	string	custom	none	PrimeSim option preservenode: If set to all, node in save statement will be preserved. Possible values are none, all, and explicit.
saPrimeSimOptionpreservesubckt	string	custom	[...]	PrimeSim option preserve_subckt: Preserve all instances within the subcircuits specified.
saPrimeSimOptionprimesimabsoffset	string	saTestbench		PrimeSim option primesim_abs_offset:
saPrimeSimOptionprimesimabsoffsetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimacatdiff	string	custom	0	PrimeSim option primesim_ac_at_diff_t: Determines whether or not small signal analyses like ac and noise are run at times specified in .OP statement
saPrimeSimOptionprimesimacatdiffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimaccelerate_rom	string	custom	0	PrimeSim option primesim_accelerate_rom: Improves performance for the simulation of ROM circuits.
saPrimeSimOptionprimesimaccelerate_romUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimaccsparse_fc	string	saTestbench	0	PrimeSim option primesim_acc_sparse_fc:
saPrimeSimOptionprimesimaccsparse_fcthreshold	string	saTestbench		PrimeSim option primesim_acc_sparse_fc_threshold:
saPrimeSimOptionprimesimaccsparse_fcthresholdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimaccsparse_fcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimacflow	string	custom		PrimeSim option primesim_ac_flow: Controls whether small signal AC analyses of 3rd-party netlists are run in a PrimeSim HSPICE-compatible flow or in a 3rd-party compatible flow (default). This option is ignored in small signal AC analyses of HSPICE netlists.
saPrimeSimOptionprimesimacflowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimacflush	string	saTestbench		PrimeSim option primesim_acflush:
saPrimeSimOptionprimesimacflushUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimadaptivemt	string	custom		PrimeSim option primesim_adaptive_mt: Enables an optimized method for handling multi-threading on an overloaded machine.
saPrimeSimOptionprimesimadaptivemvmtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimadddivider	string	custom		PrimeSim option primesim_add_divider: Defines a character to use as a hierarchy divider.
saPrimeSimOptionprimesimadddividerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimaddinstance	string	custom		PrimeSim option primesim_add_instance: Automatically creates a subcircuit call line.
saPrimeSimOptionprimesimaddinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimaddstability	string	saTestbench	0	PrimeSim option primesim_add_stability:
saPrimeSimOptionprimesimaddstabilityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimaginglib	string	custom		PrimeSim option primesim_aginglib: Loads a model aging shared library.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimaginglibUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimagingspfdivider	string	saTestbench	<file path>	PrimeSim option primesim_aging_spfdivider: Lets aging analysis provide a hierarchy divider in the stressvec SPF file.
saPrimeSimOptionprimesimagingspfdividerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimaliasvdbtoopvdb	string	saTestbench	0	PrimeSim option primesim_alias_vdb_to_opvdb:
saPrimeSimOptionprimesimaliasvdbtoopvdbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimallow3tmosfet	string	custom		PrimeSim option primesim_allow_3t_mosfet: Allows three-terminal MOSFETs.
saPrimeSimOptionprimesimallow3tmosfetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimallowdupport	string	custom	1	PrimeSim option primesim_allow_dup_port: When set to 1, allows duplicated ports.
saPrimeSimOptionprimesimallowdupportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimallowlooselteerrtol	string	saTestbench	1	PrimeSim option primesim_allow_loose_lte_errtol:
saPrimeSimOptionprimesimallowlooselteerrtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimallownestedinstparam	string	saTestbench		PrimeSim option primesim_allow_nested_inst_param:
saPrimeSimOptionprimesimallownestedinstparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimanalogmode	string	saTestbench		PrimeSim option primesim_analog_mode:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimalogmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimalogmode is loaded.
saPrimeSimOptionprimesimalogpart	string	saTestbench		PrimeSim option primesim_analog_part:
saPrimeSimOptionprimesimalogpartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimapiopt	string	saTestbench	3	PrimeSim option primesim_api_opt:
saPrimeSimOptionprimesimapioptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimassert	string	saTestbench	0	PrimeSim option primesim_assert: Control the effort applied to assert check
saPrimeSimOptionprimesimassertUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimassert is loaded.
saPrimeSimOptionprimesimautoexitinvfsdb	string	saTestbench		PrimeSim option primesim_autoexit_invfsdb:
saPrimeSimOptionprimesimautoexitinvfsdbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimautogminscale	string	custom		PrimeSim option primesim_auto_gmin_scale: Specifies whether to auto-scale values for gmin and gmindc in FinFET designs.
saPrimeSimOptionprimesimautogminscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimautogshunt	string	saTestbench	0	PrimeSim option primesim_auto_gshunt:
saPrimeSimOptionprimesimautogshuntUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimautoiprobepwlist	string	saTestbench	item	PrimeSim option primesim_auto_iprobe_pwlist:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimautoiprobepwrlstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimavallow	string	saTestbench	0	PrimeSim option primesim_ava_flow:
saPrimeSimOptionprimesimavflowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbachangenetlist	string	saTestbench		PrimeSim option primesim_ba_change_netlist:
saPrimeSimOptionprimesimbachangenetlistUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimb anew	string	saTestbench	0	PrimeSim option primesim_ba_new:
saPrimeSimOptionprimesimb anewUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbaopt	string	saTestbench	3	PrimeSim option primesim_ba_opt:
saPrimeSimOptionprimesimbaoptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbaupdatexprobe	string	saTestbench	0	PrimeSim option primesim_ba_update_xprobe:
saPrimeSimOptionprimesimbaupdatexprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbgear	string	saTestbench	0	PrimeSim option primesim_bgear:
saPrimeSimOptionprimesimbgearmax	string	saTestbench	1e33	PrimeSim option primesim_bgear_max:
saPrimeSimOptionprimesimbgearmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbgearmin	string	saTestbench	0.0	PrimeSim option primesim_bgear_min:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimbearminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbearUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbiaschkenable	string	saTestbench	0	PrimeSim option primesim_biaschk_enable:
saPrimeSimOptionprimesimbiaschkenableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbipowerautodetect	string	saTestbench		PrimeSim option primesim_big_power_auto_detect:
saPrimeSimOptionprimesimbipowerautodetectUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbipowernetsopt	string	saTestbench	0	PrimeSim option primesim_big_power_nets_opt:
saPrimeSimOptionprimesimbipowernetsoptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbisecnormabstol	string	saTestbench	0	PrimeSim option primesim_bisec_norm_abstol:
saPrimeSimOptionprimesimbisecnormabstolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbisecnormcheck	string	saTestbench	0	PrimeSim option primesim_bisec_norm_check:
saPrimeSimOptionprimesimbisecnormcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbisecnormmeasabstol	string	saTestbench	3e-12	PrimeSim option primesim_bisec_norm_meas_abstol:
saPrimeSimOptionprimesimbisecnormmeasabstolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbisecnormmeasreltol	string	saTestbench	0.01	PrimeSim option primesim_bisec_norm_meas_reltol:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimbisecnormmeasreltolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbisecnormreltol	string	saTestbench	0.01	PrimeSim option primesim_bisec_norm_reltol:
saPrimeSimOptionprimesimbisecnormreltolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbisecsisseedctrl	string	saTestbench	0	PrimeSim option primesim_bisec_sis_seed_ctrl:
saPrimeSimOptionprimesimbisecsisseedctrlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbisecticonconcurrentmode	string	custom		PrimeSim option primesim_bisection_concurrent_mode: Controls the behavior of bisection optimization when performing Concurrent Bisection for Independent Circuit Blocks.
saPrimeSimOptionprimesimbisecticonconcurrentmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbisecticonfailcontinue	string	custom		PrimeSim option primesim_bisection_fail_continue: Allows the simulation to continue to other sweeps outside the bisection in the event that the bisection sweep fails.
saPrimeSimOptionprimesimbisecticonfailcontinueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbisecticonoutput	string	custom	1	PrimeSim option primesim_bisection_output: When set to 1 PrimeSim will merge all output data of one complete bisection progress to one file.
saPrimeSimOptionprimesimbisecticonoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbisecticonsummary	string	custom	1	PrimeSim option primesim_bisection_summary: Needs Description.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimbisecti onsummaryUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbisecti onusingssis	string	saTestbe nch		PrimeSim option primesim_bisection_using_sis:
saPrimeSimOptionprimesimbisecti onusingssisUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbsim3 gateleakage	string	saTestbe nch		PrimeSim option primesim_bsim3gate_leakage:
saPrimeSimOptionprimesimbsim3 gateleakageUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbuild hdb	string	saTestbe nch	0	PrimeSim option primesim_build_hdb:
saPrimeSimOptionprimesimbuildh dbUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimbytol	string	custom	1mV	PrimeSim option primesim_bytol: Sets the voltage value to use in determining whether a MOS is latent. The default value is dependent on primesim_mode.
saPrimeSimOptionprimesimbytolU ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcckp ost	string	saTestbe nch		PrimeSim option primesim_cck_post: Sets all three post-processing options:primesim_chkdevop_post;primesim _chkrftime_post;primesim_chktiming_post
saPrimeSimOptionprimesimcckpos tnp	string	saTestbe nch	1	PrimeSim option primesim_cck_post_np:
saPrimeSimOptionprimesimcckpos tnpUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcckpos tnumgroup	string	saTestbe nch	-1	PrimeSim option primesim_cck_post_num_group:
saPrimeSimOptionprimesimcckpos tnumgroupUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimcckpos trawoutput	string	saTestbench	1	PrimeSim option primesim_cck_post_raw_output:
saPrimeSimOptionprimesimcckpos trawoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcckpos tUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcckre moveresult	string	custom		PrimeSim option primesim_cck_remove_result: Removes the circuit check result file when there are no errors.
saPrimeSimOptionprimesimcckre moveresultUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimccmisft rds	string	saTestbench		PrimeSim option primesim_ccmi_sft_rds:
saPrimeSimOptionprimesimccmisft rdsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimccmo del	string	custom		PrimeSim option primesim_ccmodel: Controls the modeling of coupling capacitors based on the total coupling capacitance ratio.
saPrimeSimOptionprimesimccmod elUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcellc har	string	custom		PrimeSim option primesim_cell_char: Suppresses printing sweep parameters to the .mt0 file and data to the log file.
saPrimeSimOptionprimesimcellcha rUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchang er3cmcpinorder	string	custom		PrimeSim option primesim_change_r3cmc_pin_order: Specifies the pin order to use when assigning pins for the CMC R3 model.
saPrimeSimOptionprimesimchang er3cmcpinorderUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimchann elcutpinpout	string	saTestbe nch	0	PrimeSim option primesim_channel_cut_pinpout:
saPrimeSimOptionprimesimchann elcutpinpoutUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcheckd ummymossize	string	saTestbe nch		PrimeSim option primesim_check_dummy_mos_size:
saPrimeSimOptionprimesimcheckd ummymossizeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimcheckdummym ossize is loaded.
saPrimeSimOptionprimesimcheckd upparam	string	saTestbe nch	0	PrimeSim option primesim_check_dup_param:
saPrimeSimOptionprimesimcheckd upparamUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcheckli neconcat	string	saTestbe nch	0	PrimeSim option primesim_check_line_concat:
saPrimeSimOptionprimesimcheckli neconcatUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcheck modeforac	string	saTestbe nch	1	PrimeSim option primesim_check_mode_for_ac:
saPrimeSimOptionprimesimcheck modeforacUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcheck model	string	custom	0	PrimeSim option primesim_check_model: Needs Description.
saPrimeSimOptionprimesimcheck modelUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcheckp oint	string	saTestbe nch	0	PrimeSim option primesim_checkpoint:
saPrimeSimOptionprimesimcheckp ointUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcheckp ortmismatch	string	saTestbe nch	0	PrimeSim option primesim_check_port_mismatch:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimcheckp ormismatchUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchecku ndefinedparam	string	saTestbe nch		PrimeSim option primesim_check_undefined_param: Specifies whether to check for undefined parameters in the netlist and then
saPrimeSimOptionprimesimchecku ndefinedparamUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcheck vth	string	custom	1	PrimeSim option primesim_check_vth: Specifies whether to use primesim_goff (0) or vth (1) to determine the ON/OFF state.
saPrimeSimOptionprimesimcheckv thUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchgacc	string	saTestbe nch		PrimeSim option primesim_chgacc:
saPrimeSimOptionprimesimchgacc UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchgtol	string	custom	1e-15	PrimeSim option primesim_chgtol: Sets absolute charge tolerance during charge-based 1teq time step algorithm.
saPrimeSimOptionprimesimchgtol UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkblk pwrpwrnode	string	custom		PrimeSim option primesim_chkblkpwr_pwrnode: Marks nodes as supply nodes in the power report.
saPrimeSimOptionprimesimchkblk pwrpwrnodeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkblk pwrpwrport	string	custom		PrimeSim option primesim_chkblkpwr_pwrport: Defines the power port of all subcircuits.
saPrimeSimOptionprimesimchkblk pwrpwrportUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimchkblk pwrspecifiedonly	string	custom		PrimeSim option primesim_chkblkpwr_specified_only: Reports only the block power/ground for the specified node when using the primesim_chkblkpwr_pwrnode or primesim_chkblkpwr_pwrport options.
saPrimeSimOptionprimesimchkblk pwrspecifiedonlyUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkdcp athbuildnet	string	saTestbe nch	1	PrimeSim option primesim_chkdcpath_build_net:
saPrimeSimOptionprimesimchkdcp athbuildnetUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkdcp athgndgroup	string	custom		PrimeSim option primesim_chkdcpath_gndgroup: Specifies whether any node connected to an ideal ground (zero) voltage source through a zero voltage source is treated separately or as the same ground group by the .CHKDCPATH command.
saPrimeSimOptionprimesimchkdcp athgndgroupUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkdcp athpwrgroup	string	custom		PrimeSim option primesim_chkdcpath_pwrgroup: Specifies whether any node connected to an ideal power (non-zero) voltage source through a zero voltage source is treated separately or as the same power group by the .CHKDCPATH command.
saPrimeSimOptionprimesimchkdcp athpwrgroupUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkdcp athrth	string	custom		PrimeSim option primesim_chkdcpath_rth: Specifies the value for determining whether a resistor is treated as a parasitic resistor and part of a resistor network or as a normal device and not part of a resistor network.
saPrimeSimOptionprimesimchkdcp athrthUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimchkdevopdisable	string	custom		PrimeSim option primesim_chkdevop_disable: Disables .chkdevop for those circuits identified with the specified tag=tag_name arguments (see Check Device Operation Point (.CHKDEVOP)) and enables .chkdevop for all other circuits including those without a tag argument.
saPrimeSimOptionprimesimchkdevopdisableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkdevopenable	string	custom		PrimeSim option primesim_chkdevop_enable: Enables .chkdevop for those circuits identified with the specified tag=tag_name arguments (see Check Device Operation Point (.CHKDEVOP)) and disables .chkdevop for all other circuits including those without a tag argument.
saPrimeSimOptionprimesimchkdevopenableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkdevopfilterin	string	saTestbench		PrimeSim option primesim_chkdevop_filter_in: Controls which devices to include under the specified subcircuit's instances and the specified instances when checking for device operation condition.
saPrimeSimOptionprimesimchkdevopfilterinUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkdevopfilterout	string	saTestbench		PrimeSim option primesim_chkdevop_filter_out: Controls which devices to exclude under the specified subcircuit's instances and the specified instances when checking for device operation condition.
saPrimeSimOptionprimesimchkdevopfilteroutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkdevopmode	string	custom		PrimeSim option primesim_chkdevop_mode: Checks lower hierarchies of the subckt for .chkdevop when subckt=subckt_name is specified.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimchkdev opmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkdev oppost	string	custom		PrimeSim option primesim_chkdevop_post: Allows you to post-process .chkdevop (see Check Device Operation Point (.CHKDEVOP)).
saPrimeSimOptionprimesimchkdev oppostUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkdev opprintinfo	string	saTestbench		PrimeSim option primesim_chkdevop_print_info:
saPrimeSimOptionprimesimchkdev opprintinfoUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimchkdevopprintinfo is loaded.
saPrimeSimOptionprimesimchkdev port	string	custom	0	PrimeSim option primesim_chk_devport: Checks device port name during wildcard matching of .probe statement.
saPrimeSimOptionprimesimchkdev portUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkdgt	string	custom		PrimeSim option primesim_chkdgt: Sets the number of digits displayed after the decimal by the .CHKRFTIME and .CHKTIMING commands.
saPrimeSimOptionprimesimchkdgt UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkdis kspace	string	custom	0	PrimeSim option primesim_chk_disk_space: Checks and reports available disk space in every tflush time period.
saPrimeSimOptionprimesimchkdis kspaceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimchkexp rdisable	string	custom		PrimeSim option primesim_chkexpr_disable: Disables .chkexpr for those circuits identified with the specified tag=tag_name arguments (see Check Expression (.CHKEXPR)) and enables .chkexpr for all other circuits including those without a tag argument.
saPrimeSimOptionprimesimchkexp rdisableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkexp renable	string	custom		PrimeSim option primesim_chkexpr_enable: Enables .chkexpr for those circuits identified with the specified tag=tag_name arguments (see Check Expression (.CHKEXPR)) and disables .chkexpr for all other circuits including those without a tag argument.
saPrimeSimOptionprimesimchkexp renableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkexp rprintall	string	saTestbench		PrimeSim option primesim_chkexpr_print_all: When set to 1, all checks, including invalid assert, are also dumped into csv file
saPrimeSimOptionprimesimchkexp rprintallUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimchkexprprintall is loaded.
saPrimeSimOptionprimesimchkfor mat	string	custom		PrimeSim option primesim_chk_format: Specifies whether .CHKDEVOP commands use the PrimeSim XA TCL-CCK output format.
saPrimeSimOptionprimesimchkfor matUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkf sdb	string	saTestbench	0	PrimeSim option primesim_chk_fsdb: This option prevents overwriting FSDB files.
saPrimeSimOptionprimesimchkfsd bUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimchkrftimepost	string	custom		PrimeSim option primesim_chkrftime_post: Allows you to post-process .chkrftime (see Check Rise/Fall Transition Time (.CHKRFTIME)).
saPrimeSimOptionprimesimchkrftimepostUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkrftimeverbose	string	saTestbench		PrimeSim option primesim_chkrftime_report_verbose:
saPrimeSimOptionprimesimchkrftimeverboseUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchktimingpost	string	custom		PrimeSim option primesim_chktiming_post: Allows you to post-process .chktiming (see Check Timing Setup/Hold/Delay/Width (.CHKTIMING)).
saPrimeSimOptionprimesimchktimingpostUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkznodedebugout	string	custom		PrimeSim option primesim_chkznodedebug_out: Specifies that device turn-on/off information be printed out for Hi-Z node debugging.
saPrimeSimOptionprimesimchkznodedebugoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkznodedoublepass	string	saTestbench		PrimeSim option primesim_chkznodedouble_pass:
saPrimeSimOptionprimesimchkznodedoublepassUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkznoderule	string	custom		PrimeSim option primesim_chkznoderule: Specifies a global option in checking conductivity of MOSFET.
saPrimeSimOptionprimesimchkznoderuleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimchkznoderulevbe	string	saTestbench		PrimeSim option primesim_chkznoderule_vbe:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimchkznodevbeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimchkznodevbe is loaded.
saPrimeSimOptionprimesimchkznodevth	string	custom	0	PrimeSim option primesim_chkznnode_vth: Sets the Vth value in calculating the ON/OFF state of MOSFET.
saPrimeSimOptionprimesimchkznodevthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcircuittype	string	saTestbench		PrimeSim option primesim_circuit_type:
saPrimeSimOptionprimesimcircuittypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcis	string	saTestbench		PrimeSim option primesim_cis:
saPrimeSimOptionprimesimcisUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcktopt	string	custom		PrimeSim option primesim_cktopt: Applies circuit optimization.
saPrimeSimOptionprimesimcktoptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimclampVerilog	string	custom	0	PrimeSim option primesim_clampVerilog: Clamps stamped conductance value to primesim_gmax.
saPrimeSimOptionprimesimclampVerilogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcmivamodel	string	saTestbench		PrimeSim option primesim_cmi_vamodel:
saPrimeSimOptionprimesimcmivamodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcmimodel	string	custom		PrimeSim option primesim_c_model: Specifies a C Model.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimcmodelexclude	string	saTestbench		PrimeSim option primesim_c_model_exclude: Excludes some instances of C-models from being replaced with the model that was created.
saPrimeSimOptionprimesimcmodelexcludeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcmpxsparsefcap	string	saTestbench		PrimeSim option primesim_cmpx_sparse_fcaps:
saPrimeSimOptionprimesimcmpxsparsefcapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimcmpxsparsefcap is loaded.
saPrimeSimOptionprimesimcomplexoutput	string	saTestbench	1	PrimeSim option primesim_complex_output:
saPrimeSimOptionprimesimcomplexoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimconnectmode	string	custom		PrimeSim option primesim_connect_mode: Specifies what the .CONNECT SPICE-compatible control uses to connect two nodes.
saPrimeSimOptionprimesimconnectmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcontmeasout	string	custom		PrimeSim option primesim_cont_measout: Controls the continuous measurement file format.
saPrimeSimOptionprimesimcontmeasoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimconvlevel	string	custom	0	PrimeSim option primesim_convlevel: Determines how PrimeSim attempts to solve the "time step too small" error.
saPrimeSimOptionprimesimconvlevelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimcorrect ionbulksamedirection	string	saTestbe nch	0	PrimeSim option primesim_correction_bulk_same_direction
saPrimeSimOptionprimesimcorrect ionbulksamedirectionUncheckLoca lized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcosimp robestyle	string	saTestbe nch		PrimeSim option primesim_cosim_probe_style:
saPrimeSimOptionprimesimcosimp robestyleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcosims tandalonecapturetime	string	saTestbe nch		PrimeSim option primesim_cosim_standalone_capture_time:
saPrimeSimOptionprimesimcosims tandalonecapturetimeUncheckLoc alized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcprbtol	string	custom		PrimeSim option primesim_cprbtol: Sets the capacitance tolerance for the capacitance print out.
saPrimeSimOptionprimesimcprbtol UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcptinte roptimization	string	saTestbe nch	1	PrimeSim option primesim_cpt_interp_optimization:
saPrimeSimOptionprimesimcptinte roptimizationUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcpu min	string	saTestbe nch	0	PrimeSim option primesim_cpu_min:
saPrimeSimOptionprimesimcpumi nUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcsensi nstparam	string	saTestbe nch	0	PrimeSim option primesim_csens_inst_param:
saPrimeSimOptionprimesimcsensi nstparamUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcsmax	string	saTestbe nch		PrimeSim option primesim_csmax:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimcsmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcurrentaccuracy	string	saTestbench	0	PrimeSim option primesim_current_accuracy:
saPrimeSimOptionprimesimcurrentaccuracyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcutedge	string	saTestbench		PrimeSim option primesim_cutedge:
saPrimeSimOptionprimesimcutedgeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcutnode	string	custom		PrimeSim option primesim_cutnode: Reduces partition size for signal nodes.
saPrimeSimOptionprimesimcutnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcvamintranstime	string	saTestbench		PrimeSim option primesim_cva_min_trans_time:
saPrimeSimOptionprimesimcvamintranstimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimcvamintranstunits	string	saTestbench	0	PrimeSim option primesim_cva_min_trans_tunits:
saPrimeSimOptionprimesimcvamintranstunitsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdcalg	string	custom	0	PrimeSim option primesim_dcalg: Sets algorithm for DC convergence.
saPrimeSimOptionprimesimdcalgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdcurrentaccuracy	string	saTestbench	0	PrimeSim option primesim_dc_current_accuracy:
saPrimeSimOptionprimesimdcurrentaccuracyiabstol	string	saTestbench		PrimeSim option primesim_dc_current_accuracy_iabstol:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimdcurr entaccuracyiabstolUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdcurr entaccuracyUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdcdam pmethod	string	saTestbe nch		PrimeSim option primesim_dcdamp_method:
saPrimeSimOptionprimesimdcdam pmethodUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdceff ort	string	custom	1	PrimeSim option primesim_dceffort: Controls effort applied for DC convergence.
saPrimeSimOptionprimesimdceffor tUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdcopt	string	saTestbe nch	0	PrimeSim option primesim_dcopt:
saPrimeSimOptionprimesimdcopt ind	string	saTestbe nch	0	PrimeSim option primesim_dcopt_ind:
saPrimeSimOptionprimesimdcopti ndUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdcoptU ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdcpwrl oadmodelonly	string	saTestbe nch	1	PrimeSim option primesim_dc_pwrloadmodel_i_only:
saPrimeSimOptionprimesimdcpwrl oadmodelonlyUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdcpwr model	string	saTestbe nch		PrimeSim option primesim_dcpwrmodel:
saPrimeSimOptionprimesimdcpwr modelUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdcser ial	string	saTestbe nch	0	PrimeSim option primesim_dc_serial:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimdcserialUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdebugnet	string	saTestbench		PrimeSim option primesim_debug_net:
saPrimeSimOptionprimesimdebugnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdelmax	string	custom		PrimeSim option primesim_delmax: Sets maximum value of internal time step in simulation.
saPrimeSimOptionprimesimdelmaxfix	string	saTestbench	1	PrimeSim option primesim_delmax_fix:
saPrimeSimOptionprimesimdelmaxfixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdelmaxfixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdelmin	string	custom		PrimeSim option primesim_delmin: Specifies the minimum time step in a simulation.
saPrimeSimOptionprimesimdelminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdelvto	string	saTestbench		PrimeSim option primesim_delvto:
saPrimeSimOptionprimesimdelvtoUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdetectbtobinv	string	saTestbench		PrimeSim option primesim_detect_btobinv:
saPrimeSimOptionprimesimdetectbtobinvUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdetectdigital	string	saTestbench	1	PrimeSim option primesim_detect_digital:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimdetectdigitalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdetecthsamp	string	saTestbench		PrimeSim option primesim_detect_hsamp:
saPrimeSimOptionprimesimdetecthsampUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdetectlvdd	string	custom		PrimeSim option primesim_detect_lvdd: Provides auto-detection of the VDD level for lprobe.
saPrimeSimOptionprimesimdetectlvddstatic	string	custom		PrimeSim option primesim_detect_lvdd_static: Clamps stamped conductance value to primesim_gmax.
saPrimeSimOptionprimesimdetectlvddstaticUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdetectlvddUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdetectsptrgate	string	saTestbench		PrimeSim option primesim_detect_sptrgate:
saPrimeSimOptionprimesimdetectsptrgateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdetectvcvsloop	string	saTestbench		PrimeSim option primesim_detect_vcvs_loop: Enables the PrimeSim Pro tool to detect loops between VCVS sources and Verilog-A and then prevent partitioning from breaking the loops causing "time step too small" errors in transient analysis.
saPrimeSimOptionprimesimdetectvcvsloopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdetectvsrcloop	string	saTestbench	2	PrimeSim option primesim_detect_vsrc_loop:
saPrimeSimOptionprimesimdetectvsrcloopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimdeviceicrule	string	saTestbench	0	PrimeSim option primesim_device_ic_rule:
saPrimeSimOptionprimesimdeviceicruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdiagba	string	saTestbench		PrimeSim option primesim_diag_ba:
saPrimeSimOptionprimesimdiagbaUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdigitalmode	string	saTestbench	0	PrimeSim option primesim_digital_mode:
saPrimeSimOptionprimesimdigitalmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdisablecmiqjflag	string	saTestbench		PrimeSim option primesim_disable_cmi_qjflag:
saPrimeSimOptionprimesimdisablecmiqjflagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdmr	string	saTestbench		PrimeSim option primesim_dmr:
saPrimeSimOptionprimesimdmrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimdmr is loaded.
saPrimeSimOptionprimesimdoubleprecisionoutput	string	custom	0	PrimeSim option primesim_double_precision_output: Changes output file value from 4 bytes to 8 bytes.
saPrimeSimOptionprimesimdoubleprecisionoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdpf	string	custom		PrimeSim option primesim_dpf: Specifies the DPF file that contains the extracted device parameter data.
saPrimeSimOptionprimesimdpfadddev	string	custom	0	PrimeSim option primesim_dpfadddev: Controls whether DPF devices that are not in the netlist are added.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimdpfadd devUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdpfh div	string	custom	<file path>	PrimeSim option primesim_dpfhdiv: Sets the divider character for hierarchical names in DPF files.
saPrimeSimOptionprimesimdpfhdi vUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdpfmo dule	string	custom		PrimeSim option primesim_dpftime: Specifies the module for DPF back-annotation.
saPrimeSimOptionprimesimdpfmo duleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdpfmo sonly	string	custom		PrimeSim option primesim_dpftime_mos_only: Specifies whether to back-annotate all devices or only MOSFET devices.
saPrimeSimOptionprimesimdpfmo sonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdpfpref fix	string	custom		PrimeSim option primesim_dpfprefix: Lists the prefixes that should be removed from DPF device names.
saPrimeSimOptionprimesimdpfpref ixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdpfsc ale	string	custom	1	PrimeSim option primesim_dpfscale: Sets the scale for devices in the DPF file.
saPrimeSimOptionprimesimdpfscal eUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdpfsuf fix	string	custom		PrimeSim option primesim_dpfsuffix: Defines the suffix in a DPF file.
saPrimeSimOptionprimesimdpfsuff ixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdpfUnc heckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimdramrampup	string	saTestbench		PrimeSim option primesim_dram_rampup:
saPrimeSimOptionprimesimdramrampupUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdumputcinfo	string	saTestbench	0	PrimeSim option primesim_dump_cktinfo:
saPrimeSimOptionprimesimdumputcinfoUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdumpe labdb	string	saTestbench		PrimeSim option primesim_dump_elab_db:
saPrimeSimOptionprimesimdumpe labdbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdumflatcell	string	saTestbench		PrimeSim option primesim_dump_flat_cell:
saPrimeSimOptionprimesimdumflatcellUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdumflatinst	string	saTestbench		PrimeSim option primesim_dump_flat_inst:
saPrimeSimOptionprimesimdumflatinstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimduplicateckcheck	string	saTestbench	1	PrimeSim option primesim_duplicate_ck_check:
saPrimeSimOptionprimesimduplicateckcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdvdvdd	string	saTestbench		PrimeSim option primesim_dvdvdd:
saPrimeSimOptionprimesimdvdvddUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdvmvmax	string	custom		PrimeSim option primesim_dvmvmax: Sets the maximum voltage change of a node in a single time step.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimdvmxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimdvm	string	saTestbench		PrimeSim option primesim_dvmin:
saPrimeSimOptionprimesimdvmUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimelapsetdflush	string	custom		PrimeSim option primesim_elapsed_tflush: Flushes output files after the specified number of seconds in elapsed runtime since the previous flush.
saPrimeSimOptionprimesimelapsetdflushUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimemirlatepostprocessing	string	saTestbench		PrimeSim option primesim_emir_late_post_processing:
saPrimeSimOptionprimesimemirlatepostprocessingUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimemirlatepostprocessing is loaded.
saPrimeSimOptionprimesimemirpost	string	saTestbench	emir_post.cfg	PrimeSim option primesim_emir_post: Reads in PrimeSim EMIR post-process config file. When users use this option with a valid config file, PrimeSim launches post-processor with the created DB.
saPrimeSimOptionprimesimemirpostUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimemirsim	string	saTestbench	emir_sim.cfg	PrimeSim option primesim_emir_sim: Reads in PrimeSim EMIR simulation config file. When users use this option with a valid config file, PrimeSim creates the DB based on user inputs.
saPrimeSimOptionprimesimemirsimUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimenablesdebug	string	saTestbench	0	PrimeSim option primesim_enable_s_debug:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimenablesdebugUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimenforcesspassive	string	saTestbench	0	PrimeSim option primesim_enforce_s_passive:
saPrimeSimOptionprimesimenforcesspassiveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimenhancedtclmode	string	custom		PrimeSim option primesim_enhanced_tcl_mode: Allows Tcl to perform model name matching.
saPrimeSimOptionprimesimenhancedtclmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimenprefix	string	custom		PrimeSim option primesim_enprefix: Specifies the prefix characters in a pre-layout netlist that should be removed to match with the DSPF instance name during back-annotation.
saPrimeSimOptionprimesimenprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimeqr2spres	string	custom		PrimeSim option primesim_eqr2spres:
saPrimeSimOptionprimesimeqr2spresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimeqroptminshortingdeg	string	saTestbench		PrimeSim option primesim_eqr_opt_min_shorting_deg:
saPrimeSimOptionprimesimeqroptminshortingdegUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimeqroptshortinglimit	string	saTestbench		PrimeSim option primesim_eqr_opt_shorting_limit:
saPrimeSimOptionprimesimeqroptshortinglimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimevabstolscale	string	saTestbench		PrimeSim option primesim_evabstolscale:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimevabstolscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimevlevel	string	custom		PrimeSim option primesim_evlevel: Improves performance especially in post-layout circuits with many coupling capacitors such as SRAM/DRAM.
saPrimeSimOptionprimesimevlevelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimevreltolyscale	string	saTestbench		PrimeSim option primesim_evreltolyscale:
saPrimeSimOptionprimesimevreltolyscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimevtgridforpdn	string	saTestbench	1	PrimeSim option primesim_evtgrid_for_pdn:
saPrimeSimOptionprimesimevtgridforpdnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimevtgridmodeforpdn	string	saTestbench	1	PrimeSim option primesim_evtgrid_mode_for_pdn:
saPrimeSimOptionprimesimevtgridmodeforpdnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimevtgridrcnumforpdn	string	saTestbench	10000	PrimeSim option primesim_evtgrid_rcnum_for_pdn:
saPrimeSimOptionprimesimevtgridrcnumforpdnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimevtolscale	string	saTestbench		PrimeSim option primesim_evtolscale:
saPrimeSimOptionprimesimevtolscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimexcludgrayboxprobe	string	saTestbench		PrimeSim option primesim_exclude_graybox_probe:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimexclud egrayboxprobeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimexclud egrayboxprobe is loaded.
saPrimeSimOptionprimesimexit	string	saTestbe nch		PrimeSim option primesim_exit: Forces the PrimeSim tool to terminate after parsing
saPrimeSimOptionprimesimexitdcf ail	string	custom		PrimeSim option primesim_exit_dc_fail: Specifies whether to issue a warning message and continue the simulation or exit the simulation entirely if DC does not converge.
saPrimeSimOptionprimesimexitdcf ailUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimexitUn checkLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimexitw arn	string	custom		PrimeSim option primesim_exitwarn: Changes a PrimeSim Pro warning to an error by defining the warning string.
saPrimeSimOptionprimesimexitwar nUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimexitwar nwithfilter	string	saTestbe nch		PrimeSim option primesim_exitwarn_with_filter:
saPrimeSimOptionprimesimexitwar nwithfilterUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimexpan dinstancemfactor	string	custom		PrimeSim option primesim_expand_instance_mfactor: Expands subcircuit instances based on the instance's multiplier parameter (M) and assigns a starting index.
saPrimeSimOptionprimesimexpan dinstancemfactorUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimextend edpwrblock	string	custom		PrimeSim option primesim_extended_pwrblock: Enables power block detection for topologies that have feedback and/or circuits that must be in the same partition.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimextend edpwrblockfix	string	saTestbench	1	PrimeSim option primesim_extended_pwrblock_fix:
saPrimeSimOptionprimesimextend edpwrblockfixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimextend edpwrblockUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimextmc bin	string	saTestbench	0	PrimeSim option primesim_ext_mc_bin:
saPrimeSimOptionprimesimextmc binUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfastcorner	string	saTestbench		PrimeSim option primesim_fast_corner: Enables fast multi-corner simulation to enhance throughput when you use the same input netlist and input vector with variations of PVT (Process)
saPrimeSimOptionprimesimfastcorner sweep	string	saTestbench		PrimeSim option primesim_fast_corner_sweep: Enables fast multi-corner simulation to enhance throughput when you use the same input netlist and input vector with variations of PVT (Process)
saPrimeSimOptionprimesimfastcorner sweepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfastcorner UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfastcorner useic	string	saTestbench	1	PrimeSim option primesim_fast_corner_use_ic:
saPrimeSimOptionprimesimfastcorner useicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfcapkeep	string	saTestbench		PrimeSim option primesim_fckeep:
saPrimeSimOptionprimesimfcapkeep UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimfcapmin	string	custom	0	PrimeSim option primesim_fcamin: Converts a small coupling capacitance into two grounded capacitance values.
saPrimeSimOptionprimesimfcapminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfcapmodel	string	custom	1	PrimeSim option primesim_fcamodel: Controls the modeling of floating capacitances.
saPrimeSimOptionprimesimfcapmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfcapratio	string	saTestbench	0	PrimeSim option primesim_fcpratio:
saPrimeSimOptionprimesimfcapratioMethod	string	saTestbench		PrimeSim option primesim_fcpratio_method:
saPrimeSimOptionprimesimfcapratioMethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfcapratioioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfcapred	string	saTestbench		PrimeSim option primesim_fcaped:
saPrimeSimOptionprimesimfcapredUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfcaprelax	string	saTestbench		PrimeSim option primesim_fcprelax:
saPrimeSimOptionprimesimfcaprelaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfinfet	string	saTestbench	2	PrimeSim option primesim_finfet:
saPrimeSimOptionprimesimfinfet24tIod	string	saTestbench	0	PrimeSim option primesim_finfet2_4t_lod:
saPrimeSimOptionprimesimfinfet24tIodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimfinfet2checkpwrpath	string	saTestbench	2	PrimeSim option primesim_finfet2_check_pwr_path:
saPrimeSimOptionprimesimfinfet2checkpwrpathUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfinfetrule	string	saTestbench	0	PrimeSim option primesim_finfet_rule:
saPrimeSimOptionprimesimfinfetruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfinfetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfingerchar	string	custom		PrimeSim option primesim_fingerchar: Sets the finger delimiter character for devices and instances.
saPrimeSimOptionprimesimfingercharUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfingercurrent	string	custom		PrimeSim option primesim_finger_current: Specifies whether to report the total device current or only the main device's finger current contribution.
saPrimeSimOptionprimesimfingercurrentUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfingersstring	string	saTestbench		PrimeSim option primesim_finger_string:
saPrimeSimOptionprimesimfingersstringUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimfingerstring is loaded.
saPrimeSimOptionprimesimflash	string	saTestbench		PrimeSim option primesim_flash: Provides auto-detection and partitioning of internally-generated power supplies in flash design simulations
saPrimeSimOptionprimesimflashcellmode	string	saTestbench		PrimeSim option primesim_flashcell_mode:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimflashcelmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimflashUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimflat	string	saTestbench		PrimeSim option primesim_flat:
saPrimeSimOptionprimesimflatsize	string	custom	7	PrimeSim option primesim_flatsize: Sets a threshold to flatten subcircuits before partitioning starts.
saPrimeSimOptionprimesimflatsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimflatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfloatingcheckignoreic	string	saTestbench	0	PrimeSim option primesim_floating_check_ignore_ic:
saPrimeSimOptionprimesimfloatingcheckignoreicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfloatinggatecheck	string	saTestbench	0	PrimeSim option primesim_floating_gate_check:
saPrimeSimOptionprimesimfloatinggatecheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfloatinggatefix	string	saTestbench	1	PrimeSim option primesim_floating_gate_fix:
saPrimeSimOptionprimesimfloatinggatefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfloatinggategshunt	string	custom	0	PrimeSim option primesim_floating_gate_gshunt: Adds a conductance between floating gate node and ground.
saPrimeSimOptionprimesimfloatinggategshuntUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimfloatin gisrcdcmode	string	saTestbe nch	0	PrimeSim option primesim_floating_isrc_dc_mode:
saPrimeSimOptionprimesimfloatin gisrcdcmodeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfloatin glodaccuracy	string	saTestbe nch	0	PrimeSim option primesim_floating_lod_accuracy:
saPrimeSimOptionprimesimfloatin glodaccuracyUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfmeasf orm	string	saTestbe nch	0	PrimeSim option primesim_fmeas_form:
saPrimeSimOptionprimesimfmeasf ormUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimforcef lat	string	saTestbe nch		PrimeSim option primesim_force_flat:
saPrimeSimOptionprimesimforcefl atUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimforce pms	string	saTestbe nch	0	PrimeSim option primesim_force_pms:
saPrimeSimOptionprimesimforcep msUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimforcerc red	string	saTestbe nch	0	PrimeSim option primesim_force_rcred:
saPrimeSimOptionprimesimforcerc redUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimforces predplus	string	saTestbe nch		PrimeSim option primesim_force_spred_plus:
saPrimeSimOptionprimesimforces predplusUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfscout odetect	string	custom		PrimeSim option primesim_fsc_auto_detect: Voltage levels corresponding to logic levels or setting the VDD for a model will be handled automatically using this option.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimfscautoDetectUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfscinstanceparam	string	saTestbench		PrimeSim option primesim_fsc_instance_param:
saPrimeSimOptionprimesimfscinstanceparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfscvdd	string	custom		PrimeSim option primesim_fsc_vdd: Specifies the supply voltage for the C-model interface.
saPrimeSimOptionprimesimfscvddUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfsdblimit	string	custom	0	PrimeSim option primesim_fsdb_limit: Specifies a size limit for fsdb files.
saPrimeSimOptionprimesimfsdblimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfsdbsplitpg	string	custom		PrimeSim option primesim_fsdb_split_pg: Specifies to split Power/Ground R-Network nodes in non-ideal Power/Ground simulation from all other Signals and dump them into a separate FSDB file.
saPrimeSimOptionprimesimfsdbsplitpgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfsdbsplitpgtime	string	custom		PrimeSim option primesim_fsdb_split_time: Specifies to split FSDB based on the time values.
saPrimeSimOptionprimesimfsdbsplitpgtimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimfsdbtermvarhier	string	saTestbench		PrimeSim option primesim_fsdb_term_var_hier: Changes the terminal delimiter
saPrimeSimOptionprimesimfsdbtermvarhierUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimfsdbversion	string	custom		PrimeSim option primesim_fsdb_version: Specifies what version of FSDB writer the PrimeSim tool should use.
saPrimeSimOptionprimesimfsdbversionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgateeventol	string	saTestbench		PrimeSim option primesim_gate_evtol:
saPrimeSimOptionprimesimgateeventolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgateleakage	string	saTestbench		PrimeSim option primesim_gate_leakage:
saPrimeSimOptionprimesimgateleakageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgdcpath	string	custom		PrimeSim option primesim_gdcpath: Adds gshunts to nodes having no DC path to ground.
saPrimeSimOptionprimesimgdcpathmode	string	saTestbench	3	PrimeSim option primesim_gdcpath_mode:
saPrimeSimOptionprimesimgdcpathmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgdcpathUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgenacop	string	custom	1	PrimeSim option primesim_gen_ac_op: Determines if binary files or ASCII .ic files are generated for each time point in .OP statement
saPrimeSimOptionprimesimgenacopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgencckdb	string	saTestbench		PrimeSim option primesim_gen_cck_db:
saPrimeSimOptionprimesimgencckdbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimgencckdb is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimgenicop	string	custom	0	PrimeSim option primesim_gen_ic_op: Generates the .op file when it is not created by default.
saPrimeSimOptionprimesimgenicopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgenmc0	string	custom		PrimeSim option primesim_gen_mc0: Specifies whether to generate the *.mc# file for Monte Carlo analysis.
saPrimeSimOptionprimesimgenmc0UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgenopcaptab	string	custom		PrimeSim option primesim_gen_op_captab: Generates node capacitance information in the .op file.
saPrimeSimOptionprimesimgenopcaptabUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgenpnc	string	custom		PrimeSim option primesim_gen_pn_c: Enables output to the *.pn_c0 file in .NOISE analysis.
saPrimeSimOptionprimesimgenpncUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgic	string	custom	1e10	PrimeSim option primesim_gic: Sets conductance value of the resistor in the Norton-type voltage source.
saPrimeSimOptionprimesimgicind	string	saTestbench		PrimeSim option primesim_gic_ind:
saPrimeSimOptionprimesimgicindUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgmax	string	custom	100	PrimeSim option primesim_gmax: Clamps the stamped conductance value to primesim_gmax.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimgmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgmitem	string	custom		PrimeSim option primesim_gmi_telem: Specifies which T-element implementation to use.
saPrimeSimOptionprimesimgmitelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgoff	string	custom		PrimeSim option primesim_goff: Works with the .CHKZNODE statement to determine if a MOSFET is on or off.
saPrimeSimOptionprimesimgoffcheck	string	saTestbench	1.0e-09	PrimeSim option primesim_goff_check:
saPrimeSimOptionprimesimgoffcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgoffpower	string	saTestbench	1.0e-05	PrimeSim option primesim_goff_power:
saPrimeSimOptionprimesimgoffpowerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgoffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgpd	string	custom		PrimeSim option primesim_gpd: Back-annotates a corner used in the Galaxy Parasitic Database (GPD).
saPrimeSimOptionprimesimgpddump	string	saTestbench	(1+4)	PrimeSim option primesim_gpd_dump:
saPrimeSimOptionprimesimgpddumpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgpdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgpthmax	string	saTestbench		PrimeSim option primesim_gpt_hmax:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimgpthmaxf	string	saTestbench		PrimeSim option primesim_gpt_hmax_f:
saPrimeSimOptionprimesimgpthmaxfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgpthmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgpthramp_time	string	saTestbench		PrimeSim option primesim_gpt_ramp_time:
saPrimeSimOptionprimesimgpthramp_timeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgpttimepointsnum	string	saTestbench	2000	PrimeSim option primesim_gpt_timepoints_num:
saPrimeSimOptionprimesimgpttimepointsnumUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgptweight	string	saTestbench		PrimeSim option primesim_gpt_weight:
saPrimeSimOptionprimesimgptweightUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgpuid	string	saTestbench		PrimeSim option primesim_gpuid:
saPrimeSimOptionprimesimgpuidUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimgpuid is loaded.
saPrimeSimOptionprimesimgpumode	string	saTestbench	2	PrimeSim option primesim_gpu_mode: Specifies the mode of operation when using GPU simulation
saPrimeSimOptionprimesimgpumodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgpuoptimize	string	saTestbench		PrimeSim option primesim_gpu_optimize:
saPrimeSimOptionprimesimgpuoptimizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimgroundmoscap	string	saTestbench		PrimeSim option primesim_ground_moscap:
saPrimeSimOptionprimesimgroundmoscapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgroup	string	saTestbench		PrimeSim option primesim_group:
saPrimeSimOptionprimesimgroupUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgshpt	string	saTestbench		PrimeSim option primesim_gshpt: Adds conductance from each node to ground during pseudo-transient simulation. After pseudo-transient converges.
saPrimeSimOptionprimesimgshptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimgvsrnc	string	saTestbench		PrimeSim option primesim_gvsrnc:
saPrimeSimOptionprimesimgvsrncUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimhflash	string	saTestbench		PrimeSim option primesim_hflash:
saPrimeSimOptionprimesimhflashUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimhgrace	string	saTestbench	1	PrimeSim option primesim_hgrace:
saPrimeSimOptionprimesimhgraceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimhiersim	string	custom		PrimeSim option primesim_hiersim: Selects hierarchical simulation mode.
saPrimeSimOptionprimesimhiersimavg	string	saTestbench		PrimeSim option primesim_hiersim_avg:
saPrimeSimOptionprimesimhiersimavgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimhiersimUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimhighaccmode	string	saTestbench		PrimeSim option primesim_highacc_mode:
saPrimeSimOptionprimesimhighaccmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimhighspeedmode	string	saTestbench		PrimeSim option primesim_highspeed_mode:
saPrimeSimOptionprimesimhighspeedmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimhstolscale	string	custom	1	PrimeSim option primesim_hstolscale: Sets a multiplier applied to all internal tolerance values for subcircuits that will be simulated with the hiersim method.
saPrimeSimOptionprimesimhstolscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimicpriority	string	custom		PrimeSim option primesim_ic_priority: Forces the PrimeSim tool to take the .IC value even if there is a .NODESET value defined later on the same node.
saPrimeSimOptionprimesimicpriorityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimidenticalmcinstancefile	string	custom		PrimeSim option primesim_identical_mc_instance_file: Generate the same random number sequence for the Monte Carlo Simulation.
saPrimeSimOptionprimesimidenticalmcinstancefileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimidrsubckt	string	saTestbench		PrimeSim option primesim_idrsubckt:
saPrimeSimOptionprimesimidrsubcktUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimignore	string	custom		PrimeSim option primesim_ignore: Ignores instances or subcircuits in simulation for higher performance.
saPrimeSimOptionprimesimignoreallhizvsrc	string	saTestbench		PrimeSim option primesim_ignore_all_hiz_vsrc:
saPrimeSimOptionprimesimignoreallhizvsrcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimignorechkfuncerror	string	custom	0	PrimeSim option primesim_ignore_chkfunc_error: Continues the simulation with a warning instead of an error and exiting.
saPrimeSimOptionprimesimignorechkfuncerrorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimignoredevice	string	custom		PrimeSim option primesim_ignore_device: Makes quick netlist changes by ignoring specified devices during simulation.
saPrimeSimOptionprimesimignoredeviceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimignoredummyinstance	string	saTestbench		PrimeSim option primesim_ignore_dummy_instance:
saPrimeSimOptionprimesimignoredummyinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimignoredummyinstance is loaded.
saPrimeSimOptionprimesimignorefloatingnode	string	saTestbench		PrimeSim option primesim_ignore_floating_node: Suppresses WARNINGS about ""No DC path to ground on MOSFET..."".
saPrimeSimOptionprimesimignorefloatingnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimignorefloatingnodeisrc	string	custom	0	PrimeSim option primesim_ignore_float_isrc: Ignores the floating current source and outputs a warning message.
saPrimeSimOptionprimesimignorefloatingnodeisrcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimignoreinstance	string	saTestbench		PrimeSim option primesim_ignore_instance:
saPrimeSimOptionprimesimignoreinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimignoreinstparam	string	saTestbench	1	PrimeSim option primesim_ignore_inst_param:
saPrimeSimOptionprimesimignoreinstparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimignorelayoutonlydevice	string	custom		PrimeSim option primesim_ignore_layout_only_device: Skips the specified devices for the include flow.
saPrimeSimOptionprimesimignorelayoutonlydeviceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimignorenovectdataerror	string	custom		PrimeSim option primesim_ignore_no_vec_tdata_error: Specifies whether to error out if there is no tabular data in the I/O vector file.
saPrimeSimOptionprimesimignorenovectdataerrorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimignoreopanalysis	string	custom		PrimeSim option primesim_ignore_op_analysis: Specifies whether to ignore .OP analysis in the netlist.
saPrimeSimOptionprimesimignoreopanalysisUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimignorepdspvtolcond	string	saTestbench	0	PrimeSim option primesim_ignore_pds_pvtol_cond:
saPrimeSimOptionprimesimignorepdspvtolcondUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimignorepincap	string	saTestbench	0	PrimeSim option primesim_ignore_pincap:
saPrimeSimOptionprimesimignorepincapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimignore subblkoptionerror	string	custom	0	PrimeSim option primesim_ignore_subblk_option_error: .
saPrimeSimOptionprimesimignore subblkoptionerrorUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimignoret dfortsc	string	saTestbe nch	3	PrimeSim option primesim_ignore_td_for_tsc:
saPrimeSimOptionprimesimignoret dfortscUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimignore UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimignor eva	string	custom		PrimeSim option primesim_ignore_va: Improves front-end performance by ignoring Verilog-A file parsing.
saPrimeSimOptionprimesimignore vaUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimim	string	saTestbe nch		PrimeSim option primesim_im:
saPrimeSimOptionprimesimimUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesiminactiv echkanodedv	string	saTestbe nch		PrimeSim option primesim_inactive_chkanode_dv: When performing fast multi-corner simulation
saPrimeSimOptionprimesiminactiv echkanodedvUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesiminactiv eshortrc	string	saTestbe nch	9	PrimeSim option primesim_inactive_short_rc:
saPrimeSimOptionprimesiminactiv eshortrccaptol	string	saTestbe nch	1e-15	PrimeSim option primesim_inactive_short_rc_cap_tol:
saPrimeSimOptionprimesiminactiv eshortrccaptolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesiminactiv eshortrccurtol	string	saTestbe nch	1e-3	PrimeSim option primesim_inactive_short_rc_cur_tol:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesiminactiv eshortrcurtolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesiminactiv eshortrcdebug	string	saTestbe nch	0	PrimeSim option primesim_inactive_short_rc_debug:
saPrimeSimOptionprimesiminactiv eshortrcdebugUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesiminactiv eshortrcresol	string	saTestbe nch	1e3	PrimeSim option primesim_inactive_short_rc_res_tol:
saPrimeSimOptionprimesiminactiv eshortrcresolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesiminactiv eshortrcUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesiminactiv eshortrcvoltage	string	saTestbe nch	1e-2	PrimeSim option primesim_inactive_short_rc_vol_tol:
saPrimeSimOptionprimesiminactiv eshortrcvoltageUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimininclude device	string	saTestbe nch		PrimeSim option primesim_include_device:
saPrimeSimOptionprimesimininclude deviceUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimininclude instance	string	custom		PrimeSim option primesim_include_instance: Includes the specified instances in the simulation. All other instances are ignored.
saPrimeSimOptionprimesimininclude instanceflow	string	saTestbe nch		PrimeSim option primesim_include_instance_flow:
saPrimeSimOptionprimesimininclude instanceflowUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimininclude instanceUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimindn	string	custom		PrimeSim option primesim_indn: Specifies whether the PrimeSim tool uses a Norton equivalent or a more accurate formulation to model a simple inductor.
saPrimeSimOptionprimesimindnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesiminfoLimit	string	saTestbench		PrimeSim option primesim_info_limit: Sets the number of ""INFO:"" messages to a limited number of user-specified lines.
saPrimeSimOptionprimesiminfoLimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimiovecabsValue	string	custom	0	PrimeSim option primesim_iovec_abs_value: Treats all the time values in the vector file as absolute time.
saPrimeSimOptionprimesimiovecabsValueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimioveckeepNode	string	saTestbench		PrimeSim option primesim_iovec_keep_node:
saPrimeSimOptionprimesimioveckeepNodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimiovecoptions	string	custom		PrimeSim option primesim_iovec_option: Specifies whether PrimeSim accuracy options can be used inside a vector file using the fscript utility fset command.
saPrimeSimOptionprimesimiovecoptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimiovecvih	string	custom		PrimeSim option primesim_iovec_vih: Sets the logiclv outside of a vector file.
saPrimeSimOptionprimesimiovecvihUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimiovecvil	string	custom		PrimeSim option primesim_iovec_vil: Sets the logiclv outside of a vector file.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimiovecv lUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimiovec voh	string	custom		PrimeSim option primesim_iovec_voh: Sets the default voh value for the vector file.
saPrimeSimOptionprimesimiovecv ohUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimiovec vol	string	custom		PrimeSim option primesim_iovec_vol: Sets the default vol value for the vector file.
saPrimeSimOptionprimesimiovecv olUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimiprbt min	string	saTestbe nch		PrimeSim option primesim_iprbtmin:
saPrimeSimOptionprimesimiprbtmi nUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimiprbtol	string	custom	1e-12	PrimeSim option primesim_iprbtol: Sets the current tolerance for the current print out.
saPrimeSimOptionprimesimiprbtol UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimiprobe eaflevel	string	custom		PrimeSim option primesim_iprobe_leaf_level: Specifies whether to output device currents at the lowest level of hierarchy in the design.
saPrimeSimOptionprimesimiprobe eaflevelUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimiprobe scope	string	saTestbe nch		PrimeSim option primesim_iprobe_scope:
saPrimeSimOptionprimesimiprobe scopeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimipwltol	string	saTestbe nch	0	PrimeSim option primesim_ipwltol:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimipwltol UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimiremdebug	string	saTestbench		PrimeSim option primesim_irem_debug:
saPrimeSimOptionprimesimiremdebug UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimiremflow	string	saTestbench	0	PrimeSim option primesim_irem_flow:
saPrimeSimOptionprimesimiremflow UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimirem rms	string	custom	0	PrimeSim option primesim_irem_rms: Calculate RMS value of the current and report it as AC current.
saPrimeSimOptionprimesimirem rmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimirem timeStep	string	saTestbench		PrimeSim option primesim_irem_time_step:
saPrimeSimOptionprimesimirem timeStepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimisolate dvsrcres	string	custom		PrimeSim option primesim_isolated_vsrc_res: Specifies whether to detect floating voltage sources which are referenced by other current controlled sources and add a shunt resistance of 1M to them.
saPrimeSimOptionprimesimisolate dvsrcresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimkeep0 vdcvs	string	custom	0	PrimeSim option primesim_keep_0v_dcvs: Keeps 0v DC voltage sources in the simulation database.
saPrimeSimOptionprimesimkeep0 vdcvsop	string	custom	0	PrimeSim option primesim_keep_0v_dcvs_op: Keeps 0v DC voltage sources for .op analysis.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimkeep0vdcvsopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimkeep0vdcvsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimkeepdevice	string	saTestbench		PrimeSim option primesim_keep_device:
saPrimeSimOptionprimesimkeepdeviceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimkeephier	string	saTestbench		PrimeSim option primesim_keeplier:
saPrimeSimOptionprimesimkeephierUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimkeepnode	string	saTestbench		PrimeSim option primesim_keep_node:
saPrimeSimOptionprimesimkeepnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimkeepzeroparms	string	custom	0	PrimeSim option primesim_keepzeroparms: Use zero values for PS, PD, AS, and AD parameters for BSIM models.
saPrimeSimOptionprimesimkeepzeroparmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlatchalgmaxiter	string	saTestbench	5	PrimeSim option primesim_latch_alg_max_iter:
saPrimeSimOptionprimesimlatchalgmaxiterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlayoutonlyoptimization	string	saTestbench	3	PrimeSim option primesim_layout_only_optimization:
saPrimeSimOptionprimesimlayoutonlyoptimizationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcdcutnode	string	saTestbench		PrimeSim option primesim_lcd_cutnode:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimlcdcutn odeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcdm ode	string	saTestbe nch		PrimeSim option primesim_lcd_mode:
saPrimeSimOptionprimesimlcdmo deaccuracy	string	saTestbe nch		PrimeSim option primesim_lcd_mode_accuracy:
saPrimeSimOptionprimesimlcdmo deaccuracyUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcdmo dealg	string	saTestbe nch	2	PrimeSim option primesim_lcd_mode_alg:
saPrimeSimOptionprimesimlcdmo dealgUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcdmo decutallva	string	saTestbe nch	0	PrimeSim option primesim_lcd_mode_cut_all_va:
saPrimeSimOptionprimesimlcdmo decutallvaUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcdmo decutgate	string	saTestbe nch	2	PrimeSim option primesim_lcd_mode_cut_gate:
saPrimeSimOptionprimesimlcdmo decutgateUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcdmo defix	string	saTestbe nch	0	PrimeSim option primesim_lcd_mode_fix:
saPrimeSimOptionprimesimlcdmo defixUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcdmo degptmax	string	saTestbe nch	2e-5	PrimeSim option primesim_lcd_mode_gpt_max:
saPrimeSimOptionprimesimlcdmo degptmaxUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcdmo dehssforpdsfail	string	saTestbe nch	1	PrimeSim option primesim_lcd_mode_hss_for_pds_fail:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimlcdmo dehssforpdsfailUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcdmo departition	string	saTestbe nch	0	PrimeSim option primesim_lcd_mode_partition:
saPrimeSimOptionprimesimlcdmo departitionUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcdmo deplus	string	saTestbe nch	1	PrimeSim option primesim_lcd_mode_plus:
saPrimeSimOptionprimesimlcdmo deplusUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcdmo deUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcdpan elpwrmesh	string	saTestbe nch		PrimeSim option primesim_lcd_panel_pwrmesh:
saPrimeSimOptionprimesimlcdpan elpwrmeshUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcdsioi evtolscale	string	saTestbe nch	5.0	PrimeSim option primesim_lcd_sio_jevtolscale:
saPrimeSimOptionprimesimlcdsioi evtolscaleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlcduse spd	string	saTestbe nch	1	PrimeSim option primesim_lcd_use_spd:
saPrimeSimOptionprimesimlcduse spdUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimleakag emode	string	custom	0	PrimeSim option primesim_leakage_mode: Uses more conservative leakage tolerances for better accuracy.
saPrimeSimOptionprimesimleakag emodeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlegacy duprule	string	saTestbe nch		PrimeSim option primesim_legacy_dup_rule:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimlegacydupruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlibinfo log	string	saTestbench	0	PrimeSim option primesim_lib_info_log:
saPrimeSimOptionprimesimlibinfo logUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlist	string	saTestbench		PrimeSim option primesim_list:
saPrimeSimOptionprimesimlistnoisesources	string	saTestbench		PrimeSim option primesim_list_noisesources:
saPrimeSimOptionprimesimlistnoisesourcesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimlistnoisesources is loaded.
saPrimeSimOptionprimesimlistUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimloadmodel	string	custom	<file path>	PrimeSim option primesim_loadmodel: Sets the capacitive load model that a partition output drives.
saPrimeSimOptionprimesimloadmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimloose_lte_errtol	string	saTestbench	1.2	PrimeSim option primesim_loose_lte_errtol:
saPrimeSimOptionprimesimloose_lte_errtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlprobe_hiz	string	saTestbench		PrimeSim option primesim_lprobe_hiz: Specifies whether to check the Hi-Z node and display the ""Z"" state in the waveform.
saPrimeSimOptionprimesimlprobe_hizUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlprobe_vh	string	custom		PrimeSim option primesim_lprobe_vh: Sets the high threshold value for signals with .LPROBE statement.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimlprobe vhUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlprob evl	string	custom		PrimeSim option primesim_lprobe_vl: Sets the low threshold value for signals with .LPROBE statement.
saPrimeSimOptionprimesimlprobe vlUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlptwei ght	string	saTestbe nch		PrimeSim option primesim_lpt_weight:
saPrimeSimOptionprimesimlptweig htUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlsfform atchars	string	custom		PrimeSim option primesim_lsf_format_chars: Allows usage of 3rd-party Verilog-A special characters.
saPrimeSimOptionprimesimlsfform atcharsUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimltdvsc ale	string	saTestbe nch		PrimeSim option primesim_lte_dv_scale:
saPrimeSimOptionprimesimltdvsc aleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimlteratio scale	string	saTestbe nch	1	PrimeSim option primesim_lteratio_scale:
saPrimeSimOptionprimesimlteratio scaleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmakel ocalvarspersistent	string	saTestbe nch	0	PrimeSim option primesim_make_local_vars_persistent:
saPrimeSimOptionprimesimmakel ocalvarspersistentUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmakeu niquemodel	string	saTestbe nch	0	PrimeSim option primesim_make_unique_model:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimmakeuniquemodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmakeuniquemosmodel	string	saTestbench	0	PrimeSim option primesim_make_unique_mos_model:
saPrimeSimOptionprimesimmakeuniquemosmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmapprbport	string	custom		PrimeSim option primesim_map_prbport: Maps probe statements from :[dgsb] to v[1234] syntax.
saPrimeSimOptionprimesimmapprbportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmapprwlztopwl	string	saTestbench	0	PrimeSim option primesim_map_pwlz_to_pwl:
saPrimeSimOptionprimesimmapprwlztopwlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmapvalueonlyiparam	string	saTestbench	0	PrimeSim option primesim_map_value_only_iparam:
saPrimeSimOptionprimesimmapvalueonlyiparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmaxicout	string	custom	1000000	PrimeSim option primesim_maxicout: Sets maximum number of node voltages included in the .ic file.
saPrimeSimOptionprimesimmaxicoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmaxparallel	string	saTestbench		PrimeSim option primesim_max_parallel: For parallel simulation in PrimeSim Pro mode with multiple CPUs
saPrimeSimOptionprimesimmaxparallelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmaxswapallowed	string	custom		PrimeSim option primesim_max_swap_allowed: Controls the maximum amount of swap memory that can be used during a simulation.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimmaxsw apallowedUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmaxwi dthtol	string	custom		PrimeSim option primesim_max_width_tol: Sets tolerance range for transistor width when it exceeds max. defined width.
saPrimeSimOptionprimesimmaxwi dthtolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmcbise cwinscale	string	saTestbe nch	0	PrimeSim option primesim_mc_bisec_win_scale:
saPrimeSimOptionprimesimmcbise cwinscaleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmcbr ief	string	custom	1	PrimeSim option primesim_mcbrief: Limits Monte Carlo information in log file.
saPrimeSimOptionprimesimmcbrie fUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmcno minalsimulation	string	custom		PrimeSim option primesim_mc_nominal_simulation: Sets the behavior of simple random sampling (SRS) for the first Monte Carlo sweep.
saPrimeSimOptionprimesimmcno minalsimulationUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmcrepl acefailedmeas	string	custom		PrimeSim option primesim_mc_replace_failed_meas: Specifies whether to continue to run Monte Carlo sweeps until the requested number of runs (MONTE=num) have successful measurements.
saPrimeSimOptionprimesimmcrepl acefailedmeasUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmcs eed	string	custom		PrimeSim option primesim_mcseed: Provides a seed to produce the same sequence of random numbers in Monte Carlo simulation.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimmcseedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmcsigma_scale	string	custom		PrimeSim option primesim_mc_sigma_scale: Scales the Monte Carlo distribution.
saPrimeSimOptionprimesimmcsigma_scaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmcstats_report	string	custom		PrimeSim option primesim_mc_stats_report: Controls printing of Monte Carlo statistics.
saPrimeSimOptionprimesimmcstats_reportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmeasfrom_to	string	custom		PrimeSim option primesim_meas_from_to: Specifies whether the FROM and TO parameters for the TARG parameter of a measurement are applied to the TRIG parameter of the measurement.
saPrimeSimOptionprimesimmeasfrom_toUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmeasformat	string	custom	0	PrimeSim option primesim_measout: Controls the measurement file format.
saPrimeSimOptionprimesimmeasformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmeastol_scale	string	custom		PrimeSim option primesim_meastol_scale: Specifies the compression factor of internally saved data when performing runtime measurement.
saPrimeSimOptionprimesimmeastol_scaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmerge_channel_connected_pwrblk	string	saTestbench	1	PrimeSim option primesim_merge_channel_connected_pwrblk:
saPrimeSimOptionprimesimmerge_channel_connected_pwrblkUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimmergedmeasfile	string	custom		PrimeSim option primesim_merged_meas_file: Specifies whether to output separate .mt0 files or a single merged .mt0 file for sweep and bisection.
saPrimeSimOptionprimesimmergedmeasfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmergesdb	string	custom		PrimeSim option primesim_merge_fsdb: Specifies whether to merge the PrimeSim tool's FSDB output with a digital FSDB file for mixed-signal simulation using the VCS PrimeSim AMS tool.
saPrimeSimOptionprimesimmergesdbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmergehdl	string	saTestbench	0	PrimeSim option primesim_merge_hdl:
saPrimeSimOptionprimesimmergehdlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmergeparmosdio	string	custom		PrimeSim option primesim_merge_parmosdio: Optimizes MOSFET device instances that are in parallel.
saPrimeSimOptionprimesimmergeparmosdioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmergepininstance	string	custom		PrimeSim option primesim_merge_pininstance: Optimizes subcircuit instances that are in parallel.
saPrimeSimOptionprimesimmergepininstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmergevectorerrmsg	string	custom		PrimeSim option primesim_merge_vector_errmsg: Specifies whether to merge the .err files from multiple runs into a single .err file.
saPrimeSimOptionprimesimmergevectorerrmsgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimmethod	string	custom	TRAP	PrimeSim option primesim_method: Sets the numerical integration method used during a transient analysis.
saPrimeSimOptionprimesimmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimminchannelcutdevcnt	string	saTestbench	15	PrimeSim option primesim_min_channel_cut_dev_cnt:
saPrimeSimOptionprimesimminchannelcutdevcntUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimminchannelcutdevratio	string	saTestbench	0.2	PrimeSim option primesim_min_channel_cut_dev_ratio:
saPrimeSimOptionprimesimminchannelcutdevratioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmnares	string	saTestbench		PrimeSim option primesim_mnares:
saPrimeSimOptionprimesimmnaresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmode	string	custom	promd	PrimeSim option primesim_mode: Sets the Simulation mode
saPrimeSimOptionprimesimmodel	string	custom	4.5	PrimeSim option primesim_model: Sets the modeling method of the MOSFETs.
saPrimeSimOptionprimesimmodelduprule	string	saTestbench	0	PrimeSim option primesim_model_dup_rule:
saPrimeSimOptionprimesimmodeldupruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmodelverificationmode	string	custom	0	PrimeSim option primesim_model_verification_mode: Use tighter simulation settings for simulations with model qualification.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimmodel verificationmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmode UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmoduleinstance	string	custom		PrimeSim option primesim_module_instance: Applies a 3DIC module for a regular netlist without modifying the input netlist.
saPrimeSimOptionprimesimmoduleinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmonitor	string	custom		PrimeSim option primesim_monitor: Provides CPU monitoring functionality when the PrimeSim tool is running on a server.
saPrimeSimOptionprimesimmonitorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmoscapcut	string	custom		PrimeSim option primesim_moscapcut: Specifies when the MOS capacitor should be cut for partitioning based on its estimated capacitance value.
saPrimeSimOptionprimesimmoscapcutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmosfet fastprobelx34	string	custom		PrimeSim option primesim_mosfet_fast_probe_lx34: Speeds up probing the LX34 MOS parameter for the level=129 CMI model.
saPrimeSimOptionprimesimmosfet fastprobelx34UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmosmacromodel	string	saTestbench	0	PrimeSim option primesim_mos_macro_model:
saPrimeSimOptionprimesimmosmacromodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmparcheck	string	custom	0	PrimeSim option primesim_mparcheck: Determines if MOSFET model parameters will be checked.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimparcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimmscale	string	saTestbench	-1	PrimeSim option primesim_mscale:
saPrimeSimOptionprimesimmscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnegres	string	custom	1	PrimeSim option primesim_negres: Keeps negative resistors in the netlist.
saPrimeSimOptionprimesimnegresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnewfcap_flow	string	saTestbench	0	PrimeSim option primesim_new_fcflow:
saPrimeSimOptionprimesimnewfcap_flowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnewfind_model	string	saTestbench		PrimeSim option primesim_new_find_model:
saPrimeSimOptionprimesimnewfind_modelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnewiprobe	string	saTestbench		PrimeSim option primesim_new_iprobe:
saPrimeSimOptionprimesimnewiprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnewoutput	string	saTestbench	3	PrimeSim option primesim_new_output:
saPrimeSimOptionprimesimnewoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnewqueue	string	saTestbench		PrimeSim option primesim_new_queue:
saPrimeSimOptionprimesimnewqueueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimnewresolve	string	saTestbench	0	PrimeSim option primesim_new_resolve:
saPrimeSimOptionprimesimnewresolveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnewxprobe	string	saTestbench	0	PrimeSim option primesim_new_xprobe:
saPrimeSimOptionprimesimnewxprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnoiseformat	string	custom		PrimeSim option primesim_noise_format: Controls the format of the .pn0 output file.
saPrimeSimOptionprimesimnoiseformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnoiseoff	string	custom		PrimeSim option primesim_noise_off: Disable noise generation
saPrimeSimOptionprimesimnoiseoffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnoiseon	string	custom		PrimeSim option primesim_noise_on: Enable noise generation
saPrimeSimOptionprimesimnoiseonUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnoshorting	string	saTestbench	0	PrimeSim option primesim_noshorting:
saPrimeSimOptionprimesimnoshortingUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnoswap	string	custom		PrimeSim option primesim_no_swap: Controls whether disk swap can be used when the simulation runs out of memory.
saPrimeSimOptionprimesimnoswapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimnpcmax	string	custom		PrimeSim option primesim_npc_max: Specifies that the PrimeSim SPICE tool should take extra effort to ensure that simulation results are consistent across a different number of threads.
saPrimeSimOptionprimesimnpcmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnrtol	string	saTestbench		PrimeSim option primesim_nrtol:
saPrimeSimOptionprimesimnrtolscale	string	saTestbench		PrimeSim option primesim_nrtol scale:
saPrimeSimOptionprimesimnrtolscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnrtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnummaxdevforoptimizepartition	string	saTestbench		PrimeSim option primesim_num_max_dev_for_optimize_partition:
saPrimeSimOptionprimesimnummaxdevforoptimizepartitionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnummeaslog	string	custom		PrimeSim option primesim_num_meas_log: Limits number of measurement results output to the screen and log file.
saPrimeSimOptionprimesimnummeaslogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimnummeasperline	string	custom	0	PrimeSim option primesim_num_meas_per_line: Outputs measurement values on multiple lines.
saPrimeSimOptionprimesimnummeasperlineUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledaccuratewaveform	string	saTestbench	0	PrimeSim option primesim_oled_accurate_waveform:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimoledacuratewaveformUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledcktsize	string	saTestbench	-1	PrimeSim option primesim_oled_ckt_size:
saPrimeSimOptionprimesimoledcktsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoleddata signal	string	saTestbench		PrimeSim option primesim_oled_data_signal:
saPrimeSimOptionprimesimoleddata signalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledfullpanel	string	saTestbench	0	PrimeSim option primesim_oled_fullpanel:
saPrimeSimOptionprimesimoledfullpanelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledglobalnode	string	saTestbench		PrimeSim option primesim_oled_global_node:
saPrimeSimOptionprimesimoledglobalnoderatio	string	saTestbench	1.	PrimeSim option primesim_oled_global_node_ratio:
saPrimeSimOptionprimesimoledglobalnoderatioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledglobalnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledmainnode	string	saTestbench		PrimeSim option primesim_oled_main_node:
saPrimeSimOptionprimesimoledmainnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledmainnodevalue	string	saTestbench	1e-18	PrimeSim option primesim_oled_main_node_value:
saPrimeSimOptionprimesimoledmainnodevalueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimoledmanualpartition	string	saTestbench	0	PrimeSim option primesim_oled_manual_partition:
saPrimeSimOptionprimesimoledmanualpartitionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledmaxsynch	string	saTestbench	1e-6	PrimeSim option primesim_oled_max_sync_h:
saPrimeSimOptionprimesimoledmaxsynchUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledmeasurerow	string	saTestbench		PrimeSim option primesim_oled_measure_row:
saPrimeSimOptionprimesimoledmeasurerowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledmeshpower	string	saTestbench		PrimeSim option primesim_oled_mesh_power:
saPrimeSimOptionprimesimoledmeshpowerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledmode	string	saTestbench		PrimeSim option primesim_oled_mode:
saPrimeSimOptionprimesimoledmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledmultirate	string	saTestbench	1	PrimeSim option primesim_oled_multirate:
saPrimeSimOptionprimesimoledmultirateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimolednumactiverow	string	saTestbench	16	PrimeSim option primesim_oled_num_active_row:
saPrimeSimOptionprimesimolednumactiverowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimolednumcol	string	saTestbench	-1	PrimeSim option primesim_oled_num_col:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimolednumcolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimolednumrow	string	saTestbench	-1	PrimeSim option primesim_oled_num_row:
saPrimeSimOptionprimesimolednumrowpernp	string	saTestbench	16	PrimeSim option primesim_oled_num_row_per_np:
saPrimeSimOptionprimesimolednumrowpernpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimolednumrowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledpixeltype	string	saTestbench	2	PrimeSim option primesim_oled_pixel_type:
saPrimeSimOptionprimesimoledpixeltypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledprintboundarynode	string	saTestbench	0	PrimeSim option primesim_oled_print_boundary_node:
saPrimeSimOptionprimesimoledprintboundarynodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledremovepurencodecap	string	saTestbench	0	PrimeSim option primesim_oled_remove_purencode_cap:
saPrimeSimOptionprimesimoledremovepurencodecapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledscan	string	saTestbench		PrimeSim option primesim_oled_scan_signal:
saPrimeSimOptionprimesimoledscanUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledshowreduction	string	saTestbench	0	PrimeSim option primesim_oled_show_reduction:
saPrimeSimOptionprimesimoledshowreductionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimoledsolver	string	saTestbench	0	PrimeSim option primesim_oled_solver:
saPrimeSimOptionprimesimoledsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoledspiceopt	string	saTestbench	1	PrimeSim option primesim_oled_spice_opt:
saPrimeSimOptionprimesimoledspiceoptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimopparasiticcapacitance	string	custom		PrimeSim option primesim_op_parasitic_capacitance: Specifies whether to output parasitic passive capacitors into the OP result file.
saPrimeSimOptionprimesimopparasiticcapacitanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimopregiondisplay	string	custom		PrimeSim option primesim_op_region_display: Specifies which values to use for different regions of MOS operation when using waveform display tools such as PrimeWave Design Environment WaveView.
saPrimeSimOptionprimesimopregiondisplayUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoptimizeflat	string	saTestbench		PrimeSim option primesim_optimize_flat:
saPrimeSimOptionprimesimoptimizeflatmaxmosfet	string	saTestbench		PrimeSim option primesim_optimize_flat_max_mosfet:
saPrimeSimOptionprimesimoptimizeflatmaxmosfetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimoptimizeflatmaxmosfet is loaded.
saPrimeSimOptionprimesimoptimizeflatmininstforflat	string	saTestbench		PrimeSim option primesim_optimize_flat_min_inst_for_flat:
saPrimeSimOptionprimesimoptimizeflatmininstforflatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimoptimiz eflatminsizeforflat	string	saTestbe nch		PrimeSim option primesim_optimize_flat_min_size_for_flat:
saPrimeSimOptionprimesimoptimiz eflatminsizeforflatUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoptimiz eflatUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoptimiz eflatuppkt	string	saTestbe nch		PrimeSim option primesim_optimize_flat_uppkt:
saPrimeSimOptionprimesimoptimiz eflatuppktUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoptimiz eignore	string	saTestbe nch		PrimeSim option primesim_optimize_ignore:
saPrimeSimOptionprimesimoptimiz eignoreUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoptimiz emhash	string	saTestbe nch	0	PrimeSim option primesim_optimize_mhash:
saPrimeSimOptionprimesimoptimiz emhashUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoptimiz epartition	string	saTestbe nch		PrimeSim option primesim_optimize_partition:
saPrimeSimOptionprimesimoptimiz epartitionUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoptimiz epat	string	saTestbe nch	0	PrimeSim option primesim_optimize_pat:
saPrimeSimOptionprimesimoptimiz epatUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoptimiz epdn	string	saTestbe nch	1	PrimeSim option primesim_optimize_pdn:
saPrimeSimOptionprimesimoptimiz epdnnonportmerginglimit	string	saTestbe nch	10	PrimeSim option primesim_optimize_pdn_nonport_merging_l imit:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimoptimizepdnportmerginglimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoptimizepdnportmerginglimit	string	saTestbench	30	PrimeSim option primesim_optimize_pdn_port_merging_limit:
saPrimeSimOptionprimesimoptimizepdnportmerginglimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoptimizepdnportmergingmethod	string	saTestbench	0	PrimeSim option primesim_optimize_pdn_port_merging_method:
saPrimeSimOptionprimesimoptimizepdnportmergingmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoptimizepdnsmallrth	string	saTestbench		PrimeSim option primesim_optimize_pdn_smallrth:
saPrimeSimOptionprimesimoptimizepdnsmallrthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoptimizepdnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoutput	string	custom		PrimeSim option primesim_output: Sets the output file format for saving transient analysis results.
saPrimeSimOptionprimesimoutputfilename_type	string	custom	1	PrimeSim option primesim_output_fname_type: Defines the naming convention for output files with the netlist has an .alter and/or .temp sweep parameter.
saPrimeSimOptionprimesimoutputfilename_typeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoutputgzip	string	custom		PrimeSim option primesim_output_gzip: Enables gzip file compression of the output files.
saPrimeSimOptionprimesimoutputgzipUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimoutput optimize	string	saTestbench		PrimeSim option primesim_output_optimize:
saPrimeSimOptionprimesimoutput optimizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoutput range	string	custom		PrimeSim option primesim_output_range: Limits output of transient results of waveforms to the waveform file.
saPrimeSimOptionprimesimoutput rangeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimoutput UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimparam duprule	string	saTestbench	0	PrimeSim option primesim_param_dup_rule:
saPrimeSimOptionprimesimparam dupruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimparhier mode	string	custom		PrimeSim option primesim_parhier_mode: Specifies how the SPICE-compatible option parhier functions when set to LOCAL.
saPrimeSimOptionprimesimparhier modeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpartition	string	custom		PrimeSim option primesim_partition: Specifies how partitioning is done.
saPrimeSimOptionprimesimpartitionfixgroundediode	string	saTestbench		PrimeSim option primesim_partition_fix_grounded_diode:
saPrimeSimOptionprimesimpartitionfixgroundediodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpartitionfixvcvs	string	saTestbench	0	PrimeSim option primesim_partition_fix_vcvs:
saPrimeSimOptionprimesimpartitionfixvcvsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpartitionmode	string	saTestbench	1	PrimeSim option primesim_partition_mode:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimpartitionmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpartitiontune	string	saTestbench	3	PrimeSim option primesim_partition_tune:
saPrimeSimOptionprimesimpartitiontuneUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpartitionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpdn	string	saTestbench		PrimeSim option primesim_pdn:
saPrimeSimOptionprimesimpdneventgrid	string	saTestbench	0	PrimeSim option primesim_pdn_event_grid:
saPrimeSimOptionprimesimpdneventgridmode	string	saTestbench	0	PrimeSim option primesim_pdn_event_grid_mode:
saPrimeSimOptionprimesimpdneventgridmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpdneventgridrcnum	string	saTestbench	0	PrimeSim option primesim_pdn_event_grid_rcnum:
saPrimeSimOptionprimesimpdneventgridrcnumUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpdneventgridUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpdnnet	string	saTestbench	1	PrimeSim option primesim_pdn_net:
saPrimeSimOptionprimesimpdnnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpdnopt	string	saTestbench		PrimeSim option primesim_pdn_opt:
saPrimeSimOptionprimesimpdnoptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimpdnopt is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimpdnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimphase noiselorentz	string	saTestbench		PrimeSim option primesim_phasenoise_lorentz:
saPrimeSimOptionprimesimphase noiselorentzUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimphasenoiselorentz is loaded.
saPrimeSimOptionprimesimphase noiseminharmfreqoffset	string	saTestbench		PrimeSim option primesim_phasenoise_min_harmfreq_offset:
saPrimeSimOptionprimesimphase noiseminharmfreqoffsetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpinst inp	string	custom		PrimeSim option primesim_pinst_in_p: Specifies how the p() power reporting function works when Probing and Measuring.
saPrimeSimOptionprimesimpinstinpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpmsminsize	string	saTestbench	200.0	PrimeSim option primesim_pms_minsize:
saPrimeSimOptionprimesimpmsminsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpmspartitionctrl	string	saTestbench	0	PrimeSim option primesim_pms_partition_ctrl:
saPrimeSimOptionprimesimpmspartitionctrlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpmsplus	string	saTestbench		PrimeSim option primesim_pms_plus:
saPrimeSimOptionprimesimpmsplusUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimpostl	string	custom	0	PrimeSim option primesim_postl: Sets the level of acceleration to use when performing post-layout analog simulation on RC-extracted circuits.
saPrimeSimOptionprimesimpostlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpoutlevellast	string	saTestbench	4	PrimeSim option primesim_pout_level_last:
saPrimeSimOptionprimesimpoutlevellastUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprbexprvar	string	custom	1	PrimeSim option primesim_prbexprvar: Determines whether to make any signals in the expression of .probe out.
saPrimeSimOptionprimesimprbexprvarUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprbport	string	custom	1	PrimeSim option primesim_prbport: Determines whether port voltages will be probed, depending on tolerance.
saPrimeSimOptionprimesimprbportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprbtmin	string	custom		PrimeSim option primesim_prb_tmin: Specifies that the waveform file records data points only after the minimum transient time set by this option has passed.
saPrimeSimOptionprimesimprbtminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprecisionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprelayoutmodels	string	custom	0	PrimeSim option primesim_prelayout_models: Sets which model PrimeSim should use.
saPrimeSimOptionprimesimprelayoutmodelsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimprintglobalparam	string	custom		PrimeSim option primesim_print_global_param: Prints global parameter names and resolved values.
saPrimeSimOptionprimesimprintglobalparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprintmaxconnnode	string	custom	20	PrimeSim option primesim_print_max_con_node: Identifies nodes with greatest number of connections for connectivity report.
saPrimeSimOptionprimesimprintmaxconnnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprintperiod	string	custom		PrimeSim option primesim_print_period: Defines the fixed interval at which the .print command will print to the output file.
saPrimeSimOptionprimesimprintperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprintto probe	string	custom	0	PrimeSim option primesim_print_to_probe: Converts all .print statements to .probe statements.
saPrimeSimOptionprimesimprintto probeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprllopt	string	custom		PrimeSim option primesim_prll_opt: Controls how the -np X command line option functions (see Command Line Options for Running Multi-CPU Simulations).
saPrimeSimOptionprimesimprlloptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprobeallnode	string	saTestbench	0	PrimeSim option primesim_probe_all_node:
saPrimeSimOptionprimesimprobeallnodefilter	string	saTestbench		PrimeSim option primesim_probe_all_node_filter:
saPrimeSimOptionprimesimprobeallnodefilterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimprobeallnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprobe_matchfullname	string	saTestbench	0	PrimeSim option primesim_probe_match_fullname:
saPrimeSimOptionprimesimprobe_matchfullnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprobepassivedevice	string	custom	0	PrimeSim option primesim_probe_passive_device: Probes passive devices like R/C..
saPrimeSimOptionprimesimprobepassivedeviceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprobeprotected	string	saTestbench		PrimeSim option primesim_probe_protected:
saPrimeSimOptionprimesimprobeprotectedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprodcalg	string	custom		PrimeSim option primesim_pro_dcalg: Sets the approach for DC convergence (Pro mode only).
saPrimeSimOptionprimesimprodcalgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprofile	string	custom	1	PrimeSim option primesim_profile: Generates profile data in a file after transient analysis..
saPrimeSimOptionprimesimprofileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimprogressprintmemusage	string	saTestbench		PrimeSim option primesim_progress_print_memusage:
saPrimeSimOptionprimesimprogressprintmemusageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimprogressprintmemusage is loaded.
saPrimeSimOptionprimesimpronqs	string	saTestbench	0	PrimeSim option primesim_pronqs:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimprongs UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimproshe	string	saTestbench	0	PrimeSim option primesim_proshe:
saPrimeSimOptionprimesimproshe UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpseud otrandbg	string	custom		PrimeSim option primesim_pseudotrandbg: Controls whether an FSDB file is generated from pseudo-transient analysis.
saPrimeSimOptionprimesimpseud otrandbgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpt0for mat	string	custom		PrimeSim option primesim_pt0_format: Changes the .print output default format into a list format.
saPrimeSimOptionprimesimpt0for matUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpvacro ssttol	string	custom		PrimeSim option primesim_pva_cross_ttol: Specifies the PrimeSim / Portable Verilog-A Engine timing accuracy for the CROSS and ABOVE functions.
saPrimeSimOptionprimesimpvacro ssttolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpvaf low	string	custom		PrimeSim option primesim_pva_flow: Simulates Verilog-A Elements using the Portable Verilog-A Engine compatible with PrimeSim HSPICE.
saPrimeSimOptionprimesimpvaflo wUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpvami ntranstime	string	saTestbench		PrimeSim option primesim_pva_min_trans_time:
saPrimeSimOptionprimesimpvami ntranstimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimpvamintransunits	string	saTestbench	0	PrimeSim option primesim_pva_min_trans_tunits:
saPrimeSimOptionprimesimpvamintransunitsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpvaoptport	string	saTestbench		PrimeSim option primesim_pva_opt_port: Specifies whether to treat the Verilog-A port as non-voltage
saPrimeSimOptionprimesimpvaoptportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwlacc	string	saTestbench	0	PrimeSim option primesim_pwl_acc:
saPrimeSimOptionprimesimpwlaccUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwlreltol	string	saTestbench	1.e-4	PrimeSim option primesim_pwlreltol:
saPrimeSimOptionprimesimpwlreltolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwlr_end	string	custom		PrimeSim option primesim_pwl_r_end: Changes the meaning of parameter R for PWL source.
saPrimeSimOptionprimesimpwlr_endUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwrblock	string	custom	1	PrimeSim option primesim_pwrblock: Detects the parasitics in the power network.
saPrimeSimOptionprimesimpwrblockexclude_node	string	saTestbench		PrimeSim option primesim_pwrblock_exclude_node:
saPrimeSimOptionprimesimpwrblockexclude_nodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimpwrblockexclude_node is loaded.
saPrimeSimOptionprimesimpwrblockexclude_subckt	string	saTestbench		PrimeSim option primesim_pwrblock_exclude_subckt:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimpwrblo ckexcludesubcktUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwrblo ckincludemoscap	string	saTestbe nch		PrimeSim option primesim_pwrblock_include_moscap:
saPrimeSimOptionprimesimpwrblo ckincludemoscapUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwrblo ckplus	string	saTestbe nch	0	PrimeSim option primesim_pwrblock_plus:
saPrimeSimOptionprimesimpwrblo ckplusnumarrayinst	string	saTestbe nch	128	PrimeSim option primesim_pwrblock_plus_num_array_inst:
saPrimeSimOptionprimesimpwrblo ckplusnumarrayinstUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwrblo ckplusnumtotalmos	string	saTestbe nch	256	PrimeSim option primesim_pwrblock_plus_num_total_mos:
saPrimeSimOptionprimesimpwrblo ckplusnumtotalmosUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwrblo ckplusUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwrblo ckterminalprefix	string	saTestbe nch		PrimeSim option primesim_pwrblock_terminal_prefix:
saPrimeSimOptionprimesimpwrblo ckterminalprefixUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwrblo ckUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwrblo ckusergivencandonly	string	saTestbe nch		PrimeSim option primesim_pwrblock_user_given_cand_only:
saPrimeSimOptionprimesimpwrblo ckusergivencandonlyUncheckLoca lized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwrloa dmodel	string	custom		PrimeSim option primesim_pwrloadmodel: Enables a power load model especially well-suited for power supply networks.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimpwrloadmodelenhanced	string	saTestbench	1	PrimeSim option primesim_pwrloadmodel_enhanced:
saPrimeSimOptionprimesimpwrloadmodelenhancedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwrloadmodelrlcd	string	saTestbench	2	PrimeSim option primesim_pwrloadmodel_rlcd:
saPrimeSimOptionprimesimpwrloadmodelrlcdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwrloadmodelsfc	string	saTestbench	1	PrimeSim option primesim_pwrloadmodel_sfc:
saPrimeSimOptionprimesimpwrloadmodelsfcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwrloadmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimpwrtol	string	custom	3mV	PrimeSim option primesim_pwrtol: Specifies the voltage tolerance to control an event between a power block partition and the other partitions.
saPrimeSimOptionprimesimpwrtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimqllevel	string	custom	1	PrimeSim option primesim_qlevel: Controls the tolerance of the signal level accuracy.
saPrimeSimOptionprimesimqllevelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimra	string	saTestbench	0	PrimeSim option primesim_ra:
saPrimeSimOptionprimesimracmd	string	custom		PrimeSim option primesim_ra_cmd: Specifies the output formats to be reported and provides backward compatibility to read the command format supported by Titan/fscript.
saPrimeSimOptionprimesimracmdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimradcmap	string	saTestbench		PrimeSim option primesim_ra_dcmmap:
saPrimeSimOptionprimesimradcmUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimranet	string	custom		PrimeSim option primesim_ra_net: Specifies the nets to report for IR Drop output.
saPrimeSimOptionprimesimranetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrapresimtime	string	saTestbench		PrimeSim option primesim_ra_presimtime:
saPrimeSimOptionprimesimrapresimtimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrasamplemethod	string	saTestbench		PrimeSim option primesim_ra_sample_method:
saPrimeSimOptionprimesimrasamplemethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrasamplerate	string	saTestbench		PrimeSim option primesim_ra_sample_rate:
saPrimeSimOptionprimesimrasamplerateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimratcl	string	custom		PrimeSim option primesim_ra_tcl: Reads a PrimeSim XA RA Tcl file.
saPrimeSimOptionprimesimratclUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimratwindow	string	saTestbench		PrimeSim option primesim_ra_twindow:
saPrimeSimOptionprimesimratwindowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimraUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimrawav eformsplit	string	saTestbe nch		PrimeSim option primesim_ra_waveform_split:
saPrimeSimOptionprimesimrawav eformsplitUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrclamp	string	saTestbe nch		PrimeSim option primesim_rclamp:
saPrimeSimOptionprimesimrclamp UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrcred	string	custom	Default	PrimeSim option primesim_rcred: Sets the level of acceleration to use when performing post-layout analog simulation with RC reduction.
saPrimeSimOptionprimesimrcredits cale	string	saTestbe nch		PrimeSim option primesim_rcreditscale: Sets a scaling factor applied for RC reduction performed using the primesim_rcred command.
saPrimeSimOptionprimesimrcredits caleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimrcreditscale is loaded.
saPrimeSimOptionprimesimrcredU ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimredm inc	string	saTestbe nch		PrimeSim option primesim_redmnc:
saPrimeSimOptionprimesimredmin cUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreduce ddcinitdesignedgshort	string	saTestbe nch	1e9	PrimeSim option primesim_reduced_dcinit_designed_gshort:
saPrimeSimOptionprimesimreduce ddcinitdesignedgshortratio	string	saTestbe nch	0.85	PrimeSim option primesim_reduced_dcinit_designed_gshort _ratio:
saPrimeSimOptionprimesimreduce ddcinitdesignedgshortratioUnchec kLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimreduce ddcinitdesignedgshortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreduce ddcinitfinalize	string	saTestbench	0	PrimeSim option primesim_reduced_dc_init_finalize:
saPrimeSimOptionprimesimreduce ddcinitfinalizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreduce ddcinitgshort	string	saTestbench	1e9	PrimeSim option primesim_reduced_dcinit_gshort:
saPrimeSimOptionprimesimreduce ddcinitgshortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreduce ddcinitmos	string	saTestbench		PrimeSim option primesim_reduced_dc_init_mos:
saPrimeSimOptionprimesimreduce ddcinitmosUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimreduceddcinitmos is loaded.
saPrimeSimOptionprimesimreduce ddcinitshortnegres	string	saTestbench	1	PrimeSim option primesim_reduced_dcinit_short_negres:
saPrimeSimOptionprimesimreduce ddcinitshortnegresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreduce dmatrixpdnnet	string	saTestbench	0	PrimeSim option primesim_reduced_matrix_pdn_net:
saPrimeSimOptionprimesimreduce dmatrixpdnnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreduce dmatrixtime	string	saTestbench		PrimeSim option primesim_reduced_matrix_time:
saPrimeSimOptionprimesimreduce dmatrixtimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreduce dminpartsize	string	saTestbench	1000	PrimeSim option primesim_reduced_min_part_size:
saPrimeSimOptionprimesimreduce dminpartsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimreduce dratio	string	saTestbe nch	2.0	PrimeSim option primesim_reduced_ratio:
saPrimeSimOptionprimesimreduce dratio2	string	saTestbe nch	0.0	PrimeSim option primesim_reduced_ratio2:
saPrimeSimOptionprimesimreduce dratio2UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreduce dratioUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreffnet	string	saTestbe nch		PrimeSim option primesim_reff_net:
saPrimeSimOptionprimesimreffnet UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrefine mc0name	string	saTestbe nch	0	PrimeSim option primesim_refine_mc0_name:
saPrimeSimOptionprimesimrefine mc0nameUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreلتolsc ale	string	saTestbe nch	1.0	PrimeSim option primesim_reلتol_scale: This option scales the final relative tolerance in engine.
saPrimeSimOptionprimesimreلتolsc aleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimreلتolscale is loaded.
saPrimeSimOptionprimesimremov edcportcap	string	saTestbe nch	0	PrimeSim option primesim_remove_dcport_cap:
saPrimeSimOptionprimesimremov edcportcapUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimremov efloatingvsrc	string	custom		PrimeSim option primesim_remove_floating_vsrc: Removes any floating voltage sources and issues a warning message.
saPrimeSimOptionprimesimremov efloatingvsrcUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimremovenonphysicalspfres	string	saTestbench		PrimeSim option primesim_remove_non_physical_spf_res:
saPrimeSimOptionprimesimremovenonphysicalspfresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimremovenonphysicalspfres is loaded.
saPrimeSimOptionprimesimremoveprobeprefix	string	custom	0	PrimeSim option primesim_remove_probe_prefix: Removes prefix from output signal.
saPrimeSimOptionprimesimremoveprobeprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimremovezeroisrc	string	saTestbench		PrimeSim option primesim_remove_zero_isrc:
saPrimeSimOptionprimesimremovezeroisrcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimremovezeroresistance	string	saTestbench	1	PrimeSim option primesim_remove_zero_resistance:
saPrimeSimOptionprimesimremovezeroresistanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreorderglobalmparam	string	saTestbench	0	PrimeSim option primesim_reorder_global_mparam:
saPrimeSimOptionprimesimreorderglobalmparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrepdot	string	saTestbench		PrimeSim option primesim_repdot: Replaces "." with another character.
saPrimeSimOptionprimesimrepdotUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreplaceespffingerchars	string	saTestbench		PrimeSim option primesim_replace_spf_fingerchars:
saPrimeSimOptionprimesimreplaceespffingercharsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreprenode	string	saTestbench	0	PrimeSim option primesim_reprenode:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimrepnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreportlargenoinstances	string	custom		PrimeSim option primesim_report_large_no_instances: Reports subckt instances that contain a large number of devices.
saPrimeSimOptionprimesimreportlargenoinstancesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreskeep	string	saTestbench		PrimeSim option primesim_reskeep:
saPrimeSimOptionprimesimreskeepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimresmax	string	custom	1T	PrimeSim option primesim_resmax: Sets maximum value for a resistor to be considered in simulation.
saPrimeSimOptionprimesimresmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimresmin	string	custom	0.001	PrimeSim option primesim_resmin: Sets minimum value for a resistor to be considered in simulation. The default value is dependent on primesim_mode.
saPrimeSimOptionprimesimresminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrestoreSNAPSHOT	string	custom		PrimeSim option primesim_restore (.SNAPSHOT): The .snapshot option captures a snapshot of the dynamic state of the circuit in motion which can be restored later with the primesim_restore option.
saPrimeSimOptionprimesimrestoreSNAPSHOTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreusmosmodel	string	custom	1	PrimeSim option primesim_reuse_mos_model: Reuses MOSFET models built in the previous iteration.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimreuse mosmodelUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimreus eop	string	saTestbe nch		PrimeSim option primesim_reuse_op: Enables the PrimeSim SPICE tool to reuse the operating point solution from a previous analysis as the initial guess for subsequent analyses
saPrimeSimOptionprimesimreuseo pUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrfactor	string	saTestbe nch		PrimeSim option primesim_rfactor:
saPrimeSimOptionprimesimrfactor UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrfflicke rnoise_fmax	string	saTestbe nch		PrimeSim option primesim_rf_flicker_noise_fmax:
saPrimeSimOptionprimesimrfflicke rnoise_fmaxUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrng	string	custom		PrimeSim option primesim_rng: Specifies the random number generator (RNG) used by the simulator.
saPrimeSimOptionprimesimrngUn checkLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrom	string	saTestbe nch		PrimeSim option primesim_rom:
saPrimeSimOptionprimesimromUn checkLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrosync	string	saTestbe nch	1	PrimeSim option primesim_rosync:
saPrimeSimOptionprimesimrosync UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrpitftm ode	string	custom	0	PrimeSim option primesim_rpitft_mode: Enables PrimeSim support for SmartSpice TFT Model correlation.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimrptftmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrunspread	string	saTestbench	0	PrimeSim option primesim_run_spread:
saPrimeSimOptionprimesimrunspreadUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimrunlvlmode	string	saTestbench	0	PrimeSim option primesim_runlvl_mode: Enable runlvl setting with more aggressive RC reduction and tighter engine accuracy control.
saPrimeSimOptionprimesimrunlvlmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimrunlvlmode is loaded.
saPrimeSimOptionprimesimruntimeas	string	custom		PrimeSim option primesim_runtime_meas: Uses runtime measurement instead of post measurement.
saPrimeSimOptionprimesimruntimeasUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsavepsfbackslash	string	saTestbench	0	PrimeSim option primesim_save_psf_backslash:
saPrimeSimOptionprimesimsavepsfbackslashUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimscale	string	custom		PrimeSim option primesim_scale: Applies the scale factor for subcircuits.
saPrimeSimOptionprimesimscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsetauto_vascope	string	saTestbench		PrimeSim option primesim_set_auto_va_scope:
saPrimeSimOptionprimesimsetauto_vascopeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsetcpulimit	string	custom		PrimeSim option primesim_set_cpu_time: Needs Description.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimsetcpu timeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsetenv	string	custom		PrimeSim option primesim_setenv: Specifies an environment variable name and sets it to value.
saPrimeSimOptionprimesimsetenv UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsetfloa tingnode	string	custom		PrimeSim option primesim_set_floating_node: Sets a user-specified voltage value for either all floating nodes or floating gate nodes only (see primesim_set_floating_node_type) at either the DC operating point only or also throughout the transient simulation (see primesim_set_floating_node_format).
saPrimeSimOptionprimesimsetfloa tingnodeformat	string	custom		PrimeSim option primesim_set_floating_node_format: Determines whether the floating node value specified by primesim_set_floating_node is applied in DC initialization only or also throughout the transient simulation.
saPrimeSimOptionprimesimsetfloa tingnodeformatUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsetfloa tingnodetype	string	custom		PrimeSim option primesim_set_floating_node_type: Determines whether the floating node value specified by primesim_set_floating_node is applied to all floating nodes or to floating gate nodes only.
saPrimeSimOptionprimesimsetfloa tingnodetypeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsetfloa tingnodeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsetspe cialchar	string	custom		PrimeSim option primesim_set_special_char: Appends a "\" before special characters during PSF output.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimsetspecialcharUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsfcreport	string	saTestbench	1e-15	PrimeSim option primesim_sfc_report:
saPrimeSimOptionprimesimsfcreportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsflash	string	saTestbench		PrimeSim option primesim_sflash:
saPrimeSimOptionprimesimsflashUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsfr	string	saTestbench	-1.0e+20	PrimeSim option primesim_sfr:
saPrimeSimOptionprimesimsfrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimshexmlwindow	string	saTestbench		PrimeSim option primesim_she_xml_window:
saPrimeSimOptionprimesimshexmlwindowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimshortnet	string	custom		PrimeSim option primesim_short_net: Shorts the resistors in an RC network that includes the specified node name.
saPrimeSimOptionprimesimshortnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimshowdatavalues	string	saTestbench		PrimeSim option primesim_show_data_values:
saPrimeSimOptionprimesimshowdatavaluesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimshowlog	string	saTestbench	1	PrimeSim option primesim_show_log:
saPrimeSimOptionprimesimshowlogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimsigload model	string	saTestbench	0	PrimeSim option primesim_sigloadmodel:
saPrimeSimOptionprimesimsigload modelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsimple emnaming	string	saTestbench		PrimeSim option primesim_simple_em_naming: Uses the "" as single hierarchical delimiter when "" "" and ""/"" are mixed in signal names. This is used in EM analysis.
saPrimeSimOptionprimesimsimple emnamingUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsinglebinmodelcheck	string	custom	0	PrimeSim option primesim_single_bin_model_check: Apply a similar model binning check for non-binning models.
saPrimeSimOptionprimesimsinglebinmodelcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsioevtol scale	string	saTestbench	0.0	PrimeSim option primesim_sio_evto scale:
saPrimeSimOptionprimesimsioevtol scaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsioievtol scale	string	saTestbench	0.0	PrimeSim option primesim_sio_ievtol scale:
saPrimeSimOptionprimesimsioievtol scaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsisstep size	string	saTestbench		PrimeSim option primesim_sis_step_size:
saPrimeSimOptionprimesimsisstep sizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimskipblock	string	saTestbench		PrimeSim option primesim_skip_block:
saPrimeSimOptionprimesimskipblockUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimskipflatplnode	string	custom		PrimeSim option primesim_skip_flat_pl_node: Reduces FSDB file size by reducing the number of nodes probed.
saPrimeSimOptionprimesimskipflatplnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimskipinfo	string	saTestbench		PrimeSim option primesim_skip_info:
saPrimeSimOptionprimesimskipinfoUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimskipmeaserror	string	custom		PrimeSim option primesim_skip_meas_error: Specifies whether simulation should error out or continue with a warning if a .MEAS statement is missing a parameter.
saPrimeSimOptionprimesimskipmeaserrorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimskipunusedparam	string	custom	0	PrimeSim option primesim_skip_unused_param: Ignores HSIM-specific parameters to avoid ineffective warning messages.
saPrimeSimOptionprimesimskipunusedparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimskipwarn	string	custom		PrimeSim option primesim_skipwarn: Determines amount and type of information output to the log file.
saPrimeSimOptionprimesimskipwarnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsmoothbehdev	string	saTestbench	0	PrimeSim option primesim_smooth_behdev:
saPrimeSimOptionprimesimsmoothbehdevabs	string	saTestbench	0.0	PrimeSim option primesim_smooth_behdev_abs:
saPrimeSimOptionprimesimsmoothbehdevabsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimsmoothbehdevfctr	string	saTestbench	1.0	PrimeSim option primesim_smooth_behdev_fctr:
saPrimeSimOptionprimesimsmoothbehdevfctrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsmoothbehdevUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsoacheckondcinit	string	custom		PrimeSim option primesim_soa_check_on_dc_init: Runs SOA checks on the first two time steps in Transient Analysis and then exits the simulation.
saPrimeSimOptionprimesimsoacheckondcinitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsoamaxwarns	string	custom	5	PrimeSim option primesim_soa_maxwarns: Specifies maximum number of SOA warning messages.
saPrimeSimOptionprimesimsoamaxwarnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsoawarn	string	custom	0	PrimeSim option primesim_soa_warn: Enables or turns off safe operating area (SOA) voltage warning message.
saPrimeSimOptionprimesimsoawarnformat	string	custom	0	PrimeSim option primesim_soa_warn_format: Format of SOA check output.
saPrimeSimOptionprimesimsoawarnformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsoawarnoutfile	string	custom	0	PrimeSim option primesim_soa_warn_to_file: Print result of SOA checks to separate file (.tsa).
saPrimeSimOptionprimesimsoawarnoutfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsoawarnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimsotp	string	saTestbench	0	PrimeSim option primesim_otp: Sets the absolute threshold for marking sparse floating capacitors.
saPrimeSimOptionprimesimsotpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsparsefcap	string	custom		PrimeSim option primesim_sparse_fc: Sets the absolute threshold for marking sparse floating capacitors.
saPrimeSimOptionprimesimsparsefcapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspeed	string	custom	1	PrimeSim option primesim_speed: Sets the speed level of the simulation.
saPrimeSimOptionprimesimspeedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspf	string	custom		PrimeSim option primesim_spf: Specifies the DSPF file that contains SPF data extracted from the layout interconnects.
saPrimeSimOptionprimesimspf2eq	string	custom		PrimeSim option primesim_spf2eq: Extract equivalent resistors from port-to-port in addition to port-to-pin
saPrimeSimOptionprimesimspf2eqrselect	string	saTestbench		PrimeSim option primesim_spf2eqr_select: Specifies the DSPF file that contains SPF data extracted from the layout interconnects.
saPrimeSimOptionprimesimspf2eqrselectUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspf2eqrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfaccirem	string	custom		PrimeSim option primesim_spf_acc_irem: Performs dynamic EM simulation of a huge back-annotated circuit with better performance than standalone IR/EM.
saPrimeSimOptionprimesimspfacciremUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfaddiremwindow	string	custom		PrimeSim option primesim_spf_add_irem_window: Specifies analysis time range for the IR/EM .em file.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspfadd iremwindowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfallowerror	string	custom	0	PrimeSim option primesim_spfallowerror: Continue simulation on SPF parser error.
saPrimeSimOptionprimesimspfallowerrorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfallowmissinginstance	string	custom	1	PrimeSim option primesim_spfallowmissinginstance: Annotates the net to which the missing device was attached as an RC net.
saPrimeSimOptionprimesimspfallowmissinginstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfallowrcparasiticinstance	string	custom		PrimeSim option primesim_spf_allow_rc_parasitic_instance: Allows you to program the RC net of a Standard Parasitic Format (SPF) file with a custom subckt module in order to estimate the RC effect of that SPF NET.
saPrimeSimOptionprimesimspfallowrcparasiticinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfbuschar	string	custom		PrimeSim option primesim_spf_bus_char: Used when extracted SPEF file bus notation is different from schematic netlist bus notation.
saPrimeSimOptionprimesimspfbuscharUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfccparse	string	custom		PrimeSim option primesim_spf_cc_parse: Specifies whether to parse all coupling capacitor NETs even if one of the NETs is not found in the schematic netlist.
saPrimeSimOptionprimesimspfccparseUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfnet	string	custom		PrimeSim option primesim_spfnet: Specifies the net names to be annotated with lumped capacitance only.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspfch tUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfdbv ersion	string	custom		PrimeSim option primesim_spfdb_version: Sets the IR drop database version.
saPrimeSimOptionprimesimspfdbv ersionUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfdpf reset	string	saTestbe nch		PrimeSim option primesim_spfdpf_reset:
saPrimeSimOptionprimesimspfdpf resetUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfeco connect	string	saTestbe nch	0	PrimeSim option primesim_spf_eco_connect.
saPrimeSimOptionprimesimspfeco connectUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimspfecoconnect is loaded.
saPrimeSimOptionprimesimspfeco instance	string	saTestbe nch		PrimeSim option primesim_spf_eco_instance:
saPrimeSimOptionprimesimspfeco instanceUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimspfecoinstance is loaded.
saPrimeSimOptionprimesimspfem version	string	custom		PrimeSim option primesim_spf_em_version: Sets the EM database version.
saPrimeSimOptionprimesimspfem versionUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfqr r	string	custom		PrimeSim option primesim_spfqr: Extract equivalent resistors from port-to-pin
saPrimeSimOptionprimesimspfqr file	string	custom		PrimeSim option primesim_spfqrfile: Output file name for the equivalent resistor analysis
saPrimeSimOptionprimesimspfqr fileUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspfegronly	string	custom	0	PrimeSim option primesim_spfegronly: Run the equivalent resistor analysis
saPrimeSimOptionprimesimspfegronlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfegronlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfexclude	string	custom		PrimeSim option primesim_spf_exclude: Excludes the specified instances from SPF back-annotation.
saPrimeSimOptionprimesimspfexcludeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfmin	string	custom	0	PrimeSim option primesim_spfmin: Sets minimum floating capacitor value allowed for back-annotation.
saPrimeSimOptionprimesimspfminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfnet	string	custom		PrimeSim option primesim_spfnet: Keeps the floating capacitance for C-only back-annotation.
saPrimeSimOptionprimesimspfnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspf_fingerchars	string	saTestbench		PrimeSim option primesim_spf_fingerchars: Translates the special SPF finger delimiter from the specified string to ""@"".
saPrimeSimOptionprimesimspf_fingercharsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspf_finger_respolicy	string	custom		PrimeSim option primesim_spf_finger_res_policy: Specifies whether finger resistors must be in parallel to the base resistor or are allowed to be a series or a mix of parallel and sequential order.
saPrimeSimOptionprimesimspf_finger_respolicyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspfdiv	string	custom		PrimeSim option primesim_spfdiv: Sets the divider character for hierarchical names in DSPF files.
saPrimeSimOptionprimesimspfdivUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfhistogram	string	custom		PrimeSim option primesim_spf_histogram: Specifies whether to print an RC Histogram for each DSPF file during back-annotation.
saPrimeSimOptionprimesimspfhistogramUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspffirst	string	custom	0	PrimeSim option primesim_spfirst: Control whether the instance section of the DSPF file is used for annotation.
saPrimeSimOptionprimesimspffirstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfremiswr	string	saTestbench		PrimeSim option primesim_spf_irem_iswr:
saPrimeSimOptionprimesimspfremiswrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfsrcdivider	string	saTestbench		PrimeSim option primesim_spf_isrc_divider:
saPrimeSimOptionprimesimspfsrcdividerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimspfsrcdivider is loaded.
saPrimeSimOptionprimesimspfsrcprobe	string	saTestbench	0	PrimeSim option primesim_spf_isrc_probe:
saPrimeSimOptionprimesimspfsrcprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfkeephier	string	custom	0	PrimeSim option primesim_spf_keep_hier: Reduce the memory foot print for C annotation.
saPrimeSimOptionprimesimspfkeephierUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspfkee pnodecap	string	custom		PrimeSim option primesim_spfkeepnodecap: Controls whether to keep or remove the pre-layout ground capacitance of back-annotated nets.
saPrimeSimOptionprimesimspfkee pnodecapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfplayo utonlydevicemodels	string	custom		PrimeSim option primesim_spf_layout_only_device_models: Specifies the device model names in the DSPF file to be added to the back-annotation simulation.
saPrimeSimOptionprimesimspfplayo utonlydevicemodelsUncheckLocali zed	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfplayo utonlynet	string	custom		PrimeSim option primesim_spf_layout_only_net: Use this option to specify one or more NETs which exist only in layout so that you can apply RC annotation options to them.
saPrimeSimOptionprimesimspfplayo utonlynetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfma psubcktport	string	custom		PrimeSim option primesim_spf_map_subckt_port: Sets mapping between the port names of the schematic file and the pin names of the back-annotation file.
saPrimeSimOptionprimesimspfma psubcktportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfmat cheffort	string	custom	0	PrimeSim option primesim_spf_matcheffort: Perform more rigorous naming matching for SPF net and devices.
saPrimeSimOptionprimesimspfmat cheffortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfmer geport	string	custom	0	PrimeSim option primesim_spfmergeport: Allow ports merge in DSPF net
saPrimeSimOptionprimesimspfmer geportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspfmodule	string	custom		PrimeSim option primesim_spfmodule: Specifies the module for SPF back-annotation.
saPrimeSimOptionprimesimspfmoduleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfnet	string	custom		PrimeSim option primesim_spfnonet: Specifies the nets that are not going to be back-annotated by DSPF data.
saPrimeSimOptionprimesimspfnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfportnamecheck	string	custom		PrimeSim option primesim_spf_port_name_check: Specifies whether to check for multiple instances of port names connecting to another NET.
saPrimeSimOptionprimesimspfportnamecheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfpost	string	custom		PrimeSim option primesim_spfpost: Sets the node names for post analysis of DSPF back-annotated simulation.
saPrimeSimOptionprimesimspfpostoutonly	string	custom		PrimeSim option primesim_spfpost_out_only: Use this option to probe the internal nodes of power/ground during EM simulation.
saPrimeSimOptionprimesimspfpostoutonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfposttUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfprb	string	custom	0	PrimeSim option primesim_spfprb: Sets the probe mode for DSPF nodes.
saPrimeSimOptionprimesimspfprbmode	string	custom	0	PrimeSim option primesim_spfprb_mode: Use proper hierarchy for the spf-annotated node name
saPrimeSimOptionprimesimspfprbmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspfprbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfprefix	string	custom		PrimeSim option primesim_spfprefix: Lists the prefixes that should be removed from device names.
saPrimeSimOptionprimesimspfprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfrcctype	string	saTestbench		PrimeSim option primesim_spfrc_ctype:
saPrimeSimOptionprimesimspfrcctypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfrcnet	string	custom		PrimeSim option primesim_spfrcnet: Specifies the net names that are annotated with RC trees.
saPrimeSimOptionprimesimspfrcnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfrcrcd	string	saTestbench		PrimeSim option primesim_spf_rcrd:
saPrimeSimOptionprimesimspfrcrcdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfrcd	string	custom	0	PrimeSim option primesim_spfrcd: Sets whether to reduce RC reduction during SPF back-annotation stage.
saPrimeSimOptionprimesimspfrcdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfrep gate	string	saTestbench		PrimeSim option primesim_spfrep gate: Picks the first GATE pin defined at (* I)/(* NET) from the DSPF file
saPrimeSimOptionprimesimspfrep gateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfrep last	string	custom	0	PrimeSim option primesim_spfrep last: Controls how the representative node is chosen when annotating DSPF

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspfrepLastUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfresmax	string	saTestbench		PrimeSim option primesim_spf_resmax:
saPrimeSimOptionprimesimspfresmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfresmax	string	custom	1.0e8	PrimeSim option primesim_spfresmax: Sets maximum resistor value allowed for back-annotation.
saPrimeSimOptionprimesimspfresmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfresmin	string	custom	0.01	PrimeSim option primesim_spfresmin: Sets minimum resistor value allowed for back-annotation.
saPrimeSimOptionprimesimspfresminDefaultMatch	string	saTestbench	val	PrimeSim option primesim_spfresmin_default_match:
saPrimeSimOptionprimesimspfresminDefaultMatchUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfresminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfresptrmax	string	custom	2000	PrimeSim option primesim_spfresptrmax: Warning threshold number (per net) for SPF resistors
saPrimeSimOptionprimesimspfresptrmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfresptrc1	string	custom	0	PrimeSim option primesim_spfresptrc1: TC1 parameter for DSPF resistors
saPrimeSimOptionprimesimspfresptrc1UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfresptrc2	string	custom	0	PrimeSim option primesim_spfresptrc2: TC2 parameter for DSPF resistors

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspfsrc2UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfscale	string	custom	1	PrimeSim option primesim_spfscale: Sets the scale for devices in the DSPF file.
saPrimeSimOptionprimesimspfscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfcheckmode	string	custom		PrimeSim option primesim_spf_sch_check_mode: Turn this option on in back-annotation simulations when the schematic netlist changes faster than layout and DSPF files can be generated.
saPrimeSimOptionprimesimspfcheckmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfcheck	string	saTestbench	0	PrimeSim option primesim_spf_sd_check:
saPrimeSimOptionprimesimspfcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfensitive	string	custom		PrimeSim option primesim_spf_sensitive: Supports case sensitivity for netlist back-annotation flow.
saPrimeSimOptionprimesimspfensitiveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfskipresforivsrc	string	saTestbench		PrimeSim option primesim_spf_skip_res_for_ivsrc: Tests to see whether any SPF nets for RC annotation are connected to any current sources or voltage sources.
saPrimeSimOptionprimesimspfskipresforivsrcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfepf	string	custom		PrimeSim option primesim_spfepf: Sets primesim_spf input to be DSPF or SPEF format.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspfspfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfspicenames	string	custom	1	PrimeSim option primesim_spf_spice_names: Specifies whether the instance names in the DSPF file include the SPICE type prefix.
saPrimeSimOptionprimesimspfspicenamesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfsplitnet	string	custom	1	PrimeSim option primesim_spfsplitnet: Back annotate split nets
saPrimeSimOptionprimesimspfsplitnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfsuffix	string	custom		PrimeSim option primesim_spfsuffix: Defines the suffix in a DSPF file.
saPrimeSimOptionprimesimspfsuffixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfctc	string	custom	0.1ps	PrimeSim option primesim_spfctc: Time constant value for RC reduction
saPrimeSimOptionprimesimspfctcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfctref	string	custom		PrimeSim option primesim_spfctref: Reference temperature for DSPF resistors
saPrimeSimOptionprimesimspfctrefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfuserdefinedgndlist	string	custom		PrimeSim option primesim_spf_user_defined_gnd_list: Specifies the node list that should be treated as ideal ground in SPF back-annotation.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspfuserdefinedgndlistUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspfwarn	string	custom		PrimeSim option primesim_spfwarn: Controls warning message output when performing and debugging back-annotation.
saPrimeSimOptionprimesimspfwarnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspred	string	custom	2	PrimeSim option primesim_spred: Level of RC reduction.
saPrimeSimOptionprimesimspredkeepname	string	saTestbench		PrimeSim option primesim_spred_keep_name:
saPrimeSimOptionprimesimspredkeepnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimspredkeepname is loaded.
saPrimeSimOptionprimesimspredkeepvdiv	string	saTestbench		PrimeSim option primesim_spred_keep_vdiv:
saPrimeSimOptionprimesimspredkeepvdivUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredmultipart	string	saTestbench		PrimeSim option primesim_spred_multi_part:
saPrimeSimOptionprimesimspredmultipartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsprednegres	string	saTestbench		PrimeSim option primesim_spred_negres:
saPrimeSimOptionprimesimsprednegresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimsprednegres is loaded.
saPrimeSimOptionprimesimsprednooshortplus	string	saTestbench	0	PrimeSim option primesim_spred_no_short_plus:
saPrimeSimOptionprimesimsprednooshortplusUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspredplus	string	saTestbench		PrimeSim option primesim_spred_plus:
saPrimeSimOptionprimesimspredplusabstolfactor	string	saTestbench	100	PrimeSim option primesim_spred_plus_abstol_factor:
saPrimeSimOptionprimesimspredplusabstolfactorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredpluscheckboth	string	saTestbench	1	PrimeSim option primesim_spred_plus_check_both:
saPrimeSimOptionprimesimspredpluscheckbothUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredpluscomptotalR	string	saTestbench	0	PrimeSim option primesim_spred_plus_comp_totalR:
saPrimeSimOptionprimesimspredpluscomptotalRUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredplusdistributetoall	string	saTestbench	0	PrimeSim option primesim_spred_plus_distribute_to_all:
saPrimeSimOptionprimesimspredplusdistributetoallUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredplusseqrcutoff	string	saTestbench		PrimeSim option primesim_spred_plus_eqr_cutoff:
saPrimeSimOptionprimesimspredplusseqrcutoffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimspredplusseqrcutoff is loaded.
saPrimeSimOptionprimesimspredplusseqropt	string	saTestbench	0	PrimeSim option primesim_spred_plus_eqr_opt:
saPrimeSimOptionprimesimspredplusseqroptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredplusseqrrelth	string	saTestbench		PrimeSim option primesim_spred_plus_eqr_relth:
saPrimeSimOptionprimesimspredplusseqrrelthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspredp luseqrth	string	saTestbe nch	1e-1	PrimeSim option primesim_spred_plus_eqr_th:
saPrimeSimOptionprimesimspredp luseqrthUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp lusfulltraversal	string	saTestbe nch	1	PrimeSim option primesim_spred_plus_full_traversal:
saPrimeSimOptionprimesimspredp lusfulltraversalUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp luskeepnegres	string	saTestbe nch	0	PrimeSim option primesim_spred_plus_keep_negres:
saPrimeSimOptionprimesimspredp luskeepnegresUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp luskeeptotalcond	string	saTestbe nch	1	PrimeSim option primesim_spred_plus_keep_total_cond:
saPrimeSimOptionprimesimspredp luskeeptotalcondUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp lusmaxmerge	string	saTestbe nch	2	PrimeSim option primesim_spred_plus_max_merge:
saPrimeSimOptionprimesimspredp lusmaxmergeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp lusopenthreshold	string	saTestbe nch	10000	PrimeSim option primesim_spred_plus_open_threshold:
saPrimeSimOptionprimesimspredp lusopenthresholdUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp lusporttcfactor	string	saTestbe nch		PrimeSim option primesim_spred_plus_port_tc_factor:
saPrimeSimOptionprimesimspredp lusporttcfactorUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp lusshortfirst	string	saTestbe nch	0	PrimeSim option primesim_spred_plus_short_first:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspredp lusshortfirstUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp lusshortingabstol	string	saTestbe nch		PrimeSim option primesim_spred_plus_shorting_abstol:
saPrimeSimOptionprimesimspredp lusshortingabstolUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp lusshortingreltol	string	saTestbe nch		PrimeSim option primesim_spred_plus_shorting_reltol:
saPrimeSimOptionprimesimspredp lusshortingreltolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp lustc	string	saTestbe nch		PrimeSim option primesim_spred_plus_tc:
saPrimeSimOptionprimesimspredp lustcUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp lustightenportsshort	string	saTestbe nch	0	PrimeSim option primesim_spred_plus_tighten_ports_short:
saPrimeSimOptionprimesimspredp lustightenportsshortUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp lustopnets	string	saTestbe nch	10	PrimeSim option primesim_spred_plus_top_nets:
saPrimeSimOptionprimesimspredp lustopnetsUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp lustwopass	string	saTestbe nch	0	PrimeSim option primesim_spred_plus_two_pass:
saPrimeSimOptionprimesimspredp lustwopassUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp lusUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp rll	string	saTestbe nch	0	PrimeSim option primesim_spred_prll:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimspredp rllUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredp wropt	string	saTestbe nch	0	PrimeSim option primesim_spredpwropt:
saPrimeSimOptionprimesimspredp wroptUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspred dtc	string	saTestbe nch		PrimeSim option primesim_spredtc:
saPrimeSimOptionprimesimspredt cUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspred UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspredv valopt	string	saTestbe nch	0	PrimeSim option primesim_spredvvalopt:
saPrimeSimOptionprimesimspredv valoptUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimspres out	string	saTestbe nch		PrimeSim option primesim_spresout: Enables and specifies the output format for the SPRES solver.
saPrimeSimOptionprimesimspreso utUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimssram	string	custom		PrimeSim option primesim_sram: Provides one accuracy setting command for SRAM characterizations for both timing and power applications.
saPrimeSimOptionprimesimssramU ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsssfca pitercnt	string	saTestbe nch		PrimeSim option primesim_ss_sfcap_iter_cnt:
saPrimeSimOptionprimesimsssfca pitercntUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimsssfcapitercnt is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimsssfcap_tol	string	saTestbench		PrimeSim option primesim_ss_sfcap_tol:
saPrimeSimOptionprimesimsssfcap_tolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimsssfcap_tol is loaded.
saPrimeSimOptionprimesimsssfcap_sparse_fcap	string	saTestbench		PrimeSim option primesim_ss_sparse_fcap:
saPrimeSimOptionprimesimsssfcap_sparse_fcapthreshold	string	saTestbench		PrimeSim option primesim_ss_sparse_fcap_threshold:
saPrimeSimOptionprimesimsssfcap_sparse_fcapthresholdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimsssfcap_sparse_fcapthreshold is loaded.
saPrimeSimOptionprimesimsssfcap_sparse_fcapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimsssfcap_sparse_fcap is loaded.
saPrimeSimOptionprimesimsubckt_duprule	string	custom	0	PrimeSim option primesim_subckt_dup_rule: Selects which sub-circuit definition to use in simulation..
saPrimeSimOptionprimesimsubckt_dupruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsweep_brief	string	custom		PrimeSim option primesim_sweep_brief: Limits parametric sweep information written to the log file.
saPrimeSimOptionprimesimsweep_briefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsync_eval	string	saTestbench	0	PrimeSim option primesim_sync_eval:
saPrimeSimOptionprimesimsync_eval_mode	string	saTestbench	0	PrimeSim option primesim_sync_eval_mode:
saPrimeSimOptionprimesimsync_eval_modeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsync_eval_no_prop	string	saTestbench	0	PrimeSim option primesim_sync_eval_no_prop:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimsyncevalnopropUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsyncevalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimsyntaxcheck	string	saTestbench		PrimeSim option primesim_syntax_check:
saPrimeSimOptionprimesimsyntaxcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtablesharemethod	string	saTestbench		PrimeSim option primesim_table_share_method:
saPrimeSimOptionprimesimtablesharemethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtclinitfile	string	custom		PrimeSim option primesim_tcl_init_file: Specifies the Tcl file for PrimeSim to source for the simulation.
saPrimeSimOptionprimesimtclinitfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtelemtsmethod	string	saTestbench	2	PrimeSim option primesim_telem_tsc_method:
saPrimeSimOptionprimesimtelemtsmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtempveccharge	string	saTestbench		PrimeSim option primesim_tempvec_charge:
saPrimeSimOptionprimesimtempvecchargeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtempvecsametempallowed	string	saTestbench		PrimeSim option primesim_tempvec_sametemp_allowed:
saPrimeSimOptionprimesimtempvecsametempallowedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtempvecetc	string	saTestbench		PrimeSim option primesim_tempvec_tc:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimtempvectcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtflush	string	custom		PrimeSim option primesim_tflush: Flushes output files at time interval x.
saPrimeSimOptionprimesimtflushUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtgrid	string	saTestbench	5	PrimeSim option primesim_tgrid:
saPrimeSimOptionprimesimtgridUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtiefloatingpodegates	string	saTestbench	1	PrimeSim option primesim_tie_floating_pode_gates:
saPrimeSimOptionprimesimtiefloatingpodegatesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtiegate	string	saTestbench		PrimeSim option primesim_tiegate:
saPrimeSimOptionprimesimtiegateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtienode	string	saTestbench		PrimeSim option primesim_tienode:
saPrimeSimOptionprimesimtienodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtitleinalterfilenames	string	custom		PrimeSim option primesim_title_in_alter_filenames: Specifies whether to append the title_string from .ALTER statements to the output filename prefix.
saPrimeSimOptionprimesimtitleinalterfilenamesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtmiagereltol	string	saTestbench		PrimeSim option primesim_tmiage_reltol: For TMI aging simulation

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimtmiaage reltolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtmica che	string	saTestbench	0	PrimeSim option primesim_tmi_cache:
saPrimeSimOptionprimesimtmicac heUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtmicac hevtol	string	saTestbench		PrimeSim option primesim_tmi_cache_vtol:
saPrimeSimOptionprimesimtmicac hevtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtmimt	string	saTestbench	1	PrimeSim option primesim_tmi_mt:
saPrimeSimOptionprimesimtmimtU ncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtmishe abstol	string	saTestbench		PrimeSim option primesim_tmishe_abstol: For TMI self-heating simulation
saPrimeSimOptionprimesimtmishe abstolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtolsc ale	string	custom		PrimeSim option primesim_tolscale: Sets a multiplier applied to all internal tolerance values.
saPrimeSimOptionprimesimtolscal eUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtopn	string	saTestbench		PrimeSim option primesim_top_n:
saPrimeSimOptionprimesimtopnU ncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtranco nvretry	string	saTestbench		PrimeSim option primesim_tran_conv_retry: If transient simulation fails to converge the first time

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimtranco nvretryUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtriabs tol	string	saTestbe nch		PrimeSim option primesim_tr_iabstol:
saPrimeSimOptionprimesimtriabst olUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtriireltol	string	saTestbe nch		PrimeSim option primesim_tr_ireltol:
saPrimeSimOptionprimesimtriireltol UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtrtol	string	saTestbe nch		PrimeSim option primesim_trtol:
saPrimeSimOptionprimesimtrtolsc ale	string	saTestbe nch		PrimeSim option primesim_trtolyscale:
saPrimeSimOptionprimesimtrtolsc aleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtrtolUn checkLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtsalg	string	saTestbe nch		PrimeSim option primesim_tsalg:
saPrimeSimOptionprimesimtsalgU ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtsc	string	saTestbe nch	lte1	PrimeSim option primesim_tsc: Sets the algorithm mode for time-step control during transient analysis.
saPrimeSimOptionprimesimtscUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtsprogr esslog	string	saTestbe nch	0	PrimeSim option primesim_ts_progress_log:
saPrimeSimOptionprimesimtsprogr esslogUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimtstop	string	saTestbench		PrimeSim option primesim_tstop: Modifies the tstop specified in the.tran command line
saPrimeSimOptionprimesimtstopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtstsch	string	saTestbench	0	PrimeSim option primesim_tsts_check:
saPrimeSimOptionprimesimtstschcknodename	string	saTestbench		PrimeSim option primesim_tsts_check_node_name:
saPrimeSimOptionprimesimtstschcknodenameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtstschckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimtunit	string	custom	0.01p	PrimeSim option primesim_tunit: Defines the base time unit of the simulation.
saPrimeSimOptionprimesimtunitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimuseinactivealterflow	string	saTestbench	1	PrimeSim option primesim_use_inactive_alter_flow:
saPrimeSimOptionprimesimuseinactivealterflowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimuseinactive sweepflow	string	saTestbench	1	PrimeSim option primesim_use_inactive_sweep_flow:
saPrimeSimOptionprimesimuseinactive sweepflowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimuseinline name	string	saTestbench		PrimeSim option primesim_use_inline_name:
saPrimeSimOptionprimesimuseinline nameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimuseold trout	string	custom	0	PrimeSim option primesim_use_old_trout: Determines whether to use new or previous output file name extensions for .print and .measure.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimuseold troutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimusesimplemodel	string	saTestbench	2	PrimeSim option primesim_use_simple_model:
saPrimeSimOptionprimesimusesimplemodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimutfmode	string	saTestbench	fast	PrimeSim option primesim_utf_mode: Outputs compressed UTF for Veritools.
saPrimeSimOptionprimesimutfmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimvarymodelparams	string	saTestbench		PrimeSim option primesim_vary_model_params:
saPrimeSimOptionprimesimvarymodelparamsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimvatmethod	string	saTestbench	0	PrimeSim option primesim_va_tsc_method:
saPrimeSimOptionprimesimvatmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimvdd	string	custom		PrimeSim option primesim_vdd: Sets the VDD value used for MOS table generation.
saPrimeSimOptionprimesimvddUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimvds0range	string	saTestbench		PrimeSim option primesim_vds0_range:
saPrimeSimOptionprimesimvds0rangeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimvector	string	custom		PrimeSim option primesim_vector: Specifies a vector file for comparison with simulation results.
saPrimeSimOptionprimesimvectorerrmsg	string	custom		PrimeSim option primesim_vector_errmsg: Specifies how errors are handled during vector comparison.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimvector errmsgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimvector mode	string	custom	0	PrimeSim option primesim_vector_mode: Sets the I/O vector file format for bus signals.
saPrimeSimOptionprimesimvector modeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimvector notabularmode	string	saTestbench		PrimeSim option primesim_vector_no_tabular_mode:
saPrimeSimOptionprimesimvector notabularmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimvectort opnode	string	saTestbench		PrimeSim option primesim_vector_topnode:
saPrimeSimOptionprimesimvectort opnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimvector UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog abypass	string	custom		PrimeSim option primesim_veriloga_bypass: Enables the model bypass of entire Verilog-A models in the design.
saPrimeSimOptionprimesimverilog abypassUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog acrossaccuracy	string	saTestbench	2	PrimeSim option primesim_veriloga_cross_accuracy:
saPrimeSimOptionprimesimverilog acrossaccuracyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog acrossdefaultetol	string	saTestbench	-1	PrimeSim option primesim_veriloga_cross_default_etol:
saPrimeSimOptionprimesimverilog acrossdefaultetolUncheckLocal ized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimverilog acrossdefaultttol	string	saTestbench	-1	PrimeSim option primesim_veriloga_cross_default_ttol:
saPrimeSimOptionprimesimverilog acrossdefaultttolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog acrossmethod	string	custom		PrimeSim option primesim_veriloga_cross_method: Specifies what value (true false) the Verilog-A cross(x) function returns when x is exactly zero.
saPrimeSimOptionprimesimverilog acrossmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog adecodepercentinopen	string	saTestbench		PrimeSim option primesim_veriloga_decode_percent_in_open:
saPrimeSimOptionprimesimverilog adecodepercentinopenUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimverilogadecodepercentinopen is loaded.
saPrimeSimOptionprimesimverilog adefaultimaxslew	string	saTestbench		PrimeSim option primesim_veriloga_default_i_maxslew:
saPrimeSimOptionprimesimverilog adefaultimaxslewUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog adefaultvmaxslew	string	saTestbench		PrimeSim option primesim_veriloga_default_v_maxslew:
saPrimeSimOptionprimesimverilog adefaultvmaxslewUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog adivisionupperlimit	string	saTestbench		PrimeSim option primesim_veriloga_division_upper_limit:
saPrimeSimOptionprimesimverilog adivisionupperlimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog adkinddef	string	saTestbench		PrimeSim option primesim_veriloga_dkind_def: Defines the device type for the Verilog-A device model

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimverilog adkinddefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog adkindmode	string	custom		PrimeSim option primesim_veriloga_dkind_mode: Specifies whether to enable (1) or disable (0) the primesim_veriloga_dkind_def option.
saPrimeSimOptionprimesimverilog adkindmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog adynarbcheck	string	saTestbench	1	PrimeSim option primesim_veriloga_dyn_arb_check:
saPrimeSimOptionprimesimverilog adynarbcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog aexpthreshold	string	saTestbench	80.0	PrimeSim option primesim_veriloga_exp_threshold:
saPrimeSimOptionprimesimverilog aexpthresholdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog aextraeval	string	saTestbench		PrimeSim option primesim_veriloga_extra_eval:
saPrimeSimOptionprimesimverilog aextraevalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog aforcesofilerebuild	string	saTestbench	0	PrimeSim option primesim_veriloga_force_sofile_rebuild:
saPrimeSimOptionprimesimverilog aforcesofilerebuildUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog agenericflag1	string	saTestbench		PrimeSim option primesim_veriloga_generic_flag1:
saPrimeSimOptionprimesimverilog agenericflag1UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionprimesimverilogagenericflag1 is loaded.
saPrimeSimOptionprimesimverilog ahdl	string	custom		PrimeSim option primesim_veriloga (.hdl): Helps include a Verilog-A file in the netlist.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimverilogahdlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilogainactivepartitionsize	string	saTestbench	0	PrimeSim option primesim_veriloga_inactive_partition_size:
saPrimeSimOptionprimesimverilogainactivepartitionsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilogalimexpthreshold	string	saTestbench	46.051701859881368	PrimeSim option primesim_veriloga_limexp_threshold:
saPrimeSimOptionprimesimverilogalimexpthresholdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilogamaptransistorport	string	saTestbench		PrimeSim option primesim_veriloga_map_transistor_port:
saPrimeSimOptionprimesimverilogamaptransistorportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilogaprintcrosstols	string	saTestbench		PrimeSim option primesim_veriloga_print_cross_tols:
saPrimeSimOptionprimesimverilogaprintcrosstolsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilogaq	string	saTestbench		PrimeSim option primesim_veriloga_qa:
saPrimeSimOptionprimesimverilogaqUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilogaslewwrap	string	saTestbench	0	PrimeSim option primesim_veriloga_slew_wrap:
saPrimeSimOptionprimesimverilogaslewwrapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilogasuppresstcrossprediction	string	saTestbench		PrimeSim option primesim_veriloga_suppress_tcross_prediction:
saPrimeSimOptionprimesimverilogasuppresstcrosspredictionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimverilog atablefillinpolicy	string	custom		PrimeSim option primesim_veriloga_table_fill_in_policy: Specifies the direction to start extrapolation if there are missing indexed entries when using the table_param built-in function to specify a file that contains a parameter values table and return the linear interpolated value from that table.
saPrimeSimOptionprimesimverilog atablefillinpolicyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog atimerreforcesactivity	string	saTestbench		PrimeSim option primesim_veriloga_time_ref_forces_activity:
saPrimeSimOptionprimesimverilog atimerreforcesactivityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog atimerperiodtrunc	string	saTestbench	0	PrimeSim option primesim_veriloga_timer_period_trunc:
saPrimeSimOptionprimesimverilog atimerperiodtruncUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog atimerstutterstepfloat	string	saTestbench	0.0	PrimeSim option primesim_veriloga_timer_stutterstep_float:
saPrimeSimOptionprimesimverilog atimerstutterstepfloatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog atimerstuttersteptunit	string	saTestbench	0	PrimeSim option primesim_veriloga_timer_stutterstep_tunit:
saPrimeSimOptionprimesimverilog atimerstuttersteptunitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog atransitionabstol	string	saTestbench	1e-6	PrimeSim option primesim_veriloga_transition_abstol:
saPrimeSimOptionprimesimverilog atransitionabstolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog atransitionreltol	string	saTestbench	1e-3	PrimeSim option primesim_veriloga_transition_reltol:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimverilog atransitionreltolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog atunit	string	saTestbench	(int)(floor(log10(tunit)))	PrimeSim option primesim_veriloga_tunit:
saPrimeSimOptionprimesimverilog atunitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog ausexptable	string	saTestbench	1	PrimeSim option primesim_veriloga_use_exp_table:
saPrimeSimOptionprimesimverilog ausexptableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimverilog avaropt	string	custom		PrimeSim option primesim_veriloga_var_opt: Sets some local variables within Verilog-A modules in order to have the variables shared among instances.
saPrimeSimOptionprimesimverilog avaroptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimvgrace	string	saTestbench	0.5	PrimeSim option primesim_vgrace:
saPrimeSimOptionprimesimvgrace UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimvprbtol	string	custom	0.1mV	PrimeSim option primesim_vprbtol: Sets the voltage tolerance for voltage print out.
saPrimeSimOptionprimesimvprbtol UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimvpwltol	string	custom		PrimeSim option primesim_vpwltol: Removes small changes in the voltage input waveform in PWL format.
saPrimeSimOptionprimesimvpwltol UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimvsrchn	string	saTestbench		PrimeSim option primesim_vsrchn:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimvsrchnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimwarnlimit	string	custom	0	PrimeSim option primesim_warn_limit: Sets the number of all warning messages to a specific number of lines.
saPrimeSimOptionprimesimwarnlimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimwdfmit	string	custom		PrimeSim option primesim_wdf_limit: Sets the number of warning messages to a number of specified lines
saPrimeSimOptionprimesimwdfmitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimwdfmode	string	saTestbench	loseless	PrimeSim option primesim_wdf_mode: Controls the amount of compression for wdf output file.
saPrimeSimOptionprimesimwdfmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimwildcardexpansionflow	string	saTestbench	0	PrimeSim option primesim_wildcard_expansion_flow:
saPrimeSimOptionprimesimwildcardexpansionflowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimwildcardrule	string	saTestbench		PrimeSim option primesim_wildcard_rule:
saPrimeSimOptionprimesimwildcardruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimwriteinstanceparam	string	custom		PrimeSim option primesim_write_instance_param: Dumps out a list of resolved instance parameters with full scope names.
saPrimeSimOptionprimesimwriteinstanceparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprimesimwriteinstancetable	string	custom	0	PrimeSim option primesim_write_instance_table: Generates an instance file.
saPrimeSimOptionprimesimwriteinstancetableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimwriteinstanceparam	string	custom	0	PrimeSim option primesim_write_mcpparam: Saves the generated parameters in each run to a file.
saPrimeSimOptionprimesimwriteinstanceparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimxprbcheckmosfet	string	saTestbench		PrimeSim option primesim_xprb_check_mosfet:
saPrimeSimOptionprimesimxprbcheckmosfetfix	string	saTestbench		PrimeSim option primesim_xprb_check_mosfet_fix:
saPrimeSimOptionprimesimxprbcheckmosfetfixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimxprbcheckmosfetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimxprbdevlimit	string	saTestbench		PrimeSim option primesim_xprb_dev_limit:
saPrimeSimOptionprimesimxprbdevlimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprimesimxprbkeepdev	string	saTestbench		PrimeSim option primesim_xprb_keep_dev:
saPrimeSimOptionprimesimxprbkeepdevUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprintincluding	string	custom	no	PrimeSim option print_including: Enable Spectre/Ultrasim to print including information in include statement. Possible values are no and yes.
saPrimeSimOptionprintsection	string	custom	no	PrimeSim option print_section: If yes, output sections used in simulations. If no, do not output sections.. Possible values are no and yes.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionprintstep	string	custom	no	PrimeSim option printstep: Enable Spectre to print results by equal step defined in .tran statement. Possible values are no and yes.
saPrimeSimOptionprintstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionprobecompatible	string	custom	spectre	PrimeSim option probe_compatible: Flag to enable or disable optimization for probe wildcard statement. Possible values are hspice and spectre.
saPrimeSimOptionpsfopmc	string	saTestbench		PrimeSim option psf_op_mc:
saPrimeSimOptionpsfopmcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionpsfopmc is loaded.
saPrimeSimOptionptranmaxsteps	string	custom	200	PrimeSim option ptranmaxsteps: Maximum number of steps for ptran phase in DC simulation.
saPrimeSimOptionputmeas	string	custom		PrimeSim option putmeas: Controls the output variables listed in the .MEASURE command
saPrimeSimOptionputmeasUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionpvaoutputdir	string	saTestbench	<file path>	PrimeSim option pva_output_dir:
saPrimeSimOptionpvaoutputdirUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionpvaoutputdir is loaded.
saPrimeSimOptionpvchar	string	saTestbench		PrimeSim option pv_char:
saPrimeSimOptionpvcharUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionpvchar is loaded.
saPrimeSimOptionqcut	string	custom	[...]	PrimeSim option qcut: Replaces all BJT instances using the specified model definitions with an open. qcut=all cuts all BJT elements.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionquantities	string	custom	no	PrimeSim option quantities: Print quantities. If quantities=min, the simulator prints out all defined quantities; if quantities=full, the simulator also prints a list of nodes and their quantities. Possible values are no, min, and full.
saPrimeSimOptionrabsclamp	string	custom	0.0	PrimeSim option rabsclamp: All fixed value and variable resistors with absolute value of $R \leq \text{rabsclamp}$ are clamped to 'rabsclamp'.
saPrimeSimOptionrabsshort	string	custom		PrimeSim option rabsshort: When this option is set, all fixed value resistors with absolute value of $R \leq \text{rabsshort}$ are shorted. Default value is 0 for Spectre, and 1m for APS. Rabsshort can additionally be applied to variable resistors using the option 'short_cut_var_elem=yes'.
saPrimeSimOptionrampsource	string	custom	yes	PrimeSim option rampsource: When performing dc hysteresis sweep, rampsource should be set to no. Possible values are no and yes.
saPrimeSimOptionrationalfuncac hedir	string	custom		PrimeSim option rational_func_cache_dir: Specifies an arbitrary directory where you have write permission that the PrimeSim tool can use to store and reuse rational function cache data
saPrimeSimOptionrationalfuncac hedirUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionrclampbsource	string	saTestbe nch		PrimeSim option rclamp_bsource:
saPrimeSimOptionrclampbsource	string	custom		PrimeSim option rclamp_bsource: When rclamp_bsource=value is given, all instance bsource resistors with $R < \text{value}$ are clamped to value. It has high priority than rclamp if both are set. Default is 0.001 Ohm for bsource resistor.
saPrimeSimOptionrclampbsource UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionrcnetsave	string	custom	all	PrimeSim option rcnet_save: Flag to enable filter internal RC nodes for probe/save statement. Possible values are all and portonly.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionrcrcgnd	string	custom	1.00E-18	PrimeSim option rcr_cgnd: this parameter is used to set the minimum value of capacitance that should be decoupled to ground.
saPrimeSimOptionrcrfmax	string	custom	1	PrimeSim option rcr_fmax: this parameter is used to set the max frequency used by rc reduction.
saPrimeSimOptionrcrnetactivebitlineonly	string	custom	0	PrimeSim option rcr_net_active_bit_line_only: When set to 1, short all resistors of the parasitic networks that are connected to an active bit-line.
saPrimeSimOptionrcrnetactivestateonly	string	custom	0	PrimeSim option rcr_net_active_state_only: When set to 1, short all resistors of the parasitic networks that are connected to an active state.
saPrimeSimOptionrcrnetactivewordlineonly	string	custom	0	PrimeSim option rcr_net_active_word_line_only: When set to 1, short all resistors of the parasitic networks that are connected to an active word-line.
saPrimeSimOptionrcrnetcgnd	string	custom	1.00E-18	PrimeSim option rcr_net_cgnd: this parameter is used by the rc net flow to set the minimum value of capacitance that should be decoupled to ground.
saPrimeSimOptionrcrnetidlebitlineonly	string	custom	0	PrimeSim option rcr_net_idle_bit_line_only: When set to 1, short all resistors of the parasitic networks that are connected to an idle bit-line.
saPrimeSimOptionrcrnetidlestateonly	string	custom	0	PrimeSim option rcr_net_idle_state_only: When set to 1, short all resistors of the parasitic networks that are connected to an idle state.
saPrimeSimOptionrcrnetidlestatevpnonly	string	custom	0	PrimeSim option rcr_net_idle_state_vpn_only: When set to 1, short all resistors of VPN parasitic networks that are connected to idle state parasitic networks.
saPrimeSimOptionrcrnetidlewordlineonly	string	custom	0	PrimeSim option rcr_net_idle_word_line_only: When set to 1, short all resistors of the parasitic networks that are connected to an idle word-line.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionrcrnetmergepni dlestateports	string	custom	0	PrimeSim option rcr_net_merge_pn_idle_state_ports: When set to 1, allows merging of those ports of power or vpn parasitic networks, that are connected to idle state nodes.
saPrimeSimOptionrcrnetpreservea ctivebitlineports	string	custom	0	PrimeSim option rcr_net_preserve_active_bit_line_ports: When set to 1, preserves ports of parasitic networks that are connected to an active bit-line node.
saPrimeSimOptionrcrnetpreservea ctivestateports	string	custom	0	PrimeSim option rcr_net_preserve_active_state_ports: When set to 1, preserves ports of parasitic networks that are connected to an active-state node.
saPrimeSimOptionrcrnetpreservea ctivewordlineports	string	custom	0	PrimeSim option rcr_net_preserve_active_word_line_ports: When set to 1, preserves ports of parasitic networks that are connected to an active word-line node.
saPrimeSimOptionrcrnetpreserved rainsourcesignals	string	custom	0	PrimeSim option rcr_net_preserve_drain_source_signals: When set to 1, preserves ports of parasitic networks that are connected to a source and drain device terminals.
saPrimeSimOptionrcrnetpreserveid lebitlineports	string	custom	0	PrimeSim option rcr_net_preserve_idle_bit_line_ports: When set to 1, preserves ports of parasitic networks that are connected to an idle bit-line node.
saPrimeSimOptionrcrnetpreserveid lestateports	string	custom	0	PrimeSim option rcr_net_preserve_idle_state_ports: When set to 1, preserves ports of parasitic networks that are connected to an idle-state node.
saPrimeSimOptionrcrnetpreserveid lewordlineports	string	custom	0	PrimeSim option rcr_net_preserve_idle_word_line_ports: When set to 1, preserves ports of parasitic networks that are connected to an idle word-line node.
saPrimeSimOptionrcrnetpreservep nports	string	custom	0	PrimeSim option rcr_net_preserve_pn_ports: When set to 1, preserves ports of parasitic networks that are connected to a DC vsource.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionrcrnetpreservevpnpports	string	custom	0	PrimeSim option rcr_net_preserve_vpn_ports: When set to 1, preserves ports of parasitic networks that are connected to a VPN source.
saPrimeSimOptionrcrrshort	string	custom	1.00E-03	PrimeSim option rcr_rshort: this parameter is used to set the minimum value of resistor that should be cut.
saPrimeSimOptionrcut	string	custom	infinity	PrimeSim option rcut: Fixed value resistors with $R > \text{rcut}$ are replaced by open. Default is infinity for Spectre and $\text{MAX}(1/\text{GMIN}, 1\text{e}12)$ for APS. For bsource resistor, default is $1\text{e}12$ for Spectre and $\text{MAX}(1/\text{GMIN}, 1\text{e}12)$ for APS. If GMIN is not specified, the value of $\text{MAX}(1/\text{GMIN}, 1\text{e}12)$ is $1\text{e}12$. rcut can additionally be applied to variable resistors using the option 'short_cut_var_elem=yes'.
saPrimeSimOptionrebuildmatrix	string	custom	no	PrimeSim option rebuild_matrix: If set to yes, rebuild circuit matrix at the beginning of ac, dc, dcmatch, montecarlo, pz, stb, sweep, tdr, and tran analyses. This is to ensure consistent matrix ordering at the beginning of the analyses for consistent results. Notice that rebuild circuit matrix can result in performance overhead. Possible values are no and yes.
saPrimeSimOptionredefinedparameters	string	custom	error	PrimeSim option redefinedparams: Specify whether parameters can be redefined in the netlist. When set to warning or ignore, the simulator allows you to redefine parameters in the netlist. However, it honors only the last definition of the redefined parameter. Depending on the value set, the simulator displays warning messages for the redefined parameters or does not display any message. When set to error, the simulator does not allow you to redefine parameters in the netlist and displays an error message. Possible values are error, ignore, warning, and warn.
saPrimeSimOptionreelaborateonalter	string	custom	force	PrimeSim option reelaborateonalter: Whether re-elaborate for every alter statement. Possible values are lazy and force.
saPrimeSimOptionreltol	string	custom	0.001	PrimeSim option reltol: Relative convergence criterion.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionreplicates	string	custom		PrimeSim option replicates: Runs replicates of the Latin Hypercube samples
saPrimeSimOptionreplicatesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionresidualtol	string	custom	1.0	PrimeSim option residualtol: Tolerance ratio for residual (multiplies retol).
saPrimeSimOptionrforce	string	custom	1	PrimeSim option rforce: Resistance used when forcing nodesets and node-based initial conditions.
saPrimeSimOptionrisetime	string	custom		PrimeSim option risetime: Sets the smallest rise time of the signal
saPrimeSimOptionrisetimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionrmdgccs	string	custom	no	PrimeSim option rmdgccs: If yes, dangling controlled current source will be removed. Default value is no.. Possible values are no and yes.
saPrimeSimOptionrmomiagefile	string	saTestbench		PrimeSim option rm_omiage_file:
saPrimeSimOptionrmomiagefileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionrmtmiagefile	string	saTestbench		PrimeSim option rm_tmiage_file:
saPrimeSimOptionrmtmiagefileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionrthresh	string	custom	0.001	PrimeSim option rthresh: All instance resistors with $\text{abs}(R) < \text{rthresh}$ will use resistance form, unless their instance parameter or model parameter overwrites it.
saPrimeSimOptionrunlvl	string	custom	4	PrimeSim option runlvl: Controls runtime speed and simulation accuracy.
saPrimeSimOptionrunlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionsaetablefmt	string	custom	1	PrimeSim option saetablefmt: Format of SOA check output. If true, SOA results are returned in TSV files.
saPrimeSimOptionsaetablefmtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionssamplingmethod	string	custom		PrimeSim option sampling_method: Enables use of advanced sampling methods with traditional Gaussian Monte Carlo trials
saPrimeSimOptionssamplingmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionssaveby	string	saTestbench		PrimeSim option save_by:
saPrimeSimOptionssavebyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionsscale	string	custom	1.0	PrimeSim option scale: Device instance scaling factor.
saPrimeSimOptionsscalefactor	string	custom	1.0	PrimeSim option scale_factor: ScaleFactor for Device Model Technology Scaling. The options parameter scalefactor enables device model providers to scale device technology independent of the design dimension scaling done by circuit designers. The resulting device instance scaling is defined by 'scale * scalefactor'. If the foundry uses a technology scale factor of 0.9 (scalefactor=0.9), and the circuit designer uses a design scale factor of 1e-6 (scale=1e-6), then the compounded scaling of the device instance dimension is 0.9e-6. Unlike options parameter scale, scalefactor cannot be used as a netlist parameter and cannot be altered or used in sweep statements.
saPrimeSimOptionsscalefactorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionsscalem	string	custom	1.0	PrimeSim option scalem: Model scaling factor.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionsscaledredefined	string	custom	ignore	PrimeSim option scale_redefined: Disallow redefining of the option scale in netlist. Possible values are error, ignore, and warning.
saPrimeSimOptionsscaledredefinedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionsscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionsscalm	string	custom		PrimeSim option scalm: Sets the model scaling factor for device model parameters
saPrimeSimOptionsscalmUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionsscreeningmethod	string	saTestbench		PrimeSim option screening_method:
saPrimeSimOptionsscreeningmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionsearch	string	custom		PrimeSim option search: Finds files in a simulation
saPrimeSimOptionsearchUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionselemcachedir	string	saTestbench	<file path>	PrimeSim option s_elem_cache_dir:
saPrimeSimOptionselemcachedirUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionssensbinparam	string	custom	no	PrimeSim option sensbinparam: Sensitivity for binning models. Possible values are no, uncorrelated, and correlated.
saPrimeSimOptionssenscompositedevice	string	saTestbench		PrimeSim option sens_composite_device:
saPrimeSimOptionssenscompositedeviceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionssensfile	string	saTestbench	sensout.txt	PrimeSim option sensfile: Determines if ASCII files for sensitivity analysis results need to be generated, providing the path and filename to use.
saPrimeSimOptionssensfileonly	string	custom	no	PrimeSim option sensfileonly: Enable or disable raw output of sensitivity. results. Possible values are no and yes.
saPrimeSimOptionssensfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionssensformat	string	custom	tabular	PrimeSim option sensformat: Format of sensitivity data. Possible values are tabular and list.
saPrimeSimOptionssenssort	string	saTestbench	0	PrimeSim option senssort:
saPrimeSimOptionssenssortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionssenstype	string	custom	partial	PrimeSim option senstype: Type of sensitivity being calculated. Possible values are partial and normalized.
saPrimeSimOptionsetmissingvalues	string	saTestbench		PrimeSim option set_missing_values:
saPrimeSimOptionsetmissingvalueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionshighpass	string	saTestbench		PrimeSim option s_highpass:
saPrimeSimOptionshighpassUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimOptionshighpass is loaded.
saPrimeSimOptionsshortbjtr	string	custom	0.0	PrimeSim option short_bjtr: All parasitic resistors inside bipolar devices less than global short_bjtr will be removed. This option is applied to all bipolar junction transistors.
saPrimeSimOptionsshortcutnonconst	string	custom	no	PrimeSim option shortcutnonconst: Cut Non const value.. Possible values are yes and no.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionshrunkmosdiffdata	string	saTestbench	0	PrimeSim option shrunkmosdiffdata:
saPrimeSimOptionshrunkmosdiffdataUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionsimstat	string	custom	basic	PrimeSim option simstat: Print simulation phase statistics report. Possible values are basic and detailed.
saPrimeSimOptionskip	string	custom	none	PrimeSim option skip: Skip the simulating specified subckt instances. For now, cut is supported, which will leave the subckt ports disconnected. Possible values are none, load, and cut.
saPrimeSimOptionskipmacromos	string	custom	[...]	PrimeSim option skip_macro_mos: The list of subcircuit names, which is skipped to be a macro model.
saPrimeSimOptionsoamode	string	custom	0	PrimeSim option soa_mode: Option to choose one SOA check mode, 0 for customer's definition and 1 for Spectre's.
saPrimeSimOptionsoawarn	string	custom	yes	PrimeSim option soa_warn: If soa_warn is no, SOA warnings will be turned off. Possible values are no and yes.
saPrimeSimOptionsoftbin	string	custom	singlemodels	PrimeSim option soft_bin: If set to singlemodels, it is used only on non-binned models. Possible values are singlemodels, no, and allmodels.
saPrimeSimOptionsoibodyinitcontrol	string	saTestbench	0	PrimeSim option soi_body_init_control:
saPrimeSimOptionsoibodyinitcontrolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionsoibodyinitn	string	saTestbench		PrimeSim option soi_body_init_n:
saPrimeSimOptionsoibodyinitnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionsoibodyinitp	string	saTestbench		PrimeSim option soi_body_init_p:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionsoibodyinitpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionsoibodyinittype	string	saTestbench	0	PrimeSim option soi_body_init_type:
saPrimeSimOptionsoibodyinittypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionsortinstance	string	custom	no	PrimeSim option sortinstance: sort devices of the netlist. Possible values are no and yes. dF dF dp F dp F
saPrimeSimOptionspef	string	custom		PrimeSim option spef: This option specifies the SPEF file to be stitched and its stitching scope. The syntax is spef="scope filename". The scope can be a subcircuit or an instance. Use "spectre -h stitch" for more information.
saPrimeSimOptionspeftriplet	string	custom	2	PrimeSim option speftriplet: This option specifies the value to be used for stitching in the SPEF file. It is effective only when the values in the SPEF file are represented by triplets (for example, 0.325:0.41:0.495).. Possible values are 1, 2, and 3.
saPrimeSimOptionspf	string	custom		PrimeSim option spf: This option specifies the DSPF file to be stitched and its stitching scope. The syntax is spf="scope filename". The scope can be a subcircuit or an instance. Use "spectre -h stitch" for more information.
saPrimeSimOptionspfaliasterm	string	custom		PrimeSim option spfaliasterm: At times, the terminal names of devices in DSPF/SPEF/DPF files are different from those in the simulation model library. This happens in technology nodes that use subcircuits to model devices. The syntax is spfaliasterm="<model subckt> <prelayout_term0>=<spf_alias1> <prelayout_term2>=<spf_alias2> ... <prelayout_termN>=<spf_aliasN>". Multiple statements are supported. Use "spectre -h stitch" for more information.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionspfbusdelim	string	custom		PrimeSim option spfbusdelim: This option maps the bus delimiter between schematic netlist and parasitic file (i.e. DSPF, SPEF, or DPF). The option defines the bus delimiter in the schematic netlist, and optionally the bus delimiter in the parasitic file. By default the bus delimiter of the parasitic file is taken from the parasitic file header (that is, * BUSBIT [], * BUS_BIT [], or * BUS_DELIMITER []). If the bus delimiter is not defined in the parasitic file header, you need specify it using the spfbusdelim option in schematic netlist. For example, the option spfbusdelim="<>" is maps A<1> in the schematic netlist to A_1 in the DSPF file, if the bus delimiter header in the DSPF file is "_". The option spfbusdelim="@ []" maps A@1 in the schematic netlist to A[1] in the DSPF file (the bus delimiter in DSPF header will be ignored). See "spectre -h stitch" for more information.
saPrimeSimOptionspfnet	string	custom		PrimeSim option spfnet: This option specifies the net that has its total capacitance stitched. All other parasitic components such as parasitic resistors that are associated with this net are ignored. The complete hierarchical names are required and multiple statements are supported. Wildcards are supported. Use "spectre -h stitch" for more information.
saPrimeSimOptionspfnetfile	string	custom		PrimeSim option spfnetfile: This option has the same functionality as spfnet, except that it accepts a text file in which all the C-only stitched nets are listed. Only one file can be specified. The syntax is spfnetfile="filename". The format of the file requires you to specify one line per net. Use "spectre -h stitch" for more information.
saPrimeSimOptionspfinstancesect ion	string	custom	1	PrimeSim option spfinstancesect: This option controls the backannotation of device parameters in the instance section of the DSPF file. If spfinstancesect is turned off, the instance section is ignored (that is, the device parameters are not changed during stitching). The default is on. Use "spectre -h stitch" for more information.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionspfinstarraydelim	string	custom		PrimeSim option spfinstarraydelim: This option specifies the supplemental bus delimiter, if more than one bus delimiter is used in pre-layout netlist (usually for instance array indexing). It is similar to the spfbusdelim option. Use "spectre -h stitch" for more information.
saPrimeSimOptionspfmsglimit	string	custom		PrimeSim option spfmsglimit: This option specifies the maximum number of messages to be printed in the spfprt file. The syntax is spfmsglimit="number STITCH-ID_1 STITCH-ID_2". Use "spectre -h stitch" for more details.
saPrimeSimOptionspfnetcmin	string	custom	0	PrimeSim option spfnetcmin: This option allows you to select the net for stitching by the value of its total node capacitance. If a net's total node capacitance exceeds spfnetcmin, all parasitics associated with the net are stitched correctly, otherwise, only the total capacitance is added to the net node. Use "spectre -h stitch" for more information.
saPrimeSimOptionspfpostparam	string	custom	replace	PrimeSim option spfpostparam: This option specifies the instance parameters sourced for stitched instances. When set to replace, only the post-layout parameters are used and the pre-layout parameters are discarded. When set to append, both pre-layout and post-layout parameters are merged for the stitched instances where the post-layout parameters have higher priority. Possible values are append and replace.
saPrimeSimOptionspfprobenode	string	custom	net_only	PrimeSim option spfprobenode: When net_only, it is the only net name in SPF file that is used to match the wild card in .probe/.ic statements. The hierarchical structure of the net name is restored like pre-layout netlist. When all, the net name in SPF file is stored as pre-layout node name, and the nodes in SPF file are preserved like the current behavior. The wild card in .probe/.ic will match all the nodes and net names. Possible values are net_only and all.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionspfrcnet	string	custom		PrimeSim option spfrcnet: This option specifies the name of the net to be stitched with parasitic resistors and capacitors. The other nets are stitched with lumped total capacitances. Multiple statements are supported. Wildcards are supported and you can specify as many nets as needed. Complete hierarchical net names are required. Use "spectre -h stitch" for more information.
saPrimeSimOptionspfrcnetfile	string	custom		PrimeSim option spfrcnetfile: This option has the same functionality as spfrcnet, except that it accepts a text file in which all the RC stitched nets are specified. Only one file can be specified. The syntax is spfrcnetfile="filename". The format of the file requires you to specify one line per net. Use "spectre -h stitch" for more details.
saPrimeSimOptionspfscale	string	custom	1.0	PrimeSim option spfscale: This option specifies the scaling factor of all the elements in the parasitic files (DSPF/SPEF/DPF). Use "spectre -h stitch" for more details.
saPrimeSimOptionspfscalec	string	custom	1	PrimeSim option spfscalec: This option specifies the scale factor for parasitic capacitors.
saPrimeSimOptionspfscaler	string	custom	1	PrimeSim option pfscaler: This option specifies the scale factor for parasitic resistors.
saPrimeSimOptionspfskipnet	string	custom		PrimeSim option pfskipnet: This option specifies the net to be skipped for stitching, that is, all parasitic components of the net are not stitched. Wildcards are supported. You can specify multiple pfskipnet statements. Use "spectre -h stitch" for more information.
saPrimeSimOptionspfskipnetfile	string	custom		PrimeSim option pfskipnetfile: This option allows you to specify the nets to be skipped as a list in a text file. The syntax is pfskipnetfile="filename". Only one file can be specified. The format in the file is one line per net. Use "spectre -h stitch" for more information.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionspfswapterm	string	custom		PrimeSim option spfswapterm: This option specifies the swappable terminals of a subcircuit macro-model. The syntax is spfswapterm="terminal1 terminal2 subcktname". Use "spectre -h stitch" for more information.
saPrimeSimOptionspfxtorprefix	string	custom		PrimeSim option spfxtorprefix: This option specifies the prefix in the device or net names in the DSPF/SPEF/DPF file. The syntax is spfxtorprefix="substring [replace_substring]". Use "spectre -h stitch" for more information.
saPrimeSimOptionspicetype	string	saTestbench	0	PrimeSim option spice_type:
saPrimeSimOptionspicetypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionsrationalfunc	string	custom		PrimeSim option s_rational_func: Globally activates the rational function model in S-element analysis
saPrimeSimOptionsrationalfuncUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionsrationalfuncwindowing	string	custom		PrimeSim option s_rational_func_windowing: Globally activates the rational function windowing function for all S-elements in a netlist
saPrimeSimOptionsrationalfuncwindowingUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionssmooth	string	saTestbench	0	PrimeSim option ssmooth:
saPrimeSimOptionssmoothUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionstepdropsize	string	custom	100	PrimeSim option stepdropsize: The threshold size of step drop to report a dramatic change warning.
saPrimeSimOptionstvernote	string	custom	no	PrimeSim option stver_note: Give -stver suggestion warning for invalid parameter. Possible values are no and yes.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionsubcktiprobes	string	custom	yes	PrimeSim option subcktiprobes: Insert iprobes when computing subcircuit terminal currents. Possible values are no and yes.
saPrimeSimOptionsubcktoppoint	string	custom	no	PrimeSim option subcktoppoint: Output oppoint parameters of subckt instance. Possible values are no and yes.
saPrimeSimOptionsubcktswitch	string	custom	full	PrimeSim option subckt_switch: If set to simple, complex subckt will be mapped to simple subckt in mapsubckt. Possible values are full and simple.
saPrimeSimOptionsubcktvthchildproc	string	custom	yes	PrimeSim option subcktvthchildproc: Computing vth of subckt in child process. Possible values are no and yes.
saPrimeSimOptiontempeffects	string	custom	all	PrimeSim option tempeffects: Temperature effect selector. If tempeffect = vt, only thermal voltage varies with temperature; if tempeffect = tc, parameters that start with tc are active and thermal voltage is dependent on temperature; and if tempeffect = all, all built-in temperature models are enabled. Possible values are vt, tc, and all.
saPrimeSimOptiontermcurmethod	string	custom	default	PrimeSim option termcur_method: Select methods to compute terminal currents. Set termcur_method=complete to get correct currents when devices have no termcurs output. However, this may negatively impact performance.. Possible values are default and complete.
saPrimeSimOptionthermalmap	string	custom	%C:r.raw	PrimeSim option thermalmap: Output raw data file name.
saPrimeSimOptiontitle	string	custom		PrimeSim option title: Circuit title.
saPrimeSimOptiontmiage	string	custom	0	PrimeSim option tmiage: Activate TMI Aging model flow. By default, it is not activated.
saPrimeSimOptiontmiagemode	string	saTestbench		PrimeSim option tmiagemode:
saPrimeSimOptiontmiagemodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiontmiageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptiontmiagingremove slash	string	custom	0	PrimeSim option tmiaging_remove_slash: Internal option to remove the slash character before dot in instance name. By default it is closed.
saPrimeSimOptiontmiastcoredata	string	custom	0	PrimeSim option tmi_fast_core_data: Speed up TMI SOA/Age performance by fast TMI coredata evaluation..
saPrimeSimOptiontmiflag	string	custom	0	PrimeSim option tmiflag: Activate TMI flow. By default TMI flow is not activated.
saPrimeSimOptiontmiflagUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiontmiinput	string	custom		PrimeSim option tmiinput: input file name including full path to read back TMI information for aging model.
saPrimeSimOptiontmiinputUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiontmimapipolicy	string	saTestbench	0	PrimeSim option tmi_mapi_policy:
saPrimeSimOptiontmimapipolicyUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiontmioutput3dic	string	saTestbench		PrimeSim option tmi_output_3dic:
saPrimeSimOptiontmioutput3dicUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiontmipath	string	custom		PrimeSim option tmipath: Location of TMI shared object libraries to be used by tmiBsim4 models.
saPrimeSimOptiontmipathUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiontmisave	string	custom	1	PrimeSim option tmisave: Enable or disable aging information to be saved.
saPrimeSimOptiontmisaveUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptiontmisort	string	saTestbench		PrimeSim option tmisort:
saPrimeSimOptiontmisort	string	custom		PrimeSim option tmisort: Sort aging information.
saPrimeSimOptiontmisortUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiontmpltpol	string	custom		PrimeSim option tmplt_pol: Enables printing of PMOS template output voltage polarity as real bias
saPrimeSimOptiontmpltpolUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiontnom	string	custom	27	PrimeSim option tn timer: Temperature measurement of the default component parameter.
saPrimeSimOptiontnomUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptiontopcheck	string	custom	full	PrimeSim option topcheck: Check circuit topology for errors. Possible values are no, min, full, fixall, errmin, and errfull.
saPrimeSimOptiontryfastop	string	custom	yes	PrimeSim option try_fast_op: Speed up the DC solution. For hard-to-converge designs, this feature fails and other methods are applied. In corner cases, this feature may have negative effects. If the DC analysis is unusually slow, the memory usage of the processes keeps increasing, or if DC analysis gets stuck even before homotopy methods start, set this option to no. Possible values are no and yes.
saPrimeSimOptionunwrap	string	custom		PrimeSim option unwrap: Sets all phase results in AC analysis to be calculated in an unwrapped form
saPrimeSimOptionunwrapUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionuseagaussformat	string	saTestbench		PrimeSim option use_agauss_format:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimOptionuseagausform atUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionusetopparam3dic	string	saTestbench		PrimeSim option use_top_param_3dic:
saPrimeSimOptionusetopparam3dicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionuseveriloga	string	custom	0	PrimeSim option use_veriloga: Determine whether to take Verilog-A as high priority. If set to '1', the Verilog-A model takes priority over the other subckt/models. If set to '0', the Verilog-A model does not take priority over the other subckt/models..
saPrimeSimOptionvabsshort	string	custom	0.0	PrimeSim option vabsshort: Voltage sources with absolute DC voltage less than or equal to vabsshort are shorted. The default value in Spectre is 0, and in APS is 1e-9 V.
saPrimeSimOptionvabstol	string	custom	1.0e-6	PrimeSim option vabstol: Convergence criterion for absolute voltage tolerance.
saPrimeSimOptionvalue	string	custom	V	PrimeSim option value: Default value quantity.
saPrimeSimOptionverilogalang	string	custom	relax	PrimeSim option verilogalang: AHDL Verilog-A language syntax check mode selector. If verilogalang=strict, show archaic syntax input as an error during Verilog-A parsing; If verilogalang=relax, show archaic syntax input as a warning during Verilog-A parsing. Possible values are strict and relax.
saPrimeSimOptionvntol	string	custom		PrimeSim option vntol: Duplicates the ABSV option
saPrimeSimOptionvrefbins	string	custom	[...]	PrimeSim option vrefbins: Specifies the voltage bins when bin_relref=yes is used. Default setting is vrefbins=[1 3 5 10].
saPrimeSimOptionvrefgnd	string	custom		PrimeSim option vrefgnd: Specify reference ground.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimOptionvthmod	string	custom	std	PrimeSim option vthmod: Vth output selector. 'std' outputs model equation Vth; 'vthcc' outputs constant current Vth and may impact simulation performance; 'vthcc_ext' outputs constant current Vth on external nodes; 'maxgm' outputs maxgm Vth. Possible values are std, vthcc, vthcc_ext, and maxgm.
saPrimeSimOptionvthmodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionwarn	string	custom	0	PrimeSim option warn: Enables or turns off SOA voltage warning message (equivalent to primesim_soa_warn)
saPrimeSimOptionwarningchange severity	string	custom	warning	PrimeSim option warning_change_severity: Change the severity of warning messages specified in immediately following warning_id. Possible values are error, warning, and notice.
saPrimeSimOptionwarningid	string	custom	[...]	PrimeSim option warning_id: Vector of warning message identifiers, such as [SPECTRE-16462 SPECTRE-16684]. Used in conjunction with warning_limit or warning_change_severity.
saPrimeSimOptionwarninglimit	string	custom	5	PrimeSim option warning_limit: The maximum number of times the warnings specified in immediately following the warning_id parameter should be displayed.
saPrimeSimOptionwarnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimOptionwfdebug	string	custom	none	PrimeSim option wfdebug: Flag to store the measurement signal in a raw file. Possible values are none and measure.
saPrimeSimOptionwfmaxsize	string	custom	infinity	PrimeSim option wfmaxsize: Limits the maximum size of the output waveform. This option is valid when uwi format is set.
saPrimeSimOutputType	string	saTestbench	Voltage	PrimeSim Pole Zero Output Probe value type (current or voltage)

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimParasiticBackAnnotationTableColumnsShown	string	user	Enabled {Type} {Format} {Back Annotate} {Skip Nets} {Min R} {Other Options} {Instance Section}	Save columns shown in the Parasitic Back Annotation table.
saPrimeSimPZCenter	string	saTestbench		PrimeSim PZ: Center point of sweep limits
saPrimeSimPZDec	string	saTestbench		PrimeSim PZ: Number of logarithmic steps per decade
saPrimeSimPZDesignVar	string	saTestbench		PrimeSim PZ: Design variable being swept
saPrimeSimPZDev	string	saTestbench		PrimeSim PZ: Instance with parameter being swept
saPrimeSimPZDoSweep	string	saTestbench	0	PrimeSim PZ: Flag indicating a sweep is to be performed
saPrimeSimPZProbe	string	saTestbench		PrimeSim Pole Zero input device probe
saPrimeSimPZLin	string	saTestbench		PrimeSim PZ: Number of linear steps
saPrimeSimPZLog	string	saTestbench		PrimeSim PZ: Total number of logarithmic steps
saPrimeSimPZMod	string	saTestbench		PrimeSim PZ: Model with parameter being swept
saPrimeSimPZNegNode	string	saTestbench		PrimeSim Pole Zero Negative output node
saPrimeSimPZNode	string	saTestbench		PrimeSim Pole Zero Positive output node
saPrimeSimPZOProbe	string	saTestbench		PrimeSim Pole Zero output device probe
saPrimeSimPZOptionname	string	saTestbench		PrimeSim option name: analysis name

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimPZOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimPZOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimPZOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimPZOptionreadic	string	saTestbench		PrimeSim option read_ic: read file for .ic
saPrimeSimPZOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimPZOptionreadns	string	custom		PrimeSim option read_ns: File that contains an estimate of the DC solution (nodeset).
saPrimeSimPZOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimPZOptionwrite	string	saTestbench		PrimeSim option write: write file at the first point
saPrimeSimPZOptionwritefinal	string	saTestbench		PrimeSim option write_final: write file at the last point
saPrimeSimPZOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimPZOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimPZParam	string	saTestbench		PrimeSim PZ: Parameter being swept
saPrimeSimPZSpan	string	saTestbench		PrimeSim PZ: Span between sweep limits
saPrimeSimPZStart	string	saTestbench		PrimeSim PZ: Starting point of sweep limits
saPrimeSimPZStep	string	saTestbench		PrimeSim PZ: Linear step size

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimPZStepSpecLin	string	saTestbench	Number of Steps	PrimeSim PZ: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimPZStepSpecLog	string	saTestbench	Points per Decade	PrimeSim PZ: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimPZStop	string	saTestbench		PrimeSim PZ: Stopping point of sweep limits
saPrimeSimPZSub	string	saTestbench		PrimeSim PZ: Subcircuit with parameter being swept
saPrimeSimPZSweep	string	saTestbench	Linear	PrimeSim PZ: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimPZSweepSpec	string	saTestbench	<file path>	PrimeSim PZ: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimPZSweepVar	string	saTestbench	Temperature	PrimeSim PZ: Specifies what will be swept ("Design Variable" "Temperature")
saPrimeSimPZValues	string	saTestbench		PrimeSim PZ: Individual values, also known as points of interest
saPrimeSimRemoveBackslash	bool	user	true	Remove backslash from node names
saPrimeSimSaveOptionsEmTStart	string	saTestbench		Start time for electromigration current analysis
saPrimeSimSaveOptionsEmTStop	string	saTestbench		Stop time for electromigration current analysis
saPrimeSimSaveOptionsEnableEM	string	saTestbench	false	Save currents for in-design layout automation
saPrimeSimSaveOptionsEnableVDRC	string	saTestbench	false	Save voltage extremes to enable VDRC flow
saPrimeSimSaveOptionsKeepSelected	string	saTestbench	false	PrimeSim: Allow Voltage and Device Terminal Currents to be selected during migration. When true (the default), original settings selected for voltage and terminal currents are kept in the Save Options dialog box when migrating from FineSim to PrimeSim. If currents are selected, the Subckt Port Current option will be checked.
saPrimeSimSaveOptionsPower	string	saTestbench	0	PrimeSim: Save power signals for each device

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSaveOptionsSave	string	saTestbench	level	PrimeSim: Save net voltages
saPrimeSimSaveOptionsSaveLevel	string	saTestbench	1	PrimeSim: Save net voltages level
saPrimeSimSaveOptionsSubcktCurrents	string	saTestbench	selected	PrimeSim: Save subckt port currents
saPrimeSimSaveOptionsSubcktCurrentsLevel	string	saTestbench	1	PrimeSim: Save subckt port currents level
saPrimeSimSaveOptionsSubcktVoltages	string	saTestbench	selected	PrimeSim: Save subckt port voltages
saPrimeSimSaveOptionsSubcktVoltagesLevel	string	saTestbench	1	PrimeSim: Save subckt port voltages level
saPrimeSimSaveOptionsTerminalCurrents	string	saTestbench	selected	PrimeSim: Save device terminal currents
saPrimeSimSaveOptionsTerminalCurrentsLevel	string	saTestbench	1	PrimeSim: Save device terminal currents level
saPrimeSimSaveOptionsTerminalVoltages	string	saTestbench	selected	PrimeSim: Save device terminal voltages
saPrimeSimSaveOptionsTerminalVoltagesLevel	string	saTestbench	1	PrimeSim: Save device terminal voltages level
saPrimeSimSaveOptionsTotalPower	string	saTestbench	0	PrimeSim: Save total power
saPrimeSimSaveOptionsVdrcTStart	string	saTestbench		Start time for VDRC voltage analysis
saPrimeSimSaveOptionsVdrcTStop	string	saTestbench		Stop time for VDRC voltage analysis
saPrimeSimSENSBaseAnalysis	string	saTestbench	dc	Base Analysis for sensitivity analysis
saPrimeSimSENSOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimSENSOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimShowModelGroups	bool	saTestbench	false	Visibility of Model Groups table for PrimeSim

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSimulationCommandPrefix	string	xtJobClass		An environment initialization command to be added to simulation commands
saPrimeSimSNACCenter	string	saTestbench		PrimeSim SNAC: Center point of sweep limits
saPrimeSimSNACCrossdirection	string	saTestbench	all	PrimeSim SNAC: Crossing direction
saPrimeSimSNACDec	string	saTestbench		PrimeSim SNAC: Number of logarithmic steps per decade
saPrimeSimSNACLin	string	saTestbench		PrimeSim SNAC: Number of linear steps
saPrimeSimSNACLog	string	saTestbench		PrimeSim SNAC: Total number of logarithmic steps
saPrimeSimSNACMaxsamples	string	saTestbench		PrimeSim SNAC: Maximum number of sampled events
saPrimeSimSNACMaxsideband	string	saTestbench		PrimeSim SNAC: Maximum Sideband
saPrimeSimSNACOptionkryloviter	string	custom	200	PrimeSim option kryloviter: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*kryloviter iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the kryloviter if the simulation reports insufficient norm reduction errors in GMRES.
saPrimeSimSNACOptionkryloviterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNACOptionkrylovrestart	string	saTestbench		PrimeSim option krylovrestart: iteration to restart for the krylov subspace algorithm
saPrimeSimSNACOptionkrylovrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNACOptionmaxsideband	string	saTestbench		PrimeSim option maxsideband: the max sidebands in the output
saPrimeSimSNACOptionmaxsidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNACOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimSNACOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNACOptionsampledef	string	saTestbench		PrimeSim option sample_def: specify the measurement name to do the sample analysis
saPrimeSimSNACOptionsampledefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNACOptionsidebands	string	saTestbench		PrimeSim option sidebands: specify the sidebands in the output
saPrimeSimSNACOptionsidebandsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNACOptiontolerance	string	custom		PrimeSim option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saPrimeSimSNACOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNACRelharms	string	saTestbench	1	PrimeSim SNAC: Harmonic index number for relative sweep
saPrimeSimSNACSampled	string	saTestbench	0	PrimeSim SNAC: PTV analysis type
saPrimeSimSNACSampleType	string	saTestbench	Probe	PrimeSim SNAC: The type of sampling trigger to use (Probe or Voltage)
saPrimeSimSNACSidebands	string	saTestbench		PrimeSim SNAC: Sidebands
saPrimeSimSNACSidebandType	string	saTestbench	Unspecified	PrimeSim SNAC: Sideband type
saPrimeSimSNACSpan	string	saTestbench		PrimeSim SNAC: Span between sweep limits
saPrimeSimSNACStart	string	saTestbench		PrimeSim SNAC: Starting point of sweep limits

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNACStep	string	saTestbench		PrimeSim SNAC: Linear step size
saPrimeSimSNACStepSpecLin	string	saTestbench	Number of Steps	PrimeSim SNAC: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimSNACStepSpecLog	string	saTestbench	Points per Decade	PrimeSim SNAC: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimSNACStop	string	saTestbench		PrimeSim SNAC: Stopping point of sweep limits
saPrimeSimSNACSweep	string	saTestbench	Logarithmic	PrimeSim SNAC: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimSNACSweepSpec	string	saTestbench	<file path>	PrimeSim SNAC: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimSNACSweeptype	string	saTestbench	Default	PrimeSim SNAC: Frequency sweep type
saPrimeSimSNACTime	string	saTestbench		PrimeSim SNAC: Extra sample time points
saPrimeSimSNACVal	string	saTestbench		PrimeSim SNAC: Threshold value
saPrimeSimSNACValues	string	saTestbench		PrimeSim SNAC: Individual values, also known as points of interest
saPrimeSimSNAutotrinit	string	saTestbench	0	PrimeSim SN: Decide trinit Automatically
saPrimeSimSNCenter	string	saTestbench		PrimeSim SN: Center point of sweep limits
saPrimeSimSNDec	string	saTestbench		PrimeSim SN: Number of logarithmic steps per decade
saPrimeSimSNDesignVar	string	saTestbench		PrimeSim SN: Design variable being swept
saPrimeSimSNDetectsteady	string	saTestbench	0	PrimeSim SN: Automatic steady state detection during transient (trinit)
saPrimeSimSNDev	string	saTestbench		PrimeSim SN: Instance with parameter being swept
saPrimeSimSNDoloadPull	string	saTestbench	0	PrimeSim SN: Flag indicating a load pull sweep is to be performed

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNDLoadPullPort	string	saTestbench	0	PrimeSim SN: Flag indicating a port will serve as the load
saPrimeSimSNDoSweep	string	saTestbench	0	PrimeSim SN: Flag indicating a sweep is to be performed
saPrimeSimSNDpmethod	string	saTestbench	Vector	PrimeSim sn parameter values in file/vector
saPrimeSimSNDynamicParameters	bool	saTestbench	false	PrimeSim sn show/hide dynamic parameters
saPrimeSimSNFreqPeriod	string	saTestbench	Beat Frequency	PrimeSim SN: Declaring the Frequency or Period
saPrimeSimSNFundMode	string	saTestbench	Specify	PrimeSim SN: Mode for declaring the Frequency or Period
saPrimeSimSNHarmsType	string	saTestbench	Number	PrimeSim SN: Harmonics Specification Type
saPrimeSimSNLin	string	saTestbench		PrimeSim SN: Number of linear steps
saPrimeSimSNLINCenter	string	saTestbench		PrimeSim SNLIN: Center point of sweep limits
saPrimeSimSNLINDec	string	saTestbench		PrimeSim SNLIN: Number of logarithmic steps per decade
saPrimeSimSNLINFreqAxis	string	saTestbench	in	PrimeSim SNLIN: Freq Axis
saPrimeSimSNLINLin	string	saTestbench		PrimeSim SNLIN: Number of linear steps
saPrimeSimSNLINLog	string	saTestbench		PrimeSim SNLIN: Total number of logarithmic steps
saPrimeSimSNLINMaxSideband	string	saTestbench	1	PrimeSim SNLIN: Maximum Side Band
saPrimeSimSNLINNoisecalc	string	saTestbench	0	PrimeSim SNLIN: Do Noise
saPrimeSimSNLINOptiondataformat	string	saTestbench		PrimeSim option dataformat: format of values
saPrimeSimSNLINOptiondataformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNLINOOptionfilename	string	saTestbench		PrimeSim option filename: filename to write result
saPrimeSimSNLINOOptionfilenameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNLINOOptioniport	string	saTestbench	0	PrimeSim option iport: input port
saPrimeSimSNLINOOptioniportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNLINOOptionkryloviter	string	custom	200	PrimeSim option kryloviter: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*kryloviter iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the kryloviter if the simulation reports insufficient norm reduction errors in GMRES.
saPrimeSimSNLINOOptionkryloviterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNLINOOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimSNLINOOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNLINOOptionnoisecalc	string	saTestbench	0	PrimeSim option noisecalc: if 1, compute noise parameters
saPrimeSimSNLINOOptionnoisecalcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNLINOOptionoport	string	saTestbench	1	PrimeSim option oport: output port
saPrimeSimSNLINOOptionoportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNLINOOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNLINOOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNLINOOptionports	string	saTestbench		PrimeSim option ports: array of p elements
saPrimeSimSNLINOOptionportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNLINOOptionspcalc	string	saTestbench	1	PrimeSim option spcalc: if 1, compute scattering parameters
saPrimeSimSNLINOOptionspcalcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNLINOOptionprobes	string	saTestbench		PrimeSim option sprobes: array of probes
saPrimeSimSNLINOOptionprobesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNLINOOptiontolerance	string	custom		PrimeSim option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saPrimeSimSNLINOOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNLINSpan	string	saTestbench		PrimeSim SNLIN: Span between sweep limits
saPrimeSimSNLINStart	string	saTestbench		PrimeSim SNLIN: Starting point of sweep limits
saPrimeSimSNLINStep	string	saTestbench		PrimeSim SNLIN: Linear step size
saPrimeSimSNLINStepSpecLin	string	saTestbench	Number of Steps	PrimeSim SNLIN: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimSNLINStepSpecLog	string	saTestbench	Points per Decade	PrimeSim SNLIN: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimSNLINStop	string	saTestbench		PrimeSim SNLIN: Stopping point of sweep limits

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNLINSweep	string	saTestbench	Linear	PrimeSim SNLIN: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimSNLINSweepSpec	string	saTestbench	<file path>	PrimeSim SNLIN: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimSNLINSweepType	string	saTestbench	Default	PrimeSim SNLIN: Frequency sweep type
saPrimeSimSNLINValues	string	saTestbench		PrimeSim SNLIN: Individual values, also known as points of interest
saPrimeSimSNLoadstate	string	saTestbench		PrimeSim SN: Load state file
saPrimeSimSNLog	string	saTestbench		PrimeSim SN: Total number of logarithmic steps
saPrimeSimSNLp2Param	string	saTestbench		PrimeSim SN: lp2Param parameter being swept
saPrimeSimSNLp2Paramlin	string	saTestbench		PrimeSim SN: Number of lp2Param linear steps
saPrimeSimSNLp2Paramstart	string	saTestbench		PrimeSim SN: Starting point of lp2Param sweep limits
saPrimeSimSNLp2Paramstep	string	saTestbench		PrimeSim SN: Linear lp2Param step size
saPrimeSimSNLp2ParamStepSpecLin	string	saTestbench	Number of Steps	PrimeSim SN: Method of specifying lp2Param linear stepping ("Step Size" "Number of Steps")
saPrimeSimSNLp2Paramstop	string	saTestbench		PrimeSim SN: Stopping point of lp2Param sweep limits
saPrimeSimSNLp2ParamSweep	string	saTestbench	Linear	PrimeSim SN: Method of sweeping lp2Param values ("Linear" "Points of Interest")
saPrimeSimSNLp2Paramvalues	string	saTestbench		PrimeSim SN: Individual lp2Param values, also known as points of interest
saPrimeSimSNLpinst	string	saTestbench		PrimeSim SN: Port that loads the amplifier (hb only)
saPrimeSimSNLpParam	string	saTestbench		PrimeSim SN: lpParam parameter being swept
saPrimeSimSNLpParamlin	string	saTestbench		PrimeSim SN: Number of lpParam linear steps

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNLpParamstart	string	saTestbench		PrimeSim SN: Starting point of lpParam sweep limits
saPrimeSimSNLpParamstep	string	saTestbench		PrimeSim SN: Linear lpParam step size
saPrimeSimSNLpParamStepSpecLin	string	saTestbench	Number of Steps	PrimeSim SN: Method of specifying lpParam linear stepping ("Step Size" "Number of Steps")
saPrimeSimSNLpParamstop	string	saTestbench		PrimeSim SN: Stopping point of lpParam sweep limits
saPrimeSimSNLpParamSweep	string	saTestbench	Linear	PrimeSim SN: Method of sweeping lpParam values ("Linear" "Points of Interest")
saPrimeSimSNLpParamvalues	string	saTestbench		PrimeSim SN: Individual lpParam values, also known as points of interest
saPrimeSimSNLpz0	string	saTestbench		PrimeSim SN: Port impedance (hb only)
saPrimeSimSNMod	string	saTestbench		PrimeSim SN: Model with parameter being swept
saPrimeSimSNNharms	string	saTestbench		PrimeSim SN: Number of Harmonics
saPrimeSimSNNharmsvec	string	saTestbench		PrimeSim SN: Vector of Harmonics
saPrimeSimSNNOISECenter	string	saTestbench		PrimeSim SNNOISE: Center point of sweep limits
saPrimeSimSNNOISECrossingdirection	string	saTestbench	all	PrimeSim SNNOISE: Crossing Direction
saPrimeSimSNNOISEDec	string	saTestbench		PrimeSim SNNOISE: Number of logarithmic steps per decade
saPrimeSimSNNOISEFullspectrum	string	saTestbench	0	PrimeSim SNNOISE: Full Spectrum
saPrimeSimSNNOISELin	string	saTestbench		PrimeSim SNNOISE: Number of linear steps
saPrimeSimSNNOISELog	string	saTestbench		PrimeSim SNNOISE: Total number of logarithmic steps
saPrimeSimSNNOISEMaxsideband	string	saTestbench		PrimeSim SNNOISE: Maximum Sideband

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNNOISENoiseout	string	saTestbench	usb	PrimeSim SNNOISE: Noise Out
saPrimeSimSNNOISEOptionfullspectrum	string	saTestbench		PrimeSim option fullspectrum: if yes, the sampled noise is computed on full spectrum.
saPrimeSimSNNOISEOptionfullspectrumUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptionkryloviter	string	custom	200	PrimeSim option kryloviter: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*kryloviter iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the kryloviter if the simulation reports insufficient norm reduction errors in GMRES.
saPrimeSimSNNOISEOptionkryloviterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptionkrylovrestart	string	saTestbench		PrimeSim option krylovrestart: iteration to restart for the krylov subspace algorithm
saPrimeSimSNNOISEOptionkrylovrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptionlistcount	string	saTestbench	1	PrimeSim option listcount: For example, listcount=5 means that only the top 5 noise contributors are printed
saPrimeSimSNNOISEOptionlistcountUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptionlistfloor	string	saTestbench	1.0e-14	PrimeSim option listfloor: defines a minimum meaningful noise value (in V/Hz ^{1/2} units).
saPrimeSimSNNOISEOptionlistfloorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptionlistfreq	string	saTestbench		PrimeSim option listfreq: specify at which frequencies the element noise value is printed.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimSNNOISEOptionlistfreqUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptionlistsources	string	saTestbench	1	PrimeSim option listsources: specify if prints the contribution from each noise source
saPrimeSimSNNOISEOptionlistsourcesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptionmaxsideband	string	saTestbench		PrimeSim option maxsideband: the max sidebands in the output
saPrimeSimSNNOISEOptionmaxsidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimSNNOISEOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptionnoiseoutput	string	saTestbench	usb	PrimeSim option noise_output: noise type
saPrimeSimSNNOISEOptionnoiseoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimSNNOISEOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptionreferencesideband	string	saTestbench		PrimeSim option reference_sideband: the reference sideband to compute input noise
saPrimeSimSNNOISEOptionreferencesidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptionsample_def	string	saTestbench		PrimeSim option sample_def: specify the measurement name to do the sample analysis

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNNOISEOptionsampledUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptionsidebands	string	saTestbench		PrimeSim option sidebands: specify the sidebands in the output
saPrimeSimSNNOISEOptionsidebandsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOptiontolerance	string	custom		PrimeSim option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saPrimeSimSNNOISEOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNNOISEOutputType	string	saTestbench	Voltage	PrimeSim SNNOISE: Output type
saPrimeSimSNNOISERefsideband	string	saTestbench		PrimeSim SNNOISE: Conversion gain sideband
saPrimeSimSNNOISERelharms	string	saTestbench	1	PrimeSim SNNOISE: Harmonic index number for relative sweep
saPrimeSimSNNOISESampled	string	saTestbench	0	PrimeSim SNNOISE: Sampled
saPrimeSimSNNOISESampleratio	string	saTestbench		PrimeSim SNNOISE: Sample Ratio
saPrimeSimSNNOISESidebands	string	saTestbench		PrimeSim SNNOISE: Sidebands
saPrimeSimSNNOISESidebandType	string	saTestbench	Unspecified	PrimeSim SNNOISE: Sideband type
saPrimeSimSNNOISESpan	string	saTestbench		PrimeSim SNNOISE: Span between sweep limits
saPrimeSimSNNOISEStart	string	saTestbench		PrimeSim SNNOISE: Starting point of sweep limits
saPrimeSimSNNOISEStep	string	saTestbench		PrimeSim SNNOISE: Linear step size
saPrimeSimSNNOISEStepSpecLin	string	saTestbench	Number of Steps	PrimeSim SNNOISE: Method of specifying linear stepping ("Step Size" "Number of Steps")

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNNOISEStepSpecLog	string	saTestbench	Points per Decade	PrimeSim SNNOISE: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimSNNOISEStop	string	saTestbench		PrimeSim SNNOISE: Stopping point of sweep limits
saPrimeSimSNNOISESweep	string	saTestbench	Logarithmic	PrimeSim SNNOISE: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimSNNOISESweepSpec	string	saTestbench	<file path>	PrimeSim SNNOISE: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimSNNOISESweeptype	string	saTestbench	Default	PrimeSim SNNOISE: Frequency sweep type
saPrimeSimSNNOISEThresholdvalue	string	saTestbench		PrimeSim SNNOISE: Threshold Value
saPrimeSimSNNOISEValues	string	saTestbench		PrimeSim SNNOISE: Individual values, also known as points of interest
saPrimeSimSNOptionautotrinit	string	saTestbench	0	PrimeSim option autotrinit: automatically stop in the initial tran
saPrimeSimSNOptionautotrinitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptiondelmax	string	saTestbench		PrimeSim option delmax: max step for the tran in SN
saPrimeSimSNOptiondelmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptiondetectsteady	string	saTestbench	0	PrimeSim option detect_steady: detect the steady state in the given time region
saPrimeSimSNOptiondetectsteadyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionharmsarray	string	saTestbench		PrimeSim option harmsarray: harms to output in the file
saPrimeSimSNOptionharmsarrayUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptioninitmode	string	saTestbench	tran	PrimeSim option init_mode: mode for initialization

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNOptioninitmodeUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionkryloviter	string	saTestbe nch		PrimeSim option kryloviter: max iteration for the krylov subspace algorithm
saPrimeSimSNOptionkryloviterUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionkrylovrestart	string	saTestbe nch		PrimeSim option krylovrestart: iteration to restart for the krylov subspace algorithm
saPrimeSimSNOptionkrylovrestart UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionloadstate	string	saTestbe nch		PrimeSim option loadstate: load state file to initialize analyses
saPrimeSimSNOptionloadstateUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionlp2param	string	saTestbe nch		PrimeSim option lp2_param: the second parameters to sweep for load pull analysis
saPrimeSimSNOptionlp2paramUn checkLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionlpinst	string	saTestbe nch		PrimeSim option lp_inst: element name to sweep for load pull analysis
saPrimeSimSNOptionlpinstUnchec kLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionlpparam	string	saTestbe nch		PrimeSim option lp_param: the first parameters to sweep for load pull analysis
saPrimeSimSNOptionlpparamUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionlpz0	string	saTestbe nch		PrimeSim option lp_z0: the characteristic impedance to sweep for load pull analysis
saPrimeSimSNOptionlpz0Uncheck Localized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimSNOptionmaxiter	string	custom		PrimeSim option maxiter: Maximum number of iterations allowed before convergence is reached in shooting or harmonic balance Newton iteration. For SN, the default is 20 for driven circuits, and 50 for oscillators; For HB, the default is 100.
saPrimeSimSNOptionmaxiterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionmaxsideband	string	saTestbench		PrimeSim option maxsideband: the max sidebands in the output
saPrimeSimSNOptionmaxsidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionmaxtrinitcycles	string	saTestbench		PrimeSim option maxtrinitcycles: max cycles for the initial tran
saPrimeSimSNOptionmaxtrinitcyclesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimSNOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionnharms	string	saTestbench		PrimeSim option nharms: number of harmonics to use for each tone
saPrimeSimSNOptionnharmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimSNOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionparam	string	saTestbench		PrimeSim option param: option name to change in tran
saPrimeSimSNOptionparamdata	string	saTestbench		PrimeSim option param_data: value array to change the option specified by "param

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimSNOptionparamdataUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionperiod	string	saTestbench		PrimeSim option period: fundamental period
saPrimeSimSNOptionperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionreadic	string	custom		PrimeSim option read_ic: File that contains initial condition.
saPrimeSimSNOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionreadns	string	custom		PrimeSim option read_ns: File that contains an estimate of the initial transient solution.
saPrimeSimSNOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionsavestate	string	saTestbench		PrimeSim option savestate: save state to a file
saPrimeSimSNOptionsavestateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionsavetrinit	string	saTestbench	0	PrimeSim option save_trinit: if yes, save the waveform of initial tran
saPrimeSimSNOptionsavetrinitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionsteadyratio	string	custom		PrimeSim option steadyratio: Ratio used to compute steady-state tolerances from LTE tolerance.
saPrimeSimSNOptionsteadyratioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptiontones	string	saTestbench		PrimeSim option tones: Fundamental frequencies

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNOptiontonesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptiontrinit	string	saTestbench		PrimeSim option trinit: Transient initialization time
saPrimeSimSNOptiontrinitmethod	string	saTestbench	trap	PrimeSim option trinit_method: Sets the numerical integration method used during a transient analysis.
saPrimeSimSNOptiontrinitmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptiontrinitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionuic	string	custom	no	PrimeSim option uic: If set to yes, there is no DC analysis for initial transient. Possible values are no, yes.
saPrimeSimSNOptionuicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionwrite	string	custom		PrimeSim option write: File to which solution at first step in sweep is written.
saPrimeSimSNOptionwritefinal	string	saTestbench		PrimeSim option write_final: write file at the last point
saPrimeSimSNOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNOscillator	string	saTestbench	0	PrimeSim SN: Design is oscillator
saPrimeSimSNParam	string	saTestbench		PrimeSim SN: Parameter being swept
saPrimeSimSNParamdata	string	saTestbench		PrimeSim sn parameter data
saPrimeSimSNParamfile	string	saTestbench		PrimeSim sn parameter file

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNParamname	string	saTestbench		PrimeSim sn parameter
saPrimeSimSNSavestate	string	saTestbench		PrimeSim SN: Save state file
saPrimeSimSNSavetrinit	string	saTestbench	0	PrimeSim SN: Save Initial Transient Results
saPrimeSimSNSpan	string	saTestbench		PrimeSim SN: Span between sweep limits
saPrimeSimSNStart	string	saTestbench		PrimeSim SN: Starting point of sweep limits
saPrimeSimSNSTBCenter	string	saTestbench		PrimeSim SNSTB: Center point of sweep limits
saPrimeSimSNSTBDec	string	saTestbench		PrimeSim SNSTB: Number of logarithmic steps per decade
saPrimeSimSNSTBLin	string	saTestbench		PrimeSim SNSTB: Number of linear steps
saPrimeSimSNSTBLog	string	saTestbench		PrimeSim SNSTB: Total number of logarithmic steps
saPrimeSimSNSTBModeType	string	saTestbench	differential	PrimeSim SNSTB: Mode Type for diffstbprobe element
saPrimeSimSNSTBOptionkryloviter	string	saTestbench		PrimeSim option kryloviter: max iteration for the krylov subspace algorithm
saPrimeSimSNSTBOptionkryloviterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNSTBOptionkrylovrestart	string	saTestbench		PrimeSim option krylovrestart: iteration to restart for the krylov subspace algorithm
saPrimeSimSNSTBOptionkrylovrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNSTBOptionmaxsideband	string	saTestbench		PrimeSim option maxsideband: the max sidebands in the output
saPrimeSimSNSTBOptionmaxsidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNSTBOptionmode	string	saTestbench	single	PrimeSim option mode: If the feedback loop has a differential amplifier, then there are two signal
saPrimeSimSNSTBOptionmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNSTBOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimSNSTBOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNSTBOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimSNSTBOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNSTBOptiontolerance	string	custom		PrimeSim option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saPrimeSimSNSTBOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNSTBOptionvsource	string	saTestbench		PrimeSim option vsource: The 0V voltage source(s) indicating the insertion point of test circuit. Note that the direction of Vxxx is of significance in diff/comm mode analysis.
saPrimeSimSNSTBOptionvsourceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNSTBSpan	string	saTestbench		PrimeSim SNSTB: Span between sweep limits
saPrimeSimSNSTBStart	string	saTestbench		PrimeSim SNSTB: Starting point of sweep limits
saPrimeSimSNSTBStep	string	saTestbench		PrimeSim SNSTB: Linear step size

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNSTBStepSpecLin	string	saTestbench	Number of Steps	PrimeSim SNSTB: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimSNSTBStepSpecLog	string	saTestbench	Points per Decade	PrimeSim SNSTB: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimSNSTBStop	string	saTestbench		PrimeSim SNSTB: Stopping point of sweep limits
saPrimeSimSNSTBSweep	string	saTestbench	Logarithmic	PrimeSim SNSTB: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimSNSTBSweepSpec	string	saTestbench	<file path>	PrimeSim SNSTB: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimSNSTBValues	string	saTestbench		PrimeSim SNSTB: Individual values, also known as points of interest
saPrimeSimSNSTBVsource	string	saTestbench		PrimeSim SNSTB: oprobe instance around which the loop gain is calculated
saPrimeSimSNStep	string	saTestbench		PrimeSim SN: Linear step size
saPrimeSimSNStepSpecLin	string	saTestbench	Number of Steps	PrimeSim SN: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimSNStepSpecLog	string	saTestbench	Points per Decade	PrimeSim SN: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimSNStop	string	saTestbench		PrimeSim SN: Stopping point of sweep limits
saPrimeSimSNSub	string	saTestbench		PrimeSim SN: Subcircuit with parameter being swept
saPrimeSimSNSweep	string	saTestbench	Linear	PrimeSim SN: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimSNSweepSpec	string	saTestbench	<file path>	PrimeSim SN: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimSNSweepVar	string	saTestbench	Temperature	PrimeSim SN: Specifies what will be swept ("Design Variable" "Temperature")
saPrimeSimSNTonesfreq	string	saTestbench		PrimeSim SN: Beat Frequency

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNTonesperiod	string	saTestbench		PrimeSim SN: Beat Period
saPrimeSimSNTrinit	string	saTestbench		PrimeSim SN: Additional Time for Stabilization
saPrimeSimSNTextParam	string	saTestbench		PrimeSim SN: Parameter being swept
saPrimeSimSNValues	string	saTestbench		PrimeSim SN: Individual values, also known as points of interest
saPrimeSimSNXFCenter	string	saTestbench		PrimeSim SNXF: Center point of sweep limits
saPrimeSimSNXFCrossdirection	string	saTestbench	all	PrimeSim SNXF: Crossing direction
saPrimeSimSNXFDec	string	saTestbench		PrimeSim SNXF: Number of logarithmic steps per decade
saPrimeSimSNXFLin	string	saTestbench		PrimeSim SNXF: Number of linear steps
saPrimeSimSNXFLog	string	saTestbench		PrimeSim SNXF: Total number of logarithmic steps
saPrimeSimSNXFMaxsamples	string	saTestbench		PrimeSim SNXF: Maximum number of sampled events
saPrimeSimSNXFMaxsideband	string	saTestbench		PrimeSim SNXF: Maximum Sideband
saPrimeSimSNXFOptionkryloviter	string	custom	200	PrimeSim option kryloviter: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*kryloviter iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the kryloviter if the simulation reports insufficient norm reduction errors in GMRES.
saPrimeSimSNXFOptionkryloviter UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNXFOptionkrylovrestart	string	saTestbench		PrimeSim option krylovrestart: iteration to restart for the krylov subspace algorithm
saPrimeSimSNXFOptionkrylovrestart UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimSNXFOptionmaxsideband	string	saTestbench		PrimeSim option maxsideband: the max sidebands in the output
saPrimeSimSNXFOptionmaxsidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNXFOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimSNXFOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNXFOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimSNXFOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNXFOptionsample_def	string	saTestbench		PrimeSim option sample_def: specify the measurement name to do the sample analysis
saPrimeSimSNXFOptionsample_defUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNXFOptionsidebands	string	saTestbench		PrimeSim option sidebands: specify the sidebands in the output
saPrimeSimSNXFOptionsidebandsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNXFOptionstimuli	string	custom	sources	PrimeSim option stimuli: Stimuli used for pxf analysis. Possible values are sources and nodes_and_terminals.
saPrimeSimSNXFOptionstimuliUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNXFOptiontolerance	string	custom		PrimeSim option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNXFOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimSNXFOutputType	string	saTestbench	Voltage	PrimeSim SNXF: Output type
saPrimeSimSNXFRelharms	string	saTestbench	1	PrimeSim SNXF: Harmonic index number for relative sweep
saPrimeSimSNXFSampled	string	saTestbench	0	PrimeSim SNXF: PTV analysis type
saPrimeSimSNXFSampleType	string	saTestbench	Probe	PrimeSim SNXF: The type of sampling trigger to use (Probe or Voltage)
saPrimeSimSNXFSidebands	string	saTestbench		PrimeSim SNXF: Sidebands
saPrimeSimSNXFSidebandType	string	saTestbench	Unspecified	PrimeSim SNXF: Sideband type
saPrimeSimSNXFSpan	string	saTestbench		PrimeSim SNXF: Span between sweep limits
saPrimeSimSNXFStart	string	saTestbench		PrimeSim SNXF: Starting point of sweep limits
saPrimeSimSNXFStep	string	saTestbench		PrimeSim SNXF: Linear step size
saPrimeSimSNXFStepSpecLin	string	saTestbench	Number of Steps	PrimeSim SNXF: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimSNXFStepSpecLog	string	saTestbench	Points per Decade	PrimeSim SNXF: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimSNXFStop	string	saTestbench		PrimeSim SNXF: Stopping point of sweep limits
saPrimeSimSNXFSweep	string	saTestbench	Logarithmic	PrimeSim SNXF: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimSNXFSweepSpec	string	saTestbench	<file path>	PrimeSim SNXF: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimSNXFSweeptype	string	saTestbench	Default	PrimeSim SNXF: Frequency sweep type

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimSNXFTime	string	saTestbench		PrimeSim SNXF: Extra sample time points
saPrimeSimSNXFVal	string	saTestbench		PrimeSim SNXF: Threshold value
saPrimeSimSNXFValues	string	saTestbench		PrimeSim SNXF: Individual values, also known as points of interest
saPrimeSimThirdPartyDiffStbProbeFile	string	user	default	PrimeSim ThirdParty format diffstbprobe file path
saPrimeSimTolscaleMinimum	string	user	0.01	PrimeSim tolscale option minimum
saPrimeSimTRANAutostop	string	saTestbench	no	PrimeSim autostop
saPrimeSimTRANDPmethod	string	saTestbench	Vector	PrimeSim tran parameter values in file/vector
saPrimeSimTRANDynamicParameters	bool	saTestbench	false	PrimeSim tran show/hide dynamic parameters
saPrimeSimTRANFinalopfile	string	saTestbench		PrimeSim finalopfile
saPrimeSimTRANIctype	string	saTestbench	all	PrimeSim ictype
saPrimeSimTRANInstancesListExp	string	saTestbench	false	PrimeSim TRAN: Activation/Deactivation of noise instances list
saPrimeSimTRANMethod	string	saTestbench	trap	PrimeSim method
saPrimeSimTRANNoiseEnableSel	string	saTestbench	Enable	PrimeSim TRAN: Select if instances list correspond to noisy or noiseless devices
saPrimeSimTRANNoiseSeedStart	string	saTestbench		PrimeSim TRAN: Trannoise seed sweep start
saPrimeSimTRANNoiseSeedStop	string	saTestbench		PrimeSim TRAN: Trannoise seed sweep stop
saPrimeSimTRANOpfile	string	saTestbench		PrimeSim opfile

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimTRANOptionautostop	string	custom	no	PrimeSim option autostop: If yes, the analysis is terminated when all event-type measurement expressions have been evaluated. Event-type expressions use thresholding, event, or delay type functions. If the value is spice, autostop is consistent with spice simulator. Possible values are no, yes, and spice.
saPrimeSimTRANOptionautostopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptiondelmax	string	saTestbench		PrimeSim option delmax: max step for the tran
saPrimeSimTRANOptiondelmax	string	custom		PrimeSim option delmax: Maximum time step. The default is derived from `errpreset`.
saPrimeSimTRANOptiondelmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionfmax	string	saTestbench	0	PrimeSim option fmax: Parameter to invoke the transient noise analysis. A value turns on noise sources during transient analysis.
saPrimeSimTRANOptionfmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionfmin	string	saTestbench		PrimeSim option fmin: If specified, the flicker noise is included in transient analysis. The noise power density below noisefmin is constant.
saPrimeSimTRANOptionfminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionictype	string	custom	all	PrimeSim option ic_type: The value to be used to set the initial condition. Possible values are dc, node, dev, and all.
saPrimeSimTRANOptionictypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionmethod	string	custom	trap	PrimeSim option method: Integration method. Possible values are: be, trap, gear, egear.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimTRANOptionmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimTRANOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionnstart	string	saTestbench		PrimeSim option nstart: Start time during transient analysis when noise sources are activated.
saPrimeSimTRANOptionnstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionnstop	string	saTestbench		PrimeSim option nstop: Stop time during transient analysis when noise sources are activated.
saPrimeSimTRANOptionnstopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionoptimes	string	custom	[...]	PrimeSim option op_times: Times when analyses specified in 'acname' array are performed.
saPrimeSimTRANOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimTRANOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionoutputstart	string	custom	start	PrimeSim option outputstart: Output is saved only after this time is reached.
saPrimeSimTRANOptionparam	string	saTestbench		PrimeSim option param: option name to change in tran
saPrimeSimTRANOptionparamdata	string	saTestbench		PrimeSim option param_data: value array to change the option specified by "param"
saPrimeSimTRANOptionparamdataUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimTRANOptionparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionprimesimrestore	string	custom		PrimeSim option primesim_restore: Specify the file to be restored.
saPrimeSimTRANOptionreadic	string	custom		PrimeSim option read_ic: File that contains initial condition.
saPrimeSimTRANOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionreadns	string	custom		PrimeSim option read_ns: File that contains an estimate of the initial transient solution.
saPrimeSimTRANOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionsavefile	string	custom		PrimeSim option savefile: File to which initial transient solution is to be written.
saPrimeSimTRANOptionsavetime	string	custom		PrimeSim option savetime: File to which final transient solution is to be written.
saPrimeSimTRANOptionscale	string	saTestbench	1	PrimeSim option scale: Noise scale for all noise sources. Default is 1.
saPrimeSimTRANOptionscale	string	custom	1	PrimeSim option scale: Noise scale factor applied to all generated noise. Can be used to artificially inflate the small noise to make it visible above transient analysis numerical noise floor, but it should be small enough to maintain the nonlinear operation of the circuit .
saPrimeSimTRANOptionscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionseed	string	saTestbench	-1	PrimeSim option seed: Seed for random number generator. Default is -1 (0 is noiseless).
saPrimeSimTRANOptionseedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionsimstart	string	custom	0	PrimeSim option simstart: Start time.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimTRANOptionsimstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionsnapshotelapsed	string	custom		PrimeSim option snapshotelapsed: Save the tran analysis periodically on the wall clock time. The default is 1800s for Spectre. This parameter is disabled in the APS mode by default.
saPrimeSimTRANOptionsnapshotfile	string	custom		PrimeSim option snapshotfile: Save the analysis states into the specified file.
saPrimeSimTRANOptionsnapshotperiod	string	custom		PrimeSim option snapshotperiod: Save the tran analysis periodically on the simulation time.
saPrimeSimTRANOptionsnapshottime	string	custom	(...)	PrimeSim option snapshottime: Save the analysis states into files on the specified time points.
saPrimeSimTRANOptionstart	string	custom	0	PrimeSim option start: Start time.
saPrimeSimTRANOptionstep	string	custom		PrimeSim option step: Minimum time step used by the simulator solely to maintain the aesthetics of the computed waveforms.
saPrimeSimTRANOptionstrobedelay	string	custom	0	PrimeSim option strobe_delay: The delay (phase shift) between the skipstart time and the first strobe point.
saPrimeSimTRANOptionstrobedelayUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionstrobenSKIP	string	custom	1	PrimeSim option strobe_nskip: Equivalent to skipcount.
saPrimeSimTRANOptionstrobenSKIPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionstrobeperiod	string	custom	0	PrimeSim option strobe_period: The output strobe interval (in seconds) of transient time.
saPrimeSimTRANOptionstrobeperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionstrobestart	string	custom	0	PrimeSim option strobe_start: Equivalent to skipstart.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimTRANOptionstrobestar tUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionstrobes tep	string	custom	0	PrimeSim option strobestep: Equivalent to strobeperiod.
saPrimeSimTRANOptionstrobes top	string	custom	stop	PrimeSim option strobe_stop: Equivalent to skipstop.
saPrimeSimTRANOptionstrobesto pUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptiontrtol	string	custom		PrimeSim option trtol: Ratio used to compute LTE tolerances from Newton tolerance.
saPrimeSimTRANOptiontrtolUnch eckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimTRANOptiontrtol is loaded.
saPrimeSimTRANOptionuic	string	custom	no	PrimeSim option uic: If set to yes, there is no DC analysis for transient. Possible values are no, yes, useprevic, waveless, rampup, autodc, sigrampup, and dcrampup.
saPrimeSimTRANOptionwrite	string	custom		PrimeSim option write: File to which initial transient solution is to be written.
saPrimeSimTRANOptionwritefinal	string	custom		PrimeSim option write_final: File to which final transient solution is to be written.
saPrimeSimTRANOptionwritefinal UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANOptionwriteUnch eckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimTRANParamdata	string	saTestbe nch		PrimeSim tran parameter data
saPrimeSimTRANParamfile	string	saTestbe nch		PrimeSim tran parameter file
saPrimeSimTRANParamname	string	saTestbe nch		PrimeSim tran parameter
saPrimeSimTRANSaveparam	string	saTestbe nch	true	PrimeSim tran save dynamic parameter as a probe or not

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimTRANSimstart	string	saTestbench		PrimeSim simstart
saPrimeSimTRANStart	string	saTestbench	0	PrimeSim Transient start time
saPrimeSimTRANStep	string	saTestbench		PrimeSim Transient step
saPrimeSimTRANStop	string	saTestbench		PrimeSim Transient stop time
saPrimeSimTRANStrobedelay	string	saTestbench		PrimeSim strobedelay
saPrimeSimTRANStrobenskip	string	saTestbench		PrimeSim strobenskip
saPrimeSimTRANStrobeperiod	string	saTestbench		PrimeSim strobeperiod
saPrimeSimTRANStrobestart	string	saTestbench		PrimeSim strobestart
saPrimeSimTRANStrobestop	string	saTestbench		PrimeSim strobestop
saPrimeSimTRANTime	string	saTestbench		PrimeSim time
saPrimeSimTRANtnafmax	string	saTestbench		PrimeSim TRAN: A nonzero value turns on the noise sources during transient analysis
saPrimeSimTRANtnafmin	string	saTestbench		PrimeSim TRAN: If specified, PSD of the noise sources from fmin to fmax
saPrimeSimTRANtnascale	string	saTestbench		PrimeSim TRAN: Trannoise scale
saPrimeSimTRANtnaSeedSel	string	saTestbench	Fixed Value	PrimeSim TRAN: Trannoise seed type selection. Fixed value or sweep setup
saPrimeSimTRANtnaSeedVal	string	saTestbench	1	PrimeSim TRAN: Trannoise seed fixed value
saPrimeSimTRANtnatstart	string	saTestbench		PrimeSim TRAN: Trannoise nstart
saPrimeSimTRANtnatstop	string	saTestbench		PrimeSim TRAN: Trannoise nstop
saPrimeSimTRANTranNoise	string	saTestbench	false	PrimeSim TRAN: Enable/disable trannoise widgets

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimTRANTrtol	string	saTestbench		PrimeSim trtol
saPrimeSimTRANUIC	string	saTestbench	0	PrimeSim Transient uic
saPrimeSimVCSACCenter	string	saTestbench		PrimeSimVCS AC: Center point of sweep limits
saPrimeSimVCSACCenter	string	saTestbench		PrimeSimVCS AC: Center point of sweep limits
saPrimeSimVCSACDec	string	saTestbench		PrimeSimVCS AC: Number of logarithmic steps per decade
saPrimeSimVCSACDec	string	saTestbench		PrimeSimVCS AC: Number of logarithmic steps per decade
saPrimeSimVCSACDesignVar	string	saTestbench		PrimeSimVCS AC: Design variable being swept
saPrimeSimVCSACDesignVar	string	saTestbench		PrimeSimVCS AC: Design variable being swept
saPrimeSimVCSACDev	string	saTestbench		PrimeSimVCS AC: Instance with parameter being swept
saPrimeSimVCSACDev	string	saTestbench		PrimeSimVCS AC: Instance with parameter being swept
saPrimeSimVCSACFreq	string	saTestbench		PrimeSimVCS AC: Single value to hold frequency while other aspect is being swept
saPrimeSimVCSACFreq	string	saTestbench		PrimeSimVCS AC: Single value to hold frequency while other aspect is being swept
saPrimeSimVCSACLin	string	saTestbench		PrimeSimVCS AC: Number of linear steps
saPrimeSimVCSACLin	string	saTestbench		PrimeSimVCS AC: Number of linear steps
saPrimeSimVCSACLog	string	saTestbench		PrimeSimVCS AC: Total number of logarithmic steps
saPrimeSimVCSACLog	string	saTestbench		PrimeSimVCS AC: Total number of logarithmic steps
saPrimeSimVCSACMod	string	saTestbench		PrimeSimVCS AC: Model with parameter being swept
saPrimeSimVCSACMod	string	saTestbench		PrimeSimVCS AC: Model with parameter being swept

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSACOptionname	string	saTestbench		PrimeSimVCS option name: analysis name
saPrimeSimVCSACOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSACOptionotherOptions	string	custom		PrimeSimVCS option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimVCSACOptionreadic	string	saTestbench		PrimeSimVCS option read_ic: read file for .ic
saPrimeSimVCSACOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSACOptionreadns	string	saTestbench		PrimeSimVCS option read_ns: File that contains an estimate of the DC solution (nodeset).
saPrimeSimVCSACOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSACOptionwrite	string	saTestbench		PrimeSimVCS option write: write file at the first point
saPrimeSimVCSACOptionwritefinal	string	saTestbench		PrimeSimVCS option write_final: write file at the last point
saPrimeSimVCSACOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSACOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSACParam	string	saTestbench		PrimeSimVCS AC: Parameter being swept
saPrimeSimVCSACParam	string	saTestbench		PrimeSimVCS AC: Parameter being swept
saPrimeSimVCSACSpan	string	saTestbench		PrimeSimVCS AC: Span between sweep limits
saPrimeSimVCSACSpan	string	saTestbench		PrimeSimVCS AC: Span between sweep limits

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSACStart	string	saTestbench		PrimeSimVCS AC: Starting point of sweep limits
saPrimeSimVCSACStart	string	saTestbench		PrimeSimVCS AC: Starting point of sweep limits
saPrimeSimVCSACStep	string	saTestbench		PrimeSimVCS AC: Linear step size
saPrimeSimVCSACStep	string	saTestbench		PrimeSimVCS AC: Linear step size
saPrimeSimVCSACStepSpecLin	string	saTestbench	Number of Steps	PrimeSimVCS AC: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimVCSACStepSpecLin	string	saTestbench	Number of Steps	PrimeSimVCS AC: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimVCSACStepSpecLog	string	saTestbench	Points per Decade	PrimeSimVCS AC: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimVCSACStepSpecLog	string	saTestbench	Points per Decade	PrimeSimVCS AC: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimVCSACStop	string	saTestbench		PrimeSimVCS AC: Stopping point of sweep limits
saPrimeSimVCSACStop	string	saTestbench		PrimeSimVCS AC: Stopping point of sweep limits
saPrimeSimVCSACSub	string	saTestbench		PrimeSimVCS AC: Subcircuit with parameter being swept
saPrimeSimVCSACSub	string	saTestbench		PrimeSimVCS AC: Subcircuit with parameter being swept
saPrimeSimVCSACSweep	string	saTestbench	Logarithmic	PrimeSimVCS AC: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimVCSACSweep	string	saTestbench	Logarithmic	PrimeSimVCS AC: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimVCSACSweepSpec	string	saTestbench	<file path>	PrimeSimVCS AC: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimVCSACSweepSpec	string	saTestbench	<file path>	PrimeSimVCS AC: Method of specifying sweep limits ("Start/Stop" "Center/Span")

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSACSweepVar	string	saTestbench	Frequency (Hz)	PrimeSimVCS AC: Specifies what be swept ("Frequency (Hz)" "Design Variable" "Temperature" "None")
saPrimeSimVCSACSweepVar	string	saTestbench	Frequency (Hz)	PrimeSimVCS AC: Specifies what will be swept ("Frequency (Hz)" "Design Variable" "Temperature" "None")
saPrimeSimVCSACValues	string	saTestbench		PrimeSimVCS AC: Individual values, also known as points of interest
saPrimeSimVCSACValues	string	saTestbench		PrimeSimVCS AC: Individual values, also known as points of interest
saPrimeSimVCSAlwaysSaveSelectedOutputs	bool	user	false	Always write the save statement for saving the selected signals
saPrimeSimVCSAnalogSimulatorPath	string	user		Path to the analog simulator executable for PrimeSimVCS
saPrimeSimVCSBlockOptionsCategories	string	saTestbench	All	Categories
saPrimeSimVCSBlockOptionsSummary	string	saTestbench		Custom commands contents holder
saPrimeSimVCSDCCenter	string	saTestbench		PrimeSimVCS DC: Center point of sweep limits
saPrimeSimVCSDCDec	string	saTestbench		PrimeSimVCS DC: Number of logarithmic steps per decade
saPrimeSimVCSDCDesignVar	string	saTestbench		PrimeSimVCS DC: Design variable being swept
saPrimeSimVCSDCDev	string	saTestbench		PrimeSimVCS DC: Instance with parameter being swept
saPrimeSimVCSDCDoSweep	string	saTestbench	0	PrimeSimVCS DC: Flag indicating a sweep is to be performed
saPrimeSimVCSDCLin	string	saTestbench		PrimeSimVCS DC: Number of linear steps
saPrimeSimVCSDCLog	string	saTestbench		PrimeSimVCS DC: Total number of logarithmic steps
saPrimeSimVCSDCMod	string	saTestbench		PrimeSimVCS DC: Model with parameter being swept
saPrimeSimVCSDCOptionname	string	saTestbench		PrimeSimVCS option name: analysis name

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSDCOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDCOptionreadic	string	saTestbench		PrimeSimVCS option read_ic: read file for .ic
saPrimeSimVCSDCOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDCOptionreadns	string	saTestbench		PrimeSimVCS option read_ns: File that contains an estimate of the DC solution (nodeset).
saPrimeSimVCSDCOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDCOptionwrite	string	saTestbench		PrimeSimVCS option write: File to which solution at first step in sweep is written.
saPrimeSimVCSDCOptionwritefinal	string	saTestbench		PrimeSimVCS option write_final: File to which solution at last step in sweep is written.
saPrimeSimVCSDCOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDCOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDCParam	string	saTestbench		PrimeSimVCS DC: Parameter being swept
saPrimeSimVCSDCSaveOP	bool	saTestbench	true	PrimeSimVCS DC sweep: Save DC Operating Point
saPrimeSimVCSDCSpan	string	saTestbench		PrimeSimVCS DC: Span between sweep limits
saPrimeSimVCSDCStart	string	saTestbench		PrimeSimVCS DC: Starting point of sweep limits
saPrimeSimVCSDCStep	string	saTestbench		PrimeSimVCS DC: Linear step size
saPrimeSimVCSDCStepSpecLin	string	saTestbench	Number of Steps	PrimeSimVCS DC: Method of specifying linear stepping ("Step Size" "Number of Steps")

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSDCStepSpecLog	string	saTestbench	Points per Decade	PrimeSimVCS DC: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimVCSDCStop	string	saTestbench		PrimeSimVCS DC: Stopping point of sweep limits
saPrimeSimVCSDCSub	string	saTestbench		PrimeSimVCS DC: Subcircuit with parameter being swept
saPrimeSimVCSDCSweep	string	saTestbench	Linear	PrimeSimVCS DC: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimVCSDCSweepSpec	string	saTestbench	<file path>	PrimeSimVCS DC: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimVCSDCSweepVar	string	saTestbench	Temperature	PrimeSimVCS DC: Specifies what be swept ("Design Variable" "Temperature")
saPrimeSimVCSDCTextParam	string	saTestbench		PrimeSimVCS DC: Parameter being swept
saPrimeSimVCSDCValues	string	saTestbench		PrimeSimVCS DC: Individual values, also known as points of interest
saPrimeSimVCSDDefaultCornersSetup	string	saTestbench		PrimeSimVCS default corners setup
saPrimeSimVCSDDefaultIncludeFiles	string	saTestbench		PrimeSimVCS default include files
saPrimeSimVCSDDefaultModelFiles	string	saTestbench		PrimeSimVCS default model files to be loaded
saPrimeSimVCSDigitalOptionbase time	string	custom	ns	PrimeSimVCS option base_time: Overrides the default TIMEBASE value in the synopsys_sim.setup file
saPrimeSimVCSDigitalOptionbase timeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionboundscheck	string	custom	false	PrimeSimVCS option boundscheck: Does a bounds check on fixed size arrays and issues an error at compile-time
saPrimeSimVCSDigitalOptionboundscheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSDigitalOptiondebug	string	custom	post-process	PrimeSimVCS option debug: Specifies the debugging level for performance/control trade-offs (in order of decreasing performance and increasing control)
saPrimeSimVCSDigitalOptiondebugUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptiondumpvars	string	custom	false	PrimeSimVCS option dumpvars: A substitute for entering the \$dumpvars system task, without arguments, in your Verilog code
saPrimeSimVCSDigitalOptiondumpvarsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionelaborationverbosity	string	custom		PrimeSimVCS option elaboration_verbosity: Specifies notice, quiet or verbose mode for elaboration output file
saPrimeSimVCSDigitalOptionelaborationverbosityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionnoerrorOPCWM	string	custom	false	PrimeSimVCS option noerrorOPCWM: Changes the inout port connection width mismatch error condition to a warning condition
saPrimeSimVCSDigitalOptionnoerrorOPCWMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionnofalseneg	string	custom	false	PrimeSimVCS option nofalseneg: Suppress the xzcheck warning message unless the value of a conditional expression ends a simulation time step with an X or Z value
saPrimeSimVCSDigitalOptionnofalsenegUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionoverride_timescale_time_precision	string	custom		PrimeSimVCS option override_timescale_time_precision: Specifies the time precision portion of the override timescale (overrides `timescale compiler directives)
saPrimeSimVCSDigitalOptionoverride_timescale_time_precisionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSDigitalOptionoverride_timescale_time_unit	string	custom		PrimeSimVCS option override_timescale_time_unit: Specifies the time unit portion of the override timescale (overrides `timescale compiler directives)
saPrimeSimVCSDigitalOptionoverride_timescale_time_unitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionplusargs	string	custom		PrimeSimVCS option plusargs: Options for specifying user defined plusargs in a file
saPrimeSimVCSDigitalOptionplusargsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionsimulation_verbosity	string	custom		PrimeSimVCS option simulation_verbosity: Specifies quiet or verbose mode for simulation output file
saPrimeSimVCSDigitalOptionsimulation_verbosityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptiontime_res	string	custom		PrimeSimVCS option time_res: Overrides the default TIME_RESOLUTION value in the synopsys_sim.setup file
saPrimeSimVCSDigitalOptiontimeresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptiontimescale_time_precision	string	custom		PrimeSimVCS option timescale_time_precision: Specifies the time precision portion of the timescale for source files that do not contain the `timescale compiler directive
saPrimeSimVCSDigitalOptiontimescale_time_precisionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptiontimescale_time_unit	string	custom		PrimeSimVCS option timescale_time_unit: Specifies the time unit portion of the timescale for source files that do not contain the `timescale compiler directive
saPrimeSimVCSDigitalOptiontimescale_time_unitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSDigitalOptionunittimeprecision	string	custom		PrimeSimVCS option unit_timescale_time_precision: Specifies the time precision portion of the default timescale (used for the compilation-unit scope)
saPrimeSimVCSDigitalOptionunittimeprecisionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionunittimeunit	string	custom		PrimeSimVCS option unit_timescale_time_unit: Specifies the time unit portion of the default timescale (used for the compilation-unit scope)
saPrimeSimVCSDigitalOptionunittimeunitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionvcsflushall	string	custom	false	PrimeSimVCS option vcs_flush_all: Increases the frequency of dumping all log file, vcd files and files opened by \$fopen
saPrimeSimVCSDigitalOptionvcsflushallUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionvcsflushdump	string	custom	false	PrimeSimVCS option vcs_flush_dump: Increases the frequency of dumping all vcd files
saPrimeSimVCSDigitalOptionvcsflushdumpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionvcsflushfopen	string	custom	false	PrimeSimVCS option vcs_flush_fopen: Increases the frequency of dumping all files opened by \$fopen
saPrimeSimVCSDigitalOptionvcsflushfopenUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionvcsflushlog	string	custom	false	PrimeSimVCS option vcs_flush_log: Increases the frequency of dumping compilation and simulation log file
saPrimeSimVCSDigitalOptionvcsflushlogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionvcsinitreg	string	custom		PrimeSimVCS option vcs_initreg: Initialize all state variables to random values

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSDigitalOptionvcsinitregseed	string	custom		PrimeSimVCS option vcs_initreg_seed: Seed value for vcs_initreg
saPrimeSimVCSDigitalOptionvcsinitregseedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionvcsinitregUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionvpdnocompress	string	custom	false	PrimeSimVCS option vpdnocompress: Do not compress data written to VPD File
saPrimeSimVCSDigitalOptionvpdnocompressUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionvpdnostrengths	string	custom	false	PrimeSimVCS option vpdnostrengths: Do not write signal strength data to VPD File
saPrimeSimVCSDigitalOptionvpdnostrengthsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalOptionxzcheck	string	custom	false	PrimeSimVCS option xzcheck: Displays a warning message every time VCS evaluates a conditional expression to have an X or Z value
saPrimeSimVCSDigitalOptionxzcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSDigitalTimingSDFConfigDefault	string	user	true {} type {}	SDF Config Default for PrimeSimVCS
saPrimeSimVCSEnableCSVCheckExpressionOutputFormat	bool	user	true	Enable CSV output format for the check expression
saPrimeSimVCSEnvOptsAccuracyLevel	string	saTestbench	Default	Accuracy Level
saPrimeSimVCSEnvOptsAnalogSimulatorOptions	string	saTestbench		Analog Simulator Options
saPrimeSimVCSEnvOptsCaseSensitive	string	user	<default>	Simulator case setting
saPrimeSimVCSEnvOptsCommandLineOptions	string	saTestbench		Additional command line options for the PrimeSimVCS

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSEnvOptsCompilerOptions	string	saTestbench		Verilog Analyzer Options
saPrimeSimVCSEnvOptsDigitalOutputDataFormat	string	saTestbench	fsdb	Digital output data format
saPrimeSimVCSEnvOptsElaborationOptions	string	saTestbench		Elaboration Options
saPrimeSimVCSEnvOptsHSPICEStopViewList	string	saTestbench	hspice hspiceD functional behavioral symbol	Stop View List for HSPICE netlister
saPrimeSimVCSEnvOptsHSPICESwitchViewList	string	saTestbench	hspice hspiceD schematic verilog functional behavioral vhdl_config vhdl_spice veriloga verilogams	Switch View List for HSPICE netlister
saPrimeSimVCSEnvOptsIncludePath	string	saTestbench		Search path for PrimeSimVCS include files
saPrimeSimVCSEnvOptsMergedFile	bool	saTestbench	true	Enable merged results file
saPrimeSimVCSEnvOptsNetlistLanguage	string	user	HSPICE	Netlist language for PrimeSimVCS
saPrimeSimVCSEnvOptsNumProcesses	string	saTestbench	1	Number of threads
saPrimeSimVCSEnvOptsOutputDataFormat	string	saTestbench	fsdb	Analog output data format
saPrimeSimVCSEnvOptsProjCfg	string	saTestbench		Project Config File
saPrimeSimVCSEnvOptsStopViewList	string	saTestbench	hspice hspiceD functional behavioral symbol	Stop View List for netlister

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSEnvOptsSwitchViewList	string	saTestbench	hspice hspiceD schematic verilog functional behavioral vhdl_config vhdl_spice veriloga verilogams	Switch View List for netlister
saPrimeSimVCSEnvOptsThirdPartyStopViewList	string	saTestbench	spectre functional behavioral symbol	Stop View List for ThirdParty netlister
saPrimeSimVCSEnvOptsThirdPartySwitchViewList	string	saTestbench	spectre schematic verilog functional behavioral vhdl_config vhdl_spice veriloga verilogams	Switch View List for ThirdParty netlister
saPrimeSimVCSEnvOptsUse64Bit	bool	saTestbench	true	64-bit simulation
saPrimeSimVCSEnvOptsUseCacheDirInCommandLine	bool	user	false	Add pva_output_dir and s_elem_cache_dir in command line option
saPrimeSimVCSEnvOptsVhdlanOptions	string	saTestbench		VHDL Analyzer Options
saPrimeSimVCSHysteresis	bool	saTestbench	false	PrimeSimVCS DC hysteresis sweep
saPrimeSimVCSIncludeSchematicNetlist	bool	user	true	Copy (true) or .include (false) the structural netlist in the final netlist
saPrimeSimVCSModelGroups	string	saTestbench		Model groups for PrimeSimVCS
saPrimeSimVCSModelsFiles	string	saTestbench		Model files for PrimeSimVCS
saPrimeSimVCSModelsIncludePath	string	saTestbench		Search path for PrimeSimVCS model files
saPrimeSimVCSMonteCarloIp	string	saTestbench	0	Use Independent parallel simulation

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSMonteCarloIterList	string	saTestbench		list of iterations
saPrimeSimVCSMonteCarloLHSReplicates	string	saTestbench	1	Runs replicates of Latin Hypercube samples
saPrimeSimVCSMonteCarloLHSSampleSize	string	saTestbench		LHS sampling method sample size
saPrimeSimVCSMonteCarloNumParallelProcesses	string	saTestbench	1	Number of Independent parallel simulation processes
saPrimeSimVCSMonteCarloNumIterations	string	saTestbench	10	Number of iterations for montecarlo analysis
saPrimeSimVCSMonteCarloOFATIntervals	string	saTestbench	1	Generate 2n+1 equally spaced samples for each OFAT variable
saPrimeSimVCSMonteCarloOFATOneSided	bool	saTestbench	false	Enable/disable one-sided intervals
saPrimeSimVCSMonteCarloOFATOneSidedValue	string	saTestbench	0.5	Generate 2n+1 equally spaced samples for each OFAT variable
saPrimeSimVCSMonteCarloSamplingMethod	string	saTestbench	Sobol	Enables advanced sampling methods
saPrimeSimVCSMonteCarloSeed	string	saTestbench	1	Starting seed for the random-number generator in montecarlo analysis
saPrimeSimVCSMonteCarloSigmaScale	string	saTestbench	2.0	Sigma Amplification Factor for High Sigma Applications
saPrimeSimVCSMonteCarloStartingIteration	string	saTestbench		Starting iteration number for montecarlo analysis
saPrimeSimVCSMonteCarloUseIterationList	string	saTestbench	0	use iteration list
saPrimeSimVCSMonteCarloUseRandomSeed	string	saTestbench	0	Use random seed for random-number generator in montecarlo analysis
saPrimeSimVCSMonteCarloUseSigmaScaling	string	saTestbench	0	Uses Sigma Amplification for High Sigma Applications
saPrimeSimVCSMonteCarloVariationIncludeOrExclude	string	saTestbench	Include	Whether statistical variation is to be applied or not applied to the specified instances/cells
saPrimeSimVCSMonteCarloVariationInstanceOrCellList	string	saTestbench		List of instances or cells for which statistical variation is to be applied/not applied

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSMonteCarloVariationObjectType	string	saTestbench	Instances	Object type (instances or cells) for which statistical variation is to be applied/not applied
saPrimeSimVCSMonteCarloVariations	string	saTestbench	All	Statistical variation for montecarlo analysis
saPrimeSimVCSMsOptsA2DInterfaceElementDefault	string	user	1.0 2.0 v off net	A2D Interface Element Default for PrimeSimVCS
saPrimeSimVCSMsOptsConnectModulesInstallDirFilePatterns	string	user	snps_cm_*.vams	Installed Connect Modules File Patterns for PrimeSimVCS
saPrimeSimVCSMsOptsConnectModulesUserDir	string	user		User Connect Modules and Rules Directory for PrimeSimVCS
saPrimeSimVCSMsOptsConnectModulesUserDirFilePatterns	string	user		User Connect Modules File Patterns for PrimeSimVCS
saPrimeSimVCSMsOptsConnectRuleDefault	string	user	1 global {} voltage {}	Connect Rule Default for PrimeSimVCS
saPrimeSimVCSMsOptsConnectRulesInstallDirFilePatterns	string	user	snps_cr_*.vams	Installed Connect Rules File Patterns for PrimeSimVCS
saPrimeSimVCSMsOptsConnectRulesUserDirFilePatterns	string	user		User Connect Rules File Patterns for PrimeSimVCS
saPrimeSimVCSMsOptsD2AInterfaceElementDefault	string	user	false {} {} 0.1n midPoint 3.0 0 v net	D2A Interface Element Default for PrimeSimVCS
saPrimeSimVCSMsOptsDisciplineResolutionDefault	string	user	basic	Net Discipline Resolution Default for PrimeSimVCS
saPrimeSimVCSMsOptsE2NInterfaceElementDefault	string	user	th_wire {} 1 1k 1	E2N Interface Element Default for PrimeSimVCS
saPrimeSimVCSMsOptsE2RInterfaceElementDefault	string	user	false "" "" 1 "" "" net	E2R Interface Element Default for PrimeSimVCS
saPrimeSimVCSMsOptsEnableAMSIEReport	bool	user	false	Enables printing the connect module report into the log file for PrimeSimVCS. Valid values: true, false
saPrimeSimVCSMsOptsN2EInterfaceElementDefault	string	user	th_wire {} 1 10p 1 50 1G {} 1	N2E Interface Element Default for PrimeSimVCS
saPrimeSimVCSMsOptsNetDisciplineDefault	string	user	ddiscrete	Net Discipline Default for PrimeSimVCS

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSMsOptsR2EInterfaceElementDefault	string	user	false "" 1 "" net	R2E Interface Element Default for PrimeSimVCS
saPrimeSimVCSMsOptsResistanceMapDefault	string	user		Resistance Map Default for PrimeSimVCS
saPrimeSimVCSOptionOtherOptions	string	custom		PrimeSimVCS option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimVCSOptionTimes	string	saTestbench		PrimeSimVCS Operating point save time
saPrimeSimVCSOptionAbstol	string	custom		PrimeSimVCS option abstol: Sets the absolute error tolerance for branch currents in DC and transient analysis.
saPrimeSimVCSOptionAgePwInteg	string	saTestbench	0	PrimeSimVCS option age_pw_integ: Controls new mosra measure file format.
saPrimeSimVCSOptionAgePwIntegUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionAgeSkipFinalSim	string	saTestbench		PrimeSimVCS option age_skip_final_sim:
saPrimeSimVCSOptionAgeSkipFinalSimUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionAgeVariationCorner	string	saTestbench		PrimeSimVCS option age_variation_corner:
saPrimeSimVCSOptionAgeVariationCornerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionAhdlDomainError	string	custom	warning	PrimeSimVCS option ahdl_domain_error: AHDL domain error handling selector. If ahdl_domain_error=error, incorrect AHDL domain input is treated as an error; If ahdl_domain_error=warning, incorrect AHDL domain input is treated as warning; If ahdl_domain_error=none, AHDL domain error is ignored. Possible values are error, warning, none, erroriter, and warniter.
saPrimeSimVCSOptionAlterSelect	string	custom		PrimeSimVCS option alter_select: Enables selection of one or more alters from a list of alters

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionalterselectUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionamsaddfile sinlib	string	saTestbench		PrimeSimVCS option ams_add_files_in_lib:
saPrimeSimVCSOptionamsaddfile sinlibUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionamsdefault spicelib	string	saTestbench		PrimeSimVCS option ams_default_spice_lib:
saPrimeSimVCSOptionamsdefault spicelibUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionamsinstlibb indfile	string	saTestbench		PrimeSimVCS option ams_inst_lib_bind_file:
saPrimeSimVCSOptionamsinstlibb indfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionamsiprobes	string	custom	no	PrimeSimVCS option amsiprobes: Insert iprobes when computing MDL-related terminal currents. Possible values are no and yes.
saPrimeSimVCSOptionamsmerge subforcm	string	saTestbench		PrimeSimVCS option ams_merge_sub_for_cm:
saPrimeSimVCSOptionamsmerge subforcmUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionamsspicec hildchangemap	string	saTestbench		PrimeSimVCS option ams_spice_child_change_map:
saPrimeSimVCSOptionamsspicec hildchangemapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionamsspicep arameterpartitionfile	string	saTestbench		PrimeSimVCS option ams_spice_parameter_partition_file:
saPrimeSimVCSOptionamsspicep arameterpartitionfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionannotateonalter	string	custom	yes	PrimeSimVCS option annotateonalter: Annotate on all alter statements. Possible values are no and yes.
saPrimeSimVCSOptionapprox	string	custom	no	PrimeSimVCS option approx: Use approximate models. Difference between approximate and exact models is generally less public. Possible values are no and yes.
saPrimeSimVCSOptionaspec	string	custom		PrimeSimVCS option aspec: ASPEC-compatibility mode
saPrimeSimVCSOptionaspecUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionassertssilentinit	string	custom	[...]	PrimeSimVCS option asserts_silent_init: Array of asserts or assert groups which don't generate message during initializing.
saPrimeSimVCSOptionatxlvl	string	saTestbench		PrimeSimVCS option atxlvl:
saPrimeSimVCSOptionatxlvl	string	custom	4	PrimeSimVCS option atxlvl: Controls runtime speed and simulation accuracy.
saPrimeSimVCSOptionatxlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionaudit	string	custom	detailed	PrimeSimVCS option audit: Print time required by various parts of the simulator. Possible values are no, brief, detailed, and full.
saPrimeSimVCSOptionautominductor	string	custom	no	PrimeSimVCS option auto_minductor: Automatic insertion of missing mutual inductor coupling. For more information, see detailed description below the parameter descriptions. Possible values are no and yes.
saPrimeSimVCSOptionautosavecurvolt	string	custom	no	PrimeSimVCS option autosavecurvolt: Automatically save terminal currents and node voltage. Possible values are no and yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionautostop	string	custom	no	PrimeSimVCS option autostop: If yes, tran analysis is terminated when all event-type measurement expressions have been evaluated. Event-type expressions use thresholding, event, or delay type functions. If the value is spice, autostop is consistent with spice simulator. Possible values are no, yes, and spice.
saPrimeSimVCSOptionautostopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionBHTNewEval	string	custom	1	PrimeSimVCS option BHT_New_Eval: Option to choose which kind of evaluate function to use, 0 for old version with Vciei derivate and 1 for new one without Vciei derivate.
saPrimeSimVCSOptionbiaschkenable	string	saTestbench	0	PrimeSimVCS option biaschk_enable:
saPrimeSimVCSOptionbiaschkenableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionbiasfile	string	saTestbench		PrimeSimVCS option biasfile:
saPrimeSimVCSOptionbiasfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionbiasfmt	string	saTestbench	0	PrimeSimVCS option biasfmt:
saPrimeSimVCSOptionbiasfmtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionbinrelref	string	custom	no	PrimeSimVCS option bin_relref: When a global relref is used, signals share a common reference value for convergence checks. If there is a large voltage in the circuit this can artificially relax convergence checks for other signals. This option creates voltage bins so that large voltages do not impact nodes with small voltage swings. Possible values are no and yes.
saPrimeSimVCSOptionblockname	string	saTestbench		PrimeSimVCS option block_name:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionblocknameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptioncapicop	string	saTestbench		PrimeSimVCS option cap_ic_op:
saPrimeSimVCSOptioncapicopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptioncapicop is loaded.
saPrimeSimVCSOptioncaptop	string	custom		PrimeSimVCS option captop: Adds up all the capacitances attached to a node and prints a table of single-plate node capacitances
saPrimeSimVCSOptioncaptopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptioncclamp	string	custom	0.0	PrimeSimVCS option cclamp: All capacitors with C<=cclamp are clamped to 'cclamp'.
saPrimeSimVCSOptionccut	string	custom	-infinity	PrimeSimVCS option ccut: Capacitors with C<=ccut are replaced by open. ccut can additionally be applied to variable capacitors using the option 'short_cut_var_elem=yes'.
saPrimeSimVCSOptioncfprobemossstate	string	saTestbench		PrimeSimVCS option cf_probe_mos_state:
saPrimeSimVCSOptioncfprobemossstateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptioncgnd	string	custom	-infinity	PrimeSimVCS option cgnd: Coupling capacitors with C<=cgnd are split into 2 grounded capacitors with same C value.
saPrimeSimVCSOptionchargeabstol	string	custom	1.0e-21	PrimeSimVCS option chargeabstol: Charge absolute tolerance convergence criterion.
saPrimeSimVCSOptioncheckformat	string	custom	xml	PrimeSimVCS option check_format: Determine the format of the checker violation report. Possible values are xml, text, and sql.
saPrimeSimVCSOptionchecklimitdest	string	custom	sqldb	PrimeSimVCS option checklimitdest: Destination(s) where violations are written. Possible values are file, psf, sqldb, and both.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionchecklimitdetails	string	custom	no	PrimeSimVCS option checklimitdetails: Print detailed information of expression. Possible values are no and yes.
saPrimeSimVCSOptionchecklimitfile	string	custom		PrimeSimVCS option checklimitfile: File to which assert violations are written public.
saPrimeSimVCSOptionchecklimitfullduration	string	custom	no	PrimeSimVCS option checklimit_full_duration: If set to yes, assert violation includes the duration for which the violation takes place, and uses interpolation when the value exceeds the max/min bound value. Possible values are no and yes.
saPrimeSimVCSOptionchecklimitskipfile	string	custom		PrimeSimVCS option checklimit_skip_file: File which contains the subcircuit masters or subcircuit master patterns to be skipped in device checking. Patterns can have any wildcard symbols.
saPrimeSimVCSOptionchecklimitskipieconnectdevices	string	custom	no	PrimeSimVCS option checklimit_skip_ie_connect_devices: If set to yes, all devices connected to AMS IE elements will be skipped in device checking. Possible values are no and yes.
saPrimeSimVCSOptionchecklimitskipinsts	string	custom	[...]	PrimeSimVCS option checklimit_skip_insts: Array of instances to be skipped in device checking. Instances can have any wildcard symbols.
saPrimeSimVCSOptionchecklimitskipinstsfile	string	custom		PrimeSimVCS option checklimit_skip_insts_file: File which contains the instances to be skipped in device checking. Instances can have any wildcard symbols.
saPrimeSimVCSOptionchecklimitskipsubs	string	custom	[...]	PrimeSimVCS option checklimit_skip_subs: Array of subcircuit masters or subcircuit master patterns to be skipped in device checking. Patterns can have any wildcard symbols.
saPrimeSimVCSOptionckptclock	string	custom		PrimeSimVCS option ckptclock: Clock time checkpoint period. Default is 1800s for Spectre.
saPrimeSimVCSOptioncmax	string	custom	infinity	PrimeSimVCS option cmax: All capacitors with C>=cmax are clamped to 'cmax'.
saPrimeSimVCSOptioncmiflag	string	custom		PrimeSimVCS option cmiflag: Loads and links the dynamically linked Common Model Interface (CMI) library

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptioncmiflagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptioncmiopts	string	custom	[...]	PrimeSimVCS option cmi_opts: The option for customer cmi.
saPrimeSimVCSOptioncmipath	string	custom		PrimeSimVCS option cmipath: Specify the path to the Custom CMI .so library
saPrimeSimVCSOptioncmipathUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptioncmiusrflag	string	custom		PrimeSimVCS option cmiusrflag: Flag to control .OPTION SCALE parsing into the External Common Model Interface (CMI) invokes one additional CMI model function call when convergence criteria is met
saPrimeSimVCSOptioncmiusrflagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptioncmivth	string	custom		PrimeSimVCS option cmivth: For Custom CMI MOSFET model only
saPrimeSimVCSOptioncmivthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptioncols	string	custom	80	PrimeSimVCS option cols: Width of screen in characters.
saPrimeSimVCSOptioncolslog	string	custom	80	PrimeSimVCS option colslog: Width of log-file in characters.
saPrimeSimVCSOptioncompatible	string	custom	spectre	PrimeSimVCS option compatible: Encourage device equations to be compatible with a foreign simulator. This option does not affect input syntax. Possible values are spectre, spice2, spice3, cdss spice, hspice, spiceplus, and eldo.
saPrimeSimVCSOptioncrdpar	string	saTestbench		PrimeSimVCS option crdpar:
saPrimeSimVCSOptioncrdparmod	string	saTestbench	0	PrimeSimVCS option crdparmod:
saPrimeSimVCSOptioncrdparmodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptioncrdparUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptioncscalefactor	string	custom	1e-3	PrimeSimVCS option cscalefactor: Scaling factor for very large capacitor.
saPrimeSimVCSOptioncshunt	string	custom	0	PrimeSimVCS option cshunt: Minimum capacitance from each node to ground.
saPrimeSimVCSOptioncshuntUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptioncthresh	string	custom	1e38	PrimeSimVCS option cthresh: Large capacitors can cause transient convergence problems, especially as the time-step shrinks. This is similar to the issues that small resistors cause. There is an alternative exact representation of a capacitor, which does not suffer from this problem, but can introduce an equation to be solved. If a capacitance is greater than cthresh, then the alternative formulation is used. Accuracy is not impacted by the change. The 'cthresh' option has lower priority than 'cthresh' parameter on the capacitor instance definition.
saPrimeSimVCSOptiondcap	string	custom		PrimeSimVCS option dcap: Specifies equations used to calculate depletion capacitance for Level 1 and 3 diodes and BJTs
saPrimeSimVCSOptiondcapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiondcdiagnoseelements	string	custom	10	PrimeSimVCS option dc_diagnose_elements: Number of elements connected to non-converge nodes in printing diagnose information in DC simulation.
saPrimeSimVCSOptiondcdiagnosetime	string	custom	1800	PrimeSimVCS option dc_diagnose_time: Time interval for printing out diagnose information in DC simulation.
saPrimeSimVCSOptiondcic	string	custom		PrimeSimVCS option dcic: Specifies whether to use or ignore .IC commands in the netlist

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptiondclUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiondcmxiter	string	custom	5	PrimeSimVCS option dcmxiter: Maximum number of Newton iterations in DC simulation.
saPrimeSimVCSOptiondcmmod	string	custom	0	PrimeSimVCS option dcmmod: DCMismatch analysis version selector. If set to 1 or 3, uses Bsim short-channel mismatch equation for BSIM3 and BSIM4 devices; if set to 2 or 3, provides compatibility with Monte Carlo analysis.
saPrimeSimVCSOptiondcoptic	string	custom	aps1	PrimeSimVCS option dcoptic: Initial condition for dcopt in DC simulation. Possible values are no, aps1, aps2, and xps.
saPrimeSimVCSOptiondcoptictype	string	custom	nodeset	PrimeSimVCS option dcoptictype: Initial condition type for dcopt in DC simulation. Possible values are nodeset and ic.
saPrimeSimVCSOptiondcoptmaxsteps	string	custom	300	PrimeSimVCS option dcoptmaxsteps: Maximum number of steps for dcopt in DC simulation.
saPrimeSimVCSOptiondcopttol	string	custom	1e-8	PrimeSimVCS option dcopttol: Tolerance used for dcopt DC analysis..
saPrimeSimVCSOptiondcpivotcheck	string	custom	no	PrimeSimVCS option dc_pivot_check: During DC analysis, the numeric pivoting is only performed when bad pivot is detected. Possible values are no and yes.
saPrimeSimVCSOptiondcut	string	custom	[...]	PrimeSimVCS option dcut: Replaces all diode instances using the specified model definitions with an open. dcut=all cuts all diode elements.
saPrimeSimVCSOptiondebug	string	custom	no	PrimeSimVCS option debug: Give debugging messages. Possible values are no and yes.
saPrimeSimVCSOptiondebugstepdrop	string	custom	no	PrimeSimVCS option debugstepdrop: Generates warnings on dramatic step size drop and notices when step size is recovered. Possible values are no and yes.
saPrimeSimVCSOptiondefad	string	custom		PrimeSimVCS option defad: Sets the default MOSFET drain diode area

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptiondefadUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiondefas	string	custom		PrimeSimVCS option defas: Sets the default MOSFET source diode area
saPrimeSimVCSOptiondefasUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiondefl	string	custom		PrimeSimVCS option defl: Sets the default MOSFET channel length.
saPrimeSimVCSOptiondeflUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiondefnrd	string	custom		PrimeSimVCS option defnrd: Sets the default number of squares for the drain resistor on a MOSFET
saPrimeSimVCSOptiondefnrdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiondefnrs	string	custom		PrimeSimVCS option defnrs: Sets the default number of squares for the source resistor on a MOSFET
saPrimeSimVCSOptiondefnrsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiondefpd	string	custom		PrimeSimVCS option defpd: Sets the default MOSFET drain diode perimeter
saPrimeSimVCSOptiondefpdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiondefps	string	custom		PrimeSimVCS option defps: Sets the default MOSFET source diode perimeter
saPrimeSimVCSOptiondefpsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiondefw	string	custom		PrimeSimVCS option defw: Sets the default MOSFET channel width

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptiondefwUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiondetailedcorrelationfile	string	saTestbench		PrimeSimVCS option detailed_correlation_file:
saPrimeSimVCSOptiondetailedcorrelationfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiondevcheckstat	string	custom	yes	PrimeSimVCS option devcheck_stat: Enable or disable output device-checking statistics. Possible values are no and yes.
saPrimeSimVCSOptiondevropt	string	custom	none	PrimeSimVCS option devropt: If set to all, diode, or mosfet, connected resistors will be folded to related instances.. Possible values are none, all, diode, and mosfet.
saPrimeSimVCSOptiondiagnose	string	custom	no	PrimeSimVCS option diagnose: Print additional information that might help diagnose accuracy and convergence problems. Possible values are no, yes, and detailed.
saPrimeSimVCSOptiondiagnosedump_topnum	string	custom	5	PrimeSimVCS option diagnose_dump_topnum: Top number to dump single device netlist.
saPrimeSimVCSOptiondiagnose_end	string	custom		PrimeSimVCS option diagnose_end: End time to enable the detailed diagnosis mode. Default is transient stop time.
saPrimeSimVCSOptiondiagnose_start	string	custom	0	PrimeSimVCS option diagnose_start: Start time to enable the detailed diagnosis mode.
saPrimeSimVCSOptiondigits	string	custom	5	PrimeSimVCS option digits: Number of digits used when printing numbers.
saPrimeSimVCSOptiondioallowscaling	string	custom	no	PrimeSimVCS option dio_allow_scaling: Use this flag to enable SCALE parameter for diode mode. Possible values are no and yes.
saPrimeSimVCSOptiondisable_save_preserve	string	custom	no	PrimeSimVCS option disable_save_preserve: Disables preserve by save statements. If no, does not disable the save preserve. If yes, disables the save preserve. Possible values are no and yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptiondiskcheckautoresume	string	custom	no	PrimeSimVCS option disk_check_autoresume: Automatically resume the simulation once the available disk space is larger than the specified threshold. Possible values are no and yes.
saPrimeSimVCSOptiondiskcheckthreshold	string	custom	1E8	PrimeSimVCS option disk_check_thresh: The threshold of disk space check.
saPrimeSimVCSOptiondochecklimit	string	custom	yes	PrimeSimVCS option dochecklimit: Check asserts in the netlist. Possible values are no and yes.
saPrimeSimVCSOptiondotprobeformat	string	custom	flat	PrimeSimVCS option dotprobeformat: Print .probe signal with original name or hierarchical name. Possible values are flat and hier.
saPrimeSimVCSOptiondpf	string	custom		PrimeSimVCS option dpf: This option specifies DPF file to be stitched and its stitching scope. The syntax is dpf="scope filename". The scope can be a subcircuit or an instance. Use "spectre -h stitch" for more information.
saPrimeSimVCSOptiondptranmethod	string	custom	node	PrimeSimVCS option dptran_gmethod: Stamp gdev, gnode, or both in the dptran (homotopy) methods. Possible values are dev, node, and both.
saPrimeSimVCSOptiondptranmaxsteps	string	custom	300	PrimeSimVCS option dptranmaxsteps: Maximum number of steps for dptran in fast DC simulation.
saPrimeSimVCSOptiondspfnodename	string	custom	original	PrimeSimVCS option dspf_nodename: When original, The current behavior, .connect is created for nodes cut by DSPF translator. When net_only, it is the only net name in DSPF file that is used to match the wild card in .probe/.ic statements. The hierarchical structure of the net name is restored like pre-layout netlist. When all, the net name in DSPF file is stored as pre-layout node name, and the nodes in DSPF file are preserved like the current behavior. The wild card in .probe/.ic will match all the nodes and net names. Possible values are original, net_only, and all.
saPrimeSimVCSOptiondumpglobaloptions	string	custom	0	PrimeSimVCS option dump_global_options: Internal option for RelXpert to dump all the global options . By default it is closed.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptiondumpwildcardinfo	string	custom	no	PrimeSimVCS option dump_wildcard_info: Dump wildcard matching details in save statement into a single file. Possible values are no and yes.
saPrimeSimVCSOptionduplicateinstance	string	custom	error	PrimeSimVCS option duplicateinstance: Specify whether duplicate instance definitions are allowed. When set to warning or ignore, the simulator allows duplicate instance definitions. However, it honors only the last instance definition. Depending on the value that is set, the simulator displays warning messages for the duplicate instance definitions or does not display any message. When set to error, the simulator does not allow duplicate instance definitions and displays an error message. Possible values are error, ignore, and warning.
saPrimeSimVCSOptionduplicatemodel	string	custom	error	PrimeSimVCS option duplicatemodel: Specify whether duplicate model definitions are allowed. When set to warning or ignore, the simulator allows duplicate model definitions. However, it honors only the last model definition. Depending on the value that is set, the simulator displays warning messages for the duplicate model definitions or does not display any message. When set to error, the simulator does not allow duplicate model definitions and displays an error message. Possible values are error, ignore, and warning.
saPrimeSimVCSOptionduplicatemodule	string	custom	error	PrimeSimVCS option duplicate_module: Specifies whether the duplicate module definitions are allowed. When set to warning or ignore, the simulator allows duplicate module definitions. However, it honors only the last module definition. Depending on the value that is set, the simulator decides whether to display warning messages for the duplicate module definitions or not. When set to error, the simulator does not allow the duplicate module definitions and displays an error message. Possible values are error, ignore, and warning.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionduplicateports	string	custom	error	PrimeSimVCS option duplicateports: Specify whether duplicate ports are allowed in the definition of the subcircuit. When set to warning or ignore, the duplicate ports are shorted. Depending on the value that is set, the simulator displays warning messages for the duplicate ports or does not display any message. When set to error, the simulator does not allow duplicate ports in the definition of the subcircuit and displays an error message. Possible values are error, ignore, and warning.
saPrimeSimVCSOptionduplicate_subckt	string	custom	error	PrimeSimVCS option duplicate_subckt: Specify whether duplicate subcircuit definitions are allowed. When set to warning or ignore, the simulator allows duplicate subcircuit definitions. However, it honors only the last subcircuit definition. Depending on the value that is set, the simulator displays warning messages for the duplicate subcircuit definitions or does not display any message. When set to error, the simulator does not allow duplicate subcircuit definitions and displays an error message. Possible values are error, ignore, and warning.
saPrimeSimVCSOptionengine	string	custom	PrimeSim SPICE VCS	PrimeSimVCS option engine: Simulation Engine
saPrimeSimVCSOptionengineUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionerror	string	custom	yes	PrimeSimVCS option error: Generate error messages. Possible values are no and yes.
saPrimeSimVCSOptionetmiagechk	string	saTestbench	0	PrimeSimVCS option etmiagechk:
saPrimeSimVCSOptionetmiagechkUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionetmiallinst	string	saTestbench	0	PrimeSimVCS option etmiallinst:
saPrimeSimVCSOptionetmiallinstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionetmicoredata	string	saTestbench	0	PrimeSimVCS option etmicoredata:
saPrimeSimVCSOptionetmicoredataUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionetmifnosharesubckt	string	saTestbench		PrimeSimVCS option etmif_noshare_subckt:
saPrimeSimVCSOptionetmifnosharesubcktUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionetmifsharemod	string	saTestbench	0	PrimeSimVCS option etmif_sharemod:
saPrimeSimVCSOptionetmifsharemodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionetmiidsmod	string	saTestbench	0	PrimeSimVCS option etmiidsmod:
saPrimeSimVCSOptionetmildsMod	string	custom	0	PrimeSimVCS option etmildsMod: Switch to select lds or total DC drain current for TMI core data ids.
saPrimeSimVCSOptionetmiidsmodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionetmimasterprocessend	string	saTestbench	0	PrimeSimVCS option etmimasterprocessend:
saPrimeSimVCSOptionetmimasterprocessendUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionetmiprint	string	saTestbench	0	PrimeSimVCS option etmiprint:
saPrimeSimVCSOptionetmiprintUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionetmiprintfd	string	custom	0	PrimeSimVCS option etmiprintfd: Output the TMI result file. By default it is closed.
saPrimeSimVCSOptionetmisoa	string	saTestbench	0	PrimeSimVCS option etmi_soa:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionetmisoaUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionetmiusrinput	string	custom		PrimeSimVCS option etmiusrinput: This option can be set in model files or netlists.
saPrimeSimVCSOptionetmiusrinputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionetmiusrstring	string	saTestbench		PrimeSimVCS option etmiusrstring:
saPrimeSimVCSOptionetmiusrstringUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionexportfile	string	custom		PrimeSimVCS option exportfile: oceanEval output file name.
saPrimeSimVCSOptionextdatapath	string	saTestbench		PrimeSimVCS option extdatapath:
saPrimeSimVCSOptionextdatapathUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionexternalfile	string	saTestbench		PrimeSimVCS option external_file:
saPrimeSimVCSOptionexternalfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionfastsensmethod	string	saTestbench		PrimeSimVCS option fast_sens_method:
saPrimeSimVCSOptionfastsensmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionfixsingularmatrix	string	custom	no	PrimeSimVCS option fix_singular_matrix: Fix matrix singular issue by inserting gmin. Possible values are no, yes, print, and both.
saPrimeSimVCSOptionflow	string	custom	1	PrimeSimVCS option flow: Default flow quantity.
saPrimeSimVCSOptiongdcpath	string	custom		PrimeSimVCS option gdcpath: Adds conductance to nodes having no DC path to ground

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptiongdcpathUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiongencurpol	string	custom		PrimeSimVCS option gen_cur_pol: Specifies whether the generic current polarity maintains backward compatibility with PrimeSim simulation files.
saPrimeSimVCSOptiongencurpolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiongennetlistdir	string	custom	no	PrimeSimVCS option gennetlistdir: Output netlist directory in logfile. Possible values are no and yes.
saPrimeSimVCSOptiongeoshrink	string	custom		PrimeSimVCS option geoshrink: Some of the latest process models have a new scale factor called geoshrink to shrink device geometry.
saPrimeSimVCSOptiongeoshrinkUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiongerationalfunc	string	custom		PrimeSimVCS option ge_rational_func: Specifies the method used for Laplace transform source convolution
saPrimeSimVCSOptiongerationalfuncUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiongformvcr	string	custom		PrimeSimVCS option gform_vcr: Use Gform for VCR device. Specify 1 for yes and 0 for no. Default is no.
saPrimeSimVCSOptiongmethod	string	custom	dev	PrimeSimVCS option gmethod: Stamp gdev, gnode, or both in the homotopy methods (other than dptran). See the detailed description below the parameter descriptions for more information. Possible values are dev, node, and both.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptiongmin	string	custom	1e-12	PrimeSimVCS option gmin: gmin (conductance) is added to each nonlinear branch of the device to prevent simulation non-convergence. Large gmin impacts accuracy of current probe, small gmin may cause circuit convergence issue. For circuit that is sensitive to leakage current, it is recommended to set gmin to a small value or zero.
saPrimeSimVCSOptiongmincheck	string	custom	max_v_only	PrimeSimVCS option gmin_check: Specifies that effect of 'gmin' should be reported if significant. Possible values are no, max_v_only, max_only, and all.
saPrimeSimVCSOptiongmindc	string	custom	1e-12	PrimeSimVCS option gmindc: Minimum conductance across each non-linear device in DC analysis. Default value is 1.0e-12.
saPrimeSimVCSOptiongmindcmax	string	custom		PrimeSimVCS option gmindcmax: The maximum value that gmindc can be increased to during the automatically increasing gmindc method for convergence. The default value is gmindc.
saPrimeSimVCSOptiongmindcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiongminstart	string	custom	1.0	PrimeSimVCS option gmin_start: Initial gmin in gmin-stepping (homotopy) methods.
saPrimeSimVCSOptiongminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiongramp	string	custom		PrimeSimVCS option gramp: Sets the conductance range over which gmindc is to be swept during the gmin ramping mechanism of the DC convergence assist algorithm
saPrimeSimVCSOptiongrampUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiongshdc	string	saTestbench		PrimeSimVCS option gshdc:
saPrimeSimVCSOptiongshdc	string	custom	0.0	PrimeSimVCS option gshdc: Minimum conductance added for all nodes in dc analysis.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptiongshdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiongshunt	string	custom	0.0	PrimeSimVCS option gshunt: Minimum conductance added for all nodes in tran analysis.
saPrimeSimVCSOptiongshuntUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionhierambiguity	string	custom	strict	PrimeSimVCS option hier_ambiguity: The default value is strict. When set to lower, the simulator will partially flatten the hier name from the back to check if an object can be found. Lower is not recommended. Possible values are strict and lower.
saPrimeSimVCSOptionhierdelimiter	string	custom	.	PrimeSimVCS option hier_delimiter: Used to set hierarchical delimiter. Length of hier_delimiter should not be longer than 1, except the leader escape character.
saPrimeSimVCSOptionhierprobe	string	custom	hier	PrimeSimVCS option hierprobe: Print .probe signal hierarchically or flatten. Possible values are flat and hier.
saPrimeSimVCSOptionhighvoltage	string	custom	no	PrimeSimVCS option highvoltage: Enable optimized Spectre settings for high voltage designs including voltage, and current binning, excluding VerilogA and dangling nodes from convergence checks, and optimized large capacitance handling. Possible values are no and yes.
saPrimeSimVCSOptionhomotopy	string	custom	all	PrimeSimVCS option homotopy: Method used when there is no convergence on initial attempt of DC analysis. You can specify methods and their orders by defining vector setting such as homotopy=[source ptran gmin]. Possible values are none, gmin, source, dptran, ptran, arclength, tranrampup, and all.
saPrimeSimVCSOptionhsmhvext	string	saTestbench	0	PrimeSimVCS option hsmhvext:
saPrimeSimVCSOptionhsmhvextUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptioniabstol	string	custom	1.0e-12	PrimeSimVCS option iabstol: Convergence criterion for absolute current tolerance.
saPrimeSimVCSOptioniccapcheck	string	custom	yes	PrimeSimVCS option iccapcheck: Check if nodes with initial conditions have capacitive path to ground. IC for the node without capacitance is treated as nodeset. Possible values are no and yes.
saPrimeSimVCSOptionicpriority	string	custom	netlist	PrimeSimVCS option icpriority: Set the ic priority order. If set to netlist, the order from lowest to highest is readNS, netlist NS, readIC, netlist IC. If set to file, the order from lowest to highest is netlist NS, readNS, netlist IC readIC. Possible values are file and netlist.
saPrimeSimVCSOptionicsweep	string	custom		PrimeSimVCS option icsweep: Saves the current analysis result of a parameter or temperature sweep as the starting point in the next analysis.
saPrimeSimVCSOptionicsweepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionicversion	string	custom	1	PrimeSimVCS option icversion: Convert initial condition to initial guess, when .ic statements exist in the netlist and there are no other options to set IC or nodeset.
saPrimeSimVCSOptionignoreagingvariation	string	saTestbench		PrimeSimVCS option ignore_aging_variation:
saPrimeSimVCSOptionignoreagingvariationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionignoreglobalvariation	string	saTestbench		PrimeSimVCS option ignore_global_variation:
saPrimeSimVCSOptionignoreglobalvariationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionignoreinterconnectvariation	string	saTestbench		PrimeSimVCS option ignore_interconnect_variation:
saPrimeSimVCSOptionignoreinterconnectvariationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionignorelocal variation	string	saTestbench		PrimeSimVCS option ignore_local_variation:
saPrimeSimVCSOptionignorelocal variationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionignorevariation	string	saTestbench		PrimeSimVCS option ignore_variation:
saPrimeSimVCSOptionignorevariationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionignshorts	string	custom	no	PrimeSimVCS option ignshorts: Silently ignore shorted components. Possible values are no and yes.
saPrimeSimVCSOptionimax	string	custom		PrimeSimVCS option imax: Sets the upper limit of iterations at a time point in transient analysis. (or itl4)
saPrimeSimVCSOptionimaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionimin	string	custom		PrimeSimVCS option imin: Sets the lower limit of iterations at a time point in transient analysis. (or itl3)
saPrimeSimVCSOptioniminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionimplicitsubcktparam	string	custom	no	PrimeSimVCS option implicit_subckt_param: Allows the implicit parameter to be declared for the spectre format. Possible values are no and yes.
saPrimeSimVCSOptioninfo	string	custom	yes	PrimeSimVCS option info: Give informational messages. Possible values are no and yes.
saPrimeSimVCSOptioningold	string	custom		PrimeSimVCS option ingold: Controls whether to prints *.lis file output in exponential form or engineering notation in HSPICE
saPrimeSimVCSOptioningoldUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptioninlinesubcktcurrent	string	custom	subckt	PrimeSimVCS option inlinesubcktcurrent: Save inline subcircuit terminal current as inline device current or subcircuit current. By default, inline subckt current is saved. Possible values are device and subckt.
saPrimeSimVCSOptioninterp	string	custom		PrimeSimVCS option interp: Sets the output to be updated on the time interval defined by .tran's timestep
saPrimeSimVCSOptioninterpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptioninventory	string	custom	detailed	PrimeSimVCS option inventory: Print summary of components used. Possible values are no, brief, detailed, and full.
saPrimeSimVCSOptionirefbins	string	custom	[...]	PrimeSimVCS option irefbins: Specifies the current bins when bin_irelref=yes is used. Default setting is irefbins=[1e-6 1e-5 1e-4 1e-3 1e-2 1e-1].
saPrimeSimVCSOptionishrink	string	custom	1.0	PrimeSimVCS option ishrink: Ishrink factor.
saPrimeSimVCSOptionitl1	string	custom	200	PrimeSimVCS option itl1: Maximum DC iteration limit.
saPrimeSimVCSOptionitl1UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionitl3	string	custom	3	PrimeSimVCS option itl3: Minimum timestep in timestep algorithms.
saPrimeSimVCSOptionitl4	string	custom	8	PrimeSimVCS option itl4: Maximum timestep in timestep algorithms.
saPrimeSimVCSOptionivthl	string	custom	0.0	PrimeSimVCS option ivthl: Length offset for constant current Vth.
saPrimeSimVCSOptionivthlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionivthn	string	custom	0.0	PrimeSimVCS option ivthn: NMOS Vth current parameter.
saPrimeSimVCSOptionivthnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionivthp	string	custom	0.0	PrimeSimVCS option ivthp: PMOS Vth current parameter.
saPrimeSimVCSOptionivthpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionivthvdsmin	string	custom	0.05	PrimeSimVCS option ivth_vdsmin: Minimum Vds in constant current Vth calculation public.
saPrimeSimVCSOptionivthvdsminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionivthw	string	custom	0.0	PrimeSimVCS option ivthw: Width offset for constant current Vth.
saPrimeSimVCSOptionivthwUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionkcut	string	custom	0.0	PrimeSimVCS option kcut: Fixed value mutual inductors with absolute value of $K \leq kcut$ are replaced by an open. kcut can additionally be applied to variable value mutual inductors using the option 'short_cut_var_elem=yes'. Default value is 0 in Spectre, and 1m in APS.
saPrimeSimVCSOptionkmax	string	custom	no	PrimeSimVCS option kmax: Sets 1.0 as the maximum absolute value for coupling co-efficient of mutual inductors. Possible values are no and yes.
saPrimeSimVCSOptionleakitimes	string	custom	[...]	PrimeSimVCS option leaki_times: Specifies input-steady state time points.
saPrimeSimVCSOptionlimit	string	custom	dev	PrimeSimVCS option limit: Limiting algorithms to aid DC convergence. Possible values are delta, log, dev, l2, and newton.
saPrimeSimVCSOptionlimitdiagpivot	string	custom	yes	PrimeSimVCS option limit_diag_pivot: If set to yes, there is a limit on the number of matrix fill-ins when selecting a pivot from a diagonal. For backward compatibility, set this option to no. Possible values are no and yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionlocalmeas	string	custom	no	PrimeSimVCS option local_meas: Specify whether local measurements definitions are allowed. When set to ignore, the simulator allows local measurements definitions. Depending on the value that is set, the simulator displays warning messages for the local measurements definitions or does not display any message. When set to warning, the simulator does not allow and ignores the local measurement definitions with a warning message. Possible values are no and yes.
saPrimeSimVCSOptionlshort	string	custom	0	PrimeSimVCS option lshort: Fixed value inductors with $L \leq lshort$ are shorted. lshort can additionally be applied to variable value inductors using the option 'short_cut_var_elem=yes'.
saPrimeSimVCSOptionmacmod	string	custom		PrimeSimVCS option macmod: subcircuit definition
saPrimeSimVCSOptionmacmodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionmacromos	string	custom	[...]	PrimeSimVCS option macro_mos: The list of subcircuit names, which is a macro model.
saPrimeSimVCSOptionmaxapproachminstep	string	custom	300	PrimeSimVCS option max_approach_minstep: The maximum number of times allowed to approach minstep within 5% of stop time.
saPrimeSimVCSOptionmaxconsecutive_minstep	string	custom	1000	PrimeSimVCS option max_consecutive_minstep: The maximum number of consecutive steps allowed to be less than $10 \times \text{minstep}$.
saPrimeSimVCSOptionmaxdeltav	string	custom	0.3	PrimeSimVCS option maxdeltav: Maximum change in voltage allowed per Newton iteration when limit=delta (default 0.3 V) or limit=I2 (default 10 V).
saPrimeSimVCSOptionmaxminstepnonconv	string	custom	200	PrimeSimVCS option max_minstep_nonconv: The maximum number of convergence failures allowed below minstep within 5% of stop time.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionmaxnotes	string	custom	5	PrimeSimVCS option maxnotes: Maximum number of times a notice is issued per analysis. Note that this option has no effect on notices issued as part of parsing the netlist. Use the -maxnotes command-line option to control the number of all notices issued.
saPrimeSimVCSOptionmaxnotestologfile	string	custom	5	PrimeSimVCS option maxnotestologfile: Maximum number of times a notice message is printed to the log file per analysis. Note that this option has no effect on notices printed as part of parsing the netlist. Use the -maxnotestolog command-line option to control the number of all notices printed to the log file.
saPrimeSimVCSOptionmaxphysic alflux	string	custom	infinity	PrimeSimVCS option maxphysicalflux: Maximum physical flux allowed in solution.
saPrimeSimVCSOptionmaxphysic ali	string	custom	infinity	PrimeSimVCS option maxphysicali: Maximum physical current allowed in solution.
saPrimeSimVCSOptionmaxphysic almmf	string	custom	infinity	PrimeSimVCS option maxphysicalmmf: Maximum physical magnetomotive force allowed in solution.
saPrimeSimVCSOptionmaxphysic alunitless	string	custom	infinity	PrimeSimVCS option maxphysicalunitless: Maximum physical unitless signals allowed in solution.
saPrimeSimVCSOptionmaxphysic alv	string	custom	infinity	PrimeSimVCS option maxphysicalv: Maximum physical voltage allowed in solution.
saPrimeSimVCSOptionmaxwarns	string	custom	5	PrimeSimVCS option maxwarns: Maximum number of times a warning message is issued per analysis. Note that this option has no effect on warnings issued as part of parsing the netlist. Use the -maxwarns command-line option to control the number of all warnings issued.
saPrimeSimVCSOptionmaxwarnst ologfile	string	custom	5	PrimeSimVCS option maxwarnstologfile: Maximum number of times a warning message is printed to the log file per analysis. Note that this option has no effect on warnings printed as part of parsing the netlist. Use the -maxwarnstolog command-line option to control the number of all warnings printed to the log file.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionmaxwarnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionmcfileonly	string	saTestbench		PrimeSimVCS option mc_file_only:
saPrimeSimVCSOptionmcfileonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionmdlanalysisnames	string	custom	rename	PrimeSimVCS option mdlanalysisnames: Flag to indicate whether or not to keep spectre analysis name in MDL flow. Possible values are rename and original.
saPrimeSimVCSOptionmdlthresholds	string	custom	exact	PrimeSimVCS option mdlthresholds: When set to exact, certain functions in MDL, for example, cross(), control the transient time-step to place a time-point at a threshold crossing. This can improve accuracy. However for applications such as cell characterization an interpolated value can give the required accuracy with better performance.. Possible values are exact and interpolated.
saPrimeSimVCSOptionmdltrigtargmode	string	custom	cross	PrimeSimVCS option mdltrigtargmode: This option specifies how to evaluate the trig and targ of the hspice and the output format. If mdltrigtargmode = deltax, we will use the deltax function to evaluate the trig and targ function. If mdltrigtargmode = cross, we will use the cross function to evaluate the trig and targ function. If mdltrigtargmode = details, we will output the trig and targ middle results. Possible values are deltax, cross, and details.
saPrimeSimVCSOptionmeasdgt	string	custom	0	PrimeSimVCS option measdgt: Number of decimal digits (in floating point numbers) in measurement output in mt0 format.
saPrimeSimVCSOptionmeasdgtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionmeaslabel	string	custom		PrimeSimVCS option measlabel: Specifies a label that appears in the header of the .mt0 file
saPrimeSimVCSOptionmeaslabelonly	string	saTestbench		PrimeSimVCS option meas_label_only:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionmeaslabelonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionmeaslabelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionmextramcmiva	string	saTestbench		PrimeSimVCS option mextram_cmi_va:
saPrimeSimVCSOptionmextramcmivaUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionminexp	string	custom		PrimeSimVCS option m_in_exp: Allows the M-factor of X-elements to appear on the right side of expressions for backward compatibility. (or xmult_in_exp)
saPrimeSimVCSOptionminexpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionminr	string	custom	0.0	PrimeSimVCS option minr: All parasitic resistors inside devices less than global minr will be removed. The order of checking devices is the follows: 1. Check if resistors are smaller than local minr. If yes, check if it is a MOSFET or BJT. If it is a MOSFET, drop the resistor, if it is BJT, clamp to the minr value, and give a warning message for both cases. 2. Check global minr, All Parasitic resistors less than global minr are removed and a warning message is issued. 3. If the resistor is not removed and is smaller than 0.001, issue a warning.
saPrimeSimVCSOptionminrmtor	string	custom	scaled	PrimeSimVCS option minr_mfactor: whether minr will be scaled. Possible values are scaled and ignore.
saPrimeSimVCSOptionminstepversion	string	custom	1	PrimeSimVCS option minstepversion: Minstep algorithm flow control. If minstepversion=0, desperate big jump is taken when minstep is reached. If minstepversion=1, a forward/backward search algorithm is taken to find a converged solution at small step size. By default, minstepversion=1.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionmismatchlevel	string	custom	0	PrimeSimVCS option mismatchlevel: With default, mismatch parameter is defined based on parameter scope concept: mismatch parameter can only have one value in one scope. For example, if a mismatch parameter appears multiple times in a subckt of the netlist, that mismatch parameter has a unique value in that subckt for each Monte Carlo run. With mismatchlevel=1, the mismatch parameter is allowed to have a different value for each appearance in the same scope. Possible values are 0 and 1.
saPrimeSimVCSOptionmontecon	string	custom		PrimeSimVCS option montecon: Specifies whether to retrieve the next random value and continue a Monte Carlo analysis
saPrimeSimVCSOptionmonteconUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionmspartreport	string	custom	0	PrimeSimVCS option ms_part_report: Depth of the ms partition report, default is 0, disabled..
saPrimeSimVCSOptionmsvgnd	string	custom		PrimeSimVCS option ms_vgnd: The virtual ground node names, globally.
saPrimeSimVCSOptionmsvgndv	string	custom	0	PrimeSimVCS option ms_vgndv: The voltage value for the virtual power network grounds in scope.
saPrimeSimVCSOptionmsvpn	string	custom		PrimeSimVCS option ms_vpn: The virtual power node names, globally.
saPrimeSimVCSOptionmsvpnistart	string	custom	0.0	PrimeSimVCS option ms_vpni_start: MS mode start time to have accurate currents. enable vpn current feedback after this time..
saPrimeSimVCSOptionmsvpnistop	string	custom	0.0	PrimeSimVCS option ms_vpni_stop: MS mode stop time to have accurate currents. disable vpn current feedback after this time..
saPrimeSimVCSOptionmsvpnv	string	custom	0	PrimeSimVCS option ms_vpnv: The voltage value for the virtual power network sources in scope.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionmtlinecachedir	string	custom		PrimeSimVCS option mtlinecachedir: The directory in which the mtline RLGC data file will be written. If an absolute path is not given, the file will be written to /home/<username>/cadence/mmsim/.
saPrimeSimVCSOptionmtlineemsolver	string	custom	cpl	PrimeSimVCS option mtlineemsolver: EM 2D solver for transmission line. Possible values are lmg and cpl.
saPrimeSimVCSOptionmtlinereuse	string	custom	yes	PrimeSimVCS option mtlinereuse: This parameter defines whether to reuse RLGC data for all mtline instances. If no, this feature is disabled. Possible values are no and yes.
saPrimeSimVCSOptionmultithread	string	custom	off	PrimeSimVCS option multithread: Enable or disable multithreading capability. When multithreading is enabled but the number of threads (nThreads) is not specified, Spectre will automatically detect the number of processors and select the proper number of threads to use. (See important note about using multithreading in the detailed description below the parameter descriptions). Possible values are off and on.
saPrimeSimVCSOptionmultmosdiffdata	string	saTestbench	0	PrimeSimVCS option multmosdiffdata:
saPrimeSimVCSOptionmultmosdiffdataUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionnarrate	string	custom	yes	PrimeSimVCS option narrate: Narrate the simulation. Possible values are no, yes, and compact.
saPrimeSimVCSOptionnewsoa	string	custom	0	PrimeSimVCS option new_soa: Print result of SOA checks to separate file (.tsoa) (new_soa=1 is equivalent to primesim_soa_warn_to_file=1 and primesim_soa_warn_format=4).
saPrimeSimVCSOptionnewsoaUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionnewton	string	custom	normal	PrimeSimVCS option newton: Method used on DC analysis. You can specify methods newton=[none normal], and the default value is normal.. Possible values are none and normal.
saPrimeSimVCSOptionnoiseoffinst	string	custom	[...]	PrimeSimVCS option noiseoff_inst: The list of instances not to be considered as noisy throughout noise analyses, which include noise, sp noise, pnoise and tran noise.
saPrimeSimVCSOptionnoiseofftype	string	custom	all	PrimeSimVCS option noiseoff_type: The noiseoff_type defines the noise sources which are disabled by the noiseon/off_inst option. The default value is all. Possible values are thermal, flicker, shot, ign, and all.
saPrimeSimVCSOptionnoiseoninst	string	custom	[...]	PrimeSimVCS option noiseon_inst: The list of instances to be considered as noisy throughout noise analysis, which include, noise, sp noise, pnoise and tran noise.
saPrimeSimVCSOptionnoiseontype	string	custom	all	PrimeSimVCS option noiseon_type: The noiseon_type defines the noise sources which are enabled by the noiseon/off_inst option. The default value is all. Possible values are thermal, flicker, shot, ign, and all.
saPrimeSimVCSOptionnonconvtopnum	string	custom	10	PrimeSimVCS option nonconv_topnum: Top number of non-convergence nodes to be printed public.
saPrimeSimVCSOptionnotation	string	custom	eng	PrimeSimVCS option notation: The notation to be used to display real numbers to the screen. Possible values are eng, sci, and float.
saPrimeSimVCSOptionnote	string	custom	yes	PrimeSimVCS option note: Give notice messages. Possible values are no and yes.
saPrimeSimVCSOptionnportbbsfittedfiledir	string	custom		PrimeSimVCS option nportbbsfittedfiledir: The directory to which the BBSpice fitted S-Parameter file will be put. If it is not specified, the file will be in directory named as 'BBSpiceOutput'. If a relative path is specified, the path is relative to the current working directory.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionnportcompress	string	custom	yes	PrimeSimVCS option nportcompress: Nport compression improves the efficiency of S-parameter simulation of large nport files when a certain percentage of the ports is unused, i.e., open or short circuited. Nport compression does not impact simulation accuracy. This option turns off compression if set to no and attempts to force compression if set to yes. If left unspecified, compression is on if N>=10 and the ratio of used ports is less than or equal to 0.8. Possible values are no, yes and unspecified.. Possible values are no and yes.
saPrimeSimVCSOptionnportcompressfiledir	string	custom		PrimeSimVCS option nportcompressfiledir: The directory where the compressed nport S-parameter file is written to. If unspecified, it is stored in outdir.
saPrimeSimVCSOptionnportdefaultpassivity	string	custom	disable	PrimeSimVCS option nport_default_passivity: Check and enforce passivity of S-parameter for all nport instances. Default is `disable`, which means this global option has no effect. If set to a value other than `disable`, all nport elements in the netlist without a value for `passivity` explicitly set, will have their `passivity` argument set to the same value as specified in this global option. If an nport instance already has the `passivity` option specified, the instance option will take priority if both are present. Possible values are no, check, enforce, fit_weak_enforce, fit_enforce, and disable.
saPrimeSimVCSOptionnportirfiledir	string	custom		PrimeSimVCS option nportirfiledir: The directory to which the nport impulse response file will be written. If it is not specified, the file will be written to /home/<username>/cadence/mmsim/. If a relative path is specified, the path is relative to the current working directory.
saPrimeSimVCSOptionnportirreuse	string	custom	yes	PrimeSimVCS option nportirreuse: Reuse impulse responses data for all nport instances. If no, disable this feature. Possible values are no and yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionnportunuse dportgmin	string	custom	0.0	PrimeSimVCS option nportunusedportgmin: Default is 0, which leaves the port open-circuited. A small value loads open-circuited ports with a finite but large resistance. This introduces a small error in the response, but it induces losses which help obtain a passive response.
saPrimeSimVCSOptionnportunuse dportrmin	string	custom	0.0	PrimeSimVCS option nportunusedportrmin: Default is 0, which leaves the port short-circuited. A small value will insert a small resistance in place of short circuited ports. This introduces a small error in the response, but it induces losses which help obtain a passive response.
saPrimeSimVCSOptionnthreads	string	custom		PrimeSimVCS option nthreads: Specifies the number of threads for multithreading.
saPrimeSimVCSOptionnumdgt	string	custom	4	PrimeSimVCS option numdgt: Controls the listing printout accuracy.
saPrimeSimVCSOptionnumdgtUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionomiage	string	saTestbe nch	0	PrimeSimVCS option omiage:
saPrimeSimVCSOptionomiagem ode	string	saTestbe nch	0	PrimeSimVCS option omiagemode:
saPrimeSimVCSOptionomiagemo deUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionomiageUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionomiflag	string	saTestbe nch		PrimeSimVCS option omiflag:
saPrimeSimVCSOptionomiflagUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionomiinput	string	saTestbe nch		PrimeSimVCS option omiinput:
saPrimeSimVCSOptionomiinputUn checkLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionomipath	string	saTestbench		PrimeSimVCS option omipath:
saPrimeSimVCSOptionomipathUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionomisave	string	saTestbench	0	PrimeSimVCS option omisave:
saPrimeSimVCSOptionomisaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionomisort	string	saTestbench		PrimeSimVCS option omisort:
saPrimeSimVCSOptionomisortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionopptcheck	string	custom	yes	PrimeSimVCS option opptcheck: Check operating point parameters against soft limits. Possible values are no and yes.
saPrimeSimVCSOptionopticaloutput	string	saTestbench		PrimeSimVCS option optical_output:
saPrimeSimVCSOptionopticaloutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionopticaloutput is loaded.
saPrimeSimVCSOptionopticalport	string	saTestbench	0	PrimeSimVCS option optical_port:
saPrimeSimVCSOptionopticalportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionoptimizebsimcmg	string	custom	no	PrimeSimVCS option optimize_bsimcmg: Enable the optimization in bsimcmg evaluation. Possible values are no and yes.
saPrimeSimVCSOptionoptimizebsource	string	custom	no	PrimeSimVCS option optimize_bsource: Enable the optimization in bsource evaluation. Possible values are no and yes.
saPrimeSimVCSOptionoptimizediode	string	custom	no	PrimeSimVCS option optimize_diode: Enable the optimization in diode evaluation. Possible values are no and yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionoscoutputport	string	custom		PrimeSimVCS option osc_output_port: Output raw data file name.
saPrimeSimVCSOptionoserandommod	string	custom	0	PrimeSimVCS option ose_random_mod: Use OSE Random Method. Possible values are 0 and 1.
saPrimeSimVCSOptionotherOptions	string	custom		PrimeSimVCS option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)]
saPrimeSimVCSOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionoutputcompactmapping	string	custom	0	PrimeSimVCS option output_compact_mapping: Internal option for RelXpert to output compact mapping file. By default it is closed.
saPrimeSimVCSOptionoutputsigmaavalue	string	saTestbench		PrimeSimVCS option output_sigma_value:
saPrimeSimVCSOptionoutputsigmaavalueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionparamrangeile	string	custom		PrimeSimVCS option paramrangeile: Parameter range file.
saPrimeSimVCSOptionparamtopchange	string	custom	yes	PrimeSimVCS option param_topchange: If set to yes, Spectre will support parametric topology change caused by device internal node changes when the device, model, or netlist parameter value is altered.. Possible values are no and yes.
saPrimeSimVCSOptionparasitics	string	custom		PrimeSimVCS option parasitics: Set parasitics for RC reduction. When used as the scoped option, specify the "+mts" command line option. The option has higher priority than the value from the command line option, "+parasitics". When used as a global option, the value from the command line, "+parasitics", has a higher priority.
saPrimeSimVCSOptionparhier	string	custom		PrimeSimVCS option parhier: Sets the parameter passing rules to control the evaluation order of subcircuit parameters

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionparhierUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionpassfailreverselogic	string	custom	no	PrimeSimVCS option passfail_reverse_logic: Pass fail bisection treats NaN as PASS, while not NaN value as FAIL. Possible values are no and yes.
saPrimeSimVCSOptionpivabs	string	custom	0	PrimeSimVCS option pivabs: Absolute pivot threshold.
saPrimeSimVCSOptionpivotdc	string	custom	no	PrimeSimVCS option pivotdc: Use numeric pivoting on every iteration of DC analysis. Possible values are no and yes.
saPrimeSimVCSOptionpivrel	string	custom	0.001	PrimeSimVCS option pivrel: Relative pivot threshold.
saPrimeSimVCSOptionportelementvoltage matchload	string	saTestbench	1	PrimeSimVCS option port_element_voltage_matchload:
saPrimeSimVCSOptionportelementvoltage matchloadUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionportelementvoltage matchload is loaded.
saPrimeSimVCSOptionportmismatchseverity	string	custom	error	PrimeSimVCS option portmismatch_severity: If set ignore/warn/error out when ports number mismatch for subckt.. Possible values are error, ignore, and warning.
saPrimeSimVCSOptionpost	string	custom		PrimeSimVCS option post: This option saves results in fsdb binary format
saPrimeSimVCSOptionpostUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionpostversion	string	custom		PrimeSimVCS option post_version: Specifies the version of the output format during the generation of a .tr0 output file
saPrimeSimVCSOptionpostversionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprecision	string	custom	%g	PrimeSimVCS option precision: Format specification of double for psfascii. Example: "%15.12g" outputs 12 decimal digits in mantissa. The default value "%g" prints 6 decimal digits.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionpreorder	string	custom	partial	PrimeSimVCS option preorder: Try this option when simulation runs out of memory or if the simulation is unreasonably slow for the size of your design. It controls the amount of matrix pre-ordering that is done and may lead to much fewer matrix fill-ins in some cases. Known cases include designs with very large number of small resistors and large number of behavioral instances containing voltage based equations. Possible values are partial, full, and limited.
saPrimeSimVCSOptionpreserveassert	string	custom	lazy	PrimeSimVCS option preserve_assert: Whether to execute the preservation for voltage check for assert statements. If the value is lazy, only execute the preservation for current checking; otherwise it will execute complete preservation. Possible values are lazy and force.
saPrimeSimVCSOptionpreserveinstance	string	custom		PrimeSimVCS option preserve_inst: Preserve the instances specified in the vector. Use 'preserve_inst=all' to preserve all instances.
saPrimeSimVCSOptionpreserveMASTER	string	custom	[...]	PrimeSimVCS option preserve_master: Preserve all instances of the masters specified.
saPrimeSimVCSOptionpreservenode	string	custom	none	PrimeSimVCS option preservenode: If set to all, node in save statement will be preserved. Possible values are none, all, and explicit.
saPrimeSimVCSOptionpreservesubckt	string	custom	[...]	PrimeSimVCS option preserve_subckt: Preserve all instances within the subcircuits specified.
saPrimeSimVCSOptionprimesimabs_offset	string	saTestbench		PrimeSimVCS option primesim_abs_offset:
saPrimeSimVCSOptionprimesimabs_offsetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimac_atdiff	string	custom	0	PrimeSimVCS option primesim_ac_at_diff_t: Determines whether or not small signal analyses like ac and noise are run at times specified in .OP statement

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimac atdiffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimac celeraterom	string	custom	0	PrimeSimVCS option primesim_accelerate_rom: Improves performance for the simulation of ROM circuits.
saPrimeSimVCSOptionprimesimac celerateromUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimac csparsefcap	string	saTestbench	0	PrimeSimVCS option primesim_acc_sparse_fcapi:
saPrimeSimVCSOptionprimesimac csparsefcapthreshold	string	saTestbench		PrimeSimVCS option primesim_acc_sparse_fcapi_threshold:
saPrimeSimVCSOptionprimesimac csparsefcapthresholdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimac csparsefcapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimac torestart	string	saTestbench		PrimeSimVCS option primesim_auto_restart: Allow to create snapshots during transient simulation that can be used in conjunction with the -auto_restart command-line option.
saPrimeSimVCSOptionprimesimac torestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimac torestart is loaded.
saPrimeSimVCSOptionprimesimac flow	string	custom		PrimeSimVCS option primesim_ac_flow: Controls whether small signal AC analyses of 3rd-party netlists are run in a PrimeSim HSPICE-compatible flow or in a 3rd-party compatible flow (default). This option is ignored in small signal AC analyses of HSPICE netlists.
saPrimeSimVCSOptionprimesimac flowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimac flush	string	saTestbench		PrimeSimVCS option primesim_acflush:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimac flushUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimad aptivemt	string	custom		PrimeSimVCS option primesim_adaptive_mt: Enables an optimized method for handling multi-threading on an overloaded machine.
saPrimeSimVCSOptionprimesimad aptivemtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimad ddivider	string	custom		PrimeSimVCS option primesim_add_divider: Defines a character to use as a hierarchy divider.
saPrimeSimVCSOptionprimesimad ddividerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimad dinstance	string	custom		PrimeSimVCS option primesim_add_instance: Automatically creates a subcircuit call line.
saPrimeSimVCSOptionprimesimad dinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimad dstability	string	saTestbench	0	PrimeSimVCS option primesim_add_stability:
saPrimeSimVCSOptionprimesimad dstabilityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimag inglib	string	custom		PrimeSimVCS option primesim_aginglib: Loads a model aging shared library.
saPrimeSimVCSOptionprimesimag inglibUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimag ingspfdivider	string	saTestbench	<file path>	PrimeSimVCS option primesim_aging_spfdivider: Lets aging analysis provide a hierarchy divider in the stressvec SPF file.
saPrimeSimVCSOptionprimesimag ingspfdividerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimaliasvdbtoopvdb	string	saTestbench	0	PrimeSimVCS option primesim_alias_vdb_to_opvdb:
saPrimeSimVCSOptionprimesimaliasvdbtoopvdbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimallow3tmosfet	string	custom		PrimeSimVCS option primesim_allow_3t_mosfet: Allows three-terminal MOSFETs.
saPrimeSimVCSOptionprimesimallow3tmosfetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimallowdupport	string	custom	1	PrimeSimVCS option primesim_allow_dup_port: When set to 1, allows duplicated ports.
saPrimeSimVCSOptionprimesimallowdupportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimallowlooselteerrtol	string	saTestbench	1	PrimeSimVCS option primesim_allow_loose_lte_errtol:
saPrimeSimVCSOptionprimesimallowlooselteerrtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimallownestedinstparam	string	saTestbench		PrimeSimVCS option primesim_allow_nested_inst_param:
saPrimeSimVCSOptionprimesimallownestedinstparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimallowanalogmode	string	saTestbench		PrimeSimVCS option primesim_analog_mode:
saPrimeSimVCSOptionprimesimallowanalogmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimallowanalogmode is loaded.
saPrimeSimVCSOptionprimesimallowanalogpart	string	saTestbench		PrimeSimVCS option primesim_analog_part:
saPrimeSimVCSOptionprimesimallowanalogpartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimap iopt	string	saTestbench	3	PrimeSimVCS option primesim_api_opt:
saPrimeSimVCSOptionprimesimap ioptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimasert	string	saTestbench	0	PrimeSimVCS option primesim_assert: Control the effort applied to assert check
saPrimeSimVCSOptionprimesimasertUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimassert is loaded.
saPrimeSimVCSOptionprimesimautoexitinvfsdb	string	saTestbench		PrimeSimVCS option primesim_autoexit_invfsdb:
saPrimeSimVCSOptionprimesimautoexitinvfsdbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimautogminscale	string	custom		PrimeSimVCS option primesim_auto_gmin_scale: Specifies whether to auto-scale values for gmin and gmindc in FinFET designs.
saPrimeSimVCSOptionprimesimautogminscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimautogshunt	string	saTestbench	0	PrimeSimVCS option primesim_auto_gshunt:
saPrimeSimVCSOptionprimesimautogshuntUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimautoirobepwrlist	string	saTestbench	item	PrimeSimVCS option primesim_auto_iprobe_pwrlist:
saPrimeSimVCSOptionprimesimautoirobepwrlistUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimavaflow	string	saTestbench	0	PrimeSimVCS option primesim_ava_flow:
saPrimeSimVCSOptionprimesimavaflowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimba changenetlist	string	saTestbe nch		PrimeSimVCS option primesim_ba_change_netlist:
saPrimeSimVCSOptionprimesimba changenetlistUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimba new	string	saTestbe nch	0	PrimeSimVCS option primesim_ba_new:
saPrimeSimVCSOptionprimesimba newUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimba opt	string	saTestbe nch	3	PrimeSimVCS option primesim_ba_opt:
saPrimeSimVCSOptionprimesimba optUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimba updatexprobe	string	saTestbe nch	0	PrimeSimVCS option primesim_ba_update_xprobe:
saPrimeSimVCSOptionprimesimba updatexprobeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbg ear	string	saTestbe nch	0	PrimeSimVCS option primesim_bgear:
saPrimeSimVCSOptionprimesimbg earmax	string	saTestbe nch	1e33	PrimeSimVCS option primesim_bgear_max:
saPrimeSimVCSOptionprimesimbg earmaxUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbg earmin	string	saTestbe nch	0.0	PrimeSimVCS option primesim_bgear_min:
saPrimeSimVCSOptionprimesimbg earminUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbg earUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbi aschkenable	string	saTestbe nch	0	PrimeSimVCS option primesim_biaschk_enable:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimbi aschkenableUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbi gpowerautodetect	string	saTestbe nch		PrimeSimVCS option primesim_big_power_auto_detect:
saPrimeSimVCSOptionprimesimbi gpowerautodetectUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbi gpowernetsopt	string	saTestbe nch	0	PrimeSimVCS option primesim_big_power_nets_opt:
saPrimeSimVCSOptionprimesimbi gpowernetsoptUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbi secnormabstol	string	saTestbe nch	0	PrimeSimVCS option primesim_bisec_norm_abstol:
saPrimeSimVCSOptionprimesimbi secnormabstolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbi secnormcheck	string	saTestbe nch	0	PrimeSimVCS option primesim_bisec_norm_check:
saPrimeSimVCSOptionprimesimbi secnormcheckUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbi secnormmeasabstol	string	saTestbe nch	3e-12	PrimeSimVCS option primesim_bisec_norm_meas_abstol:
saPrimeSimVCSOptionprimesimbi secnormmeasabstolUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbi secnormmeasreltol	string	saTestbe nch	0.01	PrimeSimVCS option primesim_bisec_norm_meas_reltol:
saPrimeSimVCSOptionprimesimbi secnormmeasreltolUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbi secnormreltol	string	saTestbe nch	0.01	PrimeSimVCS option primesim_bisec_norm_reltol:
saPrimeSimVCSOptionprimesimbi secnormreltolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimbisecsisseedctrl	string	saTestbench	0	PrimeSimVCS option primesim_bisec_sis_seed_ctrl:
saPrimeSimVCSOptionprimesimbisecsisseedctrlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbisectionconcurrentmode	string	custom		PrimeSimVCS option primesim_bisection_concurrent_mode: Controls the behavior of bisection optimization when performing Concurrent Bisection for Independent Circuit Blocks.
saPrimeSimVCSOptionprimesimbisectionconcurrentmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbisectionfailcontinue	string	custom		PrimeSimVCS option primesim_bisection_fail_continue: Allows the simulation to continue to other sweeps outside the bisection in the event that the bisection sweep fails.
saPrimeSimVCSOptionprimesimbisectionfailcontinueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbisectionoutput	string	custom	1	PrimeSimVCS option primesim_bisection_output: When set to 1 PrimeSim will merge all output data of one complete bisection progress to one file.
saPrimeSimVCSOptionprimesimbisectionoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbisectionsummary	string	custom	1	PrimeSimVCS option primesim_bisection_summary: Needs Description.
saPrimeSimVCSOptionprimesimbisectionsummaryUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbisectionusingsis	string	saTestbench		PrimeSimVCS option primesim_bisection_using_sis:
saPrimeSimVCSOptionprimesimbisectionusingsisUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbim3gateleakage	string	saTestbench		PrimeSimVCS option primesim_bsim3gate_leakage:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimbsim3gateleakageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbuildhdb	string	saTestbench	0	PrimeSimVCS option primesim_build_hdb:
saPrimeSimVCSOptionprimesimbuildhdbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimbytol	string	custom	1mV	PrimeSimVCS option primesim_bytol: Sets the voltage value to use in determining whether a MOS is latent. The default value is dependent on primesim_mode.
saPrimeSimVCSOptionprimesimbytolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcckpost	string	saTestbench		PrimeSimVCS option primesim_cck_post: Sets all three post-processing options:primesim_chkdevop_post;primesim_chkrftime_post;primesim_chktiming_post
saPrimeSimVCSOptionprimesimcckpostnp	string	saTestbench	1	PrimeSimVCS option primesim_cck_post_np:
saPrimeSimVCSOptionprimesimcckpostnpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcckpostnumgroup	string	saTestbench	-1	PrimeSimVCS option primesim_cck_post_num_group:
saPrimeSimVCSOptionprimesimcckpostnumgroupUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcckpostrawoutput	string	saTestbench	1	PrimeSimVCS option primesim_cck_post_raw_output:
saPrimeSimVCSOptionprimesimcckpostrawoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcckpostUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimcc kremoveresult	string	custom		PrimeSimVCS option primesim_cck_remove_result: Removes the circuit check result file when there are no errors.
saPrimeSimVCSOptionprimesimcc kremoveresultUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcc misftrds	string	saTestbench		PrimeSimVCS option primesim_ccmi_sft_rds:
saPrimeSimVCSOptionprimesimcc misftrdsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcc model	string	custom		PrimeSimVCS option primesim_ccmodel: Controls the modeling of coupling capacitors based on the total coupling capacitance ratio.
saPrimeSimVCSOptionprimesimcc modelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimce llchar	string	custom		PrimeSimVCS option primesim_cell_char: Suppresses printing sweep parameters to the .mt0 file and data to the log file.
saPrimeSimVCSOptionprimesimce llcharUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimch anger3cmcpinorder	string	custom		PrimeSimVCS option primesim_change_r3cmc_pin_order: Specifies the pin order to use when assigning pins for the CMC R3 model.
saPrimeSimVCSOptionprimesimch anger3cmcpinorderUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimch annelcutpinpout	string	saTestbench	0	PrimeSimVCS option primesim_channel_cut_pinpout:
saPrimeSimVCSOptionprimesimch annelcutpinpoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimch eckdummymossize	string	saTestbench		PrimeSimVCS option primesim_check_dummy_mos_size:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimcheckdummysizeUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimcheckdummysize is loaded.
saPrimeSimVCSOptionprimesimcheckdupparam	string	saTestbench	0	PrimeSimVCS option primesim_check_dup_param:
saPrimeSimVCSOptionprimesimcheckdupparamUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchecklineconcat	string	saTestbench	0	PrimeSimVCS option primesim_check_line_concat:
saPrimeSimVCSOptionprimesimchecklineconcatUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcheckmodeforac	string	saTestbench	1	PrimeSimVCS option primesim_check_mode_for_ac:
saPrimeSimVCSOptionprimesimcheckmodeforacUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcheckmodel	string	custom	0	PrimeSimVCS option primesim_check_model: Needs Description.
saPrimeSimVCSOptionprimesimcheckmodelUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcheckpoint	string	saTestbench	0	PrimeSimVCS option primesim_checkpoint:
saPrimeSimVCSOptionprimesimcheckpointUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcheckportmismatch	string	saTestbench	0	PrimeSimVCS option primesim_check_port_mismatch:
saPrimeSimVCSOptionprimesimcheckportmismatchUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcheckundefinedparam	string	saTestbench		PrimeSimVCS option primesim_check_undefined_param: Specifies whether to check for undefined parameters in the netlist and then

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimcheckundefinedparamUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcheckvth	string	custom	1	PrimeSimVCS option primesim_check_vth: Specifies whether to use primesim_goff (0) or vth (1) to determine the ON/OFF state.
saPrimeSimVCSOptionprimesimcheckvthUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchgacc	string	saTestbench		PrimeSimVCS option primesim_chgacc:
saPrimeSimVCSOptionprimesimchgaccUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchgtol	string	custom	1e-15	PrimeSimVCS option primesim_chgtol: Sets absolute charge tolerance during charge-based 1teq time step algorithm.
saPrimeSimVCSOptionprimesimchgtolUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkblkpwrpwrnode	string	custom		PrimeSimVCS option primesim_chkblkpwr_pwrnode: Marks nodes as supply nodes in the power report.
saPrimeSimVCSOptionprimesimchkblkpwrpwrnodeUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkblkpwrpwrport	string	custom		PrimeSimVCS option primesim_chkblkpwr_pwrport: Defines the power port of all subcircuits.
saPrimeSimVCSOptionprimesimchkblkpwrpwrportUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkblkpwrspecifiedonly	string	custom		PrimeSimVCS option primesim_chkblkpwr_specified_only: Reports only the block power/ground for the specified node when using the primesim_chkblkpwr_pwrnode or primesim_chkblkpwr_pwrport options.
saPrimeSimVCSOptionprimesimchkblkpwrspecifiedonlyUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimchkdcpathbuildnet	string	saTestbench	1	PrimeSimVCS option primesim_chkdcpath_build_net:
saPrimeSimVCSOptionprimesimchkdcpathbuildnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkdcpathgndgroup	string	custom		PrimeSimVCS option primesim_chkdcpath_gndgroup: Specifies whether any node connected to an ideal ground (zero) voltage source through a zero voltage source is treated separately or as the same ground group by the .CHKDCPATH command.
saPrimeSimVCSOptionprimesimchkdcpathgndgroupUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkdcpathpwrgroup	string	custom		PrimeSimVCS option primesim_chkdcpath_pwrgroup: Specifies whether any node connected to an ideal power (non-zero) voltage source through a zero voltage source is treated separately or as the same power group by the .CHKDCPATH command.
saPrimeSimVCSOptionprimesimchkdcpathpwrgroupUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkdcpathrth	string	custom		PrimeSimVCS option primesim_chkdcpath_rth: Specifies the value for determining whether a resistor is treated as a parasitic resistor and part of a resistor network or as a normal device and not part of a resistor network.
saPrimeSimVCSOptionprimesimchkdcpathrthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkdevopdisable	string	custom		PrimeSimVCS option primesim_chkdevop_disable: Disables .chkdevop for those circuits identified with the specified tag=tag_name arguments (see Check Device Operation Point (.CHKDEVOP)) and enables .chkdevop for all other circuits including those without a tag argument.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimchkdevopdisableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkdevopenable	string	custom		PrimeSimVCS option primesim_chkdevop_enable: Enables .chkdevop for those circuits identified with the specified tag=tag_name arguments (see Check Device Operation Point (.CHKDEVOP)) and disables .chkdevop for all other circuits including those without a tag argument.
saPrimeSimVCSOptionprimesimchkdevopenableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkdevopfilterin	string	custom		PrimeSimVCS option primesim_chkdevop_filter_in: Controls which devices to include under the specified subcircuit's instances and the specified instances when checking for device operation condition.
saPrimeSimVCSOptionprimesimchkdevopfilterinUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkdevopfilterout	string	custom		PrimeSimVCS option primesim_chkdevop_filter_out: Controls which devices to exclude under the specified subcircuit's instances and the specified instances when checking for device operation condition.
saPrimeSimVCSOptionprimesimchkdevopfilteroutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkdevopmode	string	custom		PrimeSimVCS option primesim_chkdevop_mode: Checks lower hierarchies of the subckt for .chkdevop when subckt=subckt_name is specified.
saPrimeSimVCSOptionprimesimchkdevopmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkdevoppost	string	custom		PrimeSimVCS option primesim_chkdevop_post: Allows you to post-process .chkdevop (see Check Device Operation Point (.CHKDEVOP)).

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimchkdevoppostUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkdevoprintinfo	string	saTestbench		PrimeSimVCS option primesim_chkdevop_print_info:
saPrimeSimVCSOptionprimesimchkdevoprintinfoUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimchkdevoprintinfo is loaded.
saPrimeSimVCSOptionprimesimchkdevport	string	custom	0	PrimeSimVCS option primesim_chk_devport: Checks device port name during wildcard matching of .probe statement.
saPrimeSimVCSOptionprimesimchkdevportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkdgt	string	custom		PrimeSimVCS option primesim_chkdgt: Sets the number of digits displayed after the decimal by the .CHKRFTIME and .CHKTIMING commands.
saPrimeSimVCSOptionprimesimchkdgtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkdiskspace	string	custom	0	PrimeSimVCS option primesim_chk_disk_space: Checks and reports available disk space in every tflush time period.
saPrimeSimVCSOptionprimesimchkdiskspaceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkexprdisable	string	custom		PrimeSimVCS option primesim_chkexpr_disable: Disables .chkexpr for those circuits identified with the specified tag=tag_name arguments (see Check Expression (.CHKEXPR)) and enables .chkexpr for all other circuits including those without a tag argument.
saPrimeSimVCSOptionprimesimchkexprdisableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimchkexprenable	string	custom		PrimeSimVCS option <code>primesim_chkexpr_enable</code> : Enables <code>.chkexpr</code> for those circuits identified with the specified <code>tag=tag_name</code> arguments (see Check Expression (<code>.CHKEXPR</code>)) and disables <code>.chkexpr</code> for all other circuits including those without a tag argument.
saPrimeSimVCSOptionprimesimchkexprenableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkexprprintall	string	saTestbench		PrimeSimVCS option <code>primesim_chkexpr_print_all</code> : When set to 1, all checks, including invalid assert, are also dumped into csv file
saPrimeSimVCSOptionprimesimchkexprprintallUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference <code>saPrimeSimVCSOptionprimesimchkexprprintall</code> is loaded.
saPrimeSimVCSOptionprimesimchkformat	string	custom		PrimeSimVCS option <code>primesim_chk_format</code> : Specifies whether <code>.CHKDEVOP</code> commands use the PrimeSim XA TCL-CCK output format.
saPrimeSimVCSOptionprimesimchkformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkfsdb	string	saTestbench	0	PrimeSimVCS option <code>primesim_chk_fsdb</code> : This option prevents overwriting FSDB files.
saPrimeSimVCSOptionprimesimchkfsdbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkkrftimereport	string	custom		PrimeSimVCS option <code>primesim_chkrftime_post</code> : Allows you to post-process <code>.chkrftime</code> (see Check Rise/Fall Transition Time (<code>.CHKRFTIME</code>)).
saPrimeSimVCSOptionprimesimchkkrftimereportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkkrftimereportverbose	string	saTestbench		PrimeSimVCS option <code>primesim_chkrftime_report_verbose</code> :
saPrimeSimVCSOptionprimesimchkkrftimereportverboseUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimchktimingpost	string	custom		PrimeSimVCS option primesim_chktiming_post: Allows you to post-process .chktiming (see Check Timing Setup/Hold/Delay/Width (.CHKTIMING)).
saPrimeSimVCSOptionprimesimchktimingpostUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkznodedebugout	string	custom		PrimeSimVCS option primesim_chkznode_debug_out: Specifies that device turn-on/off information be printed out for Hi-Z node debugging.
saPrimeSimVCSOptionprimesimchkznodedebugoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkznodedoublepass	string	saTestbench		PrimeSimVCS option primesim_chkznode_double_pass:
saPrimeSimVCSOptionprimesimchkznodedoublepassUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkznoderule	string	custom		PrimeSimVCS option primesim_chkznode_rule: Specifies a global option in checking conductivity of MOSFET.
saPrimeSimVCSOptionprimesimchkznoderuleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimchkznodevbe	string	saTestbench		PrimeSimVCS option primesim_chkznode_vbe:
saPrimeSimVCSOptionprimesimchkznodevbeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimchkznodevbe is loaded.
saPrimeSimVCSOptionprimesimchkznodevth	string	custom	0	PrimeSimVCS option primesim_chkznode_vth: Sets the Vth value in calculating the ON/OFF state of MOSFET.
saPrimeSimVCSOptionprimesimchkznodevthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcircuittype	string	saTestbench		PrimeSimVCS option primesim_circuit_type:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimcircuittypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcis	string	saTestbench		PrimeSimVCS option primesim_cis:
saPrimeSimVCSOptionprimesimcisUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcktopt	string	custom		PrimeSimVCS option primesim_ckttop: Applies circuit optimization.
saPrimeSimVCSOptionprimesimcktoptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimclampVerilog	string	custom	0	PrimeSimVCS option primesim_clampVerilog: Clamps stamped conductance value to primesim_gmax.
saPrimeSimVCSOptionprimesimclampVerilogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcmivamodel	string	saTestbench		PrimeSimVCS option primesim_cmi_vamodel:
saPrimeSimVCSOptionprimesimcmivamodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcmamodel	string	custom		PrimeSimVCS option primesim_c_model: Specifies a C Model.
saPrimeSimVCSOptionprimesimcmamodelexclude	string	saTestbench		PrimeSimVCS option primesim_c_model_exclude: Excludes some instances of C-models from being replaced with the model that was created.
saPrimeSimVCSOptionprimesimcmamodelexcludeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcmamodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcmmpxsparsefcap	string	saTestbench		PrimeSimVCS option primesim_cmpx_sparse_fcapi:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimcmplxsparsefcapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimcmplxsparsfcap is loaded.
saPrimeSimVCSOptionprimesimcomplexoutput	string	saTestbench	1	PrimeSimVCS option primesim_complex_output:
saPrimeSimVCSOptionprimesimcomplexoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimconnectmode	string	custom		PrimeSimVCS option primesim_connect_mode: Specifies what the .CONNECT SPICE-compatible control uses to connect two nodes.
saPrimeSimVCSOptionprimesimconnectmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcontmeasout	string	custom		PrimeSimVCS option primesim_cont_measout: Controls the continuous measurement file format.
saPrimeSimVCSOptionprimesimcontmeasoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimconvlevel	string	custom	0	PrimeSimVCS option primesim_convlevel: Determines how PrimeSim attempts to solve the "time step too small" error.
saPrimeSimVCSOptionprimesimconvlevelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcorrectionbulksamedirection	string	saTestbench	0	PrimeSimVCS option primesim_correction_bulk_same_direction:
saPrimeSimVCSOptionprimesimcorrectionbulksamedirectionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcosimprobeStyle	string	saTestbench		PrimeSimVCS option primesim_cosim_probe_style:
saPrimeSimVCSOptionprimesimcosimprobeStyleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcosimstandalonecapturetime	string	saTestbench		PrimeSimVCS option primesim_cosim_standalone_capture_time:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimco simstandalonecapturetimeUncheck Localized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcp rbtol	string	custom		PrimeSimVCS option primesim_cprbtol: Sets the capacitance tolerance for the capacitance print out.
saPrimeSimVCSOptionprimesimcp rbtolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcp tinteroptimization	string	saTestbe nch	1	PrimeSimVCS option primesim_cpt_interp_optimization:
saPrimeSimVCSOptionprimesimcp tinteroptimizationUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcp umin	string	saTestbe nch	0	PrimeSimVCS option primesim_cpu_min:
saPrimeSimVCSOptionprimesimcp uminUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcs ensinstparam	string	saTestbe nch	0	PrimeSimVCS option primesim_csens_inst_param:
saPrimeSimVCSOptionprimesimcs ensinstparamUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcs max	string	saTestbe nch		PrimeSimVCS option primesim_csmax:
saPrimeSimVCSOptionprimesimcs maxUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcu rrentaccuracy	string	saTestbe nch	0	PrimeSimVCS option primesim_current_accuracy:
saPrimeSimVCSOptionprimesimcu rrentaccuracyUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcu tedge	string	saTestbe nch		PrimeSimVCS option primesim_cutedge:
saPrimeSimVCSOptionprimesimcu tedgeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimcutnode	string	custom		PrimeSimVCS option primesim_cutnode: Reduces partition size for signal nodes.
saPrimeSimVCSOptionprimesimcutnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcvamintranstime	string	saTestbench		PrimeSimVCS option primesim_cva_min_trans_time:
saPrimeSimVCSOptionprimesimcvamintranstimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcvamintranstunits	string	saTestbench	0	PrimeSimVCS option primesim_cva_min_trans_tunits:
saPrimeSimVCSOptionprimesimcvamintranstunitsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdcalg	string	custom	0	PrimeSimVCS option primesim_dcalg: Sets algorithm for DC convergence.
saPrimeSimVCSOptionprimesimdcalgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdccurrentaccuracy	string	saTestbench	0	PrimeSimVCS option primesim_dc_current_accuracy:
saPrimeSimVCSOptionprimesimdccurrentaccuracyiabstol	string	saTestbench		PrimeSimVCS option primesim_dc_current_accuracy_iabstol:
saPrimeSimVCSOptionprimesimdccurrentaccuracyiabstolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdccurrentaccuracyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdcdampmethod	string	saTestbench		PrimeSimVCS option primesim_dcdamp_method:
saPrimeSimVCSOptionprimesimdcdampmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdceffort	string	custom	1	PrimeSimVCS option primesim_dceffort: Controls effort applied for DC convergence.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimdc effortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdc opt	string	saTestbench	0	PrimeSimVCS option primesim_dcopt:
saPrimeSimVCSOptionprimesimdc optind	string	saTestbench	0	PrimeSimVCS option primesim_dcopt_ind:
saPrimeSimVCSOptionprimesimdc optindUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdc optUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdc pwrloadmodelonly	string	saTestbench	1	PrimeSimVCS option primesim_dc_pwrloadmodel_i_only:
saPrimeSimVCSOptionprimesimdc pwrloadmodelonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdc pwrmodel	string	saTestbench		PrimeSimVCS option primesim_dcpwrmodel:
saPrimeSimVCSOptionprimesimdc pwrmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdc serial	string	saTestbench	0	PrimeSimVCS option primesim_dc_serial:
saPrimeSimVCSOptionprimesimdc serialUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde bugnet	string	saTestbench		PrimeSimVCS option primesim_debug_net:
saPrimeSimVCSOptionprimesimde bugnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde lmax	string	custom		PrimeSimVCS option primesim_delmax: Sets maximum value of internal time step in simulation.
saPrimeSimVCSOptionprimesimde lmaxfix	string	saTestbench	1	PrimeSimVCS option primesim_delmax_fix:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimde lmaxfixUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde lmaxUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde lmin	string	custom		PrimeSimVCS option primesim_delmin: Specifies the minimum time step in a simulation.
saPrimeSimVCSOptionprimesimde lminUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde lvto	string	saTestbe nch		PrimeSimVCS option primesim_delvto:
saPrimeSimVCSOptionprimesimde lvtoUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde tectbtobinv	string	saTestbe nch		PrimeSimVCS option primesim_detect_btobinv:
saPrimeSimVCSOptionprimesimde tectbtobinvUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde tectdigital	string	saTestbe nch	1	PrimeSimVCS option primesim_detect_digital:
saPrimeSimVCSOptionprimesimde tectdigitalUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde tecthsamp	string	saTestbe nch		PrimeSimVCS option primesim_detect_hsamp:
saPrimeSimVCSOptionprimesimde tecthsampUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde tectlvdd	string	custom		PrimeSimVCS option primesim_detect_lvdd: Provides auto-detection of the VDD level for lprobe.
saPrimeSimVCSOptionprimesimde tectlvddstatic	string	custom		PrimeSimVCS option primesim_detect_lvdd_static: Clamps stamped conductance value to primesim_gmax.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimde tectlvddstaticUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde tectlvddUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde tectsptrgate	string	saTestbench		PrimeSimVCS option primesim_detect_sptrgate:
saPrimeSimVCSOptionprimesimde tectsptrgateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde tectvcvsloop	string	saTestbench		PrimeSimVCS option primesim_detect_vcvs_loop: Enables the PrimeSim Pro tool to detect loops between VCVS sources and Verilog-A and then prevent partitioning from breaking the loops causing "time step too small" errors in transient analysis.
saPrimeSimVCSOptionprimesimde tectvcvsloopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde tectvsrclloop	string	saTestbench	2	PrimeSimVCS option primesim_detect_vsrc_loop:
saPrimeSimVCSOptionprimesimde tectvsrclloopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimde viceicrule	string	saTestbench	0	PrimeSimVCS option primesim_device_ic_rule:
saPrimeSimVCSOptionprimesimde viceicruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdi agba	string	saTestbench		PrimeSimVCS option primesim_diag_ba:
saPrimeSimVCSOptionprimesimdi agbaUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdi gitalmode	string	saTestbench	0	PrimeSimVCS option primesim_digital_mode:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimgitalmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsablecmijflag	string	saTestbench		PrimeSimVCS option primesim_disable_cmi_qjflag:
saPrimeSimVCSOptionprimesimsablecmijflagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdmr	string	saTestbench		PrimeSimVCS option primesim_dmr:
saPrimeSimVCSOptionprimesimdmrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimdmr is loaded.
saPrimeSimVCSOptionprimesimdoubleprecisionoutput	string	custom	0	PrimeSimVCS option primesim_double_precision_output: Changes output file value from 4 bytes to 8 bytes.
saPrimeSimVCSOptionprimesimdoubleprecisionoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdpf	string	custom		PrimeSimVCS option primesim_dpf: Specifies the DPF file that contains the extracted device parameter data.
saPrimeSimVCSOptionprimesimdpfadddev	string	custom	0	PrimeSimVCS option primesim_dpfadddev: Controls whether DPF devices that are not in the netlist are added.
saPrimeSimVCSOptionprimesimdpfadddevUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdpfhdiv	string	custom	<file path>	PrimeSimVCS option primesim_dpfhdiv: Sets the divider character for hierarchical names in DPF files.
saPrimeSimVCSOptionprimesimdpfhdivUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdpfmodule	string	custom		PrimeSimVCS option primesim_dpffmodule: Specifies the module for DPF back-annotation.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimdp fmoduleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdp fmosonly	string	custom		PrimeSimVCS option primesim_dpfscale: Specifies whether to back-annotate all devices or only MOSFET devices.
saPrimeSimVCSOptionprimesimdp fmosonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdp fprefix	string	custom		PrimeSimVCS option primesim_dpfprefix: Lists the prefixes that should be removed from DPF device names.
saPrimeSimVCSOptionprimesimdp fprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdp fscale	string	custom	1	PrimeSimVCS option primesim_dpfscale: Sets the scale for devices in the DPF file.
saPrimeSimVCSOptionprimesimdp fscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdp fsuffix	string	custom		PrimeSimVCS option primesim_dpfsuffix: Defines the suffix in a DPF file.
saPrimeSimVCSOptionprimesimdp fsuffixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdp fUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdr amrampup	string	saTestbench		PrimeSimVCS option primesim_dram_rampup:
saPrimeSimVCSOptionprimesimdr amrampupUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdu mpcktinfo	string	saTestbench	0	PrimeSimVCS option primesim_dump_cktinfo:
saPrimeSimVCSOptionprimesimdu mpcktinfoUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimdu mpelabdb	string	saTestbench		PrimeSimVCS option primesim_dump_elab_db:
saPrimeSimVCSOptionprimesimdu mpelabdbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdu mpflatcell	string	saTestbench		PrimeSimVCS option primesim_dump_flat_cell:
saPrimeSimVCSOptionprimesimdu mpflatcellUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdu mpflatinst	string	saTestbench		PrimeSimVCS option primesim_dump_flat_inst:
saPrimeSimVCSOptionprimesimdu mpflatinstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdu plicateckcheck	string	saTestbench	1	PrimeSimVCS option primesim_duplicate_cck_check:
saPrimeSimVCSOptionprimesimdu plicateckcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdv vdd	string	saTestbench		PrimeSimVCS option primesim_dvdd:
saPrimeSimVCSOptionprimesimdv ddUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdv max	string	custom		PrimeSimVCS option primesim_dvmax: Sets the maximum voltage change of a node in a single time step.
saPrimeSimVCSOptionprimesimdv maxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimdv min	string	saTestbench		PrimeSimVCS option primesim_dvmin:
saPrimeSimVCSOptionprimesimdv minUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimelapsedtflush	string	custom		PrimeSimVCS option primesim_elapsed_tflush: Flushes output files after the specified number of seconds in elapsed runtime since the previous flush.
saPrimeSimVCSOptionprimesimelapsedtflushUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimemirlatepostprocessing	string	saTestbench		PrimeSimVCS option primesim_emir_late_post_processing:
saPrimeSimVCSOptionprimesimemirlatepostprocessingUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimemirlatepostprocessing is loaded.
saPrimeSimVCSOptionprimesimemirpost	string	saTestbench	emir_post.cfg	PrimeSimVCS option primesim_emir_post: Reads in PrimeSim EMIR post-process config file. When users use this option with a valid config file, PrimeSim launches post-processor with the created DB.
saPrimeSimVCSOptionprimesimemirpostUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimemirsim	string	saTestbench	emir_sim.cfg	PrimeSimVCS option primesim_emir_sim: Reads in PrimeSim EMIR simulation config file. When users use this option with a valid config file, PrimeSim creates the DB based on user inputs.
saPrimeSimVCSOptionprimesimemirsimUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimenablesdebug	string	saTestbench	0	PrimeSimVCS option primesim_enable_s_debug:
saPrimeSimVCSOptionprimesimenablesdebugUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimenforcespassive	string	saTestbench	0	PrimeSimVCS option primesim_enforce_s_passive:
saPrimeSimVCSOptionprimesimenforcespassiveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimenhancedtclmode	string	custom		PrimeSimVCS option primesim_enhanced_tcl_mode: Allows Tcl to perform model name matching.
saPrimeSimVCSOptionprimesimenhancedtclmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprefix	string	custom		PrimeSimVCS option primesim_enprefix: Specifies the prefix characters in a pre-layout netlist that should be removed to match with the DSPF instance name during back-annotation.
saPrimeSimVCSOptionprimesimprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimeqr2spres	string	custom		PrimeSimVCS option primesim_eqr2spres:
saPrimeSimVCSOptionprimesimeqr2spresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimeqrptminshortingdeg	string	saTestbench		PrimeSimVCS option primesim_eqr_opt_min_shorting_deg:
saPrimeSimVCSOptionprimesimeqrptminshortingdegUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimeqrptshortinglimit	string	saTestbench		PrimeSimVCS option primesim_eqr_opt_shorting_limit:
saPrimeSimVCSOptionprimesimeqrptshortinglimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimevabstolscale	string	saTestbench		PrimeSimVCS option primesim_evabstolscale:
saPrimeSimVCSOptionprimesimevabstolscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimevlevel	string	custom		PrimeSimVCS option primesim_evlevel: Improves performance especially in post-layout circuits with many coupling capacitors such as SRAM/DRAM.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimev levelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimev reltolscale	string	saTestbench		PrimeSimVCS option primesim_evreltolscale:
saPrimeSimVCSOptionprimesimev reltolscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimev tgridforpdn	string	saTestbench	1	PrimeSimVCS option primesim_evtgrid_for_pdn:
saPrimeSimVCSOptionprimesimev tgridforpdnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimev tgridmodeforpdn	string	saTestbench	1	PrimeSimVCS option primesim_evtgrid_mode_for_pdn:
saPrimeSimVCSOptionprimesimev tgridmodeforpdnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimev tgridrcnumforpdn	string	saTestbench	10000	PrimeSimVCS option primesim_evtgrid_rcnum_for_pdn:
saPrimeSimVCSOptionprimesimev tgridrcnumforpdnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimev tolscale	string	saTestbench		PrimeSimVCS option primesim_evtolscale:
saPrimeSimVCSOptionprimesimev tolscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimex cludegrayboxprobe	string	saTestbench		PrimeSimVCS option primesim_exclude_graybox_probe:
saPrimeSimVCSOptionprimesimex cludegrayboxprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimexcludegrayboxprobe is loaded.
saPrimeSimVCSOptionprimesimev exit	string	saTestbench		PrimeSimVCS option primesim_exit: Forces the PrimeSim tool to terminate after parsing

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimexitdcfail	string	custom		PrimeSimVCS option primesim_exit_dc_fail: Specifies whether to issue a warning message and continue the simulation or exit the simulation entirely if DC does not converge.
saPrimeSimVCSOptionprimesimexitdcfailUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimexitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimexitwarn	string	custom		PrimeSimVCS option primesim_exitwarn: Changes a PrimeSim Pro warning to an error by defining the warning string.
saPrimeSimVCSOptionprimesimexitwarnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimexitwarnwithfilter	string	saTestbench		PrimeSimVCS option primesim_exitwarn_with_filter:
saPrimeSimVCSOptionprimesimexitwarnwithfilterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimexpandinstancemfactor	string	custom		PrimeSimVCS option primesim_expand_instance_mfactor: Expands subcircuit instances based on the instance's multiplier parameter (M) and assigns a starting index.
saPrimeSimVCSOptionprimesimexpandinstancemfactorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimextendedpwrblock	string	custom		PrimeSimVCS option primesim_extended_pwrblock: Enables power block detection for topologies that have feedback and/or circuits that must be in the same partition.
saPrimeSimVCSOptionprimesimextendedpwrblockfix	string	saTestbench	1	PrimeSimVCS option primesim_extended_pwrblock_fix:
saPrimeSimVCSOptionprimesimextendedpwrblockfixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimextendedpwrblockUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimextmcbn	string	saTestbench	0	PrimeSimVCS option primesim_ext_mc_bin:
saPrimeSimVCSOptionprimesimextmcbnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfastcorner	string	saTestbench		PrimeSimVCS option primesim_fast_corner: Enables fast multi-corner simulation to enhance throughput when you use the same input netlist and input vector with variations of PVT (Process)
saPrimeSimVCSOptionprimesimfastcornersweep	string	saTestbench		PrimeSimVCS option primesim_fast_corner_sweep: Enables fast multi-corner simulation to enhance throughput when you use the same input netlist and input vector with variations of PVT (Process)
saPrimeSimVCSOptionprimesimfastcornersweepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfastcornerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfastcorneruseic	string	saTestbench	1	PrimeSimVCS option primesim_fast_corner_use_ic:
saPrimeSimVCSOptionprimesimfastcorneruseicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfcapkeep	string	saTestbench		PrimeSimVCS option primesim_fcapkeep:
saPrimeSimVCSOptionprimesimfcapkeepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfcapmin	string	custom	0	PrimeSimVCS option primesim_fcapmin: Converts a small coupling capacitance into two grounded capacitance values.
saPrimeSimVCSOptionprimesimfcapminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimfc apmodel	string	custom	1	PrimeSimVCS option primesim_fcmodel: Controls the modeling of floating capacitances.
saPrimeSimVCSOptionprimesimfc apmodelUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfc apratio	string	saTestbe nch	0	PrimeSimVCS option primesim_fcpratio:
saPrimeSimVCSOptionprimesimfc aprationethod	string	saTestbe nch		PrimeSimVCS option primesim_fcpratio_method:
saPrimeSimVCSOptionprimesimfc aprationethodUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfc apratioUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfc apred	string	saTestbe nch		PrimeSimVCS option primesim_fcprad:
saPrimeSimVCSOptionprimesimfc apredUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfc aprelax	string	saTestbe nch		PrimeSimVCS option primesim_fcprelax:
saPrimeSimVCSOptionprimesimfc aprelaxUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfin fet	string	saTestbe nch	2	PrimeSimVCS option primesim_finfet:
saPrimeSimVCSOptionprimesimfin fet24tlod	string	saTestbe nch	0	PrimeSimVCS option primesim_finfet2_4t_lod:
saPrimeSimVCSOptionprimesimfin fet24tlodUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfin fet2checkpwrpath	string	saTestbe nch	2	PrimeSimVCS option primesim_finfet2_check_pwr_path:
saPrimeSimVCSOptionprimesimfin fet2checkpwrpathUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimfinfetrule	string	saTestbench	0	PrimeSimVCS option primesim_finfet_rule:
saPrimeSimVCSOptionprimesimfinfetruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfinfetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfingerchar	string	custom		PrimeSimVCS option primesim_fingerchar: Sets the finger delimiter character for devices and instances.
saPrimeSimVCSOptionprimesimfingercharUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfingercurrent	string	custom		PrimeSimVCS option primesim_finger_current: Specifies whether to report the total device current or only the main device's finger current contribution.
saPrimeSimVCSOptionprimesimfingercurrentUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfingerstring	string	saTestbench		PrimeSimVCS option primesim_finger_string:
saPrimeSimVCSOptionprimesimfingerstringUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimfingerstring is loaded.
saPrimeSimVCSOptionprimesimflash	string	saTestbench		PrimeSimVCS option primesim_flash: Provides auto-detection and partitioning of internally-generated power supplies in flash design simulations
saPrimeSimVCSOptionprimesimflashcellmode	string	saTestbench		PrimeSimVCS option primesim_flashcell_mode:
saPrimeSimVCSOptionprimesimflashcellmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimflashUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimflat	string	saTestbench		PrimeSimVCS option primesim_flat:
saPrimeSimVCSOptionprimesimflatsize	string	custom	7	PrimeSimVCS option primesim_flatsize: Sets a threshold to flatten subcircuits before partitioning starts.
saPrimeSimVCSOptionprimesimflatsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimflatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfloatingcheckignoreic	string	saTestbench	0	PrimeSimVCS option primesim_floating_check_ignore_ic:
saPrimeSimVCSOptionprimesimfloatingcheckignoreicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfloatinggatecheck	string	saTestbench	0	PrimeSimVCS option primesim_floating_gate_check:
saPrimeSimVCSOptionprimesimfloatinggatecheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfloatinggatefix	string	saTestbench	1	PrimeSimVCS option primesim_floating_gate_fix:
saPrimeSimVCSOptionprimesimfloatinggatefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfloatinggategshunt	string	custom	0	PrimeSimVCS option primesim_floating_gate_gshunt: Adds a conductance between floating gate node and ground.
saPrimeSimVCSOptionprimesimfloatinggategshuntUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfloatingisrcdcmode	string	saTestbench	0	PrimeSimVCS option primesim_floating_isrc_dc_mode:
saPrimeSimVCSOptionprimesimfloatingisrcdcmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimfloatinglodaccuracy	string	saTestbench	0	PrimeSimVCS option primesim_floating_lod_accuracy:
saPrimeSimVCSOptionprimesimfloatinglodaccuracyUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfmeasform	string	saTestbench	0	PrimeSimVCS option primesim_fmeas_form:
saPrimeSimVCSOptionprimesimfmeasformUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimforceflat	string	saTestbench		PrimeSimVCS option primesim_force_flat:
saPrimeSimVCSOptionprimesimforceflatUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimforcepms	string	saTestbench	0	PrimeSimVCS option primesim_force_pms:
saPrimeSimVCSOptionprimesimforcepmsUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimforce_rcred	string	saTestbench	0	PrimeSimVCS option primesim_force_rcred:
saPrimeSimVCSOptionprimesimforce_rcredUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimforce_spred_plus	string	saTestbench		PrimeSimVCS option primesim_force_spred_plus:
saPrimeSimVCSOptionprimesimforce_spred_plusUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfscautodetect	string	custom		PrimeSimVCS option primesim_fsc_auto_detect: Voltage levels corresponding to logic levels or setting the VDD for a model will be handled automatically using this option.
saPrimeSimVCSOptionprimesimfscautodetectUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimfs cinstanceparam	string	saTestbe nch		PrimeSimVCS option primesim_fsc_instance_param:
saPrimeSimVCSOptionprimesimfs cinstanceparamUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfs cvdd	string	custom		PrimeSimVCS option primesim_fsc_vdd: Specifies the supply voltage for the C-model interface.
saPrimeSimVCSOptionprimesimfs cvddUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfs dblimit	string	custom	0	PrimeSimVCS option primesim_fsdb_limit: Specifies a size limit for fsdb files.
saPrimeSimVCSOptionprimesimfs dblimitUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfs dbsplitpg	string	custom		PrimeSimVCS option primesim_fsdb_split_pg: Specifies to split Power/Ground R-Network nodes in non-ideal Power/Ground simulation from all other Signals and dump them into a separate FSDB file.
saPrimeSimVCSOptionprimesimfs dbsplitpgUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfs dbsplittime	string	custom		PrimeSimVCS option primesim_fsdb_split_time: Specifies to split FSDB based on the time values.
saPrimeSimVCSOptionprimesimfs dbsplittimeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfs dbtermvarhier	string	saTestbe nch		PrimeSimVCS option primesim_fsdb_term_var_hier: Changes the terminal delimiter
saPrimeSimVCSOptionprimesimfs dbtermvarhierUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimfs dbversion	string	custom		PrimeSimVCS option primesim_fsdb_version: Specifies what version of FSDB writer the PrimeSim tool should use.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimfsdbversionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgateevtol	string	saTestbench		PrimeSimVCS option primesim_gate_evtol:
saPrimeSimVCSOptionprimesimgateevtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgateleakage	string	saTestbench		PrimeSimVCS option primesim_gate_leakage:
saPrimeSimVCSOptionprimesimgateleakageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgdcpath	string	custom		PrimeSimVCS option primesim_gdcpath: Adds gshunts to nodes having no DC path to ground.
saPrimeSimVCSOptionprimesimgdcpathmode	string	saTestbench	3	PrimeSimVCS option primesim_gdcpath_mode:
saPrimeSimVCSOptionprimesimgdcpathmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgdcpathUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgenacop	string	custom	1	PrimeSimVCS option primesim_gen_ac_op: Determines if binary files or ASCII .ic files are generated for each time point in .OP statement
saPrimeSimVCSOptionprimesimgenacopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgencckdb	string	saTestbench		PrimeSimVCS option primesim_gen_cck_db:
saPrimeSimVCSOptionprimesimgencckdbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimgencckdb is loaded.
saPrimeSimVCSOptionprimesimgenicop	string	custom	0	PrimeSimVCS option primesim_gen_ic_op: Generates the .op file when it is not created by default.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimgenicoUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgenmc0	string	custom		PrimeSimVCS option primesim_gen_mc0: Specifies whether to generate the *.mc# file for Monte Carlo analysis.
saPrimeSimVCSOptionprimesimgenmc0UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgenopcaptab	string	custom		PrimeSimVCS option primesim_gen_op_captab: Generates node capacitance information in the .op file.
saPrimeSimVCSOptionprimesimgenopcaptabUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgenpn_c	string	custom		PrimeSimVCS option primesim_gen_pn_c: Enables output to the *.pn_c0 file in .NOISE analysis.
saPrimeSimVCSOptionprimesimgenpn_cUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgic	string	custom	1e10	PrimeSimVCS option primesim_gic: Sets conductance value of the resistor in the Norton-type voltage source.
saPrimeSimVCSOptionprimesimgicind	string	saTestbench		PrimeSimVCS option primesim_gic_ind:
saPrimeSimVCSOptionprimesimgicindUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgmax	string	custom	100	PrimeSimVCS option primesim_gmax: Clamps the stamped conductance value to primesim_gmax.
saPrimeSimVCSOptionprimesimgmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimgmitelem	string	custom		PrimeSimVCS option primesim_gmi_telem: Specifies which T-element implementation to use.
saPrimeSimVCSOptionprimesimgmitelemUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgoff	string	custom		PrimeSimVCS option primesim_goff: Works with the .CHKZNODE statement to determine if a MOSFET is on or off.
saPrimeSimVCSOptionprimesimgoffcheck	string	saTestbench	1.0e-09	PrimeSimVCS option primesim_goff_check:
saPrimeSimVCSOptionprimesimgoffcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgoffpower	string	saTestbench	1.0e-05	PrimeSimVCS option primesim_goff_power:
saPrimeSimVCSOptionprimesimgoffpowerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgoffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgpd	string	custom		PrimeSimVCS option primesim_gpd: Back-annotates a corner used in the Galaxy Parasitic Database (GPD).
saPrimeSimVCSOptionprimesimgpddump	string	saTestbench	(1+4)	PrimeSimVCS option primesim_gpd_dump:
saPrimeSimVCSOptionprimesimgpddumpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgpddUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgpsthmax	string	saTestbench		PrimeSimVCS option primesim_gpt_hmax:
saPrimeSimVCSOptionprimesimgpsthmaxf	string	saTestbench		PrimeSimVCS option primesim_gpt_hmax_f:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimgp thmaxfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgp thmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgp tramptime	string	saTestbench		PrimeSimVCS option primesim_gpt_ramp_time:
saPrimeSimVCSOptionprimesimgp tramptimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgp ttimepointsnum	string	saTestbench	2000	PrimeSimVCS option primesim_gpt_timepoints_num:
saPrimeSimVCSOptionprimesimgp ttimepointsnumUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgp tweight	string	saTestbench		PrimeSimVCS option primesim_gpt_weight:
saPrimeSimVCSOptionprimesimgp tweightUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgp uid	string	saTestbench		PrimeSimVCS option primesim_gpuid:
saPrimeSimVCSOptionprimesimgp uidUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimgpuid is loaded.
saPrimeSimVCSOptionprimesimgp umode	string	saTestbench	2	PrimeSimVCS option primesim_gpu_mode: Specifies the mode of operation when using GPU simulation.
saPrimeSimVCSOptionprimesimgp umodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgp uoptimize	string	saTestbench		PrimeSimVCS option primesim_gpu_optimize:
saPrimeSimVCSOptionprimesimgp uoptimizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimgroundmoscap	string	saTestbench		PrimeSimVCS option primesim_ground_moscap:
saPrimeSimVCSOptionprimesimgroundmoscapUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgroup	string	saTestbench		PrimeSimVCS option primesim_group:
saPrimeSimVCSOptionprimesimgroupUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgshpt	string	saTestbench		PrimeSimVCS option primesim_gshpt: Adds conductance from each node to ground during pseudo-transient simulation. After pseudo-transient converges.
saPrimeSimVCSOptionprimesimgshptUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimgvsrcn	string	saTestbench		PrimeSimVCS option primesim_gvsrcn:
saPrimeSimVCSOptionprimesimgvsrcnUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimhflash	string	saTestbench		PrimeSimVCS option primesim_hflash:
saPrimeSimVCSOptionprimesimhflashUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimhgrace	string	saTestbench	1	PrimeSimVCS option primesim_hgrace:
saPrimeSimVCSOptionprimesimhgraceUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimhiersim	string	custom		PrimeSimVCS option primesim_hiersim: Selects hierarchical simulation mode.
saPrimeSimVCSOptionprimesimhiersimavg	string	saTestbench		PrimeSimVCS option primesim_hiersim_avg:
saPrimeSimVCSOptionprimesimhiersimavgUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimhiersimUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimhighaccmode	string	saTestbench		PrimeSimVCS option primesim_highacc_mode:
saPrimeSimVCSOptionprimesimhighaccmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimhighspeedmode	string	saTestbench		PrimeSimVCS option primesim_highspeed_mode:
saPrimeSimVCSOptionprimesimhighspeedmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimhstolscale	string	custom	1	PrimeSimVCS option primesim_hstolscale: Sets a multiplier applied to all internal tolerance values for subcircuits that will be simulated with the hiersim method.
saPrimeSimVCSOptionprimesimhstolscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimicpriority	string	custom		PrimeSimVCS option primesim_ic_priority: Forces the PrimeSim tool to take the .IC value even if there is a .NODESET value defined later on the same node.
saPrimeSimVCSOptionprimesimicpriorityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimidenticalmcinstancefile	string	custom		PrimeSimVCS option primesim_identical_mc_instance_file: Generate the same random number sequence for the Monte Carlo Simulation.
saPrimeSimVCSOptionprimesimidenticalmcinstancefileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimidrsubckt	string	saTestbench		PrimeSimVCS option primesim_idrsubckt:
saPrimeSimVCSOptionprimesimidrsubcktUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimignore	string	custom		PrimeSimVCS option primesim_ignore: Ignores instances or subcircuits in simulation for higher performance.
saPrimeSimVCSOptionprimesimignoreallhizvsrc	string	saTestbench		PrimeSimVCS option primesim_ignore_all_hiz_vsrc:
saPrimeSimVCSOptionprimesimignoreallhizvsrcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimignorechkfuncerror	string	custom	0	PrimeSimVCS option primesim_ignore_chkfunc_error: Continues the simulation with a warning instead of an error and exiting.
saPrimeSimVCSOptionprimesimignorechkfuncerrorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimignoredevice	string	custom		PrimeSimVCS option primesim_ignore_device: Makes quick netlist changes by ignoring specified devices during simulation.
saPrimeSimVCSOptionprimesimignoredeviceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimignoredummyinstance	string	saTestbench		PrimeSimVCS option primesim_ignore_dummy_instance:
saPrimeSimVCSOptionprimesimignoredummyinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimignoredummyinstance is loaded.
saPrimeSimVCSOptionprimesimignorefloatingnode	string	saTestbench		PrimeSimVCS option primesim_ignore_floating_node: Suppresses WARNINGS about ""No DC path to ground on MOSFET..."".
saPrimeSimVCSOptionprimesimignorefloatingnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimignorefloatisrc	string	custom	0	PrimeSimVCS option primesim_ignore_float_isrc: Ignores the floating current source and outputs a warning message.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimignorefloatisrcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimignoreinstance	string	saTestbench		PrimeSimVCS option primesim_ignore_instance:
saPrimeSimVCSOptionprimesimignoreinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimignoreinstparam	string	saTestbench	1	PrimeSimVCS option primesim_ignore_inst_param:
saPrimeSimVCSOptionprimesimignoreinstparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimignorelayoutonlydevice	string	custom		PrimeSimVCS option primesim_ignore_layout_only_device: Skips the specified devices for the include flow.
saPrimeSimVCSOptionprimesimignorelayoutonlydeviceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimignorenovecldataerror	string	custom		PrimeSimVCS option primesim_ignore_no_vec_tdata_error: Specifies whether to error out if there is no tabular data in the I/O vector file.
saPrimeSimVCSOptionprimesimignorenovecldataerrorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimignoreopanalysis	string	custom		PrimeSimVCS option primesim_ignore_op_analysis: Specifies whether to ignore .OP analysis in the netlist.
saPrimeSimVCSOptionprimesimignoreopanalysisUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimignoreepdspvtolcond	string	saTestbench	0	PrimeSimVCS option primesim_ignore_pds_pvtol_cond:
saPrimeSimVCSOptionprimesimignoreepdspvtolcondUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimignorepincap	string	saTestbench	0	PrimeSimVCS option primesim_ignore_pincap:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimig norepincapUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimig noresubblkoptionerror	string	custom	0	PrimeSimVCS option primesim_ignore_subblk_option_error: .
saPrimeSimVCSOptionprimesimig noresubblkoptionerrorUncheckLoc alized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimig noretdfortsc	string	saTestbe nch	3	PrimeSimVCS option primesim_ignore_td_for_tsc:
saPrimeSimVCSOptionprimesimig noretdfortscUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimig noreUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimig noreva	string	custom		PrimeSimVCS option primesim_ignore_va: Improves front-end performance by ignoring Verilog-A file parsing.
saPrimeSimVCSOptionprimesimig norevaUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimim	string	saTestbe nch		PrimeSimVCS option primesim_im:
saPrimeSimVCSOptionprimesimim UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimin activechkanodedv	string	saTestbe nch		PrimeSimVCS option primesim_inactive_chkanode_dv: When performing fast multi-corner simulation
saPrimeSimVCSOptionprimesimin activechkanodedvUncheckLocal ized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimin activeshortrc	string	saTestbe nch	9	PrimeSimVCS option primesim_inactive_short_rc:
saPrimeSimVCSOptionprimesimin activeshortrccaptol	string	saTestbe nch	1e-15	PrimeSimVCS option primesim_inactive_short_rc_cap_tol:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesiminactiveshortrccaptolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesiminactiveshortrccurtol	string	saTestbench	1e-3	PrimeSimVCS option primesim_inactive_short_rc_cur_tol:
saPrimeSimVCSOptionprimesiminactiveshortrccurtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesiminactiveshortrcdebug	string	saTestbench	0	PrimeSimVCS option primesim_inactive_short_rc_debug:
saPrimeSimVCSOptionprimesiminactiveshortrcdebugUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesiminactiveshortrcresol	string	saTestbench	1e3	PrimeSimVCS option primesim_inactive_short_rc_res_tol:
saPrimeSimVCSOptionprimesiminactiveshortrcresolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesiminactiveshortrcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesiminactiveshortrcvoltage	string	saTestbench	1e-2	PrimeSimVCS option primesim_inactive_short_rc_vol_tol:
saPrimeSimVCSOptionprimesiminactiveshortrcvoltageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimincludedevice	string	saTestbench		PrimeSimVCS option primesim_include_device:
saPrimeSimVCSOptionprimesimincludedeviceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimincludinstance	string	custom		PrimeSimVCS option primesim_include_instance: Includes the specified instances in the simulation. All other instances are ignored.
saPrimeSimVCSOptionprimesimincludinstanceflow	string	saTestbench		PrimeSimVCS option primesim_include_instance_flow:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimincludeinstanceflowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimincludeinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimindn	string	custom		PrimeSimVCS option primesim_indn: Specifies whether the PrimeSim tool uses a Norton equivalent or a more accurate formulation to model a simple inductor.
saPrimeSimVCSOptionprimesimindnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesiminfo_limit	string	saTestbench		PrimeSimVCS option primesim_info_limit: Sets the number of ""INFO:"" messages to a limited number of user-specified lines.
saPrimeSimVCSOptionprimesiminfo_limitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimiovecabsvalue	string	custom	0	PrimeSimVCS option primesim_iovec_abs_value: Treats all the time values in the vector file as absolute time.
saPrimeSimVCSOptionprimesimiovecabsvalueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimioveckeepnode	string	saTestbench		PrimeSimVCS option primesim_iovec_keep_node:
saPrimeSimVCSOptionprimesimioveckeepnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimiovecoption	string	custom		PrimeSimVCS option primesim_iovec_option: Specifies whether PrimeSim accuracy options can be used inside a vector file using the fscript utility fset command.
saPrimeSimVCSOptionprimesimiovecoptionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimiovecvih	string	custom		PrimeSimVCS option primesim_iovec_vih: Sets the logichv outside of a vector file.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimio vecvihUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimio vecvil	string	custom		PrimeSimVCS option primesim_iovec_vil: Sets the logiclv outside of a vector file.
saPrimeSimVCSOptionprimesimio vecvilUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimio vecvoh	string	custom		PrimeSimVCS option primesim_iovec_voh: Sets the default voh value for the vector file.
saPrimeSimVCSOptionprimesimio vecvohUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimio vecvol	string	custom		PrimeSimVCS option primesim_iovec_vol: Sets the default vol value for the vector file.
saPrimeSimVCSOptionprimesimio vecvolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimipr btmin	string	saTestbench		PrimeSimVCS option primesim_iprbtmin:
saPrimeSimVCSOptionprimesimipr btminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimipr btol	string	custom	1e-12	PrimeSimVCS option primesim_iprbtol: Sets the current tolerance for the current print out.
saPrimeSimVCSOptionprimesimipr btolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimipr obeaflevel	string	custom		PrimeSimVCS option primesim_iprobe_leaf_level: Specifies whether to output device currents at the lowest level of hierarchy in the design.
saPrimeSimVCSOptionprimesimipr obeaflevelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimipr obescope	string	saTestbench		PrimeSimVCS option primesim_iprobe_scope:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimipr obescopeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimip wltol	string	saTestbe nch	0	PrimeSimVCS option primesim_ipwltol:
saPrimeSimVCSOptionprimesimip wltolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimire mdebug	string	saTestbe nch		PrimeSimVCS option primesim_irem_debug:
saPrimeSimVCSOptionprimesimire mdebugUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimire mflow	string	saTestbe nch	0	PrimeSimVCS option primesim_irem_flow:
saPrimeSimVCSOptionprimesimire mflowUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimire mrms	string	custom	0	PrimeSimVCS option primesim_irem_rms: Calculate RMS value of the current and report it as AC current.
saPrimeSimVCSOptionprimesimire mrmsUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimire mtimestep	string	saTestbe nch		PrimeSimVCS option primesim_irem_time_step:
saPrimeSimVCSOptionprimesimire mtimestepUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimis olatedvsres	string	custom		PrimeSimVCS option primesim_isolated_vsrc_res: Specifies whether to detect floating voltage sources which are referenced by other current controlled sources and add a shunt resistance of 1M to them.
saPrimeSimVCSOptionprimesimis olatedvsresUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimlteratioscale	string	saTestbench	1.0	PrimeSimVCS option primesim_iteratio_scale: Multiplier for time-step local truncation error tolerance. Larger value means larger time step. Possible values are normally between 0.1 and 10
saPrimeSimVCSOptionprimesimlteratioscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimlteratioscale is loaded.
saPrimeSimVCSOptionprimesimkeep0vdcvs	string	custom	0	PrimeSimVCS option primesim_keep_0v_dcvs: Keeps 0v DC voltage sources in the simulation database.
saPrimeSimVCSOptionprimesimkeep0vdcvsop	string	custom	0	PrimeSimVCS option primesim_keep_0v_dcvs_op: Keeps 0v DC voltage sources for .op analysis.
saPrimeSimVCSOptionprimesimkeep0vdcvsopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimkeep0vdcvsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimkeepdevice	string	saTestbench		PrimeSimVCS option primesim_keep_device:
saPrimeSimVCSOptionprimesimkeepdeviceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimkeephier	string	saTestbench		PrimeSimVCS option primesim_keeplier:
saPrimeSimVCSOptionprimesimkeephierUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimkeepnode	string	saTestbench		PrimeSimVCS option primesim_keep_node:
saPrimeSimVCSOptionprimesimkeepnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimkeepzeroparms	string	custom	0	PrimeSimVCS option primesim_keepzeroparms: Use zero values for PS, PD, AS, and AD parameters for BSIM models.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimke epzeroparmsUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlat chalgmaxiter	string	saTestbe nch	5	PrimeSimVCS option primesim_latch_alg_max_iter:
saPrimeSimVCSOptionprimesimlat chalgmaxiterUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimla youtonlyoptimization	string	saTestbe nch	3	PrimeSimVCS option primesim_layout_only_optimization:
saPrimeSimVCSOptionprimesimla youtonlyoptimizationUncheckLocal ized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlc dcutnode	string	saTestbe nch		PrimeSimVCS option primesim_lcd_cutnode:
saPrimeSimVCSOptionprimesimlc dcutnodeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlc dmode	string	saTestbe nch		PrimeSimVCS option primesim_lcd_mode:
saPrimeSimVCSOptionprimesimlc dmodeaccuracy	string	saTestbe nch		PrimeSimVCS option primesim_lcd_mode_accuracy:
saPrimeSimVCSOptionprimesimlc dmodeaccuracyUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlc dmodealg	string	saTestbe nch	2	PrimeSimVCS option primesim_lcd_mode_alg:
saPrimeSimVCSOptionprimesimlc dmodealgUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlc dmodecutallva	string	saTestbe nch	0	PrimeSimVCS option primesim_lcd_mode_cut_all_va:
saPrimeSimVCSOptionprimesimlc dmodecutallvaUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlc dmodecutgate	string	saTestbe nch	2	PrimeSimVCS option primesim_lcd_mode_cut_gate:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimlcdmodecutgateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlcdmodefix	string	saTestbench	0	PrimeSimVCS option primesim_lcd_mode_fix:
saPrimeSimVCSOptionprimesimlcdmodefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlcdmodegptmax	string	saTestbench	2e-5	PrimeSimVCS option primesim_lcd_mode_gpt_max:
saPrimeSimVCSOptionprimesimlcdmodegptmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlcdmodehssforpdsfail	string	saTestbench	1	PrimeSimVCS option primesim_lcd_mode_hss_for_pds_fail:
saPrimeSimVCSOptionprimesimlcdmodehssforpdsfailUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlcdmodepartition	string	saTestbench	0	PrimeSimVCS option primesim_lcd_mode_partition:
saPrimeSimVCSOptionprimesimlcdmodepartitionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlcdmodeplus	string	saTestbench	1	PrimeSimVCS option primesim_lcd_mode_plus:
saPrimeSimVCSOptionprimesimlcdmodeplusUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlcdmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlcdpanelpwrmesh	string	saTestbench		PrimeSimVCS option primesim_lcd_panel_pwrmesh:
saPrimeSimVCSOptionprimesimlcdpanelpwrmeshUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlcdsioievtolscale	string	saTestbench	5.0	PrimeSimVCS option primesim_lcd_sio_ievtolscale:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimlc dsioievtolscaleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlc dusespd	string	saTestbe nch	1	PrimeSimVCS option primesim_lcd_use_spd:
saPrimeSimVCSOptionprimesimlc dusespdUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimle akagemode	string	custom	0	PrimeSimVCS option primesim_leakage_mode: Uses more conservative leakage tolerances for better accuracy.
saPrimeSimVCSOptionprimesimle akagemodeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimle gacyduprule	string	saTestbe nch		PrimeSimVCS option primesim_legacy_dup_rule:
saPrimeSimVCSOptionprimesimle gacydupruleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlib infolog	string	saTestbe nch	0	PrimeSimVCS option primesim_lib_info_log:
saPrimeSimVCSOptionprimesimlib infologUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesiml ist	string	saTestbe nch		PrimeSimVCS option primesim_list:
saPrimeSimVCSOptionprimesimlis tnoisesources	string	saTestbe nch		PrimeSimVCS option primesim_list_noisesources:
saPrimeSimVCSOptionprimesimlis tnoisesourcesUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimlistnoisesources is loaded.
saPrimeSimVCSOptionprimesimlis tUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimlo admodel	string	custom	<file path>	PrimeSimVCS option primesim_loadmodel: Sets the capacitive load model that a partition output drives.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	string	saTestbench	1.2	PrimeSimVCS option primesim_loose_lte_errtol:
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	string	saTestbench		PrimeSimVCS option primesim_lprobe_hiz: Specifies whether to check the Hi-Z node and display the ""Z"" state in the waveform.
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	string	custom		PrimeSimVCS option primesim_lprobe_vh: Sets the high threshold value for signals with .LPROBE statement.
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	string	custom		PrimeSimVCS option primesim_lprobe_vl: Sets the low threshold value for signals with .LPROBE statement.
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	string	saTestbench		PrimeSimVCS option primesim_lpt_weight:
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	string	custom		PrimeSimVCS option primesim_lsf_format_chars: Allows usage of 3rd-party Verilog-A special characters.
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimloadmodelUncheckLocalized	string	saTestbench		PrimeSimVCS option primesim_lte_dv_scale:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimltdvscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimltdratioscale	string	saTestbench	1	PrimeSimVCS option primesim_iteratio_scale:
saPrimeSimVCSOptionprimesimltdratioscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmakelocalvarspersistent	string	saTestbench	0	PrimeSimVCS option primesim_make_local_vars_persistent:
saPrimeSimVCSOptionprimesimmakelocalvarspersistentUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmakeuniquemodel	string	saTestbench	0	PrimeSimVCS option primesim_make_unique_model:
saPrimeSimVCSOptionprimesimmakeuniquemodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmakeuniquemosmodel	string	saTestbench	0	PrimeSimVCS option primesim_make_unique_mos_model:
saPrimeSimVCSOptionprimesimmakeuniquemosmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmapprbport	string	custom		PrimeSimVCS option primesim_map_prbport: Maps probe statements from :[dgsb] to v[1234] syntax.
saPrimeSimVCSOptionprimesimmapprbportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmappwltopwl	string	saTestbench	0	PrimeSimVCS option primesim_map_pwlz_to_pwl:
saPrimeSimVCSOptionprimesimmappwltopwlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmapvalueonlyiparam	string	saTestbench	0	PrimeSimVCS option primesim_map_value_only_iparam:
saPrimeSimVCSOptionprimesimmapvalueonlyiparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimmaxicout	string	custom	1000000	PrimeSimVCS option primesim_maxicout: Sets maximum number of node voltages included in the .ic file.
saPrimeSimVCSOptionprimesimmaxicoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimaxparallel	string	saTestbench		PrimeSimVCS option primesim_max_parallel: For parallel simulation in PrimeSim Pro mode with multiple CPUs
saPrimeSimVCSOptionprimesimaxparallelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimaxswapallowed	string	custom		PrimeSimVCS option primesim_max_swap_allowed: Controls the maximum amount of swap memory that can be used during a simulation.
saPrimeSimVCSOptionprimesimaxswapallowedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimaxwidthtol	string	custom		PrimeSimVCS option primesim_max_width_tol: Sets tolerance range for transistor width when it exceeds max. defined width.
saPrimeSimVCSOptionprimesimaxwidthtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcbisecwinscale	string	saTestbench	0	PrimeSimVCS option primesim_mc_bisec_win_scale:
saPrimeSimVCSOptionprimesimcbisecwinscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcbrief	string	custom	1	PrimeSimVCS option primesim_mcbrief: Limits Monte Carlo information in log file.
saPrimeSimVCSOptionprimesimcbriefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimcnominalsimulation	string	custom		PrimeSimVCS option primesim_mc_nominal_simulation: Sets the behavior of simple random sampling (SRS) for the first Monte Carlo sweep.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimmcnominalsimulationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmcreplacefailedmeas	string	custom		PrimeSimVCS option primesim_mc_replace_failed_meas: Specifies whether to continue to run Monte Carlo sweeps until the requested number of runs (MONTE=num) have successful measurements.
saPrimeSimVCSOptionprimesimmcreplacefailedmeasUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmcseed	string	custom		PrimeSimVCS option primesim_mcseed: Provides a seed to produce the same sequence of random numbers in Monte Carlo simulation.
saPrimeSimVCSOptionprimesimmcseedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmcsigma scale	string	custom		PrimeSimVCS option primesim_mc_sigma_scale: Scales the Monte Carlo distribution.
saPrimeSimVCSOptionprimesimmcsigma scaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmcstatsreport	string	custom		PrimeSimVCS option primesim_mc_stats_report: Controls printing of Monte Carlo statistics.
saPrimeSimVCSOptionprimesimmcstatsreportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmeasfromto	string	custom		PrimeSimVCS option primesim_meas_from_to: Specifies whether the FROM and TO parameters for the TARG parameter of a measurement are applied to the TRIG parameter of the measurement.
saPrimeSimVCSOptionprimesimmeasfromtoUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmeasout	string	custom	0	PrimeSimVCS option primesim_measout: Controls the measurement file format.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimmasoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmasostolcale	string	custom		PrimeSimVCS option primesim_masostolcale: Specifies the compression factor of internally saved data when performing runtime measurement.
saPrimeSimVCSOptionprimesimmasostolcaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmasergechannelconnectedpwrblk	string	saTestbench	1	PrimeSimVCS option primesim_merge_channel_connected_pwrblk:
saPrimeSimVCSOptionprimesimmasergechannelconnectedpwrblkUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmasergegmeasfile	string	custom		PrimeSimVCS option primesim_merged_meas_file: Specifies whether to output separate .mt0 files or a single merged .mt0 file for sweep and bisection.
saPrimeSimVCSOptionprimesimmasergegmeasfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmasergefsdb	string	custom		PrimeSimVCS option primesim_merge_fsdb: Specifies whether to merge the PrimeSim tool's FSDB output with a digital FSDB file for mixed-signal simulation using the VCS PrimeSim AMS tool.
saPrimeSimVCSOptionprimesimmasergefsdbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmasergehdl	string	saTestbench	0	PrimeSimVCS option primesim_merge_hdl:
saPrimeSimVCSOptionprimesimmasergehdlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmasergeparmosdio	string	custom		PrimeSimVCS option primesim_merge_parmosdio: Optimizes MOSFET device instances that are in parallel.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimmergeparmosdioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmergepininstance	string	custom		PrimeSimVCS option primesim_merge_pinstance: Optimizes subcircuit instances that are in parallel.
saPrimeSimVCSOptionprimesimmergepininstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmergevectorerrormsg	string	custom		PrimeSimVCS option primesim_merge_vector_errormsg: Specifies whether to merge the .err files from multiple runs into a single .err file.
saPrimeSimVCSOptionprimesimmergevectorerrormsgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmergethethod	string	custom	TRAP	PrimeSimVCS option primesim_method: Sets the numerical integration method used during a transient analysis.
saPrimeSimVCSOptionprimesimmergethethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimminchannelcutdevcnt	string	saTestbench	15	PrimeSimVCS option primesim_min_channel_cut_dev_cnt:
saPrimeSimVCSOptionprimesimminchannelcutdevcntUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimminchannelcutdevratio	string	saTestbench	0.2	PrimeSimVCS option primesim_min_channel_cut_dev_ratio:
saPrimeSimVCSOptionprimesimminchannelcutdevratioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimminnares	string	saTestbench		PrimeSimVCS option primesim_mnares:
saPrimeSimVCSOptionprimesimminnaresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmerode	string	custom	promd	PrimeSimVCS option primesim_mode: Sets the Simulation mode

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimmodel	string	custom	4.5	PrimeSimVCS option primesim_model: Sets the modeling method of the MOSFETs.
saPrimeSimVCSOptionprimesimodelduprule	string	saTestbench	0	PrimeSimVCS option primesim_model_dup_rule:
saPrimeSimVCSOptionprimesimodeldupruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimodelverificationmode	string	custom	0	PrimeSimVCS option primesim_model_verification_mode: Use tighter simulation settings for simulations with model qualification.
saPrimeSimVCSOptionprimesimodelverificationmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoduleinstance	string	custom		PrimeSimVCS option primesim_module_instance: Applies a 3DIC module for a regular netlist without modifying the input netlist.
saPrimeSimVCSOptionprimesimoduleinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimonitor	string	custom		PrimeSimVCS option primesim_monitor: Provides CPU monitoring functionality when the PrimeSim tool is running on a server.
saPrimeSimVCSOptionprimesimonitorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoscapcut	string	custom		PrimeSimVCS option primesim_moscapcut: Specifies when the MOS capacitor should be cut for partitioning based on its estimated capacitance value.
saPrimeSimVCSOptionprimesimoscapcutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimm osfetfastprobelx34	string	custom		PrimeSimVCS option primesim_mosfet_fast_probe_lx34: Speeds up probing the LX34 MOS parameter for the level=129 CMI model.
saPrimeSimVCSOptionprimesimm osfetfastprobelx34UncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimm osmacromodel	string	saTestbe nch	0	PrimeSimVCS option primesim_mos_macro_model:
saPrimeSimVCSOptionprimesimm osmacromodelUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimm parcheck	string	custom	0	PrimeSimVCS option primesim_mparcheck: Determines if MOSFET model parameters will be checked.
saPrimeSimVCSOptionprimesimm parcheckUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimm scale	string	saTestbe nch	-1	PrimeSimVCS option primesim_mscales:
saPrimeSimVCSOptionprimesimm scaleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimne gres	string	custom	1	PrimeSimVCS option primesim_negres: Keeps negative resistors in the netlist.
saPrimeSimVCSOptionprimesimne gresUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimne wfcapflow	string	saTestbe nch	0	PrimeSimVCS option primesim_new_fcap_flow:
saPrimeSimVCSOptionprimesimne wfcapflowUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimne wfindmodel	string	saTestbe nch		PrimeSimVCS option primesim_new_find_model:
saPrimeSimVCSOptionprimesimne wfindmodelUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimnewprobe	string	saTestbench		PrimeSimVCS option primesim_new_probe:
saPrimeSimVCSOptionprimesimnewprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimnewoutput	string	saTestbench	3	PrimeSimVCS option primesim_new_output:
saPrimeSimVCSOptionprimesimnewoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimnewqueue	string	saTestbench		PrimeSimVCS option primesim_new_queue:
saPrimeSimVCSOptionprimesimnewqueueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimnewresolve	string	saTestbench	0	PrimeSimVCS option primesim_new_resolve:
saPrimeSimVCSOptionprimesimnewresolveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimnewxprobe	string	saTestbench	0	PrimeSimVCS option primesim_new_xprobe:
saPrimeSimVCSOptionprimesimnewxprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimnoiseformat	string	custom		PrimeSimVCS option primesim_noise_format: Controls the format of the .pn0 output file.
saPrimeSimVCSOptionprimesimnoiseformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimnoiseoff	string	custom		PrimeSimVCS option primesim_noise_off: Disable noise generation
saPrimeSimVCSOptionprimesimnoiseoffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimnoiseon	string	custom		PrimeSimVCS option primesim_noise_on: Enable noise generation

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimno iseonUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimno shorting	string	saTestbe nch	0	PrimeSimVCS option primesim_noshorting:
saPrimeSimVCSOptionprimesimno shortingUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimno swap	string	custom		PrimeSimVCS option primesim_no_swap: Controls whether disk swap can be used when the simulation runs out of memory.
saPrimeSimVCSOptionprimesimno swapUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimnp cmax	string	custom		PrimeSimVCS option primesim_npc_max: Specifies that the PrimeSim SPICE tool should take extra effort to ensure that simulation results are consistent across a different number of threads.
saPrimeSimVCSOptionprimesimnp cmaxUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimnr tol	string	saTestbe nch		PrimeSimVCS option primesim_nrtol:
saPrimeSimVCSOptionprimesimnr tolscale	string	saTestbe nch		PrimeSimVCS option primesim_nrtolscale:
saPrimeSimVCSOptionprimesimnr tolscaleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimnr tolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimnu mmaxdevforoptimizepartition	string	saTestbe nch		PrimeSimVCS option primesim_num_max_dev_for_optimize_partition:
saPrimeSimVCSOptionprimesimnu mmaxdevforoptimizepartitionUnch eckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimnummeaslog	string	custom		PrimeSimVCS option primesim_num_meas_log: Limits number of measurement results output to the screen and log file.
saPrimeSimVCSOptionprimesimnummeaslogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimnummeasperline	string	custom	0	PrimeSimVCS option primesim_num_meas_per_line: Outputs measurement values on multiple lines.
saPrimeSimVCSOptionprimesimnummeasperlineUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoledaccuratewaveform	string	saTestbench	0	PrimeSimVCS option primesim_oled_accurate_waveform:
saPrimeSimVCSOptionprimesimoledaccuratewaveformUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoledcktsize	string	saTestbench	-1	PrimeSimVCS option primesim_oled_ckt_size:
saPrimeSimVCSOptionprimesimoledcktsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoleddatasignal	string	saTestbench		PrimeSimVCS option primesim_oled_data_signal:
saPrimeSimVCSOptionprimesimoleddatasignalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoledfullpanel	string	saTestbench	0	PrimeSimVCS option primesim_oled_fullpanel:
saPrimeSimVCSOptionprimesimoledfullpanelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoledglobalnode	string	saTestbench		PrimeSimVCS option primesim_oled_global_node:
saPrimeSimVCSOptionprimesimoledglobalnoderatio	string	saTestbench	1.	PrimeSimVCS option primesim_oled_global_node_ratio:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimoleglobalnodeatioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoleglobalnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimolemainnode	string	saTestbench		PrimeSimVCS option primesim_ole_main_node:
saPrimeSimVCSOptionprimesimolemainnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimolemainnodevalue	string	saTestbench	1e-18	PrimeSimVCS option primesim_ole_main_node_value:
saPrimeSimVCSOptionprimesimolemainnodevalueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimolemanualpartition	string	saTestbench	0	PrimeSimVCS option primesim_ole_manual_partition:
saPrimeSimVCSOptionprimesimolemanualpartitionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimolemaxsynch	string	saTestbench	1e-6	PrimeSimVCS option primesim_ole_max_sync_h:
saPrimeSimVCSOptionprimesimolemaxsynchUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimolemeasurerow	string	saTestbench		PrimeSimVCS option primesim_ole_measure_row:
saPrimeSimVCSOptionprimesimolemeasurerowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimolemeshpower	string	saTestbench		PrimeSimVCS option primesim_ole_mesh_power:
saPrimeSimVCSOptionprimesimolemeshpowerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimolemode	string	saTestbench		PrimeSimVCS option primesim_ole_mode:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimol edmodeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimol edmultirate	string	saTestbe nch	1	PrimeSimVCS option primesim_oled_multirate:
saPrimeSimVCSOptionprimesimol edmultirateUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimol ednumactiverow	string	saTestbe nch	16	PrimeSimVCS option primesim_oled_num_active_row:
saPrimeSimVCSOptionprimesimol ednumactiverowUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimol ednumcol	string	saTestbe nch	-1	PrimeSimVCS option primesim_oled_num_col:
saPrimeSimVCSOptionprimesimol ednumcolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimol ednumrow	string	saTestbe nch	-1	PrimeSimVCS option primesim_oled_num_row:
saPrimeSimVCSOptionprimesimol ednumrowpernp	string	saTestbe nch	16	PrimeSimVCS option primesim_oled_num_row_per_np:
saPrimeSimVCSOptionprimesimol ednumrowpernpUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimol ednumrowUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimol edpixeltype	string	saTestbe nch	2	PrimeSimVCS option primesim_oled_pixel_type:
saPrimeSimVCSOptionprimesimol edpixeltypeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimol edprintboundarynode	string	saTestbe nch	0	PrimeSimVCS option primesim_oled_print_boundary_node:
saPrimeSimVCSOptionprimesimol edprintboundarynodeUncheckLoca lized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimoledremovepurenodecap	string	saTestbench	0	PrimeSimVCS option primesim_oled_remove_purenode_cap:
saPrimeSimVCSOptionprimesimoledremovepurenodecapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoledscansignal	string	saTestbench		PrimeSimVCS option primesim_oled_scan_signal:
saPrimeSimVCSOptionprimesimoledscansignalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoledshowreduction	string	saTestbench	0	PrimeSimVCS option primesim_oled_show_reduction:
saPrimeSimVCSOptionprimesimoledshowreductionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoledsolver	string	saTestbench	0	PrimeSimVCS option primesim_oled_solver:
saPrimeSimVCSOptionprimesimoledsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoledspiceopt	string	saTestbench	1	PrimeSimVCS option primesim_oled_spice_opt:
saPrimeSimVCSOptionprimesimoledspiceoptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimopparasiticcapacitance	string	custom		PrimeSimVCS option primesim_op_parasitic_capacitance: Specifies whether to output parasitic passive capacitors into the OP result file.
saPrimeSimVCSOptionprimesimopparasiticcapacitanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimopregiondisplay	string	custom		PrimeSimVCS option primesim_op_region_display: Specifies which values to use for different regions of MOS operation when using waveform display tools such as PrimeWave Design Environment WaveView.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimopregiondisplayUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoptimizeflat	string	saTestbench		PrimeSimVCS option primesim_optimize_flat:
saPrimeSimVCSOptionprimesimoptimizeflatmaxmosfet	string	saTestbench		PrimeSimVCS option primesim_optimize_flat_max_mosfet:
saPrimeSimVCSOptionprimesimoptimizeflatmaxmosfetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimoptimizeflatmaxmosfet is loaded.
saPrimeSimVCSOptionprimesimoptimizeflatmininstforflat	string	saTestbench		PrimeSimVCS option primesim_optimize_flat_min_inst_for_flat:
saPrimeSimVCSOptionprimesimoptimizeflatmininstforflatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoptimizeflatminsizeforflat	string	saTestbench		PrimeSimVCS option primesim_optimize_flat_min_size_for_flat:
saPrimeSimVCSOptionprimesimoptimizeflatminsizeforflatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoptimizeflatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoptimizeflatupckt	string	saTestbench		PrimeSimVCS option primesim_optimize_flat_upckt:
saPrimeSimVCSOptionprimesimoptimizeflatupcktUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoptimizeignore	string	saTestbench		PrimeSimVCS option primesim_optimize_ignore:
saPrimeSimVCSOptionprimesimoptimizeignoreUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoptimizehash	string	saTestbench	0	PrimeSimVCS option primesim_optimize_mhash:
saPrimeSimVCSOptionprimesimoptimizehashUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimoptimizepartition	string	saTestbench		PrimeSimVCS option primesim_optimize_partition:
saPrimeSimVCSOptionprimesimoptimizepartitionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoptimizepat	string	saTestbench	0	PrimeSimVCS option primesim_optimize_pat:
saPrimeSimVCSOptionprimesimoptimizepatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoptimizepdn	string	saTestbench	1	PrimeSimVCS option primesim_optimize_pdn:
saPrimeSimVCSOptionprimesimoptimizepdnnonportmerginglimit	string	saTestbench	10	PrimeSimVCS option primesim_optimize_pdn_nonport_merging_limit:
saPrimeSimVCSOptionprimesimoptimizepdnnonportmerginglimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoptimizepdnportmerginglimit	string	saTestbench	30	PrimeSimVCS option primesim_optimize_pdn_port_merging_limit:
saPrimeSimVCSOptionprimesimoptimizepdnportmerginglimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoptimizepdnportmergingmethod	string	saTestbench	0	PrimeSimVCS option primesim_optimize_pdn_port_merging_method:
saPrimeSimVCSOptionprimesimoptimizepdnportmergingmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoptimizepdnsmallrth	string	saTestbench		PrimeSimVCS option primesim_optimize_pdn_smallrth:
saPrimeSimVCSOptionprimesimoptimizepdnsmallrthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoptimizepdnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimou tput	string	custom		PrimeSimVCS option primesim_output: Sets the output file format for saving transient analysis results.
saPrimeSimVCSOptionprimesimou tputfname_type	string	custom	1	PrimeSimVCS option primesim_output_fname_type: Defines the naming convention for output files with the netlist has an .alter and/or .temp sweep parameter.
saPrimeSimVCSOptionprimesimou tputfname_typeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimou tputgzip	string	custom		PrimeSimVCS option primesim_output_gzip: Enables gzip file compression of the output files.
saPrimeSimVCSOptionprimesimou tputgzipUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimou tputoptimize	string	saTestbe nch		PrimeSimVCS option primesim_output_optimize:
saPrimeSimVCSOptionprimesimou tputoptimizeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimou tputrange	string	custom		PrimeSimVCS option primesim_output_range: Limits output of transient results of waveforms to the waveform file.
saPrimeSimVCSOptionprimesimou tputrangeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimou tputUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpa ramduprule	string	saTestbe nch	0	PrimeSimVCS option primesim_param_dup_rule:
saPrimeSimVCSOptionprimesimpa ramdupruleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpa rhiermode	string	custom		PrimeSimVCS option primesim_pariahier_mode: Specifies how the SPICE-compatible option parhier functions when set to LOCAL.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimpartitionmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpartition	string	custom		PrimeSimVCS option primesim_partition: Specifies how partitioning is done.
saPrimeSimVCSOptionprimesimpartitionfixgroundediode	string	saTestbench		PrimeSimVCS option primesim_partition_fix_grounded_diode:
saPrimeSimVCSOptionprimesimpartitionfixgroundediodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpartitionfixvcvs	string	saTestbench	0	PrimeSimVCS option primesim_partition_fix_vcvs:
saPrimeSimVCSOptionprimesimpartitionfixvcvsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpartitionmode	string	saTestbench	1	PrimeSimVCS option primesim_partition_mode:
saPrimeSimVCSOptionprimesimpartitionmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpartitiontune	string	saTestbench	3	PrimeSimVCS option primesim_partition_tune:
saPrimeSimVCSOptionprimesimpartitiontuneUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpartitionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesim_pdn	string	saTestbench		PrimeSimVCS option primesim_pdn:
saPrimeSimVCSOptionprimesim_pdn_eventgrid	string	saTestbench	0	PrimeSimVCS option primesim_pdn_event_grid:
saPrimeSimVCSOptionprimesim_pdn_eventgridmode	string	saTestbench	0	PrimeSimVCS option primesim_pdn_event_grid_mode:
saPrimeSimVCSOptionprimesim_pdn_eventgridmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimpd neventgridrcnum	string	saTestbench	0	PrimeSimVCS option primesim_pdn_event_grid_rcnum:
saPrimeSimVCSOptionprimesimpd neventgridrcnumUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpd neventgridUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpd nnet	string	saTestbench	1	PrimeSimVCS option primesim_pdn_net:
saPrimeSimVCSOptionprimesimpd nnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpd nopt	string	saTestbench		PrimeSimVCS option primesim_pdn_opt:
saPrimeSimVCSOptionprimesimpd noptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimpdnopt is loaded.
saPrimeSimVCSOptionprimesimpd nUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimph asenoiselorentz	string	saTestbench		PrimeSimVCS option primesim_phasenoise_lorentz:
saPrimeSimVCSOptionprimesimph asenoiselorentzUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimphasenoise_lorentz is loaded.
saPrimeSimVCSOptionprimesimph asenoiseminharmfreqoffset	string	saTestbench		PrimeSimVCS option primesim_phasenoise_min_harmfreq_offset:
saPrimeSimVCSOptionprimesimph asenoiseminharmfreqoffsetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpi nstinp	string	custom		PrimeSimVCS option primesim_pinst_in_p: Specifies how the p() power reporting function works when Probing and Measuring.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesiminstinpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmsminsize	string	saTestbench	200.0	PrimeSimVCS option primesim_pms_minsize:
saPrimeSimVCSOptionprimesimmsminsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmspartitionctrl	string	saTestbench	0	PrimeSimVCS option primesim_pms_partition_ctrl:
saPrimeSimVCSOptionprimesimmspartitionctrlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimmsplus	string	saTestbench		PrimeSimVCS option primesim_pms_plus:
saPrimeSimVCSOptionprimesimmsplusUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpostl	string	custom	0	PrimeSimVCS option primesim_postl: Sets the level of acceleration to use when performing post-layout analog simulation on RC-extracted circuits.
saPrimeSimVCSOptionprimesimpostlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpostlevellast	string	saTestbench	4	PrimeSimVCS option primesim_pout_level_last:
saPrimeSimVCSOptionprimesimpostlevellastUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprbexprvar	string	custom	1	PrimeSimVCS option primesim_prbexprvar: Determines whether to make any signals in the expression of .probe out.
saPrimeSimVCSOptionprimesimprbexprvarUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprbport	string	custom	1	PrimeSimVCS option primesim_prbport: Determines whether port voltages will be probed, depending on tolerance.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimprbportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprbtmin	string	custom		PrimeSimVCS option primesim_prb_tmin: Specifies that the waveform file records data points only after the minimum transient time set by this option has passed.
saPrimeSimVCSOptionprimesimprbtminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprecision	string	saTestbench	0	PrimeSimVCS option primesim_precision: Serves as the reference with the highest precision.
saPrimeSimVCSOptionprimesimprecisionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprelayoutmodels	string	custom	0	PrimeSimVCS option primesim_prelayout_models: Sets which model PrimeSim should use.
saPrimeSimVCSOptionprimesimprelayoutmodelsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprintglobalparam	string	custom		PrimeSimVCS option primesim_print_global_param: Prints global parameter names and resolved values.
saPrimeSimVCSOptionprimesimprintglobalparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprintmaxconnode	string	custom	20	PrimeSimVCS option primesim_print_max_con_node: Identifies nodes with greatest number of connections for connectivity report.
saPrimeSimVCSOptionprimesimprintmaxconnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprintperiod	string	custom		PrimeSimVCS option primesim_print_period: Defines the fixed interval at which the .print command will print to the output file.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimprntperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprnttoprobe	string	custom	0	PrimeSimVCS option primesim_print_to_probe: Converts all .print statements to .probe statements.
saPrimeSimVCSOptionprimesimprnttoprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprllopt	string	custom		PrimeSimVCS option primesim_prll_opt: Controls how the -np X command line option functions (see Command Line Options for Running Multi-CPU Simulations).
saPrimeSimVCSOptionprimesimprlloptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprllobeallnode	string	saTestbench	0	PrimeSimVCS option primesim_probe_all_node:
saPrimeSimVCSOptionprimesimprllobeallnodefilter	string	saTestbench		PrimeSimVCS option primesim_probe_all_node_filter:
saPrimeSimVCSOptionprimesimprllobeallnodefilterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprllobeallnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprllobematchfullname	string	saTestbench	0	PrimeSimVCS option primesim_probe_match_fullname:
saPrimeSimVCSOptionprimesimprllobematchfullnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprllobepassivedevice	string	custom	0	PrimeSimVCS option primesim_probe_passive_device: Probes passive devices like R/C..
saPrimeSimVCSOptionprimesimprllobepassivedeviceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprllobeprotected	string	saTestbench		PrimeSimVCS option primesim_probe_protected:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimprobeprotectedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprodcalg	string	custom		PrimeSimVCS option primesim_pro_dcalg: Sets the approach for DC convergence (Pro mode only).
saPrimeSimVCSOptionprimesimprodcalgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprofile	string	custom	1	PrimeSimVCS option primesim_profile: Generates profile data in a file after transient analysis..
saPrimeSimVCSOptionprimesimprofileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimprogressprintmemusage	string	saTestbench		PrimeSimVCS option primesim_progress_print_memusage:
saPrimeSimVCSOptionprimesimprogressprintmemusageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimprogressprintmemusage is loaded.
saPrimeSimVCSOptionprimesimpronqs	string	saTestbench	0	PrimeSimVCS option primesim_pronqs:
saPrimeSimVCSOptionprimesimpronqsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimproshe	string	saTestbench	0	PrimeSimVCS option primesim_proshe:
saPrimeSimVCSOptionprimesimprosheUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpseudotrandbg	string	custom		PrimeSimVCS option primesim_pseudotrandbg: Controls whether an FSDB file is generated from pseudo-transient analysis.
saPrimeSimVCSOptionprimesimpseudotrandbgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimpt0format	string	custom		PrimeSimVCS option primesim_pt0_format: Changes the .print output default format into a list format.
saPrimeSimVCSOptionprimesimpt0formatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpvacrossttol	string	custom		PrimeSimVCS option primesim_pva_cross_ttol: Specifies the PrimeSim / Portable Verilog-A Engine timing accuracy for the CROSS and ABOVE functions.
saPrimeSimVCSOptionprimesimpvacrossttolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpvaflow	string	custom		PrimeSimVCS option primesim_pva_flow: Simulates Verilog-A Elements using the Portable Verilog-A Engine compatible with PrimeSim HSPICE.
saPrimeSimVCSOptionprimesimpvaflowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpvamintranstime	string	saTestbench		PrimeSimVCS option primesim_pva_min_trans_time:
saPrimeSimVCSOptionprimesimpvamintranstimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpvamintranstunits	string	saTestbench	0	PrimeSimVCS option primesim_pva_min_trans_tunits:
saPrimeSimVCSOptionprimesimpvamintranstunitsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpvaoptport	string	saTestbench		PrimeSimVCS option primesim_pva_opt_port: Specifies whether to treat the Verilog-A port as non-voltage
saPrimeSimVCSOptionprimesimpvaoptportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpwlacc	string	saTestbench	0	PrimeSimVCS option primesim_pwl_acc:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimp wlaccUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimp wlreltol	string	saTestbench	1.e-4	PrimeSimVCS option primesim_pwlreltol:
saPrimeSimVCSOptionprimesimp wlreltolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimp wlrend	string	custom		PrimeSimVCS option primesim_pwl_r_end: Changes the meaning of parameter R for PWL source.
saPrimeSimVCSOptionprimesimp wlrendUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimp wrblock	string	custom	1	PrimeSimVCS option primesim_pwrblock: Detects the parasitics in the power network.
saPrimeSimVCSOptionprimesimp wrblockexcludenode	string	saTestbench		PrimeSimVCS option primesim_pwrblock_exclude_node:
saPrimeSimVCSOptionprimesimp wrblockexcludenodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimpwrblockexcludenode is loaded.
saPrimeSimVCSOptionprimesimp wrblockexcludesubckt	string	saTestbench		PrimeSimVCS option primesim_pwrblock_exclude_subckt:
saPrimeSimVCSOptionprimesimp wrblockexcludesubcktUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimp wrblockincludemoscap	string	saTestbench		PrimeSimVCS option primesim_pwrblock_include_moscap:
saPrimeSimVCSOptionprimesimp wrblockincludemoscapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimp wrblockplus	string	saTestbench	0	PrimeSimVCS option primesim_pwrblock_plus:
saPrimeSimVCSOptionprimesimp wrblockplusnumarrayinst	string	saTestbench	128	PrimeSimVCS option primesim_pwrblock_plus_num_array_inst:
saPrimeSimVCSOptionprimesimp wrblockplusnumarrayinstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimpwrblockplusnumtotalmos	string	saTestbench	256	PrimeSimVCS option primesim_pwrblock_plus_num_total_mos:
saPrimeSimVCSOptionprimesimpwrblockplusnumtotalmosUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpwrblockplusUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpwrblockterminalprefix	string	saTestbench		PrimeSimVCS option primesim_pwrblock_terminal_prefix:
saPrimeSimVCSOptionprimesimpwrblockterminalprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpwrblockUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpwrblockusergivencandonly	string	saTestbench		PrimeSimVCS option primesim_pwrblock_user_given_cand_only:
saPrimeSimVCSOptionprimesimpwrblockusergivencandonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpwrloadmodel	string	custom		PrimeSimVCS option primesim_pwrloadmodel: Enables a power load model especially well-suited for power supply networks.
saPrimeSimVCSOptionprimesimpwrloadmodelenhanced	string	saTestbench	1	PrimeSimVCS option primesim_pwrloadmodel_enhanced:
saPrimeSimVCSOptionprimesimpwrloadmodelenhancedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpwrloadmodelrlcd	string	saTestbench	2	PrimeSimVCS option primesim_pwrloadmodel_rlcd:
saPrimeSimVCSOptionprimesimpwrloadmodelrlcdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimpwrloadmodelsfc	string	saTestbench	1	PrimeSimVCS option primesim_pwrloadmodel_sfc:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimp wrlloadmodelsfcUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimp wrlloadmodelUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimp wrtol	string	custom	3mV	PrimeSimVCS option primesim_pwrtol: Specifies the voltage tolerance to control an event between a power block partition and the other partitions.
saPrimeSimVCSOptionprimesimp wrtolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimql evel	string	custom	1	PrimeSimVCS option primesim_qllevel: Controls the tolerance of the signal level accuracy.
saPrimeSimVCSOptionprimesimql evelUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimra	string	saTestbe nch	0	PrimeSimVCS option primesim_ra:
saPrimeSimVCSOptionprimesimra cmd	string	custom		PrimeSimVCS option primesim_ra_cmd: Specifies the output formats to be reported and provides backward compatibility to read the command format supported by Titan/fscript.
saPrimeSimVCSOptionprimesimra cmdUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimra dcmmap	string	saTestbe nch		PrimeSimVCS option primesim_ra_dcmmap:
saPrimeSimVCSOptionprimesimra dcmmapUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimra net	string	custom		PrimeSimVCS option primesim_ra_net: Specifies the nets to report for IR Drop output.
saPrimeSimVCSOptionprimesimra netUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimra presimtime	string	saTestbe nch		PrimeSimVCS option primesim_ra_presimtime:
saPrimeSimVCSOptionprimesimra presimtimeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimra samplmethod	string	saTestbe nch		PrimeSimVCS option primesim_ra_sample_method:
saPrimeSimVCSOptionprimesimra samplmethodUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimra samplrate	string	saTestbe nch		PrimeSimVCS option primesim_ra_sample_rate:
saPrimeSimVCSOptionprimesimra samplrateUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimra tcl	string	custom		PrimeSimVCS option primesim_ra_tcl: Reads a PrimeSim XA RA Tcl file.
saPrimeSimVCSOptionprimesimra tclUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimra twindow	string	saTestbe nch		PrimeSimVCS option primesim_ra_twindow:
saPrimeSimVCSOptionprimesimra twindowUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimra UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimra waveformsplit	string	saTestbe nch		PrimeSimVCS option primesim_ra_waveform_split:
saPrimeSimVCSOptionprimesimra waveformsplitUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimrcl amp	string	saTestbe nch		PrimeSimVCS option primesim_rclamp:
saPrimeSimVCSOptionprimesimrcl ampUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimrc red	string	custom	Default	PrimeSimVCS option primesim_rcred: Sets the level of acceleration to use when performing post-layout analog simulation with RC reduction.
saPrimeSimVCSOptionprimesimrc redscale	string	saTestbe nch		PrimeSimVCS option primesim_rcredscale: Sets a scaling factor applied for RC reduction performed using the primesim_rcred command.
saPrimeSimVCSOptionprimesimrc redscaleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimrcscale is loaded.
saPrimeSimVCSOptionprimesimrc redUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimre dminc	string	saTestbe nch		PrimeSimVCS option primesim_redminc:
saPrimeSimVCSOptionprimesimre dmincUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimre duceddcinitdesignedgshort	string	saTestbe nch	1e9	PrimeSimVCS option primesim_reduced_dcinit_designed_gshort:
saPrimeSimVCSOptionprimesimre duceddcinitdesignedgshortratio	string	saTestbe nch	0.85	PrimeSimVCS option primesim_reduced_dcinit_designed_gshort _ratio:
saPrimeSimVCSOptionprimesimrel tolscale	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimTRANOptiontrtol is loaded.
saPrimeSimVCSEnvOptsUseCach eDirInCommandLine	bool	user	false	Add pva_output_dir and s_elem_cache_dir in command line option.
saPrimeSimVCSOptionprimesimre duceddcinitdesignedgshortratioUn checkLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimre duceddcinitdesignedgshortUnchec kLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimre duceddcinitfinalize	string	saTestbe nch	0	PrimeSimVCS option primesim_reduced_dc_init_finalize:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimreduceddcinitfinalizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreduceddcinitgshort	string	saTestbench	1e9	PrimeSimVCS option primesim_reduced_dcinit_gshort:
saPrimeSimVCSOptionprimesimreduceddcinitgshortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreduceddcinitmos	string	saTestbench		PrimeSimVCS option primesim_reduced_dc_init_mos:
saPrimeSimVCSOptionprimesimreduceddcinitmosUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimreduceddcinitmos is loaded.
saPrimeSimVCSOptionprimesimreduceddcinitshortnegres	string	saTestbench	1	PrimeSimVCS option primesim_reduced_dcinit_short_negres:
saPrimeSimVCSOptionprimesimreduceddcinitshortnegresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreducedmatrixpdnnet	string	saTestbench	0	PrimeSimVCS option primesim_reduced_matrix_pdn_net:
saPrimeSimVCSOptionprimesimreducedmatrixpdnnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreducedmatrixtime	string	saTestbench		PrimeSimVCS option primesim_reduced_matrix_time:
saPrimeSimVCSOptionprimesimreducedmatrixtimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreducedminpartsize	string	saTestbench	1000	PrimeSimVCS option primesim_reduced_min_part_size:
saPrimeSimVCSOptionprimesimreducedminpartsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreducedratio	string	saTestbench	2.0	PrimeSimVCS option primesim_reduced_ratio:
saPrimeSimVCSOptionprimesimreducedratio2	string	saTestbench	0.0	PrimeSimVCS option primesim_reduced_ratio2:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimreducedratio2UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreducedratioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreffnet	string	saTestbench		PrimeSimVCS option primesim_reff_net:
saPrimeSimVCSOptionprimesimreffnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimrefinemc0name	string	saTestbench	0	PrimeSimVCS option primesim_refine_mc0_name:
saPrimeSimVCSOptionprimesimrefinemc0nameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimremovedcportcap	string	saTestbench	0	PrimeSimVCS option primesim_remove_dcport_cap:
saPrimeSimVCSOptionprimesimremovedcportcapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimremovefloatingvsrcc	string	custom		PrimeSimVCS option primesim_remove_floating_vsrc: Removes any floating voltage sources and issues a warning message.
saPrimeSimVCSOptionprimesimremovefloatingvsrccUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimremoveonphysicalspres	string	saTestbench		PrimeSimVCS option primesim_remove_non_physical_spf_res:
saPrimeSimVCSOptionprimesimremoveonphysicalspresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimremoveonphysicalspres is loaded.
saPrimeSimVCSOptionprimesimremoveprobeprefix	string	custom	0	PrimeSimVCS option primesim_remove_probe_prefix: Removes prefix from output signal.
saPrimeSimVCSOptionprimesimremoveprobeprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimremovezeroisrc	string	saTestbench		PrimeSimVCS option primesim_remove_zero_isrc:
saPrimeSimVCSOptionprimesimremovezeroisrcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimremovezeroresistance	string	saTestbench	1	PrimeSimVCS option primesim_remove_zero_resistance:
saPrimeSimVCSOptionprimesimremovezeroresistanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreorderglobalmparam	string	saTestbench	0	PrimeSimVCS option primesim_reorder_global_mparam:
saPrimeSimVCSOptionprimesimreorderglobalmparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimrepdot	string	saTestbench		PrimeSimVCS option primesim_repdot: Replaces ""."" with another character.
saPrimeSimVCSOptionprimesimrepdotUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreplacepfingerchars	string	saTestbench		PrimeSimVCS option primesim_replace_spf_fingerchars:
saPrimeSimVCSOptionprimesimreplacepfingercharsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimrepnode	string	saTestbench	0	PrimeSimVCS option primesim_repnode:
saPrimeSimVCSOptionprimesimrepnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreportlargenoinstances	string	custom		PrimeSimVCS option primesim_report_large_no_instances: Reports subckt instances that contain a large number of devices.
saPrimeSimVCSOptionprimesimreportlargenoinstancesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreskeep	string	saTestbench		PrimeSimVCS option primesim_reskeep:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimreskeepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimresmax	string	custom	1T	PrimeSimVCS option primesim_resmax: Sets maximum value for a resistor to be considered in simulation.
saPrimeSimVCSOptionprimesimresmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimresmin	string	custom	0.001	PrimeSimVCS option primesim_resmin: Sets minimum value for a resistor to be considered in simulation. The default value is dependent on primesim_mode.
saPrimeSimVCSOptionprimesimresminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimrestoreSNAPSHOT	string	custom		PrimeSimVCS option primesim_restore (.SNAPSHOT): The .snapshot option captures a snapshot of the dynamic state of the circuit in motion which can be restored later with the primesim_restore option.
saPrimeSimVCSOptionprimesimrestoreSNAPSHOTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreusmosmodel	string	custom	1	PrimeSimVCS option primesim_reuse_mos_model: Reuses MOSFET models built in the previous iteration.
saPrimeSimVCSOptionprimesimreusmosmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimreuseop	string	saTestbench		PrimeSimVCS option primesim_reuse_op: Enables the PrimeSim SPICE tool to reuse the operating point solution from a previous analysis as the initial guess for subsequent analyses
saPrimeSimVCSOptionprimesimreuseopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimrfactor	string	saTestbench		PrimeSimVCS option primesim_rfactor:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimrfactorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimrflickernoisefmax	string	saTestbench		PrimeSimVCS option primesim_rf_flicker_noise_fmax:
saPrimeSimVCSOptionprimesimrflickernoisefmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimrng	string	custom		PrimeSimVCS option primesim_rng: Specifies the random number generator (RNG) used by the simulator.
saPrimeSimVCSOptionprimesimrngUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimrom	string	saTestbench		PrimeSimVCS option primesim_rom:
saPrimeSimVCSOptionprimesimromUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimrosync	string	saTestbench	1	PrimeSimVCS option primesim_rosync:
saPrimeSimVCSOptionprimesimrosyncUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimrpitftmode	string	custom	0	PrimeSimVCS option primesim_rpitft_mode: Enables PrimeSim support for SmartSpice TFT Model correlation.
saPrimeSimVCSOptionprimesimrpitftmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimrunlvlmode	string	saTestbench	0	PrimeSimVCS option primesim_runlvl_mode: Enable runlvl setting with more aggressive RC reduction and tighter engine accuracy control.
saPrimeSimVCSOptionprimesimrunlvlmodeUncheckLocalized	bool	saTestbench	false	
saPrimeSimVCSOptionprimesimrunspred	string	saTestbench	0	PrimeSimVCS option primesim_run_spred:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimrunspredUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimruntime meas	string	custom		PrimeSimVCS option primesim_runtime_meas: Uses runtime measurement instead of post measurement.
saPrimeSimVCSOptionprimesimruntime measUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsavepsfbackslash	string	saTestbench	0	PrimeSimVCS option primesim_save_psf_backslash:
saPrimeSimVCSOptionprimesimsavepsfbackslashUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimscale	string	custom		PrimeSimVCS option primesim_scale: Applies the scale factor for subcircuits.
saPrimeSimVCSOptionprimesimscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsetautovscope	string	saTestbench		PrimeSimVCS option primesim_set_auto_va_scope:
saPrimeSimVCSOptionprimesimsetautovscopeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsetcpu time	string	custom		PrimeSimVCS option primesim_set_cpu_time: Needs Description.
saPrimeSimVCSOptionprimesimsetcpu timeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsetenv	string	custom		PrimeSimVCS option primesim_setenv: Specifies an environment variable name and sets it to value.
saPrimeSimVCSOptionprimesimsetenvUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimsetfloatingnode	string	custom		PrimeSimVCS option primesim_set_floating_node: Sets a user-specified voltage value for either all floating nodes or floating gate nodes only (see primesim_set_floating_node_type) at either the DC operating point only or also throughout the transient simulation (see primesim_set_floating_node_format).
saPrimeSimVCSOptionprimesimsetfloatingnodeformat	string	custom		PrimeSimVCS option primesim_set_floating_node_format: Determines whether the floating node value specified by primesim_set_floating_node is applied in DC initialization only or also throughout the transient simulation.
saPrimeSimVCSOptionprimesimsetfloatingnodeformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsetfloatingnodetype	string	custom		PrimeSimVCS option primesim_set_floating_node_type: Determines whether the floating node value specified by primesim_set_floating_node is applied to all floating nodes or to floating gate nodes only.
saPrimeSimVCSOptionprimesimsetfloatingnodetypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsetfloatingnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsetspecialchar	string	custom		PrimeSimVCS option primesim_set_special_char: Appends a "\" before special characters during PSF output.
saPrimeSimVCSOptionprimesimsetspecialcharUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsfcreport	string	saTestbench	1e-15	PrimeSimVCS option primesim_sfc_report:
saPrimeSimVCSOptionprimesimsfcreportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsflash	string	saTestbench		PrimeSimVCS option primesim_sflash:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimshUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsh	string	saTestbench	-1.0e+20	PrimeSimVCS option primesim_sh:
saPrimeSimVCSOptionprimesimshUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimshxmlwindow	string	saTestbench		PrimeSimVCS option primesim_sh_xml_window:
saPrimeSimVCSOptionprimesimshxmlwindowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimshortnet	string	custom		PrimeSimVCS option primesim_short_net: Shorts the resistors in an RC network that includes the specified node name.
saPrimeSimVCSOptionprimesimshortnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimshowdatavalues	string	saTestbench		PrimeSimVCS option primesim_show_data_values:
saPrimeSimVCSOptionprimesimshowdatavaluesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimshowlog	string	saTestbench	1	PrimeSimVCS option primesim_show_log:
saPrimeSimVCSOptionprimesimshowlogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsigloadmodel	string	saTestbench	0	PrimeSimVCS option primesim_sigloadmodel:
saPrimeSimVCSOptionprimesimsigloadmodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsimpleemnaming	string	saTestbench		PrimeSimVCS option primesim_simple_em_naming: Uses the "" as single hierarchical delimiter when "" and ""/"" are mixed in signal names. This is used in EM analysis.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimsinglebinmodelcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsinglebinmodelcheck	string	custom	0	PrimeSimVCS option primesim_single_bin_model_check: Apply a similar model binning check for non-binning models.
saPrimeSimVCSOptionprimesimsinglebinmodelcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoevtolscale	string	saTestbench	0.0	PrimeSimVCS option primesim_sio_evtolscale:
saPrimeSimVCSOptionprimesimoevtolscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimoevtolscale	string	saTestbench	0.0	PrimeSimVCS option primesim_sio_ievtolscale:
saPrimeSimVCSOptionprimesimoevtolscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsistepsize	string	saTestbench		PrimeSimVCS option primesim_sis_step_size:
saPrimeSimVCSOptionprimesimsistepsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimskipblock	string	saTestbench		PrimeSimVCS option primesim_skip_block:
saPrimeSimVCSOptionprimesimskipblockUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimskipflatplnode	string	custom		PrimeSimVCS option primesim_skip_flat_pl_node: Reduces FSDB file size by reducing the number of nodes probed.
saPrimeSimVCSOptionprimesimskipflatplnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimskipinfo	string	saTestbench		PrimeSimVCS option primesim_skip_info:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimskipinfoUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimskipmeaserror	string	custom		PrimeSimVCS option primesim_skip_meas_error: Specifies whether simulation should error out or continue with a warning if a .MEAS statement is missing a parameter.
saPrimeSimVCSOptionprimesimskipmeaserrorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimskipunusedparam	string	custom	0	PrimeSimVCS option primesim_skip_unused_param: Ignores HSI-specific parameters to avoid ineffective warning messages.
saPrimeSimVCSOptionprimesimskipunusedparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimskipwarn	string	custom		PrimeSimVCS option primesim_skipwarn: Determines amount and type of information output to the log file.
saPrimeSimVCSOptionprimesimskipwarnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsmoothbehdev	string	saTestbench	0	PrimeSimVCS option primesim_smooth_behdev:
saPrimeSimVCSOptionprimesimsmoothbehdevabs	string	saTestbench	0.0	PrimeSimVCS option primesim_smooth_behdev_abs:
saPrimeSimVCSOptionprimesimsmoothbehdevabsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsmoothbehdevfctr	string	saTestbench	1.0	PrimeSimVCS option primesim_smooth_behdev_fctr:
saPrimeSimVCSOptionprimesimsmoothbehdevfctrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsmoothbehdevUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimso acheckondcinit	string	custom		PrimeSimVCS option primesim_soa_check_on_dc_init: Runs SOA checks on the first two time steps in Transient Analysis and then exits the simulation.
saPrimeSimVCSOptionprimesimso acheckondcinitUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimso amaxwarns	string	custom	5	PrimeSimVCS option primesim_soa_maxwarns: Specifies maximum number of SOA warning messages.
saPrimeSimVCSOptionprimesimso amaxwarnsUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimso awarn	string	custom	0	PrimeSimVCS option primesim_soa_warn: Enables or turns off safe operating area (SOA) voltage warning message.
saPrimeSimVCSOptionprimesimso awarnformat	string	custom	0	PrimeSimVCS option primesim_soa_warn_format: Format of SOA check output.
saPrimeSimVCSOptionprimesimso awarnformatUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimso awarntofile	string	custom	0	PrimeSimVCS option primesim_soa_warn_to_file: Print result of SOA checks to separate file (.tsoa).
saPrimeSimVCSOptionprimesimso awarntofileUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimso awarnUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesims otp	string	saTestbe nch	0	PrimeSimVCS option primesim_sotp:
saPrimeSimVCSOptionprimesimso tpUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimsparsefcap	string	custom		PrimeSimVCS option primesim_sparse_fcaps: Sets the absolute threshold for marking sparse floating capacitors.
saPrimeSimVCSOptionprimesimsparsefcapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspeed	string	custom	1	PrimeSimVCS option primesim_speed: Sets the speed level of the simulation.
saPrimeSimVCSOptionprimesimspeedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspf	string	custom		PrimeSimVCS option primesim_spf: Specifies the DSPF file that contains SPF data extracted from the layout interconnects.
saPrimeSimVCSOptionprimesimspf2eqr	string	custom		PrimeSimVCS option primesim_spf2eqr: Extract equivalent resistors from port-to-port in addition to port-to-pin
saPrimeSimVCSOptionprimesimspf2eqrselect	string	saTestbench		PrimeSimVCS option primesim_spf2eqr_select:
saPrimeSimVCSOptionprimesimspf2eqrselectUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspf2eqrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfaccirem	string	custom		PrimeSimVCS option primesim_spf_acc_irem: Performs dynamic EM simulation of a huge back-annotated circuit with better performance than standalone IR/EM.
saPrimeSimVCSOptionprimesimspfacciremUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfaddiremwindow	string	custom		PrimeSimVCS option primesim_spf_add_irem_window: Specifies analysis time range for the IR/EM .em file.
saPrimeSimVCSOptionprimesimspfaddiremwindowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimsp fallowerror	string	custom	0	PrimeSimVCS option primesim_spfallowerror: Continue simulation on SPF parser error.
saPrimeSimVCSOptionprimesimsp fallowerrorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fallowmissinginstance	string	custom	1	PrimeSimVCS option primesim_spfallowmissinginstance: Annotates the net to which the missing device was attached as an RC net.
saPrimeSimVCSOptionprimesimsp fallowmissinginstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fallowrcparasiticinstance	string	custom		PrimeSimVCS option primesim_spf_allow_rc_parasitic_instance: Allows you to program the RC net of a Standard Parasitic Format (SPF) file with a custom subckt module in order to estimate the RC effect of that SPF NET.
saPrimeSimVCSOptionprimesimsp fallowrcparasiticinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fbuschar	string	custom		PrimeSimVCS option primesim_spf_bus_char: Used when extracted SPEF file bus notation is different from schematic netlist bus notation.
saPrimeSimVCSOptionprimesimsp fbuscharUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fccparse	string	custom		PrimeSimVCS option primesim_spf_cc_parse: Specifies whether to parse all coupling capacitor NETs even if one of the NETs is not found in the schematic netlist.
saPrimeSimVCSOptionprimesimsp fccparseUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fcnet	string	custom		PrimeSimVCS option primesim_spfcnet: Specifies the net names to be annotated with lumped capacitance only.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimsp fnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fdbversion	string	custom		PrimeSimVCS option primesim_spfdb_version: Sets the IR drop database version.
saPrimeSimVCSOptionprimesimsp fdbversionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fdpfreset	string	saTestbench		PrimeSimVCS option primesim_spdpf_reset:
saPrimeSimVCSOptionprimesimsp fdpfresetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fecoinstance	string	saTestbench		PrimeSimVCS option primesim_spf_eco_instance:
saPrimeSimVCSOptionprimesimsp fecoinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimspfecoinstance is loaded.
saPrimeSimVCSOptionprimesimsp fecoconnect	string	saTestbench	false	PrimeSimVCS option primesim_spf_eco_connect
saPrimeSimVCSOptionprimesimsp fecoconnectUncheckLocalized	bool	saTestbench		Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimspfecoconnect is loaded.
saPrimeSimVCSOptionprimesimsp femversion	string	custom		PrimeSimVCS option primesim_spf_em_version: Sets the EM database version.
saPrimeSimVCSOptionprimesimsp femversionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp feqr	string	custom		PrimeSimVCS option primesim_spfeqr: Extract equivalent resistors from port-to-pin
saPrimeSimVCSOptionprimesimsp feqrfile	string	custom		PrimeSimVCS option primesim_spfeqrfile: Output file name for the equivalent resistor analysis
saPrimeSimVCSOptionprimesimsp feqrfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimspfonly	string	custom	0	PrimeSimVCS option primesim_spfonly: Run the equivalent resistor analysis
saPrimeSimVCSOptionprimesimspfonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfqrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfexclude	string	custom		PrimeSimVCS option primesim_spf_exclude: Excludes the specified instances from SPF back-annotation.
saPrimeSimVCSOptionprimesimspfexcludeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfmin	string	custom	0	PrimeSimVCS option primesim_spfmin: Sets minimum floating capacitor value allowed for back-annotation.
saPrimeSimVCSOptionprimesimspfminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfnet	string	custom		PrimeSimVCS option primesim_spfnet: Keeps the floating capacitance for C-only back-annotation.
saPrimeSimVCSOptionprimesimspfnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspf_fingerchars	string	saTestbench		PrimeSimVCS option primesim_spf_fingerchars: Translates the special SPF finger delimiter from the specified string to ""@"".
saPrimeSimVCSOptionprimesimspf_fingercharsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspf_fingerrespolicy	string	custom		PrimeSimVCS option primesim_spf_finger_res_policy: Specifies whether finger resistors must be in parallel to the base resistor or are allowed to be a series or a mix of parallel and sequential order.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimsp ffingerrespolicyUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fhdiv	string	custom		PrimeSimVCS option primesim_spfhdiv: Sets the divider character for hierarchical names in DSPF files.
saPrimeSimVCSOptionprimesimsp fhdivUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fhistogram	string	custom		PrimeSimVCS option primesim_spf_histogram: Specifies whether to print an RC Histogram for each DSPF file during back-annotation.
saPrimeSimVCSOptionprimesimsp fhistogramUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp first	string	custom	0	PrimeSimVCS option primesim_spfirst: Control whether the instance section of the DSPF file is used for annotation.
saPrimeSimVCSOptionprimesimsp firstUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp firemiswr	string	saTestbe nch		PrimeSimVCS option primesim_spf_irem_iswr:
saPrimeSimVCSOptionprimesimsp firemiswrUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fiscdivider	string	saTestbe nch		PrimeSimVCS option primesim_spf_isrc_divider:
saPrimeSimVCSOptionprimesimsp fiscdividerUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimspfiscdivider is loaded.
saPrimeSimVCSOptionprimesimsp fiscprobe	string	saTestbe nch	0	PrimeSimVCS option primesim_spf_isrc_probe:
saPrimeSimVCSOptionprimesimsp fiscprobeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimspfkeephier	string	custom	0	PrimeSimVCS option primesim_spf_keep_hier: Reduce the memory foot print for C annotation.
saPrimeSimVCSOptionprimesimspfkeephierUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfkeepnodecap	string	custom		PrimeSimVCS option primesim_spfkeepnodecap: Controls whether to keep or remove the pre-layout ground capacitance of back-annotated nets.
saPrimeSimVCSOptionprimesimspfkeepnodecapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspflayoutonlydevicemodels	string	custom		PrimeSimVCS option primesim_spf_layout_only_device_models: Specifies the device model names in the DSPF file to be added to the back-annotation simulation.
saPrimeSimVCSOptionprimesimspflayoutonlydevicemodelsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspflayoutonlynet	string	custom		PrimeSimVCS option primesim_spf_layout_only_net: Use this option to specify one or more NETs which exist only in layout so that you can apply RC annotation options to them.
saPrimeSimVCSOptionprimesimspflayoutonlynetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfmapsubcktport	string	custom		PrimeSimVCS option primesim_spf_map_subckt_port: Sets mapping between the port names of the schematic file and the pin names of the back-annotation file.
saPrimeSimVCSOptionprimesimspfmapsubcktportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfmatcheffort	string	custom	0	PrimeSimVCS option primesim_spf_matcheffort: Perform more rigorous naming matching for SPF net and devices.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimsp fmatcheffortUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fmergeport	string	custom	0	PrimeSimVCS option primesim_spfmergeport: Allow ports merge in DSPF net
saPrimeSimVCSOptionprimesimsp fmergeportUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fmodule	string	custom		PrimeSimVCS option primesim_spfmodule: Specifies the module for SPF back-annotation.
saPrimeSimVCSOptionprimesimsp fmoduleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fnonet	string	custom		PrimeSimVCS option primesim_spfnonet: Specifies the nets that are not going to be back-annotated by DSPF data.
saPrimeSimVCSOptionprimesimsp fnonetUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fportnamecheck	string	custom		PrimeSimVCS option primesim_spf_port_name_check: Specifies whether to check for multiple instances of port names connecting to another NET.
saPrimeSimVCSOptionprimesimsp fportnamecheckUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fpost	string	custom		PrimeSimVCS option primesim_spfpost: Sets the node names for post analysis of DSPF back-annotated simulation.
saPrimeSimVCSOptionprimesimsp fpostoutonly	string	custom		PrimeSimVCS option primesim_spfpost_out_only: Use this option to probe the internal nodes of power/ground during EM simulation.
saPrimeSimVCSOptionprimesimsp fpostoutonlyUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fpostUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimspfprb	string	custom	0	PrimeSimVCS option primesim_spfprb: Sets the probe mode for DSPF nodes.
saPrimeSimVCSOptionprimesimspfprbmode	string	custom	0	PrimeSimVCS option primesim_spfprb_mode: Use proper hierarchy for the spf-annotated node name
saPrimeSimVCSOptionprimesimspfprbmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfprbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfprefix	string	custom		PrimeSimVCS option primesim_spfprefix: Lists the prefixes that should be removed from device names.
saPrimeSimVCSOptionprimesimspfprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsprcctype	string	saTestbench		PrimeSimVCS option primesim_sprc_cctype:
saPrimeSimVCSOptionprimesimsprcctypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsprcnet	string	custom		PrimeSimVCS option primesim_sprcnet: Specifies the net names that are annotated with RC trees.
saPrimeSimVCSOptionprimesimsprcnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsprcred	string	saTestbench		PrimeSimVCS option primesim_sprcred:
saPrimeSimVCSOptionprimesimsprcredUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsprfred	string	custom	0	PrimeSimVCS option primesim_sprfred: Sets whether to reduce RC reduction during SPF back-annotation stage.
saPrimeSimVCSOptionprimesimsprfredUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimspfregate	string	saTestbench		PrimeSimVCS option primesim_spfregate: Picks the first GATE pin defined at (* I)/(* NET) from the DSPF file
saPrimeSimVCSOptionprimesimspfregateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfprelast	string	custom	0	PrimeSimVCS option primesim_spfprelast: Controls how the representative node is chosen when annotating DSPF
saPrimeSimVCSOptionprimesimspfprelastUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfresmax	string	saTestbench		PrimeSimVCS option primesim_spf_resmax:
saPrimeSimVCSOptionprimesimspfresmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfrrmax	string	custom	1.0e8	PrimeSimVCS option primesim_spfrrmax: Sets maximum resistor value allowed for back-annotation.
saPrimeSimVCSOptionprimesimspfrrmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfrrmin	string	custom	0.01	PrimeSimVCS option primesim_spfrrmin: Sets minimum resistor value allowed for back-annotation.
saPrimeSimVCSOptionprimesimspfrrmindefaultmatch	string	saTestbench	val	PrimeSimVCS option primesim_spfrrmin_default_match:
saPrimeSimVCSOptionprimesimspfrrmindefaultmatchUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfrrminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfrrptrmax	string	custom	2000	PrimeSimVCS option primesim_spfrrptrmax: Warning threshold number (per net) for SPF resistors
saPrimeSimVCSOptionprimesimspfrrptrmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimsp frtc1	string	custom	0	PrimeSimVCS option primesim_spfrtc1: TC1 parameter for DSPF resistors
saPrimeSimVCSOptionprimesimsp frtc1UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp frtc2	string	custom	0	PrimeSimVCS option primesim_spfrtc2: TC2 parameter for DSPF resistors
saPrimeSimVCSOptionprimesimsp frtc2UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fscale	string	custom	1	PrimeSimVCS option primesim_spfscale: Sets the scale for devices in the DSPF file.
saPrimeSimVCSOptionprimesimsp fscaleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fschcheckmode	string	custom		PrimeSimVCS option primesim_spf_sch_check_mode: Turn this option on in back-annotation simulations when the schematic netlist changes faster than layout and DSPF files can be generated.
saPrimeSimVCSOptionprimesimsp fschcheckmodeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fsdcheck	string	saTestbe nch	0	PrimeSimVCS option primesim_spf_sd_check:
saPrimeSimVCSOptionprimesimsp fsdcheckUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fsensitive	string	custom		PrimeSimVCS option primesim_spf_sensitive: Supports case sensitivity for netlist back-annotation flow.
saPrimeSimVCSOptionprimesimsp fsensitiveUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp fskipresforivsrc	string	saTestbe nch		PrimeSimVCS option primesim_spf_skip_res_for_ivsrc: Tests to see whether any SPF nets for RC annotation are connected to any current sources or voltage sources.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimspfskipresforivsrcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspf	string	custom		PrimeSimVCS option primesim_spfspef: Sets primesim_spf input to be DSPF or SPEF format.
saPrimeSimVCSOptionprimesimspfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfspicenames	string	custom	1	PrimeSimVCS option primesim_spf_spice_names: Specifies whether the instance names in the DSPF file include the SPICE type prefix.
saPrimeSimVCSOptionprimesimspfspicenamesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfsplitnet	string	custom	1	PrimeSimVCS option primesim_spfsplitnet: Back annotate split nets
saPrimeSimVCSOptionprimesimspfsplitnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfsuffix	string	custom		PrimeSimVCS option primesim_spfsuffix: Defines the suffix in a DSPF file.
saPrimeSimVCSOptionprimesimspfsuffixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfrc	string	custom	0.1ps	PrimeSimVCS option primesim_spfrc: Time constant value for RC reduction
saPrimeSimVCSOptionprimesimspfrcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspftrf	string	custom		PrimeSimVCS option primesim_spftrf: Reference temperature for DSPF resistors
saPrimeSimVCSOptionprimesimspftrfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimspfuserdefinedgndlist	string	custom		PrimeSimVCS option primesim_spf_user_defined_gnd_list: Specifies the node list that should be treated as ideal ground in SPF back-annotation.
saPrimeSimVCSOptionprimesimspfuserdefinedgndlistUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspfwarn	string	custom		PrimeSimVCS option primesim_spfwarn: Controls warning message output when performing and debugging back-annotation.
saPrimeSimVCSOptionprimesimspfwarnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspred	string	custom	2	PrimeSimVCS option primesim_spred: Level of RC reduction.
saPrimeSimVCSOptionprimesimspredkeepname	string	saTestbench		PrimeSimVCS option primesim_spred_keep_name:
saPrimeSimVCSOptionprimesimspredkeepnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimspredkeepname is loaded.
saPrimeSimVCSOptionprimesimspredkeepvdiv	string	saTestbench		PrimeSimVCS option primesim_spred_keep_vdiv:
saPrimeSimVCSOptionprimesimspredkeepvdivUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspredmulti	string	saTestbench		PrimeSimVCS option primesim_spred_multi_part:
saPrimeSimVCSOptionprimesimspredmultiUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsprednegres	string	saTestbench		PrimeSimVCS option primesim_spred_negres:
saPrimeSimVCSOptionprimesimsprednegresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimsprednegres is loaded.
saPrimeSimVCSOptionprimesimsprednohortplus	string	saTestbench	0	PrimeSimVCS option primesim_spred_no_hort_plus:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimsp rednoshortplusUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redplus	string	saTestbench		PrimeSimVCS option primesim_spred_plus:
saPrimeSimVCSOptionprimesimsp redplusabstolfactor	string	saTestbench	100	PrimeSimVCS option primesim_spred_plus_abstol_factor:
saPrimeSimVCSOptionprimesimsp redplusabstolfactorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redpluscheckboth	string	saTestbench	1	PrimeSimVCS option primesim_spred_plus_check_both:
saPrimeSimVCSOptionprimesimsp redpluscheckbothUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redpluscomptotalR	string	saTestbench	0	PrimeSimVCS option primesim_spred_plus_comp_totalR:
saPrimeSimVCSOptionprimesimsp redpluscomptotalRUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redplusdistributetoall	string	saTestbench	0	PrimeSimVCS option primesim_spred_plus_distribute_to_all:
saPrimeSimVCSOptionprimesimsp redplusdistributetoallUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redpluseqrcutoff	string	saTestbench		PrimeSimVCS option primesim_spred_plus_eqr_cutoff:
saPrimeSimVCSOptionprimesimsp redpluseqrcutoffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimspredpluseqrcutoff is loaded.
saPrimeSimVCSOptionprimesimsp redpluseqropt	string	saTestbench	0	PrimeSimVCS option primesim_spred_plus_eqr_opt:
saPrimeSimVCSOptionprimesimsp redpluseqroptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redpluseqrrelth	string	saTestbench		PrimeSimVCS option primesim_spred_plus_eqr_relth:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimsp redpluseqrrelthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redpluseqrth	string	saTestbench	1e-1	PrimeSimVCS option primesim_spred_plus_eqr_th:
saPrimeSimVCSOptionprimesimsp redpluseqrthUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redplusfulltraversal	string	saTestbench	1	PrimeSimVCS option primesim_spred_plus_full_traversal:
saPrimeSimVCSOptionprimesimsp redplusfulltraversalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redpluskeepnegres	string	saTestbench	0	PrimeSimVCS option primesim_spred_plus_keep_negres:
saPrimeSimVCSOptionprimesimsp redpluskeepnegresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redpluskeeptotalcond	string	saTestbench	1	PrimeSimVCS option primesim_spred_plus_keep_total_cond:
saPrimeSimVCSOptionprimesimsp redpluskeeptotalcondUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redplusmaxmerge	string	saTestbench	2	PrimeSimVCS option primesim_spred_plus_max_merge:
saPrimeSimVCSOptionprimesimsp redplusmaxmergeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redplusopenthreshold	string	saTestbench	10000	PrimeSimVCS option primesim_spred_plus_open_threshold:
saPrimeSimVCSOptionprimesimsp redplusopenthresholdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redplusporttcfactor	string	saTestbench		PrimeSimVCS option primesim_spred_plus_port_tc_factor:
saPrimeSimVCSOptionprimesimsp redplusporttcfactorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimsp redplusshortfirst	string	saTestbe nch	0	PrimeSimVCS option primesim_spred_plus_short_first:
saPrimeSimVCSOptionprimesimsp redplusshortfirstUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redplusshortingabstol	string	saTestbe nch		PrimeSimVCS option primesim_spred_plus_shorting_abstol:
saPrimeSimVCSOptionprimesimsp redplusshortingabstolUncheckLoc alized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redplusshortingreltol	string	saTestbe nch		PrimeSimVCS option primesim_spred_plus_shorting_reltol:
saPrimeSimVCSOptionprimesimsp redplusshortingreltolUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redplustc	string	saTestbe nch		PrimeSimVCS option primesim_spred_plus_tc:
saPrimeSimVCSOptionprimesimsp redplustcUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redplustightenportsshort	string	saTestbe nch	0	PrimeSimVCS option primesim_spred_plus_tighten_ports_short:
saPrimeSimVCSOptionprimesimsp redplustightenportsshortUncheckL ocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redplustopnets	string	saTestbe nch	10	PrimeSimVCS option primesim_spred_plus_top_nets:
saPrimeSimVCSOptionprimesimsp redplustopnetsUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redplustwopass	string	saTestbe nch	0	PrimeSimVCS option primesim_spred_plus_two_pass:
saPrimeSimVCSOptionprimesimsp redplustwopassUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsp redplusUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimspreadprll	string	saTestbench	0	PrimeSimVCS option primesim_spreadprll:
saPrimeSimVCSOptionprimesimspreadprllUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspreadpwropt	string	saTestbench	0	PrimeSimVCS option primesim_spreadpwropt:
saPrimeSimVCSOptionprimesimspreadpwroptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspreadtc	string	saTestbench		PrimeSimVCS option primesim_spreadtc:
saPrimeSimVCSOptionprimesimspreadtcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspreadUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspreadvvalopt	string	saTestbench	0	PrimeSimVCS option primesim_spreadvvalopt:
saPrimeSimVCSOptionprimesimspreadvvaloptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimspreadresout	string	saTestbench		PrimeSimVCS option primesim_spreadresout: Enables and specifies the output format for the SPRES solver.
saPrimeSimVCSOptionprimesimspreadresoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsram	string	custom		PrimeSimVCS option primesim_sram: Provides one accuracy setting command for SRAM characterizations for both timing and power applications.
saPrimeSimVCSOptionprimesimsramUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimssfcapitercnt	string	saTestbench		PrimeSimVCS option primesim_ss_sfcap_itercnt:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimsssfcapitercntUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimsssfcapitercnt is loaded.
saPrimeSimVCSOptionprimesimsssfcaptol	string	saTestbench		PrimeSimVCS option primesim_ss_sfcap_tol:
saPrimeSimVCSOptionprimesimsssfcaptolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimsssfcaptol is loaded.
saPrimeSimVCSOptionprimesimsssfap	string	saTestbench		PrimeSimVCS option primesim_ss_sparse_fcap:
saPrimeSimVCSOptionprimesimsssfapthreshold	string	saTestbench		PrimeSimVCS option primesim_ss_sparse_fcap_threshold:
saPrimeSimVCSOptionprimesimsssfapthresholdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimsssfapthreshold is loaded.
saPrimeSimVCSOptionprimesimsssfapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimsssfap is loaded.
saPrimeSimVCSOptionprimesimsubcktduprule	string	custom	0	PrimeSimVCS option primesim_subckt_dup_rule: Selects which sub-circuit definition to use in simulation..
saPrimeSimVCSOptionprimesimsubcktdupruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsweepbrief	string	custom		PrimeSimVCS option primesim_sweep_brief: Limits parametric sweep information written to the log file.
saPrimeSimVCSOptionprimesimsweepbriefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsynceval	string	saTestbench	0	PrimeSimVCS option primesim_sync_eval:
saPrimeSimVCSOptionprimesimsyncevalmode	string	saTestbench	0	PrimeSimVCS option primesim_sync_eval_mode:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimsyncevalmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsyncevalnoprop	string	saTestbench	0	PrimeSimVCS option primesim_sync_eval_no_prop:
saPrimeSimVCSOptionprimesimsyncevalnopropUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsyncevalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimsyntaxcheck	string	saTestbench		PrimeSimVCS option primesim_syntax_check:
saPrimeSimVCSOptionprimesimsyntaxcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtablesharemethod	string	saTestbench		PrimeSimVCS option primesim_table_share_method:
saPrimeSimVCSOptionprimesimtablesharemethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtclinitfile	string	custom		PrimeSimVCS option primesim_tcl_init_file: Specifies the Tcl file for PrimeSim to source for the simulation.
saPrimeSimVCSOptionprimesimtclinitfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtelentscmethod	string	saTestbench	2	PrimeSimVCS option primesim_telem_tsc_method:
saPrimeSimVCSOptionprimesimtelentscmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtempveccharge	string	saTestbench		PrimeSimVCS option primesim_tempvec_charge:
saPrimeSimVCSOptionprimesimtempvecchargeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtempvecsametempallowed	string	saTestbench		PrimeSimVCS option primesim_tempvec_sametemp_allowed:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimtempvecsametempallowedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtempvec	string	saTestbench		PrimeSimVCS option primesim_tempvec_tc:
saPrimeSimVCSOptionprimesimtempvecUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtfflush	string	custom		PrimeSimVCS option primesim_tflush: Flushes output files at time interval x.
saPrimeSimVCSOptionprimesimtfflushUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtgrid	string	saTestbench	5	PrimeSimVCS option primesim_tgrid:
saPrimeSimVCSOptionprimesimtgridUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtiefloatingpodegates	string	saTestbench	1	PrimeSimVCS option primesim_tie_floating_pode_gates:
saPrimeSimVCSOptionprimesimtiefloatingpodegatesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtiegate	string	saTestbench		PrimeSimVCS option primesim_tiegate:
saPrimeSimVCSOptionprimesimtiegateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtienode	string	saTestbench		PrimeSimVCS option primesim_tienode:
saPrimeSimVCSOptionprimesimtienodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtitleinalterfilenames	string	custom		PrimeSimVCS option primesim_title_in_alter_filenames: Specifies whether to append the title_string from .ALTER statements to the output filename prefix.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimtitl einalterfilenamesUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtm iagereltol	string	saTestbe nch		PrimeSimVCS option primesim_tmiage_reltol: For TMI aging simulation
saPrimeSimVCSOptionprimesimtm iagereltolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtm icache	string	saTestbe nch	0	PrimeSimVCS option primesim_tmi_cache:
saPrimeSimVCSOptionprimesimtm icacheUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtm icachevtol	string	saTestbe nch		PrimeSimVCS option primesim_tmi_cache_vtol:
saPrimeSimVCSOptionprimesimtm icachevtolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtm imt	string	saTestbe nch	1	PrimeSimVCS option primesim_tmi_mt:
saPrimeSimVCSOptionprimesimtm imtUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtm isheabstol	string	saTestbe nch		PrimeSimVCS option primesim_tmishe_abstol: For TMI self-heating simulation
saPrimeSimVCSOptionprimesimtm isheabstolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtol scale	string	custom		PrimeSimVCS option primesim_tolscale: Sets a multiplier applied to all internal tolerance values.
saPrimeSimVCSOptionprimesimtol scaleUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimt opn	string	saTestbe nch		PrimeSimVCS option primesim_top_n:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimtpnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtranconvretry	string	saTestbench		PrimeSimVCS option primesim_tran_conv_retry: If transient simulation fails to converge the first time
saPrimeSimVCSOptionprimesimtranconvretryUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtriabstol	string	saTestbench		PrimeSimVCS option primesim_tr_iabstol:
saPrimeSimVCSOptionprimesimtriabstolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtrireltol	string	saTestbench		PrimeSimVCS option primesim_tr_ireltol:
saPrimeSimVCSOptionprimesimtrireltolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtrtol	string	saTestbench		PrimeSimVCS option primesim_trtol:
saPrimeSimVCSOptionprimesimtrtolyscale	string	saTestbench		PrimeSimVCS option primesim_trtolyscale:
saPrimeSimVCSOptionprimesimtrtolyscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtrtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtsalg	string	saTestbench		PrimeSimVCS option primesim_tsalg:
saPrimeSimVCSOptionprimesimtsalgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtsc	string	saTestbench	lte1	PrimeSimVCS option primesim_tsc: Sets the algorithm mode for time-step control during transient analysis.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimts cUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimts progresslog	string	saTestbe nch	0	PrimeSimVCS option primesim_ts_progress_log:
saPrimeSimVCSOptionprimesimts progresslogUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimts tstop	string	saTestbe nch		PrimeSimVCS option primesim_tstop: Modifies the tstop specified in the .tran command line
saPrimeSimVCSOptionprimesimtst opUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtst scheck	string	saTestbe nch	0	PrimeSimVCS option primesim_tsts_check:
saPrimeSimVCSOptionprimesimtst schecknodename	string	saTestbe nch		PrimeSimVCS option primesim_tsts_check_node_name:
saPrimeSimVCSOptionprimesimtst schecknodenameUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtst scheckUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimtu nit	string	custom	0.01p	PrimeSimVCS option primesim_tunit: Defines the base time unit of the simulation.
saPrimeSimVCSOptionprimesimtu nitUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimus einactivealterflow	string	saTestbe nch	1	PrimeSimVCS option primesim_use_inactive_alter_flow:
saPrimeSimVCSOptionprimesimus einactivealterflowUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimus einactivesweepflow	string	saTestbe nch	1	PrimeSimVCS option primesim_use_inactive_sweep_flow:
saPrimeSimVCSOptionprimesimus einactivesweepflowUncheckLocali zed	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimuseinline_name	string	saTestbench		PrimeSimVCS option primesim_use_inline_name:
saPrimeSimVCSOptionprimesimuseinline_nameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimuseoldtrout	string	custom	0	PrimeSimVCS option primesim_use_old_trout: Determines whether to use new or previous output file name extensions for .print and .measure.
saPrimeSimVCSOptionprimesimuseoldtroutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimusesimplemodel	string	saTestbench	2	PrimeSimVCS option primesim_use_simple_model:
saPrimeSimVCSOptionprimesimusesimplemodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimutfmode	string	saTestbench	fast	PrimeSimVCS option primesim_utf_mode: Outputs compressed UTF for Veritools.
saPrimeSimVCSOptionprimesimutfmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimvarymodelparams	string	saTestbench		PrimeSimVCS option primesim_vary_model_params:
saPrimeSimVCSOptionprimesimvarymodelparamsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimvatscmethod	string	saTestbench	0	PrimeSimVCS option primesim_va_tsc_method:
saPrimeSimVCSOptionprimesimvatscmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimvdd	string	custom		PrimeSimVCS option primesim_vdd: Sets the VDD value used for MOS table generation.
saPrimeSimVCSOptionprimesimvddUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimvds0range	string	saTestbench		PrimeSimVCS option primesim_vds0_range:
saPrimeSimVCSOptionprimesimvds0rangeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimvector	string	custom		PrimeSimVCS option primesim_vector: Specifies a vector file for comparison with simulation results.
saPrimeSimVCSOptionprimesimvectorerrmsg	string	custom		PrimeSimVCS option primesim_vector_errmsg: Specifies how errors are handled during vector comparison.
saPrimeSimVCSOptionprimesimvectorerrmsgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimvectormode	string	custom	0	PrimeSimVCS option primesim_vector_mode: Sets the I/O vector file format for bus signals.
saPrimeSimVCSOptionprimesimvectormodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimvectornotabularmode	string	saTestbench		PrimeSimVCS option primesim_vector_no_tabular_mode:
saPrimeSimVCSOptionprimesimvectornotabularmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimvectortopnode	string	saTestbench		PrimeSimVCS option primesim_vector_topnode:
saPrimeSimVCSOptionprimesimvectortopnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimvectorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogabypass	string	custom		PrimeSimVCS option primesim_verilogabypass: Enables the model bypass of entire Verilog-A models in the design.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimverilogabypassUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogacrossaccuracy	string	saTestbench	2	PrimeSimVCS option primesim_veriloga_cross_accuracy:
saPrimeSimVCSOptionprimesimverilogacrossaccuracyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogacrossdefaultetol	string	saTestbench	-1	PrimeSimVCS option primesim_veriloga_cross_default_etol:
saPrimeSimVCSOptionprimesimverilogacrossdefaultetolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogacrossdefaultttol	string	saTestbench	-1	PrimeSimVCS option primesim_veriloga_cross_default_ttol:
saPrimeSimVCSOptionprimesimverilogacrossdefaultttolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogacrossmethod	string	custom		PrimeSimVCS option primesim_veriloga_cross_method: Specifies what value (true false) the Verilog-A cross(x) function returns when x is exactly zero.
saPrimeSimVCSOptionprimesimverilogacrossmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogadecodepercentinfoopen	string	saTestbench		PrimeSimVCS option primesim_veriloga_decode_percent_infoopen:
saPrimeSimVCSOptionprimesimverilogadecodepercentinfoopenUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimverilogadecodepercentinfoopen is loaded.
saPrimeSimVCSOptionprimesimverilogadefaultimaxslew	string	saTestbench		PrimeSimVCS option primesim_veriloga_default_i_maxslew:
saPrimeSimVCSOptionprimesimverilogadefaultimaxslewUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogadefaultvmaxslew	string	saTestbench		PrimeSimVCS option primesim_veriloga_default_v_maxslew:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimverilogadefaultvmaxslewUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogadivisionupperlimit	string	saTestbench		PrimeSimVCS option primesim_veriloga_division_upper_limit:
saPrimeSimVCSOptionprimesimverilogadivisionupperlimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogadkinddef	string	saTestbench		PrimeSimVCS option primesim_veriloga_dkind_def: Defines the device type for the Verilog-A device model
saPrimeSimVCSOptionprimesimverilogadkinddefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogadkindmode	string	custom		PrimeSimVCS option primesim_veriloga_dkind_mode: Specifies whether to enable (1) or disable (0) the primesim_veriloga_dkind_def option.
saPrimeSimVCSOptionprimesimverilogadkindmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogadynarbcheck	string	saTestbench	1	PrimeSimVCS option primesim_veriloga_dyn_arb_check:
saPrimeSimVCSOptionprimesimverilogadynarbcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogaeexpthreshold	string	saTestbench	80.0	PrimeSimVCS option primesim_veriloga_exp_threshold:
saPrimeSimVCSOptionprimesimverilogaeexpthresholdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogaeextraeval	string	saTestbench		PrimeSimVCS option primesim_veriloga_extra_eval:
saPrimeSimVCSOptionprimesimverilogaeextraevalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogaeforcesofile rebuild	string	saTestbench	0	PrimeSimVCS option primesim_veriloga_force_sofile_rebuild:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimverilogaforcesofilerebuildUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogagenericflag1	string	saTestbench		PrimeSimVCS option primesim_veriloga_generic_flag1:
saPrimeSimVCSOptionprimesimverilogagenericflag1UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionprimesimverilogagenericflag1 is loaded.
saPrimeSimVCSOptionprimesimverilogahdl	string	custom		PrimeSimVCS option primesim_veriloga (.hdl): Helps include a Verilog-A file in the netlist.
saPrimeSimVCSOptionprimesimverilogahdlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogainactivepartitionsizesize	string	saTestbench	0	PrimeSimVCS option primesim_veriloga_inactive_partition_size:
saPrimeSimVCSOptionprimesimverilogainactivepartitionsizesizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogalimexpthreshold	string	saTestbench	46.051701859881368	PrimeSimVCS option primesim_veriloga_limexp_threshold:
saPrimeSimVCSOptionprimesimverilogalimexpthresholdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogamaptransistorport	string	saTestbench		PrimeSimVCS option primesim_veriloga_map_transistor_port:
saPrimeSimVCSOptionprimesimverilogamaptransistorportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogaprintcrosstols	string	saTestbench		PrimeSimVCS option primesim_veriloga_print_cross_tols:
saPrimeSimVCSOptionprimesimverilogaprintcrosstolsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogaq	string	saTestbench		PrimeSimVCS option primesim_veriloga_qa:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimverilogaaUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogaslewwrap	string	saTestbench	0	PrimeSimVCS option primesim_verilog_a_slew_wrap:
saPrimeSimVCSOptionprimesimverilogaslewwrapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogasuppresstcrossprediction	string	saTestbench		PrimeSimVCS option primesim_verilog_a_suppress_tcross_prediction:
saPrimeSimVCSOptionprimesimverilogasuppresstcrosspredictionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogatablefillinpolicy	string	custom		PrimeSimVCS option primesim_verilog_a_table_fill_in_policy: Specifies the direction to start extrapolation if there are missing indexed entries when using the table_param built-in function to specify a file that contains a parameter values table and return the linear interpolated value from that table.
saPrimeSimVCSOptionprimesimverilogatablefillinpolicyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogatimerrefforcesactivity	string	saTestbench		PrimeSimVCS option primesim_verilog_a_time_ref_forces_activity:
saPrimeSimVCSOptionprimesimverilogatimerrefforcesactivityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogatimerperiodtrunc	string	saTestbench	0	PrimeSimVCS option primesim_verilog_a_timer_period_trunc:
saPrimeSimVCSOptionprimesimverilogatimerperiodtruncUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogatimerstutterstepfloat	string	saTestbench	0.0	PrimeSimVCS option primesim_verilog_a_timer_stutterstep_float:
saPrimeSimVCSOptionprimesimverilogatimerstutterstepfloatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimverilogatimerstutterstep_tunit	string	saTestbench	0	PrimeSimVCS option primesim_veriloga_timer_stutterstep_tunit:
saPrimeSimVCSOptionprimesimverilogatimerstutterstep_tunitUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogatransitionabstol	string	saTestbench	1e-6	PrimeSimVCS option primesim_veriloga_transition_abstol:
saPrimeSimVCSOptionprimesimverilogatransitionabstolUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogatransitionreltol	string	saTestbench	1e-3	PrimeSimVCS option primesim_veriloga_transition_reltol:
saPrimeSimVCSOptionprimesimverilogatransitionreltolUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogatunit	string	saTestbench	(int)(floor(log10(tunit)))	PrimeSimVCS option primesim_veriloga_tunit:
saPrimeSimVCSOptionprimesimverilogatunitUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogauseexptable	string	saTestbench	1	PrimeSimVCS option primesim_veriloga_use_exp_table:
saPrimeSimVCSOptionprimesimverilogauseexptableUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogavaropt	string	custom		PrimeSimVCS option primesim_veriloga_var_opt: Sets some local variables within Verilog-A modules in order to have the variables shared among instances.
saPrimeSimVCSOptionprimesimverilogavaroptUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimverilogarace	string	saTestbench	0.5	PrimeSimVCS option primesim_vgrace:
saPrimeSimVCSOptionprimesimverilogaraceUncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimvp rbtol	string	custom	0.1mV	PrimeSimVCS option primesim_vprbtol: Sets the voltage tolerance for voltage print out.
saPrimeSimVCSOptionprimesimvp rbtolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimvp wltol	string	custom		PrimeSimVCS option primesim_vpwltol: Removes small changes in the voltage input waveform in PWL format.
saPrimeSimVCSOptionprimesimvp wltolUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimvs rcn	string	saTestbe nch		PrimeSimVCS option primesim_vsrch:
saPrimeSimVCSOptionprimesimvs rcnUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimw arnlimit	string	custom	0	PrimeSimVCS option primesim_warn_limit: Sets the number of all warning messages to a specific number of lines.
saPrimeSimVCSOptionprimesimw arnlimitUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimw dflimit	string	custom		PrimeSimVCS option primesim_wdf_limit: Sets the number of warning messages to a number of specified lines
saPrimeSimVCSOptionprimesimw dflimitUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimw dfmode	string	saTestbe nch	loseless	PrimeSimVCS option primesim_wdf_mode: Controls the amount of compression for wdf output file.
saPrimeSimVCSOptionprimesimw dfmodeUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimwi ldcardexpansionflow	string	saTestbe nch	0	PrimeSimVCS option primesim_wildcard_expansion_flow:
saPrimeSimVCSOptionprimesimwi ldcardexpansionflowUncheckLocal ized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimwildcardrule	string	saTestbench		PrimeSimVCS option primesim_wildcard_rule:
saPrimeSimVCSOptionprimesimwildcardruleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimwriteinstanceparam	string	custom		PrimeSimVCS option primesim_write_instance_param: Dumps out a list of resolved instance parameters with full scope names.
saPrimeSimVCSOptionprimesimwriteinstanceparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimwriteinstancetable	string	custom	0	PrimeSimVCS option primesim_write_instance_table: Generates an instance file.
saPrimeSimVCSOptionprimesimwriteinstancetableUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimwriteitemcparm	string	custom	0	PrimeSimVCS option primesim_write_mcparm: Saves the generated parameters in each run to a file.
saPrimeSimVCSOptionprimesimwriteitemcparmUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimxprbcheckmosfet	string	saTestbench		PrimeSimVCS option primesim_xprb_check_mosfet:
saPrimeSimVCSOptionprimesimxprbcheckmosfetfix	string	saTestbench		PrimeSimVCS option primesim_xprb_check_mosfet_fix:
saPrimeSimVCSOptionprimesimxprbcheckmosfetfixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimxprbcheckmosfetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprimesimxprbdevlimit	string	saTestbench		PrimeSimVCS option primesim_xprb_dev_limit:
saPrimeSimVCSOptionprimesimxprbdevlimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionprimesimxprbkeepdev	string	saTestbench		PrimeSimVCS option primesim_xprb_keep_dev:
saPrimeSimVCSOptionprimesimxprbkeepdevUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprintincluding	string	custom	no	PrimeSimVCS option print_including: Enable Spectre/Ultrsim to print including information in include statement. Possible values are no and yes.
saPrimeSimVCSOptionprintsection	string	custom	no	PrimeSimVCS option print_section: If yes, output sections used in simulations. If no, do not output sections.. Possible values are no and yes.
saPrimeSimVCSOptionprintstep	string	custom	no	PrimeSimVCS option printstep: Enable Spectre to print results by equal step defined in .tran statement. Possible values are no and yes.
saPrimeSimVCSOptionprintstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionprobecompatible	string	custom	spectre	PrimeSimVCS option probe_compatible: Flag to enable or disable optimization for probe wildcard statement. Possible values are hspice and spectre.
saPrimeSimVCSOptionpsfopmc	string	saTestbench		PrimeSimVCS option psf_op_mc:
saPrimeSimVCSOptionpsfopmcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionpsfopmc is loaded.
saPrimeSimVCSOptionptranmaxsteps	string	custom	200	PrimeSimVCS option ptranmaxsteps: Maximum number of steps for ptran phase in DC simulation.
saPrimeSimVCSOptionputmeas	string	custom		PrimeSimVCS option putmeas: Controls the output variables listed in the .MEASURE command
saPrimeSimVCSOptionputmeasUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionpvaoutputdir	string	saTestbench	<file path>	PrimeSimVCS option pva_output_dir:

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionpvoutputdirUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionpvoutputdir is loaded.
saPrimeSimVCSOptionpvchar	string	saTestbench		PrimeSimVCS option pv_char:
saPrimeSimVCSOptionpvcharUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionpvchar is loaded.
saPrimeSimVCSOptionqcut	string	custom	[...]	PrimeSimVCS option qcut: Replaces all BJT instances using the specified model definitions with an open. qcut=all cuts all BJT elements.
saPrimeSimVCSOptionquantities	string	custom	no	PrimeSimVCS option quantities: Print quantities. If quantities=min, the simulator prints out all defined quantities; if quantities=full, the simulator also prints a list of nodes and their quantities. Possible values are no, min, and full.
saPrimeSimVCSOptionrabsclamp	string	custom	0.0	PrimeSimVCS option rabsclamp: All fixed value and variable resistors with absolute value of $R \leq rabsclamp$ are clamped to 'rabsclamp'.
saPrimeSimVCSOptionrabsshort	string	custom		PrimeSimVCS option rabsshort: When this option is set, all fixed value resistors with absolute value of $R \leq rabsshort$ are shorted. Default value is 0 for Spectre, and 1m for APS. Rabsshort can additionally be applied to variable resistors using the option 'short_cut_var_elem=yes'.
saPrimeSimVCSOptionrampsourc	string	custom	yes	PrimeSimVCS option rampsourc: When performing dc hysteresis sweep, rampsourc should be set to no. Possible values are no and yes.
saPrimeSimVCSOptionrationalfunccachedir	string	custom		PrimeSimVCS option rational_func_cache_dir: Specifies an arbitrary directory where you have write permission that the PrimeSim tool can use to store and reuse rational function cache data
saPrimeSimVCSOptionrationalfunccachedirUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionrclampbsource	string	saTestbench		PrimeSimVCS option rclamp_bsource:
saPrimeSimVCSOptionrclampbsource	string	custom		PrimeSimVCS option rclamp_bsource: When rclamp_bsource=value is given, all instance bsource resistors with R<value are clamped to value. It has high priority than rclamp if both are set. Default is 0.001 Ohm for bsource resistor.
saPrimeSimVCSOptionrclampbsourceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionrcnetsave	string	custom	all	PrimeSimVCS option rcnet_save: Flag to enable filter internal RC nodes for probe/save statement. Possible values are all and portonly.
saPrimeSimVCSOptionrcrcgnd	string	custom	1.00E-18	PrimeSimVCS option rcr_cgnd: this parameter is used to set the minimum value of capacitance that should be decoupled to ground.
saPrimeSimVCSOptionrcrfmax	string	custom	1	PrimeSimVCS option rcr_fmax: this parameter is used to set the max frequency used by rc reduction.
saPrimeSimVCSOptionrcrnetactivebitlineconly	string	custom	0	PrimeSimVCS option rcr_net_active_bit_line_conly: When set to 1, short all resistors of the parasitic networks that are connected to an active bit-line.
saPrimeSimVCSOptionrcrnetactivestateconly	string	custom	0	PrimeSimVCS option rcr_net_active_state_conly: When set to 1, short all resistors of the parasitic networks that are connected to an active state.
saPrimeSimVCSOptionrcrnetactivewordlineconly	string	custom	0	PrimeSimVCS option rcr_net_active_word_line_conly: When set to 1, short all resistors of the parasitic networks that are connected to an active word-line.
saPrimeSimVCSOptionrcrnetcgnd	string	custom	1.00E-18	PrimeSimVCS option rcr_net_cgnd: this parameter is used by the rc net flow to set the minimum value of capacitance that should be decoupled to ground.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionrcrnetidlebit lineonly	string	custom	0	PrimeSimVCS option rcr_net_idle_bit_line_only: When set to 1, short all resistors of the parasitic networks that are connected to an idle bit-line.
saPrimeSimVCSOptionrcrnetidlest ateonly	string	custom	0	PrimeSimVCS option rcr_net_idle_state_only: When set to 1, short all resistors of the parasitic networks that are connected to an idle state.
saPrimeSimVCSOptionrcrnetidlest atevpnonly	string	custom	0	PrimeSimVCS option rcr_net_idle_state_vpn_only: When set to 1, short all resistors of VPN parasitic networks that are connected to idle state parasitic networks.
saPrimeSimVCSOptionrcrnetidlew ordlineonly	string	custom	0	PrimeSimVCS option rcr_net_idle_word_line_only: When set to 1, short all resistors of the parasitic networks that are connected to an idle word-line.
saPrimeSimVCSOptionrcrnetmerg epnidlestateports	string	custom	0	PrimeSimVCS option rcr_net_merge_pn_idle_state_ports: When set to 1, allows merging of those ports of power or vpn parasitic networks, that are connected to idle state nodes.
saPrimeSimVCSOptionrcrnetprese rveactivebitlineports	string	custom	0	PrimeSimVCS option rcr_net_preserve_active_bit_line_ports: When set to 1, preserves ports of parasitic networks that are connected to an active bit-line node.
saPrimeSimVCSOptionrcrnetprese rveactivestateports	string	custom	0	PrimeSimVCS option rcr_net_preserve_active_state_ports: When set to 1, preserves ports of parasitic networks that are connected to an active-state node.
saPrimeSimVCSOptionrcrnetprese rveactivewordlineports	string	custom	0	PrimeSimVCS option rcr_net_preserve_active_word_line_ports: When set to 1, preserves ports of parasitic networks that are connected to an active word-line node.
saPrimeSimVCSOptionrcrnetprese rvedrainsourcesignals	string	custom	0	PrimeSimVCS option rcr_net_preserve_drain_source_signals: When set to 1, preserves ports of parasitic networks that are connected to a source and drain device terminals.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionrcrnetprese rveidlebitlineports	string	custom	0	PrimeSimVCS option rcr_net_preserve_idle_bit_line_ports: When set to 1, preserves ports of parasitic networks that are connected to an idle bit-line node.
saPrimeSimVCSOptionrcrnetprese rveidlestateports	string	custom	0	PrimeSimVCS option rcr_net_preserve_idle_state_ports: When set to 1, preserves ports of parasitic networks that are connected to an idle-state node.
saPrimeSimVCSOptionrcrnetprese rveidlewordlineports	string	custom	0	PrimeSimVCS option rcr_net_preserve_idle_word_line_ports: When set to 1, preserves ports of parasitic networks that are connected to an idle word-line node.
saPrimeSimVCSOptionrcrnetprese rvepnports	string	custom	0	PrimeSimVCS option rcr_net_preserve_pn_ports: When set to 1, preserves ports of parasitic networks that are connected to a DC vsource.
saPrimeSimVCSOptionrcrnetprese rvevpnports	string	custom	0	PrimeSimVCS option rcr_net_preserve_vpn_ports: When set to 1, preserves ports of parasitic networks that are connected to a VPN source.
saPrimeSimVCSOptionrcrrshort	string	custom	1.00E-03	PrimeSimVCS option rcr_rshort: this parameter is used to set the minimum value of resistor that should be cut.
saPrimeSimVCSOptionrcut	string	custom	infinity	PrimeSimVCS option rcut: Fixed value resistors with $R > rcut$ are replaced by open. Default is infinity for Spectre and $MAX(1/GMIN, 1e12)$ for APS. For bsource resistor, default is 1e12 for Spectre and $MAX(1/GMIN, 1e12)$ for APS. If GMIN is not specified, the value of $MAX(1/GMIN, 1e12)$ is 1e12. rcut can additionally be applied to variable resistors using the option 'short_cut_var_elem=yes'.
saPrimeSimVCSOptionrebuildmat rix	string	custom	no	PrimeSimVCS option rebuild_matrix: If set to yes, rebuild circuit matrix at the beginning of ac, dc, dcmatch, montecarlo, pz, stb, sweep, tdr, and tran analyses. This is to ensure consistent matrix ordering at the beginning of the analyses for consistent results. Notice that rebuild circuit matrix can result in performance overhead. Possible values are no and yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionredefinedparams	string	custom	error	PrimeSimVCS option redefinedparams: Specify whether parameters can be redefined in the netlist. When set to warning or ignore, the simulator allows you to redefine parameters in the netlist. However, it honors only the last definition of the redefined parameter. Depending on the value set, the simulator displays warning messages for the redefined parameters or does not display any message. When set to error, the simulator does not allow you to redefine parameters in the netlist and displays an error message. Possible values are error, ignore, warning, and warn.
saPrimeSimVCSOptionreelaborateonalter	string	custom	force	PrimeSimVCS option reelaborateonalter: Whether re-elaborate for every alter statement. Possible values are lazy and force.
saPrimeSimVCSOptionreltol	string	custom	0.001	PrimeSimVCS option reltol: Relative convergence criterion.
saPrimeSimVCSOptionreplicates	string	custom		PrimeSimVCS option replicates: Runs replicates of the Latin Hypercube samples
saPrimeSimVCSOptionreplicatesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionresidualtol	string	custom	1.0	PrimeSimVCS option residualtol: Tolerance ratio for residual (multiplies reltol).
saPrimeSimVCSOptionrforce	string	custom	1	PrimeSimVCS option rforce: Resistance used when forcing nodesets and node-based initial conditions.
saPrimeSimVCSOptionrisetime	string	custom		PrimeSimVCS option risetime: Sets the smallest rise time of the signal
saPrimeSimVCSOptionrisetimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionrmdgccs	string	custom	no	PrimeSimVCS option rmdgccs: If yes, dangling controlled current source will be removed. Default value is no.. Possible values are no and yes.
saPrimeSimVCSOptionrmomimagefile	string	saTestbench		PrimeSimVCS option rm_omimage_file:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionrmomiagefileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionrmtmiagefile	string	saTestbench		PrimeSimVCS option rm_tmiage_file:
saPrimeSimVCSOptionrmtmiagefileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionrthresh	string	custom	0.001	PrimeSimVCS option rthresh: All instance resistors with $\text{abs}(R) < \text{rthresh}$ will use resistance form, unless their instance parameter or model parameter overwrites it.
saPrimeSimVCSOptionrunlvl	string	custom	4	PrimeSimVCS option runlvl: Controls runtime speed and simulation accuracy.
saPrimeSimVCSOptionrunlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionsaetablefmt	string	custom	1	PrimeSimVCS option saetablefmt: Format of SOA check output. If true, SOA results are returned in TSV files.
saPrimeSimVCSOptionsaetablefmtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionsamplingmethod	string	custom		PrimeSimVCS option sampling_method: Enables use of advanced sampling methods with traditional Gaussian Monte Carlo trials
saPrimeSimVCSOptionsamplingmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionsaveby	string	saTestbench		PrimeSimVCS option save_by:
saPrimeSimVCSOptionsavebyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionscale	string	custom	1.0	PrimeSimVCS option scale: Device instance scaling factor.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionsscalefactor	string	custom	1.0	PrimeSimVCS option scale_factor: ScaleFactor for Device Model Technology Scaling. The options parameter scalefactor enables device model providers to scale device technology independent of the design dimension scaling done by circuit designers. The resulting device instance scaling is defined by 'scale * scalefactor'. If the foundry uses a technology scale factor of 0.9 (scalefactor=0.9), and the circuit designer uses a design scale factor of 1e-6 (scale=1e-6), then the compounded scaling of the device instance dimension is 0.9e-6. Unlike options parameter scale, scalefactor cannot be used as a netlist parameter and cannot be altered or used in sweep statements.
saPrimeSimVCSOptionsscalefactorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionsscalem	string	custom	1.0	PrimeSimVCS option scalem: Model scaling factor.
saPrimeSimVCSOptionsscaleredefined	string	custom	ignore	PrimeSimVCS option scale_redefined: Disallow redefining of the option scale in netlist. Possible values are error, ignore, and warning.
saPrimeSimVCSOptionsscaleredefinedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionsscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionsscalcm	string	custom		PrimeSimVCS option scalcm: Sets the model scaling factor for device model parameters
saPrimeSimVCSOptionsscalcmUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionsscreeningmethod	string	saTestbench		PrimeSimVCS option screening_method:
saPrimeSimVCSOptionsscreeningmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionsearch	string	custom		PrimeSimVCS option search: Finds files in a simulation
saPrimeSimVCSOptionsearchUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionselemcachedir	string	saTestbench	<file path>	PrimeSimVCS option s_elem_cache_dir:
saPrimeSimVCSOptionselemcachedirUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionssensbinparam	string	custom	no	PrimeSimVCS option sensbinparam: Sensitivity for binning models. Possible values are no, uncorrelated, and correlated.
saPrimeSimVCSOptionssenscompositedevice	string	saTestbench		PrimeSimVCS option sens_composite_device:
saPrimeSimVCSOptionssenscompositedeviceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionssensfile	string	saTestbench	sensout.txt	PrimeSimVCS option sensfile: Determines if ASCII files for sensitivity analysis results need to be generated, providing the path and filename to use.
saPrimeSimVCSOptionssensfileonly	string	custom	no	PrimeSimVCS option sensfileonly: Enable or disable raw output of sensitivity. results. Possible values are no and yes.
saPrimeSimVCSOptionssensfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionssensformat	string	custom	tabular	PrimeSimVCS option sensformat: Format of sensitivity data. Possible values are tabular and list.
saPrimeSimVCSOptionssenssort	string	saTestbench	0	PrimeSimVCS option senssort:
saPrimeSimVCSOptionssenssortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionssensstype	string	custom	partial	PrimeSimVCS option sensstype: Type of sensitivity being calculated. Possible values are partial and normalized.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionsetmissing values	string	saTestbench		PrimeSimVCS option set_missing_values:
saPrimeSimVCSOptionsetmissing valuesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionshighpass	string	saTestbench		PrimeSimVCS option s_highpass:
saPrimeSimVCSOptionshighpass UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSOptionshighpass is loaded.
saPrimeSimVCSOptionsshortbjtr	string	custom	0.0	PrimeSimVCS option short_bjtr: All parasitic resistors inside bipolar devices less than global short_bjtr will be removed. This option is applied to all bipolar junction transistors.
saPrimeSimVCSOptionsshortcutnonconst	string	custom	no	PrimeSimVCS option shortcutnonconst: Cut Non const value.. Possible values are yes and no.
saPrimeSimVCSOptionsshrunkmos diffdata	string	saTestbench	0	PrimeSimVCS option shrunkmosdiffdata:
saPrimeSimVCSOptionsshrunkmos diffdataUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionssimstat	string	custom	basic	PrimeSimVCS option simstat: Print simulation phase statistics report. Possible values are basic and detailed.
saPrimeSimVCSOptionsskip	string	custom	none	PrimeSimVCS option skip: Skip the simulating specified subckt instances. For now, cut is supported, which will leave the subckt ports disconnected. Possible values are none, load, and cut.
saPrimeSimVCSOptionsskipmacro mos	string	custom	[...]	PrimeSimVCS option skip_macro_mos: The list of subcircuit names, which is skipped to be a macro model.
saPrimeSimVCSOptionssoamode	string	custom	0	PrimeSimVCS option soa_mode: Option to choose one SOA check mode, 0 for customer's definition and 1 for Spectre's.
saPrimeSimVCSOptionssoawarn	string	custom	yes	PrimeSimVCS option soa_warn: If soa_warn is no, SOA warnings will be turned off. Possible values are no and yes.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionsoftbin	string	custom	singlemodels	PrimeSimVCS option soft_bin: If set to singlemodels, it is used only on non-binned models. Possible values are singlemodels, no, and allmodels.
saPrimeSimVCSOptionsoibodyinit control	string	saTestbench	0	PrimeSimVCS option soi_body_init_control:
saPrimeSimVCSOptionsoibodyinit controlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionsoibodyinitn	string	saTestbench		PrimeSimVCS option soi_body_init_n:
saPrimeSimVCSOptionsoibodyinitnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionsoibodyinitp	string	saTestbench		PrimeSimVCS option soi_body_init_p:
saPrimeSimVCSOptionsoibodyinitpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionsoibodyinittype	string	saTestbench	0	PrimeSimVCS option soi_body_init_type:
saPrimeSimVCSOptionsoibodyinittypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionsortinstance	string	custom	no	PrimeSimVCS option sortinstance: sort devices of the netlist. Possible values are no and yes. dF dF dp F dp F
saPrimeSimVCSOptionspef	string	custom		PrimeSimVCS option spef: This option specifies the SPEF file to be stitched and its stitching scope. The syntax is spef="scope filename". The scope can be a subcircuit or an instance. Use "spectre -h stitch" for more information.
saPrimeSimVCSOptionspeftriplet	string	custom	2	PrimeSimVCS option speftriplet: This option specifies the value to be used for stitching in the SPEF file. It is effective only when the values in the SPEF file are represented by triplets (for example, 0.325:0.41:0.495).. Possible values are 1, 2, and 3.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionspf	string	custom		PrimeSimVCS option spf: This option specifies the DSPF file to be stitched and its stitching scope. The syntax is spf="scope filename". The scope can be a subcircuit or an instance. Use "spectre -h stitch" for more information.
saPrimeSimVCSOptionspfalias term	string	custom		PrimeSimVCS option spfaliasterm: At times, the terminal names of devices in DSPF/SPEF/DPF files are different from those in the simulation model library. This happens in technology nodes that use subcircuits to model devices. The syntax is spfaliasterm="<model subckt> <prelayout_term0>=<spf_alias1> <prelayout_term2>=<spf_alias2> ... <prelayout_termN>=<spf_aliasN>". Multiple statements are supported. Use "spectre -h stitch" for more information.
saPrimeSimVCSOptionspfbusde lim	string	custom		PrimeSimVCS option spfbusdelim: This option maps the bus delimiter between schematic netlist and parasitic file (i.e. DSPF, SPEF, or DPF). The option defines the bus delimiter in the schematic netlist, and optionally the bus delimiter in the parasitic file. By default the bus delimiter of the parasitic file is taken from the parasitic file header (that is, * BUSBIT [], * BUS_BIT [], or * BUS_DELIMITER []). If the bus delimiter is not defined in the parasitic file header, you need specify it using the spfbusdelim option in schematic netlist. For example, the option spfbusdelim="<>" is maps A<1> in the schematic netlist to A_1 in the DSPF file, if the bus delimiter header in the DSPF file is "_". The option spfbusdelim="@ []" maps A@1 in the schematic netlist to A[1] in the DSPF file (the bus delimiter in DSPF header will be ignored). See "spectre -h stitch" for more information.
saPrimeSimVCSOptionspfnet	string	custom		PrimeSimVCS option spfnet: This option specifies the net that has its total capacitance stitched. All other parasitic components such as parasitic resistors that are associated with this net are ignored. The complete hierarchical names are required and multiple statements are supported. Wildcards are supported. Use "spectre -h stitch" for more information.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionspfncnetfile	string	custom		PrimeSimVCS option spfncnetfile: This option has the same functionality as spfncnet, except that it accepts a text file in which all the C-only stitched nets are listed. Only one file can be specified. The syntax is spfncnetfile="filename". The format of the file requires you to specify one line per net. Use "spectre -h stitch" for more information.
saPrimeSimVCSOptionspfinstance section	string	custom	1	PrimeSimVCS option spfinstancesection: This option controls the backannotation of device parameters in the instance section of the DSPF file. If spfinstancesection is turned off, the instance section is ignored (that is, the device parameters are not changed during stitching). The default is on. Use "spectre -h stitch" for more information.
saPrimeSimVCSOptionspfinstarray delim	string	custom		PrimeSimVCS option spfinstarraydelim: This option specifies the supplemental bus delimiter, if more than one bus delimiter is used in pre-layout netlist (usually for instance array indexing). It is similar to the spfbusdelim option. Use "spectre -h stitch" for more information.
saPrimeSimVCSOptionspfmsglimit	string	custom		PrimeSimVCS option spfmsglimit: This option specifies the maximum number of messages to be printed in the spfprt file. The syntax is spfmsglimit="number STITCH-ID_1 STITCH-ID_2". Use "spectre -h stitch" for more details.
saPrimeSimVCSOptionspfnetcmin	string	custom	0	PrimeSimVCS option spfnetcmin: This option allows you to select the net for stitching by the value of its total node capacitance. If a net's total node capacitance exceeds spfnetcmin, all parasitics associated with the net are stitched correctly, otherwise, only the total capacitance is added to the net node. Use "spectre -h stitch" for more information.
saPrimeSimVCSOptionspfpostparam	string	custom	replace	PrimeSimVCS option spfpostparam: This option specifies the instance parameters sourced for stitched instances. When set to replace, only the post-layout parameters are used and the pre-layout parameters are discarded. When set to append, both pre-layout and post-layout parameters are merged for the stitched instances where the post-layout parameters have higher priority. Possible values are append and replace.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionspfprobenode	string	custom	net_only	PrimeSimVCS option spfprobenode: When net_only, it is the only net name in SPF file that is used to match the wild card in .probe/.ic statements. The hierarchical structure of the net name is restored like pre-layout netlist. When all, the net name in SPF file is stored as pre-layout node name, and the nodes in SPF file are preserved like the current behavior. The wild card in .probe/.ic will match all the nodes and net names. Possible values are net_only and all.
saPrimeSimVCSOptionspfrcnet	string	custom		PrimeSimVCS option spfrcnet: This option specifies the name of the net to be stitched with parasitic resistors and capacitors. The other nets are stitched with lumped total capacitances. Multiple statements are supported. Wildcards are supported and you can specify as many nets as needed. Complete hierarchical net names are required. Use "spectre -h stitch" for more information.
saPrimeSimVCSOptionspfrcnetfile	string	custom		PrimeSimVCS option spfrcnetfile: This option has the same functionality as spfrcnet, except that it accepts a text file in which all the RC stitched nets are specified. Only one file can be specified. The syntax is spfrcnetfile="filename". The format of the file requires you to specify one line per net. Use "spectre -h stitch" for more details.
saPrimeSimVCSOptionspfscale	string	custom	1.0	PrimeSimVCS option spfscale: This option specifies the scaling factor of all the elements in the parasitic files (DSPF/SPEF/DPF). Use "spectre -h stitch" for more details.
saPrimeSimVCSOptionspfscalec	string	custom	1	PrimeSimVCS option spfscalec: This option specifies the scale factor for parasitic capacitors.
saPrimeSimVCSOptionspfscaler	string	custom	1	PrimeSimVCS option spfscaler: This option specifies the scale factor for parasitic resistors.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionspfskipnet	string	custom		PrimeSimVCS option spfskipnet: This option specifies the net to be skipped for stitching, that is, all parasitic components of the net are not stitched. Wildcards are supported. You can specify multiple spfskipnet statements. Use "spectre -h stitch" for more information.
saPrimeSimVCSOptionspfskipnetfile	string	custom		PrimeSimVCS option spfskipnetfile: This option allows you to specify the nets to be skipped as a list in a text file. The syntax is spfskipnetfile="filename". Only one file can be specified. The format in the file is one line per net. Use "spectre -h stitch" for more information.
saPrimeSimVCSOptionspfswapterm	string	custom		PrimeSimVCS option spfswapterm: This option specifies the swappable terminals of a subcircuit macro-model. The syntax is spfswapterm="terminal1 terminal2 subcktname". Use "spectre -h stitch" for more information.
saPrimeSimVCSOptionspfxtorprefix	string	custom		PrimeSimVCS option spfxtorprefix: This option specifies the prefix in the device or net names in the DSPF/SPEF/DPF file. The syntax is spfxtorprefix="substring [replace_substring]". Use "spectre -h stitch" for more information.
saPrimeSimVCSOptionspicetype	string	saTestbench	0	PrimeSimVCS option spice_type:
saPrimeSimVCSOptionspicetypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionsrationalfunc	string	custom		PrimeSimVCS option s_rational_func: Globally activates the rational function model in S-element analysis
saPrimeSimVCSOptionsrationalfuncUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionsrationalfuncwindowing	string	custom		PrimeSimVCS option s_rational_func_windowing: Globally activates the rational function windowing function for all S-elements in a netlist
saPrimeSimVCSOptionsrationalfuncwindowingUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionssmooth	string	saTestbench	0	PrimeSimVCS option smooth: PrimeSimVCS option smooth:
saPrimeSimVCSOptionssmoothUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionstepdropsize	string	custom	100	PrimeSimVCS option stepdropsize: The threshold size of step drop to report a dramatic change warning.
saPrimeSimVCSOptionstvernote	string	custom	no	PrimeSimVCS option stver_note: Give -stver suggestion warning for invalid parameter. Possible values are no and yes.
saPrimeSimVCSOptionsubcktiprobes	string	custom	yes	PrimeSimVCS option subcktiprobes: Insert iprobes when computing subcircuit terminal currents. Possible values are no and yes.
saPrimeSimVCSOptionsubcktoppoint	string	custom	no	PrimeSimVCS option subcktoppoint: Output oppoint parameters of subckt instance. Possible values are no and yes.
saPrimeSimVCSOptionsubcktswitch	string	custom	full	PrimeSimVCS option subckt_switch: If set to simple, complex subckt will be mapped to simple subckt in mapsubckt. Possible values are full and simple.
saPrimeSimVCSOptionsubcktvthchildproc	string	custom	yes	PrimeSimVCS option subcktvthchildproc: Computing vth of subckt in child process. Possible values are no and yes.
saPrimeSimVCSOptiontempeffects	string	custom	all	PrimeSimVCS option tempeffects: Temperature effect selector. If tempeffect = vt, only thermal voltage varies with temperature; if tempeffect = tc, parameters that start with tc are active and thermal voltage is dependent on temperature; and if tempeffect = all, all built-in temperature models are enabled. Possible values are vt, tc, and all.
saPrimeSimVCSOptiontermcurmethod	string	custom	default	PrimeSimVCS option termcur_method: Select methods to compute terminal currents. Set termcur_method=complete to get correct currents when devices have no termcurs output. However, this may negatively impact performance.. Possible values are default and complete.
saPrimeSimVCSOptionthermalmap	string	custom	%C:r.raw	PrimeSimVCS option thermalmap: Output raw data file name.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSOptiontitle	string	custom		PrimeSimVCS option title: Circuit title.
saPrimeSimVCSOptiontmiage	string	custom	0	PrimeSimVCS option tmiage: Activate TMI Aging model flow. By default, it is not activated.
saPrimeSimVCSOptiontmiagemode	string	saTestbench		PrimeSimVCS option tmiagemode:
saPrimeSimVCSOptiontmiagemodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiontmiageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiontmiagingremove_slash	string	custom	0	PrimeSimVCS option tmiaging_remove_slash: Internal option to remove the slash character before dot in instance name. By default it is closed.
saPrimeSimVCSOptiontmi_fast_core_data	string	custom	0	PrimeSimVCS option tmi_fast_core_data: Speed up TMI SOA/Age performance by fast TMI coredata evaluation..
saPrimeSimVCSOptiontmiflag	string	custom	0	PrimeSimVCS option tmiflag: Activate TMI flow. By default TMI flow is not activated.
saPrimeSimVCSOptiontmiflagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiontmiinput	string	custom		PrimeSimVCS option tmiinput: input file name including full path to read back TMI information for aging model.
saPrimeSimVCSOptiontmiinputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiontmimapipolicy	string	saTestbench	0	PrimeSimVCS option tmi_mapi_policy:
saPrimeSimVCSOptiontmimapipolicyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiontmioutput3dic	string	saTestbench		PrimeSimVCS option tmi_output_3dic:

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptiontmioutput3dicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiontmipath	string	custom		PrimeSimVCS option tmipath: Location of TMI shared object libraries to be used by tmiBsim4 models.
saPrimeSimVCSOptiontmipathUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiontmisave	string	custom	1	PrimeSimVCS option tmisave: Enable or disable aging information to be saved.
saPrimeSimVCSOptiontmisaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiontmisort	string	saTestbench		PrimeSimVCS option tmisort:
saPrimeSimVCSOptiontmisort	string	custom		PrimeSimVCS option tmisort: Sort aging information.
saPrimeSimVCSOptiontmisortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiontmpltpol	string	custom		PrimeSimVCS option tmplt_pol: Enables printing of PMOS template output voltage polarity as real bias
saPrimeSimVCSOptiontmpltpolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiontnom	string	custom	27	PrimeSimVCS option tnom: Temperature measurement of the default component parameter.
saPrimeSimVCSOptiontnomUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptiontopcheck	string	custom	full	PrimeSimVCS option topcheck: Check circuit topology for errors. Possible values are no, min, full, fixall, errmin, and errfull.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptiontryfastop	string	custom	yes	PrimeSimVCS option try_fast_op: Speed up the DC solution. For hard-to-converge designs, this feature fails and other methods are applied. In corner cases, this feature may have negative effects. If the DC analysis is unusually slow, the memory usage of the processes keeps increasing, or if DC analysis gets stuck even before homotopy methods start, set this option to no. Possible values are no and yes.
saPrimeSimVCSOptionunwrap	string	custom		PrimeSimVCS option unwrap: Sets all phase results in AC analysis to be calculated in an unwrapped form
saPrimeSimVCSOptionunwrapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionuseagaussformat	string	saTestbench		PrimeSimVCS option use_agauss_format:
saPrimeSimVCSOptionuseagaussformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionusetopparam3dic	string	saTestbench		PrimeSimVCS option use_top_param_3dic:
saPrimeSimVCSOptionusetopparam3dicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionuseveriloga	string	custom	0	PrimeSimVCS option use_veriloga: Determine whether to take Verilog-A as high priority. If set to '1', the Verilog-A model takes priority over the other subckt/models. If set to '0', the Verilog-A model does not take priority over the other subckt/models..
saPrimeSimVCSOptionvabsshort	string	custom	0.0	PrimeSimVCS option vabsshort: Voltage sources with absolute DC voltage less than or equal to vabsshort are shorted. The default value in Spectre is 0, and in APS is 1e-9 V.
saPrimeSimVCSOptionvabstol	string	custom	1.0e-6	PrimeSimVCS option vabstol: Convergence criterion for absolute voltage tolerance.
saPrimeSimVCSOptionvalue	string	custom	V	PrimeSimVCS option value: Default value quantity.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionverilogalang	string	custom	relax	PrimeSimVCS option verilogalang: AHDL Verilog-A language syntax check mode selector. If verilogalang=strict, show archaic syntax input as an error during Verilog-A parsing; If verilogalang=relax, show archaic syntax input as a warning during Verilog-A parsing. Possible values are strict and relax.
saPrimeSimVCSOptionvntol	string	custom		PrimeSimVCS option vntol: Duplicates the ABSV option
saPrimeSimVCSOptionvrefbins	string	custom	[...]	PrimeSimVCS option vrefbins: Specifies the voltage bins when bin_relref=yes is used. Default setting is vrefbins=[1 3 5 10].
saPrimeSimVCSOptionvrefgnd	string	custom		PrimeSimVCS option vrefgnd: Specify reference ground.
saPrimeSimVCSOptionvthmod	string	custom	std	PrimeSimVCS option vthmod: Vth output selector. 'std' outputs model equation Vth; 'vthcc' outputs constant current Vth and may impact simulation performance; 'vthcc_ext' outputs constant current Vth on external nodes; 'maxgm' outputs maxgm Vth. Possible values are std, vthcc, vthcc_ext, and maxgm.
saPrimeSimVCSOptionvthmodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionwarn	string	custom	0	PrimeSimVCS option warn: Enables or turns off SOA voltage warning message (equivalent to primesim_soa_warn)
saPrimeSimVCSOptionwarningchangeseverity	string	custom	warning	PrimeSimVCS option warning_change_severity: Change the severity of warning messages specified in immediately following warning_id. Possible values are error, warning, and notice.
saPrimeSimVCSOptionwarningid	string	custom	[...]	PrimeSimVCS option warning_id: Vector of warning message identifiers, such as [SPECTRE-16462 SPECTRE-16684]. Used in conjunction with warning_limit or warning_change_severity.
saPrimeSimVCSOptionwarninglimit	string	custom	5	PrimeSimVCS option warning_limit: The maximum number of times the warnings specified in immediately following the warning_id parameter should be displayed.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSOptionwarnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSOptionwfdebug	string	custom	none	PrimeSimVCS option wfdebug: Flag to store the measurement signal in a raw file. Possible values are none and measure.
saPrimeSimVCSOptionwfmaxsize	string	custom	infinity	PrimeSimVCS option wfmaxsize: Limits the maximum size of the output waveform. This option is valid when uwi format is set.
saPrimeSimVCSSaveOptionsEmTStart	string	saTestbench		Start time for electromigration current analysis
saPrimeSimVCSSaveOptionsEmTStop	string	saTestbench		Stop time for electromigration current analysis
saPrimeSimVCSSaveOptionsEnableEM	string	saTestbench	false	Save currents for in-design layout automation
saPrimeSimVCSSaveOptionsEnableVDRC	string	saTestbench	false	Save voltage extremes to enable V-DRC flow
saPrimeSimVCSSaveOptionsPower	string	saTestbench	0	PrimeSimVCS: Save power signals for each device
saPrimeSimVCSSaveOptionsSaveNet	string	saTestbench	selected	PrimeSimVCS: Save net voltages
saPrimeSimVCSSaveOptionsSaveDigital	string	saTestbench	selected	PrimeSimVCS: Save digital signals
saPrimeSimVCSSaveOptionsSaveDigitalLevel	string	saTestbench	0	PrimeSimVCS: Save digital signals level
saPrimeSimVCSSaveOptionsSaveDigitalPorts	string	saTestbench	selected	PrimeSimVCS: Save digital ports
saPrimeSimVCSSaveOptionsSaveDigitalPortsLevel	string	saTestbench	0	PrimeSimVCS: Save digital ports level
saPrimeSimVCSSaveOptionsSaveIEPortsAll	string	saTestbench	false	Save Options save interface element/connect module ports
saPrimeSimVCSSaveOptionsSaveIEPortsLevel	string	saTestbench	0	Save Options save interface element/connect module ports level
saPrimeSimVCSSaveOptionsSaveNetLevel	string	saTestbench	0	PrimeSimVCS: Save net voltages level
saPrimeSimVCSSaveOptionsSaveOptionsInstances	string	saTestbench		PrimeSimVCS: Save instance-specific signals

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSSaveOptionsSaveVerilogABranchCurrentsAll	string	saTestbench	false	Save Options save Verilog-A branch currents
saPrimeSimVCSSaveOptionsSaveVerilogABranchCurrentsLevel	string	saTestbench	0	Save Options save Verilog-A branch currents level
saPrimeSimVCSSaveOptionsSaveVerilogABranchVoltagesAll	string	saTestbench	false	Save Options save Verilog-A branch voltages
saPrimeSimVCSSaveOptionsSaveVerilogABranchVoltagesLevel	string	saTestbench	0	Save Options save Verilog-A branch voltages level
saPrimeSimVCSSaveOptionsSaveVerilogAVarsAll	string	saTestbench	false	Save Options save Verilog-A variables
saPrimeSimVCSSaveOptionsSaveVerilogAVarsLevel	string	saTestbench	0	Save Options save Verilog-A variables level
saPrimeSimVCSSaveOptionsSubcktCurrents	string	saTestbench	selected	PrimeSimVCS: Save subckt port currents
saPrimeSimVCSSaveOptionsSubcktCurrentsLevel	string	saTestbench	0	PrimeSimVCS: Save subckt port currents level
saPrimeSimVCSSaveOptionsTerminalCurrents	string	saTestbench	selected	PrimeSimVCS: Save device terminal currents
saPrimeSimVCSSaveOptionsTerminalCurrentsLevel	string	saTestbench	0	PrimeSimVCS: Save device terminal currents level
saPrimeSimVCSSaveOptionsTerminalVoltages	string	saTestbench	selected	PrimeSimVCS: Save device terminal voltages
saPrimeSimVCSSaveOptionsTerminalVoltagesLevel	string	saTestbench	0	PrimeSimVCS: Save device terminal voltages level
saPrimeSimVCSSaveOptionsTotalPower	string	saTestbench	0	PrimeSimVCS: Save total power
saPrimeSimVCSSaveOptionsVdrcTStart	string	saTestbench		Start time for VDRC voltage analysis
saPrimeSimVCSSaveOptionsVdrcTStop	string	saTestbench		Stop time for VDRC voltage analysis
saPrimeSimVCSShowModelGroups	bool	saTestbench	false	Visibility of Model Groups table for PrimeSimVCS
saPrimeSimVCSSimulationCommandAndPrefix	string	xtJobClass		An environment initialization command to be added to simulation commands
saPrimeSimVCSSTRANAutostop	string	saTestbench	no	PrimeSimVCS autostop

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSTRANDpmethod	string	saTestbench	Vector	PrimeSimVCS tran parameter values in file/vector
saPrimeSimVCSTRANDynamicParameters	bool	saTestbench	false	PrimeSimVCS tran show/hide dynamic parameters
saPrimeSimVCSTRANFinalopfile	string	saTestbench		PrimeSimVCS finalopfile
saPrimeSimVCSTRANlctype	string	saTestbench	all	PrimeSimVCS lctype
saPrimeSimVCSTRANInstancesListExp	string	saTestbench	false	PrimeSimVCS TRAN: Activation/Deactivation of noise instances list
saPrimeSimVCSTRANMethod	string	saTestbench	trap	PrimeSimVCS method
saPrimeSimVCSTRANNoiseEnableSel	string	saTestbench	Enable	PrimeSimVCS TRAN: Select if instances list correspond to noisy or noiseless devices
saPrimeSimVCSTRANNoiseSeedStart	string	saTestbench		PrimeSimVCS TRAN: Trannoise seed sweep start
saPrimeSimVCSTRANNoiseSeedStop	string	saTestbench		PrimeSimVCS TRAN: Trannoise seed sweep stop
saPrimeSimVCSTRANOpfile	string	saTestbench		PrimeSimVCS opfile
saPrimeSimVCSTRANOptionautostop	string	custom	no	PrimeSimVCS option autostop: If yes, the analysis is terminated when all event-type measurement expressions have been evaluated. Event-type expressions use thresholding, event, or delay type functions. If the value is spice, autostop is consistent with spice simulator. Possible values are no, yes, and spice.
saPrimeSimVCSTRANOptionautostopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptiondelmax	string	saTestbench		PrimeSimVCS option delmax: max step for the tran
saPrimeSimVCSTRANOptiondelmax	string	custom		PrimeSimVCS option delmax: Maximum time step. The default is derived from 'errpreset'.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSTRANOptiondelmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionfmax	string	saTestbench	0	PrimeSimVCS option fmax: Parameter to invoke the transient noise analysis. A value turns on noise sources during transient analysis.
saPrimeSimVCSTRANOptionfmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionfmin	string	saTestbench		PrimeSimVCS option fmin: If specified, the flicker noise is included in transient analysis. The noise power density below noisefmin is constant.
saPrimeSimVCSTRANOptionfminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionic_type	string	custom	all	PrimeSimVCS option ic_type: The value to be used to set the initial condition. Possible values are dc, node, dev, and all.
saPrimeSimVCSTRANOptionic_typeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionmethod	string	saTestbench	trap	PrimeSimVCS option method: Integration method. Possible values are: be, trap, gear, egear.
saPrimeSimVCSTRANOptionmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionname	string	saTestbench		PrimeSimVCS option name: analysis name
saPrimeSimVCSTRANOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionnstart	string	saTestbench		PrimeSimVCS option nstart: Start time during transient analysis when noise sources are activated.
saPrimeSimVCSTRANOptionnstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSTRANOptionnstop	string	saTestbench		PrimeSimVCS option nstop: Stop time during transient analysis when noise sources are activated.
saPrimeSimVCSTRANOptionnstop UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionopti mes	string	custom	[...]	PrimeSimVCS option op_times: Times when analyses specified in 'acname' array are performed.
saPrimeSimVCSTRANOptionother Options	string	custom		PrimeSimVCS option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimVCSTRANOptionoutp utstart	string	custom	start	PrimeSimVCS option outputstart: Output is saved only after this time is reached.
saPrimeSimVCSTRANOptionpa ram	string	saTestbench		PrimeSimVCS option param: option name to change in tran
saPrimeSimVCSTRANOptionpara mdata	string	saTestbench		PrimeSimVCS option param_data: value array to change the option specified by "param
saPrimeSimVCSTRANOptionpara mdataUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionpara mUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionprim esimrestore	string	custom		PrimeSimVCS option primesim_restore: Specify the file to be restored.
saPrimeSimVCSTRANOptionrea dic	string	custom		PrimeSimVCS option read_ic: File that contains initial condition.
saPrimeSimVCSTRANOptionreadi cUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionrea dns	string	custom		PrimeSimVCS option read_ns: File that contains an estimate of the initial transient solution.
saPrimeSimVCSTRANOptionread nsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSTRANOptionsavefile	string	custom		PrimeSimVCS option savefile: File to which initial transient solution is to be written.
saPrimeSimVCSTRANOptionsavetime	string	custom		PrimeSimVCS option savetime: File to which final transient solution is to be written.
saPrimeSimVCSTRANOptionsscale	string	saTestbench	1	PrimeSimVCS option scale: Noise scale for all noise sources. Default is 1.
saPrimeSimVCSTRANOptionsscale	string	custom	1	PrimeSimVCS option scale: Noise scale factor applied to all generated noise. Can be used to artificially inflate the small noise to make it visible above transient analysis numerical noise floor, but it should be small enough to maintain the nonlinear operation of the circuit .
saPrimeSimVCSTRANOptionsscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionseed	string	saTestbench	-1	PrimeSimVCS option seed: Seed for random number generator. Default is -1 (0 is noiseless).
saPrimeSimVCSTRANOptionseedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionsimstart	string	custom	0	PrimeSimVCS option simstart: Start time.
saPrimeSimVCSTRANOptionsimstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionsnapshotelapsed	string	custom		PrimeSimVCS option snapshotelapsed: Save the tran analysis periodically on the wall clock time. The default is 1800s for Spectre. This parameter is disabled in the APS mode by default.
saPrimeSimVCSTRANOptionsnapshotfile	string	custom		PrimeSimVCS option snapshotfile: Save the analysis states into the specified file.
saPrimeSimVCSTRANOptionsnapshotperiod	string	custom		PrimeSimVCS option snapshotperiod: Save the tran analysis periodically on the simulation time.
saPrimeSimVCSTRANOptionsnapshottime	string	custom	(...)	PrimeSimVCS option snapshottime: Save the analysis states into files on the specified time points.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSTRANOptionstart	string	custom	0	PrimeSimVCS option start: Start time.
saPrimeSimVCSTRANOptionstep	string	custom		PrimeSimVCS option step: Minimum time step used by the simulator solely to maintain the aesthetics of the computed waveforms.
saPrimeSimVCSTRANOptionstrobe_delay	string	custom	0	PrimeSimVCS option strobe_delay: The delay (phase shift) between the skipstart time and the first strobe point.
saPrimeSimVCSTRANOptionstrobe_delayUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionstrobe_nskip	string	custom	1	PrimeSimVCS option strobe_nskip: Equivalent to skipcount.
saPrimeSimVCSTRANOptionstrobe_nskipUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionstrobe_period	string	custom	0	PrimeSimVCS option strobe_period: The output strobe interval (in seconds) of transient time.
saPrimeSimVCSTRANOptionstrobe_periodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionstrobe_start	string	custom	0	PrimeSimVCS option strobe_start: Equivalent to skipstart.
saPrimeSimVCSTRANOptionstrobe_startUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionstrobe_step	string	custom	0	PrimeSimVCS option strobestep: Equivalent to strobeperiod.
saPrimeSimVCSTRANOptionstrobe_stop	string	custom	stop	PrimeSimVCS option strobe_stop: Equivalent to skipstop.
saPrimeSimVCSTRANOptionstrobe_stopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptiontrtol	string	custom		PrimeSimVCS option trtol: Ratio used to compute LTE tolerances from Newton tolerance.

Table 32 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimVCSTRANOptiontrtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimVCSTRANOptiontrtol is loaded.
saPrimeSimVCSTRANOptionuic	string	custom	no	PrimeSimVCS option uic: If set to yes, there is no DC analysis for transient. Possible values are no, yes, useprevic, waveless, rampup, autodc, sigrampup, and dcrampup.
saPrimeSimVCSTRANOptionwrite	string	custom		PrimeSimVCS option write: File to which initial transient solution is to be written.
saPrimeSimVCSTRANOptionwriteFinal	string	custom		PrimeSimVCS option write_final: File to which final transient solution is to be written.
saPrimeSimVCSTRANOptionwriteFinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimVCSTRANParamdata	string	saTestbench		PrimeSimVCS tran parameter data
saPrimeSimVCSTRANParamfile	string	saTestbench		PrimeSimVCS tran parameter file
saPrimeSimVCSTRANParamname	string	saTestbench		PrimeSimVCS tran parameter
saPrimeSimVCSTRANSaveparam	string	saTestbench	true	PrimeSimVCS tran save dynamic parameter as a probe or not
saPrimeSimVCSTRANSimstart	string	saTestbench		PrimeSimVCS simstart
saPrimeSimVCSTRANStart	string	saTestbench	0	PrimeSimVCS Transient start time
saPrimeSimVCSTRANStep	string	saTestbench		PrimeSimVCS Transient step
saPrimeSimVCSTRANStop	string	saTestbench		PrimeSimVCS Transient stop time
saPrimeSimVCSTRANStrobedelay	string	saTestbench		PrimeSimVCS strobedelay
saPrimeSimVCSTRANStrobenskip	string	saTestbench		PrimeSimVCS strobenskip

Table 32 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimVCSTRANStrobeperiod	string	saTestbench		PrimeSimVCS strobeperiod
saPrimeSimVCSTRANStrobestart	string	saTestbench		PrimeSimVCS strobestart
saPrimeSimVCSTRANStrobestop	string	saTestbench		PrimeSimVCS strobestop
saPrimeSimVCSTRANTime	string	saTestbench		PrimeSimVCS time
saPrimeSimVCSTRANTnafmax	string	saTestbench		PrimeSimVCS TRAN: A nonzero value turns on the noise sources during transient analysis
saPrimeSimVCSTRANTnafmin	string	saTestbench		PrimeSimVCS TRAN: If specified, PSD of the noise sources from fmin to fmax
saPrimeSimVCSTRANTnascale	string	saTestbench		PrimeSimVCS TRAN: Trannoise scale
saPrimeSimVCSTRANTnaSeedSel	string	saTestbench	Fixed Value	PrimeSimVCS TRAN: Trannoise seed type selection. Fixed value or sweep setup
saPrimeSimVCSTRANTnaSeedVal	string	saTestbench	1	PrimeSimVCS TRAN: Trannoise seed fixed value
saPrimeSimVCSTRANTnatstart	string	saTestbench		PrimeSimVCS TRAN: Trannoise nstart
saPrimeSimVCSTRANTnatstop	string	saTestbench		PrimeSimVCS TRAN: Trannoise nstop
saPrimeSimVCSTRANTranNoise	string	saTestbench	false	PrimeSimVCS TRAN: Enable/disable trannoise widgets
saPrimeSimVCSTRANTrtol	string	saTestbench		PrimeSimVCS rtol
saPrimeSimVCSTRANUIC	string	saTestbench	0	PrimeSimVCS Transient uic

See Also

- [Simulation and Analysis Environment Preferences \(saA2D* through saFineSimPro*\)](#)
- [Simulation and Analysis Environment Preferences \(saGen* through saOutput*\)](#)

- [Simulation and Analysis Environment Preferences \(saPrimeSimXA* through saSpectre*\)](#)
- [Simulation and Analysis Environment Preferences \(saSt* through saXA*\)](#)

Simulation and Analysis Environment Preferences (saPrimeSimXA* through saSpectre*)

Table 33 lists continuation of PrimeWave Design Environment sa general preferences (saPrimeSimXA* through saSpectre*).

Table 33 Simulation and Analysis Environment Preferences

Name	Type	Scope	Default	Description
saPrimeSimXAActiveNetsAnalysis Prefix	string	saTestbench	xa.active_nets	Active Nets File Name
saPrimeSimXAActiveNetsAnalysis ReuseIC	string	saTestbench	1	Reuse Initial Condition
saPrimeSimXAActiveNetsAnalysis Threshold	string	saTestbench	0.1	Voltage Threshold
saPrimeSimXAActiveNetsEnabled	string	saTestbench	0	Enable Active Nets Flow
saPrimeSimXABackAnnotationFile Dpf	string	saTestbench	1	Instance section back annotation
saPrimeSimXABackAnnotationFile MaxRes	string	saTestbench	1e12	Maximum Resistor
saPrimeSimXABackAnnotationFile MinCap	string	saTestbench		Minimum Capacitor
saPrimeSimXABackAnnotationFile MinInd	string	saTestbench	0	Minimum Inductor
saPrimeSimXABackAnnotationFile MinRes	string	saTestbench	0.01	Minimum Resistor
saPrimeSimXABackAnnotationFile Report	string	saTestbench	0	Report missing net and instance
saPrimeSimXABlockOptionsCategories	string	saTestbench	All	Categories
saPrimeSimXABlockOptionsSummary	string	saTestbench		Custom commands contents holder
saPrimeSimXADefaultCornersSetup	string	saTestbench		PrimeSimXA default corners setup

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimXADefaultIncludeFiles	string	saTestbench		PrimeSimXA default include files
saPrimeSimXADefaultModelFiles	string	saTestbench		PrimeSimXA default model files to be loaded
saPrimeSimXAEnableSimulatorResultsXML	bool	user	false	Enable the PrimeSimXA to write the result XML file
saPrimeSimXAEnvOptsAccuracyLevel	string	saTestbench	set_sim_level	Accuracy Level
saPrimeSimXAEnvOptsCaseSensitive	saTestbench	false		Simulator case setting
saPrimeSimXAEnvOptsCommandLineOptions	string	saTestbench		Additional command line options for the PrimeSimXA
saPrimeSimXAEnvOptsEldoMode	bool	saTestbench	false	Enable Eldo mode
saPrimeSimXAEnvOptsEldoStopViewList	string	saTestbench	eldoD	Stop View List for Eldo netlister
saPrimeSimXAEnvOptsEldoSwitchViewList	string	saTestbench	eldoD schematic spice veriloga	Switch View List for Eldo netlister
saPrimeSimXAEnvOptsEnableParallelSim	string	saTestbench	0	Enable Parallel Simulation
saPrimeSimXAEnvOptsHSPICEStopViewList	string	saTestbench	hspice hspiceD	Stop View List for HSPICE netlister
saPrimeSimXAEnvOptsHSPICESwitchViewList	string	saTestbench	hspice hspiceD schematic spice veriloga	Switch View List for HSPICE netlister
saPrimeSimXAEnvOptsIncludePath	string	saTestbench		Search path for PrimeSimXA include files
saPrimeSimXAEnvOptsNetlistLanguage	saPrimeSimXANetlistLanguageEnum	user	HSPICE	Netlist language for the PrimeSimXA Valid values: Third-Party Spectre HSPICE Eldo
saPrimeSimXAEnvOptsNumProcesses	string	saTestbench	1	Number of threads

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimXAEEnvOptsOutputDataFormat	string	saTestbench	wdf	Output data format
saPrimeSimXAEEnvOptsStopViewList	string	saTestbench	hspice hspiceD	Stop View List for netlister
saPrimeSimXAEEnvOptsSwitchViewList	string	saTestbench	hspice hspiceD schematic spice veriloga	Switch View List for netlister
saPrimeSimXAEEnvOptsThirdPartyStopViewList	string	saTestbench	spectre	Stop View List for ThirdParty netlister
saPrimeSimXAEEnvOptsThirdPartySwitchViewList	string	saTestbench	spectre schematic veriloga	Switch View List for ThirdParty netlister
saPrimeSimXAEEnvOptsUse64Bit	bool	saTestbench	true	64-bit simulation. Valid values: true, false
saPrimeSimXAEEnvOptsUseSsl2	bool	saTestbench	true	Use v2 of accuracy/performance tradeoff parameters set. Valid values: true, false
saPrimeSimXAIncludeSchematicNetlist	bool	user	true	Copy (true) or .include (false) the structural netlist in the final netlist. Valid values: true, false
saPrimeSimXAModelGroups	string	saTestbench		Model groups for PrimeSimXA
saPrimeSimXAModelsFiles	string	saTestbench		Model files for PrimeSimXA
saPrimeSimXAModelsIncludePath	string	saTestbench		Search path for PrimeSimXA model files
saPrimeSimXAMonteCarloEnableSeed	string	saTestbench	0	Determines whether an explicit starting seed is to be specified in monte carlo analysis
saPrimeSimXAMonteCarloIterList	string	saTestbench		list of iterations
saPrimeSimXAMonteCarloLHSReplicates	string	saTestbench	1	Runs replicates of Latin Hypercube samples
saPrimeSimXAMonteCarloLHSSampleSize	string	saTestbench		LHS sampling method sample size
saPrimeSimXAMonteCarloNumIter	string	saTestbench	10	Number of iterations for montecarlo analysis

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimXAMonteCarloSamplingMethod	string	saTestbench	SRS	Enables advanced sampling methods
saPrimeSimXAMonteCarloSeed	string	saTestbench	1	Starting seed for the random-number generator in montecarlo analysis
saPrimeSimXAMonteCarloSigmaScale	string	saTestbench	2.0	Sigma Amplification Factor for High Sigma Applications
saPrimeSimXAMonteCarloStartIter	string	saTestbench	1	Starting iteration number for montecarlo analysis
saPrimeSimXAMonteCarloUseIterList	string	saTestbench	0	use iteration list
saPrimeSimXAMonteCarloUseSigmaScaling	string	saTestbench	0	Uses Sigma Amplification for High Sigma Applications
saPrimeSimXAMonteCarloVariationIncludeOrExclude	string	saTestbench	Include	Whether statistical variation is to be applied or not applied to the specified instances/cells
saPrimeSimXAMonteCarloVariationInstanceOrCellList	string	saTestbench		List of instances or cells for which statistical variation is to be applied/not applied
saPrimeSimXAMonteCarloVariationObjectType	string	saTestbench	Instances	Object type (instances or cells) for which statistical variation is to be applied/not applied
saPrimeSimXAOptionsTimes	string	saTestbench		PrimeSimXA Operating point save time
saPrimeSimXAOptionagepwinteg	string	saTestbench	0	PrimeSimXA option age_pw_integ: Controls new mosra measure result.
saPrimeSimXAOptionagepwintegUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimXAOptionagepwinteg is loaded.
saPrimeSimXAOptionAUTOSTOP	string	custom	0	PrimeSimXA option AUTOSTOP: Stops a transient analysis
saPrimeSimXAOptionAUTOSTOPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimXAOptionAUTOSTOP is loaded.
saPrimeSimXAOptionCSHUNT	string	custom	1e-20	PrimeSimXA option CSHUNT: Add capacitance from each node to ground.
saPrimeSimXAOptionCSHUNTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimXAOptionCSHUNT is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimXAOptionDCAP	string	custom	2	PrimeSimXA option DCAP: Specifies equations used to calculate depletion capacitance for Level 1 and 3 diodes and BJTs.
saPrimeSimXAOptionDCAPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAOptionengine	string	custom	PrimeSimXA	PrimeSimXA option engine: Simulation Engine
saPrimeSimXAOptionengineUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAOptionGMIN	string	custom	1e-12	PrimeSimXA option GMIN: Minimum conductance added to all PN junctions for a time sweep in transient analysis.
saPrimeSimXAOptionGMINUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAOptionMACMOD	string	custom	0	PrimeSimXA option MACMOD: To access the subcircuit definition when there is no matching model reference
saPrimeSimXAOptionMACMODUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAOptionMAXWARNS	string	custom	5	PrimeSimXA option MAXWARNS: Specifies maximum number of safe operating area (SOA) warning messages.
saPrimeSimXAOptionMAXWARNSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAOptionMODMONTE	string	custom	0	PrimeSimXA option MODMONTE: Controls whether all instances of a device get the same or unique model parameters.
saPrimeSimXAOptionMODMONTEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAOptionMONTECON	string	custom	1	PrimeSimXA option MONTECON: Continues a Monte Carlo analysis by retrieving the next random value, even if non-convergence occurs.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimXAOptionMONTECONUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAOptionotherOptions	string	custom		PrimeSimXA option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimXAOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAOptionPVAOUTPUTDIR	string	saTestbench	<file path>	PrimeSimXA option PVA_OUTPUT_DIR: Controls pva cache directory.
saPrimeSimXAOptionPVAOUTPUTDIRUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimXAOptionPVAOUTPUTDIR is loaded.
saPrimeSimXAOptionSCALE	string	custom	1.00	PrimeSimXA option SCALE: Sets the element scaling factor.
saPrimeSimXAOptionSCALEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAOptionSCALM	string	custom	1	PrimeSimXA option SCALM: Sets the model scaling factor.
saPrimeSimXAOptionSCALMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAOptionSELEMCAC HEDIR	string	saTestbench	<file path>	PrimeSimXA option S_ELEM_CACHE_DIR: Controls s-parameter cache directory.
saPrimeSimXAOptionSELEMCAC HEDIRUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimXAOptionSELEMCACHEDIR is loaded.
saPrimeSimXAOptionsetsimlevel	string	custom	3	PrimeSimXA option set_sim_level: Controls runtime speed and simulation accuracy.
saPrimeSimXAOptionsetsimlevelaccuracy	string	saTestbench	3	PrimeSimXA option set_sim_level_accuracy: Controls runtime speed and simulation accuracy.
saPrimeSimXAOptionsetsimlevelaccuracyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimXAOptionsetsimlevelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAOptionTNOM	string	custom	25	PrimeSimXA option TNOM: Sets the reference temperature for the simulation.
saPrimeSimXAOptionTNOMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAOptionWARN	string	custom	0	PrimeSimXA option WARN: Enables or turns off SOA voltage warning message
saPrimeSimXAOptionWARNUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAOptionWL	string	custom	0	PrimeSimXA option WL: Reverses the order of the VSIZE MOS element.
saPrimeSimXAOptionWLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAParasiticBackAnnotationTableColumnsShown	string	user	Enabled { Type } {Back Annotate} {Skip Nets} {Min R} {Other Options}	Save columns shown in the Parasitic Back Annotation table
saPrimeSimXASaveOptionsEmTStart	string	saTestbench		Start time for electromigration current analysis
saPrimeSimXASaveOptionsEmTStop	string	saTestbench		Stop time for electromigration current analysis
saPrimeSimXASaveOptionsEnableEM	string	saTestbench	false	Save currents for in-design layout automation
saPrimeSimXASaveOptionsEnableVDRC	string	saTestbench	false	Save voltage extremes to enable V-DRC flow
saPrimeSimXASaveOptionsSave	string	saTestbench	level	PrimeSimXA Save Options save net voltages
saPrimeSimXASaveOptionsSaveLevel	string	saTestbench	1	Save Options save net voltages level

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimXASaveOptionsSubcktCurrents	string	saTestbench	selected	PrimeSimXA Save Options save subckt port currents
saPrimeSimXASaveOptionsSubcktCurrentsLevel	string	saTestbench	1	Save Options save subckt port currents level
saPrimeSimXASaveOptionsTerminalCurrents	string	saTestbench	selected	PrimeSimXA Save Options save device terminal currents
saPrimeSimXASaveOptionsTerminalCurrentsLevel	string	saTestbench	1	Save Options save device terminal currents level
saPrimeSimXASaveOptionsTerminalVoltages	string	saTestbench	selected	PrimeSimXA Save Options save device terminal voltages
saPrimeSimXASaveOptionsTerminalVoltagesLevel	string	saTestbench	1	Save Options save device terminal voltages level
saPrimeSimXASaveOptionsVdrcTStart	string	saTestbench		Start time for VDRC voltage analysis
saPrimeSimXASaveOptionsVdrcTStop	string	saTestbench		Stop time for VDRC voltage analysis
saPrimeSimXAShowModelGroups	bool	saTestbench	false	Visibility of Model Groups table for PrimeSimXA. Valid values: true, false
saPrimeSimXASimulationCommandPrefix	string	xtJobClass		An environment initialization command to be added to simulation commands
saPrimeSimXATRANStart	string	saTestbench	0	PrimeSimXA Transient start time
saPrimeSimXATRANStep	string	saTestbench		PrimeSimXA Transient time step
saPrimeSimXATRANStop	string	saTestbench		PrimeSimXA Transient stop time
saPrimeSimXAVCSAnalogSimulatorPath	string	user		Path to the analog simulator executable for PrimeSimXAVCS
saPrimeSimXAVCSDigitalOptionsbasetimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionsboundscheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionsdebugUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimXAVCSDigitalOptiondumpvarsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionelaborationverbosityUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saPrimeSimXAVCSDigitalOptionnerrorOPCWMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionnofalsenegUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionoverridetimescaletimeprecisionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionoverridetimescaletimeunitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionplusargsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionsimulationverbosityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptiontimeresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptiontimescaletimeprecisionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptiontimescaletimeunitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionunittimescaletimeprecisionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionunittimescaletimeunitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimXAVCSDigitalOptionvc sflushallUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionvc sflushdumpUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saPrimeSimXAVCSDigitalOptionvc sflushopenUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionvc sflushlogUncheckLocalized	bool	saTestbe nch	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saPrimeSimXAVCSDigitalOptionvc sinitregseedUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionvc sinitregUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionvp dnocompressUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionvp dnostrengthsUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSDigitalOptionxz checkUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSModelGroups	string	saTestbe nch		Model groups for PrimeSimXAVCS
saPrimeSimXAVCSOptionAUTOS TOPUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionCSHUN TUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionDCAPU ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimXAVCSOptionengineUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionGMINUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionMACMODUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionMAXWARNSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionMODMONTEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionMONTECONUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionPVAOUTPUTDIR	string	saTestbench	<file path>	PrimeSimXAVCS option PVA_OUTPUT_DIR: Controls pva cache directory.
saPrimeSimXAVCSOptionPVAOUTPUTDIRUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimXAVCSOptionPVAOUTPUTDIR is loaded.
saPrimeSimXAVCSOptionSCALEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionSCALMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionSELEMCACHEDIR	string	saTestbench	<file path>	PrimeSimXAVCS option S_ELEM_CACHE_DIR: Controls s-parameter cache directory.
saPrimeSimXAVCSOptionSELEMCACHEDIRUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference saPrimeSimXAVCSOptionSELEMCACHEDIR is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimXAVCSOptionsetsimlevelaccuracy	string	saTestbench	3	PrimeSimXAVCS option set_sim_level_accuracy: Controls runtime speed and simulation accuracy.
saPrimeSimXAVCSOptionsetsimlevelaccuracyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionsetsimlevelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionTNOMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionWARNUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXAVCSOptionWLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXFCenter	string	saTestbench		PrimeSim XF: Center point of sweep limits
saPrimeSimXFDec	string	saTestbench		PrimeSim XF: Number of logarithmic steps per decade
saPrimeSimXFDesignVar	string	saTestbench		PrimeSim XF: Design variable being swept
saPrimeSimXFDev	string	saTestbench		PrimeSim XF: Instance with parameter being swept
saPrimeSimXFDoSweep	string	saTestbench	1	PrimeSim XF: Flag indicating a sweep is to be performed
saPrimeSimXFFreq	string	saTestbench		PrimeSim XF: Single value to hold frequency while other aspect is being swept
saPrimeSimXFLin	string	saTestbench		PrimeSim XF: Number of linear steps
saPrimeSimXFLog	string	saTestbench		PrimeSim XF: Total number of logarithmic steps
saPrimeSimXFMod	string	saTestbench		PrimeSim XF: Model with parameter being swept
saPrimeSimXFNegNode	string	saTestbench		PrimeSim XF: Negative output node

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeSimXFNode	string	saTestbench		PrimeSim XF: Positive output node
saPrimeSimXFProbe	string	saTestbench		PrimeSim XF: Compute mismatch at the output defined by this component
saPrimeSimXFOptionname	string	saTestbench		PrimeSim option name: analysis name
saPrimeSimXFOptionnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXFOptionotherOptions	string	custom		PrimeSim option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saPrimeSimXFOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXFOptionreadic	string	saTestbench		PrimeSim option read_ic: read file for .ic
saPrimeSimXFOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXFOptionreadns	string	custom		PrimeSim option read_ns: File that contains an estimate of the DC solution (nodeset).
saPrimeSimXFOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXFOptionstimuli	string	saTestbench	source	PrimeSim option stimuli: select the output variables
saPrimeSimXFOptionstimuliUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saPrimeSimXFOptionwrite	string	saTestbench		PrimeSim option write: write file at the first point
saPrimeSimXFOptionwritefinal	string	saTestbench		PrimeSim option write_final: write file at the last point
saPrimeSimXFOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saPrimeSimXFOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saPrimeSimXFOutputType	string	saTestbench	Voltage	PrimeSim XF: Output Type
saPrimeSimXFParam	string	saTestbench		PrimeSim XF: Parameter being swept
saPrimeSimXFSpan	string	saTestbench		PrimeSim XF: Span between sweep limits
saPrimeSimXFStart	string	saTestbench		PrimeSim XF: Starting point of sweep limits
saPrimeSimXFStep	string	saTestbench		PrimeSim XF: Linear step size
saPrimeSimXFStepSpecLin	string	saTestbench	Number of Steps	PrimeSim XF: Method of specifying linear stepping ("Step Size" "Number of Steps")
saPrimeSimXFStepSpecLog	string	saTestbench	Points per Decade	PrimeSim XF: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saPrimeSimXFStop	string	saTestbench		PrimeSim XF: Stopping point of sweep limits
saPrimeSimXFSub	string	saTestbench		PrimeSim XF: Subcircuit with parameter being swept
saPrimeSimXFSweep	string	saTestbench	Logarithmic	PrimeSim XF: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saPrimeSimXFSweepSpec	string	saTestbench	<file path>	PrimeSim XF: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saPrimeSimXFSweepVar	string	saTestbench	Frequency (Hz)	PrimeSim XF: Specifies what will be swept ("Frequency (Hz)" "Design Variable" "Temperature")
saPrimeSimXFTextParam	string	saTestbench		PrimeSim XF: Parameter being swept.
saPrimeSimXFValues	string	saTestbench		PrimeSim XF: Individual values, also known as points of interest
saPrimeWaveGridJobSyncMtMp	bool	xtJobClass	false	PrimeWave Dynamic Job Distribution sync simulator -mt / mp setting.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saPrimeWaveGridJobSyncMtMp	bool	xtJobClass	false	PrimeWave Dynamic Job Distribution sync simulator -mt / mp setting. Valid values: true, false
saPrimeWaveJobClass	string	xtJobClass		PrimeWave Job class list
saPrintAfterEsc	bool	user	false	Print after all selections are made. Valid values: true, false
saPrintOPVertical	bool	user	false	Show OP dialog in vertical format when active. Valid values: true, false
saProbeOutputs	int	user	1	Enable probe auto-highlighting
saProhibitDuplicateOutputName	bool	user	false	Controls whether prohibit create duplicate output name
saRelImportCCAnalog	bool	user	false	Set default value of Analog attribute for reimporting (MS simulations). Valid values: true, false
saRelImportDigital	bool	user	false	Set default value of Digital attribute for reimporting. Valid values: true, false
saRelImportMixedSignal	bool	user	false	Set default value of Mixed-Signal attribute for reimporting. Valid values: true, false
saRelImportNetlist	bool	user	true	Set default value of Netlist attribute for reimporting. Valid values: true, false
saRelImportNLAnalog	bool	user	true	Set default value of Analog attribute for reimporting (Analog-only simulations). Valid values: true, false
saRemoteExportPath	bool	user	false	Remote site simulation export local path to remote
saRemoteSimDir	string	user	<file path>	Top-level results directory at remote site.
saRemoveDuplicatedCorners	bool	saSession	true	Remove duplicated corners when importing
saReplaceRunScriptCore	bool	user	false	Controls whether <code>sa::createRunScript</code> will replace the run script core completely. Valid values: true, false
saResetTestbenchOnDesignChange	bool	saTestbench	true	Reset testbench on design change. Valid values: true, false

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saResistanceMapDefault	string	user	false	Path to the default resistance map file (if blank, \$(which <analog simulator>)/../include/rmapAD.init is used).
saResultsDatabaseBlock	string	user		Results Database Block.
saResultsDatabaseConfig	string	user		Results Database Name.
saResultsDatabaseConnectionTimeout	string	user	30	Results Database Connection Timeout.
saResultsDatabaseDB	string	user		Results Database Name.
saResultsDatabaseHistory	int	user	10	Results Database Password.
saResultsDatabaseImagePromotionDirectory	string	user		Directory where images are promoted for saving promoted DB space.
saResultsDatabasePassword	string	user		Results Database Password.
saResultsDatabasePort	string	user	5432	Results Database Port.
saResultsDatabaseProcess	string	user		Results Database Process.
saResultsDatabaseProduct	string	user		Results Database Product.
saResultsDatabaseProject	string	user		Results Database Design.
saResultsDatabasePsqlPath	string	user	psql	Results Database psql Path.
saResultsDatabaseRelease	string	user		Results Database Release.
saResultsDatabaseRemoteDir	string	user		Results Database Remote Directory.
saResultsDatabaseRemoteHost	string	user		Results Database Remote Host.
saResultsDatabaseServer	string	user		Results Database Server.
saResultsDatabaseTransposeLimit	int	user	3800	Results Database Transpose Limit.
saResultsDatabaseUserName	string	user		Results Database User.
saResultsDir	string	saSession	~/simulation	Top-level results directory.
saResultsFavorites	string	saTestbench		Favorite functions in Plot Assist.
saResultsHistory	int	saTestbench	10	Results History.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saResultsQuickButtons	string	user	1/x abs sqrt x^2 exp db20 mag ymax	PrimeWave Design Environment Results Analyzer expression buttons.
saResultsQuickOperators	string	user	1/x inverse x^2 sqrd (x) parens	PrimeWave Design Environment Results Analyzer quick operators.
saResultsUpdaterFilterList	string	user	false	Libraries to be filtered out in the Timestamp Dashboard.
saResultsUpdaterShowOutdatedOnly	bool	user	false	PrimeWave Design Environment Results Analyzer expression buttons. Valid values: true, false
saResultsViewCornerDetails	bool	user	false	Controls the display of Corner details in the ResultsView
saResultsViewerAutoSpanParameterCell	string	user	{}	If false, not to span parameter rows in ResultsView Consolidated and Detail table.
saResultsViewerCombineSuffixUnit	bool	user	false	Show combined Suffix and Units in ResultsView table header. Valid values: true, false
saResultsViewerConsolidPassFailFilter	string	user	{}	Used to set the ResultsView consolidated table pass/fail filter.
saResultsViewerConsolidRotateType	string	user	{}	Used to set the ResultsView consolidated table rotate type.
saResultsViewerConsolidShowFilterRow	string	user	{}	If true, show filter row in ResultsView consolidated table.
saResultsViewerConsolidShowMinMax	string	user	{}	If true, show min/max in ResultsView consolidated table.
saResultsViewerConsolidShowParameter	string	user	{}	If true, show parameters in ResultsView consolidated table.
saResultsViewerConsolidShowViolationSpec	string	user	{}	If true, show violation and specification in ResultsView consolidated table.
saResultsViewerDefaultDisableColumn	string	user	{}	Used to set the ResultsView default disable the specified table column
saResultsViewerDefaultDisplayTable	string	user	Consolidated	Used to set the ResultsView default display table scoping priority to "Summary" or "Consolidated" or "Measurements".
saResultsViewerDefaultEnableColumn	string	user	{}	Used to set the ResultsView default enable the specified table column

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saResultsViewerDefaultPlotMode	string	user	{}	Used to set the ResultsView default plotting mode.
saResultsViewerFailColor	string	saSession	lightcoral	Color used to highlight failed results in the PrimeWave Design Environment ResultsView.
saResultsViewerFreezeCornerParameterRows	bool	user	true	Controls whether to freeze corner parameter rows in the ResultsView
saResultsViewerHideStatisticalViewColumns	string	user		List of columns in statistical view to be hidden.
saResultsViewerMarginalColor	string	saSession	yellow	Color used to highlight marginal results in the PrimeWave Design Environment ResultsView.
saResultsViewerMarginalFailColor	string	user	#f7bf40	Scalar Vector Graphic color name or RGB color for marginal fail values.
saResultsViewerMarginalPassColor	string	user	#c7f648	Scalar Vector Graphic color name or RGB color for marginal pass values.
saResultsViewerMaxAutoColumnWidth	int	user	999	Maximum automatic width of results viewer columns.
saResultsViewerMaxColor	string	user	red	Scalar Vector Graphic color name for maximum value of the measurement.
saResultsViewerMeasurementPassFailFilter	string	user	{}	Used to set the ResultsView measurement table pass/fail filter.
saResultsViewerMeasurementRotateType	string	user	{}	Used to set the ResultsView measurement table rotate type.
saResultsViewerMeasurementShowFilterRow	string	user	{}	If true, show filter row in ResultsView measurement table.
saResultsViewerMeasurementShowImages	string	user	{}	If true, show images in ResultsView measurement table.
saResultsViewerMeasurementShowMinMax	string	user	{}	If true, show min/max in ResultsView measurement table.
saResultsViewerMeasurementShowParameter	string	user	{}	If true, show parameters in ResultsView measurement table.
saResultsViewerMeasurementShowScalar	string	user	{}	If true, show scalar equations in ResultsView measurement table.
saResultsViewerMeasurementShowSignals	string	user	{}	If true, show probes in ResultsView measurement table.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saResultsViewerMeasurementShowViolSpec	string	user	{}	If true, show violation and specification in ResultsView measurement table.
saResultsViewerMeasurementShowWave	string	user	{}	If true, show wave equations in ResultsView measurement table.
saResultsViewerMinColor	string	user	lightblue	Scalar Vector Graphic color name for minimum value of the measurement.
saResultsViewerModelFileTrimLeft	bool	user	false	Trim left side of model file names to fit in header. Valid values: true, false
saResultsViewerPassColor	string	saSession	lightgreen	Color used to highlight failed results in the PrimeWave Design Environment ResultsView.
saResultsViewerProcessCapabilityColumns	string	user		List of Process Capability Columns to be shown in ResultsView. Valid values: Cp, Cpm, Cpk, Cpkm
saResultsViewerResizeColumns	int	user	0	Controls whether to resize columns to fit all contents in the ResultsView. A value of 0 uses the default column size. A value of 1 resizes columns to fit all contents. Valid values: 0, 1
saResultsViewerSeparateAnalyses	bool	user	false	Controls whether to separate analyses in different columns in the ResultsView.
saResultsViewerShowDescriptionColumn	bool	user	false	Controls whether or not to show equation Description column in the ResultsView tool.
saResultsViewerStatisticShowCapabilities	string	user	{}	If true, show Cp/Cpk/Cpm/Cpkm in ResultsView statistic table.
saResultsViewerVarianceIntervals	string	user	3 4 5	List of variance interval shown in the ResultsView.
saResultsViewImages	bool	user	false	Controls the display of images in the ResultsView. Valid values: true, false
saResultsViewWaveforms	bool	user	false	Controls the display of waveforms in the ResultsView
saRunDirDelimiter	string	user	,	Default delimiter for the run directory.
saSaveAllMonteCarloImages	bool	user	false	Save images for all iterations of top-level Monte Carlo simulations. Valid values: true, false
saSaveAllStateItems	bool	xtJobClass	false	Save all items in categories in Save State dialog

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSaveChartImagesDrawSpecRegions	bool	user	true	Controls whether specification regions should be drawn. Valid values: true, false
saSaveCornerImages	bool	user	true	Save images for corner simulations. Valid values: true, false
saSaveCornerMonteCarloImages	bool	user	false	Save images for Monte Carlo simulations nested within corners. Valid values: true, false
saSaveCornerSweepImages	bool	user	false	Save images for sweep simulations nested within corners. Valid values: true, false
saSaveHistoryPointPath	string	saSession		saSaveHistoryPointPath
saSaveModelParameters	bool	user	false	If true, save the model parameter values in the output file.
saSaveMonteCarloImages	bool	user	true	Save images for Monte Carlo simulations. Valid values: true, false
saSaveMC0ParamsInCorner	bool	user	true	Save the .mc0 parameters in the corner. When netlisting, they'll be directly written in the netlist. If set to false, save the path to the .mc0 file and include it as include file in the netlist
saSaveNetlist	bool	user	true	Controls to whether save simulation results (netlist files) Valid values: true, false
saSaveSimulationData	bool	user	true	Controls whether to save simulation results (waveform files) Valid values: true, false
saSaveSimulationResults	bool	user	true	Controls whether to save simulation results (waveform file/netlist) Valid values: true, false
saSaveStateCellFilter	saSaveStateCellFilterEnum	saSession	hide	Target cell filter when saving state to openaccess (choices are: widget value; show - decide automatically; hide - no widgets and decide automatically). Valid values: hide show Design {Opened State} All
saSaveStateChangeTestbenchName	bool	saSession	true	Change testbench's name to be the name of state being saved from PrimeWave Design Environment. Valid values: true, false

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSaveStateDmCell	string	saSession		DmCell under which PrimeWave Design Environment state is to be saved.
saSaveStateMoveSimDir	bool	saSession	false	Move the simulation results.
saSaveStateName	string	saSession		Name of state being saved from PrimeWave Design Environment.
saSaveStateOptions	string	saSession	true	Default value for whether the Options groupbox in the Save State dialog is expanded.
saSaveStatePrompt	bool	saSession	true	Prompt for saving modified testbenches. Valid values: true, false
saSaveStateSaveHistoryOptions	bool	saSession	true	Save history options of the session to the saved state.
saSaveStateSaveResultsDir	bool	saSession	true	Show save results directory field on the PrimeWave Design Environment Save State dialog. Valid values: true, false
saSaveStateShowOptions	bool	saSession	false	Valid values: true, false
saSaveStateTo	string	saSession	OpenAccess	Storage mechanism to hold the PrimeWave Design Environment state.
saSaveSummaryImages	bool	user	true	Save images for summary family plots. Valid values: true, false
saSaveSweepImages	bool	user	true	Save images for sweep simulations. Valid values: true, false
saSaveSweepMonteCarloImages	bool	user	true	Save images for Monte Carlo simulations nested within sweeps. Valid values: true, false
saSchematicInteractivePickType	string	user	Terminal Current	Schematic Pick type
saScratchDirNew	string	user	<file path>	Scratch directory to run simulations on local-disk
saScratchNetworkDir	string	user		Mapped network directory pattern to the local-disk scratch directory of simulation
saSequentialRunStrictDependency Check	bool	user	true	If set to true, the PrimeWave Design Environment will not run simulation if unknown outputs are found during dependency check. Valid values: true, false

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSharedSetupStateCategories	string	saSession	cornersSetup designVariables monteCarlo models outputs sweeps temperature	List of categories to load from shared setup state
saShortenCornerParamNamesInReport	bool	user	false	Flag to show the prefixes 'Corner:Model' and 'Corner:variable' to the corner parameter names in the CSV/HTML header Valid values: true, false
saShowDesignOpenPromptCellView	bool	saSession	true	Open the top-level cellview in the design window
saShowDesignOpenPromptConfig	bool	saSession	false	Open the config in the Hierarchy Editor. Valid values: true, false
saShowFilterRow	bool	user	false	Show Filter row in Output table and Design Variables table. Valid values: true, false Valid values: true, false
saShowFullModelFilePath	bool	user	true	When set to False (0), so that you won't see the full path. You can see the path by the tooltip. Put your mouse on the parameter and you can see it.
saShowHistoryDirectoryInHistoryManager	bool	user	true	Show the history directory name in the history manager. Valid values: true, false
saShowImportLogFile	bool	user	false	Show the Import Log File upon Import Complete. Valid values: true, false
saShowIncludeGroupTable	bool	user	true	Show Include Group table in Include Files dialog box. Valid values: true, false
saShowIncRV	bool	user	false	Show ResultsView incrementally Valid values: true, false
saShowJobMonitor	bool	user	true	Show Job Monitor during Simulation Run.
saShowLoadResultsPath	string	saSession	???	Path of PrimeWave Design Environment results to load into testbench.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saShowModelGroupTable	bool	user	true	Show Model Group table in Model Files dialog. Valid values: true, false
saShowOutputAnalysesColumn	bool	saTestbench	true	Shows the analyses column in Outputs table. Valid values: true, false
saShowOutputDescriptionColumn	bool	saTestbench	false	Show description column in Outputs table
saShowOutputExprColumn	bool	saTestbench	true	Shows the expression column in Outputs table. Valid values: true, false
saShowOutputNameColumn	bool	saTestbench	true	Shows the name column in Outputs table. Valid values: true, false
saShowOutputPlotColorColumn	bool	saTestbench	true	Show plot color column in Outputs table Valid values: true, false
saShowOutputPlotColumn	bool	saTestbench	true	Shows the plot column in Outputs table. Valid values: true, false
saShowOutputPlotTypeColumn	bool	saTestbench	false	Shows the plot type column in Outputs table. Valid values: true, false
saShowOutputResultsViewerColumn	bool	saTestbench	true	Shows the results viewer column in Outputs table. Valid values: true, false
saShowOutputRowHeader	bool	user	false	Show row header in Outputs table
saShowOutputSaveColumn	bool	saTestbench	true	Shows the save column in Outputs table. Valid values: true, false
saShowOutputSuffixColumn	bool	saTestbench	false	Show suffix column in Outputs table
saShowOutputUnitsColumn	bool	saTestbench	false	Show units column in Outputs table
saShowOutputValueColumn	bool	saTestbench	true	Shows the value column in Outputs table. Valid values: true, false
saShowPassedInformInSimulationCheckViewer	bool	user	false	Shows Passed Information in Simulation Check Viewer (Assert type) . Valid values: true, false
saShowRibbonInRV	bool	user	false	Controls whether show ribbon in ResultsView. Valid values: true, false

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saShowSaveImageColumn	bool	saTestbench	true	Shows the save image column in Outputs table. Valid values: true, false
saShowSeqRunDialog	bool	user	true	Show Sequential Run dialog when Sequential Run is started. Valid values: true, false
saShowTableNavigationButtons	bool	user	false	Show table navigation buttons Valid values: true, false
saShowWebReport	bool	user	true	Show the Web Report File in a Web Viewer Tab. Valid values: true, false
saSimChangeReset	bool	user	false	Resets all testbench categories to defaults when changing simulator. Valid values: true, false
saSimulationCheckFilePatterns	string	saTestbench	*.bias* *.chk* *.tsoa* *.assert*	Bias/Circuit check file extensions.
saSimulationEngine	saDefaultEngineEnum	user	PrimeSimSPICE	Used to set the engine for PrimeSim. Valid values: PrimeSimSPICE PrimeSimPro PrimeSimHSPICE PrimeSimXA PrimeSimSPICEVCS PrimeSimProVCS PrimeSimXAVCS
saSimulationJobClass	string	xtJobClass	Simulation	Simulation job class name.
saSimulationJobLaunchInterval	int	user	10	Wait time launching jobs when user Netlist and Run
saSimulator	string	saTestbench	PrimeSim	Simulator to be used.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSimulatorList	string	user	HSPICE Spectre FineSim Pro HSIMHSP ICE XAHSPICE XASpectre FineSimPr oVCS PrimeSim PrimeSim VCS PrimeSi mXA XAVCSHS PICE	List of simulators to be shown in Select Simulator dialog.
saSpectreACCenter	string	saTestbench		Spectre AC: Center point of sweep limits
saSpectreACDec	string	saTestbench		Spectre AC: Number of logarithmic steps per decade
saSpectreACDesignVar	string	saTestbench		Spectre AC: Design variable being swept
saSpectreACDev	string	saTestbench		Spectre AC: Instance with parameter being swept
saSpectreACFreq	string	saTestbench		Spectre AC: Single value to hold frequency while other aspect is being swept
saSpectreACLin	string	saTestbench		Spectre AC: Number of linear steps
saSpectreACLog	string	saTestbench		Spectre AC: Total number of logarithmic steps
saSpectreACMATCHCenter	string	saTestbench		Spectre ACMATCH: Center point of sweep limits
saSpectreACMATCHDec	string	saTestbench		Spectre ACMATCH: Number of logarithmic steps per decade
saSpectreACMATCHLin	string	saTestbench		Spectre ACMATCH: Number of linear steps
saSpectreACMATCHLog	string	saTestbench		Spectre ACMATCH: Total number of logarithmic steps
saSpectreACMATCHMth	string	saTestbench		Spectre AC Match : Threshold

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreACMATCHNegNode	string	saTestbench		Spectre AC Match sweep: Negative output node
saSpectreACMATCHNode	string	saTestbench		Spectre AC Match sweep: Positive output node
saSpectreACMATCHOprobe	string	saTestbench		Spectre AC Match: Compute mismatch at the output defined by this component
saSpectreACMATCHOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, and steps.
saSpectreACMATCHOptionannotateUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saSpectreACMATCHOptionforce	string	custom	none	Spectre option force: The set of initial conditions to use. Possible values are none, node, dev, and all.
saSpectreACMATCHOptionforceUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saSpectreACMATCHOptiongroupby	string	custom	param	Spectre option groupby: Choose the way of how to group the total sigma. Total sigma of each contributor can be grouped either by statistics parameters or by subckt instances. Possible values are param and inst.
saSpectreACMATCHOptiongroupbyUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saSpectreACMATCHOptionoppoint	string	custom	no	Spectre option oppoint: Determines whether operating point information should be computed. If yes, specifies where should it be printed (screen or file). Operating point information is not printed if the operating point computed in the previous analysis remains unchanged. Possible values are no, screen, logfile, and rawfile.
saSpectreACMATCHOptionoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACMATCHOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreACMATCHOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACMATCHOptionprevop point	string	custom	no	Spectre option prevoppoint: Determines whether to use the operating point computed in the previous analysis. Possible values are no and yes.
saSpectreACMATCHOptionprevop pointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACMATCHOptionreadforce	string	custom		Spectre option readforce: File that contains the initial conditions.
saSpectreACMATCHOptionreadforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACMATCHOptionreadns	string	custom		Spectre option readns: File that contains an estimate of DC solution (nodeset).
saSpectreACMATCHOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACMATCHOptionrestart	string	custom	yes	Spectre option restart: Restart the DC solution from scratch if any condition has changed. If not, use the previous solution as an initial guess. Possible values are no and yes.
saSpectreACMATCHOptionrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACMATCHOptionsave	string	custom		Spectre option save: Signal levels in output. Possible values are all, lvl, allpub, lvlpub, selected, none, and nooutput.
saSpectreACMATCHOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACMATCHOptionskipdc	string	custom	no	Spectre option skipdc: Skip DC analysis. Possible values are no and yes.
saSpectreACMATCHOptionskipdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACMATCHOptiontitle	string	custom		Spectre option title: Analysis title.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreACMATCHOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACMATCHOptionuseprevic	string	custom	no	Spectre option useprevic: If set to yes or ns, use the converged initial condition from the previous analysis as ic or ns. Possible values are no, yes, and ns.
saSpectreACMATCHOptionuseprevicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACMATCHOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectreACMATCHOptionwrite	string	custom		Spectre option write: DC operating point output file at the first step of the sweep.
saSpectreACMATCHOptionwritefinal	string	custom		Spectre option writefinal: DC operating point output file at the last step of the sweep.
saSpectreACMATCHOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACMATCHOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACMATCHOutputType	string	saTestbench	Voltage	Spectre AC MATCH: Output Type.
saSpectreACMATCHSpan	string	saTestbench		Spectre ACMATCH: Span between sweep limits.
saSpectreACMATCHStart	string	saTestbench		Spectre ACMATCH: Starting point of sweep limits.
saSpectreACMATCHStep	string	saTestbench		Spectre ACMATCH: Linear step size.
saSpectreACMATCHStepSpecLin	string	saTestbench	Number of Steps	Spectre ACMATCH: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreACMATCHStepSpecLog	string	saTestbench	Points per Decade	Spectre ACMATCH: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectreACMATCHStop	string	saTestbench		Spectre ACMATCH: Stopping point of sweep limits.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreACMATCHSweep	string	saTestbench	Logarithmic	Spectre ACMATCH: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectreACMATCHSweepSpec	string	saTestbench	<file path>	Spectre ACMATCH: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectreACMATCHValues	string	saTestbench		Spectre ACMATCH: Individual values, also known as points of interest.
saSpectreACMATCHValuesfile	string	saTestbench		Spectre ACMATCH: File for individual values
saSpectreACMod	string	saTestbench		Spectre AC: Model with parameter being swept.
saSpectreACOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptioncontriblist	string	custom		Spectre option contriblist: Array of device names for distortion summary. When contriblist=[""], distortion from each non-linear device is calculated.
saSpectreACOptioncontriblistUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionfimout	string	custom	0	Spectre option fim_out: Frequency of IM output signal.
saSpectreACOptionfimoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionflinout	string	custom	0	Spectre option flin_out: Frequency of linear output signal.
saSpectreACOptionflinoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionforce	string	custom	none	Spectre option force: The set of initial conditions to use. Valid values: none, node, dev, and all.
saSpectreACOptionforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreACOptionmaxharmnonlin	string	custom	4	Spectre option maxharm_nonlin: Maximum harmonics of input signal frequency induced by non-linear effect.
saSpectreACOptionmaxharmnonlinUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionout1	string	custom		Spectre option out1: Output signal 1.
saSpectreACOptionout1UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionout2	string	custom		Spectre option out2: Output signal 2.
saSpectreACOptionout2UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionperturbation	string	custom	linear	Spectre option perturbation: The type of AC analysis. Default is linear for normal AC analysis. im2ds is for im2 distortion summary and ds is for distortion summary. Valid values: linear, ds, ip3, ip2, im2ds, multiple_beat, and triple_beat.
saSpectreACOptionperturbationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionprevoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionreadforce	string	custom		Spectre option readforce: File that contains initial conditions.
saSpectreACOptionreadforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreACOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionrf1src	string	custom		Spectre option rf1_src: Array of RF1 source names for IP3/IP2/IM2DistortionSummary.
saSpectreACOptionrf1srcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionrf2src	string	custom		Spectre option rf2_src: Array of RF2 source names for IP3/IP2/IM2DistortionSummary.
saSpectreACOptionrf2srcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionrfdbm	string	custom	0	Spectre option rfdbm: RF source dBm.
saSpectreACOptionrfdbmUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionrfmag	string	custom	0	Spectre option rfmag: RF source magnitude.
saSpectreACOptionrfmagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionskipdc	string	custom	no	Spectre option skipdc: Skip DC analysis. Valid values: no and yes.
saSpectreACOptionskipdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreACOptionuseprevic	string	custom	no	Spectre option useprevic: If set to yes or ns, use the converged initial condition from previous analysis as ic or ns. Valid values: no, yes, and ns.
saSpectreACOptionuseprevicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectreACOptionwrite	string	custom		Spectre option write: DC operating point output file at the first step of the sweep.
saSpectreACOptionwritefinal	string	custom		Spectre option writefinal: DC operating point output file at the last step of the sweep.
saSpectreACOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreACParam	string	saTestbench		Spectre AC: Parameter being swept.
saSpectreACSpan	string	saTestbench		Spectre AC: Span between sweep limits.
saSpectreACStart	string	saTestbench		Spectre AC: Starting point of sweep limits.
saSpectreACStep	string	saTestbench		Spectre AC: Linear step size.
saSpectreACStepSpecLin	string	saTestbench	Number of Steps	Spectre AC: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreACStepSpecLog	string	saTestbench	Points per Decade	Spectre AC: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectreACStop	string	saTestbench		Spectre AC: Stopping point of sweep limits.
saSpectreACSub	string	saTestbench		Spectre AC: Subcircuit with parameter being swept.
saSpectreACSweep	string	saTestbench	Logarithmic	Spectre AC: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreAC SweepSpec	string	saTestbench	<file path>	Spectre AC: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectreAC SweepType	string	saTestbench	Linear	Spectre AC sweep Sweep type.
saSpectreAC SweepVar	string	saTestbench	Frequency (Hz)	Spectre AC: Specifies what will be swept ("Frequency (Hz)" "Design Variable" "Temperature" "Instance Parameter" "Model Parameter" "Subcircuit Parameter" "None").
saSpectreACValues	string	saTestbench		Spectre AC: Individual values, also known as points of interest.
saSpectreACValuesfile	string	saTestbench		Spectre AC: File for individual values
saSpectreAlwaysSaveSelectedOutputs	bool	user	false	Always write the save statement for saving the selected signals Valid values: true, false
saSpectreAnalysesImport	string	saTestbench	Import	Spectre analyses Import Setting.
saSpectreConvergenceAidsImport	string	saTestbench	Import	Spectre convergenceAids Import Setting.
saSpectreDataImport	string	saTestbench	Include	Spectre data Import Setting.
saSpectreDCCenter	string	saTestbench		Spectre DC: Center point of sweep limits.
saSpectreDCDec	string	saTestbench		Spectre DC: Number of logarithmic steps per decade.
saSpectreDCDesignVar	string	saTestbench		Spectre DC: Design variable being swept.
saSpectreDCDev	string	saTestbench		Spectre DC sweep: Instance containing parameter to sweep.
saSpectreDCDoSweep	string	saTestbench	0	Spectre DC: Flag indicating a sweep is to be performed.
saSpectreDCLin	string	saTestbench		Spectre DC: Number of linear steps.
saSpectreDCLog	string	saTestbench		Spectre DC: Total number of logarithmic steps.
saSpectreDCMATCHCenter	string	saTestbench		Spectre DCMATCH: Center point of sweep limits.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreDCMATCHDec	string	saTestbench		Spectre DCMATCH: Number of logarithmic steps per decade.
saSpectreDCMATCHDesignVar	string	saTestbench		Spectre DCMATCH: Design variable being swept.
saSpectreDCMATCHDev	string	saTestbench		Spectre DCMATCH: Instance with parameter being swept.
saSpectreDCMATCHDoSweep	string	saTestbench	1	Spectre DCMATCH: Flag indicating a sweep is to be performed.
saSpectreDCMATCHLin	string	saTestbench		Spectre DCMATCH: Number of linear steps.
saSpectreDCMATCHLog	string	saTestbench		Spectre DCMATCH: Total number of logarithmic steps.
saSpectreDCMATCHMethod	string	saTestbench	standard	Spectre DCMATCH: Method.
saSpectreDCMATCHMod	string	saTestbench		Spectre DCMATCH: Model with parameter being swept.
saSpectreDCMATCHMth	string	saTestbench		Spectre DCMATCH: Threshold.
saSpectreDCMATCHNegNode	string	saTestbench		Spectre DCMATCH Negative output node.
saSpectreDCMATCHNode	string	saTestbench		Spectre DCMATCH: Positive output node.
saSpectreDCMATCHNSigma	string	saTestbench		Spectre DCMATCH: N Sigma.
saSpectreDCMATCHOprobe	string	saTestbench		Spectre DCMATCH: Compute mismatch at the output defined by this component.
saSpectreDCMATCHOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, and steps.
saSpectreDCMATCHOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCMATCHOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.
saSpectreDCMATCHOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreDCMATCHOptionoppo int	string	custom	no	Spectre option oppoint: Determines whether the operating point information should be computed. If yes, where should it be printed (screen or file). Operating point information is not printed in case of the following conditions: (1) operating point is computed in the previous analysis and is unchanged (2) sweep parameter param is set. Possible values are no, screen, logfile, and rawfile.
saSpectreDCMATCHOptionoppoin tUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCMATCHOptionotherO ptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saSpectreDCMATCHOptionotherO ptionsUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCMATCHOptionporti	string	custom		Spectre option porti: Current through this probe port is output of the analysis.
saSpectreDCMATCHOptionportiU ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCMATCHOptionportv	string	custom		Spectre option portv: Voltage across this probe port is output of the analysis.
saSpectreDCMATCHOptionportvU ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCMATCHOptionprevop point	string	custom	no	Spectre option prevoppoint: Use operating point computed on the previous analysis. Possible values are no and yes.
saSpectreDCMATCHOptionprevop pointUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCMATCHOptionreadns	string	custom		Spectre option readns: File that contains an estimate of DC solution (nodeset).
saSpectreDCMATCHOptionreadns UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreDCMATCHOptionrestart	string	custom	yes	Spectre option restart: Restart the DC solution from scratch if any condition has changed. If not, use the previous solution as initial guess. Possible values are no and yes.
saSpectreDCMATCHOptionrestart UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCMATCHOptionsave	string	custom		Spectre option save: Signals to output. Possible values are all, lvl, allpub, lvlpub, selected, none, and nooutput.
saSpectreDCMATCHOptionsaveU ncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCMATCHOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectreDCMATCHOptiontitleUn checkLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCMATCHOptionusepre vic	string	custom	no	Spectre option useprevic: If set to yes or ns, use the converged initial condition from previous analysis as ic or ns. Possible values are no, yes, and ns.
saSpectreDCMATCHOptionusepre vicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCMATCHOptionvalues file	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectreDCMATCHOptionvariati ons	string	custom	all	Spectre option variations: Selects the type of statistical parameters that are involved in dcmatch. The option is valid only if method=statistics. Possible values are process, mismatch, and all.
saSpectreDCMATCHOptionvariati onsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreDCMATCHOptionversion	string	custom	0	Spectre option version: Use BSIM short-channel mismatch equation for BSIM3 and BSIM4 devices, if the value is set to 1 and 3. If set to 0 and 2, do not use BSIM short-channel mismatch equation. Values 2 and 3 are compatible with Monte Carlo analysis while 0 and 1 are not. This option works only when method=standard. Possible values are 0 to 3.
saSpectreDCMATCHOptionversionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCMATCHOutputType	string	saTestbench	Voltage	Spectre DC MATCH: Output Type.
saSpectreDCMATCHParam	string	saTestbench		Spectre DCMATCH: Parameter being swept.
saSpectreDCMATCHSpan	string	saTestbench		Spectre DCMATCH: Span between sweep limits.
saSpectreDCMATCHStart	string	saTestbench		Spectre DCMATCH: Starting point of sweep limits.
saSpectreDCMATCHStep	string	saTestbench		Spectre DCMATCH: Linear step size.
saSpectreDCMATCHStepSpecLin	string	saTestbench	Number of Steps	Spectre DCMATCH: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreDCMATCHStepSpecLog	string	saTestbench	Points per Decade	Spectre DCMATCH: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectreDCMATCHStop	string	saTestbench		Spectre DCMATCH: Stopping point of sweep limits.
saSpectreDCMATCHSub	string	saTestbench		Spectre DCMATCH: Subcircuit with parameter being swept.
saSpectreDCMATCHSweep	string	saTestbench	Linear	Spectre DCMATCH: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectreDCMATCHSweepSpec	string	saTestbench	<file path>	Spectre DCMATCH: Method of specifying sweep limits ("Start/Stop" "Center/Span").

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreDCMATCHSweepVar	string	saTestbench	Temperature	Spectre DCMATCH: Specifies what will be swept ("Design Variable" "Temperature" "Instance Parameter" "Model Parameter" "Subcircuit Parameter").
saSpectreDCMATCHValues	string	saTestbench		Spectre DCMATCH: Individual values, also known as points of interest.
saSpectreDCMATCHValuesfile	string	saTestbench		Spectre DCMATCH: File for individual values
saSpectreDCMod	string	saTestbench		Spectre DC: Model with parameter being swept.
saSpectreDCOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptioncheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionemirfile	string	custom		Spectre option emirfile: Name of the EM/IR database file. The default is '%A_emir_vavo.db'. The file is printed to a raw directory.
saSpectreDCOptionemirfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionemirformat	string	custom	none	Spectre option emirformat: Format of the EM/IR database file. Valid values: none and vavo.
saSpectreDCOptionemirformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionhomotopyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionhysteresis	string	custom	no	Spectre option hysteresis: Perform DC hysteresis sweep. When set to yes, a reverse sweep will automatically be added to the DC sweep. Valid values: no and yes.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreDCOptionhysteresisUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionmaxitersUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionmaxstepsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionnewton	string	custom	normal	Spectre option newton: Users can specify newton methods such as newton=none, and newton=normal. Valid values: none and normal.
saSpectreDCOptionnewtonUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionprintUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionreadforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionreadhnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionswpuseprevic	string	custom	yes	Spectre option swpuseprevic: DC sweep uses the solution of previous point as starting point. Valid values: no and yes.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreDCOptionswpuseprevicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionuseprevic	string	custom	no	Spectre option useprevic: If set to yes or ns, use the converged initial condition from previous analysis as ic or ns. Valid values: no, yes, and ns.
saSpectreDCOptionuseprevicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectreDCOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreDCParam	string	saTestbench		Spectre DC sweep: Parameter to sweep.
saSpectreDCSaveOP	string	saTestbench	1	Spectre DC sweep: Save DC Operating Point.
saSpectreDCSpan	string	saTestbench		Spectre DC: Span between sweep limits.
saSpectreDCStart	string	saTestbench		Spectre DC: Starting point of sweep limits.
saSpectreDCStep	string	saTestbench		Spectre DC: Linear step size.
saSpectreDCStepSpecLin	string	saTestbench	Number of Steps	Spectre DC: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreDCStepSpecLog	string	saTestbench	Points per Decade	Spectre DC: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectreDCStop	string	saTestbench		Spectre DC: Stopping point of sweep limits.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreDCSub	string	saTestbench		Spectre DC: Subcircuit with parameter being swept.
saSpectreDCSweep	string	saTestbench	Linear	Spectre DC: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectreDCSweepSpec	string	saTestbench	<file path>	Spectre DC: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectreDCSweepType	string	saTestbench	Linear	Spectre DC sweep: Sweep type.
saSpectreDCSweepVar	string	saTestbench	Temperature	Spectre DC: Specifies what will be swept ("Design Variable" "Temperature" "Instance Parameter" "Model Parameter" "Subcircuit Parameter").
saSpectreDCValues	string	saTestbench		Spectre DC: Individual values, also known as points of interest.
saSpectreDCValuesfile	string	saTestbench		Spectre DC: File for individual values
saSpectreDefaultCornersSetup	string	saTestbench		Spectre default corners setup.
saSpectreDefaultCurrentType	saSpectreCurrentTypeEnum	user	Peak	The default current type in RA. Valid values: RMS, Peak
saSpectreDefaultModelFiles	string	saTestbench		Spectre default model files to be loaded.
saSpectreDefaultPowerType	saSpectrePowerTypeEnum	user	RMS	The default power type in RA Valid values: RMS Peak
saSpectreDefaultVoltageType	saSpectreVoltageTypeEnum	user	Peak	The default voltage type in RA. Valid values: RMS, Peak
saSpectreDiffStbProbeFile	string	user		Spectre diffstbprobe file path
saSpectreEnableSimulatorResultsXML	bool	user	false	Enables Spectre to write the resulting XML file.
saSpectreEnableSubcktInfoParser	bool	user	false	Enable the parser to read subckt info for plotting the terminal currents of the macro devices. Valid values: true, false

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreENVLPClockname	string	saTestbench		Spectre ENVLP: Clock Name.
saSpectreENVLPDec	string	saTestbench		Spectre ENVLP: Fast Mode Noise Sweep Points Per Decade.
saSpectreENVLPEngine	string	saTestbench	Harmonic Balance	Spectre ENVLP: Which engine to run.
saSpectreENVLPErrpreset	string	saTestbench	moderate	Spectre ENVLP: errpreset.
saSpectreENVLPFastmethod	string	saTestbench	passband	Spectre ENVLP: Fast Method.
saSpectreENVLPFastmode	string	saTestbench	0	Spectre ENVLP: Invoke fast mode.
saSpectreENVLPFixstepsize	string	saTestbench	0	Spectre ENVLP: Fixed Time-Step Mode.
saSpectreENVLPFreqdivide	string	saTestbench		Spectre ENVLP: Large Signal freqdivide Ratio.
saSpectreENVLPFreqMode	string	saTestbench	Name	Spectre ENVLP: Tone mode for netlisting.
saSpectreENVLPFreqPeriod	string	saTestbench	Frequency	Spectre ENVLP: Declaring the Frequency or Period.
saSpectreENVLPFstart	string	saTestbench		Spectre ENVLP: Fast Mode Noise Starting Frequency.
saSpectreENVLPFund	string	saTestbench		Spectre ENVLP: Frequency.
saSpectreENVLPHarms	string	saTestbench	1	Spectre ENVLP: Maximum Number of Harmonics.
saSpectreENVLPHarmsMode	string	saTestbench	Maximum	Spectre ENVLP: Harmonics Mode.
saSpectreENVLPHarmsvec	string	saTestbench		Spectre ENVLP: Harmonics Vector.
saSpectreENVLPLin	string	saTestbench		Spectre ENVLP: Fast Mode Noise Sweep Linear Steps.
saSpectreENVLPMaxharm	string	saTestbench	2	Spectre ENVLP: Tones Table 'MaxHrm' Column.
saSpectreENVLPNoisemethod	string	saTestbench	off	Spectre ENVLP: Fast Mode Noise Mode.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreENVLPNoiseSweepType	string	saTestbench	Lin	Spectre ENVLP: Fast Mode Noise Sweep Type.
saSpectreENVLPOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, and steps.
saSpectreENVLPOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptioncircuitage	string	custom		Spectre option circuitage: Stress time. Age of the circuit used to simulate hot-electron degradation of MOSFET and BSIM circuits.
saSpectreENVLPOptioncircuitageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionclockname	string	custom		Spectre option clockname: Name of the clock fundamental.
saSpectreENVLPOptionclocknameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptioncmin	string	custom	0	Spectre option cmin: Minimum capacitance from each node to ground.
saSpectreENVLPOptioncminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptioncompression	string	custom	no	Spectre option compression: Perform data compression on output. Possible values are no and yes.
saSpectreENVLPOptioncompressionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionenvliteration	string	custom		Spectre option envliteration: Ratio used to compute envelope LTE tolerances. Default is derived from `errpreset`.
saSpectreENVLPOptionenvliterationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreENVLPOptionenvmaxiters	string	custom		Spectre option envmaxiters: Maximum number of Newton iterations per envelope step. For time domain Shooting envelope, the default is 3. For Harmonic Balance Envelope, the default is 40.
saSpectreENVLPOptionenvmaxitersUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionenvmaxstep	string	custom		Spectre option envmaxstep: Maximum outer envelope step size. Default is derived from 'errpreset'.
saSpectreENVLPOptionenvmaxstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionenvmethod	string	custom	gear2only	Spectre option envmethod: Envelope Integration method. Possible values are euler, trap, traponly, gear2, gear2only, and trapgear2.
saSpectreENVLPOptionenvmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionfixstepsize	string	custom	no	Spectre option fixstepsize: Use this option to fix envelope step size for speeding up envelope analysis. Possible values are no and yes.
saSpectreENVLPOptionfixstepsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionfmspeedup	string	custom	0	Spectre option fmspeedup: The level to speed up the envelope analysis for frequency modulated signal. Default is 0 for standard envelope following and 1 for fmod sources speed up.
saSpectreENVLPOptionfmspeedupUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionic	string	custom	all	Spectre option ic: What should be used to set initial condition. Possible values are dc, node, dev, and all.
saSpectreENVLPOptionicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreENVLPOptioninexactNewton	string	custom	no	Spectre option inexactNewton: Inexact Newton method. Possible values are no and yes.
saSpectreENVLPOptioninexactNewtonUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionitres	string	custom	1e-2	Spectre option itres: Relative tolerance for linear solver.
saSpectreENVLPOptionitresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionlteratio	string	custom		Spectre option lteratio: Ratio used to compute LTE tolerances from Newton tolerance. Default is derived from `errpreset`.
saSpectreENVLPOptionlteratioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionmaxiters	string	custom	5	Spectre option maxiters: Maximum number of Newton iterations per transient integration time step.
saSpectreENVLPOptionmaxitersUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionmaxstep	string	custom		Spectre option maxstep: Maximum time step for inner transient integration. Default is derived from `errpreset`.
saSpectreENVLPOptionmaxstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionmethod	string	custom	gear2only	Spectre option method: Inner transient integration method. Possible values are euler, trap, traponly, gear2, gear2only, and trapgear2.
saSpectreENVLPOptionmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionmodulationbw	string	custom		Spectre option modulationbw: Modulation bandwidth.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreENVLPOptionmodulationbwUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.
saSpectreENVLPOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saSpectreENVLPOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionoutputstart	string	custom	start	Spectre option outputstart: Output is saved only after this time is reached.
saSpectreENVLPOptionoutputstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionoutputtype	string	custom	both	Spectre option outputtype: Output type. Possible values are both, envelope, and spectrum.
saSpectreENVLPOptionoutputtypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionoversamplefactor	string	custom	1	Spectre option oversamplefactor: Oversample sample device evaluations for Harmonic Balance Envelope.
saSpectreENVLPOptionoversamplefactorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionpacnames	string	custom	[...]	Spectre option pacnames: Names of pac, pnoise, psp, or pxf analyses to be performed at each time point in the 'pactimes' array. Not for AMS.
saSpectreENVLPOptionpacnamesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreENVLPOptionpactimes	string	custom	[...]	Spectre option pactimes: Times when analyses specified in 'pacnames' array are performed. Not for AMS.
saSpectreENVLPOptionpactimesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionreadenv	string	custom		Spectre option readenv: File from which fast mode envelope data is read. It can be used only if the circuit remains unchanged after the file is created, except for the decrease in 'srci' or 'srcq' scale. Can only be used in fast envelope.
saSpectreENVLPOptionreadenvUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionreadic	string	custom		Spectre option readic: File that contains initial transient condition.
saSpectreENVLPOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionreadns	string	custom		Spectre option readns: File that contains estimate of initial DC solution.
saSpectreENVLPOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionrecover	string	custom		Spectre option recover: Specify the file to be restored.
saSpectreENVLPOptionrecoverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionrelref	string	custom		Spectre option relref: Reference used for the relative convergence criteria. Default is derived from 'errpreset'. Possible values are pointlocal, alllocal, sigglobal, and allglobal.
saSpectreENVLPOptionrelrefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionresolutionbw	string	custom		Spectre option resolutionbw: Resolution bandwidth: if set, overwrites the stoptime to be at least 1/resolutionbw.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreENVLPOptionresolutionbwUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionrestart	string	custom	no	Spectre option restart: Restart the DC solution from scratch if any condition has changed. If not, use the previous solution as initial guess. Possible values are no and yes.
saSpectreENVLPOptionrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionsave	string	custom		Spectre option save: Signals to output. Possible values are all, lvl, allpub, lvlpub, selected, none, and nooutput.
saSpectreENVLPOptionsaveclock	string	custom	1800	Spectre option saveclock: Save the tran analysis periodically on the wall clock time.
saSpectreENVLPOptionsaveclockUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionsavefile	string	custom		Spectre option savefile: Save the analysis states into the specified file.
saSpectreENVLPOptionsavefileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionsaveperiod	string	custom		Spectre option saveperiod: Save the tran analysis periodically on the simulation time.
saSpectreENVLPOptionsaveperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionsavetime	string	custom	[...]	Spectre option savetime: Save the analysis states into files on the specified time points.
saSpectreENVLPOptionsavetimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionskipdc	string	custom	no	Spectre option skipdc: If set to yes, there will be no DC analysis for initial transient. Possible values are no and yes.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreENVLPOptionskipdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionsmoothcheck	string	custom	yes	Spectre option smoothcheck: When set to no, the smoothness of the envelope is not checked. The skip cycles are as many as possible. If 'fixstepsize=yes', 'smoothcheck' is set to 'no' automatically.. Possible values are no and yes.
saSpectreENVLPOptionsmoothcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionsrcw	string	custom	[...]	Spectre option srcw: Wireless source. Can be used only in fast envlp currently.
saSpectreENVLPOptionsrcwUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionsteadyratio	string	custom		Spectre option steadyratio: Ratio used to compute steady-state tolerances from LTE tolerance. Default is derived from 'errpreset'.
saSpectreENVLPOptionsteadyratioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionstepperperiod	string	custom		Spectre option stepperperiod: The interval (in seconds of envelope following time) between two steps when fixstepsize is yes. Should be greater than period of clock. For autonomous FM or shooting envelope, it is rounded off to the nearest integer multiple of clock period.
saSpectreENVLPOptionstepperperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionstepsize	string	custom	4	Spectre option stepsize: The number of cycles skipped between two steps when fixstepsize is yes. The time interval between the two steps will be (stepsize+1)*Tc, where Tc is the clock period. For shooting, autonomous, and fm envelope, it is rounded off to an integer.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreENVLPOptionstepsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionstrobeperiod	string	custom		Spectre option strobeperiod: The output strobe interval (in seconds) of envelope following time. For Shooting Envelope, the actual strobe interval is rounded off to an integer multiple of the clock period.
saSpectreENVLPOptionstrobeperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionswapfile	string	custom		Spectre option swapfile: Temporary file that holds the matrix information used by Newton's method. It tells Spectre to use a regular file, rather than virtual memory, to hold the matrix information. Use this option if Spectre does not have enough memory to complete this analysis. This parameter is now valid only for shooting. It does not apply to harmonic balance.
saSpectreENVLPOptionswapfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionsweepmethod	string	custom	coarse	Spectre option sweepmethod: This parameter controls the sweep algorithm during the fast envelope circuit characterization. When sweepmethod is coarse, fine, or userdefined, it uses a fixed number of sweep points. When sweepmethod is adaptive, it determines the number of sweep points automatically. coarse uses 7 magnitude points (plus 12 phase points when fastmethod=baseband); fine uses 10 magnitude points (plus 16 phase points when fastmethod=baseband); when sweepmethod=userdefined, use the sweepnum parameter to define the grid. Possible values are coarse, fine, userdefined, and adaptive. Possible values are coarse, fine, userdefined, and adaptive.
saSpectreENVLPOptionsweepmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreENVLPOptionsweepnum	string	custom	[...]	Spectre option sweepnum: This parameter controls the number of sweep points for fast envelope characterization when sweepmethod=userdefined. When fastmethod=passband, sweepnum is a one-element integer array which sets the number of magnitude sweep points. When fastmethod=baseband, it is a two-element integer array which sets the number of magnitude and phase sweep points. In passband mode, default sweepnum=[7]. In baseband mode, default sweepnum=[7 12]. In most cases, default values are adequate to capture the main and adjacent channel power accurately. Nevertheless, it is recommended to increase sweepnum gradually to ensure that the results do not change. A reasonable strategy is to start at sweepnum=[7 12] and increase to [10 16] until results converge. The upper limit of the magnitude and phase sweep points is [49 48].
saSpectreENVLPOptionsweepnum UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectreENVLPOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptiontranstrobe period	string	custom		Spectre option transtrobeperiod: The output strobe interval (in seconds) of envelope time. The value of the parameter must be less than the cycle period. Those strobe timepoints in all cycles will output when the parameter is working. It is valid for shooting and HB.
saSpectreENVLPOptiontranstrobe periodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptiontstab	string	custom	0	Spectre option tstab: Initial stabilization time: can be used to change the phase that envelope starts shooting.
saSpectreENVLPOptiontstabUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreENVLPOptionuseprevic	string	custom	no	Spectre option useprevic: If set to yes or ns, use the converged initial condition from previous analysis as ic or ns. Possible values are no, yes, and ns.
saSpectreENVLPOptionuseprevicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionwrite	string	custom		Spectre option write: File to which initial transient solution is to be written.
saSpectreENVLPOptionwriteenv	string	custom		Spectre option writeenv: The file to which fast mode envelope data is written. It can be reused by 'readenv' if the circuit remains unchanged, except for the decrease in 'srci' or 'srcq' scale. Can only be used in fast envelope.
saSpectreENVLPOptionwriteenvUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionwritefinal	string	custom		Spectre option writefinal: File to which final transient solution is to be written.
saSpectreENVLPOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreENVLPOscic	string	saTestbench	default	Spectre ENVLP: Oscillator IC method.
saSpectreENVLPOscillator	string	saTestbench	0	Spectre ENVLP: Design is oscillator.
saSpectreENVLPOutputallharms	string	saTestbench	0	Spectre ENVLP: Output Time-Domain Waveform and All Harmonics.
saSpectreENVLPOutputharmonic	string	saTestbench	1	Spectre ENVLP: Frequency.
saSpectreENVLPOversample	string	saTestbench	1	Spectre ENVLP: Tones Table 'Ovsmpl' Column.
saSpectreENVLPPeriod	string	saTestbench		Spectre ENVLP: Period.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreENVLPSaveinit	string	saTestbench	0	Spectre ENVLP: Save Initial Transient Results.
saSpectreENVLPSignal	string	saTestbench	Moderate	Spectre ENVLP: Tones Table 'Signal' Column.
saSpectreENVLPStepperperiod	string	saTestbench		Spectre ENVLP: Step Period.
saSpectreENVLPStop	string	saTestbench		Spectre ENVLP: Stop Time.
saSpectreENVLPTonesMode	string	saTestbench	Frequencies	Spectre ENVLP: Tone mode for netlisting.
saSpectreEnvOptsCircuitPreset	string	user	None	Circuit preset.
saSpectreEnvOptsCommandLineOptions	string	user		Additional command-line options for Spectre.
saSpectreEnvOptsErrorPreset	string	user	As-Is	Error preset.
saSpectreEnvOptsIncludePath	string	user		Search path for Spectre include files.
saSpectreEnvOptsInstPreservationList	string	user		List of instances to preserve in post-layout mode.
saSpectreEnvOptsInstPreservationMode	string	user	None	Mode for specifying instances to preserve in post-layout mode.
saSpectreEnvOptsMultiThreading	string	user	Auto	Thread specification mode.
saSpectreEnvOptsNetlistLanguage	string	user	Spectre	Netlist language for Spectre.
saSpectreEnvOptsNumThreads	string	user	1	Number of threads.
saSpectreEnvOptsOutputDataFormat	string	user	psfbin	Output data format.
saSpectreEnvOptsPostLayoutPresetMode	string	user	None	Post-layout preset mode.
saSpectreEnvOptsProcessorAffinity	string	user		Processor affinity.
saSpectreEnvOptsSimulatorEngine	string	user	Spectre	Simulation engine.
saSpectreEnvOptsStopViewList	string	user	spectre veriloga	Stop View List for netlister.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreEnvOptsSwitchViewList	string	user	spectre cmos.sch cmos_sch schematic veriloga	Switch View List for netlister.
saSpectreEnvOptsUse64Bit	string	user	0	64-bit simulation.
saSpectreEnvOptsUsePlusPlusAps	string	user	0	Use ++aps.
saSpectreEnvOptsUsePostLayoutOpt	string	user	0	Enable post-layout optimization.
saSpectreHBACCenter	string	saTestbench		Spectre HBAC: Center point of sweep limits.
saSpectreHBACDec	string	saTestbench		Spectre HBAC: Number of logarithmic steps per decade.
saSpectreHBACLin	string	saTestbench		Spectre HBAC: Number of linear steps.
saSpectreHBACLog	string	saTestbench		Spectre HBAC: Total number of logarithmic steps.
saSpectreHBACMaxFreq	string	saTestbench		Spectre HBAC: Maximum Frequency
saSpectreHBACMaxOrder	string	saTestbench	2	Spectre HBAC: Maximum Order
saSpectreHBACMaxsideband	string	saTestbench	1	Spectre HBAC: Maximum sideband.
saSpectreHBACMinFreq	string	saTestbench		Spectre HBAC: Minimum Frequency
saSpectreHBACOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, steps, and detailed_hb.
saSpectreHBACOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptioncontriblist	string	custom		Spectre option contriblist: Array of device names for distortion summary. When contriblist=[""], distortion from each non-linear device is calculated.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBACOptioncontriblistUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptioncrossingdirection	string	custom	all	Spectre option crossingdirection: Specifies the transitions for which sampling must be done. Possible values are all, rise, fall, and ignore.
saSpectreHBACOptionextrasampletimepoints	string	custom	[...]	Spectre option extrasampletimepoints: Additional time points for sampled PTV analysis.
saSpectreHBACOptionfimout	string	custom	0	Spectre option fim_out: Frequency of IM output signal.
saSpectreHBACOptionfimoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionflinout	string	custom	0	Spectre option flin_out: Frequency of linear output signal.
saSpectreHBACOptionflinoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionfreqaxis	string	custom		Spectre option freqaxis: Specifies whether the results should be printed as per the input frequency, the output frequency, or the absolute value of the output frequency. Default is 'absout'. Possible values are absout, out, and in.
saSpectreHBACOptionfreqaxisUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionfreqs	string	custom		Spectre option freqs: Array of RF source frequencies for triple beat analysis.
saSpectreHBACOptionfreqsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreHBACOptionhbprecondsolver	string	custom	autoset	Spectre option hbprecond_solver: Select a linear solver for the GMRES preconditioner. Default is autoset. With autoset, the simulator will automatically select the appropriate preconditioner. The preconditioner affects the rate of convergence of the linear matrix solver used in periodic small-signal analysis. When autoset is selected, the simulator may decide to switch to a different preconditioner after the analysis begins. When that happens, the simulator may issue a warning instructing you to choose a different preconditioner during subsequent runs. Although not required, choosing a different preconditioner according to the simulator's instructions may speed up subsequent analyses. Possible values are basicsolver, blocksolver, autoset, blockdense, and blocksolver2.
saSpectreHBACOptionhbprecondsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptioninmodharmnum	string	custom	1	Spectre option inmodharmnum: Harmonic value for the input source modulation.
saSpectreHBACOptioninmodharmnumUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionkrylovsize	string	custom	200	Spectre option krylov_size: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*krylov_size iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the krylov_size if the simulation reports insufficient norm reduction errors in GMRES.
saSpectreHBACOptionkrylovsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionmaxharmnonlin	string	custom	4	Spectre option maxharm_nonlin: Maximum harmonics of input signal frequency induced by non-linear effect.
saSpectreHBACOptionmaxharmnonlinUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBACOptionmaxsamples	string	custom	16	Spectre option maxsamples: Maximum number of sampled events to be processed during the sampled analysis.
saSpectreHBACOptionmodsource	string	custom		Spectre option modsource: Refer the output noise to this component.
saSpectreHBACOptionmodsourceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionmodulated	string	custom	no	Spectre option modulated: Compute transfer functions/conversion between modulated sources and outputs. Possible values are single, first, second, and no.
saSpectreHBACOptionmodulatedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionmoduppersideband	string	custom	1	Spectre option moduppersideband: Index of the upper sideband included in the modulation of an output for PAC and HBAC, or an input for PXF.
saSpectreHBACOptionmoduppersidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.
saSpectreHBACOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saSpectreHBACOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionout1	string	custom		Spectre option out1: Output signal 1.
saSpectreHBACOptionout1UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionout2	string	custom		Spectre option out2: Output signal 2.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBACOptionout2UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionoutmodharmonicmvec	string	custom	[...]	Spectre option outmodharmonic: Harmonic list for the output modulations.
saSpectreHBACOptionoutmodharmonicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionperturbation	string	custom	linear	Spectre option perturbation: The type of HBAC analysis. The default is linear for normal HBAC analysis. im2ds stands for im2 distortion summary and ds stands for distortion summary. Value multiple_beat is deprecated and will be removed in the future: use triple_beat instead. Possible values are linear, ds, ip3, ip2, im2ds, multiple_beat, and triple_beat.
saSpectreHBACOptionperturbationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionptvtype	string	custom	timeaveraged	Spectre option ptvtype: Specifies whether the PTV analysis will be traditional or sampled under certain conditions. Possible values are timeaveraged and sampled.
saSpectreHBACOptionrelativeTol	string	custom		Spectre option relativeTol: Relative tolerance for harmonic balance-based linear solver. Default value is 1.0e-2.
saSpectreHBACOptionrelativeTolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionresgmrescycle	string	custom	short	Spectre option resgmrescycle: Restarts GMRES cycle. Possible values are instant, short, long, recycleinstant, recycleshort, and recyclelong.
saSpectreHBACOptionresgmrescycleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionrf1src	string	custom		Spectre option rf1_src: Array of RF1 source names for IP3/IP2/IP1.
saSpectreHBACOptionrf1srcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBACOptionrf2src	string	custom		Spectre option rf2_src: Array of RF2 source names for IP3/IP2/IM2.
saSpectreHBACOptionrf2srcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionrfampls	string	custom		Spectre option rfampls: RF source amplitudes; the units are dBm for ports, Voltage for v-sources and Ampere for i-sources.
saSpectreHBACOptionrfamplsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionrfdbm	string	custom	0	Spectre option rfdbm: RF source dBm.
saSpectreHBACOptionrfdbmUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionrfmag	string	custom	0	Spectre option rfmag: RF source magnitude.
saSpectreHBACOptionrfmagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionrfsrc	string	custom		Spectre option rf_src: Array of RF source names for triple beat analysis.
saSpectreHBACOptionrfsrcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionsampleprobe	string	custom		Spectre option sampleprobe: The crossing event at this port triggers the sampled small signal computation.
saSpectreHBACOptionsave	string	custom		Spectre option save: Signals to output. Possible values are all, lvl, allpub, lvlpub, selected, none, and nooutput.
saSpectreHBACOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionthresholdvalue	string	custom	0	Spectre option thresholdvalue: Sampled measurement is done when the signal crosses this value.
saSpectreHBACOptiontitle	string	custom		Spectre option title: Analysis title.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBACOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptiontolerance	string	custom		Spectre option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saSpectreHBACOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBACOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectreHBACRelharmvec	string	saTestbench	1	Spectre HBAC: Harmonic index number for relative sweep.
saSpectreHBACSelectSideband	string	saTestbench	1	Spectre HBAC: Select Sidebands from list
saSpectreHBACSidebandType	string	saTestbench	Maximum Sideband	Spectre HBAC: Sideband type.
saSpectreHBACSidevec	string	saTestbench	1	Spectre HBAC: Sidebands array.
saSpectreHBACSpan	string	saTestbench		Spectre HBAC: Span between sweep limits.
saSpectreHBACStart	string	saTestbench		Spectre HBAC: Starting point of sweep limits.
saSpectreHBACStep	string	saTestbench		Spectre HBAC: Linear step size.
saSpectreHBACStepSpecLin	string	saTestbench	Number of Steps	Spectre HBAC: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreHBACStepSpecLog	string	saTestbench	Points per Decade	Spectre HBAC: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps")
saSpectreHBACStop	string	saTestbench		Spectre HBAC: Stopping point of sweep limits.
saSpectreHBACSweep	string	saTestbench	Logarithmic	Spectre HBAC: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectreHBACSweepSpec	string	saTestbench	<file path>	Spectre HBAC: Method of specifying sweep limits ("Start/Stop" "Center/Span").

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBACSweeptype	string	saTestbench	Default	Spectre HBAC: Frequency sweep type.
saSpectreHBACValues	string	saTestbench		Spectre HBAC: Individual values, also known as points of interest.
saSpectreHBACValuesfile	string	saTestbench		Spectre HBAC: File for individual values
saSpectreHBAutoharms	string	saTestbench	0	Spectre HB: Perform automatic harmonic number calculation.
saSpectreHBAutosteady	string	saTestbench	0	Spectre HB: Run automatic steady state detection during initial transient (tstab).
saSpectreHBCenter	string	saTestbench		Spectre HB: Center point of sweep limits.
saSpectreHBDec	string	saTestbench		Spectre HB: Number of logarithmic steps per decade.
saSpectreHBDesignVar	string	saTestbench		Spectre HB: Design variable being swept.
saSpectreHBDev	string	saTestbench		Spectre HB: Instance with parameter being swept.
saSpectreHBDoLoadPull	string	saTestbench	0	Spectre HB: Flag indicating a load pull sweep is to be performed
saSpectreHBDoLoadPullPort	string	saTestbench	0	Spectre HB: Flag indicating a port will serve as the load
saSpectreHBDoSweep	string	saTestbench	0	Spectre HB: Flag indicating a sweep is to be performed.
saSpectreHBErrpreset	string	saTestbench	off	Spectre HB: errpreset.
saSpectreHBHarmsType	string	saTestbench	Default	Spectre HB: Harmonics Specification Type.
saSpectreHBInst	string	saTestbench		Spectre HB: Port that loads the amplifier (hb only)
saSpectreHBLin	string	saTestbench		Spectre HB: Number of linear steps.
saSpectreHBLog	string	saTestbench		Spectre HB: Total number of logarithmic steps.
saSpectreHBMaximorder	string	saTestbench		Spectre HB: Maximum intermodulation order of harmonics.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBMod	string	saTestbench		Spectre HB: Model with parameter being swept.
saSpectreHBNOISEAugmented	string	saTestbench	no	Spectre HBNOISE: Augmented.
saSpectreHBNOISECenter	string	saTestbench		Spectre HBNOISE: Center point of sweep limits.
saSpectreHBNOISEDec	string	saTestbench		Spectre HBNOISE: Number of logarithmic steps per decade.
saSpectreHBNOISEDoMultiSweep	string	saTestbench	0	Spectre HBNOISE: Do a multisweep.
saSpectreHBNOISELin	string	saTestbench		Spectre HBNOISE: Number of linear steps.
saSpectreHBNOISELog	string	saTestbench		Spectre HBNOISE: Total number of logarithmic steps.
saSpectreHBNOISEMaxFreq	string	saTestbench		Spectre HBNOISE: Maximum Frequency
saSpectreHBNOISEMaxOrder	string	saTestbench	2	Spectre HBNOISE: Maximum Order
saSpectreHBNOISEMaxsideband	string	saTestbench	1	Spectre HBNOISE: Maximum sideband.
saSpectreHBNOISEMinFreq	string	saTestbench		Spectre HBNOISE: Minimum Frequency
saSpectreHBNOISEMultiSweepBandWidth	string	saTestbench		Spectre HBNOISE: Multisweep bandwidth.
saSpectreHBNOISEMultiSweepOscFreq	string	saTestbench		Spectre HBNOISE: Multisweep oscillation frequency.
saSpectreHBNOISEMultiSweepSimPoints	string	saTestbench		Spectre HBNOISE: Multisweep number of points per bandwidth.
saSpectreHBNOISEMultiSweepSyntax	enSpectreHBNOISEMultiSweepSyntax	user	values	Spectre HBNOISE: Multisweep syntax. Valid values: values valuesfile multipleAnalyses
saSpectreHBNOISENoiseout	string	saTestbench	usb	Spectre PNOISE: Noise Out
saSpectreHBNOISENoisetype	string	saTestbench	timeaverage	Spectre HBNOISE: Noise type.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreHBNOISENoiseType	string	saTestbench	timeaverage	Spectre HBNOISE: Noise Type.
saSpectreHBNOISEOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, steps, and detailed_hb.
saSpectreHBNOISEOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptioncyclo2txtfile	string	custom	no	Spectre option cyclo2txtfile: Output cyclo-stationary noise to text file as input source of next stage. Possible values are no and yes.
saSpectreHBNOISEOptioncyclo2txtfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionhbprensolver	string	custom	autoset	Spectre option hbprencond_solver: Select a linear solver for the GMRES preconditioner. Default is autoset. With autoset, the simulator will automatically select the appropriate preconditioner. The preconditioner affects the rate of convergence of the linear matrix solver used in periodic small-signal analysis. When autoset is selected, the simulator may decide to switch to a different preconditioner after the analysis begins. When that happens, the simulator may issue a warning instructing you to choose a different preconditioner during subsequent runs. Although not required, choosing a different preconditioner according to the simulator's instructions may speed up subsequent analyses. Possible values are basicsolver, blocksolver, autoset, blockdense, and blocksolver2.
saSpectreHBNOISEOptionhbprensolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreHBNOISEOptionkrylovsize	string	custom	200	Spectre option krylov_size: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*krylov_size iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the krylov_size if the simulation reports insufficient norm reduction errors in GMRES.
saSpectreHBNOISEOptionkrylovsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionlorentzian	string	custom	cornerfrequency	Spectre option lorentzian: This option determines if the Lorentzian plot is used in the oscillator noise analysis. 'lorentzian=yes' is only valid for 'noisetype=timeaverage'. Possible values are no, cornerfrequency, and yes.
saSpectreHBNOISEOptionlorentzianUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionmeasurement	string	custom		Spectre option measurement: Specifies the jitter event list that will be measured.
saSpectreHBNOISEOptionmeasurementUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.
saSpectreHBNOISEOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionnoiseout	string	custom	usb	Spectre option noiseout: Specify noise output. You can set a vector like noiseout=[usb am pm]. And all are using single sideband(SSB) convention, half of the total power. Possible values are usb, lsb, am, and pm.
saSpectreHBNOISEOptionnoiseoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBNOISEOptionnoiseskipcount	string	custom	-1	Spectre option noiseskipcount: Calculate time-domain noise on only one of every noiseskipcount time points. When < 0, the parameter is ignored. When >=0, the simulator uses this parameter and ignores numberofpoints.
saSpectreHBNOISEOptionnoiseskipcountUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionnoisetimepoints	string	custom	[...]	Spectre option noisetimepoints: Additional time points for time-domain noise analysis.
saSpectreHBNOISEOptionnoisetimepointsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionnumberofpoints	string	custom	5	Spectre option numberofpoints: Number of time points of interest in the period where time domain PSD is calculated. Simulator divides the period evenly into N segments (N=numberofpoints) and calculates time domain PSD on the starting time point of each segment. When < 0, the parameter is ignored.
saSpectreHBNOISEOptionnumberofpointsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionoscmacrogenerator	string	custom	no	Spectre option oscmacrogenerator: If set to yes, harmonic balance steady-state and phase noise data are saved. Applies only if there is pm noise out. Possible values are no and yes.
saSpectreHBNOISEOptionoscmacrogeneratorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionoscmacrogeneratorsave	string	custom		Spectre option oscmacrogeneratorsave: File to which harmonic balance steady-state solution and phase noise data are to be written.
saSpectreHBNOISEOptionoscmacrogeneratorsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreHBNOISEOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionoutputxf	string	custom	no	Spectre option output_xf: If set to no, there are no xf results output in hbnoise. Possible values are no and yes.
saSpectreHBNOISEOptionoutputxfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionppv	string	custom	no	Spectre option ppv: If set to yes, save the oscillator PPV after performing noise analysis. Possible values are no and yes.
saSpectreHBNOISEOptionppvUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionrefsidebandoption	string	custom	individual	Spectre option refsidebandoption: Whether to view the sideband as a specification of a frequency or a specification of an individual sideband. Possible values are freq and individual.
saSpectreHBNOISEOptionrefsidebandoptionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionrelativeTol	string	custom		Spectre option relativeTol: Relative tolerance for harmonic balance-based linear solver. Default value is 1.0e-2.
saSpectreHBNOISEOptionrelativeTolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionresgmrescycle	string	custom	short	Spectre option resgmrescycle: Restarts GMRES cycle. Possible values are instant, short, long, recycleinstant, recycleshort, and recyclelong.
saSpectreHBNOISEOptionresgmrescycleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBNOISEOptionsave	string	custom		Spectre option save: Signals to output. The option 'save' specifies the signals to be saved in the result. 'allpub' saves all signals at all levels of hierarchy in the schematic, including the internal signals of device models. 'all' works like 'allpub'. 'lvl' saves all signals through the level of hierarchy set in 'nestlvl' option. 'lvlpub' works like 'lvl'. 'selected' is not recommended to use here. Possible values are all, lvl, allpub, lvlpub, and selected.
saSpectreHBNOISEOptionsavealls idebands	string	custom	no	Spectre option saveallsidebands: Save noise contributors by sideband. Possible values are no and yes.
saSpectreHBNOISEOptionsavealls idebandsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionsaveUn checkLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptionstimuli	string	custom	sources	Spectre option stimuli: Stimuli used for XF analysis in hnoise. Possible values are sources and nodes_and_terminals.
saSpectreHBNOISEOptionstimuliU ncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectreHBNOISEOptiontitleUnc heckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOptiontolera nce	string	custom		Spectre option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saSpectreHBNOISEOptiontoleranc eUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBNOISEOutputType	string	saTestbench	Voltage	Spectre HBNOISE: Output type.
saSpectreHBNOISERefsideband	string	saTestbench	1	Spectre HBNOISE: Conversion gain sideband.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBNOISERelharmvec	string	saTestbench	1	Spectre HBNOISE: Harmonic index number for relative sweep.
saSpectreHBNOISESelectSideband	string	saTestbench	1	Spectre HBNOISE: Select Sidebands from list
saSpectreHBNOISESeparatenoise	string	saTestbench	0	Spectre HBNOISE: Separate noise.
saSpectreHBNOISESidebandType	string	saTestbench	Maximum Sideband	Spectre HBNOISE: Sideband type.
saSpectreHBNOISESidevec	string	saTestbench	1	Spectre HBNOISE: Sidebands array.
saSpectreHBNOISESpan	string	saTestbench		Spectre HBNOISE: Span between sweep limits.
saSpectreHBNOISEStart	string	saTestbench		Spectre HBNOISE: Starting point of sweep limits.
saSpectreHBNOISEStep	string	saTestbench		Spectre HBNOISE: Linear step size.
saSpectreHBNOISEStepSpecLin	string	saTestbench	Number of Steps	Spectre HBNOISE: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreHBNOISEStepSpecLog	string	saTestbench	Points per Decade	Spectre HBNOISE: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectreHBNOISEStop	string	saTestbench		Spectre HBNOISE: Stopping point of sweep limits
saSpectreHBNOISESweep	string	saTestbench	Logarithmic	Spectre HBNOISE: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest")
saSpectreHBNOISESweepSpec	string	saTestbench	<file path>	Spectre HBNOISE: Method of specifying sweep limits ("Start/Stop" "Center/Span")
saSpectreHBNOISESweepType	string	saTestbench	Default	Spectre HBNOISE: Frequency sweep type.
saSpectreHBNOISEValues	string	saTestbench		Spectre HBNOISE: Individual values, also known as points of interest.
saSpectreHBNOISEValuesfile	string	saTestbench		Spectre HBNOISE: File for individual values

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreHBOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, estimated, steps, iters, detailed, rejects, alliters, detailed_hb, and internal_hb.
saSpectreHBOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionaxisbw	string	custom		Spectre option axisbw: The width of the band part of wide funnel harmonic cut along axis.
saSpectreHBOptionaxisbwUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionbackoff	string	custom	0.0	Spectre option backoff: The backoff point. If defined, an addition harmonic balance analysis will be performed after the compression analysis is done. Default is 0 dBm when xdbgain=power, and 0 V when xdbgain=voltage.
saSpectreHBOptionbackoffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionbacktracking	string	custom	yes	Spectre option backtracking: This parameter is used to activate the backtracing utility of Newton's method. The default is yes. Possible values are no, yes, and forced.
saSpectreHBOptionbacktrackingUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptioncircuitage	string	custom		Spectre option circuitage: Stress time. Age of the circuit used to simulate hot-electron degradation of MOSFET and BSIM circuits.
saSpectreHBOptioncircuitageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptioncmin	string	custom	0	Spectre option cmin: Minimum capacitance from each node to ground.
saSpectreHBOptioncminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBOptiondev	string	custom		Spectre option dev: Name of the device instance parameter specified in param=name.
saSpectreHBOptiondevUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionevenodd	string	custom	[...]	Spectre option evenodd: Array of even, odd, or all strings for moderate tones to select harmonics.
saSpectreHBOptionevenoddUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionexcludeconvgwithBK	string	custom	yes	Spectre option excludeconvgwithBK.
saSpectreHBOptionexcludeconvgwithBKUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionfreqdivide	string	custom		Spectre option freqdivide: Large signal frequency division.
saSpectreHBOptionfreqdivideUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionfreqdividevector	string	custom	[...]	Spectre option freqdividevector: Array of frequency division factors for each tone. This parameter overrides freqdivide.
saSpectreHBOptionfreqdividevectorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionglog	string	custom	5	Spectre option glog: Number of steps, log sweep for hbhomotopy of gsweep.
saSpectreHBOptionglogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptiongstart	string	custom	1.e-7	Spectre option gstart: Start conductance for hbhomotopy of gsweep.
saSpectreHBOptiongstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBOptiongstop	string	custom	1.e-12	Spectre option gstop: Stop conductance for hbhomotopy of gsweep.
saSpectreHBOptiongstopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionhbhomotopy	string	custom	tone	Spectre option hbhomotopy: Name of Harmonic Balance homotopy selection methods. Possible values are tstab, source, gsweep, tone, inctone, and aggregation.
saSpectreHBOptionhbhomotopyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionhbpartitiondefs	string	custom	[...]	Spectre option hbpartition_defs: Define HB partitions.
saSpectreHBOptionhbpartitiondefsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionhbpartitionfundratios	string	custom	[...]	Spectre option hbpartition_fundratios: Specify HB partition fundamental frequency ratios.
saSpectreHBOptionhbpartitionfundratiosUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionhbpartitionharms	string	custom	[...]	Spectre option hbpartition_harms: Specify HB partition harmonics.
saSpectreHBOptionhbpartitionharmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionhbprecondsolver	string	custom	basicsolver	Spectre option hbprecond_solver: Choose a linear solver for the GMRES preconditioner. Possible values are basicsolver, blocksolver, autotest, blockdense, and blocksolver2.
saSpectreHBOptionhbprecondsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionic	string	custom	all	Spectre option ic: The value to be used to set the initial condition. Possible values are dc, node, dev, and all.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBOptionicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionitres	string	custom	1e-4	Spectre option itres: Controls the residual for iterative solution of linearized matrix equation at each Newton iteration. Tightening the parameter can help with the Newton convergence, but does not affect the result accuracy. The value should be between [0, 1].
saSpectreHBOptionitresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionkrylovsize	string	custom	10	Spectre option krylov_size: The minimum iteration count of the linear matrix solver used in HB large-signal analysis. After reaching krylov_size iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase krylov_size if the simulation reports insufficient norm reduction errors in GMRES.
saSpectreHBOptionkrylovsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionlsspdatafmt	string	custom	touchstone	Spectre option lsspdatafmt: Sets the file format of the large-signal S-parameter output. Possible values are spectre and touchstone. Default is touchstone.
saSpectreHBOptionlsspdatafmtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionlsspdatype	string	custom	msgphase	Spectre option lsspdatype: Sets the data format or the large-signal S-parameter output. Possible values are realimag, magphase and phase. Default is magphase.
saSpectreHBOptionlsspdatypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionlsspfile	string	custom		Spectre option lsspfile: Identifies the file name for large-signal S-parameter output.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBOptionlssprofileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionlsspharms	string	custom	[...]	Spectre option lsspharms: Specifies the output harmonic for large-signal S-parameter calculations. The input harmonic is defined by the frequency parameters on the input port instance.
saSpectreHBOptionlsspharmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionlssports	string	custom	[...]	Spectre option lssports: Specifies the list of ports on which the large-signal 2-port S-parameters are calculated.
saSpectreHBOptionlssportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionmaxperiods	string	custom		Spectre option maxperiods: Maximum number of iterations allowed before convergence is reached in shooting or harmonic balance Newton iteration. For PSS and QPSS, the default is 20 for driven circuits, and 50 for oscillators; For HB, the default is 100.
saSpectreHBOptionmaxperiodsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionmaxstep	string	custom		Spectre option maxstep: Maximum time step. The default is derived from `errpreset`.
saSpectreHBOptionmaxstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBOptionmemoryestimate	string	custom	no	Spectre option memoryestimate: Sets the memory usage estimate for Harmonic Balance. If yes, a memory estimate is printed in the log file. You can use this memory estimate to plan the computing resources before submitting harmonic balance runs. In memory estimate mode, a short simulation is performed first, and the engine exits after printing the estimate in the log file without saving harmonic balance results. You must turn it off to perform an actual simulation. Memory estimation is not recommended for simulations that require less than 500MB approximately. For PSS analysis, memory estimate mode does not apply unless balance=yes. The estimate applies only to large-signal analysis, and does not include subsequent noise or other small-signal simulations.
saSpectreHBOptionmemoryestimateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionminialiasorder	string	custom		Spectre option minialiasorder: The order of mini aliasing harmonic order.
saSpectreHBOptionminialiasorderUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionmod	string	custom		Spectre option mod: Name of the device model parameter specified in param=name.
saSpectreHBOptionmodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.
saSpectreHBOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBOptionoscic	string	custom	default	Spectre option oscic: Oscillator IC method. It determines how the starting values for the oscillator are calculated. 'oscic=lin' provides you an accurate initial value, but it takes time; oscic=lin_ic' is not recommended, which is the older version of 'oscic=lin' for shooting analysis for backward compatibility; 'oscic=fastic' is fast, but it is less accurate. 'oscic=skip' directly uses the frequency provided by you as the initial guess frequency. It is only for the two-tier method. Possible values are default, lin, lin_ic, fastic, and skip.
saSpectreHBOptionoscicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionoscmacrogene	string	custom	no	Spectre option oscmacrogene: If set to yes, harmonic balance steady-state solution is saved. Possible values are no and yes.
saSpectreHBOptionoscmacrogeneUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionoscmacroout	string	custom	[...]	Spectre option oscmacroout: Specify nodes of which the voltage data is to be saved.
saSpectreHBOptionoscmacrooutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionoscmacroprobe	string	custom		Spectre option oscmacroprobe: Specify probe of which the current data is to be saved.
saSpectreHBOptionoscmacroprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionoscmacrosave	string	custom		Spectre option oscmacrosave: File to which harmonic balance steady-state solution is to be written.
saSpectreHBOptionoscmacrosaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionoscmethod	string	custom		Spectre option oscmethod: Osc Newton method for autonomous HB. Possible values are onetier and twotier.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreHBOptionoscmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saSpectreHBOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionoversamplefactor	string	custom	1	Spectre option oversamplefactor: Oversample device evaluations.
saSpectreHBOptionoversamplefactorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionparam	string	custom		Spectre option param: Name of the parameter to be updated during pss/hb analysis (tstab stage).
saSpectreHBOptionparamfile	string	custom		Spectre option param_file: The file that contains the time_value points to param=name.
saSpectreHBOptionparamfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionparamset	string	custom		Spectre option paramset: Name of the dynamic parameter set.
saSpectreHBOptionparamsetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionparamstep	string	custom		Spectre option param_step: Defines the frequency of updating the dynamic parameter values. If param_step=0, it updates the parameter value at a given time point.
saSpectreHBOptionparamstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBOptionparamvec	string	custom	[...]	Spectre option param_vec: The time_value points to param=name.
saSpectreHBOptionparamvecUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionpinnode	string	custom		Spectre option pinnode: Node to pin during autonomous HB simulation.
saSpectreHBOptionpinnodemag	string	custom		Spectre option pinnodemag: This parameter gives an estimate of the magnitude of the pin node voltage. Default value is 0.01.
saSpectreHBOptionpinnodemagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionpinnodeminus	string	custom		Spectre option pinnodeminus: Second node to pin during autonomous HB simulation. Needed only when differential nodes exist in oscillator.
saSpectreHBOptionpinnodeminusUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionpinnodeRank	string	custom		Spectre option pinnodeRank: Harmonic rank to pin during autonomous HB simulation.
saSpectreHBOptionpinnodeRankUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionpinnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionreadhb	string	custom		Spectre option readhb: File from which final harmonic steady-state solution is to be read. Small signal analyses such as hbac, hbsp, and hbnoise can read in the steady-state solution from this file directly instead of running the hb analysis again.
saSpectreHBOptionreadhbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionreadic	string	custom		Spectre option readic: File that contains initial condition.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreHBOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionreadns	string	custom		Spectre option readns: File that contains an estimate of the initial transient solution.
saSpectreHBOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionrecover	string	custom		Spectre option recover: Specify the file to be restored.
saSpectreHBOptionrecoverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionrestart	string	custom	no	Spectre option restart: Restart the DC/PSS/QPSS solution if set to 'yes'; if set to 'no', reuse the previous solution as an initial guess; if set to 'firstonly', restart if it is the first point of sweep (supported only in HB). The default value is 'no' for HB and 'yes' for shooting. Possible values are no, yes, and firstonly.
saSpectreHBOptionrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionsave	string	custom		Spectre option save: Signals to output. Possible values are all, lvl, allpub, lvlpub, selected, none, and nooutput.
saSpectreHBOptionsaveclock	string	custom		Spectre option saveclock: Save the tran analysis periodically on the wall clock time. The default is 1800s for Spectre. This parameter is disabled in the APS mode by default.
saSpectreHBOptionsaveclockUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionsavefile	string	custom		Spectre option savefile: Save the analysis states into the specified file.
saSpectreHBOptionsavefileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreHBOptionsaveperiod	string	custom		Spectre option saveperiod: Save the tran analysis periodically on the simulation time.
saSpectreHBOptionsaveperiodhistory	string	custom	no	Spectre option saveperiodhistory: Maintains the history of saved files. If yes, maintains all the saved files. Possible values are no and yes.
saSpectreHBOptionsaveperiodhistoryUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionsaveperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionsavetime	string	custom	[...]	Spectre option savetime: Save the analysis states into files on the specified time points.
saSpectreHBOptionsavetimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionsselharmread	string	custom		Spectre option selharmread: File from which arbitrary harmonic data needs to be read.
saSpectreHBOptionsselharmreadUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionsselharmvec	string	custom	[...]	Spectre option selharmvec: Array of harmonics indices.
saSpectreHBOptionsselharmvecUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionsselharmwrite	string	custom		Spectre option selharmwrite: File to which harmonic data needs to be written.
saSpectreHBOptionsselharmwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionskipdc	string	custom	no	Spectre option skipdc: If set to yes, there is no DC analysis for initial transient. Possible values are no, yes, and sigrampup.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBOptionskipdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionsub	string	custom		Spectre option sub: Name of the subcircuit instance parameter specified in param=name.
saSpectreHBOptionsubUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionsweepic	string	custom	none	Spectre option sweepic: IC extrapolation method in sweep HB analysis. Possible values are none, linear, and log.
saSpectreHBOptionsweepicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectreHBOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptiontonehomotopy	string	custom	[...]	Spectre option tone_homotopy: Array of homotopy options for convergence assistance with multi-divider cases, when hbmhomotopy=aggregation. The number of entries should be equal to that of tones. The possible values for each entry are 0, 1 and 2. '0' means no convergence assistance is applied for that tone. '1' means only transient stabilization (tstab) is run for that tone and '2' means both tstab and a single-tone HB simulation should be run to obtain the initial guess for multi-tone HB simulation.
saSpectreHBOptiontonehomotopyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptiontstabmethod	string	custom		Spectre option tstabmethod: Integration method used in stabilization time. The default is 'traponly' for autonomous circuits, or is derived from 'errpreset' for driven circuits. Possible values are euler, trap, traponly, gear2, and gear2only.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBOptionstabmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptiontunedev	string	custom		Spectre option tunedev: Sets the instance name of a device whose parameter (identified by tuneparam) will be varied such that the circuit oscillates at the specified frequency. Applies only in tuning mode autonomous analysis. Tunedev must be used with tuneparam.
saSpectreHBOptiontunedevUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptiontunelin	string	custom		Spectre option tunelin: Specify the numbers of discrete tuning points. Must be used with 'tunerange'.
saSpectreHBOptiontunelinUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptiontuneparam	string	custom		Spectre option tuneparam: When set, tuneparam enables the tuning mode oscillator analysis. In the tuning mode analysis, a circuit parameter is automatically varied to reach the oscillation frequency specified by the fundfreqs parameter. The tuning parameter can be a device instance parameter (as determined by the parameters tunedev) or a netlist parameter. This mode applies only to autonomous circuits (oscillators).
saSpectreHBOptiontuneparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptiontunerange	string	custom	[...]	Spectre option tunerange: The tuning range of the parameter identified by tuneparam. Although tunerange is not required, it can aid in convergence if set. Tunerange also can be used with 'tunestep' or 'tunelin' to decide the acceptable discrete parameter set.
saSpectreHBOptiontunerangeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreHBOptiontunestep	string	custom		Spectre option tunestep: Specify the step size between two adjacent discrete tuning points. Must be used with 'tunerange'.
saSpectreHBOptiontunestepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptiontunevalues	string	custom	[...]	Spectre option tunevalues: Specify the values of discrete tuning points.
saSpectreHBOptiontunevaluesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionuseprevic	string	custom	no	Spectre option useprevic: If set to yes or ns, use the converged initial condition from previous analysis as ic or ns. Possible values are no, yes, and ns.
saSpectreHBOptionuseprevicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionwritehb	string	custom		Spectre option writehb: File to which final harmonic balance steady-state solution is to be written. Small-signal analyses, such as hbac,hbsp, and hbnoise can read the steady-state solution from this file directly instead of running the hb analysis again.
saSpectreHBOptionwritehbUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionxdbcompression	string	custom	no	Spectre option xdbcompression: Sets the automatic gain compression analysis. In automatic gain compression analysis, Spectre automatically sweeps the input excitation until the gain, as defined by the analysis parameter xdbgain, compresses by the amount specified by the analysis parameter xdblevel. In gain compression analysis, Spectre outputs the hb solution at the calculated compression point only. Dependent analyses, such as hbnoise and hbac, are supported and calculated about the calculated compression level. Auxiliary output includes the gain and voltage/power compression curves. These outputs are available for analysis and post-processing in ADE. The possible values are yes and no. Default is no.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBOptionxdbcompressi onUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionxdbcp	string	custom		Spectre option xdbcp: Sets the estimated input-referred compression point for rapid compression analysis.
saSpectreHBOptionxdbcpUnchec kLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionxdbgain	string	custom	power	Spectre option xdbgain: Chooses between the voltage gain and transducer power gain as the target for compression point calculation. When xdbgain=power, the gain is defined as $G \text{ (dB)} = P_{\text{load}} \text{ (dBm)} - P_{\text{available}} \text{ (dBm)}$. When xdbgain=voltage, the gain is defined as $G \text{ (dB)} = \text{dB}20(V_{\text{load}} / V_{\text{source}})$. In both cases, Spectre sweeps the excitation source until $\text{xdbref} - G = \text{xdblevel}$, where the analysis parameter xdbref defines the reference level for compression calculation. Possible values are power and voltage. Default is power.
saSpectreHBOptionxdbgainUnche ckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionxdbharm	string	custom	[...]	Spectre option xdbharm: The Integer array which specifies the harmonic indexes of the output voltage or power component.
saSpectreHBOptionxdbharmUnch eckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionxdblevel	string	custom	[...]	Spectre option xdblevel: Sets the gain compression level for compression analysis. The reference point for gain compression is the small-signal gain of the circuits, or as specified by the analysis parameter xdbref. Default is 1.
saSpectreHBOptionxdblevelUnche ckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBOptionxdbload	string	custom		Spectre option xdbload: The instance name of the load termination. When xdbgain is power, xdbload can be a port, a resistor, or a current probe.
saSpectreHBOptionxdbloadUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionxdbmax	string	custom		Spectre option xdbmax: The maximum input power (or voltage) for the compression point search. Default is 10 dBm when xdbgain=power, and 0.1 V when xdbgain=voltage.
saSpectreHBOptionxdbmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionxdbnoden	string	custom		Spectre option xdbnoden: The output terminals for voltage gain calculation when xdbgain=voltage. If either is left unspecified, the terminal is assumed to be the global ground.
saSpectreHBOptionxdbnodenUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionxdbnodep	string	custom		Spectre option xdbnodep: The output terminals for voltage gain calculation when xdbgain=voltage. If either is left unspecified, the terminal is assumed to be the global ground.
saSpectreHBOptionxdbnodepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionxdbrapid	string	custom	no	Spectre option xdbrapid: Sets the automatic gain compression analysis in rapid mode. In this mode, Spectre does not trace the compression curve and calculates only the compression point.
saSpectreHBOptionxdbrapidUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBOptionxdbref	string	custom	linear	Spectre option xdbref: Sets the reference point for gain compression calculations. When xdbref=linear, spectre uses the small-signal gain as the reference. When xdbref=max, spectre uses the maximum observed gain as the reference. Possible values are linear and max. Default is linear.
saSpectreHBOptionxdbrefnode	string	custom		Spectre option xdbrefnode: The reference node when xdbload is a current probe. The default is the ground node.
saSpectreHBOptionxdbrefnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionxdbrefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionxdbcsource	string	custom		Spectre option xdbcsource: The instance name of the excitation source, which is swept automatically to reach the compression level. When xdbgain=power, the excitation source must be a port instance. When xdbgain=voltage, the excitation source must be a vsource instance.
saSpectreHBOptionxdbcsourceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionxdbstart	string	custom		Spectre option xdbstart: The starting input power (or voltage) for the compression point search. Default is (xdbmax-50) dBm when xdbgain=power, and xdbmax/1000 when xdbgain=voltage.
saSpectreHBOptionxdbstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOptionxdbsteps	string	custom	100	Spectre option xdbsteps: The maximum number of steps for the compression point search. The simulator terminates if xdbsteps exceeds before the compression point is found. The default is 100.
saSpectreHBOptionxdbstepsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBOptionxdbtol	string	custom	0.01	Spectre option xdbtol: Sets the tolerance for compression analysis. This tolerance is used in compression curve fitting and calculating the compression point.
saSpectreHBOptionxdbtolUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBOscillator	string	saTestbench	0	Spectre HB: Design is oscillator.
saSpectreHBParam	string	saTestbench		Spectre HB: Parameter being swept.
saSpectreHBPhi	string	saTestbench		Spectre HB: phi parameter being swept
saSpectreHBPhilin	string	saTestbench		Spectre HB: Number of phi linear steps
saSpectreHBPhistart	string	saTestbench		Spectre HB: Starting point of phi sweep limits
saSpectreHBPhistep	string	saTestbench		Spectre HB: Linear phi step size
saSpectreHBPhiStepSpecLin	string	saTestbench	Number of Steps	Spectre HB: Method of specifying phi linear stepping ("Step Size" "Number of Steps")
saSpectreHBPhistop	string	saTestbench		Spectre HB: Stopping point of phi sweep limits
saSpectreHBPhiSweep	string	saTestbench	Linear	Spectre HB: Method of sweeping phi values ("Linear" "Points of Interest")
saSpectreHBPhivalues	string	saTestbench		Spectre HB: Individual phi values, also known as points of interest
saSpectreHBRho	string	saTestbench		Spectre HB: rho parameter being swept
saSpectreHBRholin	string	saTestbench		Spectre HB: Number of rho linear steps
saSpectreHBRhostart	string	saTestbench		Spectre HB: Starting point of rho sweep limits
saSpectreHBRhostep	string	saTestbench		Spectre HB: Linear rho step size
saSpectreHBRhoStepSpecLin	string	saTestbench	Number of Steps	Spectre HB: Method of specifying rho linear stepping ("Step Size" "Number of Steps")

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBRhostop	string	saTestbench		Spectre HB: Stopping point of rho sweep limits
saSpectreHBRhoSweep	string	saTestbench	Linear	Spectre HB: Method of sweeping rho values ("Linear" "Points of Interest")
saSpectreHBRhovalues	string	saTestbench		Spectre HB: Individual rho values, also known as points of interest
saSpectreHBRunTran	string	saTestbench	No	Spectre HB: Specifies to run transient.
saSpectreHBSaveinit	string	saTestbench	0	Spectre HB: Save initial transient results.
saSpectreHBSelectharm	string	saTestbench	diamond	Spectre HB: Intermodulation selection mode for harmonics.
saSpectreHBSPan	string	saTestbench		Spectre HB: Span between sweep limits.
saSpectreHBSPCenter	string	saTestbench		Spectre HBSP: Center point of sweep limits.
saSpectreHBSPDec	string	saTestbench		Spectre HBSP: Number of logarithmic steps per decade.
saSpectrehbspDoNoise	string	saTestbench	0	Spectre HBSP: Do Noise
saSpectreHBSPFreqAxis	string	saTestbench	in	Spectre HBSP: Freq Axis.
saSpectreHBSPLin	string	saTestbench		Spectre HBSP: Number of linear steps.
saSpectreHBSPLog	string	saTestbench		Spectre HBSP: Total number of logarithmic steps.
saSpectreHBSPMaxSideband	string	saTestbench	1	Spectre HBSP: Maximum Side Band.
saSpectreHBSPOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, steps, and detailed_hb.
saSpectreHBSPOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSPOptiondatafmt	string	custom	spectre	Spectre option datafmt: Data format of the S-parameter output file. Possible values are spectre, touchstone, and touchstone2.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBSPOptiondatafmtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSPOptiondatatype	string	custom	realimag	Spectre option datatype: Data type of the S-parameter output file. Possible values are realimag, magphase, and dbphase.
saSpectreHBSPOptiondatatypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSPOptionfile	string	custom		Spectre option file: Output file name. It just supports S-parameters in PSP, HBSP, and QPSP analysis.
saSpectreHBSPOptionfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSPOptionhbprecond_solver	string	custom	autoset	Spectre option hbprecond_solver: Select a linear solver for the GMRES preconditioner. Default is autoset. With autoset, the simulator will automatically select the appropriate preconditioner. The preconditioner affects the rate of convergence of the linear matrix solver used in periodic small-signal analysis. When autoset is selected, the simulator may decide to switch to a different preconditioner after the analysis begins. When that happens, the simulator may issue a warning instructing you to choose a different preconditioner during subsequent runs. Although not required, choosing a different preconditioner according to the simulator's instructions may speed up subsequent analyses. Possible values are basicsolver, blocksolver, autoset, blockdense, and blocksolver2.
saSpectreHBSPOptionhbprecond_solverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBSPOptionkrylovsize	string	custom	200	Spectre option krylov_size: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*krylov_size iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the krylov_size if the simulation reports insufficient norm reduction errors in GMRES.
saSpectreHBSPOptionkrylovsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSPOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectreHBSPOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSPOptionrelativeTol	string	custom		Spectre option relativeTol: Relative tolerance for harmonic balance-based linear solver. Default value is 1.0e-2.
saSpectreHBSPOptionrelativeTolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSPOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectreHBSPOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSPOptiontolerance	string	custom		Spectre option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saSpectreHBSPOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSPOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectreHBSPSpan	string	saTestbench		Spectre HBSP: Span between sweep limits.
saSpectreHBSPStart	string	saTestbench		Spectre HBSP: Starting point of sweep limits.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBSPStep	string	saTestbench		Spectre HBSP: Linear step size.
saSpectreHBSPStepSpecLin	string	saTestbench	Number of Steps	Spectre HBSP: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreHBSPStepSpecLog	string	saTestbench	Points per Decade	Spectre HBSP: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectreHBSPStop	string	saTestbench		Spectre HBSP: Stopping point of sweep limits.
saSpectreHBSPSweep	string	saTestbench	Logarithmic	Spectre HBSP: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectreHBSPSweepSpec	string	saTestbench	<file path>	Spectre HBSP: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectreHBSPSweepType	string	saTestbench	Default	Spectre HBSP: Frequency sweep type
saSpectreHBSPValues	string	saTestbench		Spectre HBSP: Individual values, also known as points of interest.
saSpectreHBSPValuesfile	string	saTestbench		Spectre HBSP: File for individual values
saSpectreHBStart	string	saTestbench		Spectre HB: Starting point of sweep limits.
saSpectreHBSTBCenter	string	saTestbench		Spectre HBSTB: Center point of sweep limits.
saSpectreHBSTBDec	string	saTestbench		Spectre HBSTB: Number of logarithmic steps per decade.
saSpectreHBSTBDoSweep	string	saTestbench	1	Spectre HBSTB: Flag indicating a sweep is to be performed.
saSpectreHBSTBLin	string	saTestbench		Spectre HBSTB: Number of linear steps.
saSpectreHBSTBLocalgnd	string	saTestbench		Spectre HBSTB: Node name of local ground.
saSpectreHBSTBLog	string	saTestbench		Spectre HBSTB: Total number of logarithmic steps.
saSpectreHBSTBModeType	string	saTestbench	common	Spectre HBSTB: Mode Type for diffstbprobe element.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBSTBOProbe	string	saTestbench		Spectre HBSTB: Probe instance around which the loop gain is calculated.
saSpectreHBSTBOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, steps, and detailed_hb.
saSpectreHBSTBOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSTBOptiongearorder	string	custom	2	Spectre option gear_order: Gear order used for small-signal integration.
saSpectreHBSTBOptiongearorderUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSTBOptionhbprecond solver	string	custom	autoset	Spectre option hbprecond_solver: Select a linear solver for the GMRES preconditioner. Default is autoset. With autoset, the simulator will automatically select the appropriate preconditioner. The preconditioner affects the rate of convergence of the linear matrix solver used in periodic small-signal analysis. When autoset is selected, the simulator may decide to switch to a different preconditioner after the analysis begins. When that happens, the simulator may issue a warning instructing you to choose a different preconditioner during subsequent runs. Although not required, choosing a different preconditioner according to the simulator's instructions may speed up subsequent analyses. Possible values are basicsolver, blocksolver, autoset, blockdense, and blocksolver2.
saSpectreHBSTBOptionhbprecond solverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSTBOptionkrylovsize	string	custom	200	Spectre option krylov_size: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*krylov_size iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the krylov_size if the simulation reports insufficient norm reduction errors in GMRES.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreHBSTBOptionkrylovsize UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSTBOptionlocalgnd	string	custom		Spectre option localgnd: Node name of local ground. If not specified, the probe is referenced to global ground.
saSpectreHBSTBOptionlocalgndU ncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSTBOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.
saSpectreHBSTBOptionnestlvlUnc heckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSTBOptionoscsolver	string	custom	turbo	Spectre option oscsolver: Oscillator solver type. It is recommended that you use ira for huge circuits. Possible values are std, turbo, ira, and direct.
saSpectreHBSTBOptionoscsolver UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSTBOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectreHBSTBOptionotherOptions UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSTBOptionrelativeTol	string	custom		Spectre option relativeTol: Relative tolerance for harmonic balance-based linear solver. Default value is 1.0e-2.
saSpectreHBSTBOptionrelativeTol UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSTBOptionresgmresc ycle	string	custom	short	Spectre option resgmrescycle: Restarts GMRES cycle. Possible values are instant, short, long, recycleinstant, recycleshort, and recyclelong.
saSpectreHBSTBOptionresgmresc ycleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBSTBOptionsave	string	custom		Spectre option save: Signals to output. Possible values are all, lvi, allpub, lvi pub, selected, none, and nooutput.
saSpectreHBSTBOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSTBOptionsolver	string	custom	turbo	Spectre option solver: Solver type. Possible values are std, turbo, std_hh, and turbo_hh.
saSpectreHBSTBOptionsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSTBOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectreHBSTBOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSTBOptiontolerance	string	custom		Spectre option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saSpectreHBSTBOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBSTBOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectreHBSTBSpan	string	saTestbench		Spectre HBSTB: Span between sweep limits.
saSpectreHBSTBStart	string	saTestbench		Spectre HBSTB: Starting point of sweep limits.
saSpectreHBSTBStep	string	saTestbench		Spectre HBSTB: Linear step size.
saSpectreHBSTBStepSpecLin	string	saTestbench	Number of Steps	Spectre HBSTB: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreHBSTBStepSpecLog	string	saTestbench	Points per Decade	Spectre HBSTB: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectreHBSTBStop	string	saTestbench		Spectre HBSTB: Stopping point of sweep limits.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBSTBSweep	string	saTestbench	Logarithmic	Spectre HBSTB: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectreHBSTBSweepSpec	string	saTestbench	<file path>	Spectre HBSTB: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectreHBSTBValues	string	saTestbench		Spectre HBSTB: Individual values, also known as points of interest.
saSpectreHBSTBValuesfile	string	saTestbench		Spectre HBSTB: File for individual values
saSpectreHBStep	string	saTestbench		Spectre HB: Linear step size.
saSpectreHBStepSpecLin	string	saTestbench	Number of Steps	Spectre HB: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreHBStepSpecLog	string	saTestbench	Points per Decade	Spectre HB: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectreHBStop	string	saTestbench		Spectre HB: Stopping point of sweep limits.
saSpectreHBSub	string	saTestbench		Spectre HB: Subcircuit with parameter being swept.
saSpectreHBSweep	string	saTestbench	Linear	Spectre HB: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectreHBSweepSpec	string	saTestbench	<file path>	Spectre HB: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectreHBSweepVar	string	saTestbench	Temperature	Spectre HB: Specifies what will be swept ("Design Variable" "Temperature" "Instance Parameter" "Model Parameter" "Subcircuit Parameter").
saSpectreHBTstab	string	saTestbench		Spectre HB: Additional time for stabilization.
saSpectreHBValues	string	saTestbench		Spectre HB: Individual values, also known as points of interest.
saSpectreHBXFCenter	string	saTestbench		Spectre HBXF: Center point of sweep limits.
saSpectreHBXFCrossingdirection	string	saTestbench	all	Spectre HBXF: Crossing direction.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBXFDec	string	saTestbench		Spectre HBXF: Number of logarithmic steps per decade.
saSpectreHBXFExtrasampletimepoints	string	saTestbench		Spectre HBXF: Extra sample time points.
saSpectreHBXFLin	string	saTestbench		Spectre HBXF: Number of linear steps.
saSpectreHBXFLog	string	saTestbench		Spectre HBXF: Total number of logarithmic steps.
saSpectreHBXFMaxFreq	string	saTestbench		Spectre HBXF: Maximum Frequency
saSpectreHBXFMaxOrder	string	saTestbench	2	Spectre HBXF: Maximum Order
saSpectreHBXFMaxsamples	string	saTestbench		Spectre HBXF: Maximum number of sampled events.
saSpectreHBXFMaxsideband	string	saTestbench	1	Spectre HBXF: Maximum sideband.
saSpectreHBXFMinFreq	string	saTestbench		Spectre HBXF: Minimum Frequency
saSpectreHBXFOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, steps, and detailed_hb.
saSpectreHBXFOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBXFOptionfreqaxis	string	custom		Spectre option freqaxis: Specifies whether the results should be printed as per the input frequency, the output frequency, or the absolute value of the input frequency. The default is 'absin'. Possible values are absin, in, and out.
saSpectreHBXFOptionfreqaxisUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreHBXFOptionhbprecond_solver	string	custom	autoset	Spectre option hbprecond_solver: Select a linear solver for the GMRES preconditioner. Default is autoset. With autoset, the simulator will automatically select the appropriate preconditioner. The preconditioner affects the rate of convergence of the linear matrix solver used in periodic small-signal analysis. When autoset is selected, the simulator may decide to switch to a different preconditioner after the analysis begins. When that happens, the simulator may issue a warning instructing you to choose a different preconditioner during subsequent runs. Although not required, choosing a different preconditioner according to the simulator's instructions may speed up subsequent analyses. Possible values are basicsolver, blocksolver, autoset, blockdense, and blocksolver2.
saSpectreHBXFOptionhbprecond_solverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBXFOptionkrylovsize	string	custom	200	Spectre option krylov_size: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*krylov_size iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the krylov_size if the simulation reports insufficient norm reduction errors in GMRES.
saSpectreHBXFOptionkrylovsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBXFOptionlorentzian	string	custom	cornerfrequency	Spectre option lorentzian: This option determines if the Lorentzian plot is used in the oscillator noise analysis. 'lorentzian=yes' is only valid for 'noisetype=timeaverage'. Possible values are no, cornerfrequency, and yes.
saSpectreHBXFOptionlorentzianUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBXFOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreHBXFOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBXFOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectreHBXFOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBXFOptionrelativeTol	string	custom		Spectre option relativeTol: Relative tolerance for harmonic balance-based linear solver. Default value is 1.0e-2.
saSpectreHBXFOptionrelativeTolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBXFOptionresgmrescycle	string	custom	short	Spectre option resgmrescycle: Restarts GMRES cycle. Possible values are instant, short, long, recycleinstant, recycleshort, and recyclelong.
saSpectreHBXFOptionresgmrescycleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBXFOptionsave	string	custom		Spectre option save: Signals to output. Possible values are all, lvl, allpub, lvlpub, selected, none, and nooutput.
saSpectreHBXFOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBXFOptionstimuli	string	custom	sources	Spectre option stimuli: Stimuli used for XF analysis in hbnoise. Possible values are sources and nodes_and_terminals.
saSpectreHBXFOptionstimuliUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBXFOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectreHBXFOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBXFOptiontolerance	string	custom		Spectre option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saSpectreHBXFOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreHBXFOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectreHBXFOutputType	string	saTestbench	Voltage	Spectre HBXF: Output type.
saSpectreHBXFPTVtype	string	saTestbench	timeaveraged	Spectre HBXF: PTV analysis type.
saSpectreHBXFRelharmvec	string	saTestbench	1	Spectre HBXF: Harmonic index number for relative sweep.
saSpectreHBXFSampleratio	string	saTestbench		Spectre HBXF: The ratio between sampled frequency and fund frequency.
saSpectreHBXFSampleType	string	saTestbench	Probe	Spectre HBXF: The type of sampling trigger to use (Probe or Voltage).
saSpectreHBXFSelectSideband	string	saTestbench	1	Spectre HBXF: Select Sidebands from list
saSpectreHBXFSidebandType	string	saTestbench	Maximum Sideband	Spectre HBXF: Sideband type.
saSpectreHBXFSidevec	string	saTestbench	1	Spectre HBXF: Sidebands array.
saSpectreHBXFSpan	string	saTestbench		Spectre HBXF: Span between sweep limits.
saSpectreHBXFStart	string	saTestbench		Spectre HBXF: Starting point of sweep limits.
saSpectreHBXFStep	string	saTestbench		Spectre HBXF: Linear step size.
saSpectreHBXFStepSpecLin	string	saTestbench	Number of Steps	Spectre HBXF: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreHBXFStepSpecLog	string	saTestbench	Points per Decade	Spectre HBXF: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreHBXFStop	string	saTestbench		Spectre HBXF: Stopping point of sweep limits.
saSpectreHBXFSweep	string	saTestbench	Logarithmic	Spectre HBXF: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectreHBXFSweepSpec	string	saTestbench	<file path>	Spectre HBXF: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectreHBXFSweeptype	string	saTestbench	Default	Spectre HBXF: Frequency sweep type.
saSpectreHBXFThresholdvalue	string	saTestbench		Spectre HBXF: Threshold value.
saSpectreHBXFValues	string	saTestbench		Spectre HBXF: Individual values, also known as points of interest.
saSpectreHBXFValuesfile	string	saTestbench		Spectre HBXF: File for individual values
saSpectreHBZ0	string	saTestbench		Spectre HB:
saSpectreLibrariesImport	string	saTestbench	Import	Spectre libraries Import Setting.
saSpectreMeasuresImport	string	saTestbench	Import	Spectre measures Import Setting.
saSpectreModelGroups	string	saTestbench		Model groups for Spectre
saSpectreModelGroupsCheckBox	bool	saTestbench	false	Visibility of Model Groups table for Spectre. Valid values: true, false
saSpectreModelsImport	string	saTestbench	Import	Spectre models Import Setting.
saSpectreModelsIncludePath	string	user		Search path for Spectre model files.
saSpectreMonteCarloIterList	string	saTestbench		List of iterations.
saSpectreMonteCarloSaveFamilyPlots	string	saTestbench	1	Flag for saving of data that enables family plots for the Monte Carlo analysis.
saSpectreMonteCarloUserIterList	string	saTestbench	0	Use iteration list.
saSpectreMonteCarloVariationIncludeOrExclude	string	saTestbench	Include	Whether statistical variation is to be applied or not applied to the specified instances.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreMonteCarloVariationInstanceList	string	saTestbench		List of instances for which statistical variation is to be applied/not applied.
saSpectreNoiseCenter	string	saTestbench		Spectre Noise sweep: Center of sweep.
saSpectreNOISECenter	string	saTestbench		Spectre NOISE: Center point of sweep limits.
saSpectreNoiseDec	string	saTestbench		Spectre Noise sweep: Points per Decade.
saSpectreNOISEDec	string	saTestbench		Spectre NOISE: Number of logarithmic steps per decade.
saSpectreNoiseDesignVar	string	saTestbench		Spectre Noise sweep: Design Variable to sweep.
saSpectreNOISEDesignVar	string	saTestbench		Spectre NOISE: Design variable being swept.
saSpectreNoiseDev	string	saTestbench		Spectre Noise sweep: Instance containing parameter to sweep.
saSpectreNOISEDev	string	saTestbench		Spectre NOISE: Instance with parameter being swept.
saSpectreNoiseFreq	string	saTestbench		Spectre Noise sweep: Frequency (when not sweeping frequency).
saSpectreNOISEFreq	string	saTestbench		Spectre NOISE: Single value to hold frequency while other aspect is being swept.
saSpectreNoiseIprobe	string	saTestbench		Spectre Noise sweep: Input Probe: Refer the output noise to this component.
saSpectreNoiseLin	string	saTestbench		Spectre Noise sweep: Number of Steps (linear).
saSpectreNOISELin	string	saTestbench		Spectre NOISE: Number of linear steps.
saSpectreNoiseLog	string	saTestbench		Spectre Noise sweep: Number of Steps (logarithmic).
saSpectreNOISELog	string	saTestbench		Spectre NOISE: Total number of logarithmic steps.
saSpectreNoiseMod	string	saTestbench		Spectre Noise sweep: Model containing parameter to sweep.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreNOISEMod	string	saTestbench		Spectre NOISE: Model with parameter being swept.
saSpectreNoiseNegNode	string	saTestbench		Spectre Noise sweep: Negative output node.
saSpectreNoiseNode	string	saTestbench		Spectre Noise sweep: Positive output node.
saSpectreNoiseOprobe	string	saTestbench		Spectre Noise sweep: Compute total noise output at this component.
saSpectreNOISEOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptionforce	string	custom	none	Spectre option force: The set of initial conditions to use. Valid values: none, node, dev, and all.
saSpectreNOISEOptionforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptionnestlviUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptionoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptionprevoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptionreadforce	string	custom		Spectre option readforce: File that contains initial conditions.
saSpectreNOISEOptionreadforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreNOISEOptionrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptionseparateNoise	string	custom	no	Spectre option separateNoise: Separate noise into sources and transfer functions. Valid values: no and yes.
saSpectreNOISEOptionseparateNoiseUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptionskipdc	string	custom	no	Spectre option skipdc: Skip DC analysis. Valid values: no and yes.
saSpectreNOISEOptionskipdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptionuseprevic	string	custom	no	Spectre option useprevic: If set to yes or ns, use the converged initial condition from previous analysis as ic or ns. Valid values: no, yes, and ns.
saSpectreNOISEOptionuseprevicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectreNOISEOptionwrite	string	custom		Spectre option write: DC operating point output file at the first step of the sweep.
saSpectreNOISEOptionwritefinal	string	custom		Spectre option writefinal: DC operating point output file at the last step of the sweep.
saSpectreNOISEOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreNOISEOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreNoiseParam	string	saTestbench		Spectre Noise sweep: Parameter to sweep.
saSpectreNOISEParam	string	saTestbench		Spectre NOISE: Parameter being swept.
saSpectreNoiseSpan	string	saTestbench		Spectre Noise sweep: Span of sweep.
saSpectreNOISESpan	string	saTestbench		Spectre NOISE: Span between sweep limits.
saSpectreNoiseStart	string	saTestbench		Spectre Noise sweep: start.
saSpectreNOISEStart	string	saTestbench		Spectre NOISE: Starting point of sweep limits.
saSpectreNoiseStep	string	saTestbench		Spectre Noise sweep: Step Size (linear).
saSpectreNOISEStep	string	saTestbench		Spectre NOISE: Linear step size.
saSpectreNoiseStepSpecLin	string	saTestbench	Step Size	Spectre Noise sweep: Step spec.
saSpectreNOISEStepSpecLin	string	saTestbench	Number of Steps	Spectre NOISE: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreNoiseStepSpecLog	string	saTestbench	Points per Decade	Spectre Noise sweep: Step spec.
saSpectreNOISEStepSpecLog	string	saTestbench	Points per Decade	Spectre NOISE: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectreNoiseStop	string	saTestbench		Spectre Noise sweep: stop.
saSpectreNOISEStop	string	saTestbench		Spectre NOISE: Stopping point of sweep limits.
saSpectreNOISESub	string	saTestbench		Spectre NOISE: Subcircuit with parameter being swept.
saSpectreNoiseSummaryAbsolute Threshold	string	user	0	Noise Summary Truncate Absolute Threshold.
saSpectreNoiseSummaryIncludeBreakdown	string	user	0	Noise Summary Include Noise Breakdown.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreNoiseSummaryNoiseCategory	string	user	Total	Noise Summary Results To Be Shown.
saSpectreNoiseSummaryNoiseOption	saSpectreNoiseSummaryNoiseOptionEnum	user	Spot Noise	Noise Summary Option. Valid values: {Spot Noise} {Integrated Noise}
saSpectreNoiseSummaryRelativeThreshold	string	user	0	Noise Summary Truncate Relative Threshold.
saSpectreNoiseSummarySumIteratedInstances	string	user	true	Noise Summary Sum Iterated Instances.
saSpectreNoiseSummaryTopContributors	string	user	100	Noise Summary Truncate Top Contributors.
saSpectreNoiseSummaryTruncateType	string	user	By Contribution	Noise Summary Truncate Type.
saSpectreNoiseSummaryUnit	string	user	<file path>	Noise Summary Unit.
saSpectreNoiseSweep	string	saTestbench	Frequency (Hz)	Spectre Noise sweep: Sweep variable.
saSpectreNOISESweep	string	saTestbench	Logarithmic	Spectre NOISE: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectreNoiseSweepSpec	string	saTestbench	Start/Stop	Spectre Noise sweep: Sweep spec.
saSpectreNOISESweepSpec	string	saTestbench	<file path>	Spectre NOISE: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectreNoiseSweepType	string	saTestbench	Linear	Spectre Noise sweep: Sweep type.
saSpectreNOISESweepVar	string	saTestbench	Frequency (Hz)	Spectre NOISE: Specifies what will be swept ("Frequency (Hz)" "Design Variable" "Temperature" "Instance Parameter" "Model Parameter" "Subcircuit Parameter").
saSpectreNoiseValues	string	saTestbench		Spectre Noise sweep: points.
saSpectreNOISEValues	string	saTestbench		Spectre NOISE: Individual values, also known as points of interest.
saSpectreNOISEValuesfile	string	saTestbench		Spectre NOISE: File for individual values

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionahdldomainerror	string	custom	warning	Spectre option ahldomainerror: AHDL domain error handling selector. If ahldomainerror=error, incorrect AHDL domain input is treated as an error; If ahldomainerror=warning, incorrect AHDL domain input is treated as warning; If ahldomainerror=none, AHDL domain error is ignored. Valid values: error, warning, none, erroriter, and warniter.
saSpectreOptionahdldomainerrorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionamsiprobes	string	custom	no	Spectre option amsiprobes: Insert iprobes when computing MDL-related terminal currents. Valid values: no and yes.
saSpectreOptionamsiprobesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionannotateonalter	string	custom	yes	Spectre option annotateonalter: Annotate on all alter statements. Valid values: no and yes.
saSpectreOptionannotateonalterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionapproxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionassertssilentinit	string	custom	[...]	Spectre option asserts_silent_init: Array of asserts or assert groups which don't generate message during initializing.
saSpectreOptionassertssilentinitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionauditUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionautominductor	string	custom	no	Spectre option auto_minductor: Automatic insertion of missing mutual inductor coupling. For more information, see detailed description below the parameter descriptions. Valid values: no and yes.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionautominductorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionautosavecurvolt	string	custom	no	Spectre option autosavecurvolt: Automatically save terminal currents and node voltage. Valid values: no and yes.
saSpectreOptionautosavecurvoltUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionautostop	string	custom	no	Spectre option autostop: If yes, tran analysis is terminated when all event-type measurement expressions have been evaluated. Event-type expressions use thresholding, event, or delay type functions. If the value is spice, autostop is consistent with spice simulator. Valid values: no, yes, and spice.
saSpectreOptionautostopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionBHTNewEval	string	custom	1	Spectre option BHT_New_Eval: Option to choose which kind of evaluate function to use, 0 for old version with Vciei derivatives and 1 for new one without Vciei derivatives.
saSpectreOptionBHTNewEvalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionbinrelref	string	custom	no	Spectre option bin_relref: When a global relref is used, signals share a common reference value for convergence checks. If there is a large voltage in the circuit this can artificially relax convergence checks for other signals. This option creates voltage bins so that large voltages do not impact nodes with small voltage swings. Valid values: no and yes.
saSpectreOptionbinrelrefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioncclamp	string	custom	0.0	Spectre option cclamp: All capacitors with C<=cclamp are clamped to 'cclamp'.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionccclampUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioncccut	string	custom	-infinity	Spectre option ccut: Capacitors with $C \leq \text{ccut}$ are replaced by open. ccut can additionally be applied to variable capacitors using the option 'short_cut_var_elem=yes'.
saSpectreOptioncccutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioncgnd	string	custom	-infinity	Spectre option cgnd: Coupling capacitors with $C \leq \text{cgnd}$ are split into 2 grounded capacitors with same C value.
saSpectreOptioncgndUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionchargeabstol	string	custom	1.0e-21	Spectre option chargeabstol: Charge absolute tolerance convergence criterion.
saSpectreOptionchargeabstolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioncheckformat	string	custom	xml	Spectre option check_format: Determine the format of the checker violation report. Valid values: xml, text, and sql.
saSpectreOptioncheckformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionchecklimitdestUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionchecklimitdetails	string	custom	no	Spectre option checklimitdetails: Print detailed information of expression. Valid values: no and yes.
saSpectreOptionchecklimitdetailsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionchecklimitfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionchecklimitfullduration	string	custom	no	Spectre option checklimit_full_duration: If set to yes, assert violation includes the duration for which the violation takes place, and uses interpolation when the value exceeds the max/min bound value. Valid values: no and yes.
saSpectreOptionchecklimitfulldurationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionchecklimitskipfile	string	custom		Spectre option checklimit_skip_file: File which contains the subcircuit masters or subcircuit master patterns to be skipped in device checking. Patterns can have any wildcard symbols.
saSpectreOptionchecklimitskipfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionchecklimitskipieconnectdevices	string	custom	no	Spectre option checklimit_skip_ie_connect_devices: If set to yes, all devices connected to AMS IE elements will be skipped in device checking. Valid values: no and yes.
saSpectreOptionchecklimitskipieconnectdevicesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionchecklimitskipinsts	string	custom	[...]	Spectre option checklimit_skip_insts: Array of instances to be skipped in device checking. Instances can have any wildcard symbols.
saSpectreOptionchecklimitskipinstsfile	string	custom		Spectre option checklimit_skip_insts_file: File which contains the instances to be skipped in device checking. Instances can have any wildcard symbols.
saSpectreOptionchecklimitskipinstsfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionchecklimitskipinstsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionchecklimitskipsubs	string	custom	[...]	Spectre option checklimit_skip_subs: Array of subcircuit masters or subcircuit master patterns to be skipped in device checking. Patterns can have any wildcard symbols.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionchecklimitskipsub sUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionckptclockUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioncmax	string	custom	infinity	Spectre option cmax: All capacitors with $C \geq cmax$ are clamped to 'cmax'.
saSpectreOptioncmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioncmiopts	string	custom	[...]	Spectre option cmi_opts: The option for customer cmi.
saSpectreOptioncmioptsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioncolslog	string	custom	80	Spectre option colslog: Width of log-file in characters.
saSpectreOptioncolslogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioncolsUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saSpectreOptioncompatibleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioncscalefactor	string	custom	1e-3	Spectre option cscalefactor: Scaling factor for very large capacitor.
saSpectreOptioncscalefactorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptioncthresh	string	custom	1e38	Spectre option cthresh: Large capacitors can cause transient convergence problems, especially as the time-step shrinks. This is similar to the issues that small resistors cause. There is an alternative exact representation of a capacitor, which does not suffer from this problem, but can introduce an equation to be solved. If a capacitance is greater than cthresh, then the alternative formulation is used. Accuracy is not impacted by the change. The 'cthresh' option has lower priority than 'cthresh' parameter on the capacitor instance definition.
saSpectreOptioncthreshUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondcdiagnoseelements	string	custom	10	Spectre option dc_diagnose_elements: Number of elements connected to non-converge nodes in printing diagnose information in DC simulation.
saSpectreOptiondcdiagnoseelementsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondcdiagnosetime	string	custom	1800	Spectre option dc_diagnose_time: Time interval for printing out diagnose information in DC simulation.
saSpectreOptiondcdiagnosetimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondcmxitters	string	custom	5	Spectre option dcmxitters: Maximum number of Newton iterations in DC simulation.
saSpectreOptiondcmxittersUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondcmmod	string	custom	0	Spectre option dcmmod: DCMismatch analysis version selector. If set to 1 or 3, uses Bsim short-channel mismatch equation for BSIM3 and BSIM4 devices; if set to 2 or 3, provides compatibility with Monte Carlo analysis.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptiondcmmodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondcoptic	string	custom	aps1	Spectre option dcoptic: Initial condition for dcopt in DC simulation. Valid values: no, aps1, aps2, and xps.
saSpectreOptiondcoptictype	string	custom	nodeset	Spectre option dcoptictype: Initial condition type for dcopt in DC simulation. Valid values: nodeset and ic.
saSpectreOptiondcoptictypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondcopticUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondcoptmaxsteps	string	custom	300	Spectre option dcoptmaxsteps: Maximum number of steps for dcopt in DC simulation.
saSpectreOptiondcoptmaxstepsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondcopttol	string	custom	1e-8	Spectre option dcopttol: Tolerance used for dcopt DC analysis.
saSpectreOptiondcopttolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondcpivotcheck	string	custom	no	Spectre option dc_pivot_check: During DC analysis, the numeric pivoting is only performed when bad pivot is detected. Valid values: no and yes.
saSpectreOptiondcpivotcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondcut	string	custom	[...]	Spectre option dcut: Replaces all diode instances using the specified model definitions with an open. dcut=all cuts all diode elements.
saSpectreOptiondcutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptiondebugstepdrop	string	custom	no	Spectre option debugstepdrop: Generates warnings on dramatic step size drop and notices when step size is recovered. Valid values: no and yes.
saSpectreOptiondebugstepdropUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondebugUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondevcheckstat	string	custom	yes	Spectre option devcheck_stat: Enable or disable output device-checking statistics. Valid values: no and yes.
saSpectreOptiondevcheckstatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondevropt	string	custom	none	Spectre option devropt: If set to all, diode, or mosfet, connected resisotrs will be folded to related instances.. Valid values: none, all, diode, and mosfet.
saSpectreOptiondevroptUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondiagnosedumptopnum	string	custom	5	Spectre option diagnose_dump_topnum: Top number to dump single device netlist.
saSpectreOptiondiagnosedumptopnumUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondiagnoseend	string	custom		Spectre option diagnose_end: End time to enable the detailed diagnosis mode. Default is transient stop time.
saSpectreOptiondiagnoseendUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondiagnosestart	string	custom	0	Spectre option diagnose_start: Start time to enable the detailed diagnosis mode.
saSpectreOptiondiagnosestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptiondiagnoseUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondigitsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondioallowscaling	string	custom	no	Spectre option dio_allow_scaling: Use this flag to enable SCALE parameter for diode mode. Valid values: no and yes.
saSpectreOptiondioallowscalingUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondisablesavepreserve	string	custom	no	Spectre option disable_save_preserve: Disables preserve by save statements. If no, does not disable the save preserve. If yes, disables the save preserve. Valid values: no and yes.
saSpectreOptiondisablesavepreserveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondiskcheckautoresume	string	custom	no	Spectre option disk_check_autoresume: Automatically resume the simulation once the available disk space is larger than the specified threshold. Valid values: no and yes.
saSpectreOptiondiskcheckautoresumeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondiskcheckthresh	string	custom	1E8	Spectre option disk_check_thresh: The threshold of disk space check.
saSpectreOptiondiskcheckthreshUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondochecklimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondotprobeformat	string	custom	flat	Spectre option dotprobeformat: Print .probe signal with original name or hierarchical name. Valid values: flat and hier.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptiondotprobeformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondpf	string	custom		Spectre option dpf: This option specifies DPF file to be stitched and its stitching scope. The syntax is dpf="scope filename". The scope can be a subcircuit or an instance. Use "spectre -h stitch" for more information.
saSpectreOptiondpfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondptranmethod	string	custom	node	Spectre option dptran_method: Stamp gdev, gnode, or both in the dptran (homotopy) methods. Valid values: dev, node, and both.
saSpectreOptiondptranmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondptranmaxsteps	string	custom	300	Spectre option dptranmaxsteps: Maximum number of steps for dptran in fast DC simulation.
saSpectreOptiondptranmaxstepsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondspfnodename	string	custom	original	Spectre option dspf_nodename: When original, the current behavior, .connect is created for nodes cut by DSPF translator. When net_only, it is the only net name in DSPF file that is used to match the wild card in .probe/.ic statements. The hierarchical structure of the net name is restored like pre-layout netlist. When all, the net name in DSPF file is stored as pre-layout node name, and the nodes in DSPF file are preserved like the current behavior. The wild card in .probe/.ic will match all the nodes and net names. Valid values: original, net_only, and all.
saSpectreOptiondspfnodenameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptiondumpglobaloptions	string	custom	0	Spectre option dump_global_options: Internal option for RelXpert to dump all the global options. By default it is closed.
saSpectreOptiondumpglobaloptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiondumpwildcardinfo	string	custom	no	Spectre option dump_wildcard_info: Dump wildcard matching details in save statement into a single file. Valid values: no and yes.
saSpectreOptiondumpwildcardinfoUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionduplicateinstance	string	custom	error	Spectre option duplicateinstance: Specify whether duplicate instance definitions are allowed. When set to warning or ignore, the simulator allows duplicate instance definitions. However, it honors only the last instance definition. Depending on the value that is set, the simulator displays warning messages for the duplicate instance definitions or does not display any message. When set to error, the simulator does not allow duplicate instance definitions and displays an error message. Valid values: error, ignore, and warning.
saSpectreOptionduplicateinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionduplicatemodel	string	custom	error	Spectre option duplicatemodel: Specify whether duplicate model definitions are allowed. When set to warning or ignore, the simulator allows duplicate model definitions. However, it honors only the last model definition. Depending on the value that is set, the simulator displays warning messages for the duplicate model definitions or does not display any message. When set to error, the simulator does not allow duplicate model definitions and displays an error message. Valid values: error, ignore, and warning.
saSpectreOptionduplicatemodelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionduplicateModule	string	custom	error	Spectre option duplicate_module: Specifies whether the duplicate module definitions are allowed. When set to warning or ignore, the simulator allows duplicate module definitions. However, it honors only the last module definition. Depending on the value that is set, the simulator decides whether to display warning messages for the duplicate module definitions or not. When set to error, the simulator does not allow the duplicate module definitions and displays an error message. Valid values: error, ignore, and warning.
saSpectreOptionduplicateModuleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionduplicatePorts	string	custom	error	Spectre option duplicate_ports: Specify whether duplicate ports are allowed in the definition of the subcircuit. When set to warning or ignore, the duplicate ports are shorted. Depending on the value that is set, the simulator displays warning messages for the duplicate ports or does not display any message. When set to error, the simulator does not allow duplicate ports in the definition of the subcircuit and displays an error message. Valid values: error, ignore, and warning.
saSpectreOptionduplicatePortsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionduplicatesubckt	string	custom	error	Spectre option duplicate_subckt: Specify whether duplicate subcircuit definitions are allowed. When set to warning or ignore, the simulator allows duplicate subcircuit definitions. However, it honors only the last subcircuit definition. Depending on the value that is set, the simulator displays warning messages for the duplicate subcircuit definitions or does not display any message. When set to error, the simulator does not allow duplicate subcircuit definitions and displays an error message. Valid values: error, ignore, and warning.
saSpectreOptionduplicatesubcktUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionerrorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionetmildsMod	string	custom	0	Spectre option etmildsMod: Switch to select lds or total DC drain current for TMI core data ids.
saSpectreOptionetmildsModUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionetmiprintfd	string	custom	0	Spectre option etmiprintfd: Output the TMI result file. By default it is closed.
saSpectreOptionetmiprintfdUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionetmiusrinput	string	custom		Spectre option etmiusrinput: This option can be set in model files or netlists.
saSpectreOptionetmiusrinputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionexportfile	string	custom		Spectre option exportfile: oceanEval output file name.
saSpectreOptionexportfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionfixsingularmatrix	string	custom	no	Spectre option fix_singular_matrix: Fix matrix singular issue by inserting gmin. Valid values: no, yes, print, and both.
saSpectreOptionfixsingularmatrixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionflowUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiongennetlistdir	string	custom	no	Spectre option gennetlistdir: Output netlist directory in logfile. Valid values: no and yes.
saSpectreOptiongennetlistdirUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptiongformvcr	string	custom		Spectre option gform_vcr: Use Gform for VCR device. Specify 1 for yes and 0 for no. Default is no.
saSpectreOptiongformvcrUncheck Localized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiongmethod	string	custom	dev	Spectre option gmethod: Stamp gdev, gnode, or both in the homotopy methods (other than dptran). See the detailed description below the parameter descriptions for more information. Valid values: dev, node, and both.
saSpectreOptiongmethodUncheck Localized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiongmincheckUnche ckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiongmindc	string	custom	1e-12	Spectre option gmindc: Minimum conductance across each non-linear device in DC analysis. If gmindc is not specified, the value of gmindc will be equal to gmin. Default value is 1.0e-12.
saSpectreOptiongmindcmax	string	custom		Spectre option gmindcmax: The maximum value that gmindc can be increased to during the automatically increasing gmindc method for convergence. The default value is gmindc.
saSpectreOptiongmindcmaxUnche ckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiongmindcUncheckL ocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiongminstart	string	custom	1.0	Spectre option gmin_start: Initial gmin in gmin-stepping (homotopy) methods.
saSpectreOptiongminstartUncheck Localized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiongminUncheckLoc alized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptiongshdc	string	custom	0.0	Spectre option gshdc: Minimum conductance added for all nodes in dc analysis.
saSpectreOptiongshdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiongshunt	string	custom	0.0	Spectre option gshunt: Minimum conductance added for all nodes in tran analysis.
saSpectreOptiongshuntdc	string	custom	0.0	Spectre option gshuntdc: Minimum conductance added for all nodes in dc analysis.
saSpectreOptiongshuntUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionhierambiguity	string	custom	strict	Spectre option hier_ambiguity: The default value is strict. When set to lower, the simulator will partially flatten the hier name from the back to check if an object can be found. Lower is not recommended. Valid values: strict and lower.
saSpectreOptionhierambiguityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionhierdelimiter	string	custom	.	Spectre option hier_delimiter: Used to set hierarchical delimiter. Length of hier_delimiter should not be longer than 1, except the leader escape character.
saSpectreOptionhierdelimiterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionhierprobe	string	custom	hier	Spectre option hierprobe: Print .probe signal hierarchically or flatten. Valid values: flat and hier.
saSpectreOptionhierprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionhighvoltage	string	custom	no	Spectre option highvoltage: Enable optimized Spectre settings for high voltage designs including voltage, and current binning, excluding VerilogA and dangling nodes from convergence checks, and optimized large capacitance handling. Valid values: no and yes.
saSpectreOptionhighvoltageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionhomotopyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioniabstolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioniccapcheck	string	custom	yes	Spectre option iccapcheck: Check if nodes with initial conditions have capacitive path to ground. IC for the node without capacitance is treated as nodeset. Valid values: no and yes.
saSpectreOptioniccapcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionicpriority	string	custom	netlist	Spectre option icpriority: Set the ic priority order. If set to netlist, the order from lowest to highest is readNS, netlist NS, readIC, netlist IC. If set to file, the order from lowest to highest is netlist NS, readNS, netlist IC readIC. Valid values: file and netlist.
saSpectreOptionicpriorityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionicversion	string	custom	1	Spectre option icversion: Convert initial condition to initial guess, when .ic statements exist in the netlist and there are no other options to set IC or nodeset.
saSpectreOptionicversionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionignshortsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionimplicitsubcktparam	string	custom	no	Spectre option implicit_subckt_param: Allows the implicit parameter to be declared for the spectre format. Valid values: no and yes.
saSpectreOptionimplicitsubcktparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioninfoUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioninlinesubcktcurrent	string	custom	subckt	Spectre option inlinesubcktcurrent: Save inline subcircuit terminal current as inline device current or subcircuit current. By default, inline subckt current is saved. Valid values: device and subckt.
saSpectreOptioninlinesubcktcurrentUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptioninventoryUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionirefbins	string	custom	[...]	Spectre option irefbins: Specifies the current bins when bin_irelref=yes is used. Default setting is irefbins=[1e-6 1e-5 1e-4 1e-3 1e-2 1e-1].
saSpectreOptionirefbinsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionishrink	string	custom	1.0	Spectre option ishrink: Ishrink factor.
saSpectreOptionishrinkUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionivthl	string	custom	0.0	Spectre option ivthl: Length offset for constant current Vth.
saSpectreOptionivthlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionivthn	string	custom	0.0	Spectre option ivthn: NMOS Vth current parameter.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionivthnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionivthp	string	custom	0.0	Spectre option ivthp: PMOS Vth current parameter.
saSpectreOptionivthpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionivthvdsmin	string	custom	0.05	Spectre option ivth_vdsmin: Minimum Vds in constant current Vth calculation public.
saSpectreOptionivthvdsminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionivthw	string	custom	0.0	Spectre option ivthw: Width offset for constant current Vth.
saSpectreOptionivthwUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionkcut	string	custom	0.0	Spectre option kcut: Fixed value mutual inductors with absolute value of $K \leq kcut$ are replaced by an open. kcut can additionally be applied to variable value mutual inductors using the option 'short_cut_var_elem=yes'. Default value is 0 in Spectre, and 1m in APS.
saSpectreOptionkcutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionkmax	string	custom	no	Spectre option kmax: Sets 1.0 as the maximum absolute value for coupling co-efficient of mutual inductors. Valid values: no and yes.
saSpectreOptionkmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionleakitimes	string	custom	[...]	Spectre option leaki_times: Specifies input-steady state time points.
saSpectreOptionleakitimesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionlimitdiagpivot	string	custom	yes	Spectre option limit_diag_pivot: If set to yes, there is a limit on the number of matrix fill-ins when selecting a pivot from a diagonal. For backward compatibility, set this option to no. Valid values: no and yes.
saSpectreOptionlimitdiagpivotUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionlimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionlocalmeas	string	custom	no	Spectre option local_meas: Specify whether local measurements definitions are allowed. When set to ignore, the simulator allows local measurements definitions. Depending on the value that is set, the simulator displays warning messages for the local measurements definitions or does not display any message. When set to warning, the simulator does not allow and ignores the local measurement definitions with a warning message. Valid values: no and yes.
saSpectreOptionlocalmeasUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionlshort	string	custom	0	Spectre option lshort: Fixed value inductors with L<=lshort are shorted. lshort can additionally be applied to variable value inductors using the option 'short_cut_var_elem=yes'.
saSpectreOptionlshortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmacromos	string	custom	[...]	Spectre option macro_mos: The list of subcircuit names, which is a macro model.
saSpectreOptionmacromosUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmaxapproachminstep	string	custom	300	Spectre option max_approach_minstep: The maximum number of times allowed to approach minstep within 5% of stop time.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionmaxapproachminstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmaxconsecutiveminstep	string	custom	1000	Spectre option max_consecutive_minstep: The maximum number of consecutive steps allowed to be less than 10*minstep.
saSpectreOptionmaxconsecutiveminstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmaxdeltav	string	custom	0.3	Spectre option maxdeltav: Maximum change in voltage allowed per Newton iteration when limit=delta (default 0.3 V) or limit=l2 (default 10 V).
saSpectreOptionmaxdeltavUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmaxminstepnonconv	string	custom	200	Spectre option max_minstep_nonconv: The maximum number of convergence failures allowed below minstep within 5% of stop time.
saSpectreOptionmaxminstepnonconvUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmaxnotestologfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmaxnotesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmaxphysicalflux	string	custom	infinity	Spectre option maxphysicalflux: Maximum physical flux allowed in solution.
saSpectreOptionmaxphysicalfluxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmaxphysicali	string	custom	infinity	Spectre option maxphysicali: Maximum physical current allowed in solution.
saSpectreOptionmaxphysicaliUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionmaxphysicalmmf	string	custom	infinity	Spectre option maxphysicalmmf: Maximum physical magnetomotive force allowed in solution.
saSpectreOptionmaxphysicalmmfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmaxphysicalunitless	string	custom	infinity	Spectre option maxphysicalunitless: Maximum physical unitless signals allowed in solution.
saSpectreOptionmaxphysicalunitlessUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmaxphysicalv	string	custom	infinity	Spectre option maxphysicalv: Maximum physical voltage allowed in solution.
saSpectreOptionmaxphysicalvUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmaxwarnstologfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmaxwarnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmdlanalysisnames	string	custom	rename	Spectre option mdlanalysisnames: Flag to indicate whether or not to keep spectre analysis name in MDL flow. Valid values: rename and original.
saSpectreOptionmdlanalysisnamesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmdlthresholds	string	custom	exact	Spectre option mdlthresholds: When set to exact, certain functions in MDL, for example, cross(), control the transient time-step to place a time-point at a threshold crossing. This can improve accuracy. However for applications such as cell characterization an interpolated value can give the required accuracy with better performance.. Valid values: exact and interpolated.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionmdlthresholdsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmdltrigtargmode	string	custom	cross	Spectre option mdltrigtargmode: This option specifies how to evaluate the trig and targ of the hspice and the output format. If mdltrigtargmode = deltax, we will use the deltax function to evaluate the trig and targ function. If mdltrigtargmode = cross, we will use the cross function to evaluate the trig and targ function. If mdltrigtargmode = details, we will output the trig and targ middle results. Valid values: deltax, cross, and details.
saSpectreOptionmdltrigtargmodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmeasdg	string	custom	0	Spectre option measdg: Number of decimal digits (in floating point numbers) in measurement output in mt0 format.
saSpectreOptionmeasdgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionminr	string	custom	0.0	Spectre option minr: All parasitic resistors inside devices less than global minr will be removed. The order of checking devices is the follows: 1. Check if resistors are smaller than local minr. If yes, check if it is a MOSFET or BJT. If it is a MOSFET, drop the resistor, if it is BJT, clamp to the minr value, and give a warning message for both cases. 2. Check global minr, All Parasitic resistors less than global minr are removed and a warning message is issued. 3. If the resistor is not removed and is smaller than 0.001, issue a warning.
saSpectreOptionminrmfactor	string	custom	scaled	Spectre option minr_mfactor: whether minr will be scaled. Valid values: scaled and ignore.
saSpectreOptionminrmfactorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionminrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionminstepversion	string	custom	1	Spectre option minstepversion: Minstep algorithm flow control. If minstepversion=0, desperate big jump is taken when minstep is reached. If minstepversion=1, a forward/backward search algorithm is taken to find a converged solution at small step size. By default, minstepversion=1.
saSpectreOptionminstepversionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmismatchlevel	string	custom	0	Spectre option mismatchlevel: With default, mismatch parameter is defined based on parameter scope concept: mismatch parameter can only have one value in one scope. For example, if a mismatch parameter appears multiple times in a subckt of the netlist, that mismatch parameter has a unique value in that subckt for each Monte Carlo run. With mismatchlevel=1, the mismatch parameter is allowed to have a different value for each appearance in the same scope. Valid values: 0 and 1.
saSpectreOptionmismatchlevelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmspartreport	string	custom	0	Spectre option ms_part_report: Depth of the ms partition report, default is 0, disabled.
saSpectreOptionmspartreportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmsvgnd	string	custom		Spectre option ms_vgnd: The virtual ground node names, globally.
saSpectreOptionmsvgndUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmsvgndv	string	custom	0	Spectre option ms_vgndv: The voltage value for the virtual power network grounds in scope.
saSpectreOptionmsvgndvUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionmsvpn	string	custom		Spectre option ms_vpn: The virtual power node names, globally.
saSpectreOptionmsvpnistart	string	custom	0.0	Spectre option ms_vpni_start: MS mode start time to have accurate currents. enable vpn current feedback after this time.
saSpectreOptionmsvpnistartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmsvpnistop	string	custom	0.0	Spectre option ms_vpni_stop: MS mode stop time to have accurate currents. disable vpn current feedback after this time.
saSpectreOptionmsvpnistopUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saSpectreOptionmsvpnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmsvpnv	string	custom	0	Spectre option ms_vpnv: The voltage value for the virtual power network sources in scope.
saSpectreOptionmsvpnvUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmtlinecachedir	string	custom		Spectre option mtlinecachedir: The directory in which the mtline RLGC data file will be written. If an absolute path is not given, the file will be written to /home//.cadence/mmsim/.
saSpectreOptionmtlinecachedirUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmtlineemsolver	string	custom	cpl	Spectre option mtlineemsolver: EM 2D solver for transmission line. Valid values: lmg and cpl.
saSpectreOptionmtlineemsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmtlinereuse	string	custom	yes	Spectre option mtlinereuse: This parameter defines whether to reuse RLGC data for all mtline instances. If no, this feature is disabled. Valid values: no and yes.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionmtlinereuseUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionmultithreadUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnarrateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnewton	string	custom	normal	Spectre option newton: Method used on DC analysis. You can specify methods newton=[none normal], and the default value is normal. Valid values: none and normal.
saSpectreOptionnewtonUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnoiseoffinst	string	custom	[...]	Spectre option noiseoff_inst: The list of instances not to be considered as noisy throughout noise analyses, which include noise, sp noise, pnoise and tran noise.
saSpectreOptionnoiseoffinstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnoiseofftype	string	custom	all	Spectre option noiseoff_type: The noiseoff_type defines the noise sources which are disabled by the noiseon/off_inst option. The default value is all. Valid values: thermal, flicker, shot, ign, and all.
saSpectreOptionnoiseofftypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnoiseoninst	string	custom	[...]	Spectre option noiseon_inst: The list of instances to be considered as noisy throughout noise analysis, which include, noise, sp noise, pnoise and tran noise.
saSpectreOptionnoiseoninstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionnoiseontype	string	custom	all	Spectre option noiseon_type: The noiseon_type defines the noise sources which are enabled by the noiseon/off_inst option. The default value is all. Valid values: thermal, flicker, shot, ign, and all.
saSpectreOptionnoiseontypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnonconvtopnum	string	custom	10	Spectre option nonconv_topnum: Top number of non-convergence nodes to be printed public.
saSpectreOptionnonconvtopnumUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnotationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnoteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnportbbsfittedfiledir	string	custom		Spectre option nportbbsfittedfiledir: The directory to which the BBSpice fitted S-Parameter file will be put. If it is not specified, the file will be in directory named as 'BBSpiceOutput'. If a relative path is specified, the path is relative to the current working directory.
saSpectreOptionnportbbsfittedfiledirUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnportcompress	string	custom	yes	Spectre option nportcompress: Nport compression improves the efficiency of S-parameter simulation of large nport files when a certain percentage of the ports is unused, i.e., open or short circuited. Nport compression does not impact simulation accuracy. This option turns off compression if set to no and attempts to force compression if set to yes. If left unspecified, compression is on if N>=10 and the ratio of used ports is less than or equal to 0.8. Valid values: no, yes and unspecified. Valid values: no and yes.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionnportcompressfiledir	string	custom		Spectre option nportcompressfiledir: The directory where the compressed nport S-parameter file is written to. If unspecified, it is stored in outdir.
saSpectreOptionnportcompressfiledirUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnportcompressUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnportdefaultpassivity	string	custom	disable	Spectre option nport_default_passivity: Check and enforce passivity of S-parameter for all nport instances. Default is 'disable', which means this global option has no effect. If set to a value other than 'disable', all nport elements in the netlist without a value for 'passivity' explicitly set, will have their 'passivity' argument set to the same value as specified in this global option. If an nport instance already has the 'passivity' option specified, the instance option will take priority if both are present. Valid values: no, check, enforce, fit_weak_enforce, fit_enforce, and disable.
saSpectreOptionnportdefaultpassivityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnportirfiledir	string	custom		Spectre option nportirfiledir: The directory to which the nport impulse response file will be written. If it is not specified, the file will be written to /home//.cadence/mmsim/. If a relative path is specified, the path is relative to the current working directory.
saSpectreOptionnportirfiledirUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saSpectreOptionnportirreuse	string	custom	yes	Spectre option nportirreuse: Reuse impulse responses data for all nport instances. If no, disable this feature. Valid values: no and yes.
saSpectreOptionnportirreuseUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionnportunusedportgmin	string	custom	0.0	Spectre option nportunusedportgmin: Default is 0, which leaves the port open-circuited. A small value loads open-circuited ports with a finite but large resistance. This introduces a small error in the response, but it induces losses which help obtain a passive response.
saSpectreOptionnportunusedportgminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnportunusedportrmin	string	custom	0.0	Spectre option nportunusedportrmin: Default is 0, which leaves the port short-circuited. A small value will insert a small resistance in place of short circuited ports. This introduces a small error in the response, but it induces losses which help obtain a passive response.
saSpectreOptionnportunusedportrminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionnthreadsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionopptcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionoptimizebsimcmg	string	custom	no	Spectre option optimize_bsimg: Enable the optimization in bsimg evaluation. Valid values: no and yes.
saSpectreOptionoptimizebsimcmgUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionoptimizebsource	string	custom	no	Spectre option optimize_bsource: Enable the optimization in bsource evaluation. Valid values: no and yes.
saSpectreOptionoptimizebsourceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionoptimizediode	string	custom	no	Spectre option optimize_diode: Enable the optimization in diode evaluation. Valid values: no and yes.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionoptimizediodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionoscoutputport	string	custom		Spectre option osc_output_port: Output raw data file name.
saSpectreOptionoscoutputportUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionoserandommod	string	custom	0	Spectre option ose_random_mod: Use OSE Random Method. Valid values: 0 and 1.
saSpectreOptionoserandommodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionoutputcompactmapping	string	custom	0	Spectre option output_compact_mapping: Internal option for RelXpert to output compact mapping file. By default it is closed.
saSpectreOptionoutputcompactmappingUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionparamrangefileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionparamtopchange	string	custom	yes	Spectre option param_topchange: If set to yes, Spectre will support parametric topology change caused by device internal node changes when the device, model, or netlist parameter value is altered. Valid values: no and yes.
saSpectreOptionparamtopchangeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionparasitics	string	custom		Spectre option parasitics: Set parasitics for RC reduction. When used as the scoped option, specify the "+mts" command line option. The option has higher priority than the value from the command line option, "+parasitics". When used as a global option, the value from the command line, "+parasitics", has a higher priority.
saSpectreOptionparasiticsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionpassfailreverselogic	string	custom	no	Spectre option passfail_reverse_logic: Pass fail bisection treats NaN as PASS, while not NaN value as FAIL. Valid values: no and yes.
saSpectreOptionpassfailreverselogicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionpivabsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionpivotdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionpivrelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionportmismatchseverity	string	custom	error	Spectre option portmismatch_severity: If set ignore/warn/error out when ports number mismatch for subckt. Valid values: error, ignore, and warning.
saSpectreOptionportmismatchseverityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionprecision	string	custom	%g	Spectre option precision: Format specification of double for psfascii. Example: "%15.12g" outputs 12 decimal digits in mantissa. The default value "%g" prints 6 decimal digits.
saSpectreOptionprecisionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionpreorder	string	custom	partial	Spectre option preorder: Try this option when simulation runs out of memory or if the simulation is unreasonably slow for the size of your design. It controls the amount of matrix reordering that is done and may lead to much fewer matrix fill-ins in some cases. Known cases include designs with very large number of small resistors and large number of behavioral instances containing voltage based equations. Valid values: partial, full, and limited.
saSpectreOptionpreorderUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionpreserveassert	string	custom	lazy	Spectre option preserve_assert: Whether to execute the preservation for voltage check for assert statements. If the value is lazy, only execute the preservation for current checking; otherwise it will execute complete preservation. Valid values: lazy and force.
saSpectreOptionpreserveassertUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionpreserveinst	string	custom		Spectre option preserve_inst: Preserve the instances specified in the vector. Use 'preserve_inst=all' to preserve all instances.
saSpectreOptionpreserveinstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionpreservemaster	string	custom	[...]	Spectre option preserve_master: Preserve all instances of the masters specified.
saSpectreOptionpreservemasterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionpreservenode	string	custom	none	Spectre option preservenode: If set to all, node in save statement will be preserved. Valid values: none, all, and explicit.
saSpectreOptionpreservenodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionpreservesubckt	string	custom	[...]	Spectre option preserve_subckt: Preserve all instances within the subcircuits specified.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionpreservesubcktUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionprintincluding	string	custom	no	Spectre option print_including: Enable Spectre/Ultrsim to print including information in include statement. Valid values: no and yes.
saSpectreOptionprintincludingUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionprintsection	string	custom	no	Spectre option print_section: If yes, output sections used in simulations. If no, do not output sections. Valid values: no and yes.
saSpectreOptionprintsectionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionprintstep	string	custom	no	Spectre option printstep: Enable Spectre to print results by equal step defined in .tran statement. Valid values: no and yes.
saSpectreOptionprintstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionprobecompatible	string	custom	spectre	Spectre option probe_compatible: Flag to enable or disable optimization for probe wildcard statement. Valid values: hspice and spectre.
saSpectreOptionprobecompatibleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionptranmaxsteps	string	custom	200	Spectre option ptranmaxsteps: Maximum number of steps for ptran phase in DC simulation.
saSpectreOptionptranmaxstepsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionqcut	string	custom	[...]	Spectre option qcut: Replaces all BJT instances using the specified model definitions with an open. qcut=all cuts all BJT elements.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionqcutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionquantitiesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrabsclamp	string	custom	0.0	Spectre option rabsclamp: All fixed value and variable resistors with absolute value of $R \leq rabsclamp$ are clamped to 'rabsclamp'.
saSpectreOptionrabsclampUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrabsshort	string	custom		Spectre option rabsshort: When this option is set, all fixed value resistors with absolute value of $R \leq rabsshort$ are shorted. Default value is 0 for Spectre, and 1m for APS. Rabsshort can additionally be applied to variable resistors using the option 'short_cut_var_elem=yes'.
saSpectreOptionrabsshortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrampsource	string	custom	yes	Spectre option rampsource: When performing dc hysteresis sweep, rampsource should be set to no. Valid values: no and yes.
saSpectreOptionrampsourceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrclampbsource	string	custom		Spectre option rclamp_bsource: When rclamp_bsource=value is given, all instance bsource resistors with $R < value$ are clamped to value. It has high priority than rclamp if both are set. Default is 0.001 Ohm for bsource resistor.
saSpectreOptionrclampbsourceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcnetsave	string	custom	all	Spectre option rcnet_save: Flag to enable filter internal RC nodes for probe/save statement. Valid values: all and portonly.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionrcnetsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrcgnd	string	custom	1.00E-18	Spectre option rcr_cgnd: this parameter is used to set the minimum value of capacitance that should be decoupled to ground.
saSpectreOptionrcrcgndUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrfmax	string	custom	1	Spectre option rcr_fmax: this parameter is used to set the max frequency used by rc reduction.
saSpectreOptionrcrfmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetactivebitlineonly	string	custom	0	Spectre option rcr_net_active_bit_line_only: When set to 1, short all resistors of the parasitic networks that are connected to an active bit-line.
saSpectreOptionrcrnetactivebitlineonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetactivestateonly	string	custom	0	Spectre option rcr_net_active_state_only: When set to 1, short all resistors of the parasitic networks that are connected to an active state.
saSpectreOptionrcrnetactivestateonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetactivewordlineonly	string	custom	0	Spectre option rcr_net_active_word_line_only: When set to 1, short all resistors of the parasitic networks that are connected to an active word-line.
saSpectreOptionrcrnetactivewordlineonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionrcrnetcgnd	string	custom	1.00E-18	Spectre option rcr_net_cgnd: this parameter is used by the rc net flow to set the minimum value of capacitance that should be decoupled to ground.
saSpectreOptionrcrnetcgndUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetidlebitlineconly	string	custom	0	Spectre option rcr_net_idle_bit_line_conly: When set to 1, short all resistors of the parasitic networks that are connected to an idle bit-line.
saSpectreOptionrcrnetidlebitlineconlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetidlestateconly	string	custom	0	Spectre option rcr_net_idle_state_conly: When set to 1, short all resistors of the parasitic networks that are connected to an idle state.
saSpectreOptionrcrnetidlestateconlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetidlestatevpnconly	string	custom	0	Spectre option rcr_net_idle_state_vpn_conly: When set to 1, short all resistors of VPN parasitic networks that are connected to idle state parasitic networks.
saSpectreOptionrcrnetidlestatevpnconlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetidlewordlineconly	string	custom	0	Spectre option rcr_net_idle_word_line_conly: When set to 1, short all resistors of the parasitic networks that are connected to an idle word-line.
saSpectreOptionrcrnetidlewordlineconlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetmergepnidlestateports	string	custom	0	Spectre option rcr_net_merge_pn_idle_state_ports: When set to 1, allows merging of those ports of power or vpn parasitic networks, that are connected to idle state nodes.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionrcrnetmergepnidle stateportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetpreserveactivebitlineports	string	custom	0	Spectre option rcr_net_preserve_active_bit_line_ports: When set to 1, preserves ports of parasitic networks that are connected to an active bit-line node.
saSpectreOptionrcrnetpreserveactivebitlineportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetpreserveactivestateports	string	custom	0	Spectre option rcr_net_preserve_active_state_ports: When set to 1, preserves ports of parasitic networks that are connected to an active-state node.
saSpectreOptionrcrnetpreserveactivestateportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetpreserveactivewordlineports	string	custom	0	Spectre option rcr_net_preserve_active_word_line_ports: When set to 1, preserves ports of parasitic networks that are connected to an active word-line node.
saSpectreOptionrcrnetpreserveactivewordlineportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetpreservedrainsource signals	string	custom	0	Spectre option rcr_net_preserve_drain_source_signals: When set to 1, preserves ports of parasitic networks that are connected to a source and drain device terminals.
saSpectreOptionrcrnetpreservedrainsource signalsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetpreserveidlebitlineports	string	custom	0	Spectre option rcr_net_preserve_idle_bit_line_ports: When set to 1, preserves ports of parasitic networks that are connected to an idle bit-line node.
saSpectreOptionrcrnetpreserveidlebitlineportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionrcrnetpreserveidlestateports	string	custom	0	Spectre option rcr_net_preserve_idle_state_ports: When set to 1, preserves ports of parasitic networks that are connected to an idle-state node.
saSpectreOptionrcrnetpreserveidlestateportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetpreserveidlewordlineports	string	custom	0	Spectre option rcr_net_preserve_idle_word_line_ports: When set to 1, preserves ports of parasitic networks that are connected to an idle word-line node.
saSpectreOptionrcrnetpreserveidlewordlineportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetpreservepnports	string	custom	0	Spectre option rcr_net_preserve_pn_ports: When set to 1, preserves ports of parasitic networks that are connected to a DC vsource.
saSpectreOptionrcrnetpreservepnportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrnetpreservevpnports	string	custom	0	Spectre option rcr_net_preserve_vpn_ports: When set to 1, preserves ports of parasitic networks that are connected to a VPN source.
saSpectreOptionrcrnetpreservevpnportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrcrrshort	string	custom	1.00E-03	Spectre option rcr_rshort: this parameter is used to set the minimum value of resistor that should be cut.
saSpectreOptionrcrrshortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionrcut	string	custom	infinity	Spectre option rcut: Fixed value resistors with $R > rcut$ are replaced by open. Default is infinity for Spectre and $MAX(1/GMIN, 1e12)$ for APS. For bsource resistor, default is $1e12$ for Spectre and $MAX(1/GMIN, 1e12)$ for APS. If GMIN is not specified, the value of $MAX(1/GMIN, 1e12)$ is $1e12$. rcut can additionally be applied to variable resistors using the option 'short_cut_var_elem=yes'.
saSpectreOptionrcutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrebuildmatrix	string	custom	no	Spectre option rebuild_matrix: If set to yes, rebuild circuit matrix at the beginning of ac, dc, dcmatch, montecarlo, pz, stb, sweep, tdr, and tran analyses. This is to ensure consistent matrix ordering at the beginning of the analyses for consistent results. Notice that rebuild circuit matrix can result in performance overhead. Valid values: no and yes.
saSpectreOptionrebuildmatrixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionredefinedparams	string	custom	error	Spectre option redefinedparams: Specify whether parameters can be redefined in the netlist. When set to warning or ignore, the simulator allows you to redefine parameters in the netlist. However, it honors only the last definition of the redefined parameter. Depending on the value set, the simulator displays warning messages for the redefined parameters or does not display any message. When set to error, the simulator does not allow you to redefine parameters in the netlist and displays an error message. Valid values: error, ignore, warning, and warn.
saSpectreOptionredefinedparamsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionreelaborateonalter	string	custom	force	Spectre option reelaborateonalter: Whether re-elaborate for every alter statement. Valid values: lazy and force.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionreelaborateonalterUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionreltolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionresidualtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrmdgccs	string	custom	no	Spectre option rmdgccs: If yes, dangling controlled current source will be removed. Default value is no. Valid values: no and yes.
saSpectreOptionrmdgccsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionrthresh	string	custom	0.001	Spectre option rthresh: All instance resistors with $\text{abs}(R) < \text{rthresh}$ will use resistance form, unless their instance parameter or model parameter overwrites it.
saSpectreOptionrthreshUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionscalefactor	string	custom	1.0	Spectre option scalefactor: ScaleFactor for Device Model Technology Scaling. The options parameter scalefactor enables device model providers to scale device technology independent of the design dimension scaling done by circuit designers. The resulting device instance scaling is defined by 'scale * scalefactor'. If the foundry uses a technology scale factor of 0.9 (scalefactor=0.9), and the circuit designer uses a design scale factor of 1e-6 (scale=1e-6), then the compounded scaling of the device instance dimension is 0.9e-6. Unlike options parameter scale, scalefactor cannot be used as a netlist parameter and cannot be altered or used in sweep statements.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionscalefactorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionscalemUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionscalereDEFINED	string	custom	ignore	Spectre option scale_redefined: Disallow redefining of the option scale in netlist. Valid values: error, ignore, and warning.
saSpectreOptionscalereDEFINEDUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionssensbinparam	string	custom	no	Spectre option sensbinparam: Sensitivity for binning models. Valid values: no, uncorrelated, and correlated.
saSpectreOptionssensbinparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionssensfileonly	string	custom	no	Spectre option sensfileonly: Enable or disable raw output of sensitivity. results. Valid values: no and yes.
saSpectreOptionssensfileonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionssensformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionssensstypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionsshortbjtr	string	custom	0.0	Spectre option short_bjtr: All parasitic resistors inside bipolar devices less than global short_bjtr will be removed. This option is applied to all bipolar junction transistors.
saSpectreOptionsshortbjtrUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionsshortcutnonconst	string	custom	no	Spectre option shortcutnonconst: Cut Non const value. Valid values: yes and no.
saSpectreOptionsshortcutnonconstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionssimstat	string	custom	basic	Spectre option simstat: Print simulation phase statistics report. Valid values: basic and detailed.
saSpectreOptionssimstatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionsskip	string	custom	none	Spectre option skip: Skip the simulating specified subckt instances. For now, cut is supported, which will leave the subckt ports disconnected. Valid values: none, load, and cut.
saSpectreOptionsskipmacromos	string	custom	[...]	Spectre option skip_macro_mos: The list of subcircuit names, which is skipped to be a macro model.
saSpectreOptionsskipmacromosUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionsskipUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionsoamode	string	custom	0	Spectre option soa_mode: Option to choose one SOA check mode, 0 for customer's definition and 1 for Spectre's.
saSpectreOptionsoamodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionsoawarn	string	custom	yes	Spectre option soa_warn: If soa_warn is no, SOA warnings will be turned off. Valid values: no and yes.
saSpectreOptionsoawarnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionsoftbin	string	custom	singlemodels	Spectre option soft_bin: If set to singlemodels, it is used only on non-binned models. Valid values: singlemodels, no, and allmodels.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionssoftbinUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionssortinstance	string	custom	no	Spectre option sortinstance: sort devices of the netlist. Valid values: no and yes. dF dp F dp F
saSpectreOptionssortinstanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionsspef	string	custom		Spectre option spef: This option specifies the SPEF file to be stitched and its stitching scope. The syntax is spef="scope filename". The scope can be a subcircuit or an instance. Use "spectre -h stitch" for more information.
saSpectreOptionsspeftriplet	string	custom	2	Spectre option speftriplet: This option specifies the value to be used for stitching in the SPEF file. It is effective only when the values in the SPEF file are represented by triplets (for example, 0.325:0.41:0.495). Valid values: 1, 2, and 3.
saSpectreOptionsspeftripletUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionsspefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionsspf	string	custom		Spectre option spf: This option specifies the DSPF file to be stitched and its stitching scope. The syntax is spf="scope filename". The scope can be a subcircuit or an instance. Use "spectre -h stitch" for more information.
saSpectreOptionsspfaliasterm	string	custom		Spectre option spfaliasterm: At times, the terminal names of devices in DSPF/SPEF/DPF files are different from those in the simulation model library. This happens in technology nodes that use subcircuits to model devices. The syntax is spfaliasterm="<model subckt> = ... =". Multiple statements are supported. Use "spectre -h stitch" for more information.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionspfaliasternUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfbusdelim	string	custom		Spectre option spfbusdelim: This option maps the bus delimiter between schematic netlist and parasitic file (i.e. DSPF, SPEF, or DPF). The option defines the bus delimiter in the schematic netlist, and optionally the bus delimiter in the parasitic file. By default the bus delimiter of the parasitic file is taken from the parasitic file header (that is, * BUSBIT [], * BUS_BIT [], or * BUS_DELIMITER []). If the bus delimiter is not defined in the parasitic file header, you need specify it using the spfbusdelim option in schematic netlist. For example, the option spfbusdelim="<>" is maps A<1> in the schematic netlist to A_1 in the DSPF file, if the bus delimiter header in the DSPF file is "_". The option spfbusdelim="@ []" maps A@1 in the schematic netlist to A[1] in the DSPF file (the bus delimiter in DSPF header will be ignored). See "spectre -h stitch" for more information.
saSpectreOptionspfbusdelimUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfcnet	string	custom		Spectre option spfcnet: This option specifies the net that has its total capacitance stitched. All other parasitic components such as parasitic resistors that are associated with this net are ignored. The complete hierarchical names are required and multiple statements are supported. Wildcards are supported. Use "spectre -h stitch" for more information.
saSpectreOptionspfcnetfile	string	custom		Spectre option spfcnetfile: This option has the same functionality as spfcnet, except that it accepts a text file in which all the C-only stitched nets are listed. Only one file can be specified. The syntax is spfcnetfile="filename". The format of the file requires you to specify one line per net. Use "spectre -h stitch" for more information.
saSpectreOptionspfcnetfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionspfcnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfinstancesection	string	custom	1	Spectre option spfinstancesection: This option controls the backannotation of device parameters in the instance section of the DSPF file. If spfinstancesection is turned off, the instance section is ignored (that is, the device parameters are not changed during stitching). The default is on. Use "spectre -h stitch" for more information.
saSpectreOptionspfinstancesectionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfinstarraydelim	string	custom		Spectre option spfinstarraydelim: This option specifies the supplemental bus delimiter, if more than one bus delimiter is used in pre-layout netlist (usually for instance array indexing). It is similar to the spfbusdelim option. Use "spectre -h stitch" for more information.
saSpectreOptionspfinstarraydelimUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfmsglimit	string	custom		Spectre option spfmsglimit: This option specifies the maximum number of messages to be printed in the sprpt file. The syntax is spfmsglimit="number STITCH-ID_1 STITCH-ID_2". Use "spectre -h stitch" for more details.
saSpectreOptionspfmsglimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfnetcmin	string	custom	0	Spectre option spfnetcmin: This option allows you to select the net for stitching by the value of its total node capacitance. If a net's total node capacitance exceeds spfnetcmin, all parasitics associated with the net are stitched correctly, otherwise, only the total capacitance is added to the net node. Use "spectre -h stitch" for more information.
saSpectreOptionspfnetcminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionspfpostparam	string	custom	replace	Spectre option spfpostparam: This option specifies the instance parameters sourced for stitched instances. When set to replace, only the post-layout parameters are used and the pre-layout parameters are discarded. When set to append, both pre-layout and post-layout parameters are merged for the stitched instances where the post-layout parameters have higher priority. Valid values: append and replace.
saSpectreOptionspfpostparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfprobenode	string	custom	net_only	Spectre option spfprobenode: When net_only, it is the only net name in SPF file that is used to match the wild card in .probe/.ic statements. The hierarchical structure of the net name is restored like pre-layout netlist. When all, the net name in SPF file is stored as pre-layout node name, and the nodes in SPF file are preserved like the current behavior. The wild card in .probe/.ic will match all the nodes and net names. Valid values: net_only and all.
saSpectreOptionspfprobenodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfrcnet	string	custom		Spectre option spfrcnet: This option specifies the name of the net to be stitched with parasitic resistors and capacitors. The other nets are stitched with lumped total capacitances. Multiple statements are supported. Wildcards are supported and you can specify as many nets as needed. Complete hierarchical net names are required. Use "spectre -h stitch" for more information.
saSpectreOptionspfrcnetfile	string	custom		Spectre option spfrcnetfile: This option has the same functionality as spfrcnet, except that it accepts a text file in which all the RC stitched nets are specified. Only one file can be specified. The syntax is spfrcnetfile="filename". The format of the file requires you to specify one line per net. Use "spectre -h stitch" for more details.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionspfrcnnetfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfrcnnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfscale	string	custom	1.0	Spectre option spfscale: This option specifies the scaling factor of all the elements in the parasitic files (DSPF/SPEF/DPF). Use "spectre -h stitch" for more details.
saSpectreOptionspfscalec	string	custom	1	Spectre option spfscalec: This option specifies the scale factor for parasitic capacitors.
saSpectreOptionspfscalecUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfscaler	string	custom	1	Spectre option pfscaler: This option specifies the scale factor for parasitic resistors.
saSpectreOptionspfscalerUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfskipnet	string	custom		Spectre option pfskipnet: This option specifies the net to be skipped for stitching, that is, all parasitic components of the net are not stitched. Wildcards are supported. You can specify multiple pfskipnet statements. Use "spectre -h stitch" for more information.
saSpectreOptionspfskipnetfile	string	custom		Spectre option pfskipnetfile: This option allows you to specify the nets to be skipped as a list in a text file. The syntax is pfskipnetfile="filename". Only one file can be specified. The format in the file is one line per net. Use "spectre -h stitch" for more information.
saSpectreOptionspfskipnetfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionspfskipnetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfswapterm	string	custom		Spectre option pfswapterm: This option specifies the swappable terminals of a subcircuit macro-model. The syntax is pfswapterm="terminal1 terminal2 subcktname". Use "spectre -h stitch" for more information.
saSpectreOptionspfswaptermUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionspfxtorprefix	string	custom		Spectre option pfxtorprefix: This option specifies the prefix in the device or net names in the DSPF/SPEF/DPF file. The syntax is pfxtorprefix="substring [replace_substring]". Use "spectre -h stitch" for more information.
saSpectreOptionspfxtorprefixUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionstepdropsize	string	custom	100	Spectre option stepdropsize: The threshold size of step drop to report a dramatic change warning.
saSpectreOptionstepdropsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionstvernote	string	custom	no	Spectre option stver_note: Give -stver suggestion warning for invalid parameter. Valid values: no and yes.
saSpectreOptionstvernoteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionsubcktiprobes	string	custom	yes	Spectre option subcktiprobes: Insert iprobes when computing subcircuit terminal currents. Valid values: no and yes.
saSpectreOptionsubcktiprobesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionsubcktoppoint	string	custom	no	Spectre option subcktoppoint: Output oppoint parameters of subckt instance. Valid values: no and yes.
saSpectreOptionsubcktoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionsubcktswitch	string	custom	full	Spectre option subckt_switch: If set to simple, complex subckt will be mapped to simple subckt in mapsubckt. Valid values: full and simple.
saSpectreOptionsubcktswitchUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionsubcktvthchildproc	string	custom	yes	Spectre option subcktvthchildproc: Computing vth of subckt in child process. Valid values: no and yes.
saSpectreOptionsubcktvthchildprocUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiontempeffectsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiontermcurmethod	string	custom	default	Spectre option termcur_method: Select methods to compute terminal currents. Set termcur_method=complete to get correct currents when devices have no termcurs output. However, this may negatively impact performance.. Valid values: default and complete.
saSpectreOptiontermcurmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionthermalmap	string	custom	%C:r.raw	Spectre option thermalmap: Output raw data file name.
saSpectreOptionthermalmapUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptiontmiage	string	custom	0	Spectre option tmiage: Activate TMI Aging model flow. By default, it is not activated.
saSpectreOptiontmiageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiontmiagingremoveslash	string	custom	0	Spectre option tmiaging_remove_slash: Internal option to remove the slash character before dot in instance name. By default it is closed.
saSpectreOptiontmiagingremoveslashUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiontmifastcoredata	string	custom	0	Spectre option tmi_fast_core_data: Speed up TMI SOA/Age performance by fast TMI coredata evaluation.
saSpectreOptiontmifastcoredataUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiontmiflag	string	custom	0	Spectre option tmiflag: Activate TMI flow. By default TMI flow is not activated.
saSpectreOptiontmiflagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiontmiinput	string	custom		Spectre option tmiinput: input file name including full path to read back TMI information for aging model.
saSpectreOptiontmiinputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiontmipath	string	custom		Spectre option tmipath: Location of TMI shared object libraries to be used by tmiBsim4 models.
saSpectreOptiontmipathUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiontmisave	string	custom	1	Spectre option tmisave: Enable or disable aging information to be saved.
saSpectreOptiontmisaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptiontmisort	string	custom		Spectre option tmisort: Sort aging information.
saSpectreOptiontmisortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiontnomUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiontopcheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptiontryfastop	string	custom	yes	Spectre option try_fast_op: Speed up the DC solution. For hard-to-converge designs, this feature fails and other methods are applied. In corner cases, this feature may have negative effects. If the DC analysis is unusually slow, the memory usage of the processes keeps increasing, or if DC analysis gets stuck even before homotopy methods start, set this option to no. Valid values: no and yes.
saSpectreOptiontryfastopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionuseveriloga	string	custom	0	Spectre option use_veriloga: Determine whether to take Verilog-A as high priority. If set to '1', the Verilog-A model takes priority over the other subckt/models. If set to '0', the Verilog-A model does not take priority over the other subckt/models.
saSpectreOptionuseverilogaUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionvabssshort	string	custom	0.0	Spectre option vabssshort: Voltage sources with absolute DC voltage less than or equal to vabssshort are shorted. The default value in Spectre is 0, and in APS is 1e-9 V.
saSpectreOptionvabssshortUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionvabstolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreOptionvalueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionverilogalang	string	custom	relax	Spectre option verilogalang: AHDL Verilog-A language syntax check mode selector. If verilogalang=strict, show archaic syntax input as an error during Verilog-A parsing; If verilogalang=relax, show archaic syntax input as a warning during Verilog-A parsing. Valid values: strict and relax.
saSpectreOptionverilogalangUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionvrefbins	string	custom	[...]	Spectre option vrefbins: Specifies the voltage bins when bin_relref=yes is used. Default setting is vrefbins=[1 3 5 10].
saSpectreOptionvrefbinsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionvrefgnd	string	custom		Spectre option vrefgnd: Specify reference ground.
saSpectreOptionvrefgndUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionvthmod	string	custom	std	Spectre option vthmod: Vth output selector. 'std' outputs model equation Vth; 'vthcc' outputs constant current Vth and may impact simulation performance; 'vthcc_ext' outputs constant current Vth on external nodes; 'maxgm' outputs maxgm Vth. Valid values: std, vthcc, vthcc_ext, and maxgm.
saSpectreOptionvthmodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionwarningchangeseverity	string	custom	warning	Spectre option warning_change_severity: Change the severity of warning messages specified in immediately following warning_id. Valid values: error, warning, and notice.
saSpectreOptionwarningchangeseverityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreOptionwarningid	string	custom	[...]	Spectre option warning_id: Vector of warning message identifiers, such as [SPECTRE-16462 SPECTRE-16684]. Used in conjunction with warning_limit or warning_change_severity.
saSpectreOptionwarningidUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionwarninglimit	string	custom	5	Spectre option warning_limit: The maximum number of times the warnings specified in immediately following the warning_id parameter should be displayed.
saSpectreOptionwarninglimitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionwarnUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionwfdebug	string	custom	none	Spectre option wfdebug: Flag to store the measurement signal in a raw file. Valid values: none and measure.
saSpectreOptionwfdebugUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOptionwfmaxsize	string	custom	infinity	Spectre option wfmaxsize: Limits the maximum size of the output waveform. This option is valid when uwi format is set.
saSpectreOptionwfmaxsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreOutputControlImport	string	saTestbench	Import	Spectre outputControl Import Setting.
saSpectreOutputType	string	saTestbench	Voltage	Spectre Noise sweep: Output Type.
saSpectrePACCenter	string	saTestbench		Spectre PAC: Center point of sweep limits.
saSpectrePACDec	string	saTestbench		Spectre PAC: Number of logarithmic steps per decade.
saSpectrePACLin	string	saTestbench		Spectre PAC: Number of linear steps.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePACLog	string	saTestbench		Spectre PAC: Total number of logarithmic steps.
saSpectrePACMaxsideband	string	saTestbench	1	Spectre PAC: Maximum Sideband.
saSpectrePACOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, steps, and detailed_hb.
saSpectrePACOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptioncontriblist	string	custom		Spectre option contriblist: Array of device names for distortion summary. When contriblist=[""], distortion from each non-linear device is calculated.
saSpectrePACOptioncontriblistUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptioncrossingdirection	string	custom	all	Spectre option crossingdirection: Specifies the transitions for which sampling must be done. Possible values are all, rise, fall, and ignore.
saSpectrePACOptionextrasampletimepoints	string	custom	[...]	Spectre option extrasampletimepoints: Additional time points for sampled PTV analysis.
saSpectrePACOptionfimout	string	custom	0	Spectre option fim_out: Frequency of IM output signal.
saSpectrePACOptionfimoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionflinout	string	custom	0	Spectre option flin_out: Frequency of linear output signal.
saSpectrePACOptionflinoutUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionfreqaxis	string	custom		Spectre option freqaxis: Specifies whether the results should be printed as per the input frequency, the output frequency, or the absolute value of the output frequency. Default is 'absout'. Possible values are absout, out, and in.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePACOptionfreqaxisUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionfreqdivide	string	custom	1	Spectre option freqdivide: Large signal frequency division. Used for oscillator circuit with divider in when osc_version=dtss for shooting engine.
saSpectrePACOptionfreqdivideUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionfreqs	string	custom		Spectre option freqs: Array of RF source frequencies for triple beat analysis.
saSpectrePACOptionfreqsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptiongearorder	string	custom	2	Spectre option gear_order: Gear order used for small-signal integration.
saSpectrePACOptiongearorderUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionhbprecondsolver	string	custom	autoset	Spectre option hbprecond_solver: Select a linear solver for the GMRES preconditioner. Default is autoset. With autoset, the simulator will automatically select the appropriate preconditioner. The preconditioner affects the rate of convergence of the linear matrix solver used in periodic small-signal analysis. When autoset is selected, the simulator may decide to switch to a different preconditioner after the analysis begins. When that happens, the simulator may issue a warning instructing you to choose a different preconditioner during subsequent runs. Although not required, choosing a different preconditioner according to the simulator's instructions may speed up subsequent analyses. Possible values are basicsolver, blocksolver, autoset, blockdense, and blocksolver2.
saSpectrePACOptionhbprecondsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePACOptioninmodharmnum	string	custom	1	Spectre option inmodharmnum: Harmonic value for the input source modulation.
saSpectrePACOptioninmodharmnumUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionkrylovsize	string	custom	200	Spectre option krylov_size: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*krylov_size iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the krylov_size if the simulation reports insufficient norm reduction errors in GMRES.
saSpectrePACOptionkrylovsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionmaxharmnonlin	string	custom	4	Spectre option maxharm_nonlin: Maximum harmonics of input signal frequency induced by non-linear effect.
saSpectrePACOptionmaxharmnonlinUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionmaxsamples	string	custom	16	Spectre option maxsamples: Maximum number of sampled events to be processed during the sampled analysis.
saSpectrePACOptionmodsource	string	custom		Spectre option modsource: Refer the output noise to this component.
saSpectrePACOptionmodsourceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionmodulated	string	custom	no	Spectre option modulated: Compute transfer functions/conversion between modulated sources and outputs. Possible values are single, first, second, and no.
saSpectrePACOptionmodulatedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionmoduppersideband	string	custom	1	Spectre option moduppersideband: Index of the upper sideband included in the modulation of an output for PAC and HBAC, or an input for PXF.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePACOptionmoduppersidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.
saSpectrePACOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionoscaccuracy	string	custom	2	Spectre option osc_accuracy: Accuracy control in small signal analysis for autonomous circuit when osc_version=mts. The higher this value, the more iterations GMRES solver will take. Maximum effective value is 5.
saSpectrePACOptionoscaccuracyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionoscsolver	string	custom	turbo	Spectre option oscsolver: Oscillator solver type. It is recommended that you use ira for huge circuits. Possible values are std, turbo, ira, and direct.
saSpectrePACOptionoscsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionoscversion	string	custom	mts	Spectre option osc_version: Specifies the method to use in small signal analysis for autonomous circuit. Possible values are floquet, augmented, and mts.
saSpectrePACOptionoscversionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectrePACOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionout1	string	custom		Spectre option out1: Output signal 1.
saSpectrePACOptionout1UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePACOptionout2	string	custom		Spectre option out2: Output signal 2.
saSpectrePACOptionout2UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionoutmodharmvec	string	custom	[...]	Spectre option outmodharmvec: Harmonic list for the output modulations.
saSpectrePACOptionoutmodharmvecUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionoutputperiod	string	custom	0.0	Spectre option outputperiod: Time-domain output period. The time-domain small-signal response is computed for the period specified, rounded to the nearest integer multiple of the `pss` period.
saSpectrePACOptionoutputperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionperturbation	string	custom	linear	Spectre option perturbation: The type of PAC analysis. The default is linear for normal PAC analysis. im2ds stands for im2 distortion summary and ds stands for distortion summary. Triple beat analysis is not supported for shooting engine, PSS must be run before PAC with 'balance=yes' or 'harmonicbalance=yes'. Value multiple_beat is deprecated and will be removed in the future: use triple_beat instead. Possible values are linear, ds, ip3, ip2, im2ds, multiple_beat, and triple_beat.
saSpectrePACOptionperturbationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionptvtype	string	custom	timeaveraged	Spectre option ptvtype: Specifies whether the PTV analysis will be traditional or sampled under certain conditions. Possible values are timeaveraged and sampled.
saSpectrePACOptionrelativeTol	string	custom		Spectre option relativeTol: Relative tolerance for harmonic balance-based linear solver. Default value is 1.0e-2.
saSpectrePACOptionrelativeTolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePACOptionrelharmnum	string	custom	1	Spectre option relharmnum: Harmonic to which relative frequency sweep should be referenced.
saSpectrePACOptionrelharmnumUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionresgmrescycle	string	custom	short	Spectre option resgmrescycle: Restarts GMRES cycle. Possible values are instant, short, long, recycleinstant, recycleshort, and recyclelong.
saSpectrePACOptionresgmrescycleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionrf1src	string	custom		Spectre option rf1_src: Array of RF1 source names for IP3/IP2/IM2.
saSpectrePACOptionrf1srcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionrf2src	string	custom		Spectre option rf2_src: Array of RF2 source names for IP3/IP2/IM2.
saSpectrePACOptionrf2srcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionrfampls	string	custom		Spectre option rfampls: RF source amplitudes; the units are dBm for ports, Voltage for v-sources and Ampere for i-sources.
saSpectrePACOptionrfamplsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionrfdbm	string	custom	0	Spectre option rfdbm: RF source dBm.
saSpectrePACOptionrfdbmUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionrfmag	string	custom	0	Spectre option rfmag: RF source magnitude.
saSpectrePACOptionrfmagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePACOptionrfsrc	string	custom		Spectre option rf_src: Array of RF source names for triple beat analysis.
saSpectrePACOptionrfsrcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionsampleprobe	string	custom		Spectre option sampleprobe: The crossing event at this port triggers the sampled small signal computation.
saSpectrePACOptionsave	string	custom		Spectre option save: Signals to output. Possible values are all, lvl, allpub, lvlpub, selected, none, and nooutput.
saSpectrePACOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionsolver	string	custom	turbo	Spectre option solver: Solver type. Possible values are std, turbo, std_hh, and turbo_hh.
saSpectrePACOptionsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionthresholdvalue	string	custom	0	Spectre option thresholdvalue: Sampled measurement is done when the signal crosses this value.
saSpectrePACOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectrePACOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptiontolerance	string	custom		Spectre option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saSpectrePACOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePACOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectrePACRelharmnum	string	saTestbench	1	Spectre PAC: Harmonic index number for relative sweep.
saSpectrePACSidebands	string	saTestbench	1	Spectre PAC: Sidebands.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePACSidebandType	string	saTestbench	Maximum Sideband	Spectre PAC: Sideband type.
saSpectrePACSpan	string	saTestbench		Spectre PAC: Span between sweep limits.
saSpectrePACStart	string	saTestbench		Spectre PAC: Starting point of sweep limits.
saSpectrePACStep	string	saTestbench		Spectre PAC: Linear step size.
saSpectrePACStepSpecLin	string	saTestbench	Number of Steps	Spectre PAC: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectrePACStepSpecLog	string	saTestbench	Points per Decade	Spectre PAC: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectrePACStop	string	saTestbench		Spectre PAC: Stopping point of sweep limits.
saSpectrePACSweep	string	saTestbench	Logarithmic	Spectre PAC: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectrePACSweepSpec	string	saTestbench	<file path>	Spectre PAC: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectrePACSweeptype	string	saTestbench	Default	Spectre PAC: Frequency sweep type.
saSpectrePACValues	string	saTestbench		Spectre PAC: Individual values, also known as points of interest.
saSpectrePACValuesfile	string	saTestbench		Spectre PAC: File for individual values
saSpectrePNOISEAugmented	string	saTestbench	no	Spectre PNOISE: Augmented.
saSpectrePNOISECenter	string	saTestbench		Spectre PNOISE: Center point of sweep limits.
saSpectrePNOISECrossingdirection	string	saTestbench	all	Spectre PNOISE: Crossing Direction
saSpectrePNOISEDec	string	saTestbench		Spectre PNOISE: Number of logarithmic steps per decade.
saSpectrePNOISEDoMultiSweep	string	saTestbench	0	Spectre PNOISE: Do a multisweep

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePNOISELin	string	saTestbench		Spectre PNOISE: Number of linear steps.
saSpectrePNOISELog	string	saTestbench		Spectre PNOISE: Total number of logarithmic steps.
saSpectrePNOISEMaxsideband	string	saTestbench	1	Spectre PNOISE: Maximum sideband.
saSpectrePNOISEMultiSweepBandWidth	string	saTestbench		Spectre PNOISE: Multisweep bandwidth.
saSpectrePNOISEMultiSweepOscFreq	string	saTestbench		Spectre PNOISE: Multisweep oscillation frequency.
saSpectrePNOISEMultiSweepSimPoints	string	saTestbench		Spectre PNOISE: Multisweep number of points per bandwidth.
saSpectrePNOISEMultiSweepSyntax	enSpectrePNOISEMultiSweepSyntax	user	values	Spectre PNOISE: Multisweep Syntax. Valid values: values, valuesfile, multipleAnalyses
saSpectrePNOISENoiseout	string	saTestbench	usb	Spectre PNOISE: Noise Out.
saSpectrePNOISENoiseType	string	saTestbench	timeaverage	Spectre PNOISE: Noise Type.
saSpectrePNOISEOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, steps, and detailed_hb.
saSpectrePNOISEOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptioncrossingdirection	string	custom	all	Spectre option crossingdirection: Specifies the transitions for which sampling must be done. Possible values are all, rise, fall, and ignore.
saSpectrePNOISEOptioncrossingdirectionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptioncyclo2txtfile	string	custom	no	Spectre option cyclo2txtfile: Output cyclo-stationary noise to text file as input source of next stage. Possible values are no and yes.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePNOISEOptioncyclo2txtfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionexternalsourcedata	string	custom		Spectre option externalsourcedata: Name of PXF analysis that provides information to compute the contribution of external jitter sources.
saSpectrePNOISEOptionexternalsourcedataUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionfreqdivide	string	custom	1	Spectre option freqdivide: Large signal frequency division. Used for oscillator circuit with divider in when osc_version=dts for shooting engine.
saSpectrePNOISEOptionfreqdivideUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptiongearorder	string	custom	2	Spectre option gear_order: Gear order used for small-signal integration.
saSpectrePNOISEOptiongearorderUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionhbprecondsolver	string	custom	autoset	Spectre option hbprecond_solver: Select a linear solver for the GMRES preconditioner. Default is autoset. With autoset, the simulator will automatically select the appropriate preconditioner. The preconditioner affects the rate of convergence of the linear matrix solver used in periodic small-signal analysis. When autoset is selected, the simulator may decide to switch to a different preconditioner after the analysis begins. When that happens, the simulator may issue a warning instructing you to choose a different preconditioner during subsequent runs. Although not required, choosing a different preconditioner according to the simulator's instructions may speed up subsequent analyses. Possible values are basicsolver, blocksolver, autoset, blockdense, and blocksolver2.
saSpectrePNOISEOptionhbprecondsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePNOISEOptionkrylovsize	string	custom	200	Spectre option krylov_size: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*krylov_size iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the krylov_size if the simulation reports insufficient norm reduction errors in GMRES.
saSpectrePNOISEOptionkrylovsizedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionlorentzian	string	custom	cornerfrequency	Spectre option lorentzian: This option determines if the Lorentzian plot is used in the oscillator noise analysis. 'lorentzian=yes' is only valid for 'noisetype=timeaverage'. Possible values are no, cornerfrequency, and yes.
saSpectrePNOISEOptionlorentzianUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionmaxcycles	string	custom	0	Spectre option maxcycles: Maximum cycle correlation frequency included when computing noise, that is either up-converted or down-converted to the output by the periodic drive signal.
saSpectrePNOISEOptionmaxcyclesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionmaxsamples	string	custom	16	Spectre option maxsamples: Maximum number of sampled events to be processed during the sampled analysis.
saSpectrePNOISEOptionmaxsamplesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionmeasurement	string	custom		Spectre option measurement: Specifies the jitter event list that will be measured.
saSpectrePNOISEOptionmeasurementUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePNOISEOptionnestlviUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionnoiseout	string	custom	usb	Spectre option noiseout: Specify noise output. You can set a vector like noiseout=[usb am pm]. And all are using single sideband(SSB) convention, half of the total power. Possible values are usb, lsb, am, and pm.
saSpectrePNOISEOptionnoiseskipcount	string	custom	-1	Spectre option noiseskipcount: Calculate time-domain noise on only one of every noiseskipcount time points. When < 0, the parameter is ignored. When >=0, the simulator uses this parameter and ignores numberofpoints.
saSpectrePNOISEOptionnoiseskipcountUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionnoisetimepoints	string	custom	[...]	Spectre option noisetimepoints: Additional time points for time-domain noise analysis.
saSpectrePNOISEOptionnoisetimepointsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionnumberofpoints	string	custom	5	Spectre option numberofpoints: Number of time points of interest in the period where time domain PSD is calculated. Simulator divides the period evenly into N segments (N=numberofpoints) and calculates time domain PSD on the starting time point of each segment. When < 0, the parameter is ignored.
saSpectrePNOISEOptionnumberofpointsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionoscaccuracy	string	custom	2	Spectre option osc_accuracy: Accuracy control in small signal analysis for autonomous circuit when osc_version=dtss. The higher this value, the more iterations GMRES solver will take. Maximum effective value is 5.
saSpectrePNOISEOptionoscaccuracyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePNOISEOptionoscsolver	string	custom	turbo	Spectre option oscsolver: Oscillator solver type. It is recommended that you use ira for huge circuits. Possible values are std, turbo, ira, and direct.
saSpectrePNOISEOptionoscsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionoscversion	string	custom	dtc	Spectre option osc_version: Specifies the method to use in small signal analysis for autonomous circuit. Possible values are floquet, augmented, and dtc.
saSpectrePNOISEOptionoscversionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectrePNOISEOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionppv	string	custom	no	Spectre option ppv: If set to yes, save the oscillator PPV after performing noise analysis. Possible values are no and yes.
saSpectrePNOISEOptionppvfile	string	custom		Spectre option ppvfile: File to which the PPV of oscillator is written.
saSpectrePNOISEOptionppvfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionppvUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionrelativeTol	string	custom		Spectre option relativeTol: Relative tolerance for harmonic balance-based linear solver. Default value is 1.0e-2.
saSpectrePNOISEOptionrelativeTolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionresgmrescycle	string	custom	short	Spectre option resgmrescycle: Restarts GMRES cycle. Possible values are instant, short, long, recycleinstant, recycleshort, and recyclelong.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePNOISEOptionresgmrescycleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionsampleratio	string	custom	1	Spectre option sampleratio: The ratio between sampled frequency and fund frequency (sampled frequency/fund frequency).
saSpectrePNOISEOptionsampleratioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionsave	string	custom		Spectre option save: Signals to output. The option 'save' specifies the signals to be saved in the result. 'allpub' saves all signals at all levels of hierarchy in the schematic, including the internal signals of device models. 'all' works like 'allpub'. 'lvl' saves all signals through the level of hierarchy set in 'nestlvl' option. 'lvlpub' works like 'lvl'. 'selected' is not recommended to use here. Possible values are all, lvl, allpub, lvlpub, and selected.
saSpectrePNOISEOptionsaveallsidebands	string	custom	no	Spectre option saveallsidebands: Save noise contributors by sideband. Possible values are no and yes.
saSpectrePNOISEOptionsaveallsidebandsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionsolver	string	custom	turbo	Spectre option solver: Solver type. Possible values are std, turbo, std_hh, and turbo_hh.
saSpectrePNOISEOptionsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionthresholdvalue	string	custom	0	Spectre option thresholdvalue: Sampled measurement is done when the signal crosses this value.
saSpectrePNOISEOptionthresholdvalueUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptiontitle	string	custom		Spectre option title: Analysis title.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePNOISEOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptiontolerance	string	custom		Spectre option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saSpectrePNOISEOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePNOISEOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectrePNOISEOutputType	string	saTestbench	Voltage	Spectre PNOISE: Output type.
saSpectrePNOISEPnoiseMethod	string	saTestbench	default	Spectre PNOISE: PNoise Method.
saSpectrePNOISERefsideband	string	saTestbench		Spectre PNOISE: Conversion gain sideband.
saSpectrePNOISERelharmnum	string	saTestbench	1	Spectre PNOISE: Harmonic index number for relative sweep.
saSpectrePNOISESampleratio	string	saTestbench		Spectre PNOISE: The ratio between sampled frequency and fund frequency
saSpectrePNOISESeparateNoise	string	saTestbench	0	Spectre PNOISE: Separate noise.
saSpectrePNOISESidebands	string	saTestbench	1	Spectre PNOISE: Sidebands.
saSpectrePNOISESidebandType	string	saTestbench	Maximum Sideband	Spectre PNOISE: Sideband type.
saSpectrePNOISESpan	string	saTestbench		Spectre PNOISE: Span between sweep limits.
saSpectrePNOISEStart	string	saTestbench		Spectre PNOISE: Starting point of sweep limits.
saSpectrePNOISEStep	string	saTestbench		Spectre PNOISE: Linear step size.
saSpectrePNOISEStepSpecLin	string	saTestbench	Number of Steps	Spectre PNOISE: Method of specifying linear stepping ("Step Size" "Number of Steps").

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePNOISEStepSpecLog	string	saTestbench	Points per Decade	Spectre PNOISE: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectrePNOISEStop	string	saTestbench		Spectre PNOISE: Stopping point of sweep limits.
saSpectrePNOISESweep	string	saTestbench	Logarithmic	Spectre PNOISE: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectrePNOISESweepSpec	string	saTestbench	<file path>	Spectre PNOISE: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectrePNOISESweepType	string	saTestbench	Default	Spectre PNOISE: Frequency sweep type.
saSpectrePNOISEThresholdvalue	string	saTestbench		Spectre PNOISE: Threshold Value
saSpectrePNOISEValues	string	saTestbench		Spectre PNOISE: Individual values, also known as points of interest.
saSpectrePNOISEValuesfile	string	saTestbench		Spectre PNOISE: File for individual values
saSpectrePspCenter	string	saTestbench		Spectre PSP: Center of sweep.
saSpectrePSPCenter	string	saTestbench		Spectre PSP: Center point of sweep limits.
saSpectrePspDec	string	saTestbench		Spectre PSP: Points per Decade.
saSpectrePSPDec	string	saTestbench		Spectre PSP: Number of logarithmic steps per decade.
saSpectrePspDoNoise	string	saTestbench	0	Spectre PSP: Do Noise.
saSpectrePSPFreqAxis	string	saTestbench	in	Spectre PSP: Freq Axis.
saSpectrePspLin	string	saTestbench		Spectre PSP: Number of Steps (linear).
saSpectrePSPLin	string	saTestbench		Spectre PSP: Number of linear steps.
saSpectrePsplog	string	saTestbench		Spectre PSP: Number of Steps (logarithmic).

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSPLog	string	saTestbench		Spectre PSP: Total number of logarithmic steps.
saSpectrePSPMaxSideband	string	saTestbench	1	Spectre PSP: Maximum Side Band.
saSpectrePSPOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, steps, and detailed_hb.
saSpectrePSPOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSPOptiondatafmt	string	custom	spectre	Spectre option datafmt: Data format of the S-parameter output file. Possible values are spectre, touchstone, and touchstone2.
saSpectrePSPOptiondatafmtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSPOptiondatatype	string	custom	realimag	Spectre option datatype: Data type of the S-parameter output file. Possible values are realimag, magphase, and dbphase.
saSpectrePSPOptiondatatypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSPOptionfile	string	custom		Spectre option file: Output file name. It just supports S-parameters in PSP, HBSP, and QPSP analysis.
saSpectrePSPOptionfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSPOptiongearorder	string	custom	2	Spectre option gear_order: Gear order used for small-signal integration.
saSpectrePSPOptiongearorderUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSPOptionharmsvec	string	custom	[...]	Spectre option harmsvec: List of harmonics, in addition to the ones associated with specific ports by portharmsvec, that are active.
saSpectrePSPOptionharmsvecUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePSOptionhbprecondsolver	string	custom	autoset	Spectre option hbprecond_solver: Select a linear solver for the GMRES preconditioner. Default is autoset. With autoset, the simulator will automatically select the appropriate preconditioner. The preconditioner affects the rate of convergence of the linear matrix solver used in periodic small-signal analysis. When autoset is selected, the simulator may decide to switch to a different preconditioner after the analysis begins. When that happens, the simulator may issue a warning instructing you to choose a different preconditioner during subsequent runs. Although not required, choosing a different preconditioner according to the simulator's instructions may speed up subsequent analyses. Possible values are basicsolver, blocksolver, autoset, blockdense, and blocksolver2.
saSpectrePSOptionhbprecondsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSOptionkrylovsize	string	custom	200	Spectre option krylov_size: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*krylov_size iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the krylov_size if the simulation reports insufficient norm reduction errors in GMRES.
saSpectrePSOptionkrylovsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSOptionoscaccuracy	string	custom	2	Spectre option osc_accuracy: Accuracy control in small signal analysis for autonomous circuit when osc_version=dtss. The higher this value, the more iterations GMRES solver will take. Maximum effective value is 5.
saSpectrePSOptionoscaccuracyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePSPOptionoscsolver	string	custom	turbo	Spectre option oscsolver: Oscillator solver type. It is recommended that you use ira for huge circuits. Possible values are std, turbo, ira, and direct.
saSpectrePSPOptionoscsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSPOptionoscversion	string	custom	dtc	Spectre option osc_version: Specifies the method to use in small signal analysis for autonomous circuit. Possible values are floquet, augmented, and dtc.
saSpectrePSPOptionoscversionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSPOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectrePSPOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSPOptionrelativeTol	string	custom		Spectre option relativeTol: Relative tolerance for harmonic balance-based linear solver. Default value is 1.0e-2.
saSpectrePSPOptionrelativeTolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSPOptionresgmrescycle	string	custom	short	Spectre option resgmrescycle: Restarts GMRES cycle. Possible values are instant, short, long, recycleinstant, recycleshort, and recyclelong.
saSpectrePSPOptionresgmrescycleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSPOptionsolver	string	custom	turbo	Spectre option solver: Solver type. Possible values are std, turbo, std_hh, and turbo_hh.
saSpectrePSPOptionsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSPOptionsweeptype	string	custom	relative	Spectre option sweeptype: Specifies if the sweep frequency range is the absolute frequency of input or if it is relative to the port harmonics. When the unspecified value is used, Spectre RF sweeps using relative when autonomous simulation is performed or when the analysis is PSP; for other cases Spectre RF sweeps the absolute value of the input. Possible values are absolute, relative, and unspecified.
saSpectrePSPOptionsweeptypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSPOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectrePSPOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSPOptiontolerance	string	custom		Spectre option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saSpectrePSPOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSPOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectrePspSpan	string	saTestbench		Spectre PSP: Span of sweep.
saSpectrePSPSpan	string	saTestbench		Spectre PSP: Span between sweep limits.
saSpectrePspStart	string	saTestbench		Spectre PSP: start.
saSpectrePSPStart	string	saTestbench		Spectre PSP: Starting point of sweep limits.
saSpectrePSPStep	string	saTestbench		Spectre PSP: Linear step size.
saSpectrePspStepSize	string	saTestbench		Spectre PSP: Step Size.
saSpectrePspStepSpecLin	string	saTestbench	Step Size	Spectre PSP: Lin step spec.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSPStepSpecLin	string	saTestbench	Number of Steps	Spectre PSP: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectrePspStepSpecLog	string	saTestbench	Points per Decade	Spectre PSP: Log step spec.
saSpectrePSPStepSpecLog	string	saTestbench	Points per Decade	Spectre PSP: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectrePspStop	string	saTestbench		Spectre PSP: stop.
saSpectrePSPStop	string	saTestbench		Spectre PSP: Stopping point of sweep limits.
saSpectrePSPSweep	string	saTestbench	Logarithmic	Spectre PSP: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectrePspSweepSpec	string	saTestbench	<file path>	Spectre PSP: Sweep spec.
saSpectrePSPSweepSpec	string	saTestbench	<file path>	Spectre PSP: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectrePspSweepType	string	saTestbench	Linear	Spectre PSP: Sweep type.
saSpectrePSPSweeptype	string	saTestbench	Default	Spectre PSP: Frequency sweep type
saSpectrePspValues	string	saTestbench		Spectre PSP: additional points.
saSpectrePSPValues	string	saTestbench		Spectre PSP: Individual values, also known as points of interest.
saSpectrePSPValuesfile	string	saTestbench		Spectre PSP: File for individual values
saSpectrePSSAutosteady	string	saTestbench	0	Spectre PSS: Automatic steady state detection during transient (tstab).
saSpectrePSSAutotstab	string	saTestbench	0	Spectre PSS: Decide tstab automatically.
saSpectrePSSCenter	string	saTestbench		Spectre PSS: Center point of sweep limits.
saSpectrePSSDec	string	saTestbench		Spectre PSS: Number of logarithmic steps per decade.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSDesignVar	string	saTestbench		Spectre PSS: Design variable being swept.
saSpectrePSSDev	string	saTestbench		Spectre PSS: Instance with parameter being swept.
saSpectrePSSDoLoadPull	string	saTestbench	0	Spectre PSS: Flag indicating a load pull sweep is to be performed
saSpectrePSSDoSweep	string	saTestbench	0	Spectre PSS: Flag indicating a sweep is to be performed.
saSpectrePSSErrpreset	string	saTestbench	off	Spectre PSS: errpreset.
saSpectrePSSFreqPeriod	string	saTestbench	Beat Frequency	Spectre PSS: Declaring the Frequency or Period.
saSpectrePSSFund	string	saTestbench		Spectre PSS: Beat Frequency.
saSpectrePSSFundMode	string	saTestbench	Specify	Spectre PSS: Mode for declaring the Frequency or Period.
saSpectrePSSHarms	string	saTestbench		Spectre PSS: Number of Harmonics.
saSpectrePSSHarmsType	string	saTestbench	Number	Spectre PSS: Harmonics Specification Type.
saSpectrePSSHarmsvec	string	saTestbench		Spectre PSS: Vector of Harmonics.
saSpectrePSSLin	string	saTestbench		Spectre PSS: Number of linear steps.
saSpectrePSSLog	string	saTestbench		Spectre PSS: Total number of logarithmic steps.
saSpectrePSSMod	string	saTestbench		Spectre PSS: Model with parameter being swept.
saSpectrePSSOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, estimated, steps, iters, detailed, rejects, alliters, detailed_hb, and internal_hb.
saSpectrePSSOptionannotateic	string	custom	no	Spectre option annotateic: Degree of annotation for initial condition. Possible values are no, title, sweep, status, steps, iters, detailed, and rejects.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOptionannotateicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionautofund	string	custom	no	Spectre option autofund: If the value is yes, the program ignores period/fund value and calculates the fundamental frequency automatically from source information. Possible values are no and yes.
saSpectrePSSOptionautofundUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionautoharms	string	custom	no	Spectre option autoharms: Activates automatic harmonic number calculation in harmonic balance. Applies only if tstab>0 or if autotstab=yes. If a steady-state is reached, Spectre does a spectrum analysis to calculate the optimal number of harmonics for HB. The minimum number of harmonics is specified by maxharms. If steady-state is not reached to sufficient tolerance, autoharms may be disabled. Possible values are no and yes.
saSpectrePSSOptionautoharmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionautosteady	string	custom	no	Spectre option autosteady: Activates the automatic steady state detection during initial transient (tstab) in harmonic balance and PSS shooting. When steady state is reached (or nearly reached), tstab terminates early. This parameter applies only when tstab>0 or when autotstab=yes. autosteady=no 0 turns this feature off; autosteady=yes 1 activates this feature; autosteady=2 runs autosteady with lower steady state tolerance than autosteady=1. autosteady=2 may help pss convergence but with higher tstab costs. Possible values are 0, 1, 2, no, and yes.
saSpectrePSSOptionautosteadyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOptionautotstab	string	custom	no	Spectre option autotstab: Activates the automatic initial transient (tstab) in harmonic balance and PSS shooting. If set to yes, the simulator decides whether to run tstab and for how long. Typically, the initial length of tstab is 50 periods; however, it could be longer depending on the type of circuit and its behavior. If steady-state is reached (or nearly reached), tstab terminates early. Possible values are no and yes.
saSpectrePSSOptionautotstabUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionbackoff	string	custom	0.0	Spectre option backoff: The backoff point. If defined, an addition harmonic balance analysis will be performed after the compression analysis is done. Default is 0 dBm when xdbgain=power, and 0 V when xdbgain=voltage.
saSpectrePSSOptionbackoffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionbacktracking	string	custom	yes	Spectre option backtracking: This parameter is used to activate the backtracing utility of Newton's method. The default is yes. Possible values are no, yes, and forced.
saSpectrePSSOptionbacktrackingUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionbalance	string	custom	no	Spectre option balance: Same parameter as 'harmonicbalance'. Possible values are no and yes.
saSpectrePSSOptioncheckpss	string	custom	yes	Spectre option checkpss: If set to yes, the previous PSS results (from readpss file) are checked and PSS+MIC is rerun if any condition has changed. If set to no, the simulator assumes that nothing has changed and uses the solution from the file without checking and running PSS+MIC again. This parameter is now valid only for shooting. Possible values are no and yes.
saSpectrePSSOptioncheckpssUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOptioncircuitage	string	custom		Spectre option circuitage: Stress time. Age of the circuit used to simulate hot-electron degradation of MOSFET and BSIM circuits.
saSpectrePSSOptioncircuitageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptioncmin	string	custom	0	Spectre option cmin: Minimum capacitance from each node to ground.
saSpectrePSSOptioncminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptiondev	string	custom		Spectre option dev: Name of the device instance parameter specified in param=name.
saSpectrePSSOptiondevUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionenvlpname	string	custom		Spectre option envlpname: Name of envelope analysis to be performed at tstab for pss.
saSpectrePSSOptionenvlpnameUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionexcludeconvwithBK	string	custom	yes	Spectre option excludeconvwithBK:
saSpectrePSSOptionexcludeconvwithBKUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionfdharms	string	custom	10	Spectre option fdharms: Number of harmonics considered for distributed (frequency-domain) components, such as nport, delay, mtline, and delayed controlled sources. This parameter is valid only for shooting and for those components for which 'Fmax' parameter of neither model nor instance is set.
saSpectrePSSOptionfdharmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOptionfinitediff	string	custom		Spectre option finitediff: Enable finite difference method refinement for driven circuits after shooting method. Possible values are no, yes, and refine.
saSpectrePSSOptionfinitediffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionflexbalanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionfullpssvec	string	custom		Spectre option fullpssvec: Use the full vector containing solutions at all PSS time steps in the linear solver. The default is derived from the size of the equation and the property of the PSS time steps. This parameter is only valid for shooting. Possible values are no and yes.
saSpectrePSSOptionfullpssvecUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionglog	string	custom	5	Spectre option glog: Number of steps, log sweep for hbhomotopy of gsweep.
saSpectrePSSOptionglogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptiongstart	string	custom	1.e-7	Spectre option gstart: Start conductance for hbhomotopy of gsweep.
saSpectrePSSOptiongstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptiongstop	string	custom	1.e-12	Spectre option gstop: Stop conductance for hbhomotopy of gsweep.
saSpectrePSSOptiongstopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionharmonicbalance	string	custom	no	Spectre option harmonicbalance: Use Harmonic Balance engine instead of time-domain shooting. Possible values are no and yes.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOptionharmonicbalanceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionhbhomotopy	string	custom	tone	Spectre option hbhomotopy: Name of Harmonic Balance homotopy selection methods. Possible values are tstab, source, gsweep, tone, inctone, and aggregation.
saSpectrePSSOptionhbhomotopyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionhbprecondsolver	string	custom	basicsolver	Spectre option hbprecond_solver: Choose a linear solver for the GMRES preconditioner. Possible values are basicsolver, blocksolver, autoset, blockdense, and blocksolver2.
saSpectrePSSOptionhbprecondsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionhighorder	string	custom		Spectre option highorder: Perform a high-order refinement after low-order convergence. The Multi-Interval Chebyshev polynomial spectral algorithm is used. This parameter is only valid for shooting. Possible values are no and yes.
saSpectrePSSOptionhighorderUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionic	string	custom	all	Spectre option ic: The value to be used to set the initial condition. Possible values are dc, node, dev, and all.
saSpectrePSSOptionicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptioninexactNewton	string	custom	no	Spectre option inexactNewton: Inexact Newton method. Possible values are no and yes.
saSpectrePSSOptioninexactNewtonUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePSSOptionitres	string	custom	1e-4	Spectre option itres: Controls the residual for iterative solution of linearized matrix equation at each Newton iteration. Tightening the parameter can help with the Newton convergence, but does not affect the result accuracy. The value should be between [0, 1].
saSpectrePSSOptionitresUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionkrylovsize	string	custom	10	Spectre option krylov_size: The minimum iteration count of the linear matrix solver used in HB large-signal analysis. After reaching krylov_size iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase krylov_size if the simulation reports insufficient norm reduction errors in GMRES.
saSpectrePSSOptionkrylovsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionlsspdatafmt	string	custom	touchstone	Spectre option lsspdatafmt: Sets the file format of the large-signal S-parameter output. Possible values are spectre and touchstone. Default is touchstone.
saSpectrePSSOptionlsspdatafmtUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionlsspdatype	string	custom	msgphase	Spectre option lsspdatype: Sets the data format or the large-signal S-parameter output. Possible values are realimag, magphase and phase. Default is magphase.
saSpectrePSSOptionlsspdatypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionlsspfile	string	custom		Spectre option lsspfile: Identifies the file name for large-signal S-parameter output.
saSpectrePSSOptionlsspfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePSSOptionlsspharms	string	custom	[...]	Spectre option lsspharms: Specifies the output harmonic for large-signal S-parameter calculations. The input harmonic is defined by the frequency parameters on the input port instance.
saSpectrePSSOptionlsspharmsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionlssports	string	custom	[...]	Spectre option lssports: Specifies the list of ports on which the large-signal 2-port S-parameters are calculated.
saSpectrePSSOptionlssportsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionlteminstep	string	custom	0.0	Spectre option lteminstep: Local truncation error is ignored if the step size is less than lteminstep.
saSpectrePSSOptionlteminstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionlteratio	string	custom		Spectre option lteratio: Ratio used to compute LTE tolerances from Newton tolerance. The default is derived from 'errpreset'.
saSpectrePSSOptionlteratioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionmaxacfreq	string	custom		Spectre option maxacfreq: Maximum frequency requested in a subsequent periodic small-signal analysis. The default is derived from 'errpreset' and 'harms'. This parameter is valid only for shooting.
saSpectrePSSOptionmaxacfreqUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionmaxiters	string	custom	5	Spectre option maxiters: Maximum number of iterations per time step.
saSpectrePSSOptionmaxitersUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOptionmaxorder	string	custom		Spectre option maxorder: The maximum order of the Chebyshev polynomials used in waveform approximation. Possible values are from 2 to 16. Default value is 16 for driven circuits and 12 for autonomous circuits. This parameter is valid only for shooting.
saSpectrePSSOptionmaxorderUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionmaxperiods	string	custom		Spectre option maxperiods: Maximum number of iterations allowed before convergence is reached in shooting or harmonic balance Newton iteration. For PSS and QPSS, the default is 20 for driven circuits, and 50 for oscillators; For HB, the default is 100.
saSpectrePSSOptionmaxperiodsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionmaxstep	string	custom		Spectre option maxstep: Maximum time step. The default is derived from 'errpreset'.
saSpectrePSSOptionmaxstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionmemoryestimate	string	custom	no	Spectre option memoryestimate: Sets the memory usage estimate for Harmonic Balance. If yes, a memory estimate is printed in the log file. You can use this memory estimate to plan the computing resources before submitting harmonic balance runs. In memory estimate mode, a short simulation is performed first, and the engine exits after printing the estimate in the log file without saving harmonic balance results. You must turn it off to perform an actual simulation. Memory estimation is not recommended for simulations that require less than 500MB approximately. For PSS analysis, memory estimate mode does not apply unless balance=yes. The estimate applies only to large-signal analysis, and does not include subsequent noise or other small-signal simulations.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOptionmemoryestimateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionmethod	string	custom		Spectre option method: Integration method. The default is derived from `errpreset`. This parameter is valid only for shooting. Possible values are euler, trap, traponly, gear2, and gear2only.
saSpectrePSSOptionmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionmod	string	custom		Spectre option mod: Name of the device model parameter specified in param=name.
saSpectrePSSOptionmodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.
saSpectrePSSOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionoppoint	string	custom	no	Spectre option oppoint: Should operating point information be computed for initial timestep; if yes, where should it be printed (screen or file). Possible values are no, screen, logfile, and rawfile.
saSpectrePSSOptionoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionoscic	string	custom	default	Spectre option oscic: Oscillator IC method. It determines how the starting values for the oscillator are calculated. `oscic=lin` provides you an accurate initial value, but it takes time; `oscic=lin_ic` is not recommended, which is the older version of `oscic=lin` for shooting analysis for backward compatibility; `oscic=fastic` is fast, but it is less accurate. `oscic=skip` directly uses the frequency provided by you as the initial guess frequency. It is only for the two-tier method. Possible values are default, lin, lin_ic, fastic, and skip.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOptionoscicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionoscmethod	string	custom		Spectre option oscmethod: Osc Newton method for autonomous HB. Possible values are onetier and twotier.
saSpectrePSSOptionoscmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectrePSSOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionoutputtype	string	custom	all	Spectre option outputtype: Output type. Possible values are all, time, and freq.
saSpectrePSSOptionoutputtypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionoversample	string	custom	[...]	Spectre option oversample: Array of oversample factors for each tone. This parameter overrides oversamplefactor.
saSpectrePSSOptionoversamplefactor	string	custom	1	Spectre option oversamplefactor: Oversample device evaluations.
saSpectrePSSOptionoversamplefactorUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionoversampleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionparam	string	custom		Spectre option param: Name of the parameter to be updated during pss/hb analysis (tstab stage).
saSpectrePSSOptionparamfile	string	custom		Spectre option param_file: The file that contains the time_value points to param=name.
saSpectrePSSOptionparamfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePSSOptionparamset	string	custom		Spectre option paramset: Name of the dynamic parameter set.
saSpectrePSSOptionparamsetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionparamstep	string	custom		Spectre option param_step: Defines the frequency of updating the dynamic parameter values. If param_step=0, it updates the parameter value at a given time point.
saSpectrePSSOptionparamstepUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saSpectrePSSOptionparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionparamvec	string	custom	[...]	Spectre option param_vec: The time_value points to param=name.
saSpectrePSSOptionparamvecUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionpinnode	string	custom		Spectre option pinnode: Node to pin during autonomous HB simulation.
saSpectrePSSOptionpinnodemag	string	custom		Spectre option pinnodemag: This parameter gives an estimate of the magnitude of the pin node voltage. Default value is 0.01.
saSpectrePSSOptionpinnodemagUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionpinnodeminus	string	custom		Spectre option pinnodeminus: Second node to pin during autonomous HB simulation. Needed only when differential nodes exist in oscillator.
saSpectrePSSOptionpinnodeminusUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionpinnoderank	string	custom		Spectre option pinnoderank: Harmonic rank to pin during autonomous HB simulation.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOptionpinnoderankUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saSpectrePSSOptionpinnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionppv	string	custom	no	Spectre option ppv: If set to yes, save the oscillators' perturbation projection vector (PPV), representing the oscillators' phase sensitivity to perturbations in the voltage or current at the nodes of the oscillator. Possible values are no and yes.
saSpectrePSSOptionppvUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionpsaratio	string	custom	1	Spectre option psaratio: Ratio used to compute high-order polynomial spectral accuracy from Newton tolerance. This parameter is only valid for shooting.
saSpectrePSSOptionpsaratioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionreadic	string	custom		Spectre option readic: File that contains initial condition.
saSpectrePSSOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionreadns	string	custom		Spectre option readns: File that contains an estimate of the initial transient solution.
saSpectrePSSOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionreadpss	string	custom		Spectre option readpss: File from which a previously converged steady-state solution is read. For shooting method, PSS loads the solution and checks the residue of the circuit equations only. The solution is re-used if the residue is satisfactory. Otherwise, the solution is re-converged using the finite difference method. The results from shooting QPSS cannot be used in HB QPSS analysis and vice-versa.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePSSOptionreadpssUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionrecover	string	custom		Spectre option recover: Specify the file to be restored.
saSpectrePSSOptionrecoverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionrelref	string	custom		Spectre option relref: Reference used for the relative convergence criteria. The default is derived from 'errpreset'. Possible values are pointlocal, alllocal, sigglobal, and allglobal.
saSpectrePSSOptionrelrefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionrestart	string	custom	no	Spectre option restart: Restart the DC/PSS solution if set to 'yes'; if set to 'no', reuse the previous solution as an initial guess; if set to 'firstonly', restart if it is the first point of sweep (supported only in HB). The default value is 'no' for HB and 'yes' for shooting. Possible values are no, yes, and firstonly.
saSpectrePSSOptionrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionsave	string	custom		Spectre option save: Signals to output. Possible values are all, lvi, allpub, lvi/pub, selected, none, and nooutput.
saSpectrePSSOptionsaveclock	string	custom		Spectre option saveclock: Save the tran analysis periodically on the wall clock time. The default is 1800s for Spectre. This parameter is disabled in the APS mode by default.
saSpectrePSSOptionsaveclockUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionsavefile	string	custom		Spectre option savefile: Save the analysis states into the specified file.
saSpectrePSSOptionsavefileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePSSOptionsaveperiod	string	custom		Spectre option saveperiod: Save the tran analysis periodically on the simulation time.
saSpectrePSSOptionsaveperiodhistory	string	custom	no	Spectre option saveperiodhistory: Maintains the history of saved files. If yes, maintains all the saved files. Possible values are no and yes.
saSpectrePSSOptionsaveperiodhistoryUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionsaveperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionsavetime	string	custom	[...]	Spectre option savetime: Save the analysis states into files on the specified time points.
saSpectrePSSOptionsavetimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionskipcount	string	custom	1	Spectre option skipcount: Save only one of every skipcount points.
saSpectrePSSOptionskipcountUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionskipdc	string	custom	no	Spectre option skipdc: If set to yes, there is no DC analysis for initial transient. Possible values are no, yes, and sigrampup.
saSpectrePSSOptionskipdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionskipstart	string	custom	0	Spectre option skipstart: The time to start skipping output data.
saSpectrePSSOptionskipstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionskipstop	string	custom	stop	Spectre option skipstop: The time to stop skipping output data.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOptionskipstopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionsteadyratio	string	custom		Spectre option steadyratio: Ratio used to compute steady-state tolerances from LTE tolerance. The default is derived from 'errpreset'.
saSpectrePSSOptionsteadyratioUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionstrobedelay	string	custom	0	Spectre option strobedelay: The delay (phase shift) between the skipstart time and the first strobe point.
saSpectrePSSOptionstrobedelayUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionstrobeperiod	string	custom	0	Spectre option strobeperiod: The output strobe interval (in seconds) of transient time.
saSpectrePSSOptionstrobeperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionsub	string	custom		Spectre option sub: Name of the subcircuit instance parameter specified in param=name.
saSpectrePSSOptionsubUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionswapfile	string	custom		Spectre option swapfile: Temporary file to hold steady-state information. It tells Spectre to use a regular file, rather than virtual memory to hold the periodic operating point. Use this option if Spectre complains about not having enough memory to complete the analysis. This parameter is now valid only for shooting.
saSpectrePSSOptionswapfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionsweepic	string	custom	none	Spectre option sweepic: IC extrapolation method in sweep HB analysis. Possible values are none, linear, and log.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOptionsweepicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectrePSSOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptiontstabenvlp	string	custom	no	Spectre option tstabenvlp: Determines the envelope method to be used for tstab. If the value is set to yes, envelope method will be used for tstab. Default value is no. Possible values are no and yes.
saSpectrePSSOptiontstabenvlpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptiontstabmethod	string	custom		Spectre option tstabmethod: Integration method used in stabilization time. The default is 'traponly' for autonomous circuits, or is derived from 'errpreset' for driven circuits. Possible values are euler, trap, traponly, gear2, and gear2only.
saSpectrePSSOptiontstabmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptiontstart	string	custom	0.0	Spectre option tstart: Initial transient analysis start time.
saSpectrePSSOptiontstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptiontunedev	string	custom		Spectre option tunedev: Sets the instance name of a device whose parameter (identified by tuneparam) will be varied such that the circuit oscillates at the specified frequency. Applies only in tuning mode autonomous analysis. Tunedev must be used with tuneparam.
saSpectrePSSOptiontunedevUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptiontunelin	string	custom		Spectre option tunelin: Specify the numbers of discrete tuning points. Must be used with 'tunerange'.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePSSOptiontunelinUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptiontuneparam	string	custom		Spectre option tuneparam: When set, tuneparam enables the tuning mode oscillator analysis. In the tuning mode analysis, a circuit parameter is automatically varied to reach the oscillation frequency specified by the fundfreqs parameter. The tuning parameter can be a device instance parameter (as determined by the parameters tunedev) or a netlist parameter. This mode applies only to autonomous circuits (oscillators).
saSpectrePSSOptiontuneparamUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptiontunerange	string	custom	[...]	Spectre option tunerange: The tuning range of the parameter identified by tuneparam. Although tunerange is not required, it can aid in convergence if set. Tunerange also can be used with 'tunestep' or 'tunelin' to decide the acceptable discrete parameter set.
saSpectrePSSOptiontunerangeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptiontunestep	string	custom		Spectre option tunestep: Specify the step size between two adjacent discrete tuning points. Must be used with 'tunerange'.
saSpectrePSSOptiontunestepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptiontunevalues	string	custom	[...]	Spectre option tunevalues: Specify the values of discrete tuning points.
saSpectrePSSOptiontunevaluesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionuseprevic	string	custom	no	Spectre option useprevic: If set to yes or ns, use the converged initial condition from previous analysis as ic or ns. Possible values are no, yes, and ns.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePSSOptionuseprevicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionwrite	string	custom		Spectre option write: File to which initial transient solution (before steady-state) is written.
saSpectrePSSOptionwritefinal	string	custom		Spectre option writefinal: File to which final transient solution in steady-state is written. This parameter is now valid only for shooting.
saSpectrePSSOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionwritepss	string	custom		Spectre option writepss: File to which the converged steady-state solution is written. The file of shooting and HB cannot be mutually reused.
saSpectrePSSOptionwritepssUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbcompression	string	custom	no	Spectre option xdbcompression: Sets the automatic gain compression analysis. In automatic gain compression analysis, Spectre automatically sweeps the input excitation until the gain, as defined by the analysis parameter xdbgain, compresses by the amount specified by the analysis parameter xdblevel. In gain compression analysis, Spectre outputs the hb solution at the calculated compression point only. Dependent analyses, such as hbnoise and hbac, are supported and calculated about the calculated compression level. Auxiliary output includes the gain and voltage/power compression curves. These outputs are available for analysis and post-processing in ADE. The possible values are yes and no. Default is no.
saSpectrePSSOptionxdbcompressionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOptionxdbcpi	string	custom		Spectre option xdbcpi: Sets the estimated input-referred compression point for rapid compression analysis.
saSpectrePSSOptionxdbcpiUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbgain	string	custom	power	Spectre option xdbgain: Chooses between the voltage gain and transducer power gain as the target for compression point calculation. When xdbgain=power, the gain is defined as $G \text{ (dB)} = P_{\text{load}} \text{ (dBm)} - P_{\text{available}} \text{ (dBm)}$. When xdbgain=voltage, the gain is defined as $G \text{ (dB)} = \text{dB}20(V_{\text{load}} / V_{\text{source}})$. In both cases, Spectre sweeps the excitation source until $\text{xdbref} - G = \text{xdblevel}$, where the analysis parameter xdbref defines the reference level for compression calculation. Possible values are power and voltage. Default is power.
saSpectrePSSOptionxdbgainUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbharm	string	custom	[...]	Spectre option xdbharm: The Integer array which specifies the harmonic indexes of the output voltage or power component.
saSpectrePSSOptionxdbharmUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdblevel	string	custom	[...]	Spectre option xdblevel: Sets the gain compression level for compression analysis. The reference point for gain compression is the small-signal gain of the circuits, or as specified by the analysis parameter xdbref. Default is 1.
saSpectrePSSOptionxdblevelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbload	string	custom		Spectre option xdbload: The instance name of the load termination. When xdbgain is power, xdbload can be a port, a resistor, or a current probe.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePSSOptionxdbloadUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbmax	string	custom		Spectre option xdbmax: The maximum input power (or voltage) for the compression point search. Default is 10 dBm when xdbgain=power, and 0.1 V when xdbgain=voltage.
saSpectrePSSOptionxdbmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbnoden	string	custom		Spectre option xdbnoden: The output terminals for voltage gain calculation when xdbgain=voltage. If either is left unspecified, the terminal is assumed to be the global ground.
saSpectrePSSOptionxdbnodenUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbnodep	string	custom		Spectre option xdbnodep: The output terminals for voltage gain calculation when xdbgain=voltage. If either is left unspecified, the terminal is assumed to be the global ground.
saSpectrePSSOptionxdbnodepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbrapid	string	custom	no	Spectre option xdbrapid: Sets the automatic gain compression analysis in rapid mode. In this mode, Spectre does not trace the compression curve and calculates only the compression point.
saSpectrePSSOptionxdbrapidUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbref	string	custom	linear	Spectre option xdbref: Sets the reference point for gain compression calculations. When xdbref=linear, spectre uses the small-signal gain as the reference. When xdbref=max, spectre uses the maximum observed gain as the reference. Possible values are linear and max. Default is linear.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOptionxdbrefnode	string	custom		Spectre option xdbrefnode: The reference node when xdbload is a current probe. The default is the ground node.
saSpectrePSSOptionxdbrefnodeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbrefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbsource	string	custom		Spectre option xdbsource: The instance name of the excitation source, which is swept automatically to reach the compression level. When xdbgain=power, the excitation source must be a port instance. When xdbgain=voltage, the excitation source must be a vsource instance.
saSpectrePSSOptionxdbsourceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbstart	string	custom		Spectre option xdbstart: The starting input power (or voltage) for the compression point search. Default is (xdbmax-50) dBm when xdbgain=power, and xdbmax/1000 when xdbgain=voltage.
saSpectrePSSOptionxdbstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbsteps	string	custom	100	Spectre option xdbsteps: The maximum number of steps for the compression point search. The simulator terminates if xdbsteps exceeds before the compression point is found. The default is 100.
saSpectrePSSOptionxdbstepsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSSOptionxdbtol	string	custom	0.01	Spectre option xdbtol: Sets the tolerance for compression analysis. This tolerance is used in compression curve fitting and calculating the compression point.
saSpectrePSSOptionxdbtolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSOscillator	string	saTestbench	0	Spectre PSS: Design is oscillator.
saSpectrePSSParam	string	saTestbench		Spectre PSS: Parameter being swept.
saSpectrePSSPeriod	string	saTestbench		Spectre PSS: Beat Period.
saSpectrePSSPhi	string	saTestbench		Spectre PSS: phi parameter being swept
saSpectrePSSPhilin	string	saTestbench		Spectre PSS: Number of phi linear steps
saSpectrePSSPhistart	string	saTestbench		Spectre PSS: Starting point of phi sweep limits
saSpectrePSSPhistep	string	saTestbench		Spectre PSS: Linear phi step size
saSpectrePSSPhiStepSpecLin	string	saTestbench	Number of Steps	Spectre PSS: Method of specifying phi linear stepping ("Step Size" "Number of Steps")
saSpectrePSSPhistop	string	saTestbench		Spectre PSS: Stopping point of phi sweep limits
saSpectrePSSPhiSweep	string	saTestbench	Linear	Spectre PSS: Method of sweeping phi values ("Linear" "Points of Interest")
saSpectrePSSPhivalues	string	saTestbench		Spectre PSS: Individual phi values, also known as points of interest
saSpectrePSSRho	string	saTestbench		Spectre PSS: rho parameter being swept
saSpectrePSSRholin	string	saTestbench		Spectre PSS: Number of rho linear steps
saSpectrePSSRhostart	string	saTestbench		Spectre PSS: Starting point of rho sweep limits
saSpectrePSSRhostep	string	saTestbench		Spectre PSS: Linear rho step size
saSpectrePSSRhoStepSpecLin	string	saTestbench	Number of Steps	Spectre PSS: Method of specifying rho linear stepping ("Step Size" "Number of Steps")
saSpectrePSSRhostop	string	saTestbench		Spectre PSS: Stopping point of rho sweep limits

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSSRhoSweep	string	saTestbench	Linear	Spectre PSS: Method of sweeping rho values ("Linear" "Points of Interest")
saSpectrePSSRhovalues	string	saTestbench		Spectre PSS: Individual rho values, also known as points of interest
saSpectrePSSSaveinit	string	saTestbench	0	Spectre PSS: Save Initial Transient Results.
saSpectrePSSSpan	string	saTestbench		Spectre PSS: Span between sweep limits.
saSpectrePSSStart	string	saTestbench		Spectre PSS: Starting point of sweep limits.
saSpectrePSSStep	string	saTestbench		Spectre PSS: Linear step size.
saSpectrePSSStepSpecLin	string	saTestbench	Number of Steps	Spectre PSS: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectrePSSStepSpecLog	string	saTestbench	Points per Decade	Spectre PSS: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectrePSSStop	string	saTestbench		Spectre PSS: Stopping point of sweep limits.
saSpectrePSSSub	string	saTestbench		Spectre PSS: Subcircuit with parameter being swept.
saSpectrePSSSweep	string	saTestbench	Linear	Spectre PSS: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectrePSSSweepSpec	string	saTestbench	<file path>	Spectre PSS: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectrePSSSweepVar	string	saTestbench	Temperature	Spectre PSS: Specifies what will be swept ("Design Variable" "Temperature" "Instance Parameter" "Model Parameter" "Subcircuit Parameter").
saSpectrePSSStab	string	saTestbench		Spectre PSS: Additional Time for Stabilization.
saSpectrePSSValues	string	saTestbench		Spectre PSS: Individual values, also known as points of interest.
saSpectrePSTBCenter	string	saTestbench		Spectre PSTB: Center point of sweep limits.
saSpectrePSTBDec	string	saTestbench		Spectre PSTB: Number of logarithmic steps per decade.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSTBDoSweep	string	saTestbench	1	Spectre PSTB: Flag indicating a sweep is to be performed.
saSpectrePSTBLin	string	saTestbench		Spectre PSTB: Number of linear steps.
saSpectrePSTBLocalgnd	string	saTestbench		Spectre PSTB: Node name of local ground.
saSpectrePSTBLog	string	saTestbench		Spectre PSTB: Total number of logarithmic steps.
saSpectrePSTBModeType	string	saTestbench	common	Spectre PSTB: Mode Type for diffstbprobe element.
saSpectrePSTBOperbe	string	saTestbench		Spectre PSTB: Probe instance around which the loop gain is calculated.
saSpectrePSTBOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, steps, and detailed_hb.
saSpectrePSTBOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptiongearorder	string	custom	2	Spectre option gear_order: Gear order used for small-signal integration.
saSpectrePSTBOptiongearorderUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptionhbprecondsolver	string	custom	autoset	Spectre option hbprecond_solver: Select a linear solver for the GMRES preconditioner. Default is autoset. With autoset, the simulator will automatically select the appropriate preconditioner. The preconditioner affects the rate of convergence of the linear matrix solver used in periodic small-signal analysis. When autoset is selected, the simulator may decide to switch to a different preconditioner after the analysis begins. When that happens, the simulator may issue a warning instructing you to choose a different preconditioner during subsequent runs. Although not required, choosing a different preconditioner according to the simulator's instructions may speed up subsequent analyses. Possible values are basicsolver, blocksolver, autoset, blockdense, and blocksolver2.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSTBOptionhbprecondsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptionkrylovsize	string	custom	200	Spectre option krylov_size: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*krylov_size iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the krylov_size if the simulation reports insufficient norm reduction errors in GMRES.
saSpectrePSTBOptionkrylovsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptionlocalgnd	string	custom		Spectre option localgnd: Node name of local ground. If not specified, the probe is referenced to global ground.
saSpectrePSTBOptionlocalgndUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.
saSpectrePSTBOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptionoscaccuracy	string	custom	2	Spectre option osc_accuracy: Accuracy control in small signal analysis for autonomous circuit when osc_version=dts. The higher this value, the more iterations GMRES solver will take. Maximum effective value is 5.
saSpectrePSTBOptionoscaccuracyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptionoscsolver	string	custom	turbo	Spectre option oscsolver: Oscillator solver type. It is recommended that you use ira for huge circuits. Possible values are std, turbo, ira, and direct.
saSpectrePSTBOptionoscsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSTBOptionoscversion	string	custom	dtc	Spectre option osc_version: Specifies the method to use in small signal analysis for autonomous circuit. Possible values are floquet, augmented, and dtc.
saSpectrePSTBOptionoscversionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectrePSTBOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptionrelativeTol	string	custom		Spectre option relativeTol: Relative tolerance for harmonic balance-based linear solver. Default value is 1.0e-2.
saSpectrePSTBOptionrelativeTolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptionresgmrescycle	string	custom	short	Spectre option resgmrescycle: Restarts GMRES cycle. Possible values are instant, short, long, recycleinstant, recycleshort, and recyclelong.
saSpectrePSTBOptionresgmrescycleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptionsave	string	custom		Spectre option save: Signals to output. Possible values are all, lvi, allpub, lvi/pub, selected, none, and nooutput.
saSpectrePSTBOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptionsolver	string	custom	turbo	Spectre option solver: Solver type. Possible values are std, turbo, std_hh, and turbo_hh.
saSpectrePSTBOptionsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptiontitle	string	custom		Spectre option title: Analysis title.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePSTBOptiontitleUncheck Localized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptiontolerance	string	custom		Spectre option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saSpectrePSTBOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePSTBOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectrePSTBSpan	string	saTestbench		Spectre PSTB: Span between sweep limits.
saSpectrePSTBStart	string	saTestbench		Spectre PSTB: Starting point of sweep limits.
saSpectrePSTBStep	string	saTestbench		Spectre PSTB: Linear step size.
saSpectrePSTBStepSpecLin	string	saTestbench	Number of Steps	Spectre PSTB: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectrePSTBStepSpecLog	string	saTestbench	Points per Decade	Spectre PSTB: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectrePSTBStop	string	saTestbench		Spectre PSTB: Stopping point of sweep limits.
saSpectrePSTBSweep	string	saTestbench	Logarithmic	Spectre PSTB: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectrePSTBSweepSpec	string	saTestbench	<file path>	Spectre PSTB: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectrePSTBValues	string	saTestbench		Spectre PSTB: Individual values, also known as points of interest.
saSpectrePSTBValuesfile	string	saTestbench		Spectre PSTB: File for individual values
saSpectrePXFCenter	string	saTestbench		Spectre PXF: Center point of sweep limits.
saSpectrePXFDec	string	saTestbench		Spectre PXF: Number of logarithmic steps per decade.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePXFLin	string	saTestbench		Spectre PXF: Number of linear steps.
saSpectrePXFLog	string	saTestbench		Spectre PXF: Total number of logarithmic steps.
saSpectrePXFMaxsideband	string	saTestbench	1	Spectre PXF: Maximum Sideband.
saSpectrePXFOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, steps, and detailed_hb.
saSpectrePXFOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptioncrossingdirection	string	custom	all	Spectre option crossingdirection: Specifies the transitions for which sampling must be done. Possible values are all, rise, fall, and ignore.
saSpectrePXFOptiondeterministicsources	string	custom		Spectre option deterministicsources: Pairs of terminals or nodes corresponding to deterministic jitter sources.
saSpectrePXFOptiondeterministicsourcesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptiondeterministicsourcesfreqs	string	custom		Spectre option deterministicsourcesfreqs: Frequency list corresponding to the external deterministic jitter sources.
saSpectrePXFOptiondeterministicsourcesfreqsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionextcorrsources1	string	custom		Spectre option extcorrsources1: Pairs of terminals and nodes for the first group of correlated external jitter sources.
saSpectrePXFOptionextcorrsources1UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionextcorrsources2	string	custom		Spectre option extcorrsources2: Pairs of terminals and nodes for the second group of correlated external jitter sources.
saSpectrePXFOptionextcorrsources2UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePXFOptionexternalsources	string	custom		Spectre option externalsources: Pairs of terminals or nodes corresponding to external jitter sources.
saSpectrePXFOptionexternalsourcesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionextrasampletimepoints	string	custom	[...]	Spectre option extrasampletimepoints: Additional time points for sampled PTV analysis.
saSpectrePXFOptionfreqaxis	string	custom		Spectre option freqaxis: Specifies whether the results should be printed as per the input frequency, the output frequency, or the absolute value of the input frequency. The default is 'absin'. Possible values are absin, in, and out.
saSpectrePXFOptionfreqaxisUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionfreqdivide	string	custom	1	Spectre option freqdivide: Large signal frequency division. Used for oscillator circuit with divider in when osc_version=ds for shooting engine.
saSpectrePXFOptionfreqdivideUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptiongearorder	string	custom	2	Spectre option gear_order: Gear order used for small-signal integration.
saSpectrePXFOptiongearorderUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePXFOptionhbprecondsolver	string	custom	autoset	Spectre option hbprecond_solver: Select a linear solver for the GMRES preconditioner. Default is autoset. With autoset, the simulator will automatically select the appropriate preconditioner. The preconditioner affects the rate of convergence of the linear matrix solver used in periodic small-signal analysis. When autoset is selected, the simulator can decide to switch to a different preconditioner after the analysis begins. When that happens, the simulator might issue a warning instructing you to choose a different preconditioner during subsequent runs. Although not required, choosing a different preconditioner according to the simulator's instructions might speed up subsequent analyses. Possible values are basicsolver, blocksolver, autoset, blockdense, and blocksolver2.
saSpectrePXFOptionhbprecondsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptioninmodharmvec	string	custom	[...]	Spectre option inmodharmvec: Harmonic list for the PXF modulated sources.
saSpectrePXFOptioninmodharmvecUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionkrylovsize	string	custom	200	Spectre option krylov_size: This parameter is used to set maximum iteration count of the linear matrix solver used in periodic small-signal analysis. After reaching 1.25*krylov_size iterations, the iteration is forced to terminate because of the poor rate of convergence. Increase the krylov_size if the simulation reports insufficient norm reduction errors in GMRES.
saSpectrePXFOptionkrylovsizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionmaxsamples	string	custom	16	Spectre option maxsamples: Maximum number of sampled events to be processed during the sampled analysis.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePXFOptionmodulated	string	custom	no	Spectre option modulated: Compute transfer functions/conversion between modulated sources and outputs. Possible values are single, first, second, and no.
saSpectrePXFOptionmodulatedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionmoduppersideband	string	custom	1	Spectre option moduppersideband: Index of the upper sideband included in the modulation of an output for PAC and HBAC, or an input for PXF.
saSpectrePXFOptionmoduppersidebandUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.
saSpectrePXFOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionoscaccuracy	string	custom	2	Spectre option osc_accuracy: Accuracy control in small signal analysis for autonomous circuit when osc_version=dts. The higher this value, the more iterations GMRES solver will take. Maximum effective value is 5.
saSpectrePXFOptionoscaccuracyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionoscsolver	string	custom	turbo	Spectre option oscsolver: Oscillator solver type. It is recommended that you use ira for huge circuits. Possible values are std, turbo, ira, and direct.
saSpectrePXFOptionoscsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionoscversion	string	custom	dts	Spectre option osc_version: Specifies the method to use in small signal analysis for autonomous circuit. Possible values are floquet, augmented, and dts.
saSpectrePXFOptionoscversionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePXFOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectrePXFOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionoutmodharmnum	string	custom	1	Spectre option outmodharmnum: Harmonic for the PXF output modulation.
saSpectrePXFOptionoutmodharmnumUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionptvtype	string	custom	timeaveraged	Spectre option ptvtype: Specifies whether the PTV analysis will be traditional or sampled under certain conditions. Possible values are timeaveraged and sampled.
saSpectrePXFOptionrelativeTol	string	custom		Spectre option relativeTol: Relative tolerance for harmonic balance-based linear solver. Default value is 1.0e-2.
saSpectrePXFOptionrelativeTolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionrelharmnum	string	custom	1	Spectre option relharmnum: Harmonic to which relative frequency sweep should be referenced.
saSpectrePXFOptionrelharmnumUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionresgmrescycle	string	custom	short	Spectre option resgmrescycle: Restarts GMRES cycle. Possible values are instant, short, long, recycleinstant, recycleshort, and recyclelong.
saSpectrePXFOptionresgmrescycleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionsampleprobe	string	custom		Spectre option sampleprobe: The crossing event at this port triggers the sampled small signal computation.
saSpectrePXFOptionsampleratio	string	custom	1	Spectre option sampleratio: The ratio between sampled frequency and fund frequency (sampled frequency/fund frequency).

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePXFOptionsave	string	custom		Spectre option save: Signals to output. Possible values are all, lvl, allpub, lvlpub, selected, none, and nooutput.
saSpectrePXFOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionsolver	string	custom	turbo	Spectre option solver: Solver type. Possible values are std, turbo, std_hh, and turbo_hh.
saSpectrePXFOptionsolverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionstimuli	string	custom	sources	Spectre option stimuli: Stimuli used for pxf analysis. Possible values are sources and nodes_and_terminals.
saSpectrePXFOptionstimuliUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionthresholdvalue	string	custom	0	Spectre option thresholdvalue: Sampled measurement is done when the signal crosses this value.
saSpectrePXFOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectrePXFOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptiontolerance	string	custom		Spectre option tolerance: Tolerance for linear solver. The default value is 1.0e-9 for shooting-based solver and 1.0e-4 for harmonic balance-based solver.
saSpectrePXFOptiontoleranceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePXFOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectrePXFOutputType	string	saTestbench	Voltage	Spectre PXF: Output type.
saSpectrePXFRelharmnum	string	saTestbench	1	Spectre PXF: Harmonic index number for relative sweep.
saSpectrePXFSampleType	string	saTestbench	Probe	Spectre PXF: The type of sampling trigger to use (Probe or Voltage)

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePXFSidebands	string	saTestbench	1	Spectre PXF: Sidebands.
saSpectrePXFSidebandType	string	saTestbench	Maximum Sideband	Spectre PXF: Sideband type.
saSpectrePXFSpan	string	saTestbench		Spectre PXF: Span between sweep limits.
saSpectrePXFSstart	string	saTestbench		Spectre PXF: Starting point of sweep limits.
saSpectrePXFSstep	string	saTestbench		Spectre PXF: Linear step size.
saSpectrePXFSstepSpecLin	string	saTestbench	Number of Steps	Spectre PXF: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectrePXFSstepSpecLog	string	saTestbench	Points per Decade	Spectre PXF: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectrePXFSstop	string	saTestbench		Spectre PXF: Stopping point of sweep limits.
saSpectrePXFSsweep	string	saTestbench	Logarithmic	Spectre PXF: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectrePXFSsweepSpec	string	saTestbench	<file path>	Spectre PXF: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectrePXFSsweepType	string	saTestbench	Default	Spectre PXF: Frequency sweep type.
saSpectrePXFSvalues	string	saTestbench		Spectre PXF: Individual values, also known as points of interest.
saSpectrePXFSvaluesfile	string	saTestbench		Spectre PXF: File for individual values
saSpectrePZCenter	string	saTestbench		Spectre PZ: Center point of sweep limits.
saSpectrePZDec	string	saTestbench		Spectre PZ: Number of logarithmic steps per decade.
saSpectrePZDesignVar	string	saTestbench		Spectre PZ: Design variable being swept.
saSpectrePZDev	string	saTestbench		Spectre PZ: Instance with parameter being swept.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePZDoSweep	string	saTestbench	0	Spectre PZ: Flag indicating a sweep is to be performed.
saSpectrePZFreq	string	saTestbench		Spectre PZ: Single value to hold frequency while other aspect is being swept.
saSpectrePZIProbe	string	saTestbench		Spectre Pole Zero input device probe.
saSpectrePZLin	string	saTestbench		Spectre PZ: Number of linear steps.
saSpectrePZLog	string	saTestbench		Spectre PZ: Total number of logarithmic steps.
saSpectrePZMod	string	saTestbench		Spectre PZ: Model with parameter being swept.
saSpectrePZNegNode	string	saTestbench		Spectre Pole Zero Negative output node.
saSpectrePZNode	string	saTestbench		Spectre Pole Zero Positive output node.
saSpectrePZOProbe	string	saTestbench		Spectre Pole Zero output device probe.
saSpectrePZOptionabsdiff	string	custom	1e-6	Spectre option absdiff: Pole-Zero cancel absolute distance in Hz.
saSpectrePZOptionabsdiffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, and steps.
saSpectrePZOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptiondocancel	string	custom	yes	Spectre option docancel: If set, pole-zero cancellation is requested. Possible values are no and yes.
saSpectrePZOptiondocancelUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePZOptionfmax	string	custom		Spectre option fmax: Maximum pole and zero frequency value to filter out spurious poles and zeros. This parameter is passed to psf outputs for plotting filtering.
saSpectrePZOptionfmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionmethod	string	custom	qz	Spectre option method: Method to perform pz analysis. Possible values are qz and arnoldi.
saSpectrePZOptionmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionnumpoles	string	custom		Spectre option numpoles: Maximum number of poles requested, only for arnoldi method.
saSpectrePZOptionnumpolesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionnumzeros	string	custom		Spectre option numzeros: Maximum number of zeros requested, only for arnoldi method.
saSpectrePZOptionnumzerosUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionoppoint	string	custom	no	Spectre option oppoint: Should operating point information be computed, and if so, where should it be sent. Possible values are no, screen, logfile, and rawfile.
saSpectrePZOptionoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectrePZOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectrePZOptionpoleemphasis	string	custom	lowfreq	Spectre option pole_emphasis: If set to lowfreq, calculate low-frequency poles more accurately. If set to highfreq, calculate high-frequency poles more accurately. Possible values are lowfreq and highfreq.
saSpectrePZOptionpoleemphasisUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionprevoppoint	string	custom	no	Spectre option prevoppoint: Use the operating point computed on the previous analysis. Possible values are no and yes.
saSpectrePZOptionprevoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionreadns	string	custom		Spectre option readns: File that contains estimate of DC solution (nodeset).
saSpectrePZOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionreldiff	string	custom	1e-4	Spectre option reldiff: Pole-Zero cancel relative distance.
saSpectrePZOptionreldiffUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionrestart	string	custom	yes	Spectre option restart: Restart the DC solution from scratch if any condition has changed. If not, use the previous solution as initial guess. Possible values are no and yes.
saSpectrePZOptionrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionsigmai	string	custom	0.0	Spectre option sigmai: root finding control parameter, only for arnoldi method.
saSpectrePZOptionsigmaiUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionsigmar	string	custom	0.1	Spectre option sigmar: root finding control parameter, only for arnoldi method.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePZOptionsigmarUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectrePZOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionuseprevic	string	custom	no	Spectre option useprevic: If set to yes or ns, use the converged initial condition from previous analysis as ic or ns. Possible values are no, yes, and ns.
saSpectrePZOptionuseprevicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectrePZOptionzeroonly	string	custom	no	Spectre option zeroonly: If set, only zeros are requested. Possible values are no and yes.
saSpectrePZOptionzeroonlyUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectrePZParam	string	saTestbench		Spectre PZ: Parameter being swept.
saSpectrePZSpan	string	saTestbench		Spectre PZ: Span between sweep limits.
saSpectrePZStart	string	saTestbench		Spectre PZ: Starting point of sweep limits.
saSpectrePZStep	string	saTestbench		Spectre PZ: Linear step size.
saSpectrePZStepSpecLin	string	saTestbench	Number of Steps	Spectre PZ: Method of specifying linear stepping ("Step Size" "Number of Steps")
saSpectrePZStepSpecLog	string	saTestbench	Points per Decade	Spectre PZ: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectrePZStop	string	saTestbench		Spectre PZ: Stopping point of sweep limits.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectrePZSub	string	saTestbench		Spectre PZ: Subcircuit with parameter being swept.
saSpectrePZSweep	string	saTestbench	Linear	Spectre PZ: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectrePZSweepSpec	string	saTestbench	<file path>	Spectre PZ: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectrePZSweepVar	string	saTestbench	Temperature	Spectre PZ: Specifies what will be swept ("Frequency (Hz)" "Design Variable" "Temperature" "Instance Parameter" "Model Parameter" "Subcircuit Parameter").
saSpectrePZValues	string	saTestbench		Spectre PZ: Individual values, also known as points of interest.
saSpectrePZValuesfile	string	saTestbench		Spectre PZ: File for individual values
saSpectreSaveOptionsCurrents	string	saTestBench	selected	Spectre Currents to be saved.
saSpectreSaveOptionsEmTStart	string	saTestbench		Start time for electromigration current analysis.
saSpectreSaveOptionsEmTStop	string	saTestbench		Stop time for electromigration current analysis.
saSpectreSaveOptionsEnableEM	string	saTestbench	false	Save currents for in-design layout automation.
saSpectreSaveOptionsEnableVDRC	string	saTestbench	false	Save voltage extremes to enable VDRC flow.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreSaveOptionsInfos	string	saTestBe nch	{true modelPara meter models rawfile {} { } {true element inst rawfile { } { } {true outputPara meter output rawfile {} { } { } {true designPara mVals parameters rawfile {} { } { } {true primitives primitives rawfile {} { } { } {true subckts subckts rawfile {} { } { } {false asserts assert rawfile {} { } { } {false extremei nfo all logfile {} yes { } }	Spectre circuit information to be saved.
saSpectreSaveOptionsName	string	saTestBe nch	save Options	Spectre saveOptions.
saSpectreSaveOptionsNestlvl	string	saTestBe nch		Spectre Subcircuit level to output.
saSpectreSaveOptionsPwr	string	saTestBe nch	none	Spectre Power signals to be saved.
saSpectreSaveOptionsRedundant currents	string	saTestBe nch	no	Spectre Save both currents for two-terminal devices.
saSpectreSaveOptionsRedundant currents	string	saTestbe nch	selected	FineSimProSpectre Currents to be saved.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreSaveOptionsSave	string	saTestbench	selected	Spectre Signals to be saved.
saSpectreSaveOptionsSaveahdlvars	string	saTestbench	selected	Spectre Save AHDL variables.
saSpectreSaveOptionsSubcktprobevl	string	saTestbench	0	Spectre Subcircuit level to create current probes.
saSpectreSaveOptionsUseprobes	string	saTestbench	no	Spectre Use probes to measure currents.
saSpectreSaveOptionsUseterms	string	saTestbench	index	Spectre Terminal current output style.
saSpectreSaveOptionsVdrcTStart	string	saTestbench		Start time for VDRC voltage analysis.
saSpectreSaveOptionsVdrcTStop	string	saTestbench		Stop time for VDRC voltage analysis.
saSpectreSENSAc	bool	saTestbench	false	AC as Base Analysis for sensitivity analysis. Valid values: true, false
saSpectreSENSDc	bool	saTestbench	false	DC as Base Analysis for sensitivity analysis. Valid values: true, false
saSpectreSENSDcOP	bool	saTestbench	false	dcOP as Base Analysis for sensitivity analysis. Valid values: true, false
saSpectreSENSOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectreSENSOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreShowModelGroups	bool	saTestbench	false	Displays the Model Groups table for Spectre. Valid values: true, false
saSpectreSimulationCommandPrefix	string	user		An environment initialization command to be added to simulation commands.
saSpectreSimulatorOptionsImport	string	saTestbench	Import	Spectre simulatorOptions Import Setting.
saSpectreSPCenter	string	saTestbench		Spectre SP: Center point of sweep limits.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreSPDatafmt	string	saTestbench	touchstone	Spectre SP: Data Format.
saSpectreSPDatatype	string	saTestbench	realimag	Spectre SP: Data Type.
saSpectreSPDec	string	saTestbench		Spectre SP: Number of logarithmic steps per decade.
saSpectreSPDesignVar	string	saTestbench		Spectre SP: Design variable being swept.
saSpectreSPDev	string	saTestbench		Spectre SP: Instance with parameter being swept.
saSpectreSPDoNoise	string	saTestbench	0	Spectre SP: Do Noise Analysis.
saSpectreSPFreq	string	saTestbench		Spectre SP: Single value to hold frequency while other aspect is being swept.
saSpectreSPLin	string	saTestbench		Spectre SP: Number of linear steps.
saSpectreSPLog	string	saTestbench		Spectre SP: Total number of logarithmic steps.
saSpectreSPMod	string	saTestbench		Spectre SP: Model with parameter being swept.
saSpectreSPMode	string	saTestbench	Single-Ended	Spectre SP: Mode.
saSpectreSPModeOther	string	saTestbench		Spectre SP: Mode other.
saSpectreSPOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, and steps.
saSpectreSPOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionfile	string	custom		Spectre option file: Output file name.
saSpectreSPOptionfileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionforce	string	custom	none	Spectre option force: The set of initial conditions to use. Possible values are none, node, dev, and all.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreSPOptionforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptioniprobe	string	custom		Spectre option iprobe: Input probe. Refer the output noise to this component.
saSpectreSPOptioniprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionnoisedata	string	custom	no	Spectre option noisedata: Should noise data be saved to the S-parameter output file; if yes, in what format. Possible values are no, twoport, and cy.
saSpectreSPOptionnoisedataUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionoppoint	string	custom	no	Spectre option opoint: Determines whether operating point information should be computed: if yes, where should it be printed (screen or file). Operating point information is not printed if the operating point computed in the previous analysis remains unchanged. Possible values are no, screen, logfile, and rawfile.
saSpectreSPOptionoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionoprobe	string	custom		Spectre option oprobe: Compute total noise at the output defined by this component.
saSpectreSPOptionoprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectreSPOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreSPOptionparamtype	string	custom	s	Spectre option paramtype: Output parameter type. If set to s, the S-parameters will be output to raw data. If 'file' is specified, the S-parameters will be output to the file. If set to y, both S-parameters and Y-parameters will be output to raw data. If 'file' is specified, the normalized Y-parameters will be output to the file. If set to z, the behavior is similar to y. If set to yz, then S-parameters, Y-parameters, and Z-parameters will be output to raw data. However, if 'file' is specified, only the S-parameters will be output to the file. Possible values are s, y, z, and yz.
saSpectreSPOptionparamtypeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionprevoppoint	string	custom	no	Spectre option prevoppoint: Use the operating point computed in the previous analysis. Possible values are no and yes.
saSpectreSPOptionprevoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionreadforce	string	custom		Spectre option readforce: File that contains initial conditions.
saSpectreSPOptionreadforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionreadns	string	custom		Spectre option readns: File that contains an estimate of the DC solution (nodeset).
saSpectreSPOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionrestart	string	custom	yes	Spectre option restart: Restart the DC solution from scratch if any condition has changed. If not, use the previous solution as an initial guess. Possible values are no and yes.
saSpectreSPOptionrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreSPOptionskipdc	string	custom	no	Spectre option skipdc: Skip DC analysis. Possible values are no and yes.
saSpectreSPOptionskipdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionsprobes	string	custom	[...]	Spectre option sprobes: List of s-probes.
saSpectreSPOptionsprobesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectreSPOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionuseprevic	string	custom	no	Spectre option useprevic: If set to yes or ns, use the converged initial condition from previous analysis as ic or ns. Possible values are no, yes, and ns.
saSpectreSPOptionuseprevicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectreSPOptionwrite	string	custom		Spectre option write: DC operating point output file at the first step of the sweep.
saSpectreSPOptionwritefinal	string	custom		Spectre option writefinal: DC operating point output file at the last step of the sweep.
saSpectreSPOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSPParam	string	saTestbench		Spectre SP: Parameter being swept.
saSpectreSPSpan	string	saTestbench		Spectre SP: Span between sweep limits.
saSpectreSPStart	string	saTestbench		Spectre SP: Starting point of sweep limits.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreSPStep	string	saTestbench		Spectre SP: Linear step size.
saSpectreSPStepSpecLin	string	saTestbench	Number of Steps	Spectre SP: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreSPStepSpecLog	string	saTestbench	Points per Decade	Spectre SP: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectreSPStop	string	saTestbench		Spectre SP: Stopping point of sweep limits.
saSpectreSPSub	string	saTestbench		Spectre SP: Subcircuit with parameter being swept.
saSpectreSPSweep	string	saTestbench	Logarithmic	Spectre SP: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectreSPSweepSpec	string	saTestbench	<file path>	Spectre SP: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectreSPSweepVar	string	saTestbench	Frequency (Hz)	Spectre SP: Specifies what will be swept ("Frequency (Hz)" "Design Variable" "Temperature" "Instance Parameter" "Model Parameter" "Subcircuit Parameter").
saSpectreSPValues	string	saTestbench		Spectre SP: Individual values, also known as points of interest.
saSpectreSPValuesfile	string	saTestbench		Spectre SP: File for individual values
saSpectreSTBCenter	string	saTestbench		Spectre STB: Center point of sweep limits.
saSpectreSTBDec	string	saTestbench		Spectre STB: Number of logarithmic steps per decade.
saSpectreSTBDesignVar	string	saTestbench		Spectre STB: Design variable being swept.
saSpectreSTBDev	string	saTestbench		Spectre STB: Instance with parameter being swept.
saSpectreSTBDoSweep	string	saTestbench	1	Spectre STB: Flag indicating a sweep is to be performed.
saSpectreSTBFreq	string	saTestbench		Spectre STB: Single value to hold frequency while other aspect is being swept.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreSTBLin	string	saTestbench		Spectre STB: Number of linear steps.
saSpectreSTBLocalgnd	string	saTestbench		Spectre STB: Node name of local ground.
saSpectreSTBLog	string	saTestbench		Spectre STB: Total number of logarithmic steps.
saSpectreSTBMod	string	saTestbench		Spectre STB: Model with parameter being swept.
saSpectreSTBModeType	string	saTestbench	common	Spectre STB: Mode Type for difftbprobe element.
saSpectreSTBProbe	string	saTestbench		Spectre STB: Probe instance around which the loop gain is calculated.
saSpectreSTBOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, and steps.
saSpectreSTBOptionannotateUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saSpectreSTBOptionforce	string	custom	none	Spectre option force: Which set of initial conditions to use. Possible values are none, node, dev, and all.
saSpectreSTBOptionforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSTBOptionlocalgnd	string	custom		Spectre option localgnd: Node name of local ground. If not specified, the probe is referenced to global ground.
saSpectreSTBOptionlocalgndUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSTBOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.
saSpectreSTBOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreSTBOptionoppoint	string	custom	no	Spectre option oppoint: Should operating point information be computed; if yes, where should it be sent. Operating point information would not be output if the operating point computed in the previous analysis remains unchanged. Possible values are no, screen, logfile, and rawfile.
saSpectreSTBOptionoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSTBOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectreSTBOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSTBOptionprevoppoint	string	custom	no	Spectre option prevoppoint: Use the operating point computed on the previous analysis. Possible values are no and yes.
saSpectreSTBOptionprevoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSTBOptionreadforce	string	custom		Spectre option readforce: File that contains initial conditions.
saSpectreSTBOptionreadforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSTBOptionreadns	string	custom		Spectre option readns: File that contains estimate of DC solution (nodeset).
saSpectreSTBOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSTBOptionrestart	string	custom	yes	Spectre option restart: Restart the DC solution from scratch if any condition has changed. If not, use the previous solution as initial guess. Possible values are no and yes.
saSpectreSTBOptionrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreSTBOptionsave	string	custom		Spectre option save: Signals to output. Possible values are all, lvi, allpub, lvi/pub, selected, none, and nooutput.
saSpectreSTBOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSTBOptionskipdc	string	custom	no	Spectre option skipdc: Skip the DC analysis. Possible values are no and yes.
saSpectreSTBOptionskipdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSTBOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectreSTBOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSTBOptionuseprevic	string	custom	no	Spectre option useprevic: If set to yes or ns, use the converged initial condition from previous analysis as ic or ns. Possible values are no, yes, and ns.
saSpectreSTBOptionuseprevicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSTBOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectreSTBOptionwrite	string	custom		Spectre option write: DC operating point output file at the first step of the sweep.
saSpectreSTBOptionwritefinal	string	custom		Spectre option writefinal: DC operating point output file at the last step of the sweep.
saSpectreSTBOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSTBOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreSTBParam	string	saTestbench		Spectre STB: Parameter being swept.
saSpectreSTBSpan	string	saTestbench		Spectre STB: Span between sweep limits.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreSTBStart	string	saTestbench		Spectre STB: Starting point of sweep limits.
saSpectreSTBStep	string	saTestbench		Spectre STB: Linear step size.
saSpectreSTBStepSpecLin	string	saTestbench	Number of Steps	Spectre STB: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreSTBStepSpecLog	string	saTestbench	Points per Decade	Spectre STB: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectreSTBStop	string	saTestbench		Spectre STB: Stopping point of sweep limits.
saSpectreSTBSub	string	saTestbench		Spectre STB: Subcircuit with parameter being swept.
saSpectreSTBSweep	string	saTestbench	Logarithmic	Spectre STB: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectreSTBSweepSpec	string	saTestbench	<file path>	Spectre STB: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectreSTBSweepVar	string	saTestbench	Frequency (Hz)	Spectre STB: Specifies what will be swept ("Frequency (Hz)" "Design Variable" "Temperature" "Instance Parameter" "Model Parameter" "Subcircuit Parameter").
saSpectreSTBValues	string	saTestbench		Spectre STB: Individual values, also known as points of interest.
saSpectreSTBValuesfile	string	saTestbench		Spectre STB: File for individual values
saSpectreTemperatureImport	string	saTestbench	Import	Spectre temperature Import Setting.
saSpectreTRANDpmethod	string	saTestbench	File	Spectre tran parameter values in file/vector
saSpectreTRANDynamicParameters	bool	saTestbench	false	Spectre tran show/hide dynamic parameters Valid values: true, false
saSpectreTRANErrpreset	string	saTestbench	moderate	Spectre Transient errpreset.
saSpectreTRANInstancesListExp	string	saTestbench	false	Spectre TRAN: Activation/Deactivation of noise instances list
saSpectreTRANNoiseifmax	string	saTestbench		Spectre TRAN: A nonzero value turns on the noise sources during transient analysis

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreTRANNoisefmin	string	saTestbench		Spectre TRAN: If specified, PSD of the noise sources from noise fmin to noise fmax
saSpectreTRANNoiseOnOffSel	string	saTestbench	On	Spectre TRAN: Select if instances list correspond to noisy or noiseless devices
saSpectreTRANNoiseSeedSel	string	saTestbench	Fixed Value	Spectre TRAN: Trannoise seed type selection. Fixed value or sweep setup
saSpectreTRANNoiseSeedStart	string	saTestbench		Spectre TRAN: Trannoise seed sweep start
saSpectreTRANNoiseSeedStop	string	saTestbench		Spectre TRAN: Trannoise seed sweep stop
saSpectreTRANNoiseSeedVal	string	saTestbench	1	Spectre TRAN: Trannoise seed fixed value
saSpectreTRANOptionacnames	string	custom	[...]	Spectre option acnames: Names of ac, noise, sp, stb, xf, or If analyses to be performed at each time point in the 'actimes' array. The named small-signal analyses are not run separately, but only as part of the transient analysis.
saSpectreTRANOptionacnamesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionactimes	string	custom	[...]	Spectre option actimes: Times when analyses specified in 'acname' array are performed.
saSpectreTRANOptionactimesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionannotatedigits	string	custom	4	Spectre option annotatedigits: number of significant digits for annotate tran time. Valid values: 0, 1, 2 ...16. If set to 0, the number of significant digits is dynamic according to current time and step. If set to n (n = 1, 2 ...16), the number is equal to n..
saSpectreTRANOptionannotatedigitsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionannotateic	string	custom	no	Spectre option annotateic: Degree of annotation for initial condition. Valid values: no, title, sweep, status, steps, iters, detailed, and rejects.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreTRANOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionautostopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptioncircuitageUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionckptperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptioncminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptioncompiabstol	string	custom	1.0e-12	Spectre option compiabstol: Absolute current tolerance for waveform compression.
saSpectreTRANOptioncompiabstolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptioncomplvl	string	custom		Spectre option complvl: Enables waveform compression for specified hierarchy level and below (top level=1). All levels above specified level are not compressed. Complvl has higher priority than global compression statement.
saSpectreTRANOptioncomplvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptioncompreltol	string	custom	0.001	Spectre option compreltol: Relative tolerance for waveform compression.
saSpectreTRANOptioncompreltolUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptioncompressionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreTRANOptioncompvabs tol	string	custom	1.0e-3	Spectre option compvabstol: Absolute voltage tolerance for waveform compression.
saSpectreTRANOptioncompvabsto lUncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptiond2aminstep	string	custom	0	Spectre option d2aminstep: Minimum stepsize that can be taken when there is a D2A event. If this is zero, the simulators min step size is chosen.
saSpectreTRANOptiond2aminstep UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptiond2atimetol	string	custom	0	Spectre option d2atimetol: Time tolerance for D2A events. The smaller the value, the closer the time when the analog solver actually executes the d2a event may be to the time when the event gets reported.
saSpectreTRANOptiond2atimetolU ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptiondcmxiter	string	custom	150	Spectre option dcmxiter: Maximum number of dc iterations in tranFindInitialState.
saSpectreTRANOptiondcmxiter UncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptiondev	string	custom		Spectre option dev: Name of the device instance parameter specified in param=name.
saSpectreTRANOptiondevUnchec kLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionemirfile	string	custom		Spectre option emirfile: Name of the EM/IR database file. The default is '%A_emir_vavo.db'. The file is output to raw directory.
saSpectreTRANOptionemirfileUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreTRANOptionemirformat	string	custom	none	Spectre option emirformat: Format of the EM/IR database file. Valid values: none and vavo.
saSpectreTRANOptionemirformatUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionemirstart	string	custom		Spectre option emirstart: EM/IR start time.
saSpectreTRANOptionemirstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionemirstop	string	custom		Spectre option emirstop: EM/IR stop time.
saSpectreTRANOptionemirstopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionemirtimewindows	string	custom	[...]	Spectre option emirtimewindows: Time check windows of emir. Array should have an even number of values [b_begin1 b_end1 b_begin2 b_end2 ...], the priority is higher than 'emirstart' and 'emirstop'.
saSpectreTRANOptionemirtimewindowsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionfastbreakUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionfastcrossUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionflushofftimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionflushperiod	string	custom		Spectre option flushperiod.
saSpectreTRANOptionflushperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionflushpointsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreTRANOptionflushTimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionlocalizeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptioninfoTimesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionirefmax	string	custom		Spectre option irefmax: Upper limit of the current reference for relative error calculation.
saSpectreTRANOptionirefmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionistep	string	custom	0.001*(stop-start)	Spectre option istep: When step size is greater than istep, the local truncation error checking is enabled for algebraic nodes.
saSpectreTRANOptionistepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionlinearic	string	custom	no	Spectre option linearic: Enable linear IC method to calculate initial conditions automatically from a type of stability analysis in the range [0.5*oscfreq, 1.5*oscfreq]. Overrides user-defined initial conditions if instability is detected. Valid values: no and yes.
saSpectreTRANOptionlinearicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionliteminstep	string	custom	0.0	Spectre option liteminstep: Local truncation error is ignored if the step size is less than liteminstep.
saSpectreTRANOptionliteminstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionliterationUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreTRANOptionltethstep	string	custom	1e-12	Spectre option ltethstep: LTE tolerance can be relaxed for signal with discontinuity when step size is less than ltethstep.
saSpectreTRANOptionltethstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionmaxitersUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionmaxstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionmcautonoiseeed	string	custom	no	Spectre option mc_auto_noiseeed: Regenerate the seed at every Monte Carlo iteration using same mechanism. Valid values: yes, no.
saSpectreTRANOptionmcautonoiseeedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionmethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionminstep	string	custom		Spectre option minstep: Minimum time step. If specified, the error tolerance requirements may be ignored when step size is less than minstep.
saSpectreTRANOptionminstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionmod	string	custom		Spectre option mod: Name of the device model parameter specified in param=name.
saSpectreTRANOptionmodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreTRANOptionnoiseifmax	string	custom	0	Spectre option noiseifmax: The bandwidth of pseudorandom noise sources. A valid (nonzero) noiseifmax turns on the noise sources during transient analysis. The maximum time step of the transient analysis is limited to 0.5/noiseifmax.
saSpectreTRANOptionnoiseifmaxUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionnoiseifmin	string	custom	1	Spectre option noiseifmin: If specified, the power spectral density of the noise sources depends on the frequency in the interval from noiseifmin to noiseifmax. Below noiseifmin, the noise power density is constant. If noiseifmin=noiseifmax, then only white noise would be included, and noise sources are evaluated only at noiseifmax for all models. 1/noiseifmin should be smaller than the requested time duration of transient analysis.
saSpectreTRANOptionnoiseifminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionnoiseoff	string	custom	[...]	Spectre option noiseoff: The list of instances to be considered as not noisy during transient noise analysis.
saSpectreTRANOptionnoiseon	string	custom	[...]	Spectre option noiseon: The list of instances to be considered as noisy during transient noise analysis.
saSpectreTRANOptionnoisescale	string	custom	1	Spectre option noisescale: Noise scale factor applied to all generated noise. Can be used to artificially inflate the small noise to make it visible above transient analysis numerical noise floor, but it should be small enough to maintain the nonlinear operation of the circuit.
saSpectreTRANOptionnoisescaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionnoiseseed	string	custom		Spectre option noiseseed: Seed for the random number generator. Should be positive integer. Specifying the same seed allows you to reproduce a previous experiment.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreTRANOptionnoiseseedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionoscfreq	string	custom	0.0	Spectre option oscfreq: Estimation of the oscillation frequency when linear IC method is enabled.
saSpectreTRANOptionoscfreqUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionoutputstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionparam	string	custom		Spectre option param: Name of the parameter to be updated to a different value with time during tran.
saSpectreTRANOptionparamfile	string	custom		Spectre option param_file: The file that contains the time_value points to param=name.
saSpectreTRANOptionparamset	string	custom		Spectre option paramset: Name of the dynamic parameter set.
saSpectreTRANOptionparamsetUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionparamstep	string	custom		Spectre option param_step: Defines the frequency of updating the dynamic parameter values. If param_step=0, it updates the parameter value at a given time point.
saSpectreTRANOptionparamstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionparamvec	string	custom	[...]	Spectre option param_vec: The time_value points to param=name.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreTRANOptionprogressp	string	custom		Spectre option progress_p: Print out the annotate message every progress_p percent of transient time. Note that this degrades performance.
saSpectreTRANOptionprogresspUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionprogresst	string	custom		Spectre option progress_t: Print out the annotate message every interval specified by progress_t in terms of minutes. Note that this degrades performance.
saSpectreTRANOptionprogresstUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionpstep	string	custom		Spectre option pstep: print step.
saSpectreTRANOptionpstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionreadhnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionrecover	string	custom		Spectre option recover: Specify the file to be restored.
saSpectreTRANOptionrecoverUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionrelref	string	custom		Spectre option relref: Reference used for the relative convergence criteria. The default is derived from `errpreset'. Valid values: pointlocal, alllocal, sigglobal, and allglobal.
saSpectreTRANOptionrelrefUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreTRANOptionssaveclock	string	custom		Spectre option saveclock: Save the tran analysis periodically on the wall clock time. The default is 1800s for Spectre. This parameter is disabled in the APS mode by default.
saSpectreTRANOptionssaveclockUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionssavefile	string	custom		Spectre option savefile: Save the analysis states into the specified file.
saSpectreTRANOptionssavefileUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionssaveperiod	string	custom		Spectre option saveperiod: Save the tran analysis periodically on the simulation time.
saSpectreTRANOptionssaveperiodhistory	string	custom	no	Spectre option saveperiodhistory: Maintains the history of saved files. If yes, maintains all the saved files. Valid values: no and yes.
saSpectreTRANOptionssaveperiodhistoryUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionssaveperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionssavetime	string	custom	[...]	Spectre option savetime: Save the analysis states into files on the specified time points.
saSpectreTRANOptionssavetimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionssaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionsskipcountUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionsskipdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saSpectreTRANOptionskipstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionskipstopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionstart	string	custom	0	Spectre option start: Start time value.
saSpectreTRANOptionstartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionstep	string	custom		Spectre option step: Minimum time step used by the simulator solely to maintain the aesthetics of the computed waveforms.
saSpectreTRANOptionstepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionstrobedelayUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionstrobefreq	string	custom		Spectre option strobefreq: The reciprocal of strobeperiod (strobeperiod).
saSpectreTRANOptionstrobefreqUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionstrobeoutput	string	custom	strobeonly	Spectre option strobeoutput: Specifies which time points to output during strobe. Valid values: strobeonly, all, none, and faulttimes.
saSpectreTRANOptionstrobeoutputUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionstrobeperiodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionstrobestart	string	custom	0	Spectre option strobestart: Equivalent to skipstart.
saSpectreTRANOptionstrobestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreTRANOptionstrobestep	string	custom	0	Spectre option strobestep: Equivalent to strobeperiod.
saSpectreTRANOptionstrobestepUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionstrobestop	string	custom	stop	Spectre option strobestop: Equivalent to skipstop.
saSpectreTRANOptionstrobestopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionstrobetimes	string	custom	[...]	Spectre option strobetimes: Times in ascending order when strobe output performed.
saSpectreTRANOptionstrobetimesUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionsub	string	custom		Spectre option sub: Name of the subcircuit instance parameter specified in param=name.
saSpectreTRANOptionsubUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptiontpoints	string	custom	[...]	Spectre option tpoints: Multiple of pairs<pstep, stop>.
saSpectreTRANOptiontpointsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptiontrannoisemethod	string	custom	default	Spectre option trannoisemethod: use this option to enable the adaptive noise step control. Valid values: default and adaptive.
saSpectreTRANOptiontrannoisemethodUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreTRANOptiontransres	string	custom	1e-9*stop	Spectre option transres: Transition resolution. The transient analysis attempts to stop at corners of input waveforms (for example, corners of rising/falling edge of a pulse). If such events occur within a time less than transres, the analysis combines the events into one and forces only one time point. The rest of the steps are determined by error control. This may lead to loss of detail.
saSpectreTRANOptiontransresUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionuseprevic	string	custom	no	Spectre option useprevic: If set to yes or ns, use the converged initial condition from previous analysis as ic or ns. Valid values: no, yes, and ns.
saSpectreTRANOptionuseprevicU ncheckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionvrefmax	string	custom		Spectre option vrefmax: Upper limit of the voltage reference for relative error calculation.
saSpectreTRANOptionvrefmaxUnc heckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionwritefinalUn checkLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANOptionwriteUnche ckLocalized	bool	saTestbe nch	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreTRANParam	string	saTestbe nch		Spectre tran parameter
saSpectreTRANParamfile	string	saTestbe nch		Spectre tran parameter file
saSpectreTRANParamvec	string	saTestbe nch		Spectre tran parameter vector
saSpectreTRANPsd	string	saTestbe nch	0	Spectre TRAN: Enable/Disable PSD

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreTRANPsdMaxFreq	string	saTestbench		Spectre TRAN: PSD Max Frequency
saSpectreTRANPsdStart	string	saTestbench	0	Spectre TRAN: Enable/Disable PSD Start Time
saSpectreTRANPsdStartTime	string	saTestbench		Spectre TRAN: PSD Start Time
saSpectreTRANPsdSummary	string	saTestbench	0	
saSpectreTRANPsdWindows	string	saTestbench		Spectre TRAN: Number of PSD Windows
saSpectreTRANStart	string	saTestbench	0	Spectre Transient start time.
saSpectreTRANStep	string	saTestbench		Spectre Transient min time step.
saSpectreTRANStop	string	saTestbench		Spectre Transient stop time.
saSpectreTRANStrobe	string	saTestbench	0	Spectre TRAN: Enable/Disable Strobe
saSpectreTRANTranNoise	string	saTestbench	false	Spectre TRAN: Enable/disable trannoise widgets
saSpectreVariationImport	string	saTestbench	Include	Spectre variation Import Setting.
saSpectreVectorImport	string	saTestbench	Include	Spectre vector Import Setting.
saSpectreXFCenter	string	saTestbench		Spectre XF: Center point of sweep limits.
saSpectreXFDec	string	saTestbench		Spectre XF: Number of logarithmic steps per decade.
saSpectreXFDesignVar	string	saTestbench		Spectre XF: Design variable being swept.
saSpectreXFDev	string	saTestbench		Spectre XF: Instance with parameter being swept.
saSpectreXFDoSweep	string	saTestbench	1	Spectre XF: Flag indicating a sweep is to be performed.
saSpectreXFFreq	string	saTestbench		Spectre XF: Single value to hold frequency while other aspect is being swept.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreXFLin	string	saTestbench		Spectre XF: Number of linear steps.
saSpectreXFLog	string	saTestbench		Spectre XF: Total number of logarithmic steps.
saSpectreXFMod	string	saTestbench		Spectre XF: Model with parameter being swept.
saSpectreXFNegNode	string	saTestbench		Spectre XF: Negative output node.
saSpectreXFNode	string	saTestbench		Spectre XF: Positive output node.
saSpectreXFProbe	string	saTestbench		Spectre XF: Compute mismatch at the output defined by this component.
saSpectreXFOptionannotate	string	custom	sweep	Spectre option annotate: Degree of annotation. Possible values are no, title, sweep, status, and steps.
saSpectreXFOptionannotateUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptionforce	string	custom	none	Spectre option force: The set of initial conditions to use. Possible values are none, node, dev, and all.
saSpectreXFOptionforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptionnestlvl	string	custom		Spectre option nestlvl: Levels of subcircuits to output.
saSpectreXFOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptionoppoint	string	custom	no	Spectre option oppoint: Determines whether operating point information should be computed:if yes, where should it be printed (screen or file). Operating point information is not printed if the operating point computed in the previous analysis remains unchanged. Possible values are no, screen, logfile, and rawfile.
saSpectreXFOptionoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreXFOptionotherOptions	string	custom		Spectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saSpectreXFOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptionprevoppoint	string	custom	no	Spectre option prevoppoint: Use the operating point computed in the previous analysis. Possible values are no and yes.
saSpectreXFOptionprevoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptionprobe	string	custom		Spectre option probe: Compute every transfer function to this probe component.
saSpectreXFOptionprobeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptionreadforce	string	custom		Spectre option readforce: File that contains initial conditions.
saSpectreXFOptionreadforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptionreadns	string	custom		Spectre option readns: File that contains an estimate of the DC solution (nodeset).
saSpectreXFOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptionrestart	string	custom	yes	Spectre option restart: Restart the DC solution from scratch if any condition has changed. If not, use the previous solution as an initial guess. Possible values are no and yes.
saSpectreXFOptionrestartUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptionsave	string	custom		Spectre option save: Signals to output. Possible values are all, lvl, allpub, lvlpub, selected, none, and nooutput.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreXFOptionsaveUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptionskipdc	string	custom	no	Spectre option skipdc: Skip DC analysis. Possible values are no and yes.
saSpectreXFOptionskipdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptionstimuli	string	custom	sources	Spectre option stimuli: Stimuli used for xf analysis. Possible values are sources and nodes_and_terminals.
saSpectreXFOptionstimuliUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptiontitle	string	custom		Spectre option title: Analysis title.
saSpectreXFOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptionuseprevic	string	custom	no	Spectre option useprevic: If set to yes or ns, use the converged initial condition from previous analysis as ic or ns. Possible values are no, yes, and ns.
saSpectreXFOptionuseprevicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOptionvaluesfile	string	custom		Spectre option valuesfile: Name of the file containing the sweep values.
saSpectreXFOptionwrite	string	custom		Spectre option write: DC operating point output file at the first step of the sweep.
saSpectreXFOptionwritefinal	string	custom		Spectre option writefinal: DC operating point output file at the last step of the sweep.
saSpectreXFOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine the localized is set back to unchecked or not when the preference value of the option is saved/loaded
saSpectreXFOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saSpectreXFOutputType	string	saTestbench	Voltage	Spectre XF: Output Type.

Table 33 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saSpectreXFParam	string	saTestbench		Spectre XF: Parameter being swept.
saSpectreXFSpan	string	saTestbench		Spectre XF: Span between sweep limits.
saSpectreXFStart	string	saTestbench		Spectre XF: Starting point of sweep limits.
saSpectreXFStep	string	saTestbench		Spectre XF: Linear step size.
saSpectreXFStepSpecLin	string	saTestbench	Number of Steps	Spectre XF: Method of specifying linear stepping ("Step Size" "Number of Steps").
saSpectreXFStepSpecLog	string	saTestbench	Points per Decade	Spectre XF: Method of specifying logarithmic stepping ("Points per Decade" "Number of Steps").
saSpectreXFStop	string	saTestbench		Spectre XF: Stopping point of sweep limits.
saSpectreXFSub	string	saTestbench		Spectre XF: Subcircuit with parameter being swept.
saSpectreXFSweep	string	saTestbench	Logarithmic	Spectre XF: Method of sweeping values ("Linear" "Logarithmic" "Points of Interest").
saSpectreXFSweepSpec	string	saTestbench	<file path>	Spectre XF: Method of specifying sweep limits ("Start/Stop" "Center/Span").
saSpectreXFSweepVar	string	saTestbench	Frequency (Hz)	Spectre XF: Specifies what will be swept ("Frequency (Hz)" "Design Variable" "Temperature" "Instance Parameter" "Model Parameter" "Subcircuit Parameter").
saSpectreXFValues	string	saTestbench		Spectre XF: Individual values, also known as points of interest.
saSpectreXFValuesfile	string	saTestbench		Spectre XF: File for individual values
saUseValidLocalIncludeFileSettingInCorner	bool	user	false	Use valid local include files in corner run.

See Also

- [Simulation and Analysis Environment Preferences \(saA2D* through saFineSimPro*\)](#)
- [Simulation and Analysis Environment Preferences \(saGen* through saOutput*\)](#)

- [Simulation and Analysis Environment Preferences \(saParam* through saPrimeSimVCS*\)](#)
- [Simulation and Analysis Environment Preferences \(saSt* through saXA*\)](#)

Simulation and Analysis Environment Preferences (saSt* through saXA*)

Table 34 lists continuation of PrimeWave Design Environment sa general preferences (saSt* through saXA*).

Table 34 Simulation and Analysis Environment Preferences

Name	Type	Scope	Default	Description
saStatesDir	string	saSession	~/synopsys_custom/sae_states	Defines the root directory that is used to save/load states. The following is the pattern of directory structure in which the states are saved: <libName>/<cellName>/<simulatorName>/<stateName>
saSTBDirPattern	string	user	%l%d%c %d%v	Default pattern for the STB subdirectory above the history directory.
saStimulusGeneratorInstMaster	lcv	user	//	Default LCV for instance creation in the Stimulus Generator.
saSweepCellViewTypes	string	user	schematic maskLayout SPICEText externalNetlist verilogAText verilogText VHDLText config.xml	Supported view types in sweep cell views.
saSyncCornerParamDialogs	bool	user	false	Whether to sync Design Variables/Model Files/Include Files/Stimulus dialog box to Corner setup dialog box and Manage Corner Parameters dialog box.
saTableAutopageCount	int	user	10	Number of rows a Static Web Report table page with pagination enabled will have.
saTableExternalEditionSeparator	string	user	","	Table cell separator character when using external editor.
saTandemGroups	string	user	groupA	The prefix for newly added tandem groups

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saTemperature	string	saTestbench	25	Simulation Temperature.
saTemperatureDisplay	bool	saTestbench	true	Temperature Display Setting
saTemperatureUnit	string	saTestbench	Celsius	Temperature Unit. Valid values: Celsius, Fahrenheit, Kelvin
saTestSuiteCellName	string	saSession		The test suite openAccess cell name.
saTestSuiteFilterMissingTestbenches	bool	saSession	false	Filter multiple loaded states to only those not in session. Valid values: true, false
saTestSuiteLoadMultipleStates	bool	saSession	false	Provide ability on testbench import to load multiple states into test suite session. Valid values: true, false
saTestSuiteStoreAtViewLevel	bool	saSession	true	Indicates test suite is to be stored at the view level. Valid values: true, false
saTestSuiteStoreImportStates	bool	saSession	false	Provide ability on opening/creating test suite to import multiple states. Valid values: true, false
saTestSuiteStoreStateFilter	bool	saSession	true	Filter multiple loaded states only to those not referenced by other test suites. Valid values: true, false
saTestSuiteUseGlobal	bool	saSession	true	Invokes global scope support when creating a test suite. Valid values: true, false
saThumbnailImageCommand	string	user	convert %i -blur 5x2 -sharpen 3x3 -normalize +contrast -quality 100 -crop +96+10 -resize 200x200 %o	Shell command to generate thumbnail images.
saTimestampDashboardFilterList	string	user		Libraries to be filtered out in the Timestamp Dashboard.
saTimestampDashboardShowOutdatedOnly	bool	user	false	Show only rows having outdated items. Valid values: true, false

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saTextImportIncludeFilesException sDefaultRows	string	saTestbench	{ Include Wildcard "*.lib *.dspf *.spf *.gz *.gzip *.enc *.ic* *.data" }	Default behaviour on handling files to include/parse/ignore according to their extensions
saUnconditionallySavedCategories	string	user		List of category names for which their related preferences will always be saved when a state is saved.
saUpdateTypeForReevaluation	string	user	completed AndRunningJobs	Update type for reevaluating the expressions. Valid values: completedTestbench, completedJobs, completedAndRunningJobs
saUseAbsolutePathForStimulus	bool	user	false	Use Absolute Include File Path for Stimulus
saUseInternalExternalSpec	bool	user	false	Use Internal/External Specification types for PrimeWave Design Environment Preference Examples measurements. For further details, see saUseInternalExternalSpec . Valid values: true, false
saUseSameUnitForAllHistoryPoint Sizes	bool	user	false	Show History Point in same unit. Valid values: true, false
saUseScratchNetworkDir	bool	user	false	Use scratch network directory to link to simulation outputs on local host so that not copy them back to simulation dir
saUseValidLocalSettingInCorner	bool	user	false	Use valid local model/include file/stimulus in corner run
saVCSMXElementEncoding	string	user	legacy	Encoding/decoding method for A2D/D2A Element field.
saVCSMXRequireDefaultIEs	bool	user	false	Require all A2D and D2A's have a default setting (Element=*). Valid values: true, false
saVCSMXWarnOnVddConflict	bool	user	false	Print a warning/report when a given IE has multiple digital drivers. Valid values: true, false
saVerilogParserOptions	string	user		Parser Options to send to the CC import netlist file interface
saVerilogPrintTimeScale	bool	user	false	If true, the time scale data (time units, scale precision) is printed in Verilog netlisting

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saVerilogTimeScalePrecision	string	user	1ps	Verilog simulator intertime step precision
saVerilogTimeScaleTimeUnits	string	user	1ns	Verilog simulator base time step granularity
saWebReportContentsSelectionTable	string	user		The representation of the table used to select what contents are included in a Web Report.
saWebReportType	string	user	Multi-File	ResultsView Web Report generation type. Valid values: Multi-File, Single-File.
saWorstCaseCornersAutoExtractAndRun	bool	user	false	Controls auto worst case corners extraction and running the simulation. Valid values: true, false
saWorstCaseShowMeasures	bool	user	true	In the Corners Setup dialog, shows the measures responsible for each corner existence. Valid values: true, false
saXAEIldoBlockOptionsCategories	string	saTestbench	All	XAHSPICE analyses Import Setting.
saXAEIldoBlockOptionsSummary	string	saTestbench		Custom commands contents holder
saXAEIldoDefaultCornersSetup	string	saTestbench		XAEIldo default corners setup
saXAEIldoDefaultModelFiles	string	saTestbench		XAEIldo default model files to be loaded
saXAEIldoEnvOptsCommandLineOptions	string	saTestbench		XAHSPICE convergenceAids Import Setting.
saXAEIldoEnvOptsIncludePath	string	saTestbench		Enables the XAHSPICE to write the resulting XML file.
saXAEIldoEnvOptsNetlistLanguage	string	user	Eldo	Simulator case setting.
saXAEIldoEnvOptsOutputDataFormat	string	saTestbench	wdf	Additional command line options for the XAHSPICE.
saXAEIldoEnvOptsStopViewList	string	saTestbench	eldoD	Search path for XAHSPICE include files.
saXAEIldoEnvOptsSwitchViewList	string	saTestbench	eldoD schematic veriloga	Netlist language for the XAHSPICE.
saXAEIldoEnvOptsUse64Bit	string	saTestbench	1	Output data format.

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAEldoEnvOptsUseSsl2	bool	saTestbench	true	Use v2 of accuracy/performance tradeoff parameters set Valid values: true, false
saXAEldoModelGroups	string	saTestbench		Model groups for XAEldo
saXAEldoModelGroupsCheckBox	bool	saTestbench	false	Visibility of Model Groups table for XAEldo Valid values: true, false
saXAEldoModelsFiles	string	saTestbench		Stop View List for netlister.
saXAEldoModelsIncludePath	string	saTestbench		Switch View List for netlister.
saXAEldoOPTimes	string	saTestbench	0	XAEldo Operating point save time.
saXAEldoOptionAUTOSTOP	string	custom	0	XAEldo option AUTOSTOP: Stops a transient analysis
saXAEldoOptionAUTOSTOPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAEldoOptionCSHUNT	string	custom	1e-20	XAEldo option CSHUNT: Add capacitance from each node to ground.
saXAEldoOptionCSHUNTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAEldoOptionDCAP	string	custom	2	XAEldo option DCAP: Specifies equations used to calculate depletion capacitance for Level 1 and 3 diodes and BJTs.
saXAEldoOptionDCAPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAEldoOptionGMIN	string	custom	1e-12	XAEldo option GMIN: Minimum conductance added to all PN junctions for a time sweep in transient analysis.
saXAEldoOptionGMINUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAEldoOptionMACMOD	string	custom	0	XAEldo option MACMOD: To access the subcircuit definition when there is no matching model reference

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAEldoOptionMACMODUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAEldoOptionotherOptions	string	custom		XAEldo option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)]
saXAEldoOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAEldoOptionSCALE	string	custom	1.00	XAEldo option SCALE: Sets the element scaling factor.
saXAEldoOptionSCALEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAEldoOptionSCALM	string	custom	1	XAEldo option SCALM: Sets the model scaling factor.
saXAEldoOptionSCALMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAEldoOptionTNOM	string	custom	25	XAEldo option TNOM: Sets the reference temperature for the simulation.
saXAEldoOptionTNOMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAEldoOptionWL	string	custom	0	XAEldo option WL: Reverses the order of the VSIZE MOS element.
saXAEldoOptionWLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAEldoSaveOptionsEmTStart	string	saTestbench		Start time for electromigration current analysis
saXAEldoSaveOptionsEmTStop	string	saTestbench		Stop time for electromigration current analysis
saXAEldoSaveOptionsEnableEM	string	saTestbench	false	Save currents for in-design layout automation
saXAEldoSaveOptionsEnableVDRC	string	saTestbench	false	Save voltage extremes to enable V-DRC flow

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAEIdoSaveOptionsSave	string	saTestbench	level	XAEIdo Save Options save net voltages
saXAEIdoSaveOptionsSaveLevel	string	saTestbench	1	XAHSPICE Save Options save net voltages.
saXAEIdoSaveOptionsSubcktCurrents	string	saTestbench	selected	Save Options save net voltages level.
saXAEIdoSaveOptionsSubcktCurrentsLevel	string	saTestbench	1	XAHSPICE Save Options save subckt currents.
saXAEIdoSaveOptionsTerminalCurrents	string	saTestbench	selected	Save Options save subckt currents level.
saXAEIdoSaveOptionsTerminalCurrentsLevel	string	saTestbench	1	An environment initialization command to be added to simulation commands.
saXAEIdoSaveOptionsTerminalVoltage	string	saTestbench	selected	XAHSPICE simulatorOptions Import Setting.
saXAEIdoSaveOptionsTerminalVoltageLevel	string	saTestbench	1	XAHSPICE temperature Import Setting.
saXAEIdoSaveOptionsVdrcTStart	string	saTestbench		Start time for VDRC voltage analysis
saXAEIdoSaveOptionsVdrcTStop	string	saTestbench		Stop time for VDRC voltage analysis
saXAEIdoShowModelGroups	bool	saTestbench	false	Displays the Model Groups table for XAEIdo Valid values: true, false
saXAEIdoSimulationCommandPrefix	string	xtJobClass		XAHSPICE Transient time step.
saXAEIdoTRANStep	string	saTestbench		XAHSPICE Transient stop time.
saXAEIdoTRANStop	string	saTestbench		XAHSPICE Transient setting for Use Initial Conditions.
saXAHSPICEAnalysesImport	string	saTestbench	Import	XAHSPICE analyses Import Setting.
saXAHSPICEBlockOptionsSummary	string	saTestbench		Custom commands contents holder
saXAHSPICECommands	string	user	commands	XAHSPICE commands selection.
saXAHSPICEConvergenceAidsImport	string	saTestbench	Import	XAHSPICE convergenceAids Import Setting.

Table 34 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saXAHSPICEDefaultCornersSetup	string	saTestbench		XAHSPICE default corners setup.
saXAHSPICEDefaultIncludeFiles	string	saTestbench		XAHSPICE default include files.
saXAHSPICEDefaultModelFiles	string	saTestbench		XAHSPICE default model files to be loaded.
saXAHSPICEEnableSimulatorResultsXML	bool	user	false	Enables the XAHSPICE to write the resulting XML file.
saXAHSPICEEnvOptsCaseSensitive	bool	saTestbench	false	Simulator case setting.
saXAHSPICEEnvOptsCommandLineOptions	string	saTestbench		Additional command line options for the XAHSPICE.
saXAHSPICEEnvOptsIncludePath	string	saTestbench		Search path for XAHSPICE include files.
saXAHSPICEEnvOptsNetlistLanguage	string	user	HSPICE	Netlist language for the XAHSPICE.
saXAHSPICEEnvOptsOutputDataFormat	string	saTestbench	wdf	Output data format.
saXAHSPICEEnvOptsStopViewList	string	saTestbench	hspice hspiceD functional behavioral symbol	Stop View List for netlister.
saXAHSPICEEnvOptsSwitchViewList	string	saTestbench	hspice hspiceD schematic verilog functional behavioral vhdl_config vhdl_spice veriloga verilogams	Switch View List for netlister.
saXAHSPICEEnvOptsUse64Bit	bool	saTestbench	true	64-bit simulation.
saXAHSPICEEnvOptsUseSsl2	bool	saTestbench	true	Use v2 of accuracy/performance tradeoff parameters set. Valid values: true, false

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAHSPICEIncludeSchematicNetlist	bool	user	true	Copy (true) or .include (false) the structural netlist in the final netlist. Valid values: true, false
saXAHSPICELibrariesImport	string	saTestbench	Import	XAHSPICE libraries Import Setting.
saXAHSPICEMeasuresImport	string	saTestbench	Import	XAHSPICE measures Import Setting.
saXAHSPICEModelGroups	string	saTestbench		Model groups for XAHSPICE
saXAHSPICEModelGroupsCheckBox	bool	saTestbench	false	Visibility of Model Groups table for XAHSPICE. Valid values: true, false
saXAHSPICEModelsImport	string	saTestbench	Import	XAHSPICE models Import Setting.
saXAHSPICEModelsIncludePath	string	saTestbench		Search path for XAHSPICE model files.
saXAHSPICEMonteCarloEnableSeed	bool	saTestbench	0	Determines whether an explicit starting seed is to be specified in Monte Carlo analysis. Valid values: true, false
saXAHSPICEMonteCarloLHSReplicates	string	saTestbench	1	Runs replicates of Latin Hypercube samples.
saXAHSPICEMonteCarloLHSSampleSize	string	saTestbench		LHS sampling method sample size.
saXAHSPICEMonteCarloSamplingMethod	string	saTestbench	SRS	Enables advanced sampling methods.
saXAHSPICEMonteCarloSeed	string	saTestbench	1	Starting seed for the random-number generator in Monte Carlo analysis.
saXAHSPICEMonteCarloSigmaScale	string	saTestbench	2.0	Sigma Amplification Factor for High Sigma Applications.
saXAHSPICEMonteCarloUseRandomSeed	string	saTestbench	true	Use random seed for random-number generator in Monte Carlo analysis.
saXAHSPICEMonteCarloUseSigmaScaling	string	saTestbench	0	Uses Sigma Scaling for High Sigma Applications.
saXAHSPICEMonteCarloVariationIncludeOrExclude	string	saTestbench	Include	Whether statistical variation is to be applied or not applied to the specified instances/cells.

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAHSPICEMonteCarloVariationInstanceOrCellList	string	saTestbench		List of instances or cells for which statistical variation is to be applied/not applied.
saXAHSPICEMonteCarloVariationObjectType	string	saTestbench	Instances	Object type (instances or cells) for which statistical variation is to be applied/not applied.
saXAHSPICEOPTimes	string	saTestbench		XAHSPICE Operating point save time.
saXAHSPICEOptionAUTOSTOP	string	custom	0	XAHSPICE option AUTOSTOP: Stops a transient analysis
saXAHSPICEOptionAUTOSTOPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOptionCSHUNT	string	custom	1e-20	XAHSPICE option CSHUNT: Add capacitance from each node to ground.
saXAHSPICEOptionCSHUNTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOptionDCAP	string	custom	2	XAHSPICE option DCAP: Specifies equations used to calculate depletion capacitance for Level 1 and 3 diodes and BJTs.
saXAHSPICEOptionDCAPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOptionGMIN	string	custom	1e-12	XAHSPICE option GMIN: Minimum conductance added to all PN junctions for a time sweep in transient analysis.
saXAHSPICEOptionGMINUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOptionMACMOD	string	custom	0	XAHSPICE option MACMOD: To access the subcircuit definition when there is no matching model reference
saXAHSPICEOptionMACMODUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOptionMAXWARNINGS	string	custom	5	XAHSPICE option MAXWARNINGS: Specifies maximum number of safe operating area (SOA) warning messages.

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAHSPICEOptionMAXWARNS UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOptionMODMONTE	bool	saTestbench	0	Controls whether all instances of a device get the same or unique model parameters. Valid values: true, false
saXAHSPICEOptionMODMONTE UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOptionMONTECON	bool	saTestbench	1	Continues a Monte Carlo analysis by retrieving the next random value, even if non-convergence occurs. Valid values: true, false
saXAHSPICEOptionMONTECON UncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOptionotherOptions	string	custom		XAHSPICE option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saXAHSPICEOptionotherOptionsU ncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOptionSCALE	string	custom	1.00	XAHSPICE option SCALE: Sets the element scaling factor.
saXAHSPICEOptionSCALEUnche ckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOptionSCALM	string	custom	1	XAHSPICE option SCALM: Sets the model scaling factor.
saXAHSPICEOptionSCALMUnche ckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOptionTNOM	string	custom	25	XAHSPICE option TNOM: Sets the reference temperature for the simulation.
saXAHSPICEOptionTNOMUnchec kLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOptionWARN	string	custom	0	XAHSPICE option WARN: Enables or turns off SOA voltage warning message

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAHSPICEOptionWARN	string	custom	0	XAHSPICE option WARN: Enables or turns off SOA voltage warning message.
saXAHSPICEOptionWARNUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOptionWL	string	custom	0	XAHSPICE option WL: Reverses the order of the VSIZE MOS element.
saXAHSPICEOptionWLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAHSPICEOutputControlImport	string	saTestbench	Import	XAHSPICE outputControl Import Setting.
saXAHSPICEParasiticBackAnnotationTableColumnsShown	string	user	Enabled { Type } {Back Annotate} {Skip Nets} {Min R} {Other Options}	Saves columns shown in the Parasitic Back Annotation table.
saXAHSPICESaveOptionsEmTStart	string	saTestbench		Start time for electromigration current analysis.
saXAHSPICESaveOptionsEmTStop	string	saTestbench		Stop time for electromigration current analysis.
saXAHSPICESaveOptionsEnableEM	string	saTestbench	false	Save currents for in-design layout automation.
saXAHSPICESaveOptionsEnableVDRC	string	saTestbench	false	Save voltage extremes to enable VDRC flow.
saXAHSPICESaveOptionsSave	string	saTestbench	level	XAHSPICE: Save net voltages.
saXAHSPICESaveOptionsSaveLevel	string	saTestbench	1	XAHSPICE: Save net voltages level.
saXAHSPICESaveOptionsSubcktCurrents	string	saTestbench	selected	XAHSPICE: Save subckt port currents
saXAHSPICESaveOptionsSubcktCurrentsLevel	string	saTestbench	1	XAHSPICE: Save subckt port currents level.
saXAHSPICESaveOptionsTerminalCurrents	string	saTestbench	selected	XAHSPICE: Save device terminal currents.

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAHSPICESaveOptionsTerminalCurrentsLevel	string	saTestbench	1	XAHSPICE: Save device terminal currents level.
saXAHSPICESaveOptionsTerminalVoltages	string	saTestbench	selected	XAHSPICE: Save device terminal voltages
saXAHSPICESaveOptionsTerminalVoltagesLevel	string	saTestbench	1	XAHSPICE: Save device terminal voltages level
saXAHSPICESaveOptionsVdrcStart	string	saTestbench		Start time for VDRC voltage analysis.
saXAHSPICESaveOptionsVdrcStop	string	saTestbench		Stop time for VDRC voltage analysis.
saXAHSPICEShowModelGroups	bool	saTestbench	false	Displays the Model Groups table for XAHSPICE Valid values: true, false
saXAHSPICESimulationCommandPrefix	string	user		An environment initialization command to be added to simulation commands.
saXAHSPICESimulatorOptionsImport	string	saTestbench	Import	XAHSPICE simulatorOptions Import Setting.
saXAHSPICETemperatureImport	string	saTestbench	Import	XAHSPICE temperature Import Setting.
saXAHSPICETRANStart	string	saTestbench	0	XAHSPICE Transient start time.
saXAHSPICETRANStep	string	saTestbench		XAHSPICE Transient time step.
saXAHSPICETRANStop	string	saTestbench		XAHSPICE Transient stop time.
saXAHSPICETRANUIC	string	saTestbench	0	PrimeSim XA Transient setting for Use Initial Conditions.
saXASpectreAnalysesImport	string	saTestbench	Import	XASpectre analyses Import Setting.
saXASpectreBlockOptionsSummary	string	saTestbench		Custom commands contents holder.
saXASpectreCommands	string	user	commands	XASpectre commands selection.
saXASpectreConvergenceAidsImport	string	saTestbench	Import	XASpectre convergenceAids Import Setting.
saXASpectreDefaultCornersSetup	string	saTestbench		XASpectre default corners setup.

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXASpectreDefaultModelFiles	string	saTestbench		XASpectre default model files to be loaded.
saXASpectreEnableSimulatorResultsXML	bool	user	false	Enables the XASpectre to write the resulting XML file. Valid values: true, false
saXASpectreEnvOptsCommandLineOptions	string	saTestbench		Additional command line options for the XASpectre.
saXASpectreEnvOptsIncludePath	string	saTestbench		Search path for XASpectre include files.
saXASpectreEnvOptsNetlistLanguage	string	user	Spectre	Netlist language for the XASpectre.
saXASpectreEnvOptsOutputDataFormat	string	saTestbench	wdf	Output data format.
saXASpectreEnvOptsStopViewList	string	saTestbench	spectre veriloga	Stop View List for netlister.
saXASpectreEnvOptsSwitchViewList	string	saTestbench	spectre cmos.sch cmos_sch schematic veriloga	Switch View List for netlister.
saXASpectreEnvOptsUse64Bit	string	saTestbench	0	64-bit simulation.
saXASpectreEnvOptsUseSsl2	bool	saTestbench	true	Use v2 of accuracy/performance tradeoff parameters set. Valid values: true, false
saXASpectreLibrariesImport	string	saTestbench	Import	XASpectre libraries Import Setting.
saXASpectreMeasuresImport	string	saTestbench	Import	XASpectre measures Import Setting.
saXASpectreModelGroups	string	saTestbench		Model groups for XASpectre
saXASpectreModelGroupsCheckBox	bool	saTestbench	false	Visibility of Model Groups table for XASpectre. Valid values: true, false
saXASpectreModelsImport	string	saTestbench	Import	XASpectre models Import Setting.
saXASpectreModelsIncludePath	string	saTestbench		Search path for XASpectre model files.

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXASpectreOptiongmin	string	custom	1e-12	XASpectre option gmin: Minimum conductance across each nonlinear device.
saXASpectreOptiongminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreOptionotherOptions	string	custom		XASpectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saXASpectreOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreOptionredundantcurrents	string	custom	no	XASpectre option redundant_currents: If yes, save both currents through two terminal devices.
saXASpectreOptionredundantcurrentsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreOptionrforce	string	custom	1	XASpectre option rforce: Resistance used when forcing nodesets and node-based initial conditions.
saXASpectreOptionrforceUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreOptionscale	string	custom	1	XASpectre option scale: Device instance scaling factor.
saXASpectreOptionscalem	string	custom	1	XASpectre option scalem: Model scaling factor.
saXASpectreOptionscalemUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreOptionscaleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreOptionsubcktprobelvl	string	custom	0	XASpectre option subcktprobelvl: Level up to which subcircuit terminal current probes are to be set up.
saXASpectreOptionsubcktprobelvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXASpectreOptiontitle	string	custom		XASpectre option title: Circuit title.
saXASpectreOptiontitleUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreOptiontnom	string	custom	27	XASpectre option tn timer: Default component parameter measurement temperature.
saXASpectreOptiontnomUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreOptionuseterms	string	custom	index	XASpectre option useterms: Output terminal currents by specified option.
saXASpectreOptionusetermsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreOutputControlImport	string	saTestbench	Import	XASpectre outputControl Import Setting.
saXASpectreSaveOptionsCurrents	string	saTestbench	selected	XASpectre Save Options save currents.
saXASpectreSaveOptionsSave	string	saTestbench	all	XASpectre Save Options save net voltages.
saXASpectreSaveOptionsSaveLevel	string	saTestbench	1	Save Options save net voltage level.
saXASpectreShowModelGroups	bool	saTestbench	false	Displays the Model Groups table for XASpectre. Valid values: true, false
saXASpectreSimulationCommandPrefix	string	user		An environment initialization command to be added to simulation commands.
saXASpectreSimulatorOptionsImport	string	saTestbench	Import	XASpectre simulatorOptions Import Setting.
saXASpectreTemperatureImport	string	saTestbench	Import	XASpectre temperature Import Setting.
saXASpectreTRANOptionautostop	string	custom	0	XASpectre option autostop: Stop sim after measurement events
saXASpectreTRANOptionautostopUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 34 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saXASpectreTRANOptioncmin	string	custom	0	XASpectre option cmin: Min. capacitance from each node to gnd
saXASpectreTRANOptioncminUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreTRANOptionic	string	custom	all	XASpectre option ic: Method used to set initial conditions
saXASpectreTRANOptionicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreTRANOptionnestlvl	string	custom		XASpectre option nestlvl: Subcircuit depth to output
saXASpectreTRANOptionnestlvlUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreTRANOptionoppoint	string	custom	no	XASpectre option oppoint: Where to send operating point information
saXASpectreTRANOptionoppointUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreTRANOptionotherOptions	string	custom		XASpectre option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)
saXASpectreTRANOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreTRANOptionreadic	string	custom		XASpectre option readic: Input file for initial conditions
saXASpectreTRANOptionreadicUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreTRANOptionreadns	string	custom		XASpectre option readns: Estimate of initial transient solution
saXASpectreTRANOptionreadnsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreTRANOptionskipdc	string	custom	no	XASpectre option skipdc: Skip DC analysis

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXASpectreTRANOptionskipdcUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreTRANOptionwrite	string	custom		XASpectre option write: Write initial transient solution to
saXASpectreTRANOptionwritefinal	string	custom		XASpectre option writefinal: Write final transient solution to
saXASpectreTRANOptionwritefinalUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreTRANOptionwriteUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXASpectreTRANStep	string	saTestbench		XASpectre Transient time step.
saXASpectreTRANStop	string	saTestbench		XASpectre Transient stop time.
saXAVCSHSPICEAnalogSimulatorPath	string	user		Path to the analog simulator executable for XAVCSHSPICE
saXAVCSHSPICEAnalysesImport	string	saTestbench	Import	XAVCSHSPICE analyses Import Setting.
saXAVCSHSPICEBlockOptionsSummary	string	saTestbench		Custom commands contents holder.
saXAVCSHSPICEConvergenceAidsImport	string	saTestbench	Import	XAVCSHSPICE convergenceAids Import Setting.
saXAVCSHSPICEDefaultCornersSetup	string	saTestbench		XAVCSHSPICE default corners setup.
saXAVCSHSPICEDefaultIncludeFiles	string	saTestbench		XAVCSHSPICE default include files.
saXAVCSHSPICEDefaultModelFiles	string	saTestbench		XAVCSHSPICE default model files to be loaded.
saXAVCSHSPICEDigitalOptionbaseTime	string	custom	ns	XAVCSHSPICE option base_time: Overrides the default TIMEBASE value in the synopsys_sim.setup file
saXAVCSHSPICEDigitalOptionbaseTimeUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAVCSHSPICEDigitalOptionboundscheck	string	custom	false	XAVCSHSPICE option boundscheck: Does a bounds check on fixed size arrays and issues an error at compile-time
saXAVCSHSPICEDigitalOptionboundscheckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptiondebug	string	custom	post-process	XAVCSHSPICE option debug: Specifies the debugging level for performance/control trade-offs (in order of decreasing performance and increasing control)
saXAVCSHSPICEDigitalOptiondebugUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptiondumpvars	string	custom	false	XAVCSHSPICE option dumpvars: A substitute for entering the \$dumpvars system task, without arguments, in your Verilog code
saXAVCSHSPICEDigitalOptiondumpvarsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionelaborationverbosity	string	custom		XAVCSHSPICE option elaboration_verbosity: Specifies notice, quiet or verbose mode for elaboration output file
saXAVCSHSPICEDigitalOptionelaborationverbosityUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionerrorOPCWM	string	custom	false	XAVCSHSPICE option noerrorOPCWM: Changes the inout port connection width mismatch error condition to a warning condition
saXAVCSHSPICEDigitalOptionerrorOPCWMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionnofalseneg	string	custom	false	XAVCSHSPICE option nofalseneg: Suppress the xzcheck warning message unless the value of a conditional expression ends a simulation time step with an X or Z value
saXAVCSHSPICEDigitalOptionnofalsenegUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAVCSHSPICEDigitalOptionoverride_timescale_time_precision	string	custom		XAVCSHSPICE option <code>override_timescale_time_precision</code> : Specifies the time precision portion of the override timescale (overrides <code>`timescale`</code> compiler directives)
saXAVCSHSPICEDigitalOptionoverride_timescale_time_precision_UncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionoverride_timescale_time_unit	string	custom		XAVCSHSPICE option <code>override_timescale_time_unit</code> : Specifies the time unit portion of the override timescale (overrides <code>`timescale`</code> compiler directives)
saXAVCSHSPICEDigitalOptionoverride_timescale_time_unit_UncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionplusargs	string	custom		XAVCSHSPICE option <code>plusargs</code> : Options for specifying user defined plusargs in a file
saXAVCSHSPICEDigitalOptionplusargs_UncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionsimulation_verbosity	string	custom		XAVCSHSPICE option <code>simulation_verbosity</code> : Specifies quiet or verbose mode for simulation output file
saXAVCSHSPICEDigitalOptionsimulation_verbosity_UncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptiontime_res	string	custom		XAVCSHSPICE option <code>time_res</code> : Overrides the default <code>TIME_RESOLUTION</code> value in the <code>synopsys_sim.setup</code> file
saXAVCSHSPICEDigitalOptiontime_res_UncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptiontimescale_time_precision	string	custom		XAVCSHSPICE option <code>timescale_time_precision</code> : Specifies the time precision portion of the timescale for source files that do not contain the <code>`timescale`</code> compiler directive
saXAVCSHSPICEDigitalOptiontimescale_time_precision_UncheckedLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 34 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saXAVCSHSPICEDigitalOptiontimescaletimeunit	string	custom		XAVCSHSPICE option timescale_time_unit: Specifies the time unit portion of the timescale for source files that do not contain the `timescale` compiler directive
saXAVCSHSPICEDigitalOptiontimescaletimeunitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionunittimescaletimeprecision	string	custom		XAVCSHSPICE option unit_timescale_time_precision: Specifies the time precision portion of the default timescale (used for the compilation-unit scope)
saXAVCSHSPICEDigitalOptionunittimescaletimeprecisionUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionunittimescaletimeunit	string	custom		XAVCSHSPICE option unit_timescale_time_unit: Specifies the time unit portion of the default timescale (used for the compilation-unit scope)
saXAVCSHSPICEDigitalOptionunittimescaletimeunitUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionvcsflushall	string	custom	false	XAVCSHSPICE option vcs_flush_all: Increases the frequency of dumping all log file, vcd files and files opened by \$fopen
saXAVCSHSPICEDigitalOptionvcsflushallUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionvcsflushdump	string	custom	false	XAVCSHSPICE option vcs_flush_dump: Increases the frequency of dumping all vcd files
saXAVCSHSPICEDigitalOptionvcsflushdumpUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionvcsflushfopen	string	custom	false	XAVCSHSPICE option vcs_flush_fopen: Increases the frequency of dumping all files opened by \$fopen
saXAVCSHSPICEDigitalOptionvcsflushfopenUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAVCSHSPICEDigitalOptionvcs flushlog	string	custom	false	XAVCSHSPICE option vcs_flush_log: Increases the frequency of dumping compilation and simulation log file
saXAVCSHSPICEDigitalOptionvcs flushlogUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionvcs initreg	string	custom		XAVCSHSPICE option vcs_initreg: Initialize all state variables to random values
saXAVCSHSPICEDigitalOptionvcs initregseed	string	custom		XAVCSHSPICE option vcs_initreg_seed: Seed value for vcs_initreg
saXAVCSHSPICEDigitalOptionvcs initregseedUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionvcs initregUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionvpd nocompress	string	custom	false	XAVCSHSPICE option vpdnocompress: Do not compress data written to VPD File
saXAVCSHSPICEDigitalOptionvpd nocompressUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionvpd nostrengths	string	custom	false	XAVCSHSPICE option vpdnostrengths: Do not write signal strength data to VPD File
saXAVCSHSPICEDigitalOptionvpd nostrengthsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEDigitalOptionxzc heck	string	custom	false	XAVCSHSPICE option xzcheck: Displays a warning message every time VCS evaluates a conditional expression to have an X or Z value
saXAVCSHSPICEDigitalOptionxzc heckUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEEnableSimulator ResultsXML	bool	user	false	Enables the XAVCSHSPICE to write the resulting XML file. Valid values: true, false
saXAVCSHSPICEEnvOptsAccuracyLevel	string	saTestbench	set_sim_level	Accuracy Level

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAVCSHSPICEEnvOptsCaseSensitive	bool	saTestbench	false	XAHSPICE simulator case setting.
saXAVCSHSPICEEnvOptsDigitalOutputDataFormat	string	saTestbench	fsdb	Digital output data format.
saXAVCSHSPICEEnvOptsEnableParallelSim	string	saTestbench	0	Enable Parallel Simulation
saXAVCSHSPICEEnvOptsMergedFile	bool	saTestbench	true	Enable merged results file.
saXAVCSHSPICEEnvOptsNumProcesses	string	saTestbench	1	Number of Processes
saXAVCSHSPICEEnvOptsUseSsl2	bool	saTestbench	true	Use v2 of accuracy/performance tradeoff parameters set. Valid values: true, false
saXAVCSHSPICEIncludeSchematicNetlist	bool	user	true	Copy (true) or include (false) the structural netlist in the final netlist. Valid values: true, false
saXAVCSHSPICELibrariesImport	string	saTestbench	Import	XAVCSHSPICE libraries Import Setting.
saXAVCSHSPICEMeasuresImport	string	saTestbench	Import	XAVCSHSPICE measures Import Setting.
saXAVCSHSPICEModelGroups	string	saTestbench		Model groups for XAVCSHSPICE
saXAVCSHSPICEModelGroupsCheckBox	bool	saTestbench	false	Visibility of Model Groups table for XAVCSHSPICE. Valid values: true, false
saXAVCSHSPICEModelsImport	string	saTestbench	Import	XAVCSHSPICE models Import Setting.
saXAVCSHSPICEMonteCarloSamplingMethod	string	saTestbench	SRS	Enables advanced sampling methods.
saXAVCSHSPICEMonteCarloSeed	string	saTestbench	1	Starting seed for the random-number generator in Monte Carlo analysis.
saXAVCSHSPICEMonteCarloUseRandomSeed	string	saTestbench	true	Use random seed for random-number generator in Monte Carlo analysis.
saXAVCSHSPICEMsOptsConnectModulesInstallDirFilePatterns	string	user	snps_cm_*.vams	Installed Connect Modules File Patterns for XAVCSHSPICE
saXAVCSHSPICEMsOptsConnectModulesUserDir	string	user		User Connect Modules and Rules Directory for XAVCSHSPICE

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAVCSHSPICEMsOptsConnectModulesUserDirFilePatterns	string	user		User Connect Modules File Patterns for XAVCSHSPICE
saXAVCSHSPICEMsOptsConnectRuleDefault	string	user	1 global {} voltage {}	Connect Rule Default for XAVCSHSPICE
saXAVCSHSPICEMsOptsConnectRulesInstallDirFilePatterns	string	user	snps_cr_*.vams	Installed Connect Rules File Patterns for XAVCSHSPICE
saXAVCSHSPICEMsOptsConnectRulesUserDirFilePatterns	string	user		User Connect Rules File Patterns for XAVCSHSPICE
saXAVCSHSPICEMsOptsD2AInterfaceElementDefault	string	user	false {} { 0.1n midPoint 3.0 0 v net	D2A Interface Element Default for XAVCSHSPICE.
saXAVCSHSPICEMsOptsDisciplineResolutionDefault	string	user	basic	Net Discipline Resolution Default for XAVCSHSPICE
saXAVCSHSPICEMsOptsE2NInterfaceElementDefault	string	user	th_wire {} 1 1 1k 1	saXAVCSHSPICEMsOptsE2NInterfaceElementDefault.
saXAVCSHSPICEMsOptsE2RInterfaceElementDefault	string	user	false "" "" 1 "" "" net	E2R Interface Element Default for XAVCSHSPICE.
saXAVCSHSPICEMsOptsEnableMSIERReport	bool	user	false	Enables printing the connect module report into the log file for XAVCSHSPICE. Valid values: true, false
saXAVCSHSPICEMsOptsN2EInterfaceElementDefault	string	user	th_wire {} 1 10p 1 50 1G {} 1	saXAVCSHSPICEMsOptsN2EInterfaceElementDefault.
saXAVCSHSPICEMsOptsNetDisciplineDefault	string	user	ddiscrete	Net Discipline Default for XAVCSHSPICE
saXAVCSHSPICEMsOptsR2EInterfaceElementDefault	string	user	false "" 1 "" net	R2E Interface Element Default for XAVCSHSPICE.
saXAVCSHSPICEOptionAUTOSTOP	string	custom	0	XAVCSHSPICE option AUTOSTOP: Stops a transient analysis
saXAVCSHSPICEOptionAUTOSTOPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOptionCSHUNT	string	custom	1e-20	XAVCSHSPICE option CSHUNT: Add capacitance from each node to ground.
saXAVCSHSPICEOptionCSHUNT	string	custom	1e-20	XAVCSHSPICE option CSHUNT: Add capacitance from each node to ground.

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAVCSHSPICEOptionCSHUNTUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOptionDCAP	string	custom	2	XAVCSHSPICE option DCAP: Specifies equations used to calculate depletion capacitance for Level 1 and 3 diodes and BJTs.
saXAVCSHSPICEOptionDCAPUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOptionengine	string	custom	PrimeSim XA VCS	XAVCSHSPICE option engine: Simulation Engine
saXAVCSHSPICEOptionengine	string	custom	PrimeSim XA VCS	XAVCSHSPICE option engine: Simulation Engine
saXAVCSHSPICEOptionGMIN	string	custom	1e-12	XAVCSHSPICE option GMIN: Minimum conductance added to all PN junctions for a time sweep in transient analysis.
saXAVCSHSPICEOptionGMINUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOptionMACMOD	string	custom	0	XAVCSHSPICE option MACMOD: To access the subcircuit definition when there is no matching model reference
saXAVCSHSPICEOptionMACMODUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOptionMAXWARNS	string	custom	5	XAVCSHSPICE option MAXWARNS: Specifies maximum number of safe operating area (SOA) warning messages.
saXAVCSHSPICEOptionMAXWARNS	string	custom	5	XAVCSHSPICE option MAXWARNS: Specifies maximum number of safe operating area (SOA) warning messages.
saXAVCSHSPICEOptionMAXWARNSUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOptionMODMONTE	string	custom	0	XAVCSHSPICE option MODMONTE: Controls whether all instances of a device get the same or unique model parameters.

Table 34 *Simulation and Analysis Environment Preferences (Continued)*

Name	Type	Scope	Default	Description
saXAVCSHSPICEOptionMODMONTE	string	custom	0	XAVCSHSPICE option MODMONTE: Controls whether all instances of a device get the same or unique model parameters.
saXAVCSHSPICEOptionMODMONTEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOptionMONTECON	string	custom	1	XAVCSHSPICE option MONTECON: Continues a Monte Carlo analysis by retrieving the next random value, even if non-convergence occurs.
saXAVCSHSPICEOptionMONTECON	string	custom	1	XAVCSHSPICE option MONTECON: Continues a Monte Carlo analysis by retrieving the next random value, even if non-convergence occurs.
saXAVCSHSPICEOptionMONTECONUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOptionotherOptions	string	custom		XAVCSHSPICE option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...)]
saXAVCSHSPICEOptionotherOptions	string	custom		XAVCSHSPICE option otherOptions: For including simulator options not supported by this GUI (format is name1=val1 name2=val2 ...).
saXAVCSHSPICEOptionotherOptionsUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOptionSCALE	string	custom	1.00	XAVCSHSPICE option SCALE: Sets the element scaling factor.
saXAVCSHSPICEOptionSCALEUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOptionSCALM	string	custom	1	XAVCSHSPICE option SCALM: Sets the model scaling factor.
saXAVCSHSPICEOptionSCALMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOptionsetsimlevel	string	custom	3	XAVCSHSPICE option set_sim_level: Controls runtime speed and simulation accuracy.

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAVCSHSPICEOptionsetsimlevel	string	custom	3	XAVCSHSPICE option set_sim_level: Controls runtime speed and simulation accuracy.
saXAVCSHSPICEOptionTNOM	string	custom	25	XAVCSHSPICE option TNOM: Sets the reference temperature for the simulation.
saXAVCSHSPICEOptionTNOMUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOptionWARN	string	custom	0	XAVCSHSPICE option WARN: Enables or turns off SOA voltage warning message
saXAVCSHSPICEOptionWARN	string	custom	0	XAVCSHSPICE option WARN: Enables or turns off SOA voltage warning message.
saXAVCSHSPICEOptionWARNUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOptionWL	string	custom	0	XAVCSHSPICE option WL: Reverses the order of the VSIZE MOS element.
saXAVCSHSPICEOptionWLUncheckLocalized	bool	saTestbench	false	Determine if the localized is required to be set back to unchecked when the preference is loaded.
saXAVCSHSPICEOutputControlImport	string	saTestbench	Import	XAVCSHSPICE outputControl Import Setting.
saXAVCSHSPICESaveOptionsElectromigrationStart	string	saTestbench		Start time for electromigration current analysis.
saXAVCSHSPICESaveOptionsElectromigrationStop	string	saTestbench		Stop time for electromigration current analysis.
saXAVCSHSPICESaveOptionsEnableEM	string	saTestbench	false	Save currents for in-design layout automation.
saXAVCSHSPICESaveOptionsEnableVDRC	string	saTestbench	false	Save voltage extremes to enable VDRC flow.
saXAVCSHSPICESaveOptionsSaveNetVoltages	string	saTestbench	selected	XAVCSHSPICE Save net voltages.
saXAVCSHSPICESaveOptionsSaveDigital	string	saTestbench	selected	XAVCSHSPICE: Save digital signals
saXAVCSHSPICESaveOptionsSaveDigitalLevel	string	saTestbench	0	XAVCSHSPICE: Save digital signals level

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAVCSHSPICESaveOptionsSaveDigitalPorts	string	saTestbench	selected	XAVCSHSPICE: Save digital ports
saXAVCSHSPICESaveOptionsSaveDigitalPortsLevel	string	saTestbench	0	XAVCSHSPICE: Save digital ports level
saXAVCSHSPICESaveOptionsSaveIEPortsAll	string	saTestbench	false	Save Options save interface element/connect module ports
saXAVCSHSPICESaveOptionsSaveIEPortsLevel	string	saTestbench	0	Save Options save interface element/connect module ports level
saXAVCSHSPICESaveOptionsSaveNetLevel	string	saTestbench	0	XAVCSHSPICE: Save net voltages level
saXAVCSHSPICESaveOptionsSaveOptionsInstances	string	saTestbench		XAVCSHSPICE: Save instance-specific signals
saXAVCSHSPICESaveOptionsSaveVerilogABranchCurrentsAll	string	saTestbench	false	Save Options save Verilog-A branch currents
saXAVCSHSPICESaveOptionsSaveVerilogABranchCurrentsLevel	string	saTestbench	0	Save Options save Verilog-A branch currents level
saXAVCSHSPICESaveOptionsSaveVerilogABranchVoltagesAll	string	saTestbench	false	Save Options save Verilog-A branch voltages
saXAVCSHSPICESaveOptionsSaveVerilogABranchVoltagesLevel	string	saTestbench	0	Save Options save Verilog-A branch voltages level
saXAVCSHSPICESaveOptionsSaveVerilogAVarsAll	string	saTestbench	false	Save Options save Verilog-A variables
saXAVCSHSPICESaveOptionsSaveVerilogAVarsLevel	string	saTestbench	0	Save Options save Verilog-A variables level
saXAVCSHSPICESaveOptionsSaveSubcktCurrents	string	saTestbench	selected	XAVCSHSPICE: Save subckt port currents
saXAVCSHSPICESaveOptionsSaveSubcktCurrentsLevel	string	saTestbench	0	XAVCSHSPICE: Save subckt port currents level
saXAVCSHSPICESaveOptionsSaveTerminalCurrents	string	saTestbench	selected	XAVCSHSPICE: Save device terminal currents
saXAVCSHSPICESaveOptionsSaveTerminalCurrentsLevel	string	saTestbench	0	XAVCSHSPICE: Save device terminal currents level
saXAVCSHSPICESaveOptionsSaveTerminalVoltages	string	saTestbench	selected	XAVCSHSPICE: Save device terminal voltages
saXAVCSHSPICESaveOptionsSaveTerminalVoltagesLevel	string	saTestbench	0	XAVCSHSPICE: Save device terminal voltages level

Table 34 Simulation and Analysis Environment Preferences (Continued)

Name	Type	Scope	Default	Description
saXAVCSHSPICESaveOptionsVdr ctStart	string	saTestbench		Start time for VDRC voltage analysis.
saXAVCSHSPICESaveOptionsVdr ctStop	string	saTestbench		Stop time for VDRC voltage analysis.
saXAVCSHSPICEShowModelGroups	bool	saTestbench	false	Displays the Model Groups table for XAVCSHSPICE. Valid values: true, false
saXAVCSHSPICESimulationCommandPrefix	string	user		An environment initialization command to be added to simulation commands.
saXAVCSHSPICESimulatorOptionsImport	string	saTestbench	Import	XAVCSHSPICE simulatorOptions Import Setting.
saXAVCSHSPICETemperatureImport	string	saTestbench	Import	XAVCSHSPICE temperature Import Setting.
saXAVCSHSPICETRANRunControl	string	saTestbench	Analog	XAVCSHSPICE Transient run type.

See Also

- [Simulation and Analysis Environment Preferences \(saA2D* through saFineSimPro*\)](#)
- [Simulation and Analysis Environment Preferences \(saGen* through saOutput*\)](#)
- [Simulation and Analysis Environment Preferences \(saParam* through saPrimeSimVCS*\)](#)
- [Simulation and Analysis Environment Preferences \(saPrimeSimXA* through saSpectre*\)](#)

PrimeWave Design Environment Preference Examples

The following section gives examples for some of PrimeWave Design Environment preferences.

- [saUseInternalExternalSpec](#)

saUseInternalExternalSpec

You can use the preference `saUseInternalExternalSpec` to use internal/external goals instead of the default specification type (goal/marginal). When `saUseInternalExternalSpec` is set to True, the ResultsView highlights pass and fail values, as shown in .

The of preferences are better suited for goal/marginal type specs. Customize the colors for better visibility for internal/external specs. One possible choice of colors is shown in last column.

Internal Spec	External Spec	Background	Foreground (Text Color)	Example (Default)	Example (Customized)
Pass	Pass/Not defined	saResultsViewerPassColor	Default Foreground Color (Black)	Value	Value
Fail	Pass/Not defined	saResultsViewerFailColor	Default Foreground Color (Black)	Value	Value
Pass	Fail	saResultsViewerPassColor	saResultsViewerMarginalColor Bold	Value	Value
Fail	Fail	saResultsViewerFailColor	saResultsViewerMarginalColor Bold	Value	Value
Not defined	Pass/Not defined	Application Background Color (White)	Application Foreground Color (Black)	Value	Value
Not defined	Fail	Application Background Color (White)	saResultsViewerMarginalColor Bold	Value	Value

2

Waveform Tcl

This chapter lists the commands, enumerations, objects, and preferences in the PrimeWave Design Environment Tcl wf namespace. This namespace provides Tcl for waveform analysis in the PrimeWave Design Environment.

For details, see:

- [Commands](#)
- [Enumerations](#)
- [Objects](#)
- [Preferences](#)

Commands

Interactive commands are listed after non-interactive commands in the Commands section.

The commands covered are:

- [wf::addFunctionsToCategory](#)
- [wf::appendData](#)
- [wf::clearStoredExpressionResults](#)
- [wf::closeFile](#)
- [wf::closeViewer](#)
- [wf::closeViewerTabs](#)
- [wf::createCustomPlotMode](#)
- [wf::createDataAccessFunctionMapping](#)
- [wf::createExpression](#)
- [wf::createExpressionValue](#)

- [wf::createFunction](#)
- [wf::createFunctionArgument](#)
- [wf::createFunctionArgumentGroup](#)
- [wf::createFunctionCategory](#)
- [wf::createMacro](#)
- [wf::createGraphicalAnnotation](#)
- [wf::createScan](#)
- [wf::createSignal](#)
- [wf::dmMeasure](#)
- [wf::exportPlots](#)
- [wf::exportPrefs](#)
- [wf::expr](#)
- [wf::extractTrace](#)
- [wf::findExpressionMappings](#)
- [wf::findParams](#)
- [wf::findSignal](#)
- [wf::findStoredExpressionResult](#)
- [wf::firstSignal](#)
- [wf::firstWDF](#)
- [wf::getAllData](#)
- [wf::getExpressionInputs](#)
- [wf::getFileInfo](#)
- [wf::getFunctionCategories](#)
- [wf::getFunctions](#)
- [wf::getMacros](#)
- [wf::getPrefValue](#)
- [wf::getSignalAttribute](#)

- `wf::getViewerGeometry`
- `wf::hspiceMeasureFile`
- `wf::importPrefs`
- `wf::isExpression`
- `wf::isViewerReady`
- `wf::isViewerRunning`
- `wf::launchViewer`
- `wf::loadPrefs`
- `wf::loadSession`
- `wf::loadSignals`
- `wf::nextSignal`
- `wf::nextWDF`
- `wf::openFile`
- `wf::plotExpressions`
- `wf::plotWaveforms`
- `wf::raiseViewer`
- `wf::redrawViewer`
- `wf::removeFunctionsFromCategory`
- `wf::savePrefs`
- `wf::saveSession`
- `wf::saveSignal`
- `wf::scan`
- `wf::setDataDirectory`
- `wf::setPrefValue`
- `wf::setReaderAPIPrefValue`
- `wf::setSignalAttribute`
- `wf::storeExpressionResult`

- [wf::transformParamValue](#)
- [wf::unloadSignal](#)
- [wf::updateViewerKeyBindings](#)
- [wf::updateViewerPrefs](#)
- [wf::viewerExited](#)

wf::addFunctionsToCategory

Description

Adds functions to a category. Functions already in the category will not be added again.

Syntax

```
wf::addFunctionsToCategory <functions: [string | wfFunction]> -category  
  <string | wfFunctionCategory>
```

Arguments

<string | [wfFunction](#)>

A list of function names or functions to add to the category.

-category <string> | [wfFunctionCategory](#)

The category or name of the category.

Returns

<none>

Errors

- The category specified by name does not exist.
- A function specified by name does not exist.

wf::appendData

Description

Appends a data point to a signal created by [wf::createSignal](#). The new data point is appended to the end of the existing data list in the signal. For logic target signal, warnings should be issued if states string is wider than the number of bits (width) of the target signal. Standard VCD left extension rule is applied if states is shorter than the number of bits.

Syntax

```
wf::appendData <wfSignal: wfSignal> [-i <float> | -states <string>] -x  
<float> [-y <float>]
```

Arguments

wfSignal

Target wfSignal object.

-x <float>

X value of the new data point.

-y <float>

Y value of the new data point.

-i <float>

Imaginary part of the y-value. (Default: 0.0)

-states <string>

Binary logic vector value of the new data point. "0 1 X Z" values (case-insensitive) are supported. (Default: 0)

Returns

<none>

Errors

- Out of memory.
- xval not provided.
- Invalid wfSignal.
- Invalid logic vector string.
- Invalid value: sval for non-logic signals, yval/ival for logic signals, ival for real signals. Invalid characters in sval for logic target signal.

Examples

```
set signal [wf::createSignal clk]  
set value 0  
for {set i 0} {$i<100} {incr i} {  
    wf::appendData $signal -x [expr $i*1e-9] -y $value  
    if {0==[expr $i%10]} {  
        if {0==$value} {  
            set value 1  
        } else {  
            set value 0  
        }  
    }  
}
```

```
        }  
    }  
}  
wf::plotWaveforms $signal -mode new  
foreach format {WDF Table VCD} {  
    set ext [string tolower $format]  
    set fid [wf::openFile clk.${ext} -format $format -accessMode write]  
    wf::saveSignal $signal -file $fid  
    wf::closeFile $fid  
}
```

wf::clearStoredExpressionResults

Description

Discards any stored expression results for the given results directory.

Syntax

```
wf::clearStoredExpressionResults <none: string>
```

Arguments

<string>

The results directory containing the expression results.

Returns

<none>

Errors

Invalid results directory.

wf::closeFile

Description

Closes the opened waveform file `wfDataFile` object. This command also destroys the `wfDataFile` object.

Syntax

```
wf::closeFile <wfDataFile: wfDataFile>
```

Arguments

`wfDataFile`

Waveform data file object.

Returns

<none>

Errors

invalid wfDataFile object.

Examples

```
set report ""
set resultsFile
    "./latestResults/simulation/PrimeSimSpice/PrimeSimSPICE/corners/resul
ts/resultsMap.xml"
set fid [wf::openFile $resultsFile -resultType tran -analysisName tran]
set variableConditions [db::getAttr fid.variableConditions]
foreach signalName [db::getAttr fid.signalNames] {
    append report [string repeat # 80] "\n"
    append report "# Signal $signalName\n"
    append report [string repeat # 80] "\n"

    set index 0
    append report "    Params [lindex $variableConditions $index]\n"
    set signal [wf::findSignal $signalName -file $fid]
    set scan [wf::createScan $signal]

    set sf [wf::openFile ${signalName}.table -format Table -accessMode
write]
    wf::saveSignal $signal -file $sf
    wf::closeFile $sf

    set t [wf::scan $scan -to first]
    while {$t} {
        append report "                [format %-20s%s [db::getAttr scan.x]
[db::getAttr scan.y]] \n"
        set t [wf::scan $scan -to next]
        if {2==$t} {
            incr index
            append report "    Params [lindex $variableConditions
$index]\n"
        }
    }
}
wf::closeFile $fid

set fh [open "signals.txt" "w"]
puts $fh $report
close $fh
xt::openTextViewer -files signals.txt
```

wf::closeViewer

Description

Closes a waveform viewer.

Syntax

```
wf::closeViewer
```

Arguments

None.

Returns

<none>

Examples

```
if {[wf::isViewerRunning]} {  
    wf::closeViewer  
}
```

wf::closeViewerTabs

Description

Closes waveform viewer tabs.

Syntax

```
wf::closeViewerTabs [<tbName: string>] [-job <xtJob>]
```

Arguments

tbName

Name of the testbench to close.

-job

Current job.

Returns

<none>

wf::createCustomPlotMode

Description

Creates a custom plot mode.

Syntax

```
wf::createCustomPlotMode <name: string> -config <string> [-isGlobal <bool>] [-isAlltbs <bool>] [-isUpdated <bool>]
```

Arguments

name: string

The custom plot mode name.

-config <string>

The waveform viewer configuration.

-isGlobal

Custom plot mode is a global on. Default: false.

-isAlltbs

Custom plot mode has all testbenches. Default: false.

[-isUpdated <bool>]

Custom plot mode is updated. Default: false.

Returns

<wfCustomPlotMode>

The new wfCustomPlotMode object.

wf::createDataAccessFunctionMapping

Description

Creates a wfDataAccessFunctionMapping object.

Syntax

```
wf::createDataAccessFunctionMapping -saeName <string> [-resultsDir <string>] [-filename <string>] [-waveNames [<string>]] [-resultType <string>] [-analysisName <string>] [-isExpression <bool>] [-dataType <string>] [-time <string>] [-paramName <string>] [-signalType <enum>] [-displayType <enum>] [-paramConditions <string>] [-bits <string>] [-lo <float>] [-hi <float>] [-scalarValue <float>] [-isGetVal <bool>]
```

Arguments

`-saeName`

PrimeWave Design Environment signal name in the schematic namespace.

`-resultsDir`

Results directory.

`-filename`

Result file name.

`-waveNames`

Wave names.

`-resultType`

Result type.

`-analysisName`

Analysis name.

`-isExpression`

Is this a reference to another expression? (Default: false).

`-dataType`

Waveform file data type.

`-time`

Time point.

`-paramName`

Parameter name.

`-signalType`

Signal type. ({ analogi | analogv | anytype | complex | complexi | complexv | logic | notype | power | stateye }). The default is anytype)

`-displayType`

Display type. ({ analogi | analogv | complex | complexi | complexv | logic | notype | power | stateye }). The default is analogv)

`-paramConditions`

Parametric reduction conditions.

`-bits`

Bits to filter to.

`-lo`

Low voltage threshold for converting analog signals to digital. (Default: 0)

`-hi`

High voltage threshold for converting analog signals to digital. (Default: 0).

`-scalarValue`

Pre-calculated scalar value. (Default: 0)

`-isGetVal`

Checks if this is a reference from getVal function. (Default is: false)

Returns

<wfDataAccessFunctionMapping>: The newly created wfDataAccessFunctionMapping object.

wf::createExpression

Description

Creates a wfExpression object.

Syntax

```
wf::createExpression <expression: string> -type <enum> [-exprIndex  
<int>] [-name <string>] [-resultType <string>] [-analysisName <string>]  
[-enabled <bool>] [-plot <bool>] [-plotType <enum>] [-isPlotted  
<bool>] [-logicRadix <enum>] [-color <string>] [-units <string>]  
[-params <string>] [-modifier <string>] [-global <bool>] [-values  
[<wfExpressionValue>]]
```

Arguments

`expression`

Expression string.

`-type`

Expression type. ({ expression | logicNet | measure | net | terminal | unknown })

`-exprIndex`

Expression index. (Default: -1)

`-name`

Expression name. (Default:)

`-resultType`
Result type. (Default:)

`-analysisName`
Analysis name. (Default:)

`-enabled`
Enable expression? (Default: true)

`-plot`
Plot expression? (Default: true)

`-plotType`
Plot type. ({ auto | constell | eyediag | histogram | linear | polar | scatter | smith | spectrum | stateye }). (Default: auto)

`-isPlotted`
Is expression plotted? (Default: false)

`-logicRadix`
Logic radix (digital signals only). ({ ascii | auto | binary | decimal | default | hexadecimal | octal | signed }). (Default: auto)

`-color`
Plot color. (Default:)

`-units`
Units. (Default:)

`-params`
Parametric reduction string. (Default:)

`-modifier`
Expression modifier. (Default: auto)

`-global`
Global evaluation settings. (Default: false)

`-values`
Expression values.

Returns

<wfExpression>: The newly created wfExpression object.

wf::createExpressionValue

Description

Creates a wfExpressionValue object.

Syntax

```
wf::createExpressionValue <exprIndex: int> -valueType <enum>  
    [-paramConditions <string>] [-realValue <float>] [-imagValue <float>]  
    [-logicValue <string>] [-errorValue <string>]
```

Arguments

exprIndex

Expression index.

-valueType

Expression value type. ({ complex | error | logic | real })

-paramConditions

Parameter conditions.

-realValue

Real value. The default is 0.

-imagValue

Imaginary value. The default is 0.

-logicValue

Logic value.

-errorValue

Error message for failed evaluation.

Returns

<wfExpressionValue>: The newly created wfExpressionValue object.

wf::createFunction

Description

Creates and registers a new PrimeWave Design Environment expression function.

Syntax

```
wf::createFunction <name: string> -functionType <enum> [-description  
<string>] [-arguments [<wfFunctionArgument>]] [-exclusive  
[<wfFunctionArgumentGroup>]] [-override <bool>] [-isACE <bool>]  
[-splitTraces <bool>]
```

Arguments

-name <string>

The name of the function.

-functionType

The type of the function. `dataAccess` | `point` | `rf` | `scalarMeasure` |
`waveformConversion`

-description <string>

A textual description of the function.

-arguments [[wfFunctionArgument](#)]

List of arguments that the function accepts. (Default: {})

-exclusive [[wfFunctionArgumentGroup](#)]

List of groups of mutually exclusive arguments. (Default: {})

-override <bool>

If true, the new function can override any existing function of the same name.
(Default: false)

-isACE

Function is implemented in ACE commands. Default: false. See also [Creating Custom Functions](#).

-splitTraces

Automatically split signal into traces when evaluation. (Default: false)

Returns

The newly created function. ([wfFunction](#)).

Errors

- Multiple arguments are specified with the same name.
- An exclusive group references an argument not contained in the arguments list.
- An exclusive group references a required argument.

- Invalid function name.
- Function already exists and override != true.

wf::createFunctionArgument

Description

Creates a new argument definition for a function. The returned object cannot be destroyed by db::destroy. Its lifespan is determined by the variables and objects that reference it. The default value of the argument only applies if the argument is optional.

Syntax

```
wf::createFunctionArgument <name: string> -argumentType <enum> [-label  
    <string>] [-description <string>] [-dataTypes [<string>]] [-validValues  
    [<string>]] [-optional <bool>] [-defaultValue <string>]
```

Arguments

-name <string>

The name of the argument.

-argumentType

This attribute contains a value that can be used to build a helper GUI for arguments. For example, if the value is "numeric", the GUI could contain an entry field that allows only numeric values.

-label <string>

The label to display.

-description <string>

A textual description of the argument to the function.

-dataTypes [*enWfDataType*]

A list of allowed data types for the argument. This is not used for arguments of *dataAccess* functions. When specified, at least one of *analog*, *logic* or *complex* and one of *scalar* or *signal* must be given. See also *Creating Custom Functions*.

-validValues [<string>]

A list of valid values for the function (only used for when the *argumentType* is *enum*). (Default: "")

-optional <bool>

Indicates whether the argument is optional or not. (Default: false)

`-defaultValue <string>`

The default value of the argument. This is only used if the argument is optional.
(Default: "")

Returns

The newly created argument definition. ([wfFunctionArgument](#))

Errors

- Default value specified for non-optional argument.
- validValues specified for non-enum type argument.
- defaultValue is not acceptable for the argumentType.
- Invalid argument name.

wf::createFunctionArgumentGroup

Description

Creates an argument group for a function. The argument group is a list of mutually exclusive arguments. All of the [wfFunctionArgument](#) objects in a group must be optional (this check is enforced by the `wf::createFunction` command). The returned object cannot be destroyed by `db::destroy`. Its lifespan is controlled by the objects and variables that reference it.

Syntax

```
wf::createFunctionArgumentGroup <arguments: [string |  
wfFunctionArgument]> [-optional <bool>]
```

Arguments

`-arguments` [[wfFunctionArgument](#)<string>]

Tcl list of arguments or argument names (string). All arguments must be optional.

`-optional` <bool>

Indicates if the argument group is optional to the function. (Default: false)

Returns

The newly created argument group. ([wfFunctionArgumentGroup](#)).

Errors

- Argument list less than two elements long.
- Duplicate arguments in the argument list.

wf::createFunctionCategory

Description

Creates a new category of functions.

Syntax

```
wf::createFunctionCategory <name: string> [-functions [<string |  
wfFunction>]]
```

Arguments

-name <string>

The name of the category.

-functions [<string>[wfFunction](#)]

A list of function names or functions to put in the new category.

Returns

The new category. ([wfFunctionCategory](#))

Errors

- The specified category already exists.
- A function specified by name does not exist.

wf::createMacro

Description

Creates and registers a PrimeWave Design Environment expression macro.

Syntax

```
wf::createMacro <name: string> -inputs [<string>] -expression <string>  
[-description <string>] [-override <bool>]
```

Arguments

name <string>

The name of the macro.

`-inputs <string>`

The names of the inputs for the macro.

`-expression <string>`

The core expression for the macro.

`-description <string>`

A textual description of the macro.

`-override <bool>`

If true, the new macro can override any existing macro of the same name.

Returns

The created macro (wfMacro).

Examples

```
wf::createMacro myMacro -inputs [list a b] -expression "log10((a + b)/2)"  
-override true  
set signal [wf::expr myMacro(v(a),v(out1))]  
-resultsDir ./  
latestResults/simulation/PrimeSimSpice/PrimeSimSPICE/corners/results  
-resultType tran -analysisName tran]  
wf::plotWaveforms $signal -mode new
```

wf::createGraphicalAnnotation

Description

Creates a wfGraphicalAnnotation object.

Syntax

```
wf::createGraphicalAnnotation <annotationType: enum> -functionName  
<string> -index <int> -traceIndex <int> [-argumentName <string>]  
[-argumentString <string>] [-argumentValue <float>] [-x1 <float>] [-y1  
<float>] [-x2 <float>] [-y2 <float>]
```

Arguments

`annotationType`

The kind of annotation to create. ({ argumentValue | lineSegment | xValue |
xyValue | yValue })

`-functionName`

The function this annotation is to be attached to.

`-index`

Order in which the annotation will be processed. Lower is earlier.

`-traceIndex`

The index value of a sweep signal.

`-argumentName`

Specifies which argument of the function this annotation applies to.

`-argumentValue`

The value of an argument if it evaluates to a number.

`-x1`

The x1 coordinate. (Default: 0)

`-y1`

The y1 coordinate. (Default: 0)

`-x2`

The x2 coordinate. (Default: 0))

`-y2`

The y2 coordinate. (Default is: 0)

Returns

`<enGraphicalAnnotationType>`: The new `wfGraphicalAnnotation` object.

wf::createScan

Description

Creates a scan object `wfScan` for data traversal of the target `wfSignal` object. Several types of data traversals are available: (1) data point (2) rise trigger (3) fall trigger (4) cross trigger (5) delta x and (6) delta y. For analog signals, (2)(3)(4) require a predefined threshold value. For logic signals, (2) represents a 0-1 transition, (3) represents a 1-0 transition, (4) represents any value change.

Syntax

```
wf::createScan <wfSignal: wfSignal> [-scanType <enum>] [-threshold  
  <float>]
```

Arguments

`wfSignal`

Target `wfSignal`.

`-scanType`

Scan type.

Default: point.

`-threshold <float>`

Threshold value for RISE / FALL / CROSS scan types. (Default: 0.0)

Returns

The new `wfScan` (`wfScan`).

Errors

- out of memory.
- invalid `wfSignal` object.

Examples

```
set report ""
set resultsFile
  "./latestResults/simulation/PrimeSimSpice/PrimeSimSPICE/corners/resul
ts/resultsMap.xml"
set fid [wf::openFile $resultsFile -resultType tran -analysisName tran]
set variableConditions [db::getAttr fid.variableConditions]
foreach signalName [db::getAttr fid.signalNames] {
  append report [string repeat # 80] "\n"
  append report "# Signal $signalName\n"
  append report [string repeat # 80] "\n"

  set index 0
  append report "      Params [lindex $variableConditions $index]\n"
  set signal [wf::findSignal $signalName -file $fid]
  set scan [wf::createScan $signal]

  set sf [wf::openFile ${signalName}.table -format Table -accessMode
write]
  wf::saveSignal $signal -file $sf
  wf::closeFile $sf

  set t [wf::scan $scan -to first]
  while {$t} {
    append report "          [format %-20s%s [db::getAttr scan.x]
[db::getAttr scan.y]] \n"
    set t [wf::scan $scan -to next]
    if {2==$t} {
```

```
        incr index
        append report "      Params [lindex $variableConditions
$index]\n"
    }
}
wf::closeFile $fid

set fh [open "signals.txt" "w"]
puts $fh $report
close $fh
xt::openTextViewer -files signals.txt
```

wf::createSignal

Description

Creates a new wfSignal object. Data points can be appended to the newly created signal with the wf::appendData command. Only single trace signal can be created. The width option is for logic signal type only.

Syntax

```
wf::createSignal <string: string> [-signalType <enum>] [-width <int>]
```

Arguments

<string>

Signal full hierarchy name.

-signalType

Signal type. (Default: analogv)

-width <int>

Number of bits of the created logic signal. (Default: 1)

Returns

The new wfSignal object ([wfSignal](#)).

Errors

- out of memory.
- Error needs to be issued if the width option is used with non-logic signalType.

Examples

```
set signal [wf::createSignal clk]
set value 0
for {set i 0} {$i<100} {incr i} {
```

```

wf::appendData $signal -x [expr $i*1e-9] -y $value
if {0==[expr $i%10]} {
    if {0==$value} {
        set value 1
    } else {
        set value 0
    }
}
}
wf::plotWaveforms $signal -mode new
foreach format {WDF Table VCD} {
    set ext [string tolower $format]
    set fid [wf::openFile clk.${ext} -format $format -accessMode write]
    wf::saveSignal $signal -file $fid
    wf::closeFile $fid
}

```

wf::dmMeasure

Calculates the measurement string

Syntax

```

wf::dmMeasure [<measType: string>] [-sig1 <string | wfSignal>] [-sig2
<string | wfSignal>] [-y1 <float>] [-y2 <float>] [-x1 <float>] [-x2
<float>] [-sig <string | wfSignal>] [-y <float>] [-x <float>] [-ytype
<string>] [-yrange <string>] [-pulsetype <string>] [-trace <int>]
[-xrange <string>] [-outstyle <string>] [-count <int>] [-edgetype
<string>] [-trigger <string>] [-refwave <string | wfSignal>] [-negative
<int>] [-autodelay <bool>] [-reftrigger <string>] [-refxrange <string>]
[-premise <string>] [-closestedge <int>] [-yview <string>] [-offset
<float>] [-phase <string>] [-basedeg <int>]

```

Arguments

measType

dmMeasure type. Valid values: [delay|width|threshold|crossing|slewcreate|rise|fall|freq|period|duty|delay2|lowpass|highpass|phase_m|gain_m|average|peak2peak|max|min|yield|topline|baseline] (Default is:)

-sig1

signal1 handle (Default is:)

-sig2

signal2 handle (Default is:)

-y1

y threshold value for signal1

-y2
 y threshold value for signal2

-x1
 xrange min

-x2
 xrange max

-sig
 signal handle (Default is:)

-y
 y value for signal

-x
 x value for signal

-ytype
 y value type. Valid values: level|percentage (Default is:)

-yrange
 yrange type. Valid values: signal|allsignal|zoomedy|edge|topbase (Default is:)

-pulsetype
 pulse type. Valid values: up|down|positive|negative (Default is:)

-trace
 trace index, 0-based (Default is: 0)

-xrange
 xrange. Valid values: xlow,xhigh (Default is:)

-outstyle
 outstyle. Valid values: list:x|y|xy|yield|npass|nfail|cpk|dpu/waveform:xval|
 parameter|segment|yval|yield|cpk|dpu (Default is:)

-count
 count, works with list option. Valid values: last(-1)|all(0)|<1-based index>
 (Default is: 0)

-edgetype
 edge type. Valid values: up|down|either (Default is:)

`-trigger`
trigger type. Valid values: rise|fall|either (Default is:)

`-refwave`
reference signal handle (Default is:)

`-negative`
negative option. Valid values: 0|1 (Default is: 0)

`-autodelay`
autodelay option. Valid values: false|true (Default is: false)

`-reftrigger`
reference trigger type. Valid values: rise|fall|either|same|opposite (Default is:)

`-refxrange`
reference xrange. Valid values: xlow,xhigh (Default is:)

`-premise`
premise type. Valid values: either|positive|negative (Default is:)

`-closestedge`
closest edge. Valid values: 0|1 (Default is: 0)

`-yview`
yview type. Valid values: dbm|db10|db|phase|real|imag (Default is:)

`-offset`
offset (Default is:)

`-phase`
phase type. Valid values: degree|radians (Default is:)

`-basedeg`
basedeg. Valid values: 0|1 (Default is: 0)

Returns

<float | string | wfSignal>: Vector or scalar measure result

wf::exportPlots

Description

Exports the plotted waveforms to the postscript files.

Syntax

```
wf::exportPlots [<tabName: string>] [-directory <string>] [-format  
<string>] [-overwrite <bool>]
```

Arguments

tabName

The name of the waveform viewer tab. If empty or unspecified, exports all tabs.

-directory

The directory to save the image file(s). If empty or unspecified, defaults to the current working directory.

-format

Image file format. Supports .png and .ps. If empty or unspecified, the default is .ps.

-overwrite

Overwrites the existing files. (Default: true)

Returns

<none>

Examples

```
set resultsFile [file normalize  
  "./latestResults/simulation/PrimeSimSpice/PrimeSimSPICE/corners/resul  
ts/resultsMap.xml"]  
set fid [wf::openFile $resultsFile -resultType tran -analysisName tran]  
foreach signalName [db::getattr fid.signalNames] {  
  set signal [wf::findSignal $signalName -file $fid]  
  set trace [wf::extractTrace $signal -index 0]  
  wf::plotWaveforms $trace -mode new  
}  
set imgDir [file join [pwd] images]  
file mkdir $imgDir  
wf::exportPlots -directory [file join [pwd] images] -format png  
wf::closeFile $fid
```

wf::exportPrefs

Description

Exports waveform viewer preferences from PrimeWave Design Environment into a file.

Syntax

```
wf::exportPrefs <filename: string>
```

Arguments

filename

Preference filename

Returns

<none>

wf::expr

Description

Evaluates an expression and returns the result. The expression result can be optionally stored by name and results directory for use within other expressions.

Syntax

```
wf::expr <string: string> [-resultsDir <string> | -testbench  
  <saTestbench>] [-name <string>] [-resultType <string>] [-resultFile  
  <string>] [-analysisName <string>] [-params <string>] [-hierPath  
  <string>] [-time <string>] [-xAxisParamIndex <int>]
```

Arguments

<string>

The input expression.

-name <string>

The output name that can be referred to by subsequent expressions.

-resultType <string>

The default result type for the data access functions in the expression.

-resultsFile <string>

The default value for the resultFile argument in functions in the expression.

-resultsDir

The default value for the resultsDir argument in functions in the expression.

-testbench

Testbench.

-analysisName <string>

The default user-specified analysis name for the data access functions in the expression.

`-params <string>`

The default parameter conditions for the data access functions in the expression.

`-hierPath <string>`

The default value for the hierPath argument in functions in the expression.

`-time <string>`

The default value for the time argument in functions in the expression.

`-xAxisParamIndex <int>`

The index of the parameter to use as the x-axis. Only applies to sweep scalar data.

Returns

The result of the expression. (<float> | [wfSignal](#))

Errors

- Error parsing the expression.
- Expression input not found.

Examples

In this example, the `wf::expr` command calculates the sum of two signals from the specified result directory.

```
set signal [wf::expr "2*v(/out1) + 3*v(/a)" -name "sigSum"  
-resultsDir ./latestResults/simulation/PrimeSimSpice/PrimeSimSPICE/corners/results  
-resultType tran]  
wf::plotWaveforms $signal -mode new
```

wf::extractTrace

Description

Extracts a single trace from a multi-member signal. The extracted traces becomes a new `wfSignal` that is independent from the original signal `wfSignal`.

Syntax

```
wf::extractTrace <wfSignal: wfSignal> [-index <int> | -params <string>]
```

Arguments

`wfSignal`

Source `wfSignal` object.

`-index <int>`

0-based trace index. (Default: 0)

`-params <string>`

Parameter condition in format "A=1:B=2:C=3". (Default: "")

Returns

The extracted `wfSignal` object ([wfSignal](#)).

Errors

- out of memory.
- invalid `wfSignal` object.
- no matching parameter condition or trace index found.

Examples

This example extracts a trace from a multi-member signal.

```
set resultsFile
"./latestResults/simulation/PrimeSimSpice/PrimeSimSPICE/corners/resul
ts/resultsMap.xml"
set fid [wf::openFile $resultsFile -resultType tran -analysisName tran]
foreach signalName [db::getattr fid.signalNames] {
    set signal [wf::findSignal $signalName -file $fid]
    set trace [wf::extractTrace $signal -params
"corner=cornerSpice.2:temp=2.500000000e+01:reference40_models.lib=SS"]
    wf::plotWaveforms $trace -mode replace
    set sf [wf::openFile ${signalName}.table -format Table -accessMode
write]
    wf::saveSignal $trace -file $sf
    wf::closeFile $sf
}
wf::closeFile $fid
```

`wf::findExpressionMappings`

Description

Returns a collection of mapping objects for the expression.

Syntax

```
wf::findExpressionMappings <none: string> [-resultsDir <string> |  
-testbench <saTestbench>] [-resultType <string>] [-resultFile <string>]  
[-analysisName <string>] [-params <string>] [-hierPath <string>] [-time  
<string>] [-requireSig <string>] [-invokeFrom <string>]
```

Arguments

`none`

The input expression.

`-resultType`

The default value for the `resultType` argument in functions in the expression.

`-resultFile`

The default value for the `resultFile` argument in functions in the expression.

`-resultsDir`

The default value for the `resultsDir` argument in functions in the expression.

`-testbench`

The testbench.

`-analysisName`

The default value for the `analysisName` argument in functions in the expression.

`-params`

The default value for the `params` argument in functions in the expression.

`-hierPath`

The default value for the `hierPath` argument in functions in the expression.

`-time`

The default value for the `time` argument in functions in the expression.

`-requireSig`

Valid values are 0 or 1. If set to 1, `wf::findExpressionMappings` always returns the real signal map regardless of the signal data type.

`[-invokeFrom]`

Invoke from.

Returns

`<dbCollection>`: A collection of `wfDataAccessFunctionMapping` objects.

wf::findParams

Description

Finds all parameter names that is associated with a given instance in a wfDatafile.

Syntax

```
wf::findParams <none: string> -file <wfDataFile>
```

Arguments

<string>

Name of the instance.

-file

The waveform file that contains the device information.

Returns

The list of parameter names that belongs to the instance ({<string>}).

Errors

invalid wfDataFile.

wf::findSignal

Description

Retrieves wfSignal whose name matches the name string. The subFile option is for multi-run result files. If an invalid subFile index is used, the setting is defaulted to the first sub-file (index 0).

Syntax

```
wf::findSignal <signalName: string> -file <string | wfDataFile>  
[-signalType <enum>] [-subFile <int>]
```

Returns

wfSignal ([wfSignal](#)).

Arguments

<string>

Signal name.

-file

Target wfDataFile object.

-signalType

Signal V/I type.

Default: anytype.

-subFile <int>

0-based subfile index.

Default: 0.

Returns

wfSignal ([wfSignal](#)).

Errors

- no signal with matched name found.
- Warnings if an invalid subFile is used.

Examples

```
set report ""
set resultsFile
  "./latestResults/simulation/PrimeSimSpice/PrimeSimSPICE/corners/resul
ts/resultsMap.xml"
set fid [wf::openFile $resultsFile -resultType tran -analysisName tran]
set variableConditions [db::getAttr fid.variableConditions]
foreach signalName [db::getAttr fid.signalNames] {
  append report [string repeat # 80] "\n"
  append report "# Signal $signalName\n"
  append report [string repeat # 80] "\n"

  set index 0
  append report "      Params [lindex $variableConditions $index]\n"
  set signal [wf::findSignal $signalName -file $fid]
  set scan [wf::createScan $signal]

  set sf [wf::openFile ${signalName}.table -format Table -accessMode
write]
  wf::saveSignal $signal -file $sf
  wf::closeFile $sf

  set t [wf::scan $scan -to first]
  while {$t} {
    append report "          [format %-20s%s [db::getAttr scan.x]
[db::getAttr scan.y]] \n"
    set t [wf::scan $scan -to next]
    if {2==$t} {
```

```

        incr index
        append report "      Params [lindex $variableConditions
$index]\n"
    }
}
wf::closeFile $fid

set fh [open "signals.txt" "w"]
puts $fh $report
close $fh
xt::openTextViewer -files signals.txt

```

wf::findStoredExpressionResult

Description

Retrieves the stored expression result of by name and results directory. If an underscore character is used for the name to obtain the last evaluated result, the results directory is ignored.

Syntax

```

wf::findStoredExpressionResult <none: string> [-resultsDir <string>
| -testbench <saTestbench>] [-resultType <string>] [-analysisName
<string>]

```

Arguments

none

The name of the stored expression.

-resultsDir <string>

The results directory where the expression was stored.

-testbench

Testbench.

-resultType

The result type for the expression result.

-analysisName

The analysis name for the expression result.

Returns

The result of the stored expression. (<float> | [wfSignal](#))

Errors

- Stored expression not found.
- Could not find stored results for directory.

wf::firstSignal

Description

Returns the first signal from a wfDataFile.

Syntax

```
wf::firstSignal <wfDataFile: string | wfDataFile>
```

Arguments

wfDataFile

Target wfDataFile object.

Returns

<wfSignal>: The desired signal. Returns an empty string ("") if there is no signal in the target file.

wf::firstWDF

Description

Returns the first opened wfDataFile

Syntax

```
wf::firstWDF
```

Returns

<wfDataFile>: The desired wfDataFile. Returns an empty string ("") if there is no desired wfDataFile.

wf::getAllData

Description

Gets all data from a wfSignal object.

Syntax

```
wf::getAllData <wfSignal: string | wfSignal> [-output_list <string>]
```

Arguments

wfSignal

Target wfSignal object.

-output_list

The output_list action string. Valid string values are 'x', 'y', 'xy'. (Default: xy)

Returns

<dbCore> : Get all data values by type x|y|xy from the wfSignal

Examples

```
set report ""
set resultsFile [file normalize
  "./latestResults/simulation/PrimeSimSpice/PrimeSimSPICE/corners/resul
ts/resultsMap.xml"]
set fid [wf::openFile $resultsFile -resultType tran -analysisName tran]
foreach signalName [db::getattr fid.signalNames] {
  set signal [wf::findSignal $signalName -file $fid]
  append report [string repeat # 80] "\n"
  append report "# Signal $signalName\n"
  append report [string repeat # 80] "\n"
  set data [wf::getAllData $sl]
  append report [join $data "\n"] "\n"
}

# Dump all data into file and open in Custom Compiler Text Viewer
set fh [open "signals.txt" "w"]
puts $fh $report
close $fh
xt::openTextViewer -files signals.txt

wf::closeFile $fid
```

wf::getExpressionInputs

Description

Returns an even-length list containing all of the signal names and their corresponding mapping types contained in the input expression. The returned signal names are in the design namespace. This command is meant for use during netlist creation to add signal save statements so that all of the signals necessary to evaluate the expression are saved during the simulation.

Syntax

```
wf::getExpressionInputs <none: string>
```

Arguments

<string>

The input expression.

Returns

An even-length list of signal names paired with their corresponding mapping types. ({<string>}).

Errors

Error parsing the expression.

wf::getFileInfo

Description

Gets file information from waveform file

Syntax

```
wf::getFileInfo <wfDataFile: string | wfDataFile> [-type <string>]
```

Arguments

wfDataFile

Waveform data file object

-type

Waveform information type. Valid values: path, waveforms, title, , simulator, analysisName, dataType, resultType, analysis, delimiter, deviceType, format, formatVersion, signalCount, paramInfo, date, accessMode, nSubFiles, nSweeps, variableNames (Default:)

Returns

<dbCore>: The file attribute values. Returns an empty string ("") if there is no attribute information in the target file.

wf::getFunctionCategories

Description

Returns a collection of function categories matching the optional filter criteria.

Syntax

```
wf::getFunctionCategories [<pattern <string>] [-filter <string>]
```

Arguments

`-pattern <string>`

Pattern to match object name.

`-filter <string>`

Standard attribute filter.

Returns

Collection of matching functions. ([{wfFunctionCategory}](#))

Errors

Syntax error in filter expression.

Examples

```
db::foreach cat [wf::getFunctionCategories] {  
    # Print category name  
    puts "Category: [db::getAttr cat.name]"  
    puts "Functions:"  
    db::foreach f [db::getAttr cat.functions] {  
        # Print function name  
        puts "    [db::getAttr f.name]"  
    }  
}
```

wf::getFunctions

Description

Returns a collection of wfFunctions currently registered.

Syntax

```
wf::getFunctions [<pattern <string>] [-categories  
    [<string>wfFunctionCategory]] [-filter <string>]
```

Arguments

`-pattern <string>`

Pattern to match object name.

`-categories [<string>wfFunctionCategory]`

A list of categories to match.

`-filter <string>`

Standard attribute filter.

Returns

Collection of matching functions. ({[wfFunction](#)})

Errors

- The specified category doesn't exist.
- Syntax error in filter expression.

Examples

```
db::foreach f [wf::getFunctions -filter {%functionType=="rf"}] {  
    puts "[db::getAttr f.name]: [db::getAttr f.description]"  
}
```

wf::getMacros

Description

Creates a named macro for use in expressions.

Syntax

```
wf::getMacros [<pattern: string>] [-filter <string>]
```

Arguments

`-pattern <string>`

Pattern to match object name.

`-filter <string>`

Standard attribute filter.

Returns

The created macro (wfMacro).

wf::getPrefValue

Description

Gets the waveform viewer preference value.

Syntax

```
wf::getPrefValue <name: string>
```

Arguments

name: string

The preference name.

Returns

<string>

wf::getSignalAttribute

Gets the specified attribute from a signal.

Syntax

```
wf::getSignalAttribute <wfSignal: string | wfSignal> [-index <int>]  
[-value_type <int>] [-type <string>]
```

Arguments

wfSignal

Source wfSignal object

-index

1-based trace index (Default: 0)

-value_type

value_type(begin(0)/end(-1)/idx) (Default: 0)

-type

Attribute type. Valid values: name, alias, bestfit_coefficients, file, wftype, datatype, yunit, xunit, xtypeName, xrange, yrange, npoints, xview, yview, xpower, ypower, ntrace, parameter, value, xvalue, analysisName, deviceType, isEye, resultType, variableNames, xScale, yScale, spectrum (Default:)

Returns

<dbCore> : The specified wfSignal attribute. Returns an empty string ("") if there is no attribute information in the target signal

wf::getViewerGeometry

Description

Gets waveform viewer geometry.

Syntax

```
wf::getViewerGeometry [-job <xtJob>]
```

Arguments

-job

The viewer job.

Returns

<none>

wf::hspiceMeasureFile

Description

Evaluates HSPICE measurement file for waveform file.

Syntax

```
wf::hspiceMeasureFile <wfDataFile: wfDataFile> -netFileName <string>  
-outFileName <string> [-precision <int>] [-format <int>] [-measfail  
<int>]
```

Arguments

wfDataFile

Target wfDataFile object

-netFileName

Netlist file name

-outFileName

Output file name

-precision

Output file precision digits (Default: 6)

-format

Output file format: 0-lis, 1-mt0, 2-tab, 3-csv (Default: 1)

-measfail

When measurement fail, if measfail = 1, print "failed", else print "0" (Default: 0)

Returns

<none>

wf::importPrefs

Description

Imports waveform viewer preferences into PrimeWave Design Environment from a file.

Syntax

```
wf::importPrefs <filename: string>
```

Arguments

filename

Preferences filename.

Returns

<none>

wf::isExpression

Description

Checks a string to determine if it is an expression or a simple net/term name.

Syntax

```
wf::isExpression <string: string>
```

Arguments

<string>

The string to test.

Returns

True if the input string is an expression. ([<bool>])

Errors

This command does not have any specific errors.

Examples

```
# returns false since the specified string is net name  
puts [wf::isExpression /I0/M1/D]
```

```
# returns true  
puts [wf::isExpression sin(v(amp_out))]
```

wf::isViewerReady

Description

Returns true if the waveform viewer is ready to plot a signal.

Syntax

```
wf::isViewerReady [-job <xtJob>]
```

Arguments

-job <xtJob>

The viewer job.

Returns

The Viewer ready status (Boolean value).

Examples

```
proc waitViewerReady {} {  
    while {[wf::isViewerReady]} {  
        set x 0  
        after 200 { set x 1 }  
        db::vwait x  
    }  
}  
  
if {[wf::isViewerRunning]} {  
    wf::launchViewer -background false  
}  
waitViewerReady
```

wf::isViewerRunning

Description

Checks whether a waveform viewer is running.

Syntax

```
wf::isViewerRunning [-job <xtJob>]
```

Arguments

-job <xtJob>

The viewer job.

Returns

<none>

Errors

Tcl command execution error.

Examples

Example 1

```
if {[wf::isViewerRunning]} {  
    wf::closeViewer  
}
```

Example 2

```
proc waitViewerReady {} {  
    while {[wf::isViewerReady]} {  
        set x 0  
        after 200 { set x 1 }  
        db::vwait x  
    }  
}  
  
if {[wf::isViewerRunning]} {  
    wf::launchViewer -background false  
}  
waitViewerReady
```

wf::launchViewer

Description

Launches a waveform viewer.

Syntax

```
wf::launchViewer [<directory: string>] [-default <bool>] [-displayPrefix  
    <string>] [-configFile <string>] [-exitProc <string>] [-scriptFile  
    <string>] [-geometry <string>] [-quiet <bool>] [-gui <bool>]  
    [-guiCallbacks <bool>] [-background <bool>] [-jobGroup <xtJobGroup>]
```

Arguments

<directory: string>

The directory where waveform tool is launched. (Default: ".")

-default <bool>

Specifies whether or not to use the default viewer job (Default: true)

`-displayPrefix <string>`

Shell command fragment to set DISPLAY.

`-configFile <string>`

Viewer config file.

`-exitProc`

Custom viewer exit proc.

`-scriptFile`

Script filename.

`-geometry`

Waveform viewer starting geometry

`-quiet`

Suppress messaging. (Default: false)

`-gui`

Use GUI mode. (Default: true)

`-guiCallbacks`

Call GUI callbacks. (Default: true)

`-background`

Starts waveform viewer in background mode. (Default: true)

`-jobGroup`

Parent job group for waveform viewer job.

Returns

<none>

Errors

Viewer launch Tcl error.

Examples

```
proc waitViewerReady {} {  
    while {[wf::isViewerReady]} {  
        set x 0  
        after 200 { set x 1 }  
        db::vwait x  
    }  
}
```

```
if {[wf::isViewerRunning]} {  
    wf::launchViewer -background false  
}  
waitViewerReady
```

wf::loadPrefs

Description

Loads the waveform viewer preferences from a file.

Syntax

```
wf::loadPrefs <filename: string>
```

Arguments

filename: string

The preference filename.

Returns

<none>

wf::loadSession

Description

Loads a saved waveform viewer session.

Syntax

```
wf::loadSession <filename: string> -relativePath <string> -outputsXml  
                <string>
```

Arguments

filename: string

The session filename

-relativePath <string>

The relative path for result files.

-outputsXml <string>

The path to the outputs XML file.

Returns

<none>

wf::loadSignals

Description

Loads signals from a wfDataFile.

Syntax

```
wf::loadSignals <signalNames: [string]> -file <wfDataFile> [-signalType  
    <enum>] [-subFile <int>]
```

Arguments

signalNames: [string]

Names of signals to be loaded.

-file <wfDataFile>

The target wfDataFile object.

-signalType

The signal type.

Default: anytype.

-subFile <int>

The zero-based sub-file index. (Default: 0)

Returns

The desired signals ([<wfSignal>]).

wf::nextSignal

Description

Returns the next signal from a given signal.

Syntax

```
wf::nextSignal <wfSignal: string | wfSignal>
```

Arguments

wfSignal

Target wfSignal object.

Returns

<wfSignal> : The desired signal. Returns an empty string ("") if there are no more signals next to the target signal.

wf::nextWDF

Description

Returns the next wfDataFile from a given wfDataFile

Syntax

```
wf::nextWDF <wfDataFile: wfDataFile>
```

Arguments

wfDataFile

Target wfDataFile object

Returns

<wfDataFile> : The desired wfDataFile. Returns an empty string ("") if there is no desired wfDataFile.

wf::openFile

Description

Opens a waveform file at a given file path. The file can be open in read or write mode. A write wfDataFile only supports the following formats: Table, WDF, and VCD.

A resultsMap.xml file generated by the PrimeWave Design Environment tool can also be read with the openFile command. In this case, additional arguments such as resultsType and analysisName must be supplied to identify the actual file to access.

Note:

For the Table format write mode, a second file is automatically generated with the "_wv" suffix appended to the main file name of the user-specified file path. This second file can be imported directly into Custom WaveView, while the data saved in the user-specified file is free of comment lines so that it can be imported directly to other 3rd party tools such as spreadsheet editing tools.

A wfData file cannot be opened in append mode for adding more signals.

Syntax

```
wf::openFile <fileName: string> [-accessMode <enum>] [-format <enum>]  
[-analysisName <string>] [-resultType <string>] [-dataType <string>]  
[-params <string>] [-showProgress <bool>] [-readNameOnly <bool>]  
[-loadDataAtOpen <bool>]
```

Arguments

`fileName`

The name of the waveform file.

`-accessMode`

The mode which the file is opened in. Valid values: read, write. (Default: read)

`-format`

File write format. Valid values: Table, VCD, WDF. (Default: WDF)

`-analysisName <string>`

The name of the analysis. (Default: "")

`-resultType <string>`

The results type. (Default: "")

`-dataType`

The data type (Default:)

`-params`

Parameter condition in format "A=1:B=2.5,2.7:C=<1:100>:D=<1:200:2>".
(Default: "")

`-showProgress`

Show a progress dialog and allow user interrupt. (Default: false)

`-readNameOnly`

Open file in read name only mode to save memory. (Default: false)

`-loadDataAtOpen`

Load data at open. (Default: false)

Returns

New wfDataFile object ().

Errors

- Specified file does not exist or cannot be open (corrupted).
- Specified file is not in a valid readable format.
- Error needs to be issued if the wformat option is used with the read mode.

Examples

```
set report ""
set resultsFile
    "./latestResults/simulation/PrimeSimSpice/PrimeSimSPICE/corners/resul
ts/resultsMap.xml"
set fid [wf::openFile $resultsFile -resultType tran -analysisName tran]
set variableConditions [db::getAttr fid.variableConditions]
foreach signalName [db::getAttr fid.signalNames] {
    append report [string repeat # 80] "\n"
    append report "# Signal $signalName\n"
    append report [string repeat # 80] "\n"

    set index 0
    append report "    Params [lindex $variableConditions $index]\n"
    set signal [wf::findSignal $signalName -file $fid]
    set scan [wf::createScan $signal]

    set sf [wf::openFile ${signalName}.table -format Table -accessMode
write]
    wf::saveSignal $signal -file $sf
    wf::closeFile $sf

    set t [wf::scan $scan -to first]
    while {$t} {
        append report "                [format %-20s%s [db::getAttr scan.x]
[db::getAttr scan.y]] \n"
        set t [wf::scan $scan -to next]
        if {2==$t} {
            incr index
            append report "    Params [lindex $variableConditions
$index]\n"
        }
    }
}
wf::closeFile $fid

set fh [open "signals.txt" "w"]
puts $fh $report
close $fh
xt::openTextViewer -files signals.txt
```

wf::plotExpressions

Description

Plots non-interactive expressions.

Syntax

```
wf::plotExpressions -mapFile <string> -exprFile <string> -testbenchName  
  <string> -sessionName <string> -historyIndex <string> -historyName  
  <string> -mode <string> -groupSignals <bool> -separateGroups <bool>  
  [-sessionFile <string>] [-resultsDir <string>] [-job <string |  
  xtJob>] [-jobGroup <string | xtJobGroup>] [-outputs [<saOutput>]]  
  [-allowCustomPlotMode <bool>] [-noPlot <bool>] [-sonomaInc <bool>]  
  [-isSimulationRunning <bool>] [-isMtb <bool>]
```

Arguments

-mapFile

Mapping file.

-exprFile

Expression file.

-testbenchName

Testbench name.

-sessionName

Session name.

-historyIndex

History index.

-historyName

History name.

-mode

Plotting mode. Valid values: new, append, replace, newPanel, active, custom.

-groupSignals

Specifies whether or not to group plotted signals.

-separateGroups

Separate groups of plotted signals.

-sessionFile

Session file.

`-resultsDir`

Results directory.

`-job`

Viewer job.

`-jobGroup`

Parent job group for waveform viewer job.

`-outputs`

Expression outputs.

`-allowCustomPlotMode`

Specifies whether or not to allow custom plot modes. (Default: false)

`-noPlot`

Specifies whether to plot waveform in waveform viewer. (Default: false)

`-isSimulationRunning`

Specifies whether to plot waveforms while the simulation is running. (Default: false)

`-isMtb`

Is session multiple testbench? (Default: false)

Returns

<none>

wf::plotWaveforms

Description

Plots non-interactive wfSignal object waveform.

Syntax

```
wf::plotWaveforms <wfSignal: [wfSignal]> [-color <string>] -mode  
<string | wfCustomPlotMode> [-type <enum>] [-resultsDir <string>]  
[-filename <string>] [-resultType <string>] [-analysisName <string>]  
[-callback <string>] [-bins <int>] [-runType <enum>] [-sessionName  
<string>] [-testbenchName <string>] [-job <string | xtJob>] [-jobGroup  
<xtJobGroup>] [-historyIndex <int>]
```

Arguments

`wfSignal`

Target signals to plot.

`-color <string>`

Color to use for plotting.

`-mode <string | wfCustomPlotMode>`

Waveview plotting mode. Valid values: new, append, replace, newPanel, active, custom.

`-type`

Waveview graph type (overrides any signal settings). Value values: auto, constell , eyediag, histogram, linear, polar, scatter, smith, spectrum, stateye. (Default: auto)

`-resultsDir <string>`

Directory where derived signals are stored.

`-filename <string>`

Filename in which the derived signals are stored.

Default: "derived.wdf".

`-resultType <string>`

Result type of the plotted signal from PrimeWave Design Environment resultsMap.xml file.

`-analysisName <string>`

Analysis Name of the plotted signal from PrimeWave Design Environment resultsMap.xml file.

`-callback <string>`

Tcl procedure to call when plotting succeeds.

`-bins <int>`

The number of bins used for plotting histograms. (Default: 10)

`-runType`

Simulation run type. Valid values: corner, monteCarlo, nominal, parametric. (Default: nominal)

`-sessionName`

Session name of the signal.

`-testbenchName`

Testbench name of the signal.

`-job <string | xtJob>`

The viewer job.

`-jobGroup`

Parent job group for waveform viewer job.

`-historyIndex`

PrimeWave Design Environment history index number. (Default: -1).

Returns

<none>

Errors

Invalid wfSignal object.

Examples

```
set signal [wf::createSignal clk]
set value 0
for {set i 0} {$i<100} {incr i} {
    wf::appendData $signal -x [expr $i*1e-9] -y $value
    if {0==[expr $i%10]} {
        if {0==$value} {
            set value 1
        } else {
            set value 0
        }
    }
}
wf::plotWaveforms $signal -mode new
foreach format {WDF Table VCD} {
    set ext [string tolower $format]
    set fid [wf::openFile clk.${ext} -format $format -accessMode write]
    wf::saveSignal $signal -file $fid
    wf::closeFile $fid
}
```

wf::raiseViewer

Description

Raises the current waveform viewer to desktop. If no viewer is running, this command does not do anything.

Syntax

```
wf::raiseViewer [-job <xtJob>] [-raiseBackgroundViewer <bool>]
```

Arguments

`-job <xtJob>`

The viewer job.

`-raiseBackgroundViewer`

Raise the viewer window when it is already running in background. (Default: true)

Returns

<none>

Errors

Viewer raise Tcl error.

wf::redrawViewer

Description

Redraws a waveform viewer.

Syntax

```
wf::redrawViewer [-job <xtJob>] [-timeout <int>]
```

Arguments

`-job`

Viewer job

`-timeout`

Timeout (negative value for non-blocking) (Default: -1)

Returns

<none>

wf::removeFunctionsFromCategory

Description

Removes functions from a category.

Syntax

```
wf::removeFunctionsFromCategory <functions: [string | wfFunction]>  
-category <string | wfFunctionCategory>
```

Arguments

<string | [wfFunction](#)>

A list of function names or functions to remove from the category.

-category <string> | [wfFunctionCategory](#)

The category or name of the category.

Returns

<none>

Errors

- The category specified by name does not exist.
- A function specified by name is not in the given category.

wf::savePrefs

Description

Saves the waveform viewer preferences to a file.

Syntax

```
wf::savePrefs <filename: string> -changedOnly <bool>
```

Arguments

filename: string

The preference filename.

-changedOnly

Enables saving changed preference.

Returns

<none>

wf::saveSession

Description

Saves the waveform viewer session.

Syntax

```
wf::saveSession <filename: string> -relativePath <string> [-testbenchName  
  <string>] [-sessionName <string>] [-allTestbenches <bool>] [-isGlobal  
  <bool>]
```

Arguments

filename: string

The session file name.

-relativePath <string>

The relative path for result files.

-testBenchName <string>

The testbench name.

-sessionName

Session name. (Default is:)

-allTestbenches

Save plots of all testbenches. (Default is: 0)

-isGlobal

Save plot mode as global mode. (Default is: 0)

Returns

<none>

wf::saveSignal

Description

Saves the target wfSignal to a write-only wfDataFile object. The signals to be saved are not exported to the wfDataFile object until the file is closed, so that all saved wfSignal objects can be written to the target wfDataFile file at the same time.

Syntax

```
wf::saveSignal <wfSignal: wfSignal> [-file <wfDataFile>]
```

Arguments

`wfSignal`

`wfSignal` to save.

`-file wfDataFile`

Target `wfDataFile` object.

Returns

<none>

Errors

- out of memory.
- invalid target `wfDataFile` object (ex. read-only file).

Examples

Example 1

```
set report ""
set resultsFile
"./latestResults/simulation/PrimeSimSpice/PrimeSimSPICE/corners/resul
ts/resultsMap.xml"
set fid [wf::openFile $resultsFile -resultType tran -analysisName tran]
set variableConditions [db::getAttr fid.variableConditions]
foreach signalName [db::getAttr fid.signalNames] {
    append report [string repeat # 80] "\n"
    append report "# Signal $signalName\n"
    append report [string repeat # 80] "\n"

    set index 0
    append report "    Params [lindex $variableConditions $index]\n"
    set signal [wf::findSignal $signalName -file $fid]
    set scan [wf::createScan $signal]

    set sf [wf::openFile ${signalName}.table -format Table -accessMode
write]
    wf::saveSignal $signal -file $sf
    wf::closeFile $sf

    set t [wf::scan $scan -to first]
    while {$t} {
        append report "                [format %-20s%s [db::getAttr scan.x]
[db::getAttr scan.y]] \n"
        set t [wf::scan $scan -to next]
        if {2==$t} {
            incr index
            append report "    Params [lindex $variableConditions
$index]\n"
```



```
        }
    }
}
wf::closeFile $fid

set fh [open "signals.txt" "w"]
puts $fh $report
close $fh
xt::openTextViewer -files signals.txt
```

Example 2

```
set signal [wf::createSignal clk]
set value 0
for {set i 0} {$i<100} {incr i} {
    wf::appendData $signal -x [expr $i*1e-9] -y $value
    if {0==[expr $i%10]} {
        if {0==$value} {
            set value 1
        } else {
            set value 0
        }
    }
}
wf::plotWaveforms $signal -mode new
foreach format {WDF Table VCD} {
    set ext [string tolower $format]
    set fid [wf::openFile clk.${ext} -format $format -accessMode write]
    wf::saveSignal $signal -file $fid
    wf::closeFile $fid
}
```

wf::scan

Description

Traverses a wfScan object from the current scan location. wf::scan returns 0 if the traversal action reaches the end of the data range, or the "real" x-axis value is outside of the data range.

Syntax

```
wf::scan <wfScan: wfScan> -to <string>
```

Arguments

wfScan

Target wfScan.

-to <string>

The action string. Valid values: next, prev, first, last, or a <real> value as the x-axis value.

Returns

1 on successful configuration. 0 otherwise (<bool>).

Errors

invalid wfScan object.

Examples

```
set report ""
set resultsFile
    "./latestResults/simulation/PrimeSimSpice/PrimeSimSPICE/corners/resul
ts/resultsMap.xml"
set fid [wf::openFile $resultsFile -resultType tran -analysisName tran]
set variableConditions [db::getAttr fid.variableConditions]
foreach signalName [db::getAttr fid.signalNames] {
    append report [string repeat # 80] "\n"
    append report "# Signal $signalName\n"
    append report [string repeat # 80] "\n"

    set index 0
    append report "    Params [lindex $variableConditions $index]\n"
    set signal [wf::findSignal $signalName -file $fid]
    set scan [wf::createScan $signal]

    set sf [wf::openFile ${signalName}.table -format Table -accessMode
write]
    wf::saveSignal $signal -file $sf
    wf::closeFile $sf

    set t [wf::scan $scan -to first]
    while {$t} {
        append report "                [format %-20s%s [db::getAttr scan.x]
[db::getAttr scan.y]] \n"
        set t [wf::scan $scan -to next]
        if {2==$t} {
            incr index
            append report "    Params [lindex $variableConditions
$index]\n"
        }
    }
}
wf::closeFile $fid

set fh [open "signals.txt" "w"]
puts $fh $report
```

```
close $fh  
xt::openTextViewer -files signals.txt
```

wf::setDataDirectory

Description

Sets Waveform Viewer open waveform data directory

Syntax

```
wf::setDataDirectory <filepath: string>
```

Arguments

filepath

File Data Directory.

Returns

<none>

wf::setPrefValue

Description

Sets the waveform viewer preference value.

Syntax

```
wf::setPrefValue <name: string> -value <string>
```

Arguments

name: string

The preference name.

-value <string>

The preference value.

Returns

<none>

wf::setReaderAPIPrefValue

Description

Sets readerAPI preference value.

Syntax

```
wf::setReaderAPIPrefValue <name: string> -value <int>
```

Arguments

name

Preference name

-value

Preference value

Returns

<none>

wf::setSignalAttribute

Description

Sets the specified attribute for a signal.

Syntax

```
wf::setSignalAttribute <wfSignal: string | wfSignal> [-type <string>]  
[-value <string>]
```

Arguments

wfSignal

Source wfSignal object

-type

Attribute type. Valid values: alias, yunit, xunit, xview, yview, spectrum. (Default:)

-value

The attribute value (Default:)

Returns

<int> : The status of set signal attribute.

wf::storeExpressionResult

Description

Stores a signal or the scalar value by name for use in the PrimeWave Design Environment output expressions.

Syntax

```
wf::storeExpressionResult <value: [float | wfSignal]> (-resultsDir  
  <string> | -testbench <saTestbench>) -name <string> [-resultType  
  <string>] [-analysisName <string>]
```

Arguments

value

Signal value scalar to store.

-name

The name of the stored expression.

-resultsDir

The results directory for the expression result.

-testbench

Testbench.

-resultType

The result type for the expression result.

-analysisName

The analysis name for the expression result.

Returns

<none>

wf::transformParamValue

Description

Transforms the parameter value to the stored signal format.

Syntax

```
wf::transformParamValue <string: string>
```

Arguments

`string`

The value to be transformed.

Returns

`<string>` : Return the transformed value or empty string when transformation failed.

wf::unloadSignal

Description

Unload waveform data of a signal. This command is useful to free up memory when the waveform data of signal is no longer needed. Doing so allows the same memory resource to be sequentially used by multiple signals.

Syntax

```
wf::unloadSignal <wfSignal | wfSignalList: wfSignal>
```

Arguments

`wfSignal`

Target wfSignal.

Returns

`<none>`

Errors

Invalid wfSignal object.

wf::updateViewerKeyBindings

Description

Calls back to notify that the waveform viewer updated its key bindings.

Syntax

```
wf::updateViewerKeyBindings
```

Returns

`<none>`

wf::updateViewerPrefs

Description

Calls back to notify that the waveform viewer updated its preferences.

Syntax

```
wf::updateViewerPrefs
```

Returns

<none>

wf::viewerExited

Description

Notifies that the waveform viewer exited.

Syntax

```
wf::viewerExited
```

Returns

<none>

Enumerations

Table 35 Enumerations

Name	Values	Description
enGraphType	eyediag histogram linear polar scatter smith spectrum	Waveform graph type.
enPlotMode	new append replace newPanel	Waveform plotting mode.
enScanType	change point rise fall cross deltaX deltaY	Waveform traversal type.

Table 35 Enumerations (Continued)

Name	Values	Description
enWfArgumentType	boolean enum filePath instTerm instance integer net numeric pick real signalName string terminal	This describes the argument type for function arguments. The argumentType is meant to be used by the Results Analyzer argument pane. The "pick" value indicates that the argument can be obtained by a schematic or layout or text selection operation. The "net", "terminal", "instance", and "instTerm" values are all specific design selections restricting the allowed type. "signalName" implies net on terminal or instTerm and net on wire.
enWfDataType	analog logic complex signal scalar	This describes the allowable input type for an argument, or the result type of a function.
enWfFunctionType	dataAccess point rf scalarMeasure waveformConversion	This describes the function type as described above.
enWfFileFormat	Unknown Table Tr0 VPD WDF Raw NW Tout Hout VCD COU PSF WSF WDB TI-punch WV CSDF Vector MTX DAT Saber fsdb JWDB Listing ADS WFM LeCroy Tektronix Agt S2K Lynx ALG MDS Data MICS SDIF SAE AGT	Format type for a wfDataFile.
enWfFileType	read write	File read/write type.
enWfSignalType	analogi analogv anytype complex complexi logic notype	Value type for a wfSignal. anytype is only used by wf::getSignals.

Objects

This section covers the following:

- [wfDataFile](#)
- [wfFunction](#)

- [wfFunctionArgument](#)
- [wfFunctionArgumentGroup](#)
- [wfFunctionCategory](#)
- [wfMacro](#)
- [wfScan](#)
- [wfSignal](#)

wfDataFile

A wfDataFile represents a waveform data file on a disk. A wfDataFile can be open for read or write purpose, but not for both read and write via the same wfDataFile handle. This object can be also destroyed with db::destroy which closes the data file.

Table 36 *Attributes*

Name	Type	Access	Description
filePath	string	Read-only	Waveform file path.
accessMode	<i>enWFileType</i>	Read-only	Waveform readOnly/write type.
delimiter	string	Read-only	Hierarchy separator for signal names.
format	<i>enWFileFormat</i>	Read-only	Waveform file format.
nSignals	int	Read-only	Number of signals.
nSweeps	int	Read-only	Number of sweeps.
variableNames	[string]	Read-only	List of variable names.
variableConditions	[string]	Read-only	List of variable conditions, one string for each sweep trace.
nSubfiles	int	Read-only	Number of sub-files.
signalNames	string	Read-only	The list of all signal names.
resultType	string	Read-only	Result type of signal when it comes from PrimeWave Design Environment resultsMap.xml file.

Table 36 *Attributes (Continued)*

Name	Type	Access	Description
analysisName	string	Read-only	Analysis name of signal when the signal comes from PrimeWave Design Environment resultsMap.xml file.

wfFunction

This object represents a function. The function is created with the `wf::createFunction` command and registered within the CDE subsystem.

Table 37 *Attributes*

Name	Type	Access	Description
name	string	Read-only	The name of the function.
builtin	bool	Read-only	True if the function is built into the application binary. False if it is implemented in Tcl.
description	string	Read-only	A text string describing the function.
exclusive	{wfFunctionArgumentGroup}	Read-only	These mutually exclusive arguments for the function.
functionType	<i>enWfFunctionType</i>	Read-only	This describes the type of the function.
arguments	{wfFunctionArgument}	Read-only	These are the arguments that the function accepts.

wfFunctionArgument

This object represents the specification of a function argument. These objects may be created with the `wf::createFunctionArgument` command and cannot be destroyed with `db::destroy`. Their lifespan is determined by the Tcl objects and functions reference them.

Table 38 *Attributes*

Name	Type	Access	Description
name	string	Read-only	The name of the function argument.
optional	bool	Read-only	True if the argument is optional.
description	string	Read-only	A text string describing the argument.
dataTypes	{enum-name}	Read-only	A list of allowed data types for the argument.
validValues	{string}	Read-only	The valid values for the argument. This attribute will be "" unless the argumentType is "enum".
defaultValue	string	Read-only	Default value for optional arguments. This will be "" if the default value was not provided.
argumentType	<i>enWfArgumentType</i>	Read-only	A classifier for the argument.

wfFunctionArgumentGroup

This object represents a set of mutually exclusive function arguments. Only one of the arguments in the group may be used when calling the function that uses the group. These objects are created with the `wf::createFunctionArgumentGroup` command and cannot be destroyed with `db::destroy`. Their lifespan is determined by the Tcl objects and functions that reference them.

Table 39 *Attributes*

Name	Type	Access	Description
optional	bool	Read-only	This argument group is optional.
arguments	{string}	Read-only	The list of string names for the arguments in the group.

wfFunctionCategory

This object represents a category of functions. Functions can be placed in multiple categories at once.

Table 40 *Attributes*

Name	Type	Access	Description
name	string	Read-only	The name of the category.
functions	{wfFunction}	Read-only	The functions contained in the category.

wfMacro

A wfMacro object represents a macro that can be used by name in expressions

Table 41 *Attributes*

Name	Type	Access	Description
name	string	Read-only	The name of the macro.
expression	string	Read/Write	The contents of the macro.
description	string	Read/Write	A textual description of the macro.
arguments	{string}	Read-only	A list of the argument names for the macro. These are updated whenever the "expression" attribute changes.

wfScan

A wfScan is an abstract object for data point traversal of a signal. Multiple wfScan objects can be created for the same signal

Table 42 *Attributes*

Name	Type	Access	Description
scanType	enScanType	Read/Write	Signal traversal type.
threshold	float	Read/Write	Threshold level.

Table 42 *Attributes (Continued)*

Name	Type	Access	Description
x	float	Read-only	x-value at current location.
y	float	Read-only	y-value at current location.
i	float	Read-only	Imaginary value at current location.
states	string	Read-only	Logic bus string at current location.

wfSignal

A wfSignal represents a signal in a waveform file.

Table 43 *Attributes*

Name	Type	Access	Description
name	string	Read-only	Signal name identifier.
signalType	<i>enWFSigType</i>	Read-only	Signal type.
file	<i>wfDataFile</i>	Read-only	Parent file.
width	int	Read-only	Number of bits for real or logic bus.
alias	string	Read/Write	Signal name alias.
nSweeps	int	Read-only	Number of sweeps.
variableNames	{string}	Read-only	List of variable names.
variableConditions	{string}	Read-only	List of variable conditions, one string for each sweep trace.
unit	string	Read-only	Unit of signal values.
xUnit	string	Read-only	Unit of x-axis of signal.

Preferences

[Table 44](#) lists PrimeWave Design Environment wf general preferences. Preferences use camelBack notation, where the first character is always a lowercase character

Table 44 Waveform Preferences

Name	Type	Scope	Default	Description
wfWVUUseDefaultXVar	bool	user	0	When set to 1, use the default X-variable as the X-axis of the plot. This is useful when multiple parameter sweeps are present and enables user to plot across original x-axis instead of the first sweep parameter.
wfAbbreviateHistoryName	bool	user	false	Abbreviate the history name when its prefix matches the default. Valid values: true, false
wfCCKeyBindingFilePath	string	user		Set keybindings settings file path.
wfGroupNewSignalsSeparately	bool	user	false	Separates groups of plotted signals. This option is ignored if <code>wfPlotNewSignalsAsGrouped</code> is false. Valid values: true, false
wfOpenViewerInNewWindowFrame	bool	user	true	Show WaveView window in new window frame.
wfPlotNewSignalsAsGrouped	bool	user	true	Plots new signals into one panel (grouped) rather than one signal per panel (stacked). Valid values: true, false
wfUseSAEGeometry	bool	user	false	Control waveform viewer starting window geometry from the PrimeWave Design Environment. Valid values: true, false
wfUseSAEPrefs	bool	user	true	Use PrimeWave Design Environment preferences to control waveform viewer settings. Set Custom WaveView preferences by entering <code>db::setPrefValue wf</code> at the Console command line and pressing the Tab key to open a list of available preferences. Valid values: true, false
wfUseSEKeyBindings	bool	user	true	Enable the waveform tool to use SE key binding file. Valid values: true, false
wfViewerGeometry	string	user	1024x768+200+200	Waveform viewer starting window geometry.
wfWVA2DCenterThreshold	float	user	2.5	
wfWVA2DHighThreshold	float	user	4	
wfWVA2DLowThreshold	float	user	1	
wfWVA2DSignalThreshold	bool	user	true	Valid values: true, false

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVACEFilePath	string	user		Initial ACE script file path.
wfWVAddTopLevelForFsdb	bool	user	false	Specify if always adding "toplevel" hierarchy for FSDB files. Valid values: true, false
wfWVAdjustSmallYRange	bool	user	true	Show straight line when y range difference is at or after the 9th digit Valid values: true, false
wfWVAliasBracket	bool	user	true	Valid values: true, false
wfWVAliasSignalNameOnly	bool	user	false	Valid values: true, false
wfWVAMSRealPwcFSDB	bool	user	false	Display Real/AMS WReal Type Signals in PWC by Default for FSDB File. Valid values: true, false
wfWVAnalogPanelHeight	int	user	120	
wfWVArchiveDataOnCrash	bool	user	false	Valid values: true, false
wfWVAutoConnectSplitFiles	bool	user	true	Valid values: true, false
wfWVAutoSwitchHorz	enWVAutoSwitchHorz	user	off	Automatically Switch to Row/Column Mode When Plotting Signals With Different X Ranges Valid values: on off
wfWVAutoXExtend	bool	user	false	Valid values: true, false
wfWVAutoXExtendDig	bool	user	true	Valid values: true, false
wfWVAutoYAxes	enWVAutoYAxes	user	off	Sets automatic dual Y-axes for mixed I/V signals.
wfWVAutoYMargin	bool	user	false	Automatically adjusts Y axis full scale display margin to show better tick labels. Valid values: true, false
wfWVAutoYWidth	enWVAutoYWidth	user	off	Automatically adjusts the y-axis width based on the length of labels.
wfWVAxisFont	string	user	0	Sets the default font for axis labels. The value is a string, in the format of {<fontName>} <fontSize> [regular bold]
wfWVBackingStore	string	user	internal	
wfWVBarGripScroll	bool	user	false	Valid values: true, false
wfWVBrowserWidth	int	user	250	Sets window width for the browsers. (All five left browsers.)

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVBrowserWidthLast	bool	user	false	Specify if using the signal browser width used in last Custom WaveView session Valid values: true, false
wfWVButtonAddHCursor	bool	user	false	Valid values: true, false
wfWVCalcEng	bool	user	false	Display scalar results in engineering notation. Valid values: true, false
wfWVCaseSensitiveTr0	bool	user	false	Valid values: true, false
wfWVCdsLinkPlotMode	enWVCdsLinkPlotMode	user	replace	Replaces or appends a plotted signal. This preference is only available when the Custom WaveView tool is started in CDS-Link mode.
wfWVCdsLinkUpdateMode	enWVCdsLinkUpdateMode	user	append	Replaces or appends a plotted signal when updating waveform files. This preference is only available when the Custom WaveView tool is started in CDS-Link mode.
wfWVCenterAxisLabel	bool	user	false	Places axis label in the middle and parallel with axis. Valid values: true, false
wfWVCheckXRangeForYValInACE	bool	user	false	Check Xrange for Getting Yval in ACE. Valid values: true, false
wfWVClampACPhase	bool	user	true	Valid values: true, false
wfWVClickMoveCursor	bool	user	true	Moves the cursor to the mouse-click position. Valid values: true, false
wfWVConvertSToYZ	bool	user	false	Valid values: true, false
wfWVCursorFont	string	user	0	Sets the default font for cursors. The value is a string, in the format of {<fontName>}<fontSize> [regular bold]
wfWVCursorType	enWVDefaultACXType	user	vertical	Default Cursor Type. Valid values: vertical horizontal cross
wfWVCycleColorByPanel	enWVCycleColorByPanel	user	panel+waveview	Selects color cycle mode. In the panel mode, the default line color restarts at color 0 for each panel.
wfWVD2AFallSlew	float	user	1e-11	
wfWVD2AFullExt	bool	user	true	Valid values: true, false
wfWVD2AHighValue	float	user	3.3	

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVD2ALowValue	float	user	0	
wfWVD2ARiseSlew	float	user	1e-11	Defines the rise slew for the D/A conversion process.
wfWVD2AXToI	bool	user	true	Valid values: true, false
wfWVDdefaultACMATCHXScale	enWVDef aultACM ATCHXS cale	user	db10	Sets the default x-axis type for ACMATCH signals. Valid values: linear, log, db, db10, auto
wfWVDdefaultACMATCHYScale	enWVDef aultACM ATCHYS cale	user	auto	Sets the default y-axis type for ACMATCH signals. Valid values: linear, log, db, db10, auto
wfWVDdefaultACStack	enWVDef aultACSt ack	user	magphase	Sets the default display mode for AC signals. Valid values: complex magphase realimag magdegree
wfWVDdefaultACXType	enWVDef aultACXT ype	user	log	Sets the default x-axis type for AC signals.
wfWVDdefaultACYType	enWVDef aultACYT ype	user	linear	Sets the default y-axis type for AC signals.
wfWVDdefaultDCMATCHXScale	enWVDef aultDCM ATCHXS cale	user	db10	Sets the default x-axis type for DCMATCH signals. Valid values: linear, log, db, db10, auto
wfWVDdefaultDCMATCHYScale	enWVDef aultDCM ATCHYS cale	user	auto	Sets the default y-axis type for DCMATCH signals. Valid values: linear, log, db, db10, auto
wfWVDdefaultENVLPXScale	enWVDef aultENVL PXScale	user	db10	Sets the default x-axis type for ENVLP signals.
wfWVDdefaultENVLPYScale	enWVDef aultENVL PYScale	user	auto	Sets the default y-axis type for ENVLP signals.
wfWVDdefaultFFTDDisplay	enWVDef aultFFTD isplay	user	pwl	Sets the default display type for FFT signals. Valid values: pwl spectrum

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVDefaultFFTXScale	enWVDefaultFFTXScale	user	linear	Sets the default x-axis type for FFT signals.
wfWVDefaultFFTYScale	enWVDefaultFFTYScale	user	db	Sets the default y-axis type for FFT signals.
wfWVDefaultHBACXScale	enWVDefaultHBACXScale	user	db10	Sets the default x-axis type for HBAC signals.
wfWVDefaultHBACYScale	enWVDefaultHBACYScale	user	auto	Sets the default y-axis type for HBAC signals.
wfWVDefaultHBNOISEXScale	enWVDefaultHBNOISEXScale	user	db10	Sets the default x-axis type for HBNOISE signals.
wfWVDefaultHBNOISEYScale	enWVDefaultHBNOISEYScale	user	auto	Sets the default y-axis type for HBNOISE signals.
wfWVDefaultHBSPXScale	enWVDefaultHBSPXScale	user	db10	Sets the default x-axis type for HBSP signals.
wfWVDefaultHBSPYScale	enWVDefaultHBSPYScale	user	auto	Sets the default y-axis type for HBSP signals.
wfWVDefaultHBSTBXScale	enWVDefaultHBSTBXScale	user	db10	Sets the default x-axis type for HBSTB signals.
wfWVDefaultHBSTBYScale	enWVDefaultHBSTBYScale	user	auto	Sets the default y-axis type for HBSTB signals.
wfWVDefaultHBXFXScale	enWVDefaultHBXFXScale	user	db10	Sets the default x-axis type for HBXF signals.
wfWVDefaultHBXFYScale	enWVDefaultHBXFYScale	user	auto	Sets the default y-axis type for HBXF signals.
wfWVDefaultHBXScale	enWVDefaultHBXScale	user	db10	Sets the default x-axis type for HB signals.

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVDefaultHBYScale	enWVDefaultHBYScale	user	auto	Sets the default y-axis type for HB signals.
wfWVDefaultHistogramBinSize	int	user	10	
wfWVDefaultHistogramSingle	bool	user	true	Show single histogram for family data by default. Valid values: true, false
wfWVDefaultINCLUDEXScale	enWVDefaultINCLUDEXScale	user	db10	Sets the default x-axis type for INCLUDE signals. Valid values: linear, log, db, db10, auto
wfWVDefaultINCLUDEYScale	enWVDefaultINCLUDEYScale	user	auto	Sets the default y-axis type for INCLUDE signals. Valid values: linear, log, db, db10, auto
wfWVDefaultNOISEXScale	enWVDefaultNOISEXScale	user	db10	Sets the default x-axis type for NOISE signals. Valid values: linear, log, db, db10, auto
wfWVDefaultNOISEYScale	enWVDefaultNOISEYScale	user	auto	Sets the default y-axis type for NOISE signals. Valid values: linear, log, db, db10, auto
wfWVDefaultPACXScale	enWVDefaultPACXScale	user	db10	Sets the default x-axis type for PAC signals.
wfWVDefaultPACYScale	enWVDefaultPACYScale	user	auto	Sets the default y-axis type for PAC signals.
wfWVDefaultPanelsPerRow	int	user	4	
wfWVDefaultPNOISEXScale	enWVDefaultPNOISEXScale	user	db10	Sets the default x-axis type for PNOISE signals.
wfWVDefaultPNOISEYScale	enWVDefaultPNOISEYScale	user	auto	Sets the default y-axis type for PNOISE signals.
wfWVDefaultPSPXScale	enWVDefaultPSPXScale	user	db10	Sets the default x-axis type for PSP signals.

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVDefaultPSPYScale	enWVDefaultPSPYScale	user	auto	Sets the default y-axis type for PSP signals.
wfWVDefaultPSSXScale	enWVDefaultPSSXScale	user	db10	Sets the default x-axis type for PSS signals.
wfWVDefaultPSSYScale	enWVDefaultPSSYScale	user	auto	Sets the default y-axis type for PSS signals.
wfWVDefaultPSTBXScale	enWVDefaultPSTBXScale	user	db10	Sets the default x-axis type for PSTB signals.
wfWVDefaultPSTBYScale	enWVDefaultPSTBYScale	user	auto	Sets the default y-axis type for PSTB signals.
wfWVDefaultPXFXScale	enWVDefaultPXFXScale	user	db10	Sets the default x-axis type for PXF signals.
wfWVDefaultPXFYScale	enWVDefaultPXFYScale	user	auto	Sets the default y-axis type for PXF signals.
wfWVDefaultPZXScale	enWVDefaultPZXScale	user	db10	Sets the default x-axis type for PZ signals. Valid values: linear, log, db, db10, auto
wfWVDefaultPZYScale	enWVDefaultPZYScale	user	auto	Sets the default y-axis type for PZ signals. Valid values: linear, log, db, db10, auto
wfWVDefaultSENSXScale	enWVDefaultSENSXScale	user	db10	Sets the default x-axis type for SENS signals. Valid values: linear, log, db, db10, auto
wfWVDefaultSENSYScale	enWVDefaultSENSYScale	user	auto	Sets the default y-axis type for SENS signals. Valid values: linear, log, db, db10, auto
wfWVDefaultSPXScale	enWVDefaultSPXScale	user	db10	Sets the default x-axis type for SP signals. Valid values: linear, log, db, db10, auto
wfWVDefaultSPYScale	enWVDefaultSPYScale	user	auto	Sets the default y-axis type for SP signals. Valid values: linear, log, db, db10, auto

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVDefaultSTBXScale	enWVDefaultSTBXScale	user	db10	Sets the default x-axis type for STB signals. Valid values: linear, log, db, db10, auto
wfWVDefaultSTBYScale	enWVDefaultSTBYScale	user	auto	Sets the default y-axis type for STB signals. Valid values: linear, log, db, db10, auto
wfWVDefaultTranXType	enWVDefaultTranXType	user	linear	Sets the default x-axis type for real type signals.
wfWVDefaultTranYType	enWVDefaultTranYType	user	linear	Sets the default y-axis type for real type signals.
wfWVDefaultXFXScale	enWVDefaultXFXScale	user	db10	Sets the default x-axis type for XF signals. Valid values: linear, log, db, db10, auto
wfWVDefaultXFYScale	enWVDefaultXFYScale	user	auto	Sets the default y-axis type for XF signals. Valid values: linear, log, db, db10, auto
wfWVDefaultZoomDir	enWVDefaultZoomDir	user	xyzoom	Specify the default zoom direction. Valid values: xyzoom, xzoom, yzoom
wfWVDisableAutoCloseMsg	bool	user	false	Disables auto close hint message box Valid values: true, false
wfWVDisableAutoCopyClipboard	bool	user	false	Disable Auto-Copy to Clipboard when Selecting Item Valid values: true, false
wfWVDisableAutoStrip0	bool	user	false	Disable Auto Strip Off Zeros Valid values: true, false
wfWVDisableReloadWdfConfirm	bool	user	false	Disables the waveform reloading confirmation dialog box. Valid values: true, false
wfWVDisableStarExpandTree	bool	user	false	Disable Expanding Hierarchy Tree With Key-in '*'. Valid values: true, false
wfWVDisableUpdateEquation	bool	user	false	Disable Update Equation When Updating Signals. Valid values: true, false
wfWVDisableUpdateSignal	bool	user	false	Disables Update Loaded Signals when plotting new signal. Valid values: true, false

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVDMDiffMoveLabel	bool	user	false	Specifies if the label of difference measurement move independently.
wfWVDMScale	bool	user	false	Valid values: true, false
wfWVDMHighLogic	float	user	3.3	Sets the default high logic level for dynamic meters.
wfWVDMHighMargin	float	user	90	Sets the default high slew margin for dynamic meters.
wfWVDMLowLogic	float	user	0	Sets the default low logic level for dynamic meters.
wfWVDMLowMargin	float	user	10	Sets the default low slew margin for dynamic meters.
wfWVDMResultPanelScale	bool	user	false	Valid values: true, false
wfWVDragPlotLine	bool	user	false	Enables canvas line drag-and-drop. Valid values: true, false
wfWVDrawingToolFont	string	user	normal	Sets the default font for drawing tools. The value is a string, in the format of {<fontName>} <fontSize> [regular bold].
wfWVDumpFilePath	string	user		Initial screen dump path.
wfWVDynamicFilter	bool	user	true	Enables or disables dynamic filtering in the Signal List. Valid values: true, false
wfWVEditor	string	user	vi	
wfWVEnableLineSelection	bool	user	true	Enable selecting Signal by Clicking on Plotted Line.
wfWVEnableMulClickItems	bool	user	false	Support Multiple Selection for Signals and Panels with Single Click Valid values: true, false
wfWVEnablePanelSelection	bool	user	false	Valid values: true, false
wfWVEnableWVHighlight	bool	user	true	Highlighting Signal when Mouse Hovers on its Name Valid values: true, false
wfWVExitConfirm	bool	user	true	Disables the application exiting confirmation dialog box.
wfWVExportNotation	bool	user	false	Using Scientific Notation when exporting scalar values. Valid values: true, false

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVExtendWaveform	bool	user	false	Valid values: true, false
wfWVFastVNCMode	bool	user	false	Enable VNC Display Accelerating Mode Valid values: true, false
wfWVFilterByXRange	bool	user	false	Filters out data points whose X value is greater than the simulation max time for FSDB files. Valid values: true, false
wfWVFlattenSegs	bool	user	true	Valid values: true, false
wfWVFlattenSignalPointSweep	bool	user	true	Valid values: true, false
wfWVGridBrightness	enWVGri dBrightn ess	user	normal	Sets the background grid brightness for waveviews.
wfWVGridDefault	enWVGri dDefault	user	on	Sets default grid on/off mode.
wfWVGroupDisplayOrder	enWVGri oupDispl ayOrder	user	file	Sets the signals (from grouped files) order during the drag-and-drop display operations.
wfWVGuiColor	enWVGui Color	user	bright	Select default GUI color tone.
wfWVGuiFont	enWVGui Font	user	small	Sets preferred GUI font size.
wfWVHideCrossLabelXValue	bool	user	false	Hide X values on the Value Labels at V-Cursor Crossing Points by default.
wfWVHideCursorDistance	bool	user	false	Hides all distances between cursors. Valid values: true, false
wfWVHidePanelDiv	bool	user	false	Valid values: true, false
wfWVHideRibbonMenu	bool	user	false	Hides the ribbon menu. Valid values: true, false
wfWVHideSignalType	bool	user	false	Hide the signal type. Valid values: true, false
wfWVHierSensitiveFilter	bool	user	false	Enables sensitive hierarchy filtering. Valid values: true, false
wfWVHorizontalSliderStep	int	user	50	Controls how fast the display pans left or right via the left or right keys or the waveview slider arrows.
wfWVHorzPanelHeight	int	user	80	

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVIconizable	bool	user	true	Valid values: true, false
wfWVIMax	float	user	0.001	Specify the maximum current signal value used in Y Full Range
wfWVIMin	float	user	0	Specify the minimum current signal value used in Y Full Range
wfWVIncludeSubSig	bool	user	false	Include Sub-level Signals in Signal List Valid values: true, false
wfWVInfValue	float	user	1.00E+50	Specify the value used for plotting Inf values.
wfWVInitXYMode	enWVInitXYMode	user	hysel	Selects the default orientation for XY-panels.
wfWVKeepSignalSearchString	bool	user	false	Keep search string in the Signal List filter. Valid values: true, false
wfWVLeftButtonAction	enWVLeftButtonAction	user	zoom	Sets default action for left mouse button (LMB). In zoom mode, box-zoom operation is the default action when LMB is pressed and dragged. If LMB is released without any drag action, the main cursor (if it exists) is moved to the mouse pointer location. In cursor mode, pressing LMB moves the main cursor to the pointer location. In both modes, if LMB is pressed near a cursor, the cursor is grabbed and becomes the main cursor.
wfWVLimitZoomRange	bool	user	false	Valid values: true, false
wfWVLinesPerPanel	int	user	0	
wfWVLineThickness	enWVLineThickness	user	1	Sets the default waveform line thickness. Valid values: 1, 2, 3, 4, 5, 6, 7
wfWVLoadDataAtOpen	bool	user	false	Valid values: true, false
wfWVLockColor	bool	user	false	Valid values: true, false
wfWVLogicCursorSnap	bool	user	true	Valid values: true, false
wfWVLogicGlitchHighlight	bool	user	true	Valid values: true, false
wfWVLogicPanelHeight	int	user	24	
wfWVLogicRealPwcFsdb	bool	user	true	Display Logic Real Type Signals in PWC by Default for FSDB File Valid values: true, false

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVLogicStyleDefault	enWVLo gicStyleD efault	user	vcd	Specifies the text style for logic signal values.
wfWVLoopLineStylesSweep	bool	user	false	Valid values: true, false
wfWVMaxLogSpan	int	user	25	Defines the maximum log scale span in decades.
wfWVMaxVisiblePanels	int	user	0	
wfWVMeasFileXStart1	bool	user	false	.meas files index X values start from 1 instead of 0. Valid values: true, false
wfWVMergeDigitalTime	bool	user	false	Ignores continuous identical logic values. Valid values: true, false
wfWVMinPanelHeight	int	user	20	
wfWVNormalEyeDiagramCursor	bool	user	false	Adds normal cursor in the EyeDiagram panel. Valid values: true, false
wfWVNotShowVhdlProcesses	bool	user	true	Valid values: true, false
wfWVOkButtonAutoCenter	bool	user	false	Valid values: true, false
wfWVPanelFSMargin	int	user	0	Displaying Margin for Full Scale Panels
wfWVPanelFSMarginX	int	user	0	Displaying Margin for x-axis Full Scale Panels
wfWVPanelFSMarginY	int	user	0	Displaying Margin for y-axis Full Scale Panels
wfWVPanelModeOnly	bool	user	false	Enable panel selection only. Valid values: true, false
wfWVPanelSpacing	int	user	0	
wfWVPlotSignalBottomPanel	bool	user	false	Valid values: true, false
wfWVPlotSinglePointSweepOn2D	bool	user	false	Plot Single Point Sweep Signals on 2D Panel by Default Valid values: true, false
wfWVPrecisionDigits	int	user	3	
wfWVPrintCommand	string	user		
wfWVPrinterDevice	string	user		
wfWVPrintTitle	string	user		

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVPrivateColorMap	bool	user	false	Valid values: true, false
wfWVQtFileDialog	bool	user	false	Valid values: true, false
wfWVQuickBarPosition	bool	user	false	Position of quick bar is in right/left Valid values: true, false
wfWVRaiseMainWindow	bool	user	true	Raise WaveView window when plotting from PrimeWave
wfWVReaderTopHierThreshold	float	user	5	Scope load on demand threshold (millions).
wfWVReadTopHier	bool	user	true	Loads scopes on demand when the scope count is over the threshold. Valid values: true, false
wfWVRealTimeScroll	bool	user	true	Valid values: true, false
wfWVRefCursorValueIndv	bool	user	false	Shows reference cursor crossing Value. Valid values: true, false
wfWVReloadConfirm	bool	user	false	Disables the waveform marching reloading confirmation dialog box. Valid values: true, false
wfWVRemoveDupSig	bool	user	false	Valid values: true, false
wfWVReplayDelay	int	user	1	
wfWVRightMouseZoom	bool	user	false	Enable Mouse Right Button Drag to Zoom in
wfWVSameColorSweep	bool	user	false	Valid values: true, false
wfWVSensitiveFilter	bool	user	false	Enables sensitive signal list filtering. Valid values: true, false
wfWVSessionFilePath	string	user		Initial session file path.
wfWVShowAxisUnitPrefix	bool	user	false	Display prefix in axis unit labels on a waveview.
wfWVShowConsole	bool	user	false	Valid values: true, false
wfWVShowCrossLabel	bool	user	false	Display value labels at crossing points by default. Valid values: true, false
wfWVShowEqnErrMsg	enWVCal cErr	user	1	Calculator Error / Warning Message (0: hide, 1: show in message window, 2: show in terminal). Valid values: 0, 1, 2

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVShowInfData	bool	user	false	Control the Inf value display and sets the value for Inf when plotting to waveview. Valid values: true, false
wfWVShowMPPrefix	bool	user	false	Valid values: true, false
wfWVShowPanelMode	bool	user	false	Set panel selection mode as default Valid values: true, false
wfWVShowSMButton	bool	user	false	Show Toggle Button in Tool Bar for Signal Selection Mode and Panel Selection Mode Valid values: true, false
wfWVShowTbNameInWVTab	bool	user	false	Show testbench name in waveview tab name
wfWVShowUnitInLabel	bool	user	false	Display axis unit in value labels on a waveview.
wfWVShowWVBrowser	bool	user	true	Show Browser.
wfWVShowWVRBbar	bool	user	false	Show Ribbon Menu Bar Valid values: true, false
wfWVShowWVTBbar	bool	user	true	Show icon toolbar
wfWVShowXParamString	bool	user	false	Display Parameter String Values in X-axis.
wfWVShowYType	bool	user	false	Valid values: true, false
wfWVSignalDnDMode	enWVSignalDnDMode	user	move	Moves or copies a signal when dragged and dropped.
wfWVSignalFilterOption	enWVSignalFilterOption	user	glob	Specifies the string pattern used to search against waveform names is a glob-style or a regular expression pattern in the Signal Finder.
wfWVSignalFont	string	user	0	Sets the default font for signal names. The value is a string, in the format of {<fontName> <fontSize> [regular bold]}
wfWVSignalListFilePath	string	user		Initial signal list saving path.
wfWVSignalLogicStyleDefault	string	user	vcd	
wfWVSignalMode	bool	user	false	Valid values: true, false
wfWVSignalName	enWVSignalName	user	name+file	Sets signal name mode in signal name column. Valid values are: nameonly fullname name+file name+path leafname wavename

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVSignalNameAlign	enWVSignalNameAlign	user	left	Specifies how the width of a name column is displayed in a waveview.
wfWVSignalNamePopup	bool	user	true	Valid values: true, false
wfWVSignalPath	enWVSignalPath	user	path+name	Sets signal hierarchy path style.
wfWVSigNameSpacing	enWVSignalNameSpacing	user	normal	Sets the signal name letter spacing. Valid values: normal large
wfWVSignalNameWidth	int	user	60	Signal Name Width
wfWVSimplifiedRmsCalc	bool	user	false	Use simplified PWL algorithm in rmsval calculation. Valid values: true, false
wfWVSmartHSort	bool	user	false	Valid values: true, false
wfWVSmithChartCharImpedance	float	user	50	
wfWVSnapInterp	bool	user	false	Snap-to or Interpolate for "Show Waveform X-Y Value Near Mouse Pointer" Valid values: true, false
wfWVSnapMarker	bool	user	false	Valid values: true, false
wfWVSNRIncFloorNoise	bool	user	false	Valid values: true, false
wfWVSpiceFSBFilter	string	user	NA	Specify a user-defined netlist file filter pattern.
wfWVStackAutoFit	enWVStackAutoFit	user	on	Enables panel height auto-adjustment for non-logic panels in vertical waveviews.
wfWVStartupMode	string	user	viewer	
wfWVSupportSubstrSearch	bool	user	false	Matches the substrings of waveform names with the specified searching pattern. Valid values: true, false
wfWVSuppressEqnFuncCompletion	bool	user	false	Suppresses function completion for building equations. For example, you can turn off auto-complete in the output expressions table by setting the Tcl preference as follows: db::setPrefValue wfWVSuppressEqnFuncCompletion -value 1 Valid values: true, false

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVSuppressLoadSessionMsg	bool	user	false	Suppress pop-up Warning Messages when Loading Session File
wfWVSuppressDeleteConfirm	bool	user	true	Valid values: true, false
wfWVSweepExpand	enWV SweepExpand	user	user	Treats the sweep signal lines as an individual or a family of lines.
wfWVSwitchMouseButton	bool	user	false	Switches the action of the left and right mouse buttons on the canvas. Valid values: true, false
wfWVSXDMResultPanelScale	bool	user	false	Specify if measurement meter results are in Panel's scale (i.e. db scale) Valid values: true, false
wfWVSyncAlias	bool	user	false	Valid values: true, false
wfWVSyncEqnBuilder	bool	user	false	Synchronize Signal List with Equation Builder Valid values: true, false
wfWVTabPos	enWVTabPos	user	top	Canvas tab position. Valid values: top bottom
wfWVThickLine	bool	user	false	Valid values: true, false
wfWVTraceParamPrecisionDigits	int	user	6	Sets the number of Significant Digits for Parameter Value.
wfWVTraceParmPopup	bool	user	true	Enables sweep trace parameter information popup tooltip. Valid values: true, false
wfWVUnitScale	int	user	0	
wfWVUseCCKeyBindings	bool	user	true	Use CC sae.spxkey file to initialize WV keybindings settings Valid values: true, false
wfWVUseLeafName	bool	user	false	Use signal leaf names for HSPICE and PSF files.
wfWVUseLittleEndian	bool	user	false	Use little-endian format to display bus value Valid values: true, false
wfWVUserColors	enWVUserColors	user	false	Selects the user-defined colors. Valid values: true, false
wfWVUserFixedYRange	bool	user	false	Valid values: true, false
wfWVUserRGB	string	user		A user-defined color. (R:G:B)

Table 44 Waveform Preferences (Continued)

Name	Type	Scope	Default	Description
wfWVUSeSnn	bool	user	false	Valid values: true, false
wfWVVMaX	float	user	3.3	Specify the maximum voltage signal value used in Y Full Range
wfWVVMiN	float	user	0	Specify the minimum voltage signal value used in Y Full Range
wfWVWaveformExportPath	string	user		Initial waveform export path.
wfWVWaveformFilePath	string	user		Initial waveform file path.
wfWVWaveViewBackground	enWVWaveViewBackground	user	black	Sets the waveview background color.
wfWVWaveViewGeom	string	user		Sets geometry of WaveView window
wfWVWaveViewGeomLast	bool	user	true	Specify if using WaveView geometry in last Custom WaveView session. Valid values: true, false
wfWVWdfFilter	string	user	allfiles	Specify the default Waveform File filter used when opening waveform files.
wfWVWdfFsbFilter	string	user		Adds a user-defined filter pattern to the WDF loading dialog box. This option can be used multiple times to add multiple filter patterns.
wfWVWhiteLabelColor	bool	user	false	Displays signal labels with white color. Valid values: true, false
wfWVXAxisAutoGrid	bool	user	true	Automatically determines X axis grid. Valid values: true, false
wfWVXAxisGridExp	int	user	0	Specifies x-axis grid's exponent increment value.
wfWVXAxisGridInc	int	user	0	Specifies x-axis grid's increment value.
wfWVXAxisGridStart	float	user	0	Specifies x-axis grid's starting value.
wfWVXAxisGridStep	float	user	0	Specifies x-axis grid's increasing step value.
wfWVY2AxisAutoGrid	bool	user	true	Automatically determines right Y axis grid. Valid values: true, false
wfWVY2axisGridExp	int	user	0	Specifies right y-axis grid's exponent increment value.
wfWVY2axisGridInc	int	user	0	Specifies right y-axis grid's increment value.

Table 44 *Waveform Preferences (Continued)*

Name	Type	Scope	Default	Description
wfWVY2axisGridStart	float	user	0	Specifies right y-axis grid's starting value.
wfWVY2axisGridStep	float	user	0	Specifies right y-axis grid's increasing step value.
wfWVYAxisAutoGrid	bool	user	true	Automatically determines left Y axis grid. Valid values: true, false
wfWVYaxisGridExp	int	user	0	Specifies left y-axis grid's exponent increment value.
wfWVYaxisGridInc	int	user	0	Specifies left y-axis grid's increment value.
wfWVYaxisGridStart	float	user	0	Specifies left y-axis grid's starting value.
wfWVYaxisGridStep	float	user	0	Specifies left y-axis grid's increasing step value.
wfWVYLabelWidth	int	user	30	Specifies the width of y-axis label in pixels. Max 100. Negative value to autofit.
wfWVZoomInRatio	int	user	50	Specifies the zoom-in ratio (%).