

How to begin with Jupyter notebook setup

Step1:

Connect Ethernet cable & insert SD card (containing pynq-z2 image) in pynq-z2 board.

Step2:

Go to control panel -> Network & internet -> Network & sharing center -> view n/w status & tasks -> Ethernet -> Properties -> Admin login -> Ethernet properties -> networking -> internal protocol version (TCP/IPV4) -> IP (192.168.2.1) -> SUBNET MASK (255.255.255.0) DNS (127.0.0.1).

Step3:

Go to browser and type -> 192.168.2.99:9090 -> Enter
Jupyter login page appears -> login with Password: 'xilinx'

Step4:

Home page -> upload -> system_wrapper.hwh & system_wrapper.bit -> upload

[system_wrapper.hwh & system_wrapper.bit file will be available in the 'ahb_spi_bridge_ip_user' project folder under <Project Directory>/<Project Name>.gen/sources_1/bd/<bd_name>/hw_handoff/<bd_name>.hwh & <Project Directory>/<Project Name>.<runs>/impl_1/<top_module_name>.bit

Step5:

Open new jupyter python-3 notebook -> click new -> python3

Step6:

In new tab jupyter command line interface will open -> Here python code can be implemented -> Refer the jupyter command validation test at
AHBLite_SPI_Bridge_Project/Jupyter_cmds_validation_tests/AHBLite_to_SPI_Bridge_Validation_Tests.p
df -> Run -> observe the output.