

WM100 Front Load Washing Machine

User Manual Version 1.0

Product Overview

The WM100 is a front-load washing machine designed for small and medium households. The machine supports multiple wash cycles including Cotton, Quick Wash, Delicate, and Eco Mode.

Error Codes

E21

E21 indicates a **drain blockage**.

Steps:

1. Turn off the machine.
2. Inspect the drain hose for obstructions.
3. Remove and clean the drain filter.
4. Restart the machine.

SUDS

SUDS indicates excessive detergent usage.

Steps:

1. Pause the cycle.
2. Allow excess foam to settle.
3. Run a rinse cycle.

Child Lock

To enable Child Lock:

1. Press and hold the Start/Pause button for **3 seconds**.
2. A lock icon appears on the display.

Maintenance

- Clean filter every month.
- Run Drum Clean mode every 30 cycles.