

WM-7400 Front-loading washing machine - User manual (extract)

Before first use

Remove the transport bolts from the back of the appliance before connecting it. Keep them for future transport. Connect the inlet hose to a cold water tap and make sure the drain hose is not bent.

Programs

Cotton 40-90 °C: for towels and bed linen.

Synthetics 40 °C: for shirts and mixed fabrics.

Wool / Hand wash 30 °C: gentle drum movement, low spin.

Quick 15 min: for lightly soiled clothes, max 2 kg.

Eco 40-60: lowest energy consumption.

Cleaning the pump filter

Clean the filter every three months or when the machine does not drain. Unplug the appliance, open the small door at the bottom right, place a low container under it and slowly unscrew the filter counter-clockwise. Remove fluff and coins, rinse the filter under running water and screw it back in firmly.

Troubleshooting

Error E21: the water is not draining. Check the filter and the drain hose.

Error E10: no water inlet. Check that the tap is open.

The door does not open: wait two minutes after the end of the cycle.

Warranty

The appliance is covered by a 2-year warranty from the date of purchase. Keep the receipt.