

HC-SR501 PIR Sensor

- **VCC:** Connect to Arduino 5V
- **GND:** Connect to Arduino GND
- **OUT:** Connect to Arduino Pin 3

5mm LED (with a 220Ω resistor)

- **LED Anode (+):** Connect to Arduino Pin 13
- **LED Cathode (-):** Connect to one side of the 220Ω resistor
- **Resistor (other side):** Connect to Arduino GND

Piezo Buzzer

- **Buzzer Red Wire (+):** Connect to Arduino Pin 8
- **Buzzer Black Wire (-):** Connect to Arduino GND