SOP MNT01 Replacing Furnace Filter Rev 0

DATE ISSUED: 11/4/22

DATE REVISED: N/A

SCOPE: Monthly Building Maintenance

REFERENCED DOCUMENTS: SOP MNT02 Completing PM in Limble

RESPONSIBILITY: Owner

PURPOSE: To ensure the furnace is being filtered properly and regularly.

Step	Action	Picture
1	Grab a 20x25x1 air filter from the CAD room.	

Go to the furnace air vent and pull the two latches to the right. Pull the top of the vent toward you. 3

A Remove the older air filter by grabbing the top of the filter towards you



Place the new air filter in the same orientation as the previous one AND ensure the white arrow on the label is pointing TOWARDS the furnace.



6	Push the air vent back into position and pull the latches to the left to lock it.	20.25 x1
7	Throw out the old filter. WARNING: Do not breathe too close to the older filter.	
8	Log activity into Limble. Refer to SOP MNT02 Completing PM in Limble	

Approved: Dan Mo	Date: 11-10-22
Owner	

Change Log:

Date	Change Description	Rev	Requestor
11/4/22	Initial Release	0	B. Morris