

Firmware Flash Instructions

Flashing the ESP32-S3

1. Connect the ESP32-S3 via USB

Connect the ESP32-S3 to your PC using a USB cable.

2. Open the Web Flasher

Open the following website in your browser:

<https://espressif.github.io/esptool-js/>

3. Connect

- Click **Connect**
 - Select the correct COM port
 - Confirm the connection.
-

4. Add the Files

Add the following files with their corresponding flash addresses:

Flash Address	File
0x0	AMS_Display_Dial_V1.3.ino.bootloader.bin
0x8000	AMS_Display_Dial_V1.3.ino.partitions.bin
0x10000	AMS_Display_Dial_V1.3.ino.bin

5. Flash Settings

Use the following settings:

Setting	Value
Flash Mode	Keep
Flash Frequency	Keep
Flash Size	Keep

6. Optional: Erase the Flash Memory

Recommended for a clean installation:

- Click **Erase Flash**
 - Wait until the process is complete.
-

7. Flash the Firmware

- Click **Program**
- Wait until the flashing process has been completed.

The ESP32-S3 will automatically reboot afterwards.

First Startup in AP Mode (Access Point)

If no Wi-Fi credentials are stored or no known Wi-Fi network can be found, the device will automatically start in AP mode.

Access Information

Setting	Value
IP Address	192.168.4.1
SSID	AMS_Dial-Setup
Password	12345678

Note

During the first startup, establishing the connection may take a few seconds.

After entering and saving your Wi-Fi credentials, it may take **1–2 minutes** before the confirmation message appears indicating that the settings have been successfully applied.