

AMS Dial – English Manual

Overview

The AMS Dial is an additional rotary controller for the AMS Spool Display.

With the Dial you can:

- subtract spool weight
- swap spools
- configure settings directly via WiFi
- use MQTT or HTTP

After initial setup no Arduino IDE is required anymore.

Features

Subtract Weight

1. Select “WEIGHT” mode
2. Select spool
3. Adjust weight with encoder
4. Press encoder to confirm

The Dial uses dynamic encoder acceleration:

- slow rotation = precise 1g steps
 - fast rotation = large jumps
-

Swap Spools

1. Select “SWAP” mode
2. Select first spool
3. Select target spool
4. Press encoder

The complete spool is swapped:

- material
- color
- type
- weight
- all spool data

Menu

Current menu options:

- German / English language
- AP Mode on/off

AP Mode

AP Mode starts its own WiFi network:

AMS-Dial-Setup

Password:

12345678

Then open this address in your browser:

192.168.4.1

Web Interface

The web interface allows configuration of:

- WiFi name
- WiFi password
- Display IP
- MQTT server

MQTT is optional.

If no MQTT is used, leave the field empty.

Factory Reset

The button:

DELETE SETTINGS

removes:

- WiFi settings
- Display IP
- MQTT settings

After restart the Dial automatically enters AP setup mode again.

Operating Modes

MQTT

If an MQTT server is configured:

- the Dial uses MQTT
- status shows “MQTT”

If MQTT is unavailable:

- automatic HTTP fallback is used
-

HTTP Only

If no MQTT server is configured:

- the Dial operates completely via HTTP
 - status shows “HTTP”
-

Navigation

The Dial supports full back navigation.

Every important screen includes a “BACK” option.
