Lab commands Cross-compiling kernel:

export ARCH—arm
export CROSS_COMPILE=arm-linuxmake sama5_defconfig

Booting kernel through ftp:
setenv bootargs console=ttyS0 root=/dev/nfs
setenv bootard tftp 0x21000000 zimage; tftp
0x22000000 ditb: broot 0x21000000 vz200

Making ubifs images: mkfs.ubifs -d rootfs -o root.ubifs -e 124KiB -m 2048 -c 1024

Encountered issues: Restart NFS server after editing /etc/exports!