



Installation Instructions

Step-by-step guide to install your new Remote Sensor

1 What's Included

Make sure all of the parts are nearby.

- LG temperature sensor
- Metal plate

Image: <https://casview.apple.com/view/D3E4CC42-DB2C-4377-BF72-049450B72072?dl=1>

2 Installation Method

Your sensor uses a magnet to stay in place on metal surfaces.

On other surfaces, you'll need to install the metal plate.

Install without Metal Plate → Go to step 3

Install with Metal Plate → Go to step 4

Image: <https://casview.apple.com/view/01099A73-5E38-4F0A-B010-302040EE12F7?dl=1>

3 Install Sensor

1. Remove the battery tab.

2. Wait for your sensor to turn on.

3. Place your sensor on a metal surface using the magnet.

Image: <https://casview.apple.com/view/D3E4CC42-DB2C-4377-BF72-049450B72072?dl=1>

4 Install Sensor with Metal Plate

1. Remove the protective film from the tape on the metal plate.

2. Attach the metal plate where you want your sensor to be.

3. Remove the battery tab.

4. Wait for your sensor to turn on.

5. Place your sensor on a metal surface using the magnet.

Image: <https://casview.apple.com/view/D3E4CC42-DB2C-4377-BF72-049450B72072?dl=1>