For using VCI, driver should be installed with zadig


Elder devices supported only one interface: HID. Newer devices/firmware support 2 interfaces: HID and VCI. HID is very simple and does not require any additional driver on any system. VCI is faster. On some devices drastically faster than HID. Unfortunately, on windows this VCI requires installation of a special driver. It either should be provided by a vendor (but we don't), or by using zadig or UsbDk. Zadig is preferable. So, if your device supports both interfaces the list(enumeration) with available devices will have 2 connections for the device. You can choose a proper connection descriptor and connect against it instead of using simple helper argument-less open. You can find out the interface by a special field (connectionInterface get-accessor in C#; InterfaceCode field for python; ciface_code in C so on). Instructions on how to install a driver using zadig see another document. It has to be provided in a API or GUI bundle.

Workflow


- https://zadig.akeo.ie/
- Run zadiq
- If a drop-down (combobox) is empty set checked Options > List All Devices
- Choose "PocketVNA (Interface 1)" in the drop-down
 - Very Important: you should select exactly "interface 1" -- otherwise HID interface will be down
 - Very Important: select exactly "PocketVNA", otherwise some other device will be down
- Choose "Winuse (v6.1.7600...)" in a spin-box after a green arrow. Zadig may detect the driver automatically
- Select "Replace Driver"/"Install Driver" in a context for a bottom button: click on the down-arrow on it
 - **Note**: Don't use "Install WCID Driver" ("Downgrade WCID Driver"). Sometimes, at least on older zadig versions it works weirdly
- Hit "Replace Driver"/"Install Driver" button and wait driver to be installed
- Profit. App should use VCI connection instead of HID
- Attention: in case of installing an incorrect driver; or a driver for incorrect device/interface you have to roll-back drivers. On windows all installed drivers are stacked. That does mean, that if you install driver 2 times to recover the original state you have to "Uninstall Device" 2 times!

Comics


• The list may be empty




• In this case set Options > List All Devices checkbox




• Choose exactly "PocketVNA (interface 1)"




• Pay attention: the correct interface is a correct "WCID WinUSB" device. All settings should be detected by Zadig automatically



• In the previous picture combo-button has the state that should be changed. "Install WCID Driver" ("Downgrade WCID Driver") should be changed with "Install Driver". Click on "down-arrow". Hitting on a button's area leads to driver installation



• Hit "Install Driver" (or "Replace Driver")



- Wait until driver install
- Note: It seems to be "libusb-win32" driver works well too. <u>But in case of running 32</u>
 <u>bit version</u> of PocketVNA application WinUSB should be chosen