

5.2 Add a Custom Sensor (Example: Soil Temperature & Moisture Sensor)

5.2.1 Preparation

Prepare the sensor: Soil Temperature & Moisture sensor, 5V, Modbus address as 128.

Solder the aviation connector to the sensor: follow the wire number/sequence, and solder the aviation connector to the sensor .



When connecting to a custom sensor, users need to solder the aviation connector to the sensor by following the wire number/sequence below. (contact us if you need to purchase the connector):

Aviation Connector Pin	Sensor Wire Pin	Description
1	12V	If the sensor is powered by 12v, connect this pin
2	5V	If the sensor is powered by 5v, connect this pin
3	RS485 A	-
4	RS485 B	-
5	GND	Ground

Connect to Sensor Hub: Plug the aviation connector into any port (1 to 4) on Sensor Hub Data Logger.

5.2.2 Configure Sensors' Basic Information

- (1) Read the information.