## B1504-86, B1507-01、 B1508-51、 B1509-51、 B1510-51、 B1514-62、 B1520-55

| **Fault diagnosis code** |
| --- |
| B1504-86：No EMS challenge Rx |
| B1507-01：Key authentication failure |
| B1508-51：No SK generated |
| B1509-51：No PIN writed |
| B1510-51：IMMO key information not stored |
| B1514-62：ECM authentication failed |
| B1520-55：IMMO unlock |
| **Detection tools** |
| 1 Multimeter and diagnostic apparatus |
| **Possible causes** |
| • BCM fault<br>• PEPS fault<br>• Ignition key fault |
| **Conditions for fault code operation** |
| Turn the ignition switch to ON position. |
| **Conditions for fault code setting** |
| B1504-86 |
| No EMS challenge Rx within 2s |
| B1507-01 |
| Key authentication failure |
| B1508-51 |
| NO SK is generated |
| B1509-51 |
| No PIN be written |
| B1510-51 |
| No key information is stored |
| B1514-62 |
| ECM authentication failed |
| B1520-55 |
| Engine authentication failed |
| **To set the effect of a fault code condition** |
| 1 Start function fault; 2 BCM unlocked<br>3 BCM unlocked; 4 Add key function fault |

| **Troubleshooting steps** | | |
|---|---|---|
| Step 1 | General inspection. | |
| | | 1 Check battery capacity.<br>2 Check whether the ignition key battery charge is sufficient.<br>3 Check the harness plug of air conditioning control module for damage, poor contact, aging and looseness.<br>4 Check whether the result is normal or not? |
| | | **NO →** Repair or replace the faulted parts. |
| **YES ↓** | | |
| Step 2 | Check fault codes. | |
| | | 1 Connect the fault diagnosis instrument to the diagnosis interface.<br>2 Turn the ignition switch to ON position.<br>3 Check the body control module with a diagnostic apparatus.<br>4 If there is any fault code except for B1504-86, B1507-01、B1508-51、B1509-51、B1510-51、B1514-62、B1520-55? |
| | | **YES →** Refer to:DTC Summary list(BCM). |
| **NO ↓** | | |
| Step 3 | Perform initialization. | |
| | | 1 Turn the ignition switch to OFF.<br>2 Connect the fault diagnosis instrument to the diagnosis interface.<br>3 Turn the ignition switch to ON.<br>4 Initialize the body control module and register all keys using a diagnostic apparatus.<br>5 Can the body control module be initialized and the registered key start the engine? |
| | | **NO →** Repair or replace the ignition key or body control module. |
| **YES ↓** | | |
| At this point the system is functioning normally. The problem may be caused by module connections. Address the root cause of any connector or pin problems, | | |
| **Next Step ↓** | | |
| Diagnosis end. | | |