P0641-00、 P0AC2-00

Fault diagnosis code
P0641-00：PACKCurrent sensor power failure
P0AC2-00：PACKCurrent sensor hardware failure
Detection tools
1 Multimeter and diagnostic apparatus
Possible causes
• BMS fault • The current circuit of BMS fault
Conditions for fault code operation
Turn the ignition switch to ON position.
Conditions for fault code setting
P0641-00
Hall power drive failure (indistinguishable from a feedback signal shared with the DC positive relay drive chip, and alarms at the same time)
P0AC2-00
PACK Current sensor hardware failure
To set the effect of a fault code condition
BMS function is limited

Troubleshooting steps		
Step 1	General inspection.	
		1 Check battery capacity. 2 Check the harness plug of BMS for damage, poor contact, aging and looseness. 3 Check whether the result is normal or not?
		NO → Repair or replace the faulted parts.
YES ↓		
Step 2	Check fault codes.	
		1 Connect the fault diagnosis instrument to the diagnosis interface. 2 Turn the ignition switch to ON position. 3 Diagnose the BMS with diagnostic apparatus. 4 If there is any fault code except for P0641-00,P0AC2-00?
		YES → Refer to:DTC Summary list(BMS).
NO ↓		
Step 3	Check cooling system.	
		1 Check whether there is leakage or poor heat dissipation in the cooling system. 2 Check whether the result is normal or not?
		NO → Repair the cooling system.
YES ↓		
Step 4	Check the connecting cable of BMS.	
		1 Turn the ignition switch to OFF. 2 Make protective preparations according to the safety operation specifications of the high voltage voltage in the maintenance manual. 3 Disconnect the harness plug battery pack high voltage. 4 Disconnect the high voltage harness plug of BMS. 5 Check whether the BMS connection cable is rotten, damaged, and water enters. 6 Check whether the result is normal or not?
		NO → Repair or replace the faulted parts.
YES ↓		

Step 5	Perform initialization.
	1 Turn the ignition switch to OFF. 2 Connect the fault diagnosis instrument to the diagnosis interface. 3 Turn the ignition switch to ON. 4 The BMS module was initialized with the diagnostic instrument. 5 Can the BMS be initialized and is the BMS restored?
	NO → Repair or change the BMS module.
YES ↓	
Step 6	Test whether BMS is norm.
	1 Turn the ignition switch to OFF. 2 Disconnect and check the harness plug CH1001 of BMS. 3 Check and repair. • Corrosion(install new adapting piece or terminal-cleaning module and pin). • Pin damaged or bent-install new terminal/pin. • Fly out of pins-install new pins as needed. 4 Reconnect the BMS plug and all other previously disconnected plug. Make sure the pin is properly positioned and fixed. 5 Run the system and determine if the problem persists?
	YES → Replace the BMS.
NO ↓	
At this point the system is functioning normally. The problem may be caused by module connections. Address the root cause of any connector or pin problems.	
Next Step ↓	
Diagnosis end.	