U1D06-4B、 U1D07-97、 U1D08-46、 U1D0A-57、 U1D0B-96

Fault diagnosis code
U1D06-4B：Image Process Unit temperature high
U1D07-97：DAS(Driver Assistant System) Camera View Blocked
U1D08-46：DAS(Driver Assistant System) calibration failure
U1D0A-57：DAS(Driver Assistant System) software mismatch
U1D0B-96：DAS(Driver Assistant System) Internal Faults
Detection tools
1 Multimeter and diagnostic apparatus
Possible causes
• Circuit,terminal and adapting piece fault • DAS Module • Calibration fault
Conditions for fault code operation
Turn the ignition switch to ON position.
Conditions for fault code setting
U1D06-4B
The DAS internal temperature exceeds 119 ℃ during initialization. The operating temperature within 5s is over 115 ℃
U1D07-97
The view of DAS camera is blocked by foreign objects and smudges
U1D08-46
TAC calibration failure
U1D0A-57
APP and Eye MEST versions are not compatible
U1D0B-96
1. DAS internal 5V/3.3V/1.8V/1.2V is 500ms overvoltage or undervoltage, 2. MCU and PLL out of range, 3. MCU reset abnormally, 4. MCU flash checksum fault, 5. MCU and RAM test fault, 6. EEPROM test fault, 7. The image processing unit reports a test failure in the boost diagnostics message, 8. The image processing unit reports a fatal application message twice in a row, 9. SPI communication with the image processing unit is lost. (500Ms, no relevant informations)
To set the effect of a fault code condition

1. DAS controller is fault, and DAS function cannot be used properly
2.DAS controller is incorrectly identified, and DAS function cannot be used normally
3.DAS controller fails to calibrate the DTC, and the DTS function cannot be used normally.
4.DAS controller is incorrectly identified, and DAS function cannot be used normally.
5.DAS controller is faulty, and DAS function cannot be used properly.

Troubleshooting steps		
Step 1	General inspection.	
		1 Check battery capacity. 2 Check whether there is dirt or cover around the DAS camera. 3 Check the harness plug of DAS for damage, poor contact, aging and looseness. 4 Check whether the result is normal or not?
		NO → Repair or replace the faulted parts.
YES ↓		
Step 2	Check fault codes.	
		1 Connect the fault diagnosis instrument to the diagnosis interface. 2 Turn the ignition switch to ON position. 3 Check the body control module with a diagnostic apparatus. 4 Is there any other fault code except for U1D06-4B/U1D07-97/U1D08-46/U1D0A-57/U1D0B-96?
		YES → Refer to:DTC Summary list(DAS).
NO ↓		
Step 3	Perform initialization.	
		1 Turn the ignition switch to OFF. 2 Connect the fault diagnosis instrument to the diagnosis interface. 3 Turn the ignition switch to ON. 4 The DAS module was initialized with the diagnostic instrument, and the function was recalibrated. 5 Can the DAS module be initialized? Is the function of the calibrated module normal?
		NO → Repair or change the DAS module.
YES ↓		
At this point the system is functioning normally. The problem may be caused by module connections. Address the root cause of any connector or pin problems.		
Next Step ↓		
Diagnosis end.		