## P1CB1

| Fault diagnosis code |
| --- |
| P1CB1：DEM_stAmdCrashSens |
| **Detection tools** |
| 1 Multimeter and diagnostic apparatus |
| **Possible causes** |
| • No need to repair |
| **Conditions for fault code operation** |
| Turn the ignition switch to ON position. |
| **Conditions for fault code setting** |
| P1CB1 |
| ABSActive |
| **To set the effect of a fault code condition** |
| |

| Troubleshooting steps | | |
|---|---|---|
| Step 1 | General inspection. | |
| | | 1 Check the fuse for damage.<br>2 Check the relay for damage.<br>3 Check battery capacity.<br>4 Check the harness plug of main relay, VCU for damage, poor contact, aging and looseness.<br>5 Check whether the result is normal or not? |
| | | **NO →** Repair or replace the faulted parts. |
| **YES ↓** | | |
| Step 2 | Check fault codes. | |
| | | 1 Connect the fault diagnosis instrument to the diagnosis interface.<br>2 Turn the ignition switch to ON position.<br>3 Diagnose the VCU with diagnostic apparatus.<br>4 Is there any other fault code except for P1CB1? |
| | | **YES →** Refer to:DTC Summary list(VCU). |
| **NO ↓** | | |
| Step 3 | Check the vehicle for collisions. | |
| | | 1 Check the condition of the vehicle and confirm to the owner whether the vehicle has been involved in a collision. |
| | | **YES →** Replace airbags. |
| **NO ↓** | | |
| Step 4 | Power on and off the vehicle again. | |
| | | 1 Turn the ignition switch to OFF.<br>2 Disconnect the negative polar of the battery.<br>3 After waiting for 15s, reconnect the negative polar of the battery.<br>4 Connect the fault diagnosis instrument to the diagnosis interface.<br>5 Turn the ignition switch to ON position.<br>6 Diagnose the VCU with diagnostic apparatus.<br>7 Test whether the faulted code is existed. |
| | | **YES →** Replace airbags. |
| **NO ↓** | | |
| At this point the system is functioning normally. The problem may be caused by module connections. Address the root cause of any connector or pin problems. | | |

| **Next Step ↓** |
| --- |
| Diagnosis end. |