P1CE0、 P1CE1

Fault diagnosis code
P1CE0：DEM_stThmAlarmSenFlt
P1CE1：DEM_stThmAlarm
Detection tools
1 Multimeter and diagnostic apparatus
Possible causes
• Circuit,terminal and adapting piece fault • VCU module fault • PEM fault
Conditions for fault code operation
Turn the ignition switch to ON position.
Conditions for fault code setting
P1CE0
FEM controller reports a fault message
P1CE1
FEM controller reports a thermal runaway message
To set the effect of a fault code condition

Troubleshooting steps		
Step 1	General inspection.	
		1 Check the fuse for damage. 2 Check the relay for damage. 3 Check battery capacity. 4 Check the harness plug of main relay, VCU for damage, poor contact, aging and looseness. 5 Check whether the result is normal or not?
		NO → Repair or replace the faulted parts.
YES ↓		
Step 2	Check fault codes.	
		1 Connect the fault diagnosis instrument to the diagnosis interface. 2 Turn the ignition switch to ON position. 3 Diagnose the VCU with diagnostic apparatus. 4 If there is any fault code except for P1CE0,P1CE1?
		YES → Refer to:DTC Summary list(VCU).
NO ↓		
Step 3	Check the fault code of PEM module.	
		1 Turn the ignition switch to OFF. 2 Connect the fault diagnosis instrument to the diagnosis interface. 3 Turn the ignition switch to ON position. 4 Diagnose the PEM with diagnostic apparatus. 5 Check whether the result is normal or not?
		NO → Perform diagnosis based on the specific DTC.
YES ↓		

Step 4	Test whether VCU is norm.
	1 Turn the ignition switch to OFF. 2 Disconnect and check the harness plug EB1000_1, IP55_A of VCU. 3 Check and repair. • Corrosion(install new adapting piece or terminal-cleaning module and pin). • Pin damaged or bent-install new terminal/pin. • Fly out of pins-install new pins as needed. 4 Reconnect the VCU plug and all other previously disconnected plug. Make sure the pin is properly positioned and fixed. 5 Run the system and determine if the problem persists?
	YES → Change the VCU Module
NO ↓	
At this point the system is functioning normally. The problem may be caused by module connections. Address the root cause of any connector or pin problems.	
Next Step ↓	
Diagnosis end.	