P1CE5、 P1CE6、 P1CE9

Fault diagnosis code
P1CE5：DEM_stBPTCInSnsrEr
P1CE6：DEM_stBPTCOutSnsrEr
P1CE9：DEM_stBPTCOutPowerEr
Detection tools
1 Multimeter and diagnostic apparatus
Possible causes
• Circuit,terminal and adapting piece fault • VCU module fault • PEM fault
Conditions for fault code operation
Turn the ignition switch to ON position.
Conditions for fault code setting
P1CE5
BPTC reports inlet water temperature sensor fault
P1CE6
BPTC reports outlet water temperature sensor fault
P1CE9
BPTC reports an output fault
To set the effect of a fault code condition

Troubleshooting steps		
Step 1	General inspection.	
		1 Check the fuse for damage. 2 Check the relay for damage. 3 Check battery capacity. 4 Check the harness plug of main relay, VCU for damage, poor contact, aging and looseness. 5 Check whether the result is normal or not?
		NO → Repair or replace the faulted parts.
YES ↓		
Step 2	Check fault codes.	
		1 Connect the fault diagnosis instrument to the diagnosis interface. 2 Turn the ignition switch to ON position. 3 Diagnose the VCU with diagnostic apparatus. 4 Is there any other fault code except for P1CE5/P1CE6/P1CE9?
		YES → Refer to:DTC Summary list(VCU).
NO ↓		
Step 3	Check the fault code of BPTC module.	
		1 Turn the ignition switch to OFF. 2 Connect the fault diagnosis instrument to the diagnosis interface. 3 Turn the ignition switch to ON position. 4 Diagnose the BPTC with diagnostic apparatus. 5 Check whether the result is normal or not?
		NO → Perform diagnosis based on the specific DTC.
YES ↓		

Step 4	Test whether VCU is norm.
	1 Turn the ignition switch to OFF. 2 Disconnect and check the harness plug EB1000_1, IP55_A of VCU. 3 Check and repair. • Corrosion(install new adapting piece or terminal-cleaning module and pin). • Pin damaged or bent-install new terminal/pin. • Fly out of pins-install new pins as needed. 4 Reconnect the VCU plug and all other previously disconnected plug. Make sure the pin is properly positioned and fixed. 5 Run the system and determine if the problem persists?
	YES → Change the VCU Module
NO ↓	
At this point the system is functioning normally. The problem may be caused by module connections. Address the root cause of any connector or pin problems.	
Next Step ↓	
Diagnosis end.	