P020A、P020B、P020C、P020D

Description of fault diagnosis codes		
P020A-F0:DFC reporting error state on comparing energising time to Max value logical injector 1		
P020A-F1:DFC reporting error state on comparing energising time to Max value logical injector 1		
P020B-F0:DFC reporting error state on comparing energising time to Max value logical injector 4		
P020B-F1:DFC reporting error state on comparing energising time to Max value logical injector 4		
P020C-F0:DFC reporting error state on comparing energising time to Max value logical injector 2		
P020C-F1:DFC reporting error state on comparing energising time to Max value logical injector 2		
P020D-F0:DFC reporting error state on comparing energising time to Max value logical injector 3		
P020D-F1:DFC reporting error state on comparing energising time to Max value logical injector 3		
Detection tools		
1 Diagnostic apparatus		
Possible causes		
• Vehicle overload • Unreasonable gearbox matching • Oil problem		
Troubleshooting procedures		
Step 1	General inspection.	
		1 Check the fuse for damage. 2 Check battery capacity. 3 Check if there is any damage, bad contact, aging and looseness phenomenon on harness plug of engine control module and fuel injector. 4 Check whether the result is normal?
		No → Repair or replace the faulted parts .
Yes ↓		
Step 2	Check fault codes.	
		1 Connect the fault diagnosis instrument to diagnosis interface. 2 Turn the ignition switch to ON position. 3 Diagnose the engine control system with diagnostic apparatus. 4 If there is any fault code except for P020A/P020B/P020C/P020D?
		Yes → Refer to:DTC Summary List (EU5).
No ↓		

Step 3	Clear ZFC learning value with diagnostic apparatus.	
	1 Connect the failure diagnosis instrument to the diagnosis interface. 2 Turn the ignition switch to ON position. 3 Clear ZFC learning value with diagnostic apparatus. 4 Turn the ignition switch to OFF, and wait for at least 60s. 5 Check whether the result is normal?	
	No →	Check vehicle overload; check gearbox matching; replace fuel oil.
Next ↓		
Step 4	Complete the check and confirm whether the system works normally nor not.	