P1704、 P1706、 P1708

Description of fault diagnosis codes		
P1704-F0：Clutch Learning fault		
P1706-64：Clutch Pedal Learn Value Memory Corruption		
P1708-F0：Clutch Pedal Fully Applied Position Not Learned		
Detection tools		
1 Multimeter and diagnostic apparatus		
Possible causes		
• Fault in harness or harness plug • Environment temperature sensor fault		
Troubleshooting procedures		
Step 1	General inspection.	
		1 Check the fuse for damage. 2 Check battery capacity. 3 Check the engine control module for damage, poor contact, aging, and looseness. 4 Check whether the result is normal or not.
		否 ➜ Repair or replace the faulted parts.
是 ↓		
Step 2	Check fault codes.	
		1 Connect the fault diagnosis instrument to diagnosis interface. 2 Turn the ignition switch to ON position. 3 Diagnose the engine control system with diagnostic apparatus. 4 Is there any other fault code except for P1704、 P1706、 P1708?
		是 ➜ Refer to: DTC Summary List (EU5).
否 ↓		
Step 3	Replace engine control module.	
		1 Replace engine control module.
下一步 ↓		
Step 4	Complete the check and confirm whether the system works normally nor not.	