P2228、 P2229

Description of fault diagnosis codes		
P2228-11：SRC low for Environment Pressure		
P2229-12：SRC High for Environment Pressure		
Detection tools		
1 Diagnostic apparatus		
Possible causes		
• Damages of engine control module		
Description of fault diagnosis		
The voltage signal of atmospheric pressure sensor is converted via engine control module, which is displayed as atmospheric pressure parameter on the fault diagnosis instrument (Unit: bar). The signal of atmospheric pressure sensor will vary with the altitude and atmospheric conditions. It will indicate current atmospheric pressure for the engine control module. The engine control module will utilize such information for multiple internal computations. The engine control module will monitor the atmospheric pressure sensor voltage/pressure signals beyond normal range. The engine control module also monitors the stability of atmospheric pressure sensor by comparing continuous examples.		
Troubleshooting procedures		
Step 1	General inspection.	
		1 Check the fuse for damage. 2 Check battery capacity. 3 Check the harness plug of engine control module for damage, poor contact, aging and looseness. 4 Check whether the result is normal?
		No → Repair or replace the faulted parts .
Yes ↓		
Step 2	Inspect the atmospheric pressure sensor with diagnostic apparatus.	
		1 Turn the ignition switch to ON position. 2 Read the data stream with diagnostic apparatus. **Standard value:** **Atmospheric pressure: ≈ 1bar (at 0 elevation)** **Atmospheric pressure sensor voltage: ≈ 4V (at 0 elevation)** 3 Check whether the result is normal?
		No → Replace engine control module.
Next ↓		
Step 3	Complete the check and confirm whether the system works normally nor not.	

P2263

Description of fault diagnosis codes		
P2263-84：PCR negative governor deviation below limit		
P26E4-11：PCR positive governor deviation above limit		
Detection tools		
1 Multimeter and diagnostic apparatus		
Possible causes		
• Harness or connector fault • Air filter fault • Turbocharger fault • Inlet air leak • Exhaust leak • Fault in boost pressure temperature sensor		
Troubleshooting procedures		
Step 1	Check the air filter.	
		1 Check whether the air filter is blocked. 2 Check whether the result is normal?
		Yes → Repair or replace the faulted parts.
No ↓		
Step 2	Check the air inlet pipe.	
		1 Check whether the air inlet pipe is blocked. 2 Check whether the result is normal?
		No → Repair or replace the faulted parts.
Yes ↓		
Step 3	Check the exhaust leakage.	
		1 Check whether the exhaust pipe is leaking. 2 Check whether the result is normal?
		No → Repair or replace the faulted parts.
Yes ↓		
Step 4	Check the boost pressure and temperature sensor.	
		1 Check the boost pressure and temperature sensor. 2 Check whether the result is normal?
		No → Replace the boost pressure temperature sensor.
Yes ↓		

Step 5	Check the turbocharger.	
		1 Check whether the turbocharger is damaged. 2 Check whether the result is normal?
		No → Replace the turbocharger.
Yes ↓		
Step 6	Check fault codes.	
		1 Connect the fault diagnosis instrument to diagnosis interface. 2 Turn the ignition switch to ON position. 3 Diagnose the engine control system with diagnostic apparatus. 4 Is there any other fault code except for P2263?
		Yes → Reference: DTC Summary List (EU5).
Next ↓		
Step 7	Complete the check and confirm whether the system works normally nor not.	