

5 Control Command

5.1 Control			
Start Code			ESC+A
Hexadecimal code	ESC <1B> ₁₆	A <41> ₁₆	Parameter
Initial value	Nil		
Valid range and term of command	When the power switch is OFF		The set command is not maintained.
	Valid range within items		The set command becomes invalid.
	Valid range between items		The set command becomes invalid.

[Function]

Specifying the start of data transmission.

[Format]

<A>

[Coding Example]

```
<A>
<V>100<H>200<P>2<L>0202<XM>ABCD
<Q>2
<Z>
```

[Supplementary Explanation]

1. Indicates the start of item and to be placed at the head of item.
2. Use <A> and End of Data Transmission <Z> as a pair of commands.

[Notes]

1. Setting value of all commands excluding a part of system commands will be set to default.
2. If this command is not specified, printing will not be performed.