

5.3 Control			
Print Quantity			ESC+Q
Hexadecimal code	ESC <1B> ₁₆	Q <51> ₁₆	Parameter aaaaaa
Initial value	aaaaaa=1		
Valid range and term of command	When the power switch is OFF		The set parameter is not maintained.
	Valid range within items		The set parameter becomes invalid.
	Valid range between items		The set parameter becomes invalid.

[Function]

Specifying the number of labels to print.

[Format]

<Q>aaaaaa

•Parameter

a[Number of labels to print] = Valid range: 1 to 999999

[Coding Example]

Number of labels: 2

<A>

<V>100<H>200<P>2<L>0202<XM>ABCD

<Q>2

<Z>

[Supplementary Explanation]

1. Print contents specified by Start of Data Transmission <A> and End of Data Transmission <Z> are regarded as 1 label, and the number of reprints can be specified.
2. Use this command prior to End of Data Transmission <Z>.

[Note]

1. Reprint will be performed based on the specified print quantity. If specifying sequential numbering command <F>, the value of sequential number that was set up for that field portion will print.
2. When this command is used in combination with Multiple Cutting <->, the specified print quantity multiplied by specified value for cutting becomes the number of labels to print.

[Initial value of parameter and Valid range]

Model	Initial value	Valid range
CL4NX/CL6NX	1	1~999999