

5.2 Control			
Stop Code			ESC+Z
Hexadecimal code	ESC <1B> ₁₆	Z <5A> ₁₆	Parameter
Initial value	Nil		
Valid range and term of command	When the power switch is OFF		The set command is not maintained.
	Valid range within items		The set command becomes invalid.
	Valid range between items		The set command becomes invalid.

[Function]
Specifying the end of data transmission.

[Format]
<Z>

[Coding Example]
 <A>
 <V>100<H>200<P>2<L>0202<XM>ABCD
 <Q>2
<Z>

[Supplementary Explanation]
 1. Indicates the end of item and to be placed at the tail of item.
 2. Use Start of Data Transmission <A> and <Z> as a pair of commands.

[Note]
If this command is not specified, printing will not be performed.