

17.5 Common Commands for All Languages

Printer Status Information Acquisition			DC2+PG
Command	DC2	PG	Parameter
HEX code	<12> ₁₆	<50> ₁₆ <47> ₁₆	None
Default value	None		

Valid range and term of command	When turning off the power switch	
	Valid range	
	Printer operation in progress	The command can be received even during the printer operation.
	Error	Commands can be received even if an error is occurring.

[Function]

This command returns the printer status.

[Format]

DC2 (12H) + PG

[Return data format (normal)]

[STX]a...a,b...bc,d...de,...[ETX] *There is no ", (comma)" before ETX

Symbol	Parameter name	Valid range
a	Total number of data byte *This is the total number of bytes after parameter b. The delimiting comma between parameters a and b, and the ETX are not included.	Data size from the first identifier until before [ETX]
b(d)	Printer status information name *Text format	Refer to the printer status information list
c(e)	Printer status information data *Text format	Refer to the printer status information list

Data Example)

[STX]32,PS0,RS0,RE0,PE0,EN00,BT0,Q000000[ETX]

[Printer status information data list]

No	Description	Printer status information name	Printer status information data
1	Printer status	PS	0: Standby (waiting for receiving data) 1: Waiting for dispensing 2: Analyzing 3: Printing 4: Offline 5: Error
2	Receive buffer status	RS	0: Buffer available 1: Buffer near full 2: Buffer full
3	Ribbon status *Monitoring can be performed during printing and feeding The correct value cannot be acquired when the operation has stopped	RE	0: Ribbon present 1: Ribbon near end 2: No ribbon 3: Direct thermal model
4	Media status *Monitoring can be performed during printing and feeding The correct value cannot be acquired when the operation has stopped	PE	0: Media present (including during startup) 2: No media

No	Description	Printer status information name	Printer status information data
5	Error No. *1	EN	00:Online *Not an error. Return is performed 01:Offline *Not an error. Return is performed 02: Machine error 03: Memory error 04: Program error 05: Setting information error (FLASH-ROM error) 06: Setting information error (EE-PROM error) 07: Download error 08: Parity error 09: Over run 10: Framing error 11: LAN timeout error 12: Buffer over 13: Head open 14: Paper end 15: Ribbon end 16: Media error 17: Sensor error 18: Printhead error 19: Cover open error 20: Memory/Card type error 21: Memory/Card read/write error 22: Memory/Card full error 23: Memory/Card no battery error 24: Ribbon saver error 25: Cutter error 26: Cutter sensor error 27: Stacker full error 28: Command error 29: Sensor error at Power-On 30: RFID tag error 31: Interface card error 32: Rewinder error 33: Other error 34: RFID control error 35: Head density error 36: Kanji data error 37: Calendar error 38: Item No error 39: BCC error 40: Cutter cover open error 41: Ribbon rewind non-lock error 42: Communication timeout error 43: Lid latch open error 44: No media error at Power-On 45: SD card access error 46: SD card full error 47: Head lift error 48: Head overheat error 49: SNTP time correction error 50: CRC error 51: Cutter motor error 52: WLAN module error 53: Scanner reading error 54: Scanner checking error 55: Scanner connection error 56: BluetoothModuleerror 57: EAP authentication error(EAP failed) 58: EAP authentication error(Time out) 59: Battery error 60: Low Battery error 61: Low Battery error (Charging) 62: Battery not installed error 63: Battery temperature error 64: Battery deterioration error 65: Motor temperature error 66: Inside chassis temperature error 67: Jam error

No	Description	Printer status information name	Printer status information data
			68:SIPL Field full error 69: Power off error when charging 70: WLAN module error 71:Option mismatch error 72: Battery deterioration error (Notice) 73: Battery deterioration error (Warning) 74: Power off error 75:NonRFID Warning Error 76: Barcode reader connection error 77: Barcode reading error 78: Barcode verification error 79: Barcode reading error (Verification start position abnormality)
6	Battery status	BT	0: Normal 1: Battery near end 2: Battery error
7	Remaining number of print	Q	000000 to 999999: 6-digit remaining number of print

*1) Described error numbers contain errors which will never occur on this printer.

[Return data format (when a command error occurs)]

[NAK]<15>₁₆

[Supplemental explanation]

1. In the case of power supply, the battery status is always returned as 0: Normal.
2. The media status is returned as "Media present" unless paper end has reached during printing.
3. The correct value will be returned for receive buffer, ribbon end, media status, and battery when the error is updated.

