Dell PowerFlex v3.6.x

Log Collection Technical Notes

March 2023
Rev. 02

DELL Technologies

Notes, cautions, and warnings

NOTE: A NOTE indicates important information that helps you make better use of your product.

CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

WARNING: A WARNING indicates a potential for property damage, personal injury, or death.

© 2020 – 2023 Dell Inc. or its subsidiaries. All rights reserved. Dell Technologies, Dell, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Contents

Chapter 1: Log Collection 4

Chapter 2: Retrieving logs for the PowerFlex GUI and PowerFlex servers 5
Retrieve PowerFlex GUI logs 5
Retrieve ESXi operating system logs 5
Retrieve Linux operating system logs 6
Retrieve Windows operating system logs 6
Configure and retrieve operating system crash dumps 7

Chapter 3: Retrieving logs for PowerFlex components 8
Retrieve PowerFlex component logs manually 8
get_info 9
Automatically collect logs 9
Retrieve PowerFlex component logs using the PowerFlex Installer 10
Add LIA to a system to enable automated maintenance and upgrades 11
Change LIA behavior 12
Limit log collection scope during PowerFlex Installer maintenance tasks 13

Chapter 4: Addition PowerFlex logs 16
Retrieve RAID controller logs from VxFlex Ready Node systems 16
Retrieve vSphere PowerFlex plug-in logs 17
Retrieve PowerFlex Installer/PowerFlex Gateway logs 18
Retrieve system event logs in VxFlex Ready Node servers 18

1

Log Collection

Use the procedures in this guide to retrieve and view log files in PowerFlex and VxFlex Ready Node. Unless specified, the log retrieval procedures apply to all systems.

2

Retrieving logs for the PowerFlex GUI and PowerFlex servers

This section describes how to retrieve logs for the PowerFlex GUI and the PowerFlex server operating systems.

Retrieve PowerFlex GUI logs

Retrieve the PowerFlex GUI logs.

Prerequisites

Ensure that you have:

- Access to the operating system on the PowerFlex presentation server (which hosts the PowerFlex GUI).
- Admin rights and password for logging in to the PowerFlex presentation server.

About this task

PowerFlex GUI logs are collected in a system-defined folder on the local drive of the PowerFlex presentation server.

Steps

1. Using SSH, log in to the PowerFlex presentation server that runs the PowerFlex GUI for the logs you want to collect.
2. Navigate to `/opt/emc/scaleio/mgmt-server/diag/`.
3. Run:

   ```
   ./get_info.sh -u admin -p <password>
   ```

   where *<password>* is the PowerFlex GUI's admin password.

   For example:

   ```
   ./get_info.sh -u admin -p Scaleio123
   ```

   The following output should appear:

   ```
   Archive /tmp/scaleio-getinfo/getInfoDump.tgz created successfully
   ```

4. Retrieve the `getInfoDump.tgz` file from `/tmp/scaleio-getinfo/`.

Retrieve ESXi operating system logs

This topic describes how to retrieve the operating system logs from an ESXi server in PowerFlex.

Prerequisites

Ensure that you have access to the following:

- IP address of the node
- Password for the root user

About this task

When the OS is started, the ESXi operating system logs are collected in the system-defined folders `/var/log` and `/scratch/log/` on the local drive.

Steps

1. Log in to the PowerFlex node.
2. From ESXi, run the `scp` command to collect the ESXi operating system logs from the following folders on the local drive:
   - `/var/log`
   - `/scratch/log/`

   For additional data, see *VMware KB-653: Collecting diagnostic information for VMware ESX/ESXi* (https://kb.vmware.com/kb/653).

Retrieve Linux operating system logs

This topic describes how to retrieve the operating system logs from a Linux server in PowerFlex.

Prerequisites

Ensure that you have access to the following:

- IP address of the node
- Password for the root user
- Grab Utility, downloadable from the Support portal (https://support.dell.com)

About this task

When the Linux server is started, the Linux logs are collected in the system-defined directory `/var/log`, on the local drive. Operating system logs are also collected automatically whn running the get_info log collection process.

For information on running get_info, see Retrieve PowerFlex component logs manually.

Steps

1. Log in to the PowerFlex node.
2. Run the `scp` command to collect the Linux operating system logs from the `/var/log` directory on the local drive.

   The `/var/log` folder provides logs for preliminary system investigation.
3. To retrieve full logs, including customer- and OS-related information, run the Grab utility.

Retrieve Windows operating system logs

This topic describes how to retrieve the operating system logs from a Windows server in PowerFlex.

Prerequisites

Ensure that you have access to the following:

- IP address of the node
- Password for the administrator user
- Grab Utility, downloadable from Online Support portal (https://support.dell.com)

Steps

1. Log in to the PowerFlex node.
2. Run the Windows Event Viewer.

   The **Event Viewer** screen displays **Event Viewer (Local)** as the root node.
3. In the navigation pane, drill down to the **Windows Logs** node and select the **System** sub node.
   The **Actions** pane is displayed on the right side of the screen.
4. From the **Actions** pane, click **Save All Events As**.

The navigation tree with your local folders is displayed.

5. Browse to the intended location on your local drive, give the file an appropriate name, and select the file format.
6. Click **Save**.
   The Windows OS-related log files are saved on your local drive.

   The file on the local drive provides logs for preliminary system investigation.
7. To retrieve full logs, including customer- and OS-related information, run the Grab utility.

Configure and retrieve operating system crash dumps

Use this task to configure and retrieve the operating system crash dumps.

Prerequisites

Ensure that you have access to a web browser.

Steps

1. Open your web browser.
2. Configure and retrieve the crash dumps.
   To see the procedure, click an appropriate link that matches with your operating system:

Operating System	Link for crash dump configuration procedure
ESXi	http://kb.vmware.com/kb/1000328
Linux (RedHat)	https://access.redhat.com/solutions/6038
Linux (SLES)	https://www.suse.com/support/kb/doc?id=3374462
Windows	https://support.microsoft.com/en-ie/kb/969028

3. Analyze the crash dumps.
   To see the procedure, click an appropriate link that matches with your operating system:

Operating System	Link for crash dump configuration procedure
ESXi	http://kb.vmware.com/kb/1006796 or http://kb.vmware.com/kb/1004128
Linux (RedHat)	https://access.redhat.com/solutions/2121
Linux (SLES)	https://www.suse.com/support/kb/doc.php?id=7010484
Windows	https://support.microsoft.com/en-ie/kb/315263

3

Retrieving logs for PowerFlex components

You can retrieve the log files for PowerFlex components manually or automatically. You can collect the logs of one component at a time, or of all system components at one time. You can also enable automatic log collection that collects logs automatically when triggered by system alerts.

Retrieve PowerFlex component logs manually

You can retrieve the PowerFlex component logs manually, directly from the component server, one node at a time.

Prerequisites

Ensure that you have the following user login credentials:

- IP address of the node
- Password for the root user in ESXi- and Linux-based systems and the administrator user in Windows-based systems

About this task

The PowerFlex logs relate to specific components (MDM, SDS, or LIA) on each server node and its operating system environment.

Steps

1. SSH or RDP to the PowerFlex node.
   In ESXi-based PowerFlex, log in to the SVM (which is Linux-based).
2. Run the script for the PowerFlex component.

Operating System	Run this script
ESXi or Linux	`/opt/emc/scaleio/<PowerFlex component>/diag/get_info.sh -f` where the value of the PowerFlex component is mdm, sds, or lia
Windows	`"C:\Program Files\EMC\scaleio\<PowerFlex component>\diag\get_info.bat" -f` where the value of the PowerFlex component is mdm, sds, or lia

   The get_info syntax is explained fully in get_info.

   - If the selected node is the Master MDM, use the flags `-u <MDMuser> -p <MDMpassword>`, instead of `-f`.
   - If the selected node contains more than one PowerFlex component, running any script will gather logs for all components on that node.

   When the log collection process is complete, a `ZIP` file, containing the logs of all PowerFlex components in the node, is created in the `\Temp\ScaleIO-getinfo\n` directory.
3. Verify that output similar to the following is returned, which shows that the process of log collection was completed successfully:

```
Archive c:\Windows\Temp\ScaleIO-getinfo\getInfoDump.zip created successfully.
```

   NOTE: The script can generate numerous lines of output. Therefore, look for this particular line in the output.
4. Retrieve the log file.

get_info

Collects logs for Customer Support analysis.

Syntax

```
./get_info.sh [-help | Options]
```

Options:

-h, --help
Display help documentation.

-d <PATH>
Specify the path to receive all the collected information.

-c
Generate SDS and/or MDM core dump. Available only when one or more of the components are running.

-r
Collect repository files.

-e
Collect exception files only.

-l
Light version. Copy only trc.0 and exp.0 from the logs directory and repository files.

-u <USERNAME>
MDM username, which must be supplied with a password.

-p <PASSWORD>
MDM password, which must be supplied with a username.

-b
Collect MDM, SDS, LIA binaries and core dumps.

-g
Collect MDM, SDS, LIA binaries and valgrind core dumps.

-s
Collect SDBG output.

-f
Skip querying CLI info, when you do not have credentials.

-a
Collect all info.

-n
Connect to the MDM in nonsecure mode.

-k <Num>
Collect Num core files from each component. This flag implies -b.

-i <Input_file_name>
Extended configuration file.

Automatically collect logs

The Auto Collect Logs feature allows you to retrieve PowerFlex component logs that are collected automatically in response to a system alert of severity 3 or higher, even when you are not actively monitoring PowerFlex. Auto Collect Logs is disabled by default and can be enabled using the PowerFlex Installer. The feature applies to all PowerFlex components.

In order to use the Auto Collect Logs feature, a Lockbox must be configured with the MDM and LIA credentials saved in it, and the PowerFlex Gateway service restarted.

A new file is created at the following location every time Auto Collect Logs is triggered:

- Linux: `/opt/emc/scaleio/gateway/temp/scaleio-auto-collect-logs/`
- Windows: `C:\Program Files\EMC\ScaleIO\Gateway\Temp\scaleio-auto-collect-logs\`

Each log collection is saved in a `ZIP` file. The file name is a concatenation of the alert that triggered the log collection and a timestamp from when the log collection started.

The total capacity available for logs that are saved by the Auto Collect Logs feature is 1024 MB. When the log directory reaches 95% of its capacity, log deletion is initiated. Logs are deleted in a first-in, first-out manner, such that the oldest log file is deleted first. Log deletion stops when 20 percent of the capacity is available.

Once an automated log collection finishes, the Auto Collect Logs feature enters a cool-down period for 10 minutes. During this time, no logs are automatically collected, even if an alert of severity 3 or higher is issued. During automated log collection, the PowerFlex Installer is not available for any other actions, including manual log collection. When necessary, it is possible to abort an automated log collection from the **Monitor** tab in the PowerFlex Installer.

NOTE: When new nodes are manually added to an existing system, the Auto Collect Logs feature will not automatically collect logs from the new nodes. To have the new nodes included in the Auto Collect Logs, you should install the LIA with the correct LIA password on the new nodes and approve the new LIA certificate in the PowerFlex Installer. To approve the new LIA certificate, retrieve the system topology in the PowerFlex Installer. For detailed information, see "Add LIA to a system to enable automated maintenance and upgrades".

Retrieve PowerFlex component logs using the PowerFlex Installer

Use the PowerFlex Installer to automatically retrieve the PowerFlex component logs. This procedure collects the PowerFlex component logs on all the nodes in the system. You can also enable the Auto Collect Logs feature to automatically collect logs when triggered by a system alert of severity 3 or higher.

Prerequisites

Ensure that you have the following credentials for retrieving the system topology and accessing the PowerFlex Installer server:

- Master MDM IP address
- MDM username
- MDM password
- LIA password
- Password for the admin user for accessing the PowerFlex Installer

To enable the Auto Collect Logs feature, ensure that a lockbox has been configured, that the MDM and LIA credentials are saved in it, and that the PowerFlex Gateway service was restarted. If a lockbox has not previously been configured, see the *Configure and Customize Dell PowerFlex* for instructions on creating one.

You must approve the LIA certificate prior to enabling Auto Collect Logs.

Steps

1. Log in to the PowerFlex Installer:

Operating System	Steps
Windows- and Linux-based system	a. From Internet Explorer, browse to **`https://<Installer_server_IP_address>`**, where *<IInstaller_server_IP_address>* is the IP address of the PowerFlex Gateway server, with the PowerFlex Gateway/PowerFlex Installer package installed on it. b. From the PowerFlex Installer **Welcome** screen, enter the PowerFlex Installer credentials.
ESXi-based system	a. From the vSphere plug-in **VxFlex OS Systems** screen, right-click the system for which you want to collect the logs. b. Select **Open PowerFlex Gateway**.

Operating System	Steps
	NOTE: Opening the PowerFlex Gateway can take some time. c. From the PowerFlex Installer **Welcome** screen, enter the PowerFlex Installer credentials.

2. From the PowerFlex Installer main menu, select **Maintain**.
3. Enter the login credentials and click **Retrieve system topology**.
   The **Maintenance operation** view displays the system topology.
4. Click **System Logs & Analysis** and select the appropriate option:
   - To enable Auto Collect Logs, from the list box, select **Enable Auto Collect Logs**. Once enabled, you can disable it from the same list box.
     NOTE: While the logs are being collected, the PowerFlex Installer is unavailable for other actions. The automated log collection can be aborted from the **Monitor** tab.
   - To automatically collect component logs, select **Collect Logs** and proceed with the following steps.
5. Enter the **MDM admin** password and select one of the following options:
   - **Copy repositories**

     Besides full logs, includes the MDM repository from installed components.

     Usual size for the repository is ~306 MB
   - **Collect exceptions only**

     Instead of full logs, collects the PowerFlex Core dumps only.

     By default, PowerFlex Core dumps are disabled. Customer Support will instruct you if PowerFlex Core dumps need to be enabled.
   - **Last version**

     Instead of full logs, collects the most recently-created log file from each component.
6. Click **System Logs & Analysis**.
7. From the list box, select **Collect Logs**.
   The Get Info operation, the log collection function of the PowerFlex Installer, begins.

   This operation may take some time to complete, depending on your system topology. Once started, this operation can be rolled back.
8. Select the **Monitor** tab. Log collection progress is displayed.
9. When the Get Info operation is complete, click **Download logs** to download the log files.
   A `ZIP` file, containing all PowerFlex component logs, is downloaded.
10. Click **Mark operation completed** to clear the log files from the PowerFlex Installer and enable it to be available for other operations.

Add LIA to a system to enable automated maintenance and upgrades

Add the LIA, a component that is required to use the PowerFlex Installer to upgrade and maintain PowerFlex physical server system components.

Prerequisites

To determine if the LIA is installed, run the following command on any server in the system:

```
rpm -qa | grep -i LIA
```

If LIA is not installed, you must install it before proceeding.

Steps

1. Install the LIA component on every new node, by running the following command:

   ```
   TOKEN=<LIA_password> rpm -i <full rpm path to LIA file>
   ```

   Example:

   ```
   TOKEN=Scaleio123 rpm -i EMC-ScaleIO-lia-3.6-X.<build>.<flavor>.x86_64.rpm
   ```

   The LIA password must be identical in all LIAs within the same system

   The password must meet the following criteria:

   - Between 6 and 31, ASCII-printable characters
   - No blank spaces
   - Include at least 3 of the following groups: [a-z], [A-Z], [0-9], special chars (!@#$ …)

   NOTE: Do not use single or double quote characters in the TOKEN password.

   Example:

   ```
   48\%93\@72xP\#
   ```

   NOTE: If you use special characters on a Linux-based server, you must escape, (\), them when issuing the command. The escape, (\), preceding a character tells the shell to literally interpret that character.

   Example:

   ```
   TOKEN=Scaleio123\# rpm -i EMC-ScaleIO-lia-3.6-X.<build>.<flavor>.x86_64.rpm
   ```

2. Import the system installation ID into the LIA:
   a. Create the following file:
   `/opt/emc/scaleio/lia/cfg/installation_id.txt`
   b. Query the MDM for the installation ID by running the following command:

   ```
   scli --query_all|grep "Installation ID"
   ```

   c. Copy the installation ID into the new file.
   d. Restart the LIA service by running the following command:

   ```
   pkill lia
   ```

3. Repeat the previous steps on every new node in the system.
4. In the PowerFlex Installer, select the **Maintain** tab.
5. Enter the requested information and select **Retrieve system topology**.
   The alert `An attempt to query LIAs configuration failed: Error. Please refer to Monitor tab for more details.` is displayed.
6. Select the **Monitor** tab.
   For every certificate error displayed, select to view the certificate details and approve each certificate.

Results

LIA is installed.

Change LIA behavior

You can change the default behavior of the LIA by editing its configuration file.

The default location of the LIA configuration file is host operating system dependent, as follows:

- Windows: `C:\Program Files\emc\scaleio\LIA\cfg\conf.txt`

- Linux: `/opt/emc/scaleio/lia/cfg/conf.txt`

  The following are some values relevant to LIA behavior:

  ```
  lia_token=5
  lia_enable_install=1
  lia_enable_uninstall=1
  lia_enable_configure_fetch_logs=1
  ```

  To restrict which PowerFlex Gateway IP addresses can access the LIA, add those IP addresses to this line in the `conf.txt` file:

  ```
  lia_trusted_ips=<IP_ADDRESS_1>,<IP_ADDRESS_2>
  ```

  To set this during LIA installation, set the TRUSTED_IPS environment variable. For example:

  ```
  TRUSTED_IPS=1.2.3.4,5.6.7.8 rpm -i lia.rpm
  ```

Limit log collection scope during PowerFlex Installer maintenance tasks

PowerFlex Installer can collect logs successfully only in groupings of up to 512 hosts. Use this procedure to limit the scope of collected logs.

Prerequisites

Obtain the IP addresses of all the components in the PowerFlex system.

About this task

Logs are collected to the same disk partition where PowerFlex Gateway is installed. The available space can be limited. In large scale systems, where you are interested in collecting logs for specific maintenance actions, it is recommended to perform the maintenance actions on small batches of nodes.

Steps

1. Create IP address ignore lists in the `gatewayUser.properties` file.
   a. Using a text editor, open the `gatewayUser.properties` file, located in the following directory on the PowerFlex Gateway server:
      - Windows—`C:\Program Files\EMC\ScaleIO\Gateway\webapps\ROOT\WEB-INF\classes\`
      - Linux—`/opt/emc/scaleio/gateway/webapps/ROOT/WEB-INF/classes`
   b. Add a new line containing the property *im.ip.ignore.list=* for each batch of components that will be *ignored* during processing. Add a comma-separated list of IP addresses to the property. The first batch to be processed must include MDMs and SDSs, so they should not be included in the first ignore list. Subsequent batches should include all MDMs and up to 512 SDCs. Comment out the ignore lists for the second, and subsequent, batches, using the # symbol at the beginning of a line. Optionally, for clarity, add comments describing each ignore list.

   ```
   # Log collection ignore list for batch 1
   # sdc_group_01,sdc_group_02,sdc_group_03,sdc_group_04
   im.ip.ignore.list=<IP_ADDRESSES_SDC_GROUP_1><IP_ADDRESSES_SDC_GROUP_2><IP_ADDRESSES_
   SDC_GROUP_3><IP_ADDRESSES_SDC_GROUP_4>
   ```

   ```
   # Log collection ignore list for batch 2
   # all_sds,sdc_group_02,sdc_group_03,sdc_group_04
   #
   im.ip.ignore.list=<IP_ADDRESSES_ALL_SDS><IP_ADDRESSES_SDC_GROUP_2><IP_ADDRESSES_SDC_
   GROUP_3><IP_ADDRESSES_SDC_GROUP_4>
   ```

   ```
   # Log collection ignore list for batch 3
   # all_sds,sdc_group_01,sdc_group_03,sdc_group_04
   #
   ```

```
im.ip.ignore.list=<IP_ADDRESSES_ALL_SDS><IP_ADDRESSES_SDC_GROUP_1><IP_ADDRESSES_SDC_
GROUP_3><IP_ADDRESSES_SDC_GROUP_4>
```

```
# Log collection ignore list for batch 4
# all_sds,sdc_group_01,sdc_group_02,sdc_group_04
#
im.ip.ignore.list=<IP_ADDRESSES_ALL_SDS><IP_ADDRESSES_SDC_GROUP_1><IP_ADDRESSES_SDC_
GROUP_2><IP_ADDRESSES_SDC_GROUP_4>
```

```
# Log collection ignore list for batch 5
# all_sds,sdc_group_01,sdc_group_02,sdc_group_03
#
im.ip.ignore.list=<IP_ADDRESSES_ALL_SDS><IP_ADDRESSES_SDC_GROUP_1><IP_ADDRESSES_SDC_
GROUP_2><IP_ADDRESSES_SDC_GROUP_3>
```

Example:

```
# Log collection ignore list for batch 1
# sdc_group_01,sdc_group_02,sdc_group_03,sdc_group_04
im.ip.ignore.list=1.1.25.10,2.2.25.10,1.1.25.103,2.2.25.103,1.1.25.104,2.2.25.104,1.
1.25.106,...
```

```
# Log collection ignore list for batch 2
# all_sds,sdc_group_02,sdc_group_03,sdc_group_04
#
im.ip.ignore.list=1.1.90.20,4.4.90.20,3.3.90.20,2.2.90.20,1.1.90.21,4.4.90.21,2.2.90
.21,...
```

```
# Log collection ignore list for batch 3
# all_sds,sdc_group_01,sdc_group_03,sdc_group_04
#
im.ip.ignore.list=1.1.90.20,4.4.90.20,3.3.90.20,2.2.90.20,1.1.90.21,4.4.90.21,2.2.90
.21,...
```

```
# Log collection ignore list for batch 4
# all_sds,sdc_group_01,sdc_group_02,sdc_group_04
#
im.ip.ignore.list=1.1.90.20,4.4.90.20,3.3.90.20,2.2.90.20,1.1.90.21,4.4.90.21,2.2.90
.21,...
```

```
# Log collection ignore list for batch 5
# all_sds,sdc_group_01,sdc_group_02,sdc_group_03
#
im.ip.ignore.list=1.1.90.20,4.4.90.20,3.3.90.20,2.2.90.20,1.1.90.21,4.4.90.21,2.2.90
.21,...
```

c. Save and close the file.
d. Restart the PowerFlex Gateway service:
   - Windows—From the Windows **Services** window, restart the **EMC ScaleIO Gateway**.
   - Linux—Type the following command:

     ```
     service scaleio-gateway restart
     ```

2. Run the log collection procedure on the first batch of components.
3. Collect the logs from the nodes that were processed, and move them to another partition or node.
4. Edit the `gatewayUser.properties` file described in step 1.
   a. Comment out the first ignore list.
   b. Uncomment the second ignore list.
   Example:

   ```
   # Log collection ignore list for batch 1
   # sdc_group_01,sdc_group_02,sdc_group_03,sdc_group_04
   #
   ```

```
im.ip.ignore.list=1.1.25.10,2.2.25.10,1.1.25.103,2.2.25.103,1.1.25.104,2.2.25.104,1.
1.25.106,...
```

```
# Log collection ignore list for batch 2
# all_sds,sdc_group_02,sdc_group_03,sdc_group_04
im.ip.ignore.list=1.1.90.20,4.4.90.20,3.3.90.20,2.2.90.20,1.1.90.21,4.4.90.21,2.2.90
.21,...
```

c. Save and close the file.
d. Restart the PowerFlex Gateway service:
   - Windows—From the Windows **Services** window, restart the **EMC ScaleIO Gateway**.
   - Linux—Type the following command:

     ```
     service scaleio-gateway restart
     ```

5. Run the log collection process again for the second batch.
6. Collect the logs from the nodes that were processed, and move them to another partition or node.
7. If there are more than two batches of components to be processed, edit the `gatewayUser.properties` file again.
   a. Comment out the second batch of components.
   b. Uncomment the third batch of components.
   c. Save and close the file.
   d. Restart the PowerFlex Gateway service:
      - Windows—From the Windows **Services** window, restart the **EMC ScaleIO Gateway**.
      - Linux—Type the following command:

        ```
        service scaleio-gateway restart
        ```

8. Run the log collection process again for the third batch.
9. Collect the logs from the nodes that were processed, and move them to another partition or node.
10. Repeat the procedures in steps 6, 7, 8, and 9 for the remaining batches.

4

Addition PowerFlex logs

This section contains instructions for retrieving RAID controller, vSphere PowerFlex plug-in, PowerFlex Installer, and system event logs.

Retrieve RAID controller logs from VxFlex Ready Node systems

This topic describes how to retrieve the RAID controller logs from ESXi-, Linux-, and Windows-based servers in a VxFlex Ready Node system.

Prerequisites

Ensure that you have access to the following:

- IP address of the node
- Password for the root user in ESXi- and Linux-based systems and the administrator user in Windows-based systems
- The RAID controller utility, which is enabled (for details, refer to *Hardware Configuration and Operating System Installation Guide* of your system)

Steps

1. SSH or RDP to the VxFlex Ready Node.
2. Retrieve the controller information:

Operating System	Run this command

ESXi	`/opt/lsi/perccli/perccli /call show all > <file_name>`
	Example:
	`/opt/lsi/perccli/perccli /call show all > /var/tmp/store/RAIDinfo.txt`

Linux	`/opt/MegaRAID/perccli/perccli64 /call show all > <file_name>`
	Example:
	`/opt/MegaRAID/perccli/perccli64 /call show all > /var/tmp/store/RAIDinfo.txt`

3. Retrieve the `Show Events` log file:

Operating System	Run this command

ESXi	`/opt/lsi/perccli/perccli /call show events file=<file_name>`
	Example:
	`/opt/lsi/perccli/perccli /call show events file=/var/tmp/store/RAIDevents.txt`

Operating System	Run this command

Linux	`/opt/MegaRAID/perccli/perccli64 /call show events file=<file_name>`
	Example:
	`/opt/MegaRAID/perccli/perccli64 /call show events file=/var/tmp/store/RAIDevents.txt`

You can retrieve the `RAIDevents.txt` file from your local drive.

4. Retrieve the `Termlog` log file:

Operating System	Run this command

ESXi	`/opt/lsi/perccli/perccli /call show termlog file=<file_name>`
	Example:
	`/opt/lsi/perccli/perccli /call show termlog file=/var/tmp/store/RAIDtermlog.txt`

Linux	`/opt/MegaRAID/perccli/perccli64 /call show termlog file=<file_name>`
	Example:
	`/opt/MegaRAID/perccli/perccli64 /call show termlog file=/var/tmp/store/RAIDtermlog.txt`

You can retrieve the `RAIDtermlog.txt` file from your local drive.

Retrieve vSphere PowerFlex plug-in logs

This topic describes how to retrieve the vSphere PowerFlex plug-in logs from ESXi-based servers in PowerFlex.

Prerequisites

Ensure that you have access to the following:

- IP address of the vCenter where the PowerFlex plug-in is installed
- Login credentials for the vCenter

About this task

NOTE: To re-enable SFTP access using winscp and retrieve the logs, refer to the steps defined in the following knowledge base article: https://kb.vmware.com/s/article/2107727

Steps

1. SSH or RDP to the vCenter server.
2. Retrieve all the files from the following folders, depending on the vCenter server's operating system:

Operating System	vCenter 6.x log folders
Linux	• `/var/log/vmware/vsphere-client/logs` • `/etc/vmware/vsphere-client/vc-packages/scaleio`

Operating System	vCenter 6.x log folders
	• /etc/vmware/vsphere-client/vc-packages/vsphere-client-serenity • /usr/lib/vmware-vsphere-client/server/configuration
Windows	• C:\ProgramData\VMWare\vCenterServer\logs\vsphere-client\logs • C:\Users\vspherewebclientsvc\AppData\Roaming\VMware\scaleio • C:\ProgramData\VMware\vCenterServer\cfg\vsphere-client\vc-packages\vsphere-client-serenity • C:\ProgramData\VMware\vCenterServer\runtime\vsphere-client\server\configuration

Retrieve PowerFlex Installer/PowerFlex Gateway logs

Retrieve the PowerFlex Installer/PowerFlex Gateway log files, which are downloaded in a single ZIP file.

Prerequisites

Ensure that you have access to:

- The admin-level user password for accessing the PowerFlex Installer
- IP address of the PowerFlex Installer server

Steps

1. From a web browser, go to **https://*<Installer_Server_IP_Address>***.
   where *<Installer_Server_IP_Address>* is the IP address of the PowerFlex Gateway server, with the PowerFlex Gateway/ PowerFlex Installer package installed on it.
2. From the **Installer** main menu, select **Maintain**.
   The **Maintenance operation** view appears.
3. Click the **Download Installer logs** link.
   The PowerFlex Installer logs are collected as a single ZIP file in the browser-configured location.

Retrieve system event logs in VxFlex Ready Node servers

This topic describes how to access the system events logs (SEL) in a VxFlex Ready Node server.

Prerequisites

Ensure that you have access to the following:

- IP address of the iDRAC port
- Login credentials for the iDRAC (admin/admin as default username/password)

Steps

1. From a web browser, go to **http://*<IP_address_iDRAC_port>***.
2. In the **Console Login** window, type the user name and password, then click **Login**.
3. To view the event log, select **View Logs** in the **Quick Launch Tasks** pane.
   The **System Event Log** is displayed with color-coded severity levels.
4. To save the event log, click the **Save As** button at the bottom of the table.
   The event log is saved in a `.CSV` file.

   The power supply- and fan-related errors in **Event Log** may be intermittent in nature, and therefore may display repetitive events for one module. For such errors, it is recommended that you remove the module and replace it in its socket. This might be a connection-related issue.