








Visualization: Simple Elements





We software Automation.









Visualization: Simple Elements

This training shows you how to use simple visualization elements in CoDeSys.





Introduction


After this module you will be able to ...

- configure simple visualization elements
- use static properties
- use dynamic properties
- display texts
- display values
- configure value changes
- display pictures
- configure this: <u>Documents\Solution.avi</u>





Static properties












Dynamic properties (Toggle Color)












- Use the project SimpleElements_All_Exercise.project.
- Create an object (rectangle) on the visualization screen.
- Configure colour toggling depending on the boolean variable PLC PRG.xblink








Dynamic properties - movements





'Absolute movement' moves, rotates and scales the **whole** object.













Dynamic properties - movements



Most objects have the property 'Rotation'.
The object's position can rotate around a defined center point. The center is the black dot with the white cross inside.















Dynamic properties - movements





Objects (polygon and polyline) with the property 'Interior rotation' can rotate around their centers marked by the black dot.










- Use the result project from Exercise 1.
- Have the rectangle move in X and Y direction by using the variables: PLC PRG.rXPOS and PLC PRG.rYPOS
- Create another rectangle and use PLC_PRG.iRotation to rotate it around a centerpoint outside the object
- Create a triangle and rotate it by using the variable PLC PRG.iRotation
 - Try different positions of the center point





X+

Dynamic properties - movements



'Relative movement' moves the edges thus scaling up or down the object.














- Use the result project from Exercise 2.
- Create a new rectangle and use the relative movement for the bottom right corner (use PLC_PRG.rXPos and PLC_PRG.rYPos).



Display static texts
















Display value
















- Use the result project from Exercise 3.
- Create a new rectangle. Enter a text in 'Texts-Text' and a different one in 'Texts-Tooltip'
- Create a new rectangle. Enter a text with an included format string and connect a variable in 'Text variables' – 'Text Variable' (try different format strings).





Toggle/Tap boolean values

















Change values – by keyboard















Change values - by numpad / keypad















- Use the result project from Exercise 4.
- Use an object to toggle PLC_PRG.xToggle.
- Use another object to tap PLC_PRG.xTap.
- Enable the editing of the displayed variable PLC_PRG.ri.
- Copy the rectangle and configure the editing PLC_PRG.ri by numpad.















- Add at least one Image Pool.
- Refer to the image or include it in the Image Pool now accessible by ID.
- Use the ID to add the image to the visualization
















Display pictures / scaling and clipping





21












Exercise 6

- Use the project SimpleElements_All_Exercise.
- Create all elements.
- All texts are white on a silver background.

CoDeSys logo moves up and down controlled by PLC_PRG.rYPos.

Top line moves up and down controlled by PLC PRG.rYPos.

Toggles PLC PRG.xEnable: Changes color to green if xEnable is true.

















Multiple Pages - Change Shown Visualization

Page1

- Use the 'Change shown visualization' command to change between visualizations.
- You can change to a specified 'Page' by assignment.



















Multiple Pages – Change Shown Visualization

The page changes are recorded → you can step to the previous and next 'Page'


















- Use the project 'ChangeShownVisuExercise'.
- Create the following navigation structure by configuring the input actions of the buttons.






Keyboard configuration

- Hotkeys valid for all visualizations in the whole application can be defined.
- Possible action types:
 - Change shown visualization
 - Change language
 - Close dialog

- Execute command
- Execute ST-Code
- Open dialog









Visualization Manager 🌃 TargetVisualization WebVisualization









We software Automation

Keyboard configuration


- Keys just for one visualization
- Additional possible action types:
 - Execute mouse event (only down and up)
 - Change frame visualization
 - Write a variable








- Use the result project from Exercise 7.
- Configure the cursor keys on your keyboard to initiate the commands assigned to the buttons.
- Configure the ESCAPE key to always to the previous page.
- Configure the HOME key to change to Page1.













Let's check

Summary: CoDeSys allows you...

- the simple and easy creation of visualizations
- direct access to all variables in the application
- to change the displayed values with just a few mouse clicks
- to work with multiple pages (visualizations)
- to navigate between the pages
 - absolute navigation
 - relative navigation (previous/next)
- to configure your keyboard according to your needs









