









1. Connect the machine to the electricity supply.

2.Plug one end of USB cable into USB port of your computer

3. Plug the other end into PBC board of the machine

The firmware is optimized by my company, and then loaded on mainboard, please do not upgrade The firmware by yourself.

After the USB cable plugged, the USB driver will auto-install on Win7 system, as picture below



1. System prompted the USB driver is installing



2. Setup complete, different 3d printer has different USB Serial port, here shows **COM13**









































