



PRE-FLIGHT CHECKS

BATTERY N1, N2..... ON
BATTERY N3, N4..... ON
FIRE SYSTEM AGENT ARM..... ON
APU START SWITCH ON
APU START MODE.....START
START BUTTONPRESS
APU POWER SELECTOR..... ON
RECTIFIER N2, N1 ON
PTS-250 INVERTER ON
NAV LIGHTS ON
ELEC HYD PUMP 1, 2..... ON
HYD CROSSFEED..... ON
ACCUMULATOR CHARGEPRESS
HYD CROSSFEED..... OFF
ELEC HYD PUMP 1, 2..... OFF
PARK BRAKE.....SET
APU BLEED HOLD UP
L, R LINE AIR MASS SUP UP
PRESSURE VALVE BOTH UP
CABIN TEMP SELECTALL AUTO
GROUND AIR CONDITION ON
AP FD ON
FDI L, R..... ON
VG REF ON



COMPASS POWER N1, N2 ON
GYRO HEAT (IF OAT < 15).....AS NEEDED
MAG CORRECTION N1, N2 ON
VOR/ILS HDI L, R MAG
IAS SYSTEM POWER ON
IAS SYSTEM HEAT.....AS NEEDED
UNS MAIN ON
UNS NAV ON
UNS VOR 2 AUTO
UNS NAV VOR 2 AUTO
UNS VOR 1 MAN
UNS NAV VOR 1 MAN
UNS VOR 1/2..... SET NM
VSI RIGHT ON
TCAS MAIN..... TA/RA
TCAS BACKUP..... AC
VBE N1 ON
COURSE MP N1, N2..... ON
TRA 76A ON
RSCN POWER (NVU NAV).....AS NEEDED
RSCN RECON (NVU NAV)AS NEEDED
RADIO-ALT N1, N2 ON
VHF N1, N2 ON
GYRO ROLL STAB MAIN & REF ON
HF RADIO N1, N2 ON



INT	ON
AUDIO	ON
DME N1, N2	ON
VOICE RECORDER.....	ON
VBE N2	ON
DOPPLER POWER.....	ON
DOPPLER MODE.....	GROUND
NAV.....	NVU BY DOPP
VSI LEFT	ON
AOA INDICATOR.....	ON
UVID	ON
TURN INDICATOR.....	ON
AHZ AUX	ON
ATT POWER	ON
SEATBELT SIGN	ON
NO SMOKING SIGN	ON
EXIT LIGHTS.....	ON
ABSU PREPARE NAV.....	NAV
ABSU NEEDLES ON AHZ	ON
ABSU ROLL CHANNEL.....	ON
ABSU PITCH CHANNEL	ON
NVU POWER	ON

**FUEL SYSTEM**

FLOWMETER GAUGE SET
TANK 2L, 2R ON
TANK 3L, 3R ON
TANK 4 ON
SERVICE TANK 1 ALL ON
EQUALIZER ON
FUEL AUTO ON
FUEL MANAGEMENT ON
MSRP FLIGHT RECORDER ON
RECORDER MAIN ON
RECORDER AUX ON
BEACON LIGHTS ON



ALIGN COMPASS AND GYROS

LATITUDESET
COMPASS MODE..... MAG
COMPASS USERS..... MAIN
COMPASS CORRECTION MAIN
ADJUSTMENTPRESS
COMPASS CORRECTIONREF
ADJUSTMENTPRESS
COMPASS MODE.....DG
COMPASS CORRECTION MAIN
ADJUSTMENTPRESS
COMPASS CORRECTIONREF
ADJUSTMENTPRESS
COMPASS MODE..... MAG
COMPASS CORRECTION MAIN



ENGINE START

GEAR BLOCKS..... REMOVED
GROUND AIR CONDITION OFF
ENGINE FIREWALL VALVES..... ALL ON
PRESSURE VALVES BOTH DOWN
ENGINE INST. SWITCH..... ALL ON
ENGINE START PANEL OPEN
FUEL CUTOFF HANDLES ON
STARTER MAIN SWITCH ON
START MODE START
AIR PRESSURE >35 KG/CM2
ENGINE SELECT 1
ENGINE START PRESS
ENGINE 1 GENERATOR..... CHECK
ENGINE 1 GENERATOR..... ON
ENGINE 1 BLEED ON
ENGINE SELECT 2
ENGINE START PRESS
ENGINE 2 GENERATOR..... CHECK
ENGINE 2 GENERATOR..... ON
ENGINE 2 BLEED ON
ENGINE SELECT 3
ENGINE START PRESS
ENGINE 3 GENERATOR..... CHECK
ENGINE 3 GENERATOR..... ON



ENGINE 3 BLEED ON
ENGINE SELECT OFF
START MODECRANK
STARTER MAIN SWITCH OFF
ENGINE START PANEL CLOSED

BEFORE START

ATT TESTUP & DOWN
AP FDOFF THEN ON
ICE DETECT ON
PTS-250 INVERTER OFF
FUEL QTY INDICATOR ON
FUEL FLOWMETER ON

AFTER ENGINE START

APU POWER SELECTOR OFF
APU BLEEDHOLD DOWN
APU SHUTDOWNPRESS
APU START MODECRANK
APU START SWITCH OFF
CABIN PRESSURE 650 mm Hg
CABIN PRESSURE DIFF SET 0.6
PRESSURE VALVES BOTH UP
CABIN TEMP SET
FLIGHT CONTROL BOOSTERS ALL ON
WINDSHIELD HEAT LOW

**BEFORE TAXI**

NOSEWHEEL STEERING 63 DEGREES
PARKING BRAKE RELEASE
FLAPS SET
TAXI LIGHTS EXTEND
RLS SYSTEM POWER ON
RLS SYSTEM TEST
AUTOTHROTTLE PREPARE ON

BEFORE TAKEOFF

LANDING LIGHTS EXTEND
SIGNAL LIGHTS ON
PITOT HEAT ON
RLS SYSTEM ON
FLIGHT STOPWATCH RED

AFTER LINEUP RUNWAY

NOSEWHEEL STEERING 10 DEGREES
CHECK: NOT READY NOT LIT



TAKEOFF AND CLIMB

POWER FULL (595 MAX)
GEAR UP & OFF
FLAPS OFF
LANDING LIGHTS (>350 KM/H) OFF
CABIN PRESSURE 760 mm Hg
POWER CLIMB (585 MAX)
CLIMB (<10000 FT) 250 KT
CLIMB (>10000 FT) 295 KT
SIGNAL LIGHTS OFF
HIGH ALT. CLIMB 0.78 MACH
CRUISE SPEED 0.89 MACH

DESCENT

INITIAL DESCENT SPEED 80 MACH
DESCENT ABOVE FL100 270 KT
DESCENT BELOW FL100 250 KT
SIGNAL LIGHTS ON
500 FT/MIN = 2.54 M/S
1000 FT/MIN = 5.08 M/S
1500 FT/MIN = 7.62 M/S
2000 FT/MIN = 10.16 M/S
2500 FT/MIN = 12.7 M/S



AFTER LANDING

NOSEWHEEL STEERING 63 DEGREES
FLAPS UP
SPOILERS RETRACTED
TAXI LIGHTS ON
APU START SWITCH ON
APU START MODE START
APU START BUTTON PRESS
L & R SIDE WINDOWS OPEN
SIGNAL LIGHTS OFF
AP MODE RESET
ABSU PREPARE NAV OFF
ABSU PREPARE LANDING OFF

PARKING AND SHUTDOWN

PARKING BRAKE SET
GEAR BLOCKS SET
ENGINE 1, 3 BLEED OFF
APU POWER SELECTOR ON
ENGINE 1, 3 GENERATOR OFF
ENGINE 1, 3 FUEL CUTOFF OFF
DOORS OPEN
OHD SWITCHES ALL OFF
FUEL SYSTEM ALL OFF
BOOSTERS ALL OFF