



MEL PC-12
HB-FVT

Issue 1 Revision 0

01.05.2023

0 Preamble
1 Item Base Relief
2 CAS Message Based Relief
3 MOP



0	Preamble	0-1
0.1	Introduction	0-2
0.2	Contents of MEL	0-3
0.3	Criteria for dispatch	0-3
0.4	Maintenance action	0-3
0.5	Rectification intervals	0-3
0.6	Rectification interval extension	0-4
0.7	Definitions	0-4
0.8	Centralized message system	0-6
0.9	Operations outside the scope MEL	0-6
0.10	Kind of operation and equipments	0-6
0.11	Approval	0-8
0.12	AMAC Policy	0-8
1	Item Base Relief	1-1
1.1	ATA 21 – Air conditioning	1-2
1.2	ATA 22 – Auto Flight	1-5
1.3	ATA 23 – Communications	1-6
1.4	ATA 24 – Electrical power	1-8
1.5	ATA 25 – Equipment and furnishings	1-9
1.6	ATA 26 – Fire protection	1-14
1.7	ATA 27 – Flight controls	1-15
1.8	ATA 28 – Fuel	1-17
1.9	ATA 30 – Ice and rain protection	1-18
1.10	ATA 31 – Indicating and recording systems	1-20
1.11	ATA 32 – Landing gear	1-21
1.12	ATA 33 – Lights	1-22
1.13	ATA 34 – Navigation	1-24
1.14	ATA 35 – Oxygen	1-32
1.15	ATA 45 – Central Maintenance System (CMS)	1-33
1.16	ATA 46 – Information systems	1-34



1.17	ATA 52 – Doors	1-38
1.18	ATA 56 – Windows	1-39
1.19	ATA 77 – Engine indicating	1-40
2	CAS Message Based Relief	2-1
2.1	PREAMBLE – CAS MESSAGES	2-1
3	MOP	3-1
3.1	ATA 21 – AIR CONDITIONING	3-4
3.1.1	21-10-01A – Air cycle system	3-4
3.1.2	21-30-01D – Cabin pressurization system	3-5
3.1.3	21-30-02D – Pressurization safety valve	3-6
3.1.4	21-30-03A – Cabin altitude indicator	3-7
3.1.5	21-30-04B – Cabin altitude warning system	3-8
3.1.6	21-30-05A – Cabin rate of climb indicator	3-9
3.1.7	21-30-06A – Differential pressure indicator	3-10
3.1.8	21-30-10A – Emergency dump function	3-11
3.1.9	21-40-01-2D – Auxiliary heating system	3-12
3.1.10	21-40-01-2E – Auxiliary heating system	3-13
3.1.11	21-40-01-2F – Auxiliary heating system	3-13
3.1.12	21-50-01A – Vapour cycle cooling system (VCCS)	3-14
3.2	ATA 22 – AUTO FLIGHT	3-15
3.2.1	22-10-01A – Autopilot	3-15
3.2.2	22-10-02A – Autopilot disconnect functions – Quick release controls	3-16
3.3	ATA 23 – COMMUNICATIONS	3-17
3.3.1	23-30-01B – Public address system	3-17
3.4	ATA 25 – EQUIPMENT AND FURNISHINGS	3-18
3.4.1	25-11-01-1A – Flight crew compartment seats – Horizontal adjustment	3-18
3.4.2	25-11-01-2A – Flight crew compartment seats – Vertical adjustment	3-19
3.4.3	25-11-01-3A – Flight Crew Compartment Seats – Other Adjustment except Horizontal, Vertical and Armrest Adjustment	3-20
3.4.4	25-11-01-5A – Flight Crew Compartment Seats – Armrest	3-21
3.4.5	25-20-01 – Storage cabinets/wardrobe	3-22



3.4.6	25-21-01A – Passenger seats	3-23
3.4.7	25-21-01-1A – Passenger seats – Recline function	3-24
3.4.8	25-21-01-3A – Passenger seat – Armrests with recline/swivel control mechanism	3-25
3.4.9	25-21-01-4A – Passenger seats – Armrests without recline/swivel control mechanism	3-26
3.4.10	25-21-01-5A – Passenger Seats – Swivel/Travel Mechanism	3-27
3.4.11	25-40-01A – Lavatory waste system	3-28
3.4.12	25-64-01 – Life Jackets	3-29
3.5	ATA 26 – FIRE PROTECTION	3-30
3.5.1	26-24-01A – Hand fire extinguishers	3-30
3.6	ATA 27 – FLIGHT CONTROLS	3-31
3.6.1	27-15-01A – Aileron trim	3-32
3.6.2	27-20-01A – Rudder trim position indication	3-33
3.6.3	27-30-01A – Stabiliser trim position indication	3-34
3.6.4	27-50-01A – Flap position indication	3-35
3.7	ATA 28 – FUEL	3-36
3.7.1	28-40-01A – Fuel quantity indication	3-36
3.7.2	28-40-01B – Fuel quantity indication	3-37
3.8	ATA 30 – ICE AND RAIN PROTECTION	3-38
3.8.1	30-00-01B – Inertial separator	3-38
3.8.2	30-41-01A – Windshield heating system	3-39
3.9	ATA 31 – INDICATING AND RECORDING SYSTEMS	3-40
3.9.1		3-40
3.9.2	31-22-01A – Hour meter	3-40
3.10	ATA 32 – LANDING GEAR	3-41
3.10.1	32-40-01A – Parking brake	3-41
3.11	ATA 33 – LIGHTS	3-42
3.11.1	33-20-02A – Cabin signs – Fasten seat belt/No smoking	3-42
3.12	ATA 34 – NAVIGATION	3-43
3.12.1	34-15-01A (ALL) – Altitude alerting system	3-43



3.12.2	34-40-01B – Traffic alert and collision avoidance system (TCAS)	3-44
3.12.3	34-43-01-3A (ALL) – Advisory call-outs	3-45
3.12.4	34-43-02-5A – Advisory call-outs	3-46
3.12.5	34-50-01-1A (ALL) – Navigation databases	3-47
3.12.6	34-50-01-1B – Navigation databases	3-48
3.12.7	34-51-01B – Navigation system	3-49
3.13	ATA 35 – OXYGEN	3-50
3.13.1	35-10-01-1A (ALL) – Flight Deck Pressure Indications	3-50
3.13.2	35-20-01A (ALL) – Passenger oxygen system	3-51
3.13.3	35-20-01-1A – Passenger service units	3-52
3.14	ATA 46 – INFORMATION SYSTEMS	3-53
3.14.1	46-10-01-1A – Modular avionics unit (MAU) - Actuator input/output processor (AIOP) module channels	3-53
3.14.2	46-10-01-2A – Modular avionics unit (MAU) – Advanced graphics module (AGM) channels	3-54
3.14.3	46-20-01-1A – Display units – Four display configuration	3-55
3.14.4	46-32-01A – Wireless data loading/downloading system	3-56
3.15	ATA 52 – DOORS	3-57
3.15.1	52-10-01A – Door key locks	3-57
3.15.2	52-20-01A – Cabin door seal	3-58
3.15.3	52-20-02A – Cargo door seal	3-59
3.15.4	52-20-03A – Emergency exit seal	3-60
3.15.5	52-70-01A – Door warning system (Caption and voice callout)	3-61
3.16	ATA 56 – WINDOWS	3-62
3.16.1	56-20-01A – DV-window seal	3-62
3.17	CAS MESSAGES	3-63
3.17.1	DME 1 Fail (Caution)	3-63
3.17.2	FCMU Fault (Status)	3-64
3.17.3	GPS 1 Fail (Advisory)	3-65
3.17.4	GPS 2 Fail (Advisory)	3-66
3.17.5	MMDR 2 Fail (Caution)	3-67



Revision Number	Revision Date
0	01.05.2023



Approved by:	Date:	Sign:
--------------	-------	-------

Chapter	Page	Revision	Date	Chapter	Page	Revision	Date
		0	01.05.2023	1	23	0	01.05.2023
		0	01.05.2023	1	24	0	01.05.2023
		0	01.05.2023	1	25	0	01.05.2023
		0	01.05.2023	1	26	0	01.05.2023
		0	01.05.2023	1	27	0	01.05.2023
		0	01.05.2023	1	28	0	01.05.2023
		0	01.05.2023	1	29	0	01.05.2023
		0	01.05.2023	1	30	0	01.05.2023
		0	01.05.2023	1	31	0	01.05.2023
		0	01.05.2023	1	32	0	01.05.2023
0	1	0	01.05.2023	1	33	0	01.05.2023
0	2	0	01.05.2023	1	34	0	01.05.2023
0	3	0	01.05.2023	1	35	0	01.05.2023
0	4	0	01.05.2023	1	36	0	01.05.2023
0	5	0	01.05.2023	1	37	0	01.05.2023
0	6	0	01.05.2023	1	38	0	01.05.2023
0	7	0	01.05.2023	1	39	0	01.05.2023
0	8	0	01.05.2023	1	40	0	01.05.2023
1	1	0	01.05.2023	2	1	0	01.05.2023
1	2	0	01.05.2023	2	2	0	01.05.2023
1	3	0	01.05.2023	2	3	0	01.05.2023
1	4	0	01.05.2023	2	4	0	01.05.2023
1	5	0	01.05.2023	2	5	0	01.05.2023
1	6	0	01.05.2023	3	1	0	01.05.2023
1	7	0	01.05.2023	3	2	0	01.05.2023
1	8	0	01.05.2023	3	3	0	01.05.2023
1	9	0	01.05.2023	3	4	0	01.05.2023
1	10	0	01.05.2023	3	5	0	01.05.2023
1	11	0	01.05.2023	3	6	0	01.05.2023
1	12	0	01.05.2023	3	7	0	01.05.2023
1	13	0	01.05.2023	3	8	0	01.05.2023
1	14	0	01.05.2023	3	9	0	01.05.2023
1	15	0	01.05.2023	3	10	0	01.05.2023
1	16	0	01.05.2023	3	11	0	01.05.2023
1	17	0	01.05.2023	3	12	0	01.05.2023
1	18	0	01.05.2023	3	13	0	01.05.2023
1	19	0	01.05.2023	3	14	0	01.05.2023
1	20	0	01.05.2023	3	15	0	01.05.2023
1	21	0	01.05.2023	3	16	0	01.05.2023
1	22	0	01.05.2023	3	17	0	01.05.2023

(continued)



Chapter	Page	Revision	Date	Chapter	Page	Revision	Date
3	18	0	01.05.2023	3	43	0	01.05.2023
3	19	0	01.05.2023	3	44	0	01.05.2023
3	20	0	01.05.2023	3	45	0	01.05.2023
3	21	0	01.05.2023	3	46	0	01.05.2023
3	22	0	01.05.2023	3	47	0	01.05.2023
3	23	0	01.05.2023	3	48	0	01.05.2023
3	24	0	01.05.2023	3	49	0	01.05.2023
3	25	0	01.05.2023	3	50	0	01.05.2023
3	26	0	01.05.2023	3	51	0	01.05.2023
3	27	0	01.05.2023	3	52	0	01.05.2023
3	28	0	01.05.2023	3	53	0	01.05.2023
3	29	0	01.05.2023	3	54	0	01.05.2023
3	30	0	01.05.2023	3	55	0	01.05.2023
3	31	0	01.05.2023	3	56	0	01.05.2023
3	32	0	01.05.2023	3	57	0	01.05.2023
3	33	0	01.05.2023	3	58	0	01.05.2023
3	34	0	01.05.2023	3	59	0	01.05.2023
3	35	0	01.05.2023	3	60	0	01.05.2023
3	36	0	01.05.2023	3	61	0	01.05.2023
3	37	0	01.05.2023	3	62	0	01.05.2023
3	38	0	01.05.2023	3	63	0	01.05.2023
3	39	0	01.05.2023	3	64	0	01.05.2023
3	40	0	01.05.2023	3	65	0	01.05.2023
3	41	0	01.05.2023	3	66	0	01.05.2023
3	42	0	01.05.2023	3	67	0	01.05.2023



Abbreviation	Definition	Page
ADS-B	Automatic Dependent Surveillance Broadcast	1-31
AFM	Airplane Flight Manual	0-5
AIOP	Actuator Input/Output Processor	1-34
APCH	Approach	0-7
AR	Autorisation Required	0-7
ATA	Air Transport Association	0-6
CCD	Cursor Control Device	1-37
CMC	Central Maintenance Computer	1-33
CMM	Component Maintenance Manual	3-19
CPDLC	Controller Pilot Data Link Communication	0-7
CVFDR	Cockpit Voice and Flight Data Recorder	1-20
DAP	Downlinked Aircraft Parameters	1-31
EASA	European Aviation Safety Agency	0-2
ECS	Environmental Control System	1-3
ELS	Elementary Surveillance	1-30
ELT	Emergency Locator Transmitter	1-12
EPS	Emergency Power Supply	1-8
ESIS	Electronic Standby Instrument System	1-24
FIKI	Flight Into Known Icing conditions	0-7
FOD	Foreign Object Debris	1-18
GNSS	Global Navigation Satellite System	0-7
IAF	Instrument Approach Fix	1-27
IFR	Instrument Flight Rules	0-5
INOP	Inoperative	0-3
IOAT	Indicated Outside Air Temperature	1-3
LVTO	Low Visibility Take Off	0-7
MAU)	Modular Avionic Unit	1-34
MEL	Minimum Equipment List	0-2
MFC	Multi Function Controller	1-34
MFD	Multi Function Display	1-34
PA	Pax Announcement	1-6
PFD	Primary Flight Display	1-34
RNAV	Radio Navigation	0-7
RNP	Required Navigation Performance	0-7
RVSM	Reduced Vertical Separation Minima	0-7
SSR	Secondary Surveillance Radar	1-30
TAWS	Terrain Awareness Warning System	1-28
TCAS	Traffic alert and Collision Avoidance System	1-27
TECHLOG	Technical Log	0-4
UTC	Universal Time Coordinated	0-5
VCCS	Vapour Cycle Cooling System	1-4
VFR	Visual Flight Rule	0-7
VMC	Visual Meteorological Condition	0-5



Abbreviation	Definition	Page
There are no abbreviations		



0.1	Introduction	0-2
0.2	Contents of MEL	0-3
0.3	Criteria for dispatch	0-3
0.4	Maintenance action	0-3
0.5	Rectification intervals	0-3
0.6	Rectification interval extension	0-4
0.7	Definitions	0-4
0.8	Centralized message system	0-6
0.9	Operations outside the scope MEL	0-6
0.10	Kind of operation and equipments	0-6
0.11	Approval	0-8
0.12	AMAC Policy	0-8



0.1 Introduction

This Minimum Equipment List (MEL) is based on:

- EASA Pilatus PC-12 series Master Minimum Equipment List (document 02395) Issue 001, Revision 06 dated March 09/2022
- EASA Pilatus PC-12 series Maintenance and Operating Procedures (document 02398) Issue 001, Revision 5 dated March 09/2022.

This MEL shall be revised and notified to FOCA within an acceptable timescale of 90 days after:

- any applicable change to the MMEL and/or MMOP;
- a reduction of rectification intervals;
- change of an item, only when the change is applicable to the aircraft or type of operations and is more restrictive;
- reduced timescales for the implementation of safety-related amendments may be required by the Agency and/or the competent authority.

This MEL takes into consideration AMAC Corporate Jet particular aircraft equipment, configuration and operational conditions and routes being flown.

This MEL will not deviate from the any applicable Airworthiness Directives or any other requirements and will be no less restrictive than the MMEL.

The MEL is intended to permit operations with inoperative items of equipment for a specified period of time until rectification has to be accomplished.

Rectifications are to be accomplished at the earliest opportunity, but within the timeframe specified in the MEL.

MEL conditions and limitations do not relieve the Pilot-in-Command from determining that the aircraft is in a fit condition for safe operation with specified unserviceable items or systems allowed by the MEL.

The provisions of the MEL are applicable until the airplane commences the flight, i.e. the point at which an aircraft begins to move under its own power for the purpose of preparing for take-off.

Any decisions to continue a flight following a failure or unserviceability which becomes apparent after the commencement of a flight must be the subject of pilot judgment and good airmanship. The Pilot-in-Command may continue to make reference to and use of the MEL as appropriate.

By publication of the MEL, AMAC Corporate Jet permits dispatch of the airplane for non-revenue, ferry or training flight with certain items or components inoperative provided an acceptable level of safety is maintained by use of appropriate operational or maintenance procedures, by transfer of the function to another operating component, or by reference to other instruments or components providing the required information.



0.2 Contents of MEL

The MEL contains only those items required by Operating Regulations or those items of airworthiness significance which may be inoperative prior to dispatch, provided that appropriate limitations and procedures are observed. Equipment obviously basic to the aircraft's airworthiness such as wings, rudders, flaps, engines, landing gear, etc. is not listed and must be operative for all flights.

NOTE: ALL ITEMS WHICH ARE RELATED TO THE AIRWORTHINESS OF THE AIRCRAFT AND NOT INCLUDED ON THE LIST ARE AUTOMATICALLY REQUIRED TO BE OPERATIVE.

0.3 Criteria for dispatch

The decision of the Pilot-in-Command of the flight to have allowable inoperative items corrected prior to flight will take precedence over the provisions contained in the MEL. The Pilot-in-Command may request requirements above the minimum listed, whenever in his judgment such added equipment is essential to the safety of a particular flight under the special conditions prevailing at the time.

The MEL cannot take into account all multiple unserviceability. Therefore, before dispatching an airplane with multiple MEL items inoperative, it must be assured that any interface or inter-relationship between inoperative items will not result in degradation in the level of safety and/or an undue increase in crew workload. It is particularly in this area of multiple discrepancies and especially discrepancies in related systems that good judgment, based on the circumstances of the situation must be applied taking into account actual meteorological en-route conditions.

0.4 Maintenance action

Every effort shall be made by Maintenance to correct all technical defects as early as practicable and that the aircraft can be released from a maintenance station in fully operational condition. The Commander must be informed by a certified Maintenance Organization as soon as practicable, should it be impossible to rectify the inoperative item prior to departure.

Whenever an aircraft is released by Maintenance for dispatch with items inoperative, the following is required:

The technical log book (TECHLOG) aboard the aircraft must contain a detailed description of the inoperative item(s), special advice to the flight crew, if necessary, and information about corrective action taken.

If the flight crew has direct access to control(s), switches and/or indicator(s) related to inoperative unit(s) or component(s), the status must be clearly placarded. (i.e. "INOP")

If inadvertent operation could result in a hazardous condition, such equipment must be rendered inoperative (physically) as given in the appropriate Maintenance Procedure

The relevant Operational and Maintenance Procedures (MMOP) are included in this MEL document in Section 2 – MMOP.

0.5 Rectification intervals

Inoperative items or components, deferred in accordance with the MEL, must be rectified at or prior to the rectification intervals



established by the following letter designators given in the "Rectification Interval Category" column of the MEL.

Category A

No standard interval is specified, however, items in this category shall be rectified in accordance with the conditions stated in the Remarks column (5) of the MMEL.

Where a time period is specified, it shall start at 00:01 on the calendar day following the day of the discovery.

Category B

Items in this category shall be rectified within three (3) consecutive calendar days, excluding the day of discovery.

Category C

Items in this category shall be rectified within ten (10) consecutive calendar days, excluding the day of discovery.

Category D

Items in this category shall be rectified within one hundred and twenty (120) consecutive calendar days, excluding the day of discovery.

0.6 Rectification interval extension

Such item intervals may be exceeded by the defined period (one time overrun pre-listed TECHLOG item only). A one-time extension of the applicable rectification interval B, C or D may be permitted for the same duration as that specified in the MEL.

0.7 Definitions

For the purpose of this MEL the following definitions shall apply:

- **Authority:** The competent regulatory authority according to the country or registry. For aircrafts registered in Switzerland, it is the Federal Office of Civil Aviation (FOCA)
- **Administrative Control Items:** Items listed by the operator in the MEL for tracking and informational purposes. It may be added to the MEL provided no relief is granted, or provided conditions and limitations are contained in and approved document such as the Structural Repair Manual. If relief other than that granted by an approved document is sought for an administrative control item, a request must be submitted to the FOCA. If the request results in review and approval, the item become an MMEL item rather than an administrative control item.



- *Airplane Flight Manual (AFM)*: is the document required for type certification and approved by the Agency. Visual Meteorological Conditions (VMC) means the atmospheric environment is such that would allow a flight under the Visual Flight Rules applicable to the flight. This does not preclude operating under Instrument Flight Rules (IFR)
- *DAY operation*: is any flight conducted from the point of take-off to landing between 30 minutes before sunrise and 30 minutes after sunset.
- *Dash (-)*: in columns 3 and 4 indicated a variable quantity.
- *Icing conditions*: the atmospheric environment is such that ice can form on the aircraft or in the engine(s).
- *Commencement of flight*: the point when an aircraft begins to move under its own power for the purpose of preparing for take-off.
- *Inoperative*: any time a system and/or component malfunctions to the extent that it does not accomplish its intended purpose and/or is not consistently functioning within its designed operating limit(s) or tolerance(s).
- Some systems have been designed to be fault tolerant and are monitored by digital computers which transmit fault messages to a centralized computer for the purpose of maintenance. The presence of this category of message does not mean that the system is inoperative.
- *Combustible Material*: material which is capable of catching fire and burning.
- *Print in different typeface* (e.g. italics) :
 - items which according to MMEL are subject to national regulations (e.g. <<as required by AIR-OPS >>)
 - text or numbers that are different from the original MMEL entry.
- (O) *Symbol*: indicates a requirement for a specific operation procedure which must be accomplished in planning for and/or operating with the listed item inoperative. Normally these procedures are accomplished by the flight crew; however, other personnel may be qualified and authorized to perform certain functions. The satisfactory accomplishment of all procedures, regardless of who performs them, is the responsibility of the operator.
- (M) *Symbol*: indicates a Maintenance procedure other than specified in column 5. "(M)" symbol indicates a requirement for a specific maintenance procedure which must be accomplished prior to operation with the listed item inoperative. These procedures are accomplished by maintenance personnel.

Note – The (M) and (O) symbols are required in the MEL unless the procedure is defined directly in the Remarks / Exceptions column or unless otherwise accepted by FOCA.

- *"Deleted"* in the remarks column after a sequence item indicates that the item was previously listed but is now required to be operative if installed.
- *"Secured" and "deactivated"*: that the specified component must be put into an acceptable condition for safe flight.
- *Alphabetical symbol* (Column 4): a proviso (condition or limitation) that must be complied with for operation with the listed item inoperative.
- *Flight Day* : A 24 hour period (from midnight to midnight) UTC during which at least one flight is initiated for the affected aircraft.
- *Number Required for Dispatch* (column 3): the minimum number (quantity) of items required for operation provided the conditions specified in Column 4 are met.
- *Number Installed* (column 2): the number (quantity) of items installed in the aircraft.



- Remark / Exceptions (column 4) – A statement either prohibiting or permitting operation with a specific number of items inoperative, proviso (conditions and limitations) for such operation, and appropriate notes.
- System Numbers (column 1) – Are based on the Air Transport Association (ATA) Specification Number 100.
- Visible Moisture – An atmospheric environment containing water in any form that can be seen in natural or artificial light, for example, cloud, fog, rain, sleet, hail or snow.
- ER Operations – Flight conducted over a route that contains a point further than one hour flying time, at the approved one-engine inoperative cruise speed, from an adequate airport.
- Day of Discovery – The calendar day an equipment/instrument malfunction was discovered. This day is excluded from the calendar days or flight days specified in the MEL for the rectification of an inoperative item of equipment, and is applicable to all MEL items in categories A, B, C and D.

0.8 Centralized message system

Not applicable

0.9 Operations outside the scope MEL

The following procedure shall be applied in the event that an item or system of airworthiness significance, and which is not listed in the MEL becomes inoperative, and cannot be rectified prior to the next flight, or the allowable rectification interval extension as outlined in chapter 6 of this preamble has expired.

If a defect rectification of an item or system not listed in the MEL, having an airworthiness significance is locally not possible, or the rectification at a different location is preferable, continued operation in accordance with the "Permit to fly" procedures as outlined in CAME Part 1A.

Non-revenue technical ferry flights or other flights under the Permit to Fly conditions will be coordinated between the AMAC Corporate Jet CAM, the contracted Part-145 maintenance organization, the flight crew and FOCA or EASA as appropriate. The Pilot-in-Command shall inform the AMAC Corporate Jet CAMO to identify the location, aircraft, engine, component, system or nature of the defect and the reason for the request.

The Continuing Airworthiness Manager and the Flight Crew will review the request and determine the course of actions taking the operational and maintenance aspects into consideration.

The dispatch of the aircraft is not allowed after expiry of the Rectification Interval extension specified in the paragraph 6 of this preamble, unless a "Permit to Fly" is made available to the Flight Crew.

0.10 Kind of operation and equipments

AMAC Corporate Jet is currently operating the Pilatus PC-12E registered HB-FVT under PART-NCO regulation for non-commercial private flights.



Kind of operations table

	HB-FVT (MSN 1280)
VFR	✓
IFR	✓
DAY	✓
NIGHT	✓
LVTO (RVR ≥ 150 m)	✓
FIKI	✓
Steep Approach	O
RVSM airspace	✓
MNPS airspace	✓
CPDLC	O
RNP 10 (RNAV 10)	O
RNAV 5	✓
RNP 4	O
RNAV 2	✓
RNP 2	O
RNAV 1	✓
RNP 1	✓
A- RNP	O
RNP APCH (RNAV (GNSS))	✓
LPV	✓
BARO VNAV	✓
RNP AR APCH	O
RNP 0.3	O



0.11 Approval

Not applicable.

0.12 AMAC Policy

The following Policy and Procedures will be adhered to by AMAC in the use of this Minimum Equipment List (MEL):

- It is the Pilot-in-Command responsibility to become thoroughly familiar with the policy and procedures concerning the use of this MEL and its preamble.
- All items related to the airworthiness of the aircraft and not included on the MEL are required to be fully operative.
- If an inoperative item requires an (O) or (M) procedure, that procedure must be accomplished in accordance with the procedures outlined in this MEL.
- When a discrepancy is corrected, the Maintenance person performing the maintenance will record it in accordance with AMAC CAMO.
- Inoperative items allowed by this MEL must be corrected no later than the appropriate A, B, C or D Category which that particular item falls under.
- An item, which is inoperative but required by special flight conditions, will be repaired before operating in that condition.
- The TECHLOG must be on board the aircraft during operation so the commander may be aware of any inoperative instruments or equipment.
- Required (M) Maintenance, (O) Operational and Placarding Procedures (PLACARD) are indicated in the column "Procedures" on the MEL. The procedures defined must be followed in the event MEL authority is exercised. Procedures outlined, such as pulling and collaring circuit breakers may be performed by a Flight Crew member, however if the procedure requires specialized tools, training or appropriate licenses, the procedure must be performed by a qualified individual.



1.1	ATA 21 – Air conditioning	1-2
1.2	ATA 22 – Auto Flight	1-5
1.3	ATA 23 – Communications	1-6
1.4	ATA 24 – Electrical power	1-8
1.5	ATA 25 – Equipment and furnishings	1-9
1.6	ATA 26 – Fire protection	1-14
1.7	ATA 27 – Flight controls	1-15
1.8	ATA 28 – Fuel	1-17
1.9	ATA 30 – Ice and rain protection	1-18
1.10	ATA 31 – Indicating and recording systems	1-20
1.11	ATA 32 – Landing gear	1-21
1.12	ATA 33 – Lights	1-22
1.13	ATA 34 – Navigation	1-24
1.14	ATA 35 – Oxygen	1-32
1.15	ATA 45 – Central Maintenance System (CMS)	1-33
1.16	ATA 46 – Information systems	1-34
1.17	ATA 52 – Doors	1-38
1.18	ATA 56 – Windows	1-39
1.19	ATA 77 – Engine indicating	1-40



1.1 ATA 21 – Air conditioning

1. System & Sequence numbers					
	2. Item		3. Category		
			4. Number Installed		
				5. Number required for Dispatch	
				6. Remarks or Exceptions	
21 AIR CONDITIONING AND PRESSURIZATION					
21-10-01	Air cycle system				
21-10-01A		C	1	0	(O) May be inoperative provided: a. Flight is conducted unpressurised, b. ECS or ACS (as applicable) Emergency Shut Off Lever is pulled, c. ambient conditions allow acceptable cockpit/cabin temperatures, and d. the regulations requiring oxygen use are complied with.
21-20-01	Fresh air ventilation outlets				
21-20-01A		C	4	1	Any in excess of one may be inoperative provided the supply of fresh air is acceptable to the flight crew.
21-30-01	Cabin pressurization system				
21-30-01D		D	1	0	(O) May be inoperative provided: a. flight is conducted unpressurized, and b. the regulations requiring oxygen use are complied with.
21-30-02	Pressurization safety valve				
21-30-02D		D	1	0	(O) May be inoperative provided: a. flight is conducted unpressurized, and b. the regulations requiring oxygen use are complied with.
21-30-03	Cabin altitude indicator				
21-30-03A		D	1	0	(M)(O) May be inoperative provided: a. the flight is conducted unpressurized, and b. the regulations requiring oxygen use are complied with.
21-30-04	Cabin altitude warning system				
21-30-04A		C	1	0	May be inoperative provided the flight is not conducted above 10000 feet MSL.
(Cont'd)					



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
21 AIR CONDITIONING AND PRESSURIZATION					
cont'd	cont'd				cont'd
21-30-04B		D	1	0	(M) (O) May be inoperative provided: a. the flight is conducted unpressurized, and b. the regulations requiring oxygen use are complied with.
21-30-05	Cabin rate of climb indicator				
21-03-05A		D	1	0	(M) (O) May be inoperative provided: a. the flight is conducted unpressurized, a nd b. the regulations requiring oxygen use are complied with.
21-30-06	Differential pressure indicator				
21-30-06A		D	1	0	(M) (O) May be inoperative provided: a. the flight is conducted unpressurized, and b. the regulations requiring oxygen use are complied with.
21-30-10	Emergency dump function				
21-30-10A		C	1	0	(M) (O) May be inoperative provided: a. the flight is conducted unpressurized, and b. the regulations requiring oxygen use are complied with.
21-30-20	ECS ground mode function				
21-30-20A		D	1	0	May be inoperative.
21-30-30	Cabin Temperature Indicator				
21-30-30A		C	1	0	May be inoperative.
21-40-01	Auxiliary heating system				
21-40-01-2	Secondary heating system				Note: MSN 321 and up.
21-40-01-2D		D	2	1	(O) Cabin heater may be inoperative provided underfloor heater is operative.
21-40-01-2E		D	2	0	(O) Cabin and underfloor heater may be inoperative provided the flight is conducted at IOAT above -15°C.
cont'd	cont'd				cont'd



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
21 AIR CONDITIONING AND PRESSURIZATION					
cont'd	cont'd				cont'd
21-40-01-2F		D	2	0	(O) Cabin and underfloor heater may be inoperative provided the flight is conducted at IOAT above -15°C.
21-40-01-5	Electrical foot warmer system				
21-40-01-5A		C	1	0	May be inoperative.
21-50-01	Vapour cycle cooling system VCCS				
21-50-01A		D	1	0	(O) May be inoperative provided the VCCS is deactivated.



1.2 ATA 22 – Auto Flight

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
22 AUTO FLIGHT					
22-10-01	Autopilot				
22-10-01A		C	1	0	(O) May be inoperative provided: a. autopilot is deactivated, b. AFM limitations are observed, and c. operations do not depend upon its use. Note: Yaw damper will be inoperative after autopilot deactivation.
22-10-02	Autopilot disconnect functions – Quick release controls				
22-10-02A		C	2	1	(O) One may be inoperative provided: a. the operative one is on the pilot flying side, and b. approach and landing minima do not require use of the autopilot.
22-10-02B		B	2	0	May be inoperative provided autopilot is not used (refer to item 22-10-01).
22-10-04	Yaw damper				
22-10-04A		C	1	0	May be inoperative provided autopilot is not used (refer to item 22-10-01). <u>Note:</u> above FL200 the aircraft must be flown only in balanced flight (slip ball centered ± 1 ball).



1.3 ATA 23 – Communications

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
23 COMMUNICATIONS					
23-10-01	Headsets				<u>Note:</u> A headset consists of a communication device which includes two earphones to receive and a microphone to transmit audio signals to the aeroplane's communication system.
23-10-01A		C	2	1	May be inoperative or missing provided: a. procedures do not depend on its use, and b. audio over the cabin speaker is acceptable to the flight crew.
23-10-02	Audio control panel				<u>Note:</u> For interphone function refer to 23-40-01. For PA function refer to 23-30-01.
23-10-02A		D	2	1	Any in excess of one for each flight crew member may be inoperative or missing.
23-10-03	Flight crew compartment speaker				
23-10-03A		C	2	0	May be inoperative provided: a. one headset is operative and used by each flight crew member, and b. a spare operative headset is readily available in the flight crew compartment.
23-10-04	Handheld microphones				
23-10-04A		C	2	0	May be inoperative provided one headset is operative and used by each flight crew member.
23-10-05	Yoke mounted push-to-talk switches				
23-10-05A		D	2	0	May be inoperative provided the associated handheld microphone is operative.
23-12-01	VHF communication systems				
cont'd	cont'd				cont'd



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
23 COMMUNICATIONS					
cont'd	cont'd				cont'd
23-12-01A		D	2	1	Any in excess of those required may be inoperative.
23-30-01	Public address system				
23-30-01B		C	1	0	(O) May be inoperative provided: a. flight crew member brief passengers prior to take-off b. check visually that passengers are well fastened prior to take-off, landing and in case of turbulence.
23-40-01	Flight crew interphone system				
23-40-01A		D	1	0	Any in excess of those required may be inoperative.
23-50-01	Oxygen mask microphones				
23-50-01A		C	2	1	One may be inoperative provided an operative mask microphone is available to the pilot. <u>Note:</u> Relief is only permissible for single-pilot operation.
23-60-01	Static dischargers				
23-60-01-2	MSN 181 and up, and MSN 101-180 with SB 23-001				<u>Note:</u> No more than two of the provisos may be applied at any time.
23-60-01-2A	Left winglet	C	2	1	One may be inoperative or missing.
23-60-01-2B	Right winglet	C	2	1	One may be inoperative or missing.
23-60-01-2C	Rudder	C	3	1	One or two may be inoperative or missing.
23-60-01-2D	Left elevator	C	2	1	One may be inoperative or missing.
23-60-01-2E	Right elevator	C	2	1	One may be inoperative or missing.



1.4 ATA 24 – Electrical power

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
24 ELECTRICAL POWER					
24-30-01	Generator				
24-30-01B		C	2	1	Generator 1 may be inoperative provided: a. flight is conducted in VFR, b. flight is not conducted in known or forecast icing conditions, c. it is not required by operating regulations, and d. flight is conducted at IOAT above -15°C.
24-40-01	External power system				
24-40-01A		D	1	0	May be inoperative.
24-52-01	Emergency power (EPS) system				
24-52-01B		C	1	0	May be inoperative.



1.5 ATA 25 – Equipment and furnishings

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
25 EQUIPMENT/FURNISHINGS					
25-10-01	Cockpit sunvisors				
25-10-01A		C	2	0	May be inoperative or missing provided there is no field of vision restriction for the flight crew.
25-11-01	Flight crew compartment seats				
25-11-01-1	Horizontal adjustment				
25-11-01-1A		C	2	0	(M) May be inoperative provided: a. the affected seat is secured and locked, b. the position is acceptable to the flight crew member, and c. the seat position when the seat is used allows a full travel of the flight controls. <u>Note:</u> No additionnal cushion(s) acceptable. Rudder pedal adjustment must be operative.
25-11-01-2	Vertical adjustment				
25-11-01-2A		C	2	0	(M) May be inoperative provided: a. the affected seat is secured or locked, b. the position is acceptable to the flight crew member, and c. the seat position when the seat is used allows a full travel of the flight controls. d. <u>Note:</u> No additionnal cushion(s) acceptable.
25-11-01-3	Other adjustments except horizontal, vertical and armrest adjustments				
25-11-01-3A		C	4	0	(M) May be inoperative provided: a. the affected seat is secured or locked, and b. the position is acceptable to the flight crew member.
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
25 EQUIPMENT/FURNISHINGS					
Cont'd	Cont'd				Cont'd
25-11-01-4	Safety harnesses				
25-11-01-4A		C	2	1	Right hand seat may be inoperative provided: a. the flight is conducted in single pilot operations, and b. the right hand seat is not occupied.
25-11-01-5	Armrest				
25-11-01-5A		C	4	0	(M) May be inoperative provided: a. it is not hinder emergency egress, and b. it does not block access to the flight controls or restrict any other flight deck duties.
25-20-01	Storage cabinets/wardrobe				
25-20-01A		C	2	0	(M) May be inoperative provided: a. the compartment is confirmed to be empty, b. the compartment is secured closed, and c. the compartment is placarded INOPERATIVE – DO NOT USE.
25-21-01	Passenger seats				
25-21-01A		D	6/8	0	(M) May be inoperative provided: a. inoperative seat does not block an emergency exit, b. inoperative seat does not restrict any passenger from access to the aeroplane aisle, and c. affected seat(s) are blocked and placarded “DO NOT OCCUPY”. <u>Note:</u> A seat with an inoperative or missing restraint system is considered inoperative. On aft-facing seats the headrest must be operational.
25-21-01-1	Recline functions				
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
25 EQUIPMENT/FURNISHINGS					
Cont'd	Cont'd				Cont'd
25-21-01-1 A		D	6/8	0	(M) May be inoperative and seat occupied provided the seat is secured in the take-off and landing position.
25-21-01-1B		C	6/8	0	May be inoperative provided the seat back is immovable in the take-off and landing position.
25-21-01-2	Under seat baggage restraining bars/stowage drawers				
25-21-01-2A		D	6	0	May be inoperative provided: a. baggage is not stowed under associated seat, and b. associated seat is placarded "DO NOT STOW BAGGAGE UNDER THIS SEAT"
25-21-01-3	Armrests with recline/swivel control mechanism				
25-21-01-3A		D	6/8	0	(M) May be inoperative, damaged or missing provided that: a. armrest does not block an emergency exit, b. armrest is not in such position that it restricts any passengers from accessing the aeroplane's aisle, and c. if the armrest is missing, associated seat is secured in fully upright and fully outboard and fully aft (towards the tail of the aircraft) position.
25-21-01-4	Armrests without recline/swivel control mechanism				
25-21-01-4A		D	6/8	0	(M) May be inoperative, damaged or missing, provided that: a. armrest does not block an emergency exit, and b. armrest is not in such a position that it restricts any passengers from accessing the aeroplane's aisle.
25-21-01-5	Swivel/travel mechanism				
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers							
	2. Item						
		3. Category					
			4. Number Installed				
				5. Number required for Dispatch			
					6. Remarks or Exceptions		
25 EQUIPMENT/FURNISHINGS							
Cont'd	Cont'd				Cont'd		
25-21-01-5A		D	6	0	(M) May be inoperative provided: a. associated seat is secured in the take-off and landing position, and b. associated seat does not restrict emergency egress.		
25-21-01-5B		C	6	0	May be inoperative provided the associated seat is immovable in the take-off and landing position.		
25-40-01	Lavatory waste system	D	1	0	(M) May be inoperative provided: a. Waste is drained and system is inspected for leakages, b. system components are deactivated, and c. lavatory access is closed and placarded "INOPERATIVE – DO NOT USE"		
25-50-01	Cargo restraint system						
25-50-01A		C	1	0	May be inoperative provided acceptable cargo loading limits from an approved source (e.g. cargo loading manual, cargo handling manual, weight and balance document) are observed.		
25-50-01B		D	1	0	May be inoperative or missing provided cargo compartment remains empty.		
25-60-01	Electrical flashlights						
25-60-01A		D	2	0	May be inoperative or missing for daylight operations.		
25-61-01	Crash axes						
25-61-01A		D	-	-	Any in excess of those required may be inoperative or missing.		
25-62-01	First-aid kits						
25-62-01A		D	2	1	Any in excess of one may be inoperative or missing.		
25-63-01	Automatic emergency locator transmitters ELT (AF)						
Cont'd	Cont'd				Cont'd		



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
25 EQUIPMENT/FURNISHINGS					
Cont'd	Cont'd				Cont'd
25-63-01A		D	1	0	Any in excess of those required may be inoperative.
25-63-01B		A	1	0	May be inoperative for a maximum of 6 flights or 25 flight hours, whichever occurs first.
25-64-01	Life jackets				
25-64-01A		D	8/10	2	(M) Any in excess of those required for the intended flight may be inoperative or missing, provided: a. Required distribution of operative units is maintained throughout the aeroplane, and b. the inoperative unit is removed from the aeroplane and its installed location is placarded inoperative; secured out of sight, and the inoperative unit and its installed location are placarded inoperative.



1.6 ATA 26 – Fire protection

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
26 FIRE PROTECTION					
26-24-01	Hand fire extinguishers				
26-24-01A		D	1	1	(M) Any in excess of one may be inoperative or missing provided: a. the inoperative hand fire extinguisher is removed from the aircraft and its installed position is placarded inoperative; or it is removed from the installed location, secured out of sight, and the hand fire extinguisher and its installed location are placarded inoperative, and b. required distribution of operative units is maintained throughout the aircraft.



1.7 ATA 27 – Flight controls

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
27 FLIGHT CONTROLS					
27-10-01	Aileron trim position indication				
27-10-01A		C	1	0	(O) May be inoperative provided: a. trim tab is visually checked for full range of travel, b. trim tab operation is not restricted, and c. trim tab is set to position for take-off and appropriate setting is verified by visual inspection prior to each departure.
27-15-01	Aileron trim				
27-15-01A		C	1	0	(M)(O) May be inoperative provided: a. the aileron trim tab is set to NEUTRAL, and b. if autopilot is used, it must be disconnected every 20 minutes to detect any possible fuel imbalance.
27-20-01	Rudder trim position indication				
27-20-01A		C	1	0	(O) May be inoperative provided: a. trim tab is visually checked for full range of travel, b. trim tab operation is not restricted, and c. trim tab is set to position for take-off and appropriate setting is verified by visual inspection prior to each departure.
27-30-01	Stabilizer trim position indication				
27-30-01A		C	1	0	(O) May be inoperative provided: a. horizontal stabilizer trim is visually checked for full range of travel, b. horizontal stabilizer trim operation is not restricted, and c. horizontal stabilizer trim is set to position for take-off and appropriate setting is verified by visual inspection prior to each departure.
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
27 FLIGHT CONTROLS					
Cont'd	Cont'd				Cont'd
27-50-01	Flaps position indication				
27-50-01A		C	1	0	(O) May be inoperative provided: a. prior to each flight, flaps are visually checked for full travel, b. flaps operation is not restricted, and c. flaps are visually checked for proper setting prior to each departure.



1.8 ATA 28 – Fuel

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
28 FUEL					
28-40-01	Fuel quantity indication				
28-40-01A		B	2	0	(O) One or both (L/R) may be inoperative provided: a. the aircraft is fueled to maximum, b. the flight is restricted to a maximum of 3 hours, c. triple trim indication is operative, d. aileron trim is operative, and e. if autopilot is used, it must be disconnected every 20 minutes to detect any possible fuel imbalance. <u>Note:</u> FUEL RESET is not possible.
28-40-01B		B	2	1	(O) One (L or R) may be inoperative provided: a. triple trim indication is operative, b. aileron trim is operative, and c. if autopilot is used, it must be disconnected every 20 minutes to detect any possible fuel imbalance. <u>Note:</u> FUEL RESET is not possible.
28-40-02	Fuel flow/Fuel used system				
28-40-02B		C	1	0	May be inoperative provided analogue Fuel quantity systems are operative.



1.9 ATA 30 – Ice and rain protection

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
30 ICE AND RAIN PROTECTION					
30-00-01	Inertial separator				
30-00-01A		C	1	0	May be inoperative in the closed position provided: a. flight is not conducted in actual or forecast icing conditions, and b. aircraft is not operated from unpaved ground surfaces or other ground FOD conditions which would normally require the inertial separator function.
30-00-01B		C	1	0	(M) May be inoperative in the open position provided: a. the inertial separator switch is set to the OPEN position, b. the PUSHER ICE MODE function is confirmed to be operative, and c. AFM limitations for operation with inertial separator OPEN are observed.
30-00-02	Inertial separator – Position indication system				
30-00-02B		C	1	0	May be inoperative provided operations are not conducted in known or forecast icing conditions.
30-10-01	Airframe aerodynamic surface ice protection				
30-10-01B		C	1	0	May be inoperative provided operations are not conducted in known or forecast icing conditions.
30-31-01	Pitot heating system				
30-31-01C		B	2	0	May be inoperative provided: a. operations are conducted under VFR, and b. operations are not conducted in visible moisture or into known icing conditions.
30-31-03	Static port heating system				
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
30 ICE AND RAIN PROTECTION					
Cont'd	Cont'd				Cont'd
30-31-03C		C	2	0	One or both may be inoperative provided: a. operations are conducted under day VFR, and b. operations are not conducted in known or forecast icing conditions.
30-32-01	Angle of attack sensor heating				
30-32-01A		B	2	0	One or both may be inoperative provided: a. operations are conducted under ay VMC, and b. operations are not conducted in known or forecast icing conditions.
30-41-01	Windshield heating system				
30-41-01A		B	1	0	(M) May be inoperative provided: a. operations are not conducted in known or forecast icing conditions, and b. one heating zone of the left windshield is verified to be operational.
30-61-01	Propeller de-ice system				
30-61-01B		C	1	0	May be inoperative provided operations are not conducted in known or forecast icing conditions.



1.10 ATA 31 – Indicating and recording systems

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
31 INDICATING / RECORDING SYSTEMS					
31-21-01	Clock				
31-21-01A		C	1	0	May be inoperative provided an accurate timepiece is operative on the flight crew compartment indicating the time in hours, minutes and seconds. <u>Note:</u> On the basis that the timepiece required does not need to be approved, an accurate pilot wristwatch which indicates hours, minutes and seconds is acceptable.
31-22-01	Hour meter				
31-22-01A		D	1	0	(O) May be inoperative provided a procedure is established to record flight time.
31-31-01	Lightweight data recorder				<u>Note:</u> Also referred to as CVFDR
31-31-01A		D	1	0	May be inoperative.
31-50-01	Master WARNING pushbutton				
31-50-01-1	Indication lamps				
31-50-01-1A		C	4	1	For single pilot operations, any in excess of one lamp in the pilot side master WARNING pushbutton may be inoperative.
31-50-01-1B		C	4	2	One lamp in each master WARNING pushbutton may be inoperative.
31-50-01-2	Reset function				
31-50-01-2A		C	2	1	For single pilot operations, reset function in co-pilot side master WARNING pushbutton may be inoperative in inactive (non reset) position.
31-50-02	Master CAUTION pushbutton				
31-50-02-1	Indication lamps				
31-50-02-1A		C	4	1	For single pilot operations, any in excess of one lamp in the pilot side master CAUTION pushbutton may be inoperative.
31-50-02-1B		C	4	2	One lamp in each master CAUTION pushbutton may be inoperative.
31-50-02-2	Reset function				
31-50-02-2A		C	2	1	For single pilot operations, reset function in co-pilot side master CAUTION pushbutton may be inoperative in inactive (non reset) position.



1.11 ATA 32 – Landing gear

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
32 LANDING GEAR					
32-40-01	Parking brake				
32-40-01A		C	1	0	(O) May be inoperative provided PIC should ensure to prevent aircraft movement by applying brakes: a. before taxiing and after chocks are off b. after taxiing until chocks are on. c. make sure that on apron position chocks are placed on both main gear.



1.12 ATA 33 – Lights

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
	6. Remarks or Exceptions				
33 LIGHTS					
33-10-01	Flight crew compartment lighting				<u>Note:</u> Excluding internally lighted buttons/switches, emergency lights and annunciations.
33-10-01A		C	12	0	May be inoperative for daylight operations.
33-10-01B		C	12	0	Individuals lights may be inoperative provided: a. sufficient lighting is operative to make each required instrument control and other device for which it is provided easily readable, and b. lighting configuration at dispatch is acceptable to the flight crew.
33-20-01	Passenger compartment lighting				
33-20-01A		D	18	0	May be inoperative provided passengers are not carried when operating at night.
33-20-01B		C	18	0	Individual lights may be inoperative provided lighting configuration at dispatch is acceptable to the flight crew.
33-20-02	Cabin signs (Fasten seat belt/No smoking)				
33-20-02A		C	2	0	May be inoperative provided oral briefing and appropriates placards are established and used fo passengers briefing.
33-20-02B		D	2	0	May be inoperative provided no passengers are carried.
33-41-01	Navigation/Position lights				
33-41-01A		C	3	0	One or more may be inoperative for daylight operations.
33-42-01	Anti-collision light system				<u>Note:</u> white flashing strobes.
33-42-01A		C	1	0	May be inoperative for daylight operations.
33-42-02	Red flashing beacon				
33-42-02A		C	2	0	May be inoperative.
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers					
	2. Item	3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
33 LIGHTS					
33-43-01	Wing illumination light				<u>Note:</u> known as well as inspection light (left wing only)
33-43-01A		D	1	0	May be inoperative for daylight operations.
33-43-01B		C	1	0	May be inoperative provided operations are not conducted at night into known or forecast icing conditions.
33-44-01	Landing lights				
33-44-01B		C	2	1	One may be inoperative for night operation.
33-44-01C		C	2	0	One or both may be inoperative for daylight operations.
33-45-01	Taxi lights				
33-45-01A		C	1	0	May be inoperative.
33-46-01	Recognition lights				
33-46-01A		D	2	0	May be inoperative.



1.13 ATA 34 – Navigation

1. System & Sequence numbers					
	2. Item	3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
34 NAVIGATION					
34-10-01	Primary airspeed indication				
34-10-01A		C	2	1	One may be inoperative provided: a. a primary airspeed indication is available at the pilot's station, b. the airspeed indication on ESIS is available, and c. regulations do not require dual-crew.
34-10-02	Primary altitude indication				
34-10-02B		C	2	1	One may be inoperative provided: a. flight is conducted under VFR, and b. an altitude indication is available at each required pilot's station. <u>Note:</u> The altitude indication from the ESIS or the 3 rd altimeter may be used by the pilot in the left seat, but not by the pilot in the right seat. Primary altitude indications may not be cross-read.
34-10-03	Turn and slip indication				
34-10-03-1	Turn indication				
34-10-03-1B		C	2	0	May be inoperative for single pilot operations provided operations are conducted under day VFR.
34-10-03-1C		C	2	0	May be inoperative for single pilot operations provided operations are conducted under day VFR.
34-10-03-1D		C	2	1	Any in excess of one may be inoperative provided: 1. the operative turn indication is on the pilot flying side, and 2. primary attitude indicators are operative at each required pilot's station.
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
34 NAVIGATION					
Cont'd	Cont'd				Cont'd
34-10-03-1E		B	2	1	Any in excess of one may be inoperative provided: a. operations are conducted under day VFR, and b. primary attitude indications are operative at each required pilot's station.
34-10-03-2	Slip indication				
34-10-03-2A		C	2	1	Any in excess of one may be inoperative provided the operative slip indicator is on the pilot flying side.
34-10-03-2B		D	2	0	May be inoperative provided operations are conducted under day VFR.
34-10-04	Vertical speed indicator				
34-10-04B		C	2	0	May be inoperative for day VFR operation.
34-15-01	Altitude alerting system				
34-15-01A		C	1	0	(O) May be inoperative provided the altitude alerting system is not part of the equipment required for intended operation (for instance RVSM operation).
34-15-02	Altitude pre-select				
34-15-02A		C	1	0	May be inoperative provided Altitude alerting system is considered inoperative (refer to 34-15-01)
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
34 NAVIGATION					
Cont'd	Cont'd				Cont'd
34-15-03	Radar Altimeter				
34-15-03A		C	1	0	May be inoperative provided approach minima or operating procedures are not dependent on its use.
34-20-01	Stabilized direction indication				
34-20-01C		C	2	1	Any in excess of one may be inoperative provided a stabilized direction indication is operative the pilot flying side.
34-20-01D		C	2	0	May be inoperative on the pilot flying side for day VFR operations, in sight of the surface with adequate external attitude reference.
34-20-02	Primary attitude indication				
34-20-02C		C	2	1	Any in excess of one may be inoperative for single pilot operations provided the primary attitude indication is operative on the pilot flying side.
34-20-02D		B	2	0	May be inoperative provided: a. operations are conducted under VFR, and b. standby attitude indication is operative.
34-20-02F		C	2	0	May be inoperative for single pilot operations provided operations are conducted under day VFR and in sight of the surface with adequate external attitude reference.
34-22-01	Magnetic standby compass				
34-22-01A		B	2	0	May be inoperative for single pilot operations provided: a. a stabilized direction indication is operative on the pilot flying side, and b. another source of magnetic heading is available and visible by the pilot flying.
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
	6. Remarks or Exceptions				
34 NAVIGATION					
Cont'd	Cont'd				Cont'd
34-22-01B		B	2	0	May be inoperative provided: a. operations are conducted under day VFR, and b. two independent stabilized direction indications are operative.
34-22-01C		B	2	0	May be inoperative provided: a. two independent stabilized direction indications are operative, and b. another source of magnetic heading is available and visible by the pilot flying.
34-31-01	Marker beacon				
34-31-01A		C	1	0	May be inoperative under IFR operations provide approach procedures do not require marker fixes.
34-31-01B		D	1	0	May be inoperative under VFR operations.
34-32-01	Approach aids				<u>Note:</u> includes all IFR navigation aids required to navigate from the IAF to the Decision Point of a published instrument approach.
34-32-01A		B	4	0	May be inoperative under IFR operations provided approaches and missed approaches where navigation is based on the affected item, are not included in the flight plan.
34-32-01B		D	4	0	May be inoperative under VFR operations.
34-40-01	Traffic alert and collision avoidance system (TCAS I)				
34-40-01B		D	1	0	(M) (O) May be inoperative provided: a. TCAS is deactivated, and b. operations are not conducted in an airspace where TCAS
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
34 NAVIGATION					
Cont'd	Cont'd				Cont'd
34-41-01	Weather detection system				<u>Note:</u> Weather radar/thunderstorm detection equipment, if installed
34-41-01A		D	2	0	May be inoperative.
34-43-01	Terrain awareness warning system (Class B TAWS)				
34-43-01A		D	1	0	May be inoperative.
34-43-01-1	Modes 1 and 3				
34-43-01-1A		C	2	0	One or both modes may be inoperative provided forward looking terrain avoidance (FLTA) and premature descent alert (PDA) functions are operative.
34-43-01-2	FLTA and PDA functions				
34-43-01-2A		B	1	0	May be inoperative provided: a. modes 1 and 3 are operative, and b. approach procedures do not require its use.
34-43-01-3	Advisory call-outs				
34-43-01-3A		C	1	0	(O) May be inoperative provided: 1. low visibility approaches requiring the use of affected call-outs are not performed, and 2. PM shall perform the appropriate call-outs as below: "FIVE HUNDRED" = 500 ft "APPROACHING MINIMUM" = DH / MDA bug setting + 100 ft "MINIMUMS" = At minimum
34-50-01	Flight Management System (FMS)				
34-50-01A		C	1	0	May be inoperative provided: a. enroute navigation does not require its use,
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
34 NAVIGATION					
Cont'd	Cont'd				Cont'd
					b. procedures do not require its use, and c. operational regulations do not require its use.
35-50-01-1	Navigation databases				
34-50-01-1A		C	1	0	(O) May be inoperative for the intended flight route where conventional (non-RNAV/RNP) navigation is sufficient, provided: a. current aeronautical information (e.g. charts) is available for the entire route and for the aerodromes to be used, b. navigation database information is disregarded, and c. radio navigation aids, which are required to be flown for departure, arrival and approach procedures are manually tuned and verified.
34-50-01-1B		A	1	0	(O) May be out of date for a maximum of 10 calendar days provided: a. Aera Navigation (RNAV/RNP) departure, arrival and approach procedures are checked not to depend on the data amended in the current database cycle or Conventional (Non-RNAV/RNP) or ANSP assistance are used as an alternative to RNAV/RNP procedures which have been amended in the current database cycle. b. before each flight, current aeronautical information is used to verify the database navigation fixes, the coordinates, frequencies, status (as applicable) and suitability of navigation facilities required for the intended flight route, and c. radio navigation aids, which are required to be flown for departure, arrival and approach procedures and which have been amended in the current database cycle, are manually tuned and verified.
34-51-01	Navigation systems				<u>Note:</u> Based on VOR, DME, ADF, GNSS, INS, RMI
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers						
	2. Item					
		3. Category				
			4. Number Installed			
				5. Number required for Dispatch		
					6. Remarks or Exceptions	
34 NAVIGATION						
Cont'd	Cont'd				Cont'd	
34-51-01B		D	6	2	(O)One or more may be inoperative provided: a. the navigation systems required for each segment of the intended flight route are operative, and b. aeroplane shall have sufficient navigation equipment to ensure that, in the event of the failure of one item of equipment at any stage of the flight, remaining equipment shall allow safe navigation in accordance with the flight plan.	
34-54-02	Secondary Surveillance Radar (SSR) transponder, mode S					
34-54-02A		D	2	1	Any in excess of those required for the intended flight route may be inoperative. <u>Note:</u> A SSR transponder with an operative mode S function is defined as a transponder which can provide, at least, elementary surveillance capability.	
34-54-02B		C	2	0	One or more may be inoperative provided permission is obtained from the Air Navigation Service Provider(s) when required for the intended flight route. <u>Note:</u> a. A SSR transponder with an operative mode S function is defined as a transponder which can provide, at least, elementary surveillance capability. b. Elementary surveillance (ELS) capability (mode S including aeroplane identification and pressure altitude reporting) is required in European mode S designated airspace. c. Altitude reporting provided by SSR transponder mode S function is required for flight into RVSM airspace.	
34-54-02-1	Enhanced surveillance functions					
Cont'd	Cont'd				Cont'd	



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
34 NAVIGATION					
Cont'd	Cont'd				Cont'd
34-54-02-1A		D	2	0	One or more downlinked aircraft parameters (DAPs) which provide enhanced surveillance may be inoperative when not required for the intended flight route.
34-54-02-1B		C	2	0	One or more downlinked aircraft parameters (DAPs) which provide enhanced surveillance may be inoperative when required for the flight route. <u>Note:</u> Enhanced surveillance capability is required in mode S enhanced notified airspace.
34-54-02-2	Extended squitter (ADS-B out) transmissions				
34-54-02-2A		D	2	0	One or more extended squitter transmissions may be inoperative when not required for the intended flight route.
34-54-02-2B		C	2	0	One or more extended squitter transmissions may be inoperative when required for the intended flight route. Note: A SSR transponder with an operative mode S function is defined as a transponder which can provide, at least, elementary surveillance capability.



1.14 ATA 35 – Oxygen

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
35 OXYGEN					
35-10-01	Flight crew fixed oxygen system				
35-10-01-1	Flight deck pressure indications				
35-10-01-1A		C	1	0	(O) May be inoperative provided a procedure is used to ensure the oxygen supply is above the minimum required for the intended flight.
35-10-01-2	Bottle gauge				
35-10-01-2A		C	1	0	May be inoperative provided the flight deck pressure indication is operative.
35-10-01-3	Flight crew oxygen mask (right side)				
35-10-01-3A		D	1	0	May be inoperative provided the right seat is not occupied.
35-20-01	Passenger oxygen system				
35-20-01A		C	11	0	(O) May be inoperative provided: a. maximum altitude is limited to 10,000 ft. pressure altitude, b. an adequate supply of fresh air is provided to the cabin, and c. passengers are appropriately briefed.
35-20-01B		D	11	0	May be inoperative provided no cabin occupant is carried.
35-20-01-1	Passenger service units				<u>Note:</u> Applies to dropdown and manual oxygen masks.
35-20-01-1A		C	11	0	(O) One or more may be inoperative provided: a. affected seats are blocked and placarded to prevent occupancy, and b. units are operative for all operative passenger seats and the toilet compartment (if applicable).



1.15 ATA 45 – Central Maintenance System (CMS)

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
				6. Remarks or Exceptions	
45 DIAGNOSTIC AND MAINTENANCE SYSTEM					
45-10-01	Central Maintenance Computer (CMC)				
45-10-01A		D	1	0	May be inoperative.



1.16 ATA 46 – Information systems

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
46 INFORMATION SYSTEMS					
46-10-01	Modular Avionics (MAU)				
46-10-01-1	Actuator input/output processor (AIOP) module channels				
46-10-01-1A		B	2	1	(O) One may be inoperative provided: a. autopilot is considered inoperative, b. yaw damper is considered inoperative, c. autothrottle (if installed) is considered inoperative, d. associated flight management system (FMS) is considered inoperative, e. flight director is not part of the equipment required for intended operation, f. flight is conducted unpressurised, and g. flight is conducted in day VFR.
46-10-01-2	Advanced graphics module (AGM) channels				
46-10-01-2A		B	2	1	(O) One may be inoperative provided: a. reversionary modes are operative, b. ESIS is operative, c. Standby compass (if installed) is operative, d. flight is conducted unpressurised below 10,000 ft., and e. flight is conducted in day VFR.
46-20-01	Display units				
46-20-01-1	Four display configuration				
46-20-01-1A		B	4	2	(O) Two displays may be inoperative provided: a. operative displays are PFD and one MFD , b. reversionary modes are operative, c. ESIS is operative, d. magnetic standby compass (if installed) is operative, and e. operation does not require dual crew.
46-30-01	Multi-function controller (MFC)				
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers					
	2. Item		3. Category		
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
46 INFORMATION SYSTEMS					
Cont'd	Cont'd				Cont'd
46-30-01A		A	1	0	May be inoperative provided: a. operations do not require RNAV and FMS use, b. PFD controllers are operative, c. Weather radar is not required for the intended flight, and d. repairs are made within 2 flight days.
46-30-01B		C	1	0	May be inoperative provided: a. operations do not require its use, b. cursor control devices is operative, and c. weather radar is not required for the intended flight.
46-30-01-1	MFC shortcut control keys				<u>Note:</u> Two top push button rows.
46-30-01-1A		D	1	0	May be inoperative.
46-30-01-2	MFC secure digital data card slot				
46-30-01-2A		C	1	0	May be inoperative provided navigation database requires no update.
46-30-01-3	MFC joystick				
46-30-01-3A		B	1	0	May be inoperative provided: a. operations do not require RNAV and FMS use, and b. procedures do not require FMS use.
46-30-01-3B		C	1	0	May be inoperative provided: a. Cursor control device is operative, and b. operations do not require its use.
46-30-01-4	MFC DETAIL and ENT keys				<u>Note:</u> next to joystick.
46-30-01-4A		D	2	0	One or both may be inoperative.
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
46 INFORMATION SYSTEMS					
Cont'd	Cont'd				Cont'd
46-30-01-5	MFC arrow keys				
46-30-01-5A		B	4	0	May be inoperative provided: a. operations do not require RNAV and FMS use, and b. procedures do not require FMS use.
46-30-01-5B		C	4	0	May be inoperative provided: a. Cursor control device is operative, and b. operations do not require its use.
46-30-01-6	MFC PAGE and MFD keys				
46-30-01-6A		B	2	0	May be inoperative provided: a. operations do not require RNAV and FMS use, and b. procedures do not require FMS use.
46-30-01-6B		C	2	0	May be inoperative provided: a. Cursor control device is operative, and b. operations do not require its use.
46-30-01-7	MFC alphanumeric keys				
46-30-01-7A		B	46	0	May be inoperative.
46-30-01-7B		C	46	0	May be inoperative provided: a. Cursor control device is operative, and b. operations do not require its use.
46-30-01-8	MFC weather radar control device				
46-30-01-8A		D	1	0	May be inoperative provided the Weather detection system (item 34-41-01) is considered inoperative.
Cont'd	Cont'd				Cont'd



1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
46 INFORMATION SYSTEMS					
Cont'd	Cont'd				Cont'd
46-30-01-8B		C	1	0	May be inoperative provided: a. Cursor control device is operative, and b. operations do not require its use.
46-31-01	Cursor control device CCD				
46-31-01A		C	1	0	May be inoperative provided Multi-function controller (MFC) is operative.
46-32-01	Wireless data loading/downloading system				
46-32-01A		D	1	0	(O) May be inoperative provided the system is deactivated.



1.17 ATA 52 – Doors

1. System & Sequence numbers					
	2. Item	3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
52 DOORS					
52-10-01	Door key locks				
52-10-01A		D	2	0	(M) May be inoperative provided the lock is secured in the UNLOCKED position.
52-20-01	Cabin door seal				
52-20-01A		C	1	0	(O) May be inoperative provided flight is conducted unpressurized and at or below 10,000 ft.
52-20-02	Cargo door seal				
52-20-02A		C	1	0	(O) May be inoperative provided flight is conducted unpressurized and at or below 10,000 ft.
52-20-03	Emergency exit seal				
52-20-03A		C	1	0	(O) May be inoperative provided flight is conducted unpressurized and at or below 10,000 ft.
52-30-01	Cargo door closing mechanism (electric motor)				
52-30-01A		C	1	0	May be inoperative.
52-30-02	Cargo door opening mechanism (gas strut)				
52-30-02A		C	1	0	May be inoperative provided the cargo door remains closed, latched and locked.
52-70-01	Door warning system (caption and voice callout)				
52-70-01A		C	1	0	(O) May be inoperative provided: a. a flight crew member confirms by visual inspection that all doors are properly closed, latched and locked prior to each departure, b. the doors are not re-opened again prior to departure, c. "FASTEN SEAT BELT" signs remains ON, and d. the passengers are briefed prior to each departure to have their seat belts fastened during the entire flight. <u>Note:</u> Passenger and cargo door.



1.18 ATA 56 – Windows

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
56 WINDOWS					
56-20-01	DV-Window seal				
56-20-01A		C	1	0	(O) May be inoperative provided flight is conducted unpressurized and at or below 10,000 ft.



1.19 ATA 77 – Engine indicating

1. System & Sequence numbers					
	2. Item				
		3. Category			
			4. Number Installed		
				5. Number required for Dispatch	
					6. Remarks or Exceptions
77 ENGINE INDICATING					
77-10-01	Engine trend monitoring system				
77-10-01A		D	1	0	May be inoperative.



2.1 PREAMBLE – CAS MESSAGES

This section lists CAS messages for which the dispatch status can be determined without any further fault diagnosis by maintenance. The absence of a CAS message from this section does not necessarily preclude dispatch with it displayed. Dispatch with a CAS message displayed may also be allowable provided the dispatch



(1) Message Indication	(2) Rectification Interval	(3) Remarks or Exceptions
ACMF Logs Full (Advisory)	C	May be displayed.
ACMF Logs>80% Full (Advisory)	C	May be displayed.
ADC A Fail (Caution)	C	May be displayed for single pilot operations provided: (a) ADAHRS channel B is selected as source for pilot PFD, (b) flight is conducted under VFR, (c) aircraft is not operated in RVSM airspace, (d) VNAV function of the FMS is not used, and (e) "AHRS B Fail" caution CAS message is not displayed.
ADC B Fail (Caution)	C	May be displayed for single pilot operations provided: (a) ADAHRS channel A is selected as source for co-pilot PFD (if installed), (b) flight is conducted under VFR, (c) aircraft is not operated in RVSM airspace, (d) VNAV function of the FMS is not used, and (e) "AHRS A Fail" caution CAS message is not displayed.
ADS-B In Fail (Advisory)	-	May be displayed provided ADS-B In is considered inoperative.
AFCS Fault (Advisory)	B	May be displayed provided: (a) flight director is not part of the equipment required for intended operation, (b) autopilot is considered inoperative.
AGM 1 Fail (Advisory)	-	May be displayed provided advanced graphics module (AGM) channel 1 is considered inoperative.
AGM 2 Fail (Advisory)	-	May be displayed provided advanced graphics module (AGM) channel 2 is considered inoperative.
AGM1 DB Error (Status)	-	May be displayed provided the aircraft is dispatched under the dispatch conditions of 34-50-01-1A or 34-50-01-1B.
AGM1 DB Old (Status)	-	May be displayed provided the aircraft is dispatched under the dispatch conditions of 34-50-01-1A or 34-50-01-1B.
AGM1+2 DB Error (Status)	-	May be displayed provided the aircraft is dispatched under the dispatch conditions of 34-50-01-1A or 34-50-01-1B.
AGM1+2 DB Old (Status)	-	May be displayed provided the aircraft is dispatched under the dispatch conditions of 34-50-01-1A or 34-50-01-1B.
AGM1/FMS1 GFP Inop (Status)	C	May be displayed provided: (a) enroute navigation does not require use of graphical flight planning, and (b) procedures do not require use of graphical flight planning.

(Cont'd)



(1) Message Indication	(2) Rectification Interval	(3) Remarks or Exceptions
AGM2 DB Error (Status)	-	May be displayed provided the aircraft is dispatched under the dispatch conditions of 34-50-01-1A or 34-50-01-1B.
AGM2 DB Old (Status)	-	May be displayed provided the aircraft is dispatched under the dispatch conditions of 34-50-01-1A or 34-50-01-1B.
AGM2/FMS1 GFP Inop (Status)	C	May be displayed provided: (a) enroute navigation does not require use of graphical flight planning, and (b) procedures do not require use of graphical flight planning.
AHRS A Fail (Caution)	C	May be displayed for single pilot operations provided: (a) ADAHRS channel B is selected as source for pilot PFD, (b) flight is conducted under VFR, and (c) "ADC B Fail" caution CAS message is not displayed.
AHRS B Fail (Caution)	C	May be displayed for single pilot operations provided: (a) ADAHRS channel A is selected as source for co-pilot PFD (if installed), (b) flight is conducted under VFR, and (c) "ADC A Fail" caution CAS message is not displayed.
AIOP A Module Fail (Advisory)	-	May be displayed provided actuator input/output processor (AIOP) A module is considered inoperative.
AIOP B Module Fail (Advisory)	-	May be displayed provided actuator input/output processor (AIOP) B module is considered inoperative.
Aural Warning Fault (Advisory)	C	May be displayed.
Autopilot Fail (Advisory)	-	May be displayed provided autopilot is considered inoperative.
CPCS Fault (Caution)	-	May be displayed provided cabin pressurisation system is considered inoperative.
CPCS Fault (Status)	C	May be displayed.
Check DU 2 (Caution)	-	May be displayed provided upper MFD (display unit 2) is considered inoperative.
Check DU 3 (Caution)	-	May be displayed provided lower MFD (display unit 3) is considered inoperative.
Check DU 4 (Caution)	-	May be displayed provided copilot PFD (display unit 4) is considered inoperative.
DME 1 Fail (Caution)	D	(O) May be displayed provided: (a) DME 1 is not required for any segment of the intended flight route, and (b) alternate procedures are established and used, where applicable.

(Cont'd)



(1) Message Indication	(2) Rectification Interval	(3) Remarks or Exceptions
Engine Log Full (Advisory)	C	May be displayed.
Engine Log>80% Full (Advisory)	C	May be displayed.
FCMU Fault (Status)	B	(O) May be displayed provided: (a) the aircraft is fueled to maximum, (b) the flight is restricted to a maximum of three hours, (c) triple trim indication is operative, (d) aileron trim is operative, and (e) if autopilot is used it must be disconnected every 20 minutes to detect any possible fuel imbalance. Note: FUEL RESET is not possible.
FLT CTRL Ch B Fail (Caution)	C	May be displayed.
FMS Fail (Advisory)	-	May be displayed provided flight management system (FMS) is considered inoperative.
FMS1 Fail (Advisory)	-	May be displayed provided flight management system (FMS) 1 is considered inoperative.
Flight Director Fail (Advisory)	B	May be displayed provided: (a) flight director is not part of the equipment required for intended operation, and (b) autopilot is considered inoperative.
GPS 1 Fail (Advisory)	D	(O) May be displayed provided: (a) GPS 1 is not required for any segment of the intended flight route, and (b) alternate procedures are established and used, where applicable.
GPS 2 Fail (Advisory)	D	(O) May be displayed provided: (a) GPS 2 is not required for any segment of the intended flight route, and (b) alternate procedures are established and used, where applicable.
Generator 1 Off (Caution)	-	May be displayed provided generator 1 is considered inoperative.
LH OAT Fail (Advisory)	C	May be displayed provided: (a) single pilot operations are not conducted, and (b) operations are not conducted in known or forecasted icing conditions.
	C	May be displayed provided: (a) operations are conducted under VFR, (b) operations are not conducted in known or forecasted icing conditions, and (c) weather reports indicate that at any point of the route that is intended to be flown, the OAT is within the aircraft's operating temperature limitations.

(Cont'd)



(1) Message Indication	(2) Rectification Interval	(3) Remarks or Exceptions
Low Lvl Sense Fault (Status)	C	May be displayed provided: (a) both fuel quantity indications are operative, and (b) fuel flow/fuel used system is operative.
MF CTRL Fail (Advisory)	-	May be displayed provided multi-function controller (MFC) is considered inoperative.
MMDR 2 Fail (Caution)	D	(O) May be displayed provided: (a) COM 2 is not required, (b) NAV 2 is not required for any segment of the intended flight route (c) Datalink (if installed) is considered inoperative, and (d) alternate procedures are established and used, where applicable.
Maint Memory Full (Status)	D	May be displayed.
Maintenance Fail (Advisory)	D	May be displayed.
No Engine Trend Store (Status)	C	May be displayed.
RA 1 Fail (Caution)	-	May be displayed provided radar altimeter is considered inoperative.
RH OAT Fail (Advisory)	C	May be displayed provided operations are not conducted in known or forecasted icing conditions.
TAWS Fail (Advisory)	-	May be displayed provided terrain awareness warning system (Class A TAWS) is considered inoperative.
	-	May be displayed provided terrain awareness warning system (Class B TAWS) is considered inoperative.
Traffic Fail (Advisory)	-	May be displayed provided traffic alert and collision avoidance system (TCAS I and II) is considered inoperative.
XPDR 1 Fail (Caution)	-	May be displayed provided secondary surveillance radar (SSR) transponder (mode A/C and S) 1 is considered inoperative.
XPDR 2 Fail (Caution)	-	May be displayed provided secondary surveillance radar (SSR) transponder (mode A/C and S) 2 is considered inoperative.
XPDR Fail (Caution)	-	May be displayed provided secondary surveillance radar (SSR) transponder (mode A/C and S) is considered inoperative.
Yaw Damper Fail (Advisory)	-	May be displayed provided yaw damper is considered inoperative.



3.1	ATA 21 – AIR CONDITIONING	3-4
3.1.1	21-10-01A – Air cycle system	3-4
3.1.2	21-30-01D – Cabin pressurization system	3-5
3.1.3	21-30-02D – Pressurization safety valve	3-6
3.1.4	21-30-03A – Cabin altitude indicator	3-7
3.1.5	21-30-04B – Cabin altitude warning system	3-8
3.1.6	21-30-05A – Cabin rate of climb indicator	3-9
3.1.7	21-30-06A – Differential pressure indicator	3-10
3.1.8	21-30-10A – Emergency dump function	3-11
3.1.9	21-40-01-2D – Auxiliary heating system	3-12
3.1.10	21-40-01-2E – Auxiliary heating system	3-13
3.1.11	21-40-01-2F – Auxiliary heating system	3-13
3.1.12	21-50-01A – Vapour cycle cooling system (VCCS)	3-14
3.2	ATA 22 – AUTO FLIGHT	3-15
3.2.1	22-10-01A – Autopilot	3-15
3.2.2	22-10-02A – Autopilot disconnect functions – Quick release controls	3-16
3.3	ATA 23 – COMMUNICATIONS	3-17
3.3.1	23-30-01B – Public address system	3-17
3.4	ATA 25 – EQUIPMENT AND FURNISHINGS	3-18
3.4.1	25-11-01-1A – Flight crew compartment seats – Horizontal adjustment	3-18
3.4.2	25-11-01-2A – Flight crew compartment seats – Vertical adjustment	3-19
3.4.3	25-11-01-3A – Flight Crew Compartment Seats – Other Adjustment except Horizontal, Vertical and Armrest Adjustment	3-20
3.4.4	25-11-01-5A – Flight Crew Compartment Seats – Armrest	3-21
3.4.5	25-20-01 – Storage cabinets/wardrobe	3-22
3.4.6	25-21-01A – Passenger seats	3-23
3.4.7	25-21-01-1A – Passenger seats – Recline function	3-24
3.4.8	25-21-01-3A – Passenger seat – Armrests with recline/swivel control mechanism	3-25
3.4.9	25-21-01-4A – Passenger seats – Armrests without recline/swivel control mechanism	3-26



3.4.10	25-21-01-5A – Passenger Seats – Swivel/Travel Mechanism	3-27
3.4.11	25-40-01A – Lavatory waste system	3-28
3.4.12	25-64-01 – Life Jackets	3-29
3.5	ATA 26 – FIRE PROTECTION	3-30
3.5.1	26-24-01A – Hand fire extinguishers	3-30
3.6	ATA 27 – FLIGHT CONTROLS	3-31
3.6.1	27-15-01A – Aileron trim	3-32
3.6.2	27-20-01A – Rudder trim position indication	3-33
3.6.3	27-30-01A – Stabiliser trim position indication	3-34
3.6.4	27-50-01A – Flap position indication	3-35
3.7	ATA 28 – FUEL	3-36
3.7.1	28-40-01A – Fuel quantity indication	3-36
3.7.2	28-40-01B – Fuel quantity indication	3-37
3.8	ATA 30 – ICE AND RAIN PROTECTION	3-38
3.8.1	30-00-01B – Inertial separator	3-38
3.8.2	30-41-01A – Windshield heating system	3-39
3.9	ATA 31 – INDICATING AND RECORDING SYSTEMS	3-40
3.9.1		3-40
3.9.2	31-22-01A – Hour meter	3-40
3.10	ATA 32 – LANDING GEAR	3-41
3.10.1	32-40-01A – Parking brake	3-41
3.11	ATA 33 – LIGHTS	3-42
3.11.1	33-20-02A – Cabin signs – Fasten seat belt/No smoking	3-42
3.12	ATA 34 – NAVIGATION	3-43
3.12.1	34-15-01A (ALL) – Altitude alerting system	3-43
3.12.2	34-40-01B – Traffic alert and collision avoidance system (TCAS)	3-44
3.12.3	34-43-01-3A (ALL) – Advisory call-outs	3-45
3.12.4	34-43-02-5A – Advisory call-outs	3-46
3.12.5	34-50-01-1A (ALL) – Navigation databases	3-47
3.12.6	34-50-01-1B – Navigation databases	3-48



3.12.7	34-51-01B – Navigation system	3-49
3.13	ATA 35 – OXYGEN	3-50
3.13.1	35-10-01-1A (ALL) – Flight Deck Pressure Indications	3-50
3.13.2	35-20-01A (ALL) – Passenger oxygen system	3-51
3.13.3	35-20-01-1A – Passenger service units	3-52
3.14	ATA 46 – INFORMATION SYSTEMS	3-53
3.14.1	46-10-01-1A – Modular avionics unit (MAU) - Actuator input/output processor (AIOP) module channels	3-53
3.14.2	46-10-01-2A – Modular avionics unit (MAU) – Advanced graphics module (AGM) channels	3-54
3.14.3	46-20-01-1A – Display units – Four display configuration	3-55
3.14.4	46-32-01A – Wireless data loading/downloading system	3-56
3.15	ATA 52 – DOORS	3-57
3.15.1	52-10-01A – Door key locks	3-57
3.15.2	52-20-01A – Cabin door seal	3-58
3.15.3	52-20-02A – Cargo door seal	3-59
3.15.4	52-20-03A – Emergency exit seal	3-60
3.15.5	52-70-01A – Door warning system (Caption and voice callout)	3-61
3.16	ATA 56 – WINDOWS	3-62
3.16.1	56-20-01A – DV-window seal	3-62
3.17	CAS MESSAGES	3-63
3.17.1	DME 1 Fail (Caution)	3-63
3.17.2	FCMU Fault (Status)	3-64
3.17.3	GPS 1 Fail (Advisory)	3-65
3.17.4	GPS 2 Fail (Advisory)	3-66
3.17.5	MMDR 2 Fail (Caution)	3-67



3.1 ATA 21 – AIR CONDITIONING

3.1.1 21-10-01A – Air cycle system

1. Placard

- A. Put an AIR CYCLE SYSTEM INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:

- 1. Set ACS switch to the INHIBIT position.
- 2. Pull the ACS emergency shut off lever.

- B. Perform the flight at an altitude not exceeding 10,000 ft. AMSL.

Note: If required, the flight crew should adjust the flight duration depending on the operating conditions (e.g. temperature, number of aircraft occupants, etc.) to ensure that the available fresh air inflow provides a suitable and comfortable environment for the occupants.



3.1.2 21-30-01D – Cabin pressurization system

1. Placard

- A. Put a PRESSURIZATION SYSTEM INOPERATIVE placard in a position near the Pressurization controls where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:
 - 1. Press DUMP switch.
 - 2. Open the hinged service panel (11BR) on the right side of the fuselage and visually confirm that the outflow valve is fully open. The butterfly valve must be in the horizontal position.
 - 3. Pull the following CBs:

<u>CIRCUIT BREAKER</u>	<u>BUS</u>
CPCS CH. 1	EPS BUS
CPCS CH. 2	MAIN BUS

Or

<u>CIRCUIT BREAKER</u>	<u>BUS</u>
CPCS MON	EPS BUS
CPCS AUTO	ESSENTIAL BUS

- B. Perform the flight at an altitude not exceeding 10,000 ft. AMSL.

Note: The ACS may be used normally to provide conditioned air to the cabin.



3.1.3 21-30-02D – Pressurization safety valve

1. Placard

- A. Put a PRESSURIZATION SYSTEM INOPERATIVE placard in a position near the Pressurization controls where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:
 - 1. Press DUMP switch.
 - 2. Open the hinged service panel (11BR) on the right side of the fuselage and visually confirm that the outflow valve is fully open. The butterfly valve must be in the horizontal position.
 - 3. Pull the following CBs:

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CPCS CH. 1	EPS BUS
CPCS CH. 2	MAIN BUS

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CPCS MON	EPS BUS
CPCS AUTO	ESSENTIAL BUS

- B. Perform the flight at an altitude not exceeding 10,000 ft. AMSL.

Note: The ECS may be used normally to provide conditioned air to the cabin.



3.1.4 21-30-03A – Cabin altitude indicator

1. Placard

- A. Put a PRESSURIZATION SYSTEM INOPERATIVE placard in a position near the Pressurization controls where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:
 - 1. Press DUMP switch.
 - 2. Open the hinged service panel (11BR) on the right side of the fuselage and visually confirm that the outflow valve is fully open. The butterfly valve must be in the horizontal position.
 - 3. Pull the following CBs:

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CPCS CH. 1	EPS BUS
CPCS CH. 2	MAIN BUS

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CPCS MON	EPS BUS
CPCS AUTO	ESSENTIAL BUS

- B. Perform the flight at an altitude not exceeding 10,000 ft. AMSL.

Note: The ECS may be used normally to provide conditioned air to the cabin.



3.1.5 21-30-04B – Cabin altitude warning system

1. Placard

- A. Put a PRESSURIZATION SYSTEM INOPERATIVE placard in a position near the Pressurization controls where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:
 - 1. Press DUMP switch.
 - 2. Open the hinged service panel (11BR) on the right side of the fuselage and visually confirm that the outflow valve is fully open. The butterfly valve must be in the horizontal position.
 - 3. Pull the following CBs:

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CPCS CH. 1	EPS BUS
CPCS CH. 2	MAIN BUS

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CPCS MON	EPS BUS
CPCS AUTO	ESSENTIAL BUS

- B. Perform the flight at an altitude not exceeding 10,000 ft. AMSL.

Note: The ECS may be used normally to provide conditioned air to the cabin.



3.1.6 21-30-05A – Cabin rate of climb indicator

1. Placard

- A. Put a PRESSURIZATION SYSTEM INOPERATIVE placard in a position near the Pressurization controls where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:
 - 1. Press DUMP switch.
 - 2. Open the hinged service panel (11BR) on the right side of the fuselage and visually confirm that the outflow valve is fully open. The butterfly valve must be in the horizontal position.
 - 3. Pull the following CBs:

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CPCS CH. 1	EPS BUS
CPCS CH. 2	MAIN BUS

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CPCS MON	EPS BUS
CPCS AUTO	ESSENTIAL BUS

- B. Perform the flight at an altitude not exceeding 10,000 ft. AMSL.

Note: The ECS may be used normally to provide conditioned air to the cabin.



3.1.7 21-30-06A – Differential pressure indicator

1. Placard

- A. Put a PRESSURIZATION SYSTEM INOPERATIVE placard in a position near the Pressurization controls where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:
 - 1. Press DUMP switch.
 - 2. Open the hinged service panel (11BR) on the right side of the fuselage and visually confirm that the outflow valve is fully open. The butterfly valve must be in the horizontal position.
 - 3. Pull the following CBs:

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CPCS CH. 1	EPS BUS
CPCS CH. 2	MAIN BUS

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CPCS MON	EPS BUS
CPCS AUTO	ESSENTIAL BUS

- B. Perform the flight at an altitude not exceeding 10,000 ft. AMSL.

Note: The ECS may be used normally to provide conditioned air to the cabin.



3.1.8 21-30-10A – Emergency dump function

1. Placard

- A. Put a PRESSURIZATION SYSTEM INOPERATIVE placard in a position near the Pressurization controls where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:
 - 1. Press DUMP switch.
 - 2. Open the hinged service panel (11BR) on the right side of the fuselage and visually confirm that the outflow valve is fully open. The butterfly valve must be in the horizontal position.
 - 3. Pull the following CBs:

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CPCS CH. 1	EPS BUS
CPCS CH. 2	MAIN BUS

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CPCS MON	EPS BUS
CPCS AUTO	ESSENTIAL BUS

- B. Perform the flight at an altitude not exceeding 10,000 ft. AMSL.

Note: The ECS may be used normally to provide conditioned air to the cabin.



3.1.9 21-40-01-2D – Auxiliary heating system

1. Placard

- A. Put an UNDERFLOOR HEATER DEACTIVATED placard in a position on the instrument panel where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, pull the following CBs in the cabin to deactivate the underfloor heater:

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CABIN HTR	POWERLINE BUS



3.1.10 21-40-01-2E – Auxiliary heating system

1. Placard

A. Put an UNDERFLOOR HEATER DEACTIVATED placard in a position on the instrument panel where it is visible to the flight crew.

2. Maintenance (M)

None required.

3. Operations (O)

A. Before the flight, pull the following CB in the cabin to deactivate the underfloor heater:

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
U/F FLOOR HTR	SEC POWERLINE BUS
U/F FLOOR FAN	GENERATOR 2 BUS

3.1.11 21-40-01-2F – Auxiliary heating system

1. Placard

A. Put a CABIN HEATER DEACTIVATED & UNDERFLOOR HEATER DEACTIVATED placard in a position on the instrument panel where it is visible to the flight crew.

B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

A. Before the flight, pull the following CBs in the cabin to deactivate the cabin and underfloor heaters:

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
CABIN HTR	POWERLINE BUS
U/F FLOOR HTR	SEC POWERLINE BUS
U/F FLOOR FAN	GENERATOR 2 BUS



3.1.12 21-50-01A – Vapour cycle cooling system (VCCS)

1. Placard

- A. Put a VCCS DEACTIVATED placard in a position on the instrument panel where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, pull the following CBs to deactivate the VCCS:

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
FLOOD FAN	NON ESSENTIAL BUS
VENTS FAN	NON ESSENTIAL BUS
COND CTL	NON ESSENTIAL BUS
CB 641 (CPRSR PWR)	POWERLINE BUS *

* This 100 Amp CB is installed in the Battery Compartment.



3.2 ATA 22 – AUTO FLIGHT

3.2.1 22-10-01A – Autopilot

1. Placard

- A. Put an AUTOPILOT INOPERATIVE placard in a position near the AFCS control panel where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before flight, pull the "A/P SERVO" circuit breaker (AVIONIC 1 BUS).
- B. Consider the increase in workload due to the unavailability of the AP and the prevailing conditions (e.g. crew skill level, IMC/VMC, Day/Night, duration of flight, complexity of the intended approach procedure, etc.). If the increase in workload may become excessively high then Pilatus recommends implementing suitable mitigations (e.g. safety pilot, change in flight plan, postponement of the flight, etc.).

Note: RVSM operations not permitted.



3.2.2 22-10-02A – Autopilot disconnect functions – Quick release controls

1. Placard

- A. Put a LEFT SEAT AUTOPILOT QUICK DISCONNECT INOPERATIVE or RIGHT SEAT AUTOPILOT QUICK DISCONNECT INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before flight, review and brief any applicable restrictions (e.g. approach and landing minima, en-route operations, RVSM, etc.).



3.3 ATA 23 – COMMUNICATIONS

3.3.1 23-30-01B – Public address system

1. Placard

- A. Put a PA SYSTEM INOPERATIVE placard in a position near the Audio panel where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Brief the cabin crew members (if carried) and the passengers on the communication procedures that will be used.
- B. Use direct communication (verbal and with hand signs) between flight deck and cabin.



3.4 ATA 25 – EQUIPMENT AND FURNISHINGS

3.4.1 25-11-01-1A – Flight crew compartment seats – Horizontal adjustment

1. Placard

- A. Put a SEAT HORIZONTAL ADJUSTMENT INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

Refer to the applicable seat Component Maintenance Manual (CMM) for support in the following procedures:

- A. Determine the reason for the inoperativeness of the horizontal seat adjustment.
- B. Move/adjust the seat position to the satisfaction of the pilot.
- C. Consider the reason for the inoperativeness and use appropriate aircraft maintenance practice to secure and lock the seat in this horizontal position. Make sure that the relevant pins fully engage in the seat track and that they are secure in this position.
- D. Operate the rudder pedal adjustment to make sure it is operative.

Note: No additional cushions are acceptable to achieve a seating position which is acceptable to the pilot.

3. Operations (O)

None required.



3.4.2 25-11-01-2A – Flight crew compartment seats – Vertical adjustment

1. Placard

- A. Put a SEAT VERTICAL ADJUSTMENT INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

Refer to the applicable seat Component Maintenance Manual (CMM) for support in the following procedures:

- A. Determine the reason for the inoperativeness of the vertical seat adjustment.
- B. Move/adjust the seat position to the satisfaction of the pilot.
- C. Consider the reason for the inoperativeness and use appropriate aircraft maintenance practice to secure and lock the seat in this vertical position.

Note: No additional cushions are acceptable to achieve a seating position which is acceptable to the pilot.

3. Operations (O)

None required.



3.4.3 25-11-01-3A – Flight Crew Compartment Seats – Other Adjustment except Horizontal, Vertical and Armrest Adjustment

1. Placard

- A. Put a SEAT ADJUSTMENT INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

Refer to the applicable seat Component Maintenance Manual (CMM) for support in the following procedures:

- A. Determine the reason for the inoperativeness of the seat adjustment.
- B. Move/adjust the seat position to the satisfaction of the pilot.
- C. Consider the reason for the inoperativeness and use appropriate aircraft maintenance practice to secure and lock the seat in this position.

3. Operations (O)

None required.



3.4.4 25-11-01-5A – Flight Crew Compartment Seats – Armrest

1. Placard

- A. Put a FLIGHT CREW SEAT ARMREST INOPERATIVE placard on the affected armrest.
- B. Note on the AMAC HIL.

2. Maintenance (M)

Refer to the applicable seat Component Maintenance Manual (CMM) for support in the following procedures:

EITHER:

- A. Use appropriate aircraft maintenance practice to secure the armrest in a position where it does not hinder emergency egress, does not block access to the flight controls and does not restrict any other flight deck duties.

Note: If this maintenance procedure is ineffective so that the inoperative armrest may harm the crewmember then no dispatch is permissible until the inoperative armrest is repaired.

OR:

- A. Remove the inoperative armrest in accordance with Component Maintenance Manual (CMM).

3. Operations (O)

None required.



3.4.5 25-20-01 – Storage cabinets/wardrobe

1. Placard

- A. Put an INOPERATIVE - DO NOT USE placard on the affected compartment door or drawer.
- B. Note on the AMAC HIL.

2. Maintenance (M)

- A. Remove all loose items from the compartment.
- A. Use appropriate aircraft maintenance practice to secure the compartment closed. For example, self-adhesive tape may be used.
Make sure that the adhesive does not damage the surface finish.

3. Operations (O)

None required.



3.4.6 25-21-01A – Passenger seats

1. Placard

- A. Install the placards as described in the (M) procedure.
- B. Note on the AMAC HIL.

2. Maintenance (M)

Refer to the applicable seat Component Maintenance Manual (CMM) for support in the following procedures:

- A. Make sure that the inoperative seat does not block an emergency exit. If required, use appropriate aircraft maintenance practice to secure the seat in a position where it does not block the emergency exit.
- B. Make sure that the inoperative seat does not restrict any passenger from access to the aeroplane aisle. If required, use appropriate aircraft maintenance practice to secure the seat in a position where it does not restrict access.
- C. Make sure that the inoperative seat is in the take-off position. If required, use appropriate aircraft maintenance practice to secure the seat in the take-off position.
- D. Put PASSENGER SEAT INOPERATIVE placard on the affected seat.
- E. Put a conspicuous DO NOT OCCUPY placard on the affected seat. Secure the placard in such a way that it is not possible to occupy the seat without disturbing the placard, for example by securing the placard with tape between the seat and seatback.

3. Operations (O)

None required.



3.4.7 25-21-01-1A – Passenger seats – Recline function

1. Placard

- A. Put a SEAT RECLINE FUNCTION INOPERATIVE placard on the recline adjustment handle of the affected seat.
- B. Note on the AMAC HIL.

2. Maintenance (M)

Refer to the applicable seat Component Maintenance Manual (CMM) for support in the following procedures:

EITHER:

- A. Determine the reason for the inoperativeness of the recline function.
- B. Move/adjust the seatback to the vertical (take-off) position.
- C. Consider the reason for the inoperativeness and use appropriate aircraft maintenance practice to secure and lock the seat in this position.

OR:

- A. Apply the procedures of 25-21-01A.

3. Operations (O)

None required.



3.4.8 25-21-01-3A – Passenger seat – Armrests with recline/swivel control mechanism

1. Placard

- A. Put a SEAT ARMREST INOPERATIVE placard on the armrest of the affected seat.
- B. Note on the AMAC HIL.

2. Maintenance (M)

Refer to the applicable seat Component Maintenance Manual (CMM) for support in the following procedures:

EITHER:

- A. Make sure that the inoperative armrest does not block an emergency exit. If required, use appropriate aircraft maintenance practice to secure the armrest in a position where it does not block the emergency exit.
- B. Make sure that the inoperative armrest does not restrict any passengers from accessing the airplane's aisle. If required, use appropriate aircraft maintenance practice to secure the armrest in a position where it does not restrict access.
- C. Make sure that the seat is secured in fully upright, fully outboard and fully aft (towards the tail of the aircraft) position.

OR:

- A. Remove the inoperative armrest in accordance with Component Maintenance Manual (CMM).
- B. Make sure that the seat is secured in fully upright, fully outboard and fully aft (towards the tail of the aircraft) position.

OR:

- A. Apply the procedures of 25-21-01A.

3. Operations (O)

None required.



3.4.9 25-21-01-4A – Passenger seats – Armrests without recline/swivel control mechanism

1. Placard

- A. Put a SEAT ARMREST INOPERATIVE placard on the armrest of the affected seat.
- B. Note on the AMAC HIL.

2. Maintenance (M)

Refer to the applicable seat Component Maintenance Manual (CMM) for support in the following procedures:

EITHER:

- A. Make sure that the inoperative armrest does not block an emergency exit. If required, use appropriate aircraft maintenance practice to secure the armrest in a position where it does not block the emergency exit.
- B. Make sure that the inoperative armrest does not restrict any passengers from accessing the airplane's aisle. If required, use appropriate aircraft maintenance practice to secure the armrest in a position where it does not restrict access.

OR:

- A. Remove the inoperative armrest in accordance with Component Maintenance Manual (CMM).
- B. Make sure that the seat is secured in fully upright position.

OR:

- A. Apply the procedures of 25-21-01A.

3. Operations (O)

None required.



3.4.10 25-21-01-5A – Passenger Seats – Swivel/Travel Mechanism

1. Placard

- A. Put a SWIVEL/TRAVEL MECHANISM INOPERATIVE placard on the affected seat.
- B. Note on the AMAC HIL.

2. Maintenance (M)

Refer to the applicable seat Component Maintenance Manual (CMM) for support in the following procedures:

EITHER:

- A. Make sure that the seat is secured in fully upright, fully outboard and fully aft (towards the tail of the aircraft) position. If required, use appropriate aircraft maintenance practice to secure the seat in this position.

OR:

- A. Apply the procedures of 25-21-01A.

3. Operations (O)

None required.



3.4.11 25-40-01A – Lavatory waste system

1. Placard

- A. Put a LAVATORY INOPERATIVE placard in the cockpit in a location that is visible to the flight crew.
- B. Install the placard as described by the (M) procedure.
- C. Note on the AMAC HIL.

2. Maintenance (M)

- A. Drain the waste in accordance with the "Operator's Manual with Illustrated Parts List" or the "SERVICE AND MAINTENANCE MANUAL WITH ILLUSTRATED PARTS LIST" for the "MODEL 50 SERIES Self-Contained AIRCRAFT TOILETS".
- B. Inspect for signs of leakage.
- C. Remove power from the toilet unit:
- D. Pull the "TOILET" circuit breaker (CABIN BUS).
- E. Latch the lavatory door closed and put an "INOPERATIVE-DO NOT USE" placard on the door. Install the placard in such a manner that it is not possible to operate the door without disturbing the placard.

3. Operations (O)

None required.



3.4.12 25-64-01 – Life Jackets

1. Placard

- A. Put a LIFE JACKET INOPERATIVE placard on the inoperative life jacket.
- B. Put a LIFE JACKET INOPERATIVE placard next to the affected seat so that it is clearly visible to the seat occupant.
- C. Note on the AMAC HIL.

2. Maintenance (M)

EITHER:

- A. Remove the inoperative life jacket from its installed location.
- B. Store the unit in the baggage compartment, out of sight, so it cannot be mistaken for a functional unit.
- C. Make sure that the required distribution of operative life jackets is provided.

OR:

- A. Remove the inoperative life jacket from the aircraft.

3. Operations (O)

None required



3.5 ATA 26 – FIRE PROTECTION

3.5.1 26-24-01A – Hand fire extinguishers

1. Maintenance (M)

- A. Place the inoperative Hand fire extinguisher in a plastic bag and mark the bag "INOPERATIVE" with indelible ink.
- B. Place the inoperative Hand fire extinguisher in a location where it is out-of-sight for the passengers and properly secured, OR remove the inoperative Hand fire extinguisher from the aircraft.
- C. Ensure that the required distribution in accordance with national regulations is maintained. If required, remove installed Hand fire extinguisher(s) from the installed location and install in the required location.
- D. Put a HAND FIRE EXTINGUISHER INOPERATIVE placard near the installed location so that it can be clearly seen by a person intending to use it.

2. Operations (O)

None required



3.6 ATA 27 – FLIGHT CONTROLS

1. Placard

- A. Put an AILERON TRIM INDICATION INOPERATIVE placard on the edge of the lower MFD. Make sure the display is not obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

Note: Two persons are required to perform the following procedure. One person operates the trim switch in the cockpit. The second person observes the aileron trim tab movement.

- A. Operate the trim tab through the full range of travel:
 - 1. Check that the aileron trim tab moves through the full range of travel.
 - 2. Check that the operation is not restricted.
- B. Make sure the aileron control is centred. Install the yoke gust lock.
- C. Operate the trim so that the trailing edge of the aileron trim tab is approximately 6 mm up, measured from the centre of the trim tab trailing edge to the centre of the aileron trailing edge (take-off setting).
- D. Remove the gust lock. Do not change the aileron trim setting on the ground before take-off. After take-off the aileron trim may be operated as required.



3.6.1 27-15-01A – Aileron trim

1. Placard

- A. Put an AILERON TRIM INOPERATIVE placard in the cockpit in a location that is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

Set the aileron trim tab to the neutral position. If the aileron cannot be set to the neutral position due to the system inoperability then no dispatch is permissible.

- A. Make sure the aileron control is centered. Install the yoke gust lock.
- B. Make sure that the aileron trim tab is approximately 6 mm up, measured from the center of the trim tab trailing edge to the center of the aileron trailing edge (take-off setting).
- C. Pull the "AIL TRIM" circuit breaker (BATTERY BUS or ESSENTIAL BUS).
- D. Remove the gust lock.

3. Operations (O)

- A. At intervals not exceeding 20 minutes make sure there are no indications of a potential fuel imbalance (increased aileron control forces). Disconnect the autopilot, if used, for this check.

Note: If there are indications of a potential fuel imbalance, use fuel transfer to balance the fuel. Land as soon as practical.



3.6.2 27-20-01A – Rudder trim position indication

1. Placard

- A. Put an RUDDER TRIM INDICATION INOPERATIVE placard on the edge of the lower MFD. Make sure the display is not obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

Note: Two persons are required to perform the following procedure. One person operates the trim switch in the cockpit. The second person observes the rudder trim tab movement.

- A. Operate the trim tab through the full range of travel:
 - 1. Check that the rudder trim tab moves through the full range of travel.
 - 2. Check that the operation is not restricted.
- B. Make sure the rudder control is centred.
- C. Operate the trim so that the rudder trim tab is approximately 14 mm left, looking forward and measured from the centre of the trim tab trailing edge to the centre of the rudder trailing edge.
- D. Do not change the rudder trim setting on the ground before take-off. After take-off the rudder trim may be operated as required.



3.6.3 27-30-01A – Stabiliser trim position indication

1. Placard

- A. Put a PITCH TRIM INDICATION INOPERATIVE placard on the edge of the lower MFD. Make sure that the display is not obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

Note: Two persons are required to perform the following procedure. One person operates the trim switch in the cockpit. The second person observes the horizontal stabiliser movement.

- A. Operate the pitch trim through the full range of travel:
 - 1. Check that the horizontal stabiliser moves through the full range of travel.
 - 2. Check that the operation is not restricted.
- B. Operate the pitch trim so that the horizontal stabiliser trim mark is within the green take-off area (on the left side of the bullet fairing).
- C. Do not change the pitch trim setting on the ground before take-off. After take-off the pitch trim may be operated as required.



3.6.4 27-50-01A – Flap position indication

1. Placard

- A. Put a FLAPS POSITION INDICATION INOPERATIVE placard on the upper edge of the lower MFD. Make sure that the display is not obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

Note: Two persons are required to perform the following procedure. One person operates the flaps control in the cockpit. The second person observes the flaps movement.

- A. Operate the flaps through the full range of travel:
 - 1. Check that the flaps move through the full range of travel.
 - 2. Check that the operation is not restricted.
- B. Set the flaps by moving the flaps selector handle to the required take-off flaps setting detent. Check that the flaps move and then stop at a reasonable position for the selected setting.
- C. Do not change flaps setting on the ground before take-off. After take-off the flaps may be normally operated as required.



3.7 ATA 28 – FUEL

3.7.1 28-40-01A – Fuel quantity indication

1. Placard

- A. Put a FUEL QTY INDICATION INOPERATIVE placard on the upper edge of the lower MFD. Make sure that the display is not obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Prior to each departure:
 - 1. Refuel the aircraft to maximum.
 - 2. Operate all three trims through the full range and make sure that correct movement is indicated on the trim indications.
- B. During flight:
 - 1. Limit the flight duration to maximum three (3) hours.
 - 2. At intervals not exceeding 20 minutes make sure there are no indications of a potential fuel imbalance (increased aileron control forces). Disconnect the autopilot, if used, for this check.

Note: If there are indications of a potential fuel imbalance, use fuel transfer to balance the fuel and alnd as soon as practical.



3.7.2 28-40-01B – Fuel quantity indication

1. Placard

A. Put a L FUEL QTY INDICATION INOPERATIVE or R FUEL QTY INDICATION INOPERATIVE placard on the upper edge of the lower MFD. Make sure that the display is not obstructed.

B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

A. Prior to each departure:

1. Fuel the aircraft on the wing with the operative fuel quantity indication at least to a level which can be clearly seen through the filler port.
2. Visually compare the fuel level in the tanks and fuel the aircraft on the wing with the inoperative fuel quantity indication to the same level as the opposite tank.
3. Calculate two times the indicated fuel quantity on the operative fuel quantity indication. Use this amount of fuel for the flight planning. Double the applicable fuel reserve requirements
4. Prior to each departure, operate all three trims through the full range and make sure that correct movement is indicated on the trim indications.

B. During flight:

1. At intervals not exceeding 20 minutes make sure there are no indications of a potential fuel imbalance (increased aileron control forces). Disconnect the autopilot, if used, for this check.

Note: If there are indications of a potential fuel imbalance, use fuel transfer to balance the fuel and land as soon as practical.



3.8 ATA 30 – ICE AND RAIN PROTECTION

3.8.1 30-00-01B – Inertial separator

1. Placard

- A. Put an INERTIAL SEPARATOR INOPERATIVE placard in a position near the Inertial separator switch.
- B. Note on the AMAC HIL.

2. Maintenance (M)

The operational test of the inertial separator system verifies that the inertial separator is OPEN and that the signal required for proper operation of the Pusher ice mode is provided by the inertial separator system.

As the test only involves activation of switches in the cockpit, interpretation of displayed information in the cockpit, and a visual determination of the inertial separator door position, the procedure may be performed by appropriately instructed flight crew.

- A. Perform the ADJUSTMENT/TEST procedure for the AIR INTAKE DE-ICE SYSTEM (AMM 12-B-30-20-00-00A-903A-A). Stop the procedure after step 2.10. Close the circuit breaker PROP DE-ICE (MAIN BUS).

3. Operations (O)

None required.



3.8.2 30-41-01A – Windshield heating system

1. Placard

- A. Put a WINDSHIELD HEATING SYSTEM INOPERATIVE placard in a position near the Ice protection panel where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

- A. Make sure that at least one heating panel on the windshield is operative:
 - 1. Set LH WSH switch on the overhead panel (Legacy) or left crossbar panel (NG) to ON and select HEAVY.
 - 2. Make sure that at least one area of the windshield in front of the pilot in the left seat is operative by touching the windshield with the hand to feel if it is warm.
 - 3. Observe the AMP indications when the LH WSH switch is turned on. Make sure an increased current draw is indicated.
 - 4. Set LH WSH switch to off or as required.

3. Operations (O)

None required.



3.9 ATA 31 – INDICATING AND RECORDING SYSTEMS

3.9.1

3.9.2 31-22-01A – Hour meter

1. Placard

- A. Put an HOUR METER INOPERATIVE placard in a position near the Hour meter where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Measure flight time as required by the operator.
- B. Record the flight time as required by regulations.



3.10 ATA 32 – LANDING GEAR

3.10.1 32-40-01A – Parking brake

1. Placard

- A. Put a PARKING BRAKE INOPERATIVE placard in a position near the Parking brake handle where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. When no pilot is seated in the pilot seat, secure the aircraft by applying wheel chocks and, in case of strong winds, wing tie down (AFM Section 8 "Parking"/"Mooring").
- B. When a pilot is seated at the pilot station, pay attention to inadvertent aircraft movement and use wheel brakes as necessary.



3.11 ATA 33 – LIGHTS

3.11.1 33-20-02A – Cabin signs – Fasten seat belt/No smoking

1. Placard

- A. Put a CABIN SIGNS INOPERATIVE placard in a position near the PASS WNG section of the overhead panel where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Brief the cabin crew members (if carried) and the passengers on the communication procedures that will be used.

OR

- A. Use direct communication (verbal and with hand signs) between flight deck and cabin to advise occupants when the seatbelts must be fastened and when smoking is prohibited.



3.12 ATA 34 – NAVIGATION

3.12.1 34-15-01A (ALL) – Altitude alerting system

1. Placard

- A. Put an ALTITUDE ALERTING SYSTEM INOPERATIVE placard in a position near the AFCS control panel where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Flights in RVSM airspace not permitted.
- B. Check and observe any applicable AFM Section 2 "Limitations".
- C. During the flight, use altitude hold (ALT) and autopilot functions for all operations for which they are appropriate.
- D. Monitor altitude indications when maintaining an assigned altitude.



3.12.2 34-40-01B – Traffic alert and collision avoidance system (TCAS)

1. Placard

- A. Put a TCAS INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

- A. Pull the "TCAS" circuit breaker (AVIONIC 2 BUS or AVIONIC 1 BUS).

Note: A flight crew member may be authorized to perform this procedure.

3. Operations (O)

- A. Make sure that the flight is not conducted in airspace where TCAS is required.



3.12.3 34-43-01-3A (ALL) – Advisory call-outs

1. Placard

- A. Put a TAWS ADVISORY CALL-OUTS INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Review the Minimum Safe Altitudes (MSA) along the planned route, at the destination and any alternate airports.
- B. During the flight, monitor flight progress with reference to MSA along the route and especially during descent and approach.



3.12.4 34-43-02-5A – Advisory call-outs

1. Placard

- A. Put a TAWS ADVISORY CALL-OUTS INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Review the Minimum Safe Altitudes (MSA) along the planned route, at the destination and any alternate airports.
- B. During the flight, monitor flight progress with reference to MSA along the route and especially during descent and approach.



3.12.5 34-50-01-1A (ALL) – Navigation databases

1. Placard

A. Put a NAVIGATION DATABASE INOP placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.

B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

Procedure below shall be followed:

A. PIC is responsible for the task.

B. EFB, including Jeppesen Mobile FD aeronautical information such as aerodrome charts (destination aerodrome and any alternates) & airway manual, must be used for the entire route.

C. Jeppesen Mobile FD must be up to date prior departure.

D. Aid frequencies and identifiers (including for any alternates) are readily available to the flight crew (EFB used as per OM A 8.3.19 / EFBG).



3.12.6 34-50-01-1B – Navigation databases

1. Placard

- A. Put a NAVIGATION DATABASE INOP placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

Procedure below shall be followed:

- A. PIC is responsible for the task.
- B. A crew check of Area Navigation (RNAV/RNP) departure, arrival and approach procedures to ensure that they do not depend on the data amended in the current database cycle. Use Jeppesen Mobile FD on EFB for the check. Alternatively, conventional (non RNAV/RNP) navigation or ANSP (Air Navigation Service Provider) assistance may be used. Crew will brief accordingly.
- C. EFB, including Jeppesen Mobile FD aeronautical information such as aerodrome charts (destination aerodrome and any alternates) & airway manual, must be used for the entire route.
- D. Jeppesen Mobile FD must be up to date prior departure.
- E. Aid frequencies and identifiers (including for any alternates) are readily available to the flight crew (EFB used as per OM A 8.3.19 / EFBG).



3.12.7 34-51-01B – Navigation system

1. Placard

- A. Put a NAVIGATION SYSTEM INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew.
Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Make sure that the available navigation equipment is sufficient for the intended flight route and type of operation (VFR/IFR).
- B. Use alternative instrumentation to ensure the navigation capability required for the intended flight and for the planned route.
- C. Review and brief before flight the alternate procedures established under (B).



3.13 ATA 35 – OXYGEN

3.13.1 35-10-01-1A (ALL) – Flight Deck Pressure Indications

1. Placard

- A. Put an O2 PRESSURE INDICATOR INOPERATIVE placard in a position near the Flight deck pressure indication where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Make sure that the available oxygen quantity is sufficient for the intended flight by using the pressure gauge located on the bottle (AFM Section 4, Normal Procedures, Oxygen System).



3.13.2 35-20-01A (ALL) – Passenger oxygen system

1. Placard

- A. Put a PAX O2 SYSTEM INOPERATIVE placard in a position near the Flight deck pressure indication where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance

None required.

3. Operations (O)

- A. Make sure that the Air conditioning system is operative. Make sure that there is flow from air outlets.
- B. Set the Oxygen control valve to the "OFF" position.
- C. Brief the passengers that the Oxygen masks depicted on the Safety briefing cards are inoperative, but that they will not be required due to the selected flight altitude.
- D. Consider in the flight planning that no oxygen is available to the passengers. Consider options (e.g. possibility to descend to a lower altitude) should a passenger develop a condition where use of supplemental oxygen may be advised.
- E. Perform the flight at an altitude not exceeding 10,000 ft. AMSL.



3.13.3 35-20-01-1A – Passenger service units

1. Placard

- A. Install the placard as described in the (O) procedure.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Put a SEAT INOPERATIVE placard on the affected seat.
- B. Put a conspicuous DO NOT OCCUPY placard on the affected seat. Secure the placard in such a way that it is not possible to occupy the seat without disturbing the placard, for example by securing the placard with tape between the seat and seatback.



3.14 ATA 46 – INFORMATION SYSTEMS

3.14.1 46-10-01-1A – Modular avionics unit (MAU) - Actuator input/output processor (AIOP) module channels

1. Placard

- A. Refer to 22-10-01 and 22-30-01.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:
 - 1. Press DUMP switch
- B. Operate the aircraft at an altitude not exceeding 10000 feet.

Note: The ACS may be used normally to provide conditioned air to the cabin.

(O) procedures are also required for inoperative autopilot (refer to 22-10-01A/B) and (if installed) inoperative auto-throttle (refer to 22-30-01A).



3.14.2 46-10-01-2A – Modular avionics unit (MAU) – Advanced graphics module (AGM) channels

1. Placard

- A. Put an AGM CARD INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:
 - 1. Press DUMP switch.
 - 2. Open the hinged service panel (11BR) on the right side of the fuselage and visually confirm that the outflow valve is fully open. The butterfly valve must be in the horizontal position.

Pull the following CBs:

CIRCUIT BREAKERS	BUS
CPCS CH. 1	EPS BUS
CPCS CH. 2	MAIN BUS

CIRCUIT BREAKERS	BUS
CPCS MON	EPS BUS
CPCS AUTO	ESSENTIAL BUS

- B. Perform the flight at an altitude not exceeding 10,000 ft. AMSL.

Note: The ACS may be used normally to provide conditioned air to the cabin.



3.14.3 46-20-01-1A – Display units – Four display configuration

1. Placard

- A. Put a DISPLAY UNIT INOPERATIVE placard in a position near the inoperative display(s).
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Make sure that the operative displays are the pilot-in-command's PFD and at least one of the MFDs.
- B. Use the controls on the Display reversion control panel to achieve an acceptable display configuration on the operative displays.
Make sure that all required display configurations for the intended flight can be configured.
- C. Make sure that no error messages or crossed-out areas are shown on the ESIS.
- D. Confirm that the magnetic standby compass indication agrees with the heading indication on the PFD and that the compass swings freely.

Note: Operation requiring dual crew are not permitted.



3.14.4 46-32-01A – Wireless data loading/downloading system

1. Placard

- A. Put a WIRELESS DATA LOADING/DOWNLOADING SYSTEM INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Pull the following CB:

<u>CIRCUIT BREAKERS</u>	<u>BUS</u>
WLAN DATA LOAD CB	STBY BUS



3.15 ATA 52 – DOORS

3.15.1 52-10-01A – Door key locks

1. Placard

- A. Put a DOOR LOCKS INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

- A. Remove the door lock (use applicable Aircraft Maintenance Manual part for passenger or cargo door, Section 1, Removal).

Note: It is permissible to only remove the locking cam and leave the lock installed.

- B. Install the trim (use applicable AMM chapter, Section 2, Installation).

3. Operations (O)

None required.



3.15.2 52-20-01A – Cabin door seal

1. Placard

- A. Put a CABIN DOOR SEAL INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:
 - 1. Press DUMP switch.
- B. Operate the aircraft at an altitude not exceeding 10 000 feet.



3.15.3 52-20-02A – Cargo door seal

1. Placard

- A. Put a CARGO DOOR SEAL INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew.
Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:
 - 1. Press DUMP switch.
- B. Operate the aircraft at an altitude not exceeding 10,000 feet.



3.15.4 52-20-03A – Emergency exit seal

1. Placard

- A. Put an EMERGENCY EXIT SEAL INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:
 - 1. Press DUMP switch.
- B. Operate the aircraft at an altitude not exceeding 10,000 feet.



3.15.5 52-70-01A – Door warning system (Caption and voice callout)

1. Placard

A. Put a DOOR WARNING SYSTEM INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.

B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

A. Instruct passengers to keep their seatbelts fastened during the entire flight.

B. Instruct passengers not to operate the door mechanism except when directed to do so by the pilot.



3.16 ATA 56 – WINDOWS

3.16.1 56-20-01A – DV-window seal

1. Placard

- A. Put a DV WINDOW SEAL INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Before the flight, prepare the airplane to operate in unpressurized configuration:
 - 1. Press DUMP switch.
- B. Operate the aircraft at an altitude not exceeding 10,000 feet.



3.17 CAS MESSAGES

3.17.1 DME 1 Fail (Caution)

1. Placard

- A. Put a DME 1 INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Make sure that the available navigation equipment is sufficient for the intended flight route and type of operation (VFR/IFR).
- B. Establish procedures to use alternative instrumentation to ensure the navigation capability required for the intended flight.
- C. Review and brief before flight the alternate procedures established under (B).



3.17.2 FCMU Fault (Status)

1. Placard

- A. Put a FCMU INOPERATIVE placard on the edge of the lower MFD. Make sure the display is not obstructed.
- B. Note on the AMAC HIL.

2. Maintenance (M)

None required.

3. Operations (O)

- A. Prior to each departure:
 - 1. Refuel the aircraft to maximum.
 - 2. Operate all three trims through the full range and make sure that correct movement is indicated on the trim indications.
 - B. During flight:
 - 1. Limit the flight duration to maximum three (3) hours.
 - 2. At intervals not exceeding 20 minutes make sure there are no indications of a potential fuel imbalance (increased aileron control forces). Disconnect the autopilot, if used, for this check.
- Note:** If there are indications of a potential fuel imbalance, use fuel transfer to balance the fuel. Land as soon as practical.



3.17.3 GPS 1 Fail (Advisory)

1. Placard

- A. Put a GPS 1 INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL

2. Maintenance (M)

None required.

3. Operations (O)

- A. Make sure that the available navigation equipment is sufficient for the intended flight route and type of operation (VFR/IFR).
- B. Use alternative instrumentation to ensure the navigation capability required for the intended flight on the planned route.
- C. Review and brief before flight the alternate procedures established under (B).



3.17.4 GPS 2 Fail (Advisory)

1. Placard

- A. Put a GPS 2 INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL

2. Maintenance (M)

None required.

3. Operations (O)

- A. Make sure that the available navigation equipment is sufficient for the intended flight route and type of operation (VFR/IFR).
- B. Use alternative instrumentation to ensure the navigation capability required for the intended flight and the planned route.
- C. Review and brief before flight the alternate procedures established under (B).



3.17.5 MMDR 2 Fail (Caution)

1. Placard

- A. Put an MMDR 2 INOPERATIVE placard in a position on the instrument panel where it is visible to the flight crew. Make sure that no displays or other placards are obstructed.
- B. Note on the AMAC HIL

2. Maintenance (M)

None required.

3. Operations (O)

- A. Make sure that the available navigation and communication equipment is sufficient for the intended flight route and type of operation (VFR/IFR). The operator should implement a process where the impact of the unavailability of COM2 VHF is assessed and briefed to the flight crew. This process should consider factors such as, but not limited to:
 - 1. Density and complexity of the airspace,
 - 2. The number of frequency changes and handovers required for the intended flight,
 - 3. Operational rules requiring the monitoring of emergency frequencies,
 - 4. Single or dual crew operation.
- B. Establish procedures to use alternative instrumentation to ensure the navigation capability required for the intended flight.
- C. Review and brief before flight the alternate procedures established under (B).