

The Acme Laser 40 is a desktop CO2 laser cutter for wood, acrylic, card and fabric. This manual covers setup, daily use and routine care. Read the whole manual before the first job, and keep it beside the machine for calibration and cleaning reference.

Clean the lens and mirrors every 20 hours of cutting with the supplied wipes.
Empty the crumb tray weekly and check the exhaust hose for blockages. Replace the air filter when the indicator turns red.

Work area: 400 x 300 mm

Laser power: 40 W CO2 tube

Maximum engraving speed: 600 mm/s

Positioning accuracy: 0.01 mm

Supported files: SVG, DXF, PDF, PNG

Weight: 32 kg

Input voltage: 110-120 V AC, 60 Hz

Rated current: 5 A

Connect the machine to a grounded outlet on its own circuit. Do not use an extension cord.