

Uso del Multímetro y Fuente de Alimentación

Valor de referencia (Vr) [V]:

5.00

N° Medición	Vr [V] (Referencia)	Vm [V] (Medido)	Error Absoluto Ea = Vm - Vr [V]
1	5.000	5.010	0.010
2	5.000	5.009	0.009
3	5.000	5.007	0.007
4	5.000	5.005	0.005
5	5.000	5.002	0.002
6	5.000	5.006	0.006
7	5.000	5.009	0.009
8	5.000	5.009	0.009
9	5.000	5.008	0.008
10	5.000	5.007	0.007
Promedio	5.000	5.007	0.007
Máximo			0.010

Resumen — Error del Multímetro

Rango de Fuente	Vr [V]	Vm Promedio [V]	Error Absoluto Promedio [V]
5V	5.000	5.007	0.007
3.3V	3.300	3.351	0.051
12V	0.000	12.044	0.108

— Vr = 5.0 V

Uso del Multímetro y Fuente de A

Valor de referencia (Vr) [V]:

3.30

Error Relativo $Er = (Ea/Vr) \times 100$ [%]
0.20%
0.18%
0.14%
0.10%
0.04%
0.12%
0.18%
0.18%
0.16%
0.14%
0.14%
0.20%

N° Medición	Vr [V] (Referencia)	Vm [V] (Medido)
1	3.300	3.316
2	3.300	3.354
3	3.300	3.355
4	3.300	3.356
5	3.300	3.355
6	3.300	3.352
7	3.300	3.355
8	3.300	3.357
9	3.300	3.349
10	3.300	3.363
Promedio	3.300	3.351
Máximo		

2

Error Relativo Promedio [%]
0.14%
0.20%
0.90%

Alimentación — Vr = 3.3 V

Error Absoluto Ea = Vm - Vr [V]	Error Relativo Er = (Ea/Vr)x100 [%]
0.016	0.47%
0.054	1.64%
0.055	1.67%
0.056	1.70%
0.055	1.67%
0.052	1.58%
0.055	1.67%
0.057	1.73%
0.049	1.48%
0.063	1.91%
0.051	1.55%
0.063	1.91%

Uso del Multímetro

Valor de referencia (Vr) [V]:

Nº Medición	Vr [V] (Referencia)
1	12.000
2	12.000
3	12.000
4	12.000
5	12.000
6	12.000
7	12.000
8	12.000
9	12.000
10	12.000
Promedio	12.000
Máximo	

metro y Fuente de Alimentación — $V_r = 12.0\text{ V}$

12.00

V _m [V] (Medido)	Error Absoluto E _a = V _m - V _r [V]	Error Relativo E _r = (E _a /V _r)x100 [%]
12.010	0.010	0.08%
12.110	0.110	0.92%
11.720	0.280	2.33%
11.960	0.040	0.33%
12.110	0.110	0.92%
12.100	0.100	0.83%
12.090	0.090	0.75%
12.110	0.110	0.92%
12.110	0.110	0.92%
12.120	0.120	1.00%
12.044	0.108	0.90%
	0.280	2.33%