



Emacs support for the VHDL Hardware Description Language



Description	Keystroke	Function	Note
VHDL Editing	Emacs provide any built-in mode for the VHDL hardware description language support natively.  PEL support for VHDL is minimal		
Last updated on:	2026-09-20		
Open this PDF file. See also: 📘 Help/Info	<f11> SPC H <f1>	(pel-help-pdf &optional OPEN-WEB-PAGE)	Open the VHDL - VHDL local PDF. With C-u , M-- , M- -1 or C- -1 prefix: open the remote GitHub hosted PDF instead. If the pel-flip-help-pdf-arg user-option is set it's the other way around.
📘 Customize PEL VHDL support	<f11> SPC H <f2>	(pel-customize-pel &optional OTHER-WINDOW)	Customize PEL VHDL support. If OTHER-WINDOW is non-nil (use C-u), display in another window.
📘 Customize Emacs VHDL support	<f11> SPC H <f3>	(pel-customize-library &optional OTHER-WINDOW)	Customize Emacs VHDL support: vhd If OTHER-WINDOW is non-nil (use C-u), display in another window.
Comments			
Toggle display of comments in buffer or active region See also: 📘 Comments	<f11> ; ;	(hide/show-comments-toggle &optional START END)	Toggle hiding/showing of comments in the active region or whole buffer. If the region is active then toggle in the region. Otherwise, in the whole buffer.  This requires the hide-comnt.el package (see 📘 Comments).  PEL activates it when the pel-use-hide-comnt user option is t .

Emacs & VHDL — References

Document	Notes
The VHDLHardware Description Language	VHDL @ Wikipedia