1. Safety

Isolate power and vent the receiver to 0 bar before removing any panel. Stored pressure can reach 10 bar.

The compressor restarts automatically on demand; lock out the main isolator before service.

2. Specifications

Free air delivery 6.0 m3/min at 8 bar; maximum working pressure 10 bar.

Motor 37 kW; noise level 68 dB(A) at 1 m.

Oil capacity 18 litres of AF-SYN 46 synthetic compressor oil.

3. Service intervals

Daily: drain the receiver condensate (automatic drain fitted; check it cycles every 10 minutes).

Every 2000 hours: replace the air filter (AF-AIR-60) and the oil filter (AF-OIL-60).

Every 4000 hours: replace the oil separator (AF-SEP-60) and the oil; check the drive belt tension.

4. Fault messages

HIGH DISCHARGE TEMP (above 105 C): clean the cooler fins, check the oil level and the room ventilation; ambient must stay below 40 C.

MOTOR OVERLOAD: check the supply voltage on all three phases and the motor current against 68 A full load.

SEPARATOR DP HIGH (pressure drop above 1 bar across the oil separator): replace the separator element AF-SEP-60.