1. Installation

Water supply: 2 to 4 bar inlet pressure; inlet water hardness should be below 7 dH, otherwise fit the BW-SOFT softener.

Electrical: 400 V three-phase, 32 A breaker. The booster heater draws 9 kW.

2. Cycle data

Wash tank temperature 60 C; final rinse temperature 82 C (sanitising).

Cycle times: 60 s light, 90 s normal, 120 s heavy. Capacity up to 40 racks per hour on the light cycle.

3. Cleaning and maintenance

After every service: drain the tank, remove and rinse the filter baskets, and leave the door open to dry.

Weekly: descale with BW-DESCALE at 1 litre per 50 litres of tank water if limescale is visible on the wash arms.

Every 3 months: check the rinse-aid and detergent dosing hoses for cracks.

4. Error codes

F2 - Tank does not fill within 4 minutes: check the inlet tap is open and the inlet filter screen is clean.

F5 - Final rinse below 82 C: the booster heater is not reaching temperature; check the 9 kW element and its contactor.

F8 - Drain pump blocked: switch off, drain the tank manually and remove debris from the pump impeller.