# PUMP INSTALLATION GUIDE

Disconnect the power supply before installation. The pump requires 24 V and draws 3.5 A. Do not operate it without water.

> Check both valves before starting.

Dimensions: 2 H x 4 W x 6 D in. Maximum pressure: 7 bar. Keep the emergency stop accessible.

Use a 12-pin connector and a 4-meter cable. Operating temperature: -15 to 65 degrees Celsius. Firmware version v4.7.9.

Record the serial number before servicing. Replace the filter every 500 hours. Never bypass the safety switch.