

mostly-a-Scooter - key shortcuts

M5Stack Cardputer ADV | Xiaomi Pro 2 | lock / tail light / brake / alarm build

HOME	
S	Scan for scooters and start a ride
W	Export ride logs over WiFi
B	Export ride logs over Bluetooth
T	Change colour theme (crt / neon / orange)

SCAN	
; .	Move selection up / down
Enter	Connect to the selected scooter
S	Rescan
A	Show all Bluetooth devices / only scooters
F	Forget saved pairing of the selected scooter
Q	Back to home

RIDE SCREEN	
L	Motor lock / unlock (refused above 1 km/h)
H	Tail light: cycles off, brake, always (no headlight control, see note)
S	Open settings
R	Start / stop ride recording (IMU + telemetry log)
I	Battery info pages (press again for next page)
T	Change colour theme
Q	Disconnect and go home

Tail light: the scooter's register only controls the rear light. Headlight is still the power button (double press).

SETTINGS	
L	Motor lock / unlock
H	Tail light: off / brake / always
, .	Motor brake (energy recovery) weaker / stronger: weak, medium, strong. Saved and re-applied on every connect
A	Lock alarm mode: off / wheel / wheel+shake
B	Beep test (check the speaker volume)
Q	Back to ride screen

The bottom line shows what the scooter itself reports for brake and tail light, so you can confirm a change really arrived.

BATTERY INFO PAGES	
I or /	Next page
,	Previous page
R	Start / stop recording
Q	Back to ride screen

LOCK ALARM	
wheel	Beeps when the scooter is locked and the wheel moves faster than 0.5 km/h
wheel+shake	Also beeps when the Cardputer itself is shaken (it must be mounted on the scooter)
Stop	Beeping lasts 4 s after the last movement. Unlock with L to switch it off.

Armed 2.5 s after locking. Needs the Cardputer to stay connected to the scooter.