

SERVICE INSTRUCTION REFRIGERATION

DETECTION OF A TEMPERATURE SENSOR FAULT

In case of a NTC temperature sensor fault, the relative symbols are shown in the displays of the electronic appliances (according to the different appliances).

Please find below the various phases to check if a temperature sensor is faulty:



WARNING: unplug the appliance before operating

- 1. Unplug the appliance before operating, trying to keep the doors closed as long as possible.
- 2. Detach the connectors of the temperature sensors from the electronic board.
- 3. Place a thermometer near or in contact with the temperature sensor (for the evaporator sensors, place the thermometer in a central zone of the evaporating plate).
- 4. Simultaneously, measure the resistance of the temperature sensor at the edges of the connector.
- 5. Compare the value of the measured temperature with the corresponding temperature value of the measured resistance (see attached **tab. A**).
- 6. If the temperatures differ of max. + or 10 °C, the temperature sensor must not be replaced (in this case there could be a false contact; therefore, verify the sensor wiring and the contacts of its connector with the electronic board). If not, the temperature sensor can be considered damaged and must be replaced (order the part no. of the temperature sensor contained in the spare part list of the relative appliance, or, if missing, refer to the Service Bulletin n. 599374122).
- 7. Repeat points 3, 4, 5 and 6 for each temperature sensor.

Characteristics of the temperature sensor:

Temperature	Resistance
[°C]	[Ohm]
-40	90721
-39	84867
-38	79431
-37	74381
-36	69686
-35	65320
-34	61258
-33	57475
-32	53952
-31	50668
-30	47606
-29	44735
-28	42056
-27	39556
-26	37221
-25	35039
-24	32999
-23	31092
-22	29307
-21	27637
-20	26072
-19	24600
-18	23221
-17	21928
-16	20715
-15	19577
-14	18509

Temperature	Resistance
[°C]	[Ohm]
-13	17506
-12	16564
-11	15678
-10	14845
-9	14059
-8	13320
-7	12624
-6	11969
-5	11352
-4	10770
-3	10222
-2	9705
-5 -4 -3 -2 -1 0	9218
0	8758
1	8322
2	7911
3 4	7523
4	7156
5	6809
6	6481
7	6171
8	5877
9	5600
10	5337
11	5087
12	4851
13	4626

Temperature	Resistance
[°C]	[Ohm]
14	4414
15	4213
16	4022
17	3840
18	3668
19	3505
20	3350
21	3202
22	3062
23	2929
24	2802
25	2682
26	2567
27	2458
28	2354
29	2255
30	2161
31	2071
32	1985
33	1904
34	1826
35	1752
36	1681
37	1614
38	1549
39	1488
40	1429

