# MANUAL

1234 1236 1238

ACINDUCTION MOTOR CONTROLLERS

OS 11 with VCL

© 2008 CURTIS INSTRUMENTS, INC.

DESIGN OF CURTIS PMC 1200 SERIES CONTROLLERS PROTECTED BY U.S. PATENT NO. 4626750.

1234/36/38 Manual, p/n 37022 Rev. D: July 2008

» Software version OS 11.0 «



#### **CURTIS INSTRUMENTS, INC.**

200 Kisco Avenue Mt. Kisco, New York 10549 USA Tel. 914.666.2971 Fax 914.666.2188

www.curtisinstruments.com

# **CONTENTS**

1.	OVERVIEV	V1
2.	Mounti High C Low Cu Contro Switch Throttle	TION AND WIRING
3.		MMABLE PARAMETERS
4a.	MONITO	R MENU64
4b.	CONTROL	LLER INFORMATION MENU74
5.	INITIAL S	ETUP75
6.	TUNING (	GUIDE80
7.	VEHICLE	CONTROL LANGUAGE84
8.	DIAGNOS	TICS AND TROUBLESHOOTING110
9.	MAINTEN	IANCE120
APF	PENDIX A	Theory of Operation
APF	PENDIX B	Vehicle Design Considerations
	PENDIX C	Programmer Operation
	ENDIX D	Specifications 1234/36/38 Controllers

# **FIGURES**

FIG. 1:	Curtis 1234, 1236, and 1238 controllers
FIG. 2a:	Mounting dimensions, Curtis 1234 controller
FIG. 2b:	Mounting dimensions, Curtis 1236/38 controllers 4
FIG. 3:	Basic wiring diagram
FIG. 4:	Wiring for Type 1 throttles
FIG. 5:	Wiring for Type 2 throttles
FIG. 6:	Wiring for Type 3 throttles
FIG. 7:	Response rate diagram
FIG. 8:	Throttle mapping, torque control mode
FIG. 9:	Effect of gear soften parameter, torque control mode $37$
FIG. 10:	Effect of brake taper speed parameter, torque control mode $37$
FIG. 11:	Drive current limiting map
FIG. 12:	Regen current limiting map
FIG. 13:	Throttle adjustment
FIG. 14:	VCL motor command diagram
FIG. 15:	VCL control mode processing
FIG. 16:	VCL proportional driver processing
FIG. A-1:	IFO diagram
FIG. A-2:	Power section topology
FIG. C-1:	Curtis 1311 handheld programmer
	TABLES
TABLE 1:	High current connections
TABLE 2:	Low current connections
TABLE 3:	Programmable parameter menus
TABLE 4:	Types of LED display
TABLE 5:	Troubleshooting chart
TABLE D-1:	Specifications, 1234/36/38 controllers

1

# **OVERVIEW**


Curtis 1234, 1236, and 1238 AC induction motor controllers deliver smooth power unlike any previous vehicle control system. They provide unprecedented flexibility and power through inclusion of a field-programmable logic controller embedded in a state-of-the-art motor controller.

The embedded logic controller runs a fully functional field-oriented AC motor control operating system (OS) that can be user-tailored via parameter modification; see Section 3. The OS also contains logic to execute OEM-developed software, called VCL, that can be used to enhance the controller capabilities beyond the basics; see Section 7.

VCL (Vehicle Control Language) is an innovative software programming language developed by Curtis. Many electric vehicle functions are uniquely built into the VCL code, and additional functions can be OEM-controlled using VCL code. VCL opens new avenues of customization, product differentiation, and responsiveness to the market.

The CAN bus communications included in the 1234/36/38, as well as in many other Curtis products, allow these AC induction motor controllers to be part of an efficient distributed system. Inputs and outputs can be optimally shared throughout the system, minimizing wiring and creating integrated functions that often reduce the cost of the system.

Curtis 1234/36/38 controllers are the ideal solution for traction, hoist, dual drive, and other motor drive and vehicle control needs.



**Fig. 1** Curtis 1234 (left), 1236 (middle), and 1238 (right) AC induction motor controllers. All three models have the same standard features.

Like all Curtis controllers, the 1234/36/38 offers superior operator control of motor drive performance. **Features include:** 

- ✓ High efficiency, field-oriented motor control algorithms
- ✓ Advanced Pulse Width Modulation technology for efficient use of battery voltage, low motor harmonics, low torque ripple, and minimized switching losses
- Extremely wide torque/speed range including full regeneration capability
- ✓ Smooth low speed control, including zero speed

More Features 😭

- ✓ Adaptation of control algorithm to motor temperature variation so optimal performance is maintained under widely varying conditions
- ✓ Real-time battery current, motor torque, and power estimates available
- ✓ Power limiting maps allow performance customization for reduced motor heating and consistent performance over varying battery state-of-charge
- ✓ Powerful operating system allows parallel processing of vehicle control tasks, motor control tasks, and user configurable programmable logic
- ✓ A wide range of I/O can be applied wherever needed, for maximum distributed system control
- ✓ Internal battery-state-of-charge, hourmeter, and maintenance timers
- ✓ Easily programmable through the Curtis 1311 handheld programmer and 1314 PC Programming Station
- ✓ CAN bus connection allows communication with other CAN bus enabled system components; protocol meets CANopen standards; other 11-bit identifier field CAN protocols can be custom configured through VCL
- ✓ Field-programmable, with flash downloadable main operating code
- ✓ Thermal cutback, warning, and automatic shutdown provide protection to motor and controller
- ✓ Rugged sealed housing and connectors meet IP65 environmental sealing standards for use in harsh environments
- ✓ Insulated metal substrate power base provides superior heat transfer for increased reliability
- ✓ Built-in Dual Drive software allows easy setup and control of typical dual-drive vehicles, without VCL.

Note: If you have a dual-drive application, see the Dual Drive Addendum to the 1234/36/38 manual, part number 37022-DD.

Familiarity with your Curtis controller will help you install and operate it properly. We encourage you to read this manual carefully. If you have questions, please contact the Curtis office nearest you.



Using the 1311 handheld programmer, you can set up the controller to perform all the basic operations. In this manual, we first show you how to wire your system and adjust its performance characteristics without the use of VCL. Then, in Section 7, we show you how to adjust the system using VCL, which interacts with a second, independent software realm resident in a powerful logic controller embedded within the 1234/36/38 controller.

2


# **INSTALLATION AND WIRING**

#### MOUNTING THE CONTROLLER

The outline and mounting hole dimensions for the 1234 controller are shown in Figure 2a, and for the 1236 and 1238 controllers in Figure 2b. These controllers meet the IP65 requirements for environmental protection against dust and water. Nevertheless, in order to prevent external corrosion and leakage paths from developing, the mounting location should be carefully chosen to keep the controller as clean and dry as possible.

It is recommended that the controller be fastened to a clean, flat metal surface with four 6 mm (1/4) diameter bolts, using the holes provided. A thermal joint compound can be used to improve heat conduction from the controller

Fig. 2a Mounting dimensions, Curtis 1234 motor controller.




heatsink to the mounting surface. Additional heatsinking or fan cooling may be necessary to meet the desired continuous ratings.

You will need to take steps during the design and development of your end product to ensure that its EMC performance complies with applicable regulations; suggestions are presented in Appendix B.



The 1234/36/38 controllers contain **ESD-sensitive components**. Use appropriate precautions in connecting, disconnecting, and handling the controller. See installation suggestions in Appendix B for protecting the controller from ESD damage.

Fig. 2b Mounting dimensions, Curtis 1236 and 1238 motor controllers.





Working on electrical systems is potentially dangerous. You should protect yourself against uncontrolled operation, high current arcs, and outgassing from lead acid batteries:

UNCONTROLLED OPERATION — Some conditions could cause the motor to run out of control. Disconnect the motor or jack up the vehicle and get the drive wheels off the ground before attempting any work on the motor control circuitry.

HIGH CURRENT ARCS — Batteries can supply very high power, and arcing can occur if they are short circuited. Always open the battery circuit before working on the motor control circuit. Wear safety glasses, and use properly insulated tools to prevent shorts.

LEAD ACID BATTERIES — Charging or discharging generates hydrogen gas, which can build up in and around the batteries. Follow the battery manufacturer's safety recommendations. Wear safety glasses.

#### HIGH CURRENT CONNECTIONS


There are five high-current terminals, identified on the controller housing as **B+**, **B-**, **U**, **V**, and **W**.

T	able 1 High Current Connections			
TERMINAL	FUNCTION			
B+	Positive battery to controller.			
B-	Negative battery to controller.			
U	Motor phase U.			
V	Motor phase V.			
W	Motor phase W.			

#### Lug assembly: 1234 models

Five aluminum M6 terminals are provided. Lugs should be installed as follows, using M6 bolts sized to provide proper engagement (see diagram):

- Place the lug on top of the aluminum terminal, followed by a high-load safety washer with its convex side on top. The washer should be a SCHNORR 416320, or equivalent.
- If two lugs are used on the same terminal, stack them so the lug carrying the least current is on top.
- Tighten the assembly to  $10.2 \pm 1.1 \text{ N} \cdot \text{m}$  (90 ±10 in-lbs).




#### Lug assembly: 1236 and 1238 models

Five brass M8 terminals are provided. Lugs should be installed as follows, using M8 bolts sized to provide proper engagement (see diagram):

- Place the lug on top of the brass terminal, followed by a high-load safety washer with its convex side on top. The washer should be a SCHNORR 700800, or equivalent.
- If two lugs are used on the same terminal, stack them so the lug carrying the least current is on top.
- Tighten the assembly to 9.6  $\pm$ 0.9 N·m (85  $\pm$ 8 in-lbs).

Note: The terminals may rotate up to  $\pm 5^{\circ}$  in the cover.



# High current wiring recommendations: all models

#### Battery cables (B+, B-)

These two cables should be run close to each other between the controller and the battery. Use high quality copper lugs and observe the recommended torque ratings. For best noise immunity the cables should not run across the center section of the controller. With multiple high current controllers, use a star ground from the battery **B-** terminal.


#### Motor wiring (U, V, W)

The three phase wires should be close to the same length and bundled together as they run between the controller and the motor. The cable lengths should be kept as short as possible. Use high quality copper lugs and observe the recommended torque ratings. For best noise immunity the motor cables should not run across the center section of the controller. In applications that seek the lowest possible emissions, a shield can be placed around the bundled motor cables and connected to the **B-** terminal at the controller. Typical installations will readily pass the emissions standards without a shield. Low current signal wires should not be run next to the motor cables. When necessary they should cross the motor cables at a right angle to minimize noise coupling.

#### LOW CURRENT CONNECTIONS

All low power connections are made through a single 35-pin AMPSEAL connector. The mating plug housing is AMP p/n 776164-1 and the contact pins are AMP p/n 770520-3. The connector will accept 20 to 16 AWG wire with a 1.7 to 2.7mm diameter thin-wall insulation.

The 35 individual pins are characterized in Table 2.



#### Low current wiring recommendations

#### Motor encoder (Pins 31, 32)

All four encoder wires should be bundled together as they run between the motor and controller logic connector. These can often be run with the rest of the low current wiring harness. The encoder cables should not be run near the motor cables. In applications where this is necessary, shielded cable should be used with the ground shield connected to the I/O ground (pin 7) at only the controller side. In extreme applications, common mode filters (e.g. ferrite beads) could be used.

#### CAN bus (Pins 21, 23, 34, 35)

It is recommended that the CAN wires be run as a twisted pair. However, many successful applications at 125 kBaud are run without twisting, simply using two lines bundled in with the rest of the low current wiring. CAN wiring should be kept away from the high current cables and cross it at right angles when necessary.

#### All other low current wiring

The remaining low current wiring should be run according to standard practices. Running low current wiring next to the high current wiring should always be avoided.

	Table 2 Low Current Connections							
			RELATED '	VCL*				
PIN	NAME	DESCRIPTION	FUNCTIONS	REFERENCES				
1	KSI	Keyswitch input. Provides logic power for the controller and power for the coil drivers.	Setup_BDI	Keyswitch_Voltage				
2	Prop. Driver	Proportional driver. This is a coil driver with current control capability typically used for a proportional valve on a hydraulic manifold. Can also be used as a digital input.	Automate_PWM Put_PWM	Sw_13 PWM5 PD_Current PD_Output PD_Throttle VCL_PD_Throttle				
3	Driver 4	Generic driver #4; can also be used as a digital input. Has low frequency PWM capabilities.	Automate_PWM Put_PWM	Sw_12 PWM4 PWM4_Output				
4	Driver 3	Generic driver #3; can also be used as a digital input. Has low frequency PWM capabilities. Typically used for pump contactor.	Automate_PWM Put_PWM	Sw_11 PWM3 PWM3_Output				
5	Driver 2	Generic driver #2; can also be used as a digital input. Has low frequency PWM capabilities and a slightly higher current rating. Typically used for electromagnetic brake.	Automate_PWM Put_PWM	Sw_10 PWM2 PWM2_Output				
6	Driver 1	Generic driver #1; can also be used as a digital input. Has low frequency PWM capabilities. Typically used for main contactor.	Automate_PWM Put_PWM Set_Interlock Clear_Interlock	Sw_9 PWM1 PWM1_Output Interlock_State Main_State				
7	I/O Ground	Input and output ground reference.						
8	Switch 2 Analog 2	Can be used as generic switch input #2 or as generic analog input #2. Typically used as the motor temperature analog input.		Sw_2 Analog2_Input				
9	Switch 3	Generic switch input #3. Typically used as the interlock switch.		Sw_3				
10	Switch 4	Generic switch input #4.		Sw_4				
11	Switch 5	Generic switch input #5.		Sw_5				

<sup>\*</sup> The related VCL columns are vital when writing VCL code (see Section 7). VCL "functions" are used to access the various I/Os; VCL "references" are predefined names for specific pins.

		Table 2 Low Current	Connections, cont'd	
PIN	NAME	DESCRIPTION	RELATED FUNCTIONS	VCL REFERENCES
12	Switch 6	Generic switch input #6.	TONCTIONS	Sw_6
13	Coil Return	This is the coil return pin for all the contactor coils.		
14	Switch 16 / DNC	In the 1234, this is generic switch input #16. In the 1236 and 1238, Do Not Connect.		Sw_16
15	Throttle Pot High	Pot high connection for a 3-wire throttle pot.		
16	Throttle Pot Wiper	Pot wiper connection for the throttle pot.	Setup_Pot Setup_Pot_Faults	Throttle_Pot Throttle_Pot_Output
17	Pot2 Wiper	Pot wiper connection for the brake pot.	Setup_Pot Setup_Pot_Faults	Brake_Pot Brake_Pot_Output
18	Pot Low	Common pot low connection for the throttle and brake pots.		Pot_Low_Output
19	Digital Out 6	An open collector digital output. Can also be used as a digital input.	Set_DigOut Clear_DigOut	Sw_14 DigOut6 Dig6_Output
20	Digital Out 7	An open collector digital output. Can also be used as a digital input.	Set_DigOut Clear_DigOut	Sw_15 DigOut7 Dig7_Output
21	CAN Term H	High connection for the CAN termination jumper.		
22	Switch 7	Generic switch input #7. Typically used as the Forward switch.		Sw_7
23	CANH	CAN bus high.	Setup_CAN Setup_Mailbox Send_Mailbox etc.	
24	Switch 1 Analog 1	Can be used as generic switch input #1 or as generic analog input #1. Typically used for emergency reverse switch (if applicable).		Sw_1 Analog1_Input
25	+12V Out	Unregulated low power +12V output.		Ext_Supply_Current
26	+5V Out	Regulated low power +5V output.		5_Volts_Output Ext_Supply_Current
27	Pot2 High	Pot high connection for a 3-wire brake pot.		

Yes, this remains Brake\_Pot in VCL.

	Table 2 Low Current Connections, cont'd							
			RELATED VCL					
PIN	NAME	DESCRIPTION	FUNCTIONS	REFERENCES				
28	Serial TX	Serial transmit line for display or flash update.	Setup_Serial					
29	Serial RX	Serial receive line for flash update.	Setup_Serial					
30	Analog Output	Low power, low frequency 0–10V analog output.	Automate_PWM Put_PWM	PWM6 Analog_Output				
31	Encoder A	Quadrature encoder input phase A.		Motor_RPM MotorspeedA				
32	Encoder B	Quadrature encoder input phase B.		Motor_RPM MotorspeedB				
33	Switch 8	Generic switch input #8. Typically used as the Reverse switch.		Sw_8				
34	CAN Term L	Low connection for the CAN bus termination jumper.						
35	CANL	CAN bus low.	Setup_CAN Setup_Mailbox Send_Mailbox etc.					

#### CONTROLLER WIRING: BASIC CONFIGURATION

A basic wiring diagram is shown in Figure 3. Throttle and brake are shown in the diagram as 3-wire potentiometers; other types of throttle and brake inputs are easily accommodated, and are discussed in the following throttle wiring section.

The main contactor coil must be wired directly to the controller as shown in Figure 3 to meet EEC safety requirements. The controller can be programmed




Fig. 3 Basic wiring diagram, Curtis 1234/36/38 motor controller.

to check for welded or missing contactor faults and uses the main contactor coil driver output to remove power from the controller and motor in the event of various other faults. If the main contactor coil is not wired to Pin 6 of the 35-pin connector as shown, the controller will not be able to open the main contactor in serious fault conditions and the system will therefore not meet EEC safety requirements.

Note that the basic wiring diagram is designed for generic applications and may not fully meet the requirements of your system. These controllers have very flexible I/O and wiring configurations; you may wish to contact your local Curtis representative to discuss your particular application.

#### **SWITCH INPUT WIRING**

The following inputs are dedicated to specific functions when the parameter settings are as shown:

```
Switch 1: Emergency Reverse input if the EMR Enable = On and EMR Type = 0 (see page 59).

Switch 3: Interlock input if Interlock Type = 0 (see page 48).

Switch 5: Lift input (depends on VCL program).

Switch 6: Lower input (depends on VCL program).

Switch 7: Forward input if Throttle Type = 1–3 (see page 42).

Switch 8: Reverse input if Throttle Type = 1–3 (see page 42).
```

#### THROTTLE WIRING

In this manual, the term *throttle* is used in two senses: as another name for the drive throttle, and as a generic term covering both the drive throttle and the brake throttle. Wiring is the same, whether the throttle in question is used for braking or for acceleration.

Various throttles can be used with the 1234/36/38 controller. They are characterized as one of five types in the programming menu of the 1311 programmer.

Type 1:	2-wire $5k\Omega$ –0 potentiometers
Type 2:	single-ended 0–5V throttles, current source throttles, 3-wire potentiometers, and electronic throttles
Type 3:	2-wire 0–5k $\Omega$ potentiometers
Type 4:	wigwag 0-5V throttles and 3-wire potentiometers
Type 5:	VCL input (VCL_Throttle or VCL_Brake)

The two throttle inputs (drive throttle and brake throttle) are programmed independently.

<u>For potentiometers</u>, the controller provides complete throttle fault protection that meets all applicable EEC regulations. <u>For voltage throttles</u>, the controller protects against out-of-range wiper values, but does not detect wiring faults; it is therefore the responsibility of the OEM to provide full throttle fault protection in vehicles using voltage throttles.

Throttle types 1–3 use the forward and reverse inputs (switches 7 and 8) in addition to the throttle pot input to define the throttle command (see Figure 13). Throttle types 4 and 5 do not use the forward and reverse inputs.

Wiring for the most common throttles is described in the following text and shown in the accompanying illustrations. If a throttle you are planning to use is not covered, contact the Curtis office nearest you.

## **Throttle Type 1**

For these 2-wire resistive potentiometers, shown in Figure 4, full throttle request corresponds to  $0~\Omega$  measured between the pot wiper pin and the Pot Low pin.

Fig. 4 Wiring for Type 1 throttles.



Broken wire protection is provided by the controller sensing the current flow from the pot wiper input (pin 16 or 17) through the potentiometer and into Pot Low (pin 18). If the Pot Low input current falls below 0.65 mA, a throttle fault is generated and the throttle request is zeroed. Note: Pot Low (pin 18) must not be tied to ground (B-).


# Throttle Type 2

With these throttles, the controller looks for a voltage signal at the wiper input. Zero throttle request corresponds to 0 V and full throttle request to 5 V. A variety of devices can be used with this throttle input type, including voltage sources, current sources, 3-wire pots, and electronic throttles. The wiring for each is slightly different, as shown in Figure 5, and they have varying levels of throttle fault protection.

When a <u>voltage source</u> is used as a throttle, it is the responsibility of the OEM to provide appropriate throttle fault detection. For ground-referenced 0–5V throttles, the controller will detect open breaks in the wiper input but cannot provide full throttle fault protection.

To use a <u>current source</u> as a throttle, a resistor must be added to the circuit to convert the current source value to a voltage; the resistor should be sized to provide a 0–5V signal variation over the full current range. It is the responsibility of the OEM to provide appropriate throttle fault detection.

Fig. 5 Wiring for Type 2 throttles.




When a 3-wire potentiometer is used, the controller provides full fault protection in accordance with EEC requirements. The pot is used in its voltage divider mode, with the controller providing the voltage source and return. Pot High provides a current limited 5V source to the pot, and Pot Low provides the return path. This is the throttle shown in the basic wiring diagram (Figure 3) for the drive throttle and for the brake throttle.

The <u>ET-XXX</u> electronic throttle is typically used only as a drive throttle. The ET-XXX contains no built-in fault detection, and the controller will detect only open wiper faults. It is the responsibility of the OEM to provide any additional throttle fault detection necessary.

# **Throttle Type 3**

For these 2-wire resistive potentiometers, shown in Figure 6, full throttle request corresponds to  $5 \text{ k}\Omega$  measured between the pot wiper pin and the Pot Low pin.

**Fig. 6** Wiring for Type 3 throttles.



Broken wire protection is provided by the controller sensing the current flow from the wiper input (pin 16 or 17) through the potentiometer and into Pot Low (pin 18). If the Pot Low input current falls below 0.65 mA, a throttle fault is generated and the throttle request is zeroed. Note: Pot Low (pin 18) must not be tied to ground (B-).

# **Throttle Type 4**

Type 4 throttles operate in wigwag style. No signals to the controller's forward and reverse inputs are required; the direction is determined by the wiper input value. Only 0–5V voltage sources and 3-wire potentiometers can be used as Type 4 throttles. The controller interface for Type 4 throttles is the same as for Type 2 throttles; see Figure 5. The neutral point will be with the wiper at 2.5 V, measured between pot wiper input (pin 16) and I/O ground return (pin 7). The controller will provide increasing forward speed as the wiper input value is increased, and increasing reverse speed as the wiper input value is decreased.

When a 3-wire pot is used, the controller provides full fault protection. When a voltage throttle is used, the controller will detect open breaks in the wiper input but cannot provide full throttle fault protection.

## **Throttle Type 5**

Throttle Type 5 provides a different way of sending the throttle command to the controller. This throttle type uses VCL to define the throttle signal that will be "input" into the throttle signal chain (see Figure 14). This throttle type can be used for either the drive throttle or the brake throttle by using the VCL variables VCL\_Throttle and VCL\_Brake. How the VCL program is written will determine where the throttle signal originates from, making this a very flexible throttle input method. VCL can be written to use the throttle pot inputs, switch inputs, or CAN communication messages as the source of the throttle signals. If you have questions regarding this throttle type, contact the Curtis office nearest you.

Setting the Throttle Type to Type 5 also allows the throttle and brake pot inputs to be redefined by a VCL program for uses other than throttle or brake input. The variable names that VCL can use to interface with these two inputs are Throttle\_Pot\_Output (see page 93) and Brake\_Pot\_Output (see page 95).

#### INPUT/OUTPUT SIGNAL SPECIFICATIONS

The input/output signals wired to the 35-pin connector can be grouped by type as follows; their electrical characteristics are discussed below.

- digital inputs
- low power outputs
- high power outputs
- analog inputs
- analog output
- power supply outputs
- KSI and coil return inputs
- throttle and brake inputs
- communications port inputs/outputs
- encoder inputs.

## **Digital inputs**

These control lines can be used as digital (on/off) inputs. Normal "on" connection is direct to B+; "off" is direct to B-. Input will pull low (off) if no connection is made. All digital inputs are protected against shorts to B+ or B-.

Nine of these lines (Switches 1–8, 16) are designed to pull current to keep switch contacts clean and prevent leakage paths from causing false signals.

The remaining lines are digital inputs associated with driver outputs; note that they have much higher input impedances. The two digital output lines can also be read as inputs, and are therefore included in this group.

The lines at pins 24 and 8 can also be used as analog inputs, and are included in that group as well.


$\bigcirc \bigcirc \bullet \bigcirc \bigcirc$	DIGITAL INPUT SPECIFICATIONS							
0 0 0 0 0 0 0 0 0 0 13	SIGNAL NAME	PIN	LOGIC THRESHOLDS	INPUT IMPEDANCE	VOLTAGE RANGE*	ESD TOLERANCE		
	Switch 1	24	Rising edge=	24-36V models:	-10 V to	±8 kV (air		
	Switch 2	8	4.4 V max	about 7.1 kΩ	(MaxV+10 V)	discharge)		
	Switch 3	9	Falling edge=	36-48V models:				
	Switch 4	10	1.5 V min	about 11.0 kΩ				
	Switch 5	11		48-80V models:				
	Switch 6	12		about 26.0 kΩ				
	Switch 7	22						
	Switch 8	33						
1234 only (DNC in 1236/38) →	Switch 16	14						
	Digital Out 6	19	Rising edge=	Below 5.5 V=	-5 V to			
1236/38 →	Digital Out 7	20	29.5 V max	134 kΩ	(MaxV+10 V)			
1200/00			Falling edge=	Above 5.5 V=				
			10.1 V min	124 kΩ				
1234 → (	Digital Out 6	19	Rising edge=	Below 10 V=	-0.5 V to			
1204	Digital Out 7	20	4.4 V max	300 kΩ	(MaxV+10 V)			
	Driver 1	6	Falling edge=	Above 10 V=				
	Driver 2	5	1.5 V min	150 kΩ				
	Driver 3	4						
	Driver 4	3						
	Prop Driver	2						

<sup>\* &</sup>quot;MaxV" in this and the following tables is the controller's maximum voltage: 30 V for 24V models; 45 V for 24–36V models; 60 V for 36–48V models; and 105 V for 48–80V models.

#### Low power outputs

Two control lines on the 1236/38 are available as low power digital outputs. These are open collector drivers that can only sink current, not source it, and are intended to drive LEDs or other low current loads connected to the +5V or +12V external power supplies; see power supply output group specs. Fault protection will turn off these outputs if output voltage exceeds about 15 V when the output is On (low output). Both outputs are protected against shorts to B+ or B-.

These lines can also be used as digital inputs, and are included in that group as well.




LOW POWER OUTPUT SPECIFICATIONS							
SIGNAL NAME PIN ALLOWED OUTPUT PROTECTED ESD IMPEDANCE VOLTAGE TOLERANCE							
Digital Out 6	-5 V to	±8 kV (air					
Digital Out 7	20		Off: 134 kΩ	(MaxV+10 V)	discharge)		

<sup>\*</sup> The digital outputs for the 1234 are below, with the high power outputs.

#### High power outputs

Seven control lines on the 1234 and five on the 1236/38 can be used as high power output drivers. One of these, the proportional driver, can be operated in a current control mode for driving a proportional valve or similar load. Each output can be independently turned on continuously (low level) or pulse width modulated to set the average output voltage. These outputs are intended to drive inductive loads such as contactors and electromagnetic brakes but could also be used to drive resistive loads if peak current ratings are not exceeded. All these outputs are protected against shorts to B+ or B-.

These lines can also be used as digital inputs, and are included in that group as well.



HIGH POWER OUTPUT SPECIFICATIONS								
SIGNAL NAME	PIN	PWM	PV CURRENT	FREQ- UENCY	OUTPUT CURRENT	PROTECTED VOLTAGE	ESD TOLERANCE	
Driver 1	6	0 to 100%	n/a	200 Hz	2 A max	-0.5 V to	±8 kV (air	
Driver 2	5	duty cycle			3 A max	keyswitch	discharge)	
Driver 3	4				2 A max	voltage		
Driver 4	3							
Prop Driver	2		0 to 2 A in 607 nominal steps	18 kHz				
Digital Out 6	19	on/off	n/a	n/a	1 A max			
Digital Out 7	20							

<sup>\*</sup> On the 1234, the combined current supplied by all seven output drivers should not exceed 10 A.


1234\* →

#### **Analog inputs**

Two control lines can be used as analog inputs. Both inputs are protected against shorts to B+ or B-.

Typically Analog 2 is used as the input for the motor temperature sensor. This input provides a constant current appropriate for a thermistor sensor. Some standard predefined motor temperature sensors are supported in software (see Sensor Type parameter, page 50). Note: The industry standard KTY temperature sensors are silicon temperature sensors with a polarity band; the polarity band of a KTY sensor must be the end connected to I/O Ground (pin 7).


These lines can also be used as digital inputs, and are included in that group as well.



ANALOG INPUT SPECIFICATIONS								
SIGNAL NAME	PIN	OPERATING VOLTAGE	INPUT IMPEDANCE	PROTECTED VOLTAGE	ESD TOLERANCE			
Analog 1	24	0 to 10 V in	24-36V models:	-10 V to	±8 kV (air			
Analog 2	8	1024 steps	about 7.1 kΩ	(MaxV+10 V)	discharge)			
			36-48V models:					
			about 11.0 kΩ					
			48-80V models:					
			about 26.0 kΩ					

#### Analog output


A single line is available as a low power analog output and is intended to drive instrumentation such as a battery discharge indicator. This output is generated from a filtered PWM signal and has about 1% ripple. The 2% settling time is <25ms for a 0–5V step and <30 ms for a 0–10V step. This output line is protected against shorts to B+ or B-.



ANALOG OUTPUT SPECIFICATIONS					
SIGNAL NAME	PIN	OUTPUT VOLTAGE	OUTPUT IMPEDANCE	PROTECTED VOLTAGE	ESD TOLERANCE
Analog Out	30	0 to 10 V	Source: 100 $\Omega$ Sink: 66 k $\Omega$	-1 V to (MaxV+10 V)	±8 kV (air discharge)

#### Power supply outputs

Two lines provide auxiliary output power for low power circuits such as electronic throttles, LED indicators, displays, position encoder, and remote I/O boards. I/O Ground (at pin 7) is the return line for these low power devices. Both power supply outputs are protected against shorts to B+ or B-.



POWER SUPPLY OUTPUT SPECIFICATIONS					
SIGNAL NAME PIN OUTPUT OUTPUT PROTECTED ESD CURRENT VOLTAGE TOLERAN					ESD TOLERANCE
+12V Out	25	11.5 to 14.5 V	200 mA max	-1 V to	±8 kV (air
+5V Out	26	5 V ±5%	(combined total)	(MaxV+10 V)	discharge)
I/O Ground	7	n/a	500 mA max	not protected	

#### KSI and coil return

KSI input provides power for all low power control circuits, power capacitor precharge (before main contactor turn on), power supply outputs, and high power output drivers. Battery voltage is sensed on the input for the VCL battery discharge function.

Coil Return should be wired to the positive battery side of the contactors being driven so that switching noise associated with PWM operation of the contactors is localized to the contactor wiring only.

It is important to maintain the division between KSI and coil return in order to ensure reverse polarity protection (vehicle wiring correct, battery terminals reversed).




KSI AND COIL RETURN INPUT SPECIFICATIONS					
SIGNAL NAME	OPERATING INPUT PROTECTED ESI PIN VOLTAGE CURRENT VOLTAGE TOLER/				
KSI	1	Between under- and overvoltage	1.0 A max *	±(MaxV+10 V)	±8 kV (air discharge)
Coil Return	13	cutbacks	12 A max **	(KSI-0.3 V) to (MaxV+10 V)	

<sup>\*</sup> Additionally must carry the current supplied to the driver loads by the coil return (pin 13).

# Throttle and brake inputs

The two pot inputs are independently programmable to allow use of a voltage throttle or a 2-wire or 3-wire resistance throttle. Voltage throttles require only the Pot Wiper input (with I/O Ground for the return line). Resistance throttles require Pot Wiper and Pot Low (2-wire) or Pot High, Pot Wiper, and Pot Low (3-wire). All throttle I/O is protected against shorts to B+ or B-.

Alternatively, these two inputs can be used for analog signals other than the throttle and brake pot inputs. Configuring the inputs for use with other signals requires VCL programming; see Section 7.



THROTTLE INPUT SPECIFICATIONS						
SIGNAL NAME	PIN	OPERATING VOLTAGE	INPUT IMPEDANCE	S/SINK CURRENT	PROTECTED VOLTAGE	ESD TOLERANCE
Throttle Pot High	15	0 V (shorted	n/a	7 mA	-50 V to	±8 kV (air
Pot2 High	27	to Pot Low)		nominal	(MaxV+10 V)	discharge)
		5 V (open		(source)		
		circuit)				
Throttle Pot Wiper	16	0 to 6.25 V	290 kΩ	0.76 mA		
Pot2 Wiper	17		(voltage	nominal		
			and 3-wire)	(source,		
				2-wire)		
Pot Low	18	0 to 10 V	20 $\Omega$ nom.	Faults if	-1 V to	
				above	(MaxV+10 V)	
				11 mA		
				(sink)		


<sup>\*\*</sup>On the 1234, the combined current supplied by all seven output drivers should not exceed 10 A.

#### Communications ports

Separate CAN and serial ports provide complete communications and programming capability for all user available controller information.

The Curtis 1311 handheld programmer plugs into a connector wired to pins 28 and 29, along with ground (pin 7) and the +12V power supply (pin 25); see wiring diagram, Figure 3. The Curtis Model 840 display can plug into the same 4-pin connector.

Wiring the CAN Term H and CAN Term L pins together provides a local CAN termination of 120  $\Omega$ , 0.5 W; keep the length of these wires short. CAN Term H and CAN Term L should never be connected to any external wiring.



	COMMUNICATIONS PORT SPECIFICATIONS						
SIGNAL NAME	PIN	SUPPORTED PROTOCOL/DEVICES	DATA RATE	PROTECTED VOLTAGE	ESD TOLERANCE		
CANH CANL	23 35	CANopen, NODES 2.0, other 11-bit identifier field CAN protocols	up to 500 kbps	Continuous= -36 V to (MaxV+10 V) Transient= ±200 V	±8 kV (air discharge)		
CAN Term H CAN Term L	21 34			(no connection to external wiring)	±8 kV (air discharge)		
Serial TX Serial RX	28 29	Curtis 840 Display, 1311 Handheld Programmer, 1314 PC Program- ming Station	as required, 9.6 to 56 kbps	-0.3 to 12 V	±8 kV (air discharge)		

#### **Encoder inputs**

Two control lines are internally configured to read a quadrature type position encoder. The encoder is typically powered from the 5V supply (pin 26) or 12V supply (pin 25), but can be powered from any external supply (from 5 V up to B+) as long as the logic threshold requirements are met.



ENCODER INPUT SPECIFICATIONS						
SIGNAL NAME	PIN	LOGIC THRESHOLDS	INPUT IMPEDANCE	MAX FREQ.	PROTECTED VOLTAGE	ESD TOLERANCE
Encoder A	31	Rising edge=	720 Ω	10 kHz	-5 V to	±8 kV (air
Encoder B	32	2.8 V max Falling edge= 2.2 V min	(internal pull-up to +4V)		(MaxV+10 V)	discharge)

3

# PROGRAMMABLE PARAMETERS

These controllers have a number of parameters that can be programmed using a Curtis 1311 handheld programmer or 1314 Programming Station. The programmable parameters allow the vehicle's performance to be customized to fit the needs of specific applications. For programmer operation, see Appendix C.

#### PROGRAMMING MENUS

The programmable parameters are grouped into nested hierarchical menus, as shown in Table 3.

# Motor response tuning

Motor response characteristics can be tuned through speed control or through torque control, depending on the application. Use the Control Mode Select parameter (page 27) to select which tuning mode you will use:

- Speed Mode Express
- Speed Mode
- Torque Mode.

Speed Mode Express is a simplified version of Speed Mode with a reduced set of parameters that is adequate for most speed-controlled applications.

Use *Speed Mode* or *Speed Mode Express* for applications where throttle input corresponds to motor speed output.

Use *Torque Mode* for applications where throttle input corresponds to motor torque output.

Note: You can tune using torque control or speed control, but not both. For example, if you adjust a torque control parameter while Speed Mode or Speed Mode Express has been selected as your tuning mode, the programmer will show the new setting but it will have no effect.


We strongly urge you to read Section 5, Initial Setup, before adjusting any of the parameters.


Even if you opt to leave most of the parameters at their default settings, it is imperative that you perform the procedures outlined in Section 5, which set up the basic system characteristics for your application.



#### **Table 3 Programmable Parameter Menus: 1311 Programmer**


# CONTROL MODE SELECT ...... p. 27





2 - TORQUE MODE MENU
— <u>Speed Limiter</u> p. 34
—Max Speed
—Kp
—Ki
∟Kd
—Accel Rate
—Accel Release Rate
—Brake Rate
—Brake Release Rate
—Neutral Braking
—Neutral Taper Speed
Fine Tuning p. 36
—Creep Torque
—Brake Full Creep Cancel
—Creep Build Rate
—Creep Release Rate
—Gear Soften
-Brake Taper Speed
-Reversal Soften
└─Max Speed Decel

RESTRAINT MENUp. 38
-Restraint Forward
-Restraint Back
—Soft Stop Speed
Position Holdp. 38
-Position Hold Enable
—Kp
-Kp Deadband (Motor Deg)
—Kd
—Set Speed Settling Time
—Set Speed Threshold
Entry Rate
Exit Rollback Reduction



<u>THROTTLE MENU</u> p. 42
—Throttle Type
-Forward Deadband
—Forward Map
—Forward Max
—Forward Offset
-Reverse Deadband
—Reverse Map
—Reverse Max
—Reverse Offset
—HPD/SRO Type
—Sequencing Delay
VCL Throttle Enable

<b>BRAKE MENU</b> p. 45
—Brake Pedal Enable
—Brake Type
—Brake Deadband
—Brake Map
—Brake Max
—Brake Offset
VCL Brake Enable

#### Table 3 Programmable Parameter Menus: 1311 Programmer, cont'd

EM BRAKE CONTROL MENU p. 46
—Brake Type
—Pull In Voltage
—Holding Voltage
—Battery Voltage Comp
—Set EM Brake On Fault
—Set Speed Threshold
—Release Delay
—Set Speed Settling Time
—Torque Preload Delay
—Torque Preload Enable
Torque Preload Cancel Delay

- Torque Preload Caricel Delay
DRIVERS MENU
—Main Contactor
—Proportional Driver
—Hydraulic Contactor p. 51 —Contactor Enable —Pull In Voltage —Holding Voltage
—Fault Checkingp. 52 —Driver1 Checks Enable —Driver2 Checks Enable —Driver3 Checks Enable

MOTOR MENU p. 53  —Typical Max Speed				
—Swap Encoder Direction				
—Swap Two Phases				
—Encoder Steps				
Temperature Control p. 54				
—Sensor Enable				
—Sensor Type				
—Sensor Offset				
—Temperature Hot				
—Temperature Max				
☐MotorTemp LOS Max Speed				

BAT	<b>TERY MENU</b> p. 55
	—Nominal Voltage
	—Undervoltage Cutback Range
	—User Overvoltage
	—User Undervoltage
	-Reset Volts Per Cell
	—Full Volts Per Cell
	Empty Volts Per Cell
	—Discharge Time
	BDI Reset Percent

DUAL DRIVE MENU ..... see Sec. 4 of

of the Dual Drive


addendum, p/n 37022-DD.

<b>VEHICLE MENU</b> p. 58
—Metric Units
—Speed to RPM
—Capture Speed 1
—Capture Speed 2
-Capture Distance 1
—Capture Distance 2
Capture Distance 3


EMERGENCY REVERSE MENU p. 59			
—EMR Enable			
—EMR Type			
—EMR Dir Interlock			
—EMR Time Limit			
—EMR Speed			
-EMR Accel Rate			
EMR Decel Rate			

INTERLOCK BRAKING MENU p. 60		
—Enable		
—Decel Rate HS		
—Decel Rate LS		
Interlock Brake Timeout		

CAN INTERFACE MENUp. 61			
—CANopen Interlock			
—CAN Node ID			
—Baud Rate			
-Heartbeat Rate			
—PDO Timeout Period			
—Emergency Message Rate			
Suppress CANopen Init			



-Driver4 Checks Enable -PD Checks Enable -External Supply Max -External Supply Min Individual parameters are presented as follows in the menu charts:



Note: All bit variables have two VCL parameter names. The first is the name of the bit, and the second is the name of the byte containing the bit. The bit position within the byte is indicated in brackets after the byte name.

## Examples:

BIT NAME: Metric\_Units
BYTE NAME: OptionBits3 [Bit 5]
BIT NAME: EMR\_Dir\_Interlock
BYTE NAME: EMR\_Dir\_Interlock\_Bit0 [Bit 0]

In the second example, "\_Bit0" is part of the byte name, and does not indicate the bit position; this byte, like all bytes, has 8 available bits.

Within the menu charts, each pair of bit variable names is shown as a grouped set, with the bit name appearing first and then the byte name:

Metric UnitsOn/OffMetric\_UnitsOn/OffOptionBits3[Bit 5]

CONTROL MODE SELECT		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Control Mode Select Control_Mode_Select	0–2 <i>0–2</i>	This parameter determines which control method will be in effect when programming motor response:  0 = SPEED MODE EXPRESS  1 = SPEED MODE  2 = TORQUE MODE.  Contact Curtis if you are interested in a custom control method.  Note: Do not change this parameter while the controller is powering the motor. Any time this parameter is changed a Parameter Change Fault (fault code 49) is set and must be cleared by cycling power; this protects the controller and the operator.

### **Note: Motor Speed Constraints**

The maximum motor speed is a programmable parameter in each control mode. Regardless of which control mode is used, the maximum motor speed the controller will allow is constrained by the number of motor poles, the number of encoder pulses per motor revolution, and the maximum speed constraint imposed by the firmware.

#### Electrical frequency constraint

The maximum electrical frequency the controller will output is 300 Hz. To determine how fast this constraint will allow your motor to spin, use the equation

Max Motor RPM = 36000 / Number of Motor Poles (e.g., a 6-pole motor can run up to 6000 rpm).

#### Encoder pulses/revolution constraint

The maximum encoder frequency the controller will accept is 10 kHz. To determine how fast this constraint will allow your motor to spin, use the equation

Max Motor RPM = 600000 / Encoder Size (e.g., a motor with a 128-pulse encoder can run up to 4687 rpm).

#### Firmware max speed constraint

The maximum motor speed the controller will allow is 8000 rpm.



The overall maximum motor speed allowed is the least of these three constraints.

0 – SPEED MODE EXPRESS MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Max_Speed_SpdMx	100–8000 rpm <i>100–8000</i>	Defines the maximum requested motor rpm at full throttle. Partially-applied throttle is scaled proportionately; e.g., 40% applied throttle corresponds to a request for 40% of the set Max Speed Value.  Note: The maximum motor rpm is subject to the constraints on page 27.
<b>Kp</b> <i>Kp_SpdMx</i>	0–100 % <i>0–8192</i>	Determines how aggressively the speed controller attempts to match the speed of the motor to the commanded speed. Larger values provide tighter control.  If the gain is set too high, you may experience oscillations as the controller tries to control speed. If it is set too low, the motor may behave sluggishly and be difficult to control.
<b>Ki</b> Ki_SpdMx	5–100 % 50–1000	The integral term (Ki) forces zero steady state error, so the motor will run at exactly the commanded speed. Larger values provide tighter control.  If the gain is set too high, you may experience oscillations as the controller tries to control speed. If it is set too low, the motor may take a long time to approach the exact commanded speed.
Accel Rate Accel_Rate_SpdMx	0.1–30.0 sec. 100–30000	Sets the rate (in seconds) at which the speed command increases when throttle is applied. Larger values represent slower response.
Decel_Rate_SpdMx	0.1–30.0 sec. 100–30000	Sets the rate (in seconds) that is used to slow down the vehicle when the throttle is reduced. Larger values represent slower response.
Brake Rate Brake_Rate_SpdMx	0.1–30.0 sec. 100–30000	Sets the rate (in seconds) at which the vehicle slows down when brake is applied or when throttle is applied in the opposite direction. Larger values represent slower response.
Pump Enable  AC_Pump_Enable_SpdM  AC_Pump_Enable_SpdM_Ba	On/Off On/Off it0 [Bit 0]	This parameter should be programmed On to operate a pump motor rather than a vehicle drive motor. Speed controller responsiveness and stability are enhanced, and the motor is allowed to turn only in the forward direction.

1 – SPEED MODE SPEED CONTROLLER MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Max Speed Max_Speed_SpdM	100–8000 rpm <i>100–8000</i>	Defines the maximum requested motor rpm at full throttle. Partially-applied throttle is scaled proportionately; e.g., 40% applied throttle corresponds to a request for 40% of the set Max Speed Value.  If Max_Speed_SpdM is set <100 rpm (through VCL or CAN), the throttle request is zeroed.  Note: The maximum motor rpm is subject to the constraints on page 27.
<b>Кр</b> Кр_SpdM	0–100 % <i>0–8192</i>	Determines how aggressively the speed controller attempts to match the speed of the motor to the commanded speed. Larger values provide tighter control.  If the gain is set too high, you may experience oscillations as the controller tries to control speed. If it is set too low, the motor may behave sluggishly and be difficult to control.
<b>Ki</b> Ki_SpdM	5–100 % <i>50–1000</i>	The integral term (Ki) forces zero steady state error, so the motor will run at exactly the commanded speed. Larger values provide tighter control.  If the gain is set too high, you may experience oscillations as the controller tries to control speed. If it is set too low, the motor may take a long time to approach the exact commanded speed.

	1 – SPEED MO	DE VELOCITY FEEDFORWARD MENU [OPTIONAL]
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Kvff_SpdM	0–500 A <i>0–5000</i>	This velocity feedforward term is designed to improve throttle responsiveness and speed controller performance, especially at low speeds.  For traction systems, set it to 50–70% of the current needed to maintain a very low speed, unloaded, on flat ground.  For a pump system, set it to the lowest load current (i.e., the current running at the minimum load). Alternatively, the responsiveness of a pump speed control loop can be significantly enhanced by using a VCL program to continuously update this parameter to the appropriate value as each pump load is requested.
Build Rate  Vel_FF_Build_Rate_SpdM	0.1–5.0 sec 100–5000	Determines how fast the Kvff term builds up.  For traction systems, if you feel or hear the mechanical slop pick up abruptly when you move the throttle from neutral to a very small value, slowing the build rate (i.e., setting it to a higher value) will soften the feel.  For a pump system, start with this parameter at the minimum setting.  Slowing it down (i.e., setting it to a higher value) will reduce speed overshoot if too much feedforward has been commanded.
Release Rate Vel_FF_Release_Rate_SpdM	0.1–2.0 sec 100–2000	Determines how fast the Kvff term releases. If the release seems too abrupt, slowing the release rate (i.e., setting it to a higher value) will soften the feel.  It should be set fast enough (i.e., at a low enough value) to prevent the vehicle from running on after throttle release.

	1 – SPEED MODE	ACCELERATION FEEDFORWARD MENU [OPTIONAL]
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Kaff Kaff_SpdM	0–500 A <i>0–5000</i>	This acceleration feedforward term is designed to improve throttle responsiveness and speed controller performance at all speeds. It can be thought of as a "quick start" function which can enhance responsiveness at all speeds.  Using your present accel and decel rates, observe the average current you are running at full throttle at low speeds while accelerating without load on flat ground, and set Kaff to 50–70% of that value.  Note: If any accel rate parameters get changed, this parameter will need to be changed also.
Kbff Kbff_SpdM	0–500 A <i>0–5000</i>	This braking feedforward term is designed to improve braking responsiveness at all speeds.  Using your present decel rates, observe the average current you are running at full throttle braking, and set Kbff to that value.
Build Rate  Acc_FF_Build_Rate_SpdM	0.1–5.0 sec 100–5000	Determines how fast the Kaff and Kbff terms build up.  For traction systems, if you feel or hear the mechanical slop pick up abruptly when you move the throttle from neutral to a very small value, slowing the build rate (i.e., setting it to a higher value) will soften the feel.  For a pump system, start with this parameter at the minimum setting. Slowing it down (i.e., setting it to a higher value) will reduce speed overshoot if too much feedforward has been commanded.
Release Rate  Acc_FF_Release_Rate_SpdM	0.1–2.0 sec 100–2000	Determines how fast the Kaff and Kbff terms release. It should be set fast enough (i.e., at a low enough value) to prevent the vehicle from running on after throttle release.

1 – SPEED MODE RESPONSE MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Full_Accel_Rate_HS_SpdM	0.1–30.0 sec 100–30000	Sets the rate (in seconds) at which the speed command increases when full throttle is applied at high vehicle speeds. Larger values represent slower response.
Full Accel Rate LS Full_Accel_Rate_LS_SpdM	0.1–30.0 sec 100–30000	Sets the rate (in seconds) at which the speed command increases when full throttle is applied at low vehicle speeds. Larger values represent slower response.
Low Accel Rate  Low_Accel_Rate_SpdM	0.1–30.0 sec 100–30000	Sets the rate (in seconds) at which the speed command increases when a small amount of throttle is applied. This rate is typically adjusted to affect low speed maneuverability.
Neutral Decel Rate HS Neutral_Decel_Rate_HS_SpdM	0.1–30.0 sec 100–30000	Sets the rate (in seconds) that is used to slow down the vehicle when the throttle is released to neutral at high vehicle speeds.  Larger values represent slower response.
Neutral Decel Rate LS Neutral_Decel_Rate_LS_SpdM	0.1–30.0 sec 100–30000	Sets the rate (in seconds) that is used to slow down the vehicle when the throttle is released to neutral at slow vehicle speeds.  Larger values represent slower response.
Full Brake Rate HS Full_Brake_Rate_HS_SpdM	0.1–30.0 sec 100–30000	Sets the rate (in seconds) at which the vehicle slows down from high speeds when full brake is applied or when full throttle is applied in the opposite direction. Larger values represent slower response.
Full Brake Rate LS Full_Brake_Rate_LS_SpdM	0.1–30.0 sec 100–30000	Sets the rate (in seconds) at which the vehicle slows down from low speeds when full brake is applied or when full throttle is applied in the opposite direction. Larger values represent slower response.
Low Brake Rate  Low_Brake_Rate_SpdM	0.1–30.0 sec 100–30000	Sets the rate (in seconds) at which the vehicle slows down at all speeds when a small amount of brake is applied or a small amount of throttle is applied in the opposite direction. Larger values represent slower response.

1 – SPEED MODE FINE TUNING MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Partial Decel Rate Partial_Decel_Rate_SpdM	0.1–30.0 sec. 100–30000	Sets the rate (in seconds) that is used to slow down the vehicle when the throttle is reduced without being released to neutral. Larger values represent slower response.
HS (High Speed) HS	0–100 % <i>0–3276</i> 7	Sets the percentage of the Typical Max Speed (page 53) above which the "HS" parameters will be used.
LS (Low Speed)	0–100 % <i>0–32767</i>	Sets the percentage of the Typical Max Speed (page 53) below which the "LS" parameters will be used.
Reversal Soften Reversal Soften_SpdM	0–100 % <i>0–3000</i>	Larger values create a softer reversal from regen braking to drive when near zero speed. This helps soften the transition when the regen and drive current limits are set to different values.
Max Speed Accel Max_Speed_Accel_SpdM	0.1–30.0 sec 100–30000	In some applications, the Max Speed value is changed frequently, through VCL or over the CAN bus. The Max Speed Accel parameter controls the rate at which the maximum speed setpoint is allowed to change when the value of Max Speed is raised. The rate set by this parameter is the time to ramp from 0 rpm to Typical Max Speed rpm.  For example, suppose Max Speed is raised from 1000 rpm to 4000 rpm. If Typical Max Speed is 5000 rpm, and the rate is 10.0 seconds, it will take 10.0 * (4000–1000) / 5000 = 6.0 seconds to ramp from 1000 rpm to 4000 rpm.
Max Speed Decel Max_Speed_Decel_SpdM	0.1–30.0 sec 100–30000	This parameter works like the Max Speed Accel parameter, except that it controls the rate at which the maximum speed setpoint is allowed to change when the value of Max Speed is <u>lowered</u> .  For example, suppose you change Max Speed from 4500 rpm to 2500 rpm. If Typical Max Speed is 5000 rpm, and the rate is 5.0 seconds, it will take 5.0 * (4500–2500) / 5000 = 2.0 seconds to ramp from 4500 rpm to 2500 rpm.


**Fig. 7** Response rate diagram.

In this example,

HS = 70%,

LS = 30%,

Typ Max Spd = 5000 rpm.




		1 – SPEED MODE PUMP ENABLE
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Pump Enable  AC_Pump_Enable_SpdM  AC_Pump_Enable_SpdM_Bit0 [B	On/Off On/Off it 0]	This parameter should be programmed On to operate a pump motor rather than a vehicle drive motor. Speed controller responsiveness and stability are enhanced, and the motor is allowed to turn only in the forward direction.

2 - TORQUE MODE SPEED LIMITER MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Max Speed Max_Speed_TrqM	500–8000 rpm <i>500–8000</i>	Defines the maximum allowed motor rpm for torque control mode (independent of throttle position). In torque control mode, full throttle requests 100% of the available torque. Partially-applied throttle is scaled proportionately; e.g., 40% applied throttle corresponds to a request for 40% of the available torque.  Note: The maximum motor rpm is subject to the constraints on page 27.
<b>Kp</b> Kp_TrqM	0–100 % <i>0–8192</i>	Determines how aggressively the speed controller attempts to limit the speed of the motor to Max Speed. Larger values provide tighter control.  If Kp is set too high, you may experience oscillations as the controller tries to control speed. Setting Kp too low may result in a top speed much higher than Max Speed.
<b>Ki</b> Ki_TrqM	5–100 % 50–1000	The integral term (Ki) forces zero steady state error, so the motor speed will be limited to Max Speed. Larger values provide faster control.  If the gain is set too high, you may experience oscillations as the controller tries to limit speed. If it is set too low, it may take a long time for the motor to approach Max Speed from overspeed.
<b>Kd</b> Kd_TrqM	0–100 % <i>0–8192</i>	Provides damping as the vehicle approaches top speed, thereby reducing overshoot. If Kd is set too high, the vehicle may take too long to reach top speed. If Kd is set too low, the vehicle may overshoot top speed, especially when traveling downhill.


2 - TORQUE MODE RESPONSE MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Accel Rate Accel_Rate_TrqM	0.1–30.0 sec. 100–30000	Sets the rate (in seconds) at which the motor torque increases to full when full throttle is applied. Larger values represent slower response.
Accel Release Rate  Accel_Release_Rate_TrqM	0.1–2.0 sec. 100–2000	Determines how quickly deceleration will be initiated when the throttle is released while the vehicle is still accelerating. If the release rate is fast (i.e., set to a low value), the transition is initiated abruptly. The transition is smoother if the release rate is set to a higher value (slower transition); however, setting the rate too high can cause the vehicle to feel uncontrollable when the throttle is released, as it will continue to drive for a short time.
Brake Rate Brake_Rate_TrqM	0.1–5.0 sec. 100–5000	Adjusts the rate (in seconds) at which braking torque builds as the vehicle transitions from drive to braking when direction is reversed, the brake pedal is applied, or neutral braking begins. Lower values represent faster times and therefore faster braking; gentler braking is achieved by setting the braking rate to a higher value.
Brake Release Rate Brake_Release_Rate_TrqM	0.1–2.0 sec. 100–2000	Adjusts the rate (in seconds) at which braking torque releases as as the vehicle transitions from braking to drive.
Neutral Braking Neutral_Braking_TrqM	0–100 % <i>0–3276</i> 7	Neutral braking occurs progressively when the throttle is reduced toward the neutral position or when no direction is selected. The neutral braking parameter is adjustable from 0 to 100% of the regen current limit (see Current Limits menu, page 39).
Neutral Taper Speed Neutral_Taper_Speed_TrqM	200–6000 rpm 200–6000	Determines the motor speed below which braking current is adjusted in both the positive and negative directions when throttle is reduced; see Figure 8.  In the positive direction, the neutral braking current is linearly reduced from 100% at the Neutral Taper Speed to the Creep Torque current at zero rpm motor speed.  In the negative direction, the restraint current is linearly increased from the Creep Torque current at zero rpm motor speed to the restraint current at the Neutral Taper Speed.  Note: Setting the taper speed too low may cause oscillations in the motor.

2 – TORQUE MODE FINE TUNING MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Creep Torque Creep_Torque_TrqM	0–100 % <i>0–32767</i>	Determines the amount of torque applied to the vehicle at a stop with no throttle input, to emulate the feel of an automatic transmission automobile; see Figure 8. <i>WARNING!</i> When interlock is engaged, creep torque allows vehicle propulsion if a direction is selected even though no throttle is applied. Care should be taken when setting up this parameter.  If pedal braking is enabled (see page 45), creep torque is progressively disabled as brake is applied so as to prevent the motor from driving into the brakes and thus wasting energy.
Brake Full Creep Cancel Brake_Full_Creep_Cancel_TrqM	25–100 % 8192–32767	Determines the amount of brake pedal input that will fully cancel the . creep torque. Amount of cancellation is proportional to the brake input.
Creep Build Rate Creep_Build_Rate_TrqM	0.1-5.0 sec 100-5000	Determines how fast the programmed creep torque builds when a direction is selected.
Creep Release Rate Creep_Release_Rate_TrqM	0.1–5.0 sec 100–5000	Determines how fast the programmed creep torque releases when the brake is cancelling the creep torque or when the direction switches are cleared (neutral).
Gear Soften Gear_Soften_TrqM	0–100 % <i>0–5000</i>	Adjusts the throttle take-up from linear (0% setting) to an S curve. Larger values create softer throttle take-up, in forward and reverse. Softening is progressively reduced at higher speeds; see Figure 9.
Brake Taper Speed Brake_Taper_Speed_TrqM	200–6000 rpm 200–6000	Determines the motor speed below which the maximum braking current is linearly reduced from 100% to 0% at zero speed; see Figure 10.  Setting the taper speed too low for the braking current will cause oscillations in the motor as it attempts to brake the vehicle to a stop on very steep slopes.  Taper speed is applicable only in response to brake pedal input; it does not affect direction reversal braking or neutral braking.
Reversal Soften Reversal_Soften	0–100 % <i>0–3000</i>	Larger values create a softer reversal from regen braking to drive when near zero speed. This helps soften the transition when the regen and drive current limits are set to different values.
Max Speed Decel  Max_Speed_Accel_TrqM	0.1–30.0 sec 100–30000	In some applications, the Max Speed value is changed frequently, through VCL or over the CAN bus. The Max Speed Accel parameter controls the rate at which the maximum speed setpoint is allowed to change when the value of Max Speed is lowered. The rate set by this parameter is the time to ramp from Typical Max Speed rpm to 0 rpm.  For example, suppose you change Max Speed from 3000 rpm to 1000 rpm. If Typical Max Speed is 5000 rpm, and the rate is 5.0 seconds, it will take 5.0 * (3000–1000) / 5000 = 2.0 seconds to ramp from 3000 rpm to 1000 rpm.




**Fig. 8** Throttle mapping (torque control mode).

**Fig. 9** Effect of Gear Soften parameter (torque control mode).



**Fig. 10** Effect of Brake Taper Speed parameter (torque control mode).



RESTRAINT MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Restraint Forward Restraint_Forward	0–100 % <i>0–32767</i>	Increases torque when on a steep hill in order to limit roll-forward speed. Setting this parameter too high may cause oscillations in the motor as it attempts to limit the roll-forward speed.
Restraint Back Restraint_Back	0–100 % <i>0–32767</i>	Increases torque when on a steep hill in order to limit roll-back speed. Setting this parameter too high may cause oscillations in the motor as it attempts to limit the roll-back speed.
Soft Stop Speed Soft_Stop_Speed	0–500 rpm <i>0–500</i>	Defines the speed below which a much slower decel rate is used.  A setting of zero disables the function. Note: This parameter works only in Speed Mode and Speed Mode Express.  Soft Stop Speed is useful for vehicles that have fast deceleration and vehicles operating on ramps using the Position Hold function.  With vehicles that have fast deceleration, the driver may find the final speed reduction to zero rpm uncomfortable; the vehicle may even rock back as a result of tire wind-up. Soft Stop Speed allows the vehicle to slow at the same fast rate until it reaches the set threshold, at which point it changes to a slower (softer) deceleration rate. However, if the threshold is set too high, the vehicle will feel like it is "running on."  When throttle is released on a ramp, the vehicle may roll back before Position Hold (see below) takes control. Soft Speed Stop can be used to reduce the amount of rollback, but shouldn't be set so high the vehicle drives up the ramp after the throttle is released.

POSITION HOLD MENU [SPEED MODE & SPEED MODE EXPRESS only]		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Position Hold Enable	On/Off	Allows the Position Hold mode to be entered at zero throttle when
Position Hold Enable	On/Off	the vehicle comes to a stop.
Position_Hold_Enable_Bit0 [Bit (	)]	Note: EM Brake Type = 2 also enables the Position Hold function.
Кр	2–100 %	Determines the stiffness with which position is regulated when in
Kp_Position_Hold	82–2048	Position Hold mode. High Kp will produce less rollback on a ramp, but more bouncing; see Kd below. Too much Kp will cause instability.
Kp Deadband (motor degrees) Kp_Deadband_Position_Hold	0–720 motor <i>0–</i> 819	
Kd Kd_Position_Hold	0–100 % <i>0–8192</i>	Determines the damping in Position Hold mode. Some damping must be present in the control system to keep the vehicle from oscillating slowly ("bouncing"). High Kd will improve the dynamic response of the Position Hold controller, but too much Kd will cause fast instability.
Set Speed Settling Time Set_Speed_Settling_Time	0–5000 rpm <i>0–156</i>	This parameter appears twice in the menu structure. For description, see EM Brake Control menu, page 47.
Set Speed Threshold	5–100 rpm	This parameter appears twice in the menu structure. For description,
Set_Speed_Threshold	5-100	see EM Brake Control menu, page 47.

	POSITION HOLD MENU, cont'd		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION	
Entry Rate Entry_Rate_Position_Hold	5–100 % 50–1000	When the vehicle transitions from forward speed to reverse speed or from reverse speed to forward speed (for example, when coming to a stop going up a steep ramp), Position Hold is automatically entered immediately at zero speed—regardless of this parameter.  This parameter applies when the vehicle needs to be brought to a stop without the assistance of gravity (for example, when moving forward down a ramp). This rate determines how quickly zero speed is attained after the ramped speed request reaches zero. Setting this parameter too high will make the stop seem very abrupt, and may even cause the vehicle to roll back slightly. When the parameter is set lower, the vehicle take longer to come to a stop and enter Position Hold mode.	
Exit Rollback Reduction Exit_Rollback_Reduction	0–100 % <i>0–2048</i>	This function is applicable only when the Torque Preload function has been disabled (see EM Brake menu), or its timer has expired. It introduces a proportional feedforward term into the speed controller based on the position signal. For example, suppose the vehicle is on a ramp and a forward throttle request is given such that the vehicle rolls back slightly before climbing the ramp (again, assuming the torque preload function is inactive). As the vehicle rolls back a feedforward torque term proportional to the rollback position will be added to the torque request until forward speed is sensed.	


CURRENT LIMITS MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Drive Current Limit Drive_Current_Limit	5–100 % 1638–32767	Sets the maximum RMS current the controller will supply to the motor during drive operation, as a percentage of the controller's full rated current.* Reducing this value will reduce the maximum drive torque.
Regen Current Limit Regen_Current_Limit	5–100 % 1638–32767	Sets the maximum RMS regen current, as a percentage of the controller's full rated current.* The regen current limit applies during neutral braking, direction reversal braking, and speed limiting when traveling downhill.
Brake Current Limit Brake_Current_Limit	5–100 % 1638–32767	Sets the maximum RMS regen current during braking when a brake command is given, as a percentage of the controller's full rated current.* Typically the brake current limit is set equal to the regen current limit. The brake current limit overrides the regen current limit when the brake input is active.
EMR Current Limit EMR_Current_Limit	5–100 % 1638–32767	Sets the maximum RMS current allowed for braking and drive when in emergency reverse. The emergency reverse current limit is a percentage of the controller's full rated current.*
Interlock Brake Current Interlock_Brake_Current_		Sets the maximum RMS regen current during interlock braking, as a percentage of the controller's full rated current.*

<sup>\*</sup> The full rated current depends on the controller model; see specifications in Table D-1 for the rated current of your model.

POWER LIMITING MAP MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Nominal Speed PL_Nominal_Speed	100–4000 rpm 100–4000	Sets the base speed that will be used in the drive limiting map and regen limiting map.
Delta Speed PL_Delta_Speed	50–1000 rpm <i>50–1000</i>	Sets the width of the delta increment that will be used in the drive limiting map and regen limiting map.


DRIVE LIMITING MAP MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Nominal PL_Drive_Nominal	0–100 % <i>0–32767</i>	
Plus Delta PL_Drive_Nominal_Plus_Delta	0–100 % <i>0–32767</i>	These parameters define the percentage of drive current limit that will be applied at the speeds defined by the base speed
Plus 2xDelta PL_Drive_Nominal_Plus_2xDelta	0–100 % <i>0–32767</i>	and delta speed parameters. The resulting map allows the controller to reduce the drive current as a function of speed.  Reducing the power requirements at certain speeds
Plus 4xDelta PL_Drive_Nominal_Plus_4xDelta	0–100 % <i>0–32767</i>	<ul> <li>restricts performance. This can be useful for reducing motor heating. It can also be used to keep consistent vehicle power with changing battery state-of-charge.</li> </ul>
Plus 8xDelta PL_Drive_Nominal_Plus_8xDelta	0–100 % <i>0–32767</i>	

Fig. 11 Drive current limiting map (typical example).



	REGEN LIMITING MAP MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION	
Nominal PL_Regen_Nominal	0–100 % <i>0–32767</i>		
Plus Delta PL_Regen_Nominal_Plus_Delta	0–100 % <i>0–32767</i>	These parameters define the percentage of regen current limit that will be applied at the speeds defined by the base speed	
Plus 2xDelta PL_Regen_Nominal_Plus_2xDelta	0–100 % <i>0–32767</i>	and delta speed parameters.  The curve can be shaped to limit the available torque at various speeds. One possible use is to compensate for the	
Plus 4xDelta PL_Regen_Nominal_Plus_4xDelta	0–100 % <i>0–32767</i>	torque-speed characteristic of the motor.	
Plus 8xDelta PL_Regen_Nominal_Plus_8xDelta	0–100 % <i>0–32767</i>		

Fig. 12 Regen current limiting map (two examples).



THROTTLE MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Throttle Type Throttle_Type	1–5 1–5	The 1234/36/38 controllers accept a variety of throttle inputs. The throttle type parameter can be programmed as follows:
		1 2-wire rheostat, $5k\Omega$ –0 input
		2 <u>single-ended</u> 3-wire $1k\Omega$ – $10k\Omega$ potentiometer, or 0–5V voltage source
		3 2-wire rheostat, $0-5k\Omega$ input
		4 wigwag 3-wire $1k\Omega$ -10kΩ potentiometer, or 0-5V voltage source
		5 VCL input (VCL_Throttle)
		Note: Do not change this parameter while the controller is powering the motor. Any time this parameter is changed a Parameter Change Fault (fault code 49) is set and must be cleared by cycling power; this protects the controller and the operator.
Forward Deadband Forward_Deadband	0–5.00 V <i>0–32767</i>	Defines the wiper voltage at the throttle deadband threshold. Increasing the throttle deadband setting will increase the neutral range. This parameter is especially useful with throttle assemblies that do not reliably return to a well-defined neutral point, because it allows the deadband to be defined wide enough to ensure that the controller goes into neutral when the throttle mechanism is released.
Forward Map Forward_Map	0–100 % <i>0–32767</i>	Modifies the vehicle's response to the throttle input. Setting the throttle map at 50% provides a linear output response to throttle position. Values below 50% reduce the controller output at low throttle settings, providing enhanced slow speed maneuverability. Values above 50% give the vehicle a faster, more responsive feel at low throttle settings.  The map value is the percentage of controller output at half throttle ((deadband + max)/2).
Forward Max Forward_Max	0–5.00 V <i>0–32767</i>	Defines the wiper voltage required to produce 100% controller output. Decreasing the throttle max setting reduces the wiper voltage and therefore the full stroke necessary to produce full controller output. This parameter allows reduced-range throttle assemblies to be accommodated.
Forward Offset Forward_Offset	0–100 % <i>0–32767</i>	Defines the initial controller output generated when the throttle is first rotated out of the neutral deadband. For most vehicles, a setting of 0 is appropriate. For heavy vehicles, however, increasing the offset may improve controllability by reducing the amount of throttle required to start the vehicle moving.




Note: All four throttle adjustment parameters — Deadband, Map, Max, Offset — condition the raw throttle voltage into a single % throttle command, as shown in Figure 13.

THROTTLE MENU, cont'd		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Reverse Deadband	0-5.00 V	
Reverse_Deadband	0–32767	
Reverse Map	0–100 %	
Reverse_Map	0–32767	The four Throttle Reverse parameters are the same as their
Reverse Max	0–5.00 V	Throttle Forward counterparts, and apply when the throttle direction is reversed.
Reverse_Max	0–32767	
Reverse Offset	0–100 %	
Reverse_Offset	0-32767	

Fig. 13 Effect of throttle adjustment parameters. Together these four generic parameters determine the controller's response to throttle demand (in forward or reverse) and to brake demand.

In the examples shown in this figure,

Deadband = 0.5V Max = 4.5VOffset = 0.



		THROTTLE MENU, cont'd
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
HPD/SRO Type  [HPD_SRO_Type  OptionBits1 [Bit 4]	0–3 <i>0–3</i>	Determines whether the HPD/SRO feature will be active. One type of checks is available for material-handling vehicles, and two types for golf-style vehicles. If any of the HPD/SRO checks finds an input sequencing problem, an HPD/Sequencing Fault (flash code 47) is set.
		0 HPD/SRO feature is disabled.
		1 HPD/SRO checks enabled for material-handling vehicle.  At KSI on, a one-time check of the inputs is made to verify that the following inputs have been activated in the proper order: KSI first, then interlock before either direction input or a throttle input >25%.  Continuous check every time the interlock turns Off and the sequencing delay time has expired (the sequencing delay timer starts counting down when interlock switches off); a check is made the next time interlock is applied to verify that interlock was applied before either direction input or a throttle input >25%.
		At KSI on, a one-time check is made to verify the throttle input <25%.  Continuous check when the vehicle is stationary (bit variable Park_State_Speed_Control = On means stationary) to verify the interlock and a direction switch were applied before throttle input >25%. The order of the interlock and direction switch does not matter. Once moving (Park_State_Speed_Control = Off), directional switching (forward to reverse, or reverse to forward) is allowed with throttle input >25%; i.e., no fault results.  HPD/SRO checks enabled for golf-style vehicle.  At KSI on, a one-time check is made to verify the throttle input <25%.  Continuous check to verify the interlock and a direction switch were applied before throttle input >25%. The order of the interlock and direction switch does not matter. Type 3 differs from Type 2 in that it only checks this condition when the vehicle is stationary. With Type 3 the interlock and a direction switch must always precede the throttle input regardless of vehicle speed.
Sequencing Delay Sequencing_Delay	0.0–5.0 sec. <i>0–312</i>	Typically the sequencing delay feature allows the interlock switch to be cycled within a set time (the defined sequencing delay), thus preventing inadvertent activation of HPD/SRO. This feature is especially useful in applications where the interlock switch may bounce or be momentarily cycled during operation.
VCL Throttle Enable  VCL_Throttle_Enable  VCL_Throttle_Enable_Bit0 [Bit	On/Off On/Off	When programmed On, the throttle processing with fault detection will operate normally; however, the throttle command (see Figure 14, page 92) will require VCL to define the connection between the OS_Throttle and VCL_Throttle variables. This allows VCL flexibility and customization of throttle processing, while still allowing Throttle_Type 1–4 with throttle fault detection.

		BRAKE MENU
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Brake Pedal Enable Brake_Pedal_Enable OptionBits1 [Bit 3]	On/Off On/Off	Determines whether the brake input and algorithm are enabled, making the brake throttle part of the motor control command.
Brake Type Brake_Type	1–5 <i>1–</i> 5	The 1234/36/38 controllers accept a variety of brake inputs. The brake type parameter can be programmed as follows:
		1 2-wire rheostat, $5k\Omega$ –0 input
		<ul> <li>single-ended 3-wire 1kΩ-10kΩ potentiometer,</li> <li>0-5V voltage source, or current source</li> </ul>
		3 2-wire rheostat, $0-5k\Omega$ input
		4 (not applicable)
		5 VCL input ( <i>VCL_Brake</i> )
		Note: Do not change this parameter while the controller is powering the motor. Any time this parameter is changed a Parameter Change Fault (fault code 49) is set and must be cleared by cycling power; this protects the controller and the operator.
Brake Deadband	0-5.00 V	
Brake_Deadband	0–32767	
Brake Map Brake_Map	0–100 % <i>0–32767</i>	The four Brake throttle adjustment parameters are the same as their Drive throttle counterparts; see descriptions and Figure 13.
Brake Max Brake_Max	0–5.00 V <i>0–32767</i>	
Brake Offset	0–100 %	<del></del>
Brake_Offset	0–32767	
VCL_Brake Enable VCL_Brake_Enable VCL_Brake_Enable_Bit0 [E	On/Off On/Off Bit 0]	When programmed On, the brake processing with fault detection will operate normally; however, the brake command (see Figure 14) will require VCL to define the connection between the OS_Brake and VCL_Brake variables. This allows VCL flexibility and customization of throttle processing,

EM BRAKE CONTROL MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Brake Type  EM_Brake_Type	0–2 <i>0–</i> 2	The brake type parameter determines how the EM brake responds to the interlock input, throttle, and vehicle motor speed.
		0 EM brake function disabled. The EM brake driver (PWM2) is released to general I/O use with VCL.
		1 EM brake controlled by interlock. The controller will command the EM brake to release whenever the interlock is closed (Interlock = On). If interlock braking is enabled and the interlock opens when the vehicle is moving at motor speed greater than EM_Brake_Set_Speed_Threshold, the controller will brake the vehicle to a stop (with interlock braking) and then command the EM brake to set. If the vehicle motor speed is less than this threshold, the EM brake will engage after the Sequencing_Delay has expired.  If interlock braking is disabled, the EM brake will engage after the Sequencing_Delay has expired.
		2 EM brake controlled by interlock and neutral. The controller will command the EM brake to set whenever the throttle command is zero and motor speed is less than EM_Brake_Set_Speed_Threshold. Position Hold will be enabled automatically.
Pull In Voltage  EM_Brake_Pull_In_Voltage	0–100 % <i>0–32767</i>	The EM brake pull-in voltage allows a high initial voltage when the EM brake first turns on, to ensure brake release. After 1 second, this peak voltage drops to the EM brake holding voltage.  Note: The Battery Voltage Compensated parameter controls whether the pull-in and holding voltages are battery voltage compensated.
Holding Voltage EM_Brake_Holding_Voltage	0–100 % <i>0–32767</i>	The EM brake holding voltage allows a reduced average voltage to be applied to the brake coil once the brake has been released. This parameter must be set high enough to hold the brake released under all shock and vibration conditions the vehicle will be subjected to.  Note: The Battery Voltage Compensated parameter controls whether the pull-in and holding voltages are battery voltage compensated.
Battery Voltage Compensated  EM_Brake_Battery_Voltage_ Compensated  EM_Brake_Battery_Voltage_ Compensated_Bit0 [Bit 0]	On/Off On/Off	This parameter determines whether the EM brake pull-in and holding voltages are battery voltage compensated. When set On, the pull-in and holding voltages are compensated relative to the set Nominal Voltage (see Battery Menu, page 55). In other words, the output voltage is adjusted to compensate for swings in battery voltage, so the percentage is relative to the set Nominal Voltage—not to the actual voltage.  For example, suppose Nominal Voltage is set to 48V and Holding Voltage is set to 75% (36V) to the output driver. Now suppose the bus volt age dips to 40V. If Battery Voltage Compensated = On, the output will still be 36V (Nominal Voltage × Holding Voltage) to the coil. If Battery Voltage Compensated = Off, the output will be 30V (Actual Voltage × Holding Voltage) to the coil.
Set EM Brake On Fault  EM_Brake_Set_Upon_Fault  EM_Brake_Set_Upon_ Fault_Bit0 [Bit 0]	On/Off On/Off	When programmed On, the controller's operating system will drop the electromagnetic brake when a fault occurs that has a fault action of ShutdownEMBrake. See Section 8 for a list of all the faults that have a fault action of ShutdownEMBrake.

EM BRAKE CONTROL MENU, cont'd		
ALLOWABLE PARAMETER RANGE	DESCRIPTION	
Set Speed Threshold 5–100 rpm Set_Speed_Threshold 5–100	Determines the speed below which the EM brake will be commanded to set. Setting this speed too high may cause a jerky stop when the EM brake sets and stops the motor.	
Release Delay 40–2000 msec EM_Brake_Release_Delay 5–250	Estimated time for the EM brake to physically release after the pull-in voltage is applied. This is used to ensure the position hold torque buildup is complete before the brake releases. When set too low, the vehicle may experience rollback on EM brake release.	
Set Speed Settling Time 0–5000 msec Set_Speed_Settling_Time 0–156	Determines how long the position hold function is allowed to operate before the EM brake is set. This time should be set long enough for the position hold to settle.  Note: This parameter is applicable only when Speed Mode or Speed Mode Express is selected and either Position Hold Enable = On or EM Brake Type = 2.	
Torque Preload Delay 0–800 msec  EM_Brake_Torque_Preload_ 0–100  Delay	Estimated worst-case time to build up the torque required to hold the vehicle stationary on a hill prior to EM brake release. This is used in conjunction with Release Delay to determine when to release the brake and allow the speed request to slew away from zero.  Note: This parameter is applicable only when Speed Mode or Speed Mode Express is selected and either Position Hold Enable = On or EM Brake Type = 2.	
Torque Preload Enable On/Off  EM_Brake_Torque_Preload_Enable On/Off  EM_Brake_Torque_Preload_ Enable_Bit0 [Bit 0]	When enabled, this function eliminates rollback when the throttle is re-engaged on a ramp by forcing the vehicle to first enter position-hold before setting the EM brake, and then "remembering" the amount of torque that was necessary to hold it on the ramp. When throttle is re-engaged, this value is loaded in the motor before the EM brake is released. The torque value is cleared automatically when KSI power is cycled.  Off = When a valid throttle input is received, the speed controller will start with no torque preload as soon as the Release Delay expires. This will allow some rollback when the EM brake releases.  On = When a valid throttle input is received, the speed controller will start with a pre-set torque as measured by position-hold when the vehicle came to a stop.  Note: This parameter is applicable only when Speed Mode or Speed Mode Express is selected and either Position Hold Enable = On or EM Brake Type = 2.	
Torque Preload Cancel Delay  EM_Brake_Torque_Preload_ Cancel_Delay  0-120 sec 0-15000	The timer starts after the EM brake is set. If the timer expires before the throttle is re-engaged, the torque preload memory will be cleared. Setting this parameter to zero disables the timer, i.e., the preload is never cancelled. The purpose of this delay is to prevent the vehicle from lunging forward if it is unloaded on a hill such that the torque measured by position-hold is no longer valid.  Note: This parameter is applicable only when Torque Preload Enable = On (see conditions above).	

			MAIN CONTACTOR MENU
PARAMETER	A	RANGE	DESCRIPTION
Main Enable Main_Enable OptionBits1 [Bit 0]		On/Off On/Off	When programmed On, the controller's native software controls the main contactor when the interlock is enabled; when programmed Off, the contactor is controlled by VCL. Note: With Main Enable programmed Off, the controller will not be able to open the main contactor in serious fault conditions and the system will therefore not meet EEC safety requirements
Pull In Voltage Main_Pull_In_Voltag		)–100 % <i>0–32767</i>	The main contactor pull-in voltage parameter allows a high initial voltage when the main contactor driver first turns on, to ensure contactor closure.  After 1 second, this peak voltage drops to the contactor holding voltage.  Note: The Battery Voltage Compensated parameter (below) controls whether the pull-in and holding voltages are battery voltage compensated.
Holding Voltage Main_Holding_Voltag		0–100 % <i>0–32767</i>	The main contactor holding voltage parameter allows a reduced average voltage to be applied to the contactor coil once it has closed. This parameter must be set high enough to hold the contactor closed under all shock and vibration conditions the vehicle will be subjected to.  Note: The Battery Voltage Compensated parameter (below) controls whether the pull-in and holding voltages are battery voltage compensated.
Battery Voltage Cor Main_Driver_Battery Compensated Main_Driver_Battery Compensated_Bit	_Voltage_ v_Voltage_	On/Off On/Off	This parameter determines whether the main pull-in and holding voltages are battery voltage compensated. When set On, the pull-in and holding voltages are set relative to the set Nominal Voltage (see Battery Menu, page 55). In other words, the output voltage is adjusted to compensate for swings in battery voltage, so the percentage is relative to the set Nominal Voltage—not to the actual voltage.  For example, suppose Nominal Voltage is set to 48V and Holding Voltage is set to 75% (36V) to the output driver. Now suppose the bus voltage dips to 40V. If Battery Voltage Compensated = On, the output will still be 36V (Nominal Voltage × Holding Voltage) to the coil. If Battery Voltage Compensated = Off, the output will be 30V (Actual Voltage × Holding Voltage) to the coil.
Interlock Type Interlock_Type		0–2 <i>0–2</i>	Three interlock options are available:  0 = interlock turns on with switch 3.  1 = interlock controlled by VCL functions.  2 = interlock turns on with KSI.
Open Delay Open_Delay	0–40 sec. <i>0–2500</i>		Applicable only when Interlock Type = 0 or 1. The delay can be set to allow the contactor to remain closed for a period of time (the delay) after the interlock switch is opened. The delay is useful for preventing unnecessary cycling of the contactor and for maintaining power to auxiliary functions that may be used for a short time after the interlock switch has opened.
Checks Enable Checks_Enable OptionBits1 [Bit 2]	On/Off On/Off		When programmed On, the controller performs ongoing checks to ensure that the main contactor has closed properly each time it is commanded to do so, and that it has not welded closed. These checks (Main Contactor Welded and Main Contactor Did Not Close) are not performed if this parameter is Off. The main contactor driver, however, is always protected from short circuits.

MAIN CONTACTOR MENU, cont'd		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Main DNC Threshold Main_DNC_Threshold	0–84.0 V <i>0–5376</i>	When Checks Enable = On, this parameter is used as the threshold for detecting a Main Did Not Close fault. The Main DNC Threshold is the minimum voltage difference between the Keyswitch and Capacitor voltages. When the voltage difference is below this threshold, and the battery current is low, a Main Did Not Close fault will be set. Setting this parameter lower will increase the sensitivity of the fault detect. Setting this parameter too low may cause false fault trips due to normal voltage drops between the keyswitch and capacitor voltages.  Setting this parameter = 0 V will disable the Main Did Not Close fault check.
Precharge Enable Precharge_Enable OptionBits2 [Bit 6]	On/Off <i>On/Off</i>	Turns the precharge feature on and off. Precharge provides a limited current charge of the controller's internal capacitor bank before the main contactor is closed. This decreases the arcing that would otherwise occur when the contactor is closed with the capacitor bank discharged.

PROPORTIONAL DRIVER MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
PD Enable PD_Enable OptionBits1 [Bit 6]	On/Off On/Off	Determines how the PWM of the proportional driver is controlled. When programmed On, it is controlled by the controller's PD current control software. When programmed Off, it is controlled by the VCL function <i>Put_PWM</i> (PWM5, value); see Figure 16, page 97.
Hyd Lower Enable  Hyd_Lower_Enable  OptionBits1 [Bit 7]	On/Off On/Off	When programmed On, lowering is controlled by throttle position.  When programmed Off, lowering is controlled by the VCL variable VCL_PD_  Throttle; see Figure 16, page 97.
PD Max Current PD_Max_Current	0.0–2.0 A <i>0–607</i>	* The Lower speed is determined by the aperture of the proportional valve.  This parameter sets the maximum allowed current through the valve, which in turn defines its aperture.
PD Min Current PD_Min_Current	0.0–2.0 A <i>0–607</i>	* Sets the minimum allowed current through the proportional valve.  Most proportional valves need a non-zero closed current in order to start opening immediately when Lower is requested.
PD Dither % PD_Dither_Percent	0–100 % <i>0–32767</i>	* Dither provides a constantly changing current in the coil to produce a rapid back-and-forth motion of the valve; this keeps the valve lubricated and allows low-friction, precise movement. The PD Dither % parameter specifies the amount of dither as a percentage of the PD max current, and is applied in a continuous cycle of add%-subtract%.
PD Dither Period PD_Dither_Period	16–112 msec 1–7	* Sets the period for proportional valve dither.
PD Kp PD_Kp	1–100 % <i>82–8192</i>	* Sets the proportional gain of the current feedback controller. Higher gains force the control loop to respond quickly but may cause oscillations.
PD Ki PD_Ki	1–100 % 327–32767	* Sets the integral gain of the current feedback controller. Integral gain tries to force the error to zero. Higher gains force the control loop to respond quickly but may cause oscillations.

<sup>\*</sup> These parameter descriptions assume the proportional driver is being used to drive a proportional valve, and that the PD current control software is active (PD\_Enable = On).

HYDRAULIC CONTACTOR MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Contactor Enable	On/Off	When programmed On, VCL functions control Driver 3 as the hydraulic
Hydraulic_Contactor_Enable   OptionBits4 [Bit 1]	On/Off	pump contactor.  On: The VCL function Start_Pump() will close the pump contactor according to the defined pull-in and holding voltages. The VCL function Stop_Pump() will open the pump contactor.
		Off: Driver 3 will be available for general VCL usage. Start_Pump() and Stop_Pump() will not have any effect.
Pull In Voltage Hydraulic_Pull_In_Voltage	0–100 % <i>0–32767</i>	The hydraulic contactor pull-in voltage parameter allows a high initial voltage when the hydraulic contactor driver first turns on, to ensure contactor closure. After 1 second, this peak voltage drops to the contactor holding voltage.  Note: This voltage will be battery voltage compensated.
Holding Voltage Hydraulic_Holding_Voltage	0–100 % <i>0–3276</i> 7	The hydraulic contactor holding voltage parameter allows a reduced average voltage to be applied to the contactor coil once it has closed. This parameter must be set high enough to hold the contactor closed under all shock and vibration conditions the vehicle will be subjected to.  Note: This voltage will be battery voltage compensated.

FAULT CHECKING MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Driver1 Checks Enable  Driver1_Checks_Enable  OptionBits2 [Bit 1]	On/Off <i>On/Off</i>	
Driver2 Checks Enable  Driver2_Checks_Enable  OptionBits2 [Bit 2]	On/Off On/Off	<ul> <li>The five Checks Enable parameters are used to enable driver and coil fault detection at the five individual drivers (at Pins J1-6, J1-5, J1-4, J1-3, and J1-2). When a Checks parameter is enabled, the associated driver, driver wiring, and driver load are checked to verify that the driver correctly drives the load</li> </ul>
Driver3 Checks Enable  Driver3_Checks_Enable  OptionBits2 [Bit 3]	On/Off On/Off	both high and low. The checks will occur regardless of the PWM output of the driver. The checks will detect both open and shorted conditions. When a fault is detected, the controller opens the driver and issues a fault code.
Driver4 Checks Enable  Driver4_Checks_Enable  OptionBits2 [Bit 4]	On/Off <i>On/Off</i>	If nothing is connected to a driver, its Checks Enable parameter should be set Off.  Note: Short circuit protection is always active at these five drivers, regardless of how Checks Enable is set.
PD Checks Enable  [PD_Checks_Enable OptionBits2 [Bit 5]	On/Off On/Off	
External Supply Max  External_Supply_Max	5–200 mA <i>52–800</i>	Sets the upper threshold of the combined current of the 5V and 12V external supplies. At or above this threshold a fault will be created that can be read by VCL.
External Supply Min External_Supply_Min	5–200 mA <i>52–800</i>	Sets the lower threshold of the combined current of the 5V and 12V external supplies. At or below this threshold a fault will be created that can be read by VCL.

		MOTOR MENU
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Typical Max Speed Typical_Max_Speed	500–8000 rpm 500–8000	Set this parameter to the typical maximum motor speed of the vehicle.  This value does not need to be set precisely; an estimate will do.  All of the vehicle response rates are normalized to Typical Max Speed.  For example, suppose Typical_Max_Speed is fixed at 6000 rpm, and Full_Accel_Rate_LS_SpdM = 3.0 seconds:
		<ul> <li>If Max_Speed_SpdM = 6000 rpm, it will take 3.0 sec to accelerate from zero to top speed (6000 rpm).</li> <li>If Max_Speed_SpdM = 3000 rpm, it will take 1.5 sec to accelerate from zero to top speed (3000 rpm).</li> <li>If Max_Speed_SpdM = 1000 rpm, it will take 0.5 sec to accelerate from zero to top speed (1000 rpm).</li> </ul>
Swap Encoder Direction  Swap_Encoder_Direction  OptionBits3 [Bit 0]	On/Off On/Off	Changes the motor encoder's effective direction of rotation. The encoder provides data used to calculate motor position and speed. This parameter must be set such that when the motor is turning forward, the controller reports back a positive motor speed.  Positive motor speed must be in the forward direction in order for the emergency reverse feature to operate properly.  Note: Do not change this parameter while the controller is powering the motor. Any time this parameter is changed a Parameter Change Fault (fault code 49) is set and must be cleared by cycling power; this protects the controller and the operator.  Adjusting this parameter can be hazardous. For instructions, see Section 5, Step @ (page 78).
Swap Two Phases  Swap_Two_Phases OptionBits3 [Bit 3]	On/Off On/Off	If, after Swap Encoder Direction has been set correctly, the vehicle drives in the wrong direction (i.e., drives forward when in reverse, and vice versa), try changing the setting of the Swap Two Phases parameter. This parameter has the same effect as physically swapping the cables on any two of the three motor phase connections.  Positive motor speed must be in the forward direction in order for the emergency reverse feature to operate properly.  Note: Do not change this parameter while the controller is powering the motor. Any time this parameter is changed a Parameter Change Fault (fault code 49) is set and must be cleared by cycling power; this protects the controller and the operator.  Adjusting this parameter can be hazardous. For instructions, see Section 5, Step @ (page 78).
Encoder Steps Encoder_Steps	32–256 <i>32–256</i>	Sets the number of encoder pulses per revolution. This must be set to match the encoder; see motor nameplate.  Note: Do not change this parameter while the controller is powering the motor. Any time this parameter is changed a Parameter Change Fault (fault code 49) is set and must be cleared by cycling power; this protects the controller and the operator.  Adjusting this parameter can be hazardous; setting it improperly may cause vehicle malfunction, including uncommanded drive. For instructions, see Section 5, Step ① (page 76).

MOTOR TEMPERATURE CONTROL MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Sensor Enable  MotorTemp_Sensor_Enable OptionBits3 [Bit 1]	On/Off On/Off	When programmed On, the motor temperature cutback and the motor temperature compensation features are enabled. This parameter can be used only if a temperature sensor has been properly configured.  The motor temperature cutback feature will linearly cutback the drive current from 100% to 0% between the Temperature Hot and Temperature Max temperatures.  The motor temperature compensation feature will adapt the motor control algorithms to varying motor temperatures, for improved efficiency and more consistant performance.
Sensor Type  MotorTemp_Sensor_Type	1–5 1–5	Five sensor types are predefined in the software:.  Type 1 KTY83–122  Type 2 2× Type 1, in series  Type 3 KTY84–130 or KTY84–150  Type 4 2× Type 3, in series  Type 5 PT1000.  Custom sensor types can be set up easily, if none of the five predefined types is appropriate for your application. Please contact your Curtis customer support engineer.  Note: The industry standard KTY temperature sensors are silicon temperature sensors with a polarity band; the polarity band of a KTY sensor must be the end connected to I/O Ground (pin 7).
Sensor Temp Offset  MotorTemp_Sensor_Offset	-20 – 20 °C -200–200	Often the sensor is placed in the motor at a location with a known offset to the critical temperature; the offset can be corrected with this parameter. The parameter can also be used to correct a known offset in the sensor itself.
Temperature Hot  MotorTemp_Hot	0–250 °C <i>0–2500</i>	Defines the temperature at which drive current cutback begins.
Temperature Max MotorTemp_Max	0–250 °C <i>0–2500</i>	Defines the temperature at which drive current is cut back to zero.
MotorTemp LOS Max Speed MotorTemp_LOS_Max_Speed	100–3000 rpm 100–3000	When a Motor Temp Sensor Fault (fault code 29) is set, a LOS (Limited Operating Strategy) mode is engaged. The maximum speed is reduced to the programmed Max Speed in the operating mode (Max_Speed_SpdMx, Max_Speed_SpdM, Max_Speed_TrqM) <i>or</i> to the MotorTemp_LOS_Max_Speed, whichever is lower.

		BATTE	RY MENU				
A PARAMETER	LLOWABLE RANGE		DESC	RIPTION			
Nominal Voltage 24	I–84 V	to batteries and of Undervoltage prot their design threst	e vehicle's ning the o system. protection ther electr ection pre nolds. shold poin	nominal batter overvoltage and cuts back rege ical system con events systems ts are calculate	undervoltage  n braking to purponents due from operating  d from the No	protection three protection three protection three protections to overvoltage at voltages to ominal Voltage	e e. pelow , Under-
		settings and the c	-	-			
				VOLTAGE RA	TINGS		
		24 24- 36- 48-	36V 48V	BROWNOUT VOLTAGE * 15V 15V 20V 20V 30V	MIN VOLTAGE 16.8V 16.8V 25.2V 33.6V 50.4V	MAX VOLTAGE 30V 45V 60V 105V 130V	
		Severe Overvolt  Undervoltage =	voltage × N age = Ove Either Mi	Nominal Voltago	e, whichever is previous item) voltage rating	s lower. + 10V. s table)	
		Severe Undervo				· ·	Range
	t '\ ( E	* The Brownout Vote changed. Where the bridge is switch voltage stays below (equivalent to cycle Brownout voltage) The Severe Under	oltage is don the capa hed off (i.e w the Browing the ke before 64	etermined by the citor voltage fact, motor current whout voltage factorial yswitch). If the msec have passet to the control of	ne controller b Ils below the E nt is switched or > 64 msec capacitor volta ssed the bridg	pase type and Brownout volta off). If the cap the controller age rises above will be reena	cannot age acitor will reset re the abled.
Undervoltage Cutback Range Undervoltage_Cutback_Range		Severe Underv A Severe	voltage po Undervolta le Severe	voltage range ints (see Nomi age fault will be Undervoltage pridge disabled,	nal Voltage de set if the cap point (drive cu	escription). eacitor voltage rrent limit set	falls
User Overvoltage User_Overvoltage	115–200 % <i>293–512</i>	The value of the The User Over threshold, which braking to prevent Typically the Used in an appear 48–80V content this case, the Covervoltage to raised above the Theorem The User Theorem The User Theorem Th	rvoltage parch is the volent dama- nis paramolication at roller bein overvoltage a higher voltage.	arameter can booltage at which ge to the electreter is changed the low end of gused in a system threshold carvalue. The over	e used to adjute the controller ical system. If only when the the controller stem with a 48 in be raised by voltage threst	ust the overvolusion will cut back the controller is it is range; such BV battery pactions the Ushold can never	tage regen being as k. In ser

BATTERY MENU, cont'd			
PARAMETER	ALLOWABL RANGE	E DESCRIPTION	
User Undervoltage User_Undervoltage	50–80 % 128–204	The value of this parameter is a percentage of the Nominal Voltage setting. The User Undervoltage parameter can be used to adjust the undervoltage threshold, which is the voltage at which the controller will cut back drive current to prevent damage to the electrical system.  Typically this parameter is changed only when the controller is being used in an application at the high end of the controller's range: such as a 24–36V controller being used in a system with a 36V battery pack. In this case, the undervoltage threshold can be lowered by setting the User Undervoltage to a lower value. The undervoltage threshold can never be lowered below the controller's power base minimum voltage rating.	

## **BDI Algorithm**

The BDI (battery discharge indicator) algorithm continuously calculates the battery state-of-charge whenever KSI is on. The result of the BDI algorithm is the variable BDI Percentage, which is viewable in the 1311 menu Monitor» Battery. When KSI is turned off, the present BDI Percentage is stored in nonvolatile memory.

The standard values for volts per cell are as follows, for flooded lead acid and sealed maintenance-free batteries.

	BALLEI	
	FLOODED	SEALED
Reset Volts Per Cell	2.09	2.09
Full Volts Per Cell	2.04	2.04
Empty Volts Per Cell	1.73	1.90

Use the standard values for your type of batteries as the starting point in setting the reset, full, and empty volts-per-cell parameters.

		BATTERY MENU, cont'd
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Reset Volts Per Cell BDI_Reset_Volts_Per_Cell	0.90–3.00 V 900–3000	The reset voltage level is checked only once, when KSI is first turned on.  Note that the BDI Reset Percent parameter also influences the algorithm that determines whether BDI Percentage is reset to 100%.  Reset Volts Per Cell should always be set higher than Full Volts Per Cell.  Reset Voltage Level = Reset Volts Per Cell × number of cells in the battery pack.*
Full Volts Per Cell  BDI_Full_Volts_Per_Cell	0.90–3.00 V 900–3000	The full voltage level sets the Keyswitch Voltage that is considered to be 100% state-of-charge; when a loaded battery drops below this voltage, it begins to lose charge. Keyswitch Voltage is viewable in the 1311 menu Monitor» Battery.  Full Voltage Level = Full Volts Per Cell × number of cells in the battery pack.*
Empty Volts Per Cell  BDI_Empty_Volts_Per_Cell	0.90–3.00 V 900–3000	The empty voltage level sets the Keyswitch_Voltage that is considered to be 0% state-of-charge.  Empty Voltage Level = Empty Volts Per Cell × number of cells in the battery pack.*
Discharge Time  BDI_Discharge_Time	0–600 min. <i>0–600</i>	Sets the minimum time for the BDI algorithm to count down the BDI Percentage from 100% to 0%. The BDI algorithm integrates the time the filtered keyswitch voltage is below the state of charge voltage level. When that cumulative time exceeds the Discharge Time / 100, the BDI Percentage is decremented by one percentage point and a new state of charge voltage level is calculated.  State of Charge Level = ((Full Voltage Level - Empty Voltage Level) × BDI Percentage / 100) + Empty Voltage Level.
BDI Reset Percent  BDI_Reset_Percent	0–100 % <i>0–100</i>	When a battery has a high BDI percentage, its float voltage at KSI On can sometimes cause false resets. The BDI Reset Percent parameter addresses this problem by allowing the user to define a BDI Percentage value above which the BDI Percentage variable will not reset.  When KSI is first powered on, the BDI Percentage variable will reset to 100% only if ((Keyswitch Voltage > Reset Voltage Level) and (BDI Percentage < BDI Reset Percent)).

<sup>\*</sup> To determine the number of cells in your battery pack, divide your Nominal Voltage setting (page 55) by 2.

DUAL DRIVE MENU
FOR DUAL DRIVE PARAMETERS, SEE THE DUAL DRIVE ADDENDUM, P/N 37022-DD.

	VEHICLE MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION	
Metric Units  Metric_Units OptionBits3 [Bit 5]	On/Off On/Off	When this parameter is programmed On, the distance variables (Vehicle Odometer, Braking Distance Captured, Distance Since Stop, Distance Fine, and the Capture Distance variables) will accumulate and display in metric units (km, meters, or decimeters). When programmed Off, the distance variables will accumulate and display in English units (miles, feet, or inches). Distance variables are displayed in the Monitor » Vehicle menu, page 71.	
Speed to RPM Speed_to_RPM	10.0–3000.0 100–30000	This parameter affects the vehicle speed displayed in the Monitor» Motor menu (see page 68), and also modifies the VCL variable <i>Vehicle_Speed</i> ; it does <u>not</u> affect actual vehicle performance. The value entered for Speed to RPM is a conversion factor that scales motor speed to vehicle speed.  KPH to RPM: (G/d)*53.05, where G = gear ratio, d = tire diameter [cm].  MPH to RPM: (G/d)*33.61, where G = gear ratio, d = tire diameter [in].	
Capture Speed 1 Capture_Speed_1	0–8000 rpm <i>0–8000</i>	The controller captures the time it takes the motor to go from 0 rpm to the programmed Capture Speed. The result is stored as "Time to Speed 1" in the Monitor» Vehicle menu (page 71). This timer starts every time the motor accelerates from zero speed.	
Capture Speed 2 Capture_Speed_2	0–8000 rpm <i>0–8000</i>	This parameter allows a second capture speed to be defined, and works identically to Capture Speed 1. The result is stored as "Time to Speed 2" in the Monitor» Vehicle menu (page 71).	
Capture Distance 1 Capture_Distance_1	1–1320 1–1320	The controller captures the time it takes the vehicle to travel from 0 rpm to the programmed Capture Distance. The result is stored as "Time to Dist 1" in the Monitor» Vehicle menu (page 71). This timer starts every time the vehicle accelerates from zero speed.  Note: For accurate distance measuring, the Speed to RPM parameter must be set correctly.  With the Metric Units parameter programmed Off, distance is in units of feet. With Metric Units programmed On, distance is in units of meters.	
Capture Distance 2 Capture_Distance_2	1–1320 1–1320	This parameter allows a second capture distance to be defined, and works identically to Capture Distance 1. The result is stored as "Time to Dist 2" in the Monitor» Vehicle menu.	
Capture Distance 3 Capture_Distance_3	1–1320 1–1320	This parameter allows a third capture distance to be defined, and works identically to Capture Distance 1. The result is stored as "Time to Dist 3" in the Monitor» Vehicle menu.	

	EMERGENCY R	REVERSE MENU [SPEED MODE & SPEED MODE EXPRESS only]
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
EMR Enable  EMR_Enable  OptionBits1 [Bit 1]	On/Off <i>On/Off</i>	Determines whether the emergency reverse function is active.  On = emergency reverse is enabled.  Off = emergency reverse is disabled.
EMR Type  EMR_Type	0–1 <i>0–</i> 1	Determines where the input comes from for emergency reverse.  0 = emergency reverse activated by switch 1 (pin 24).  1 = emergency reverse is activated by VCL functions  Enable_Emer_Rev() and Disable_Emer_Rev().
EMR Dir Interlock  EMR_Dir_Interlock  EMR_Dir_Interlock_Bit0	On/Off On/Off [Bit 0]	Determines whether the interlock switch must be turned off after emergency reverse before the vehicle can be driven again.  On = Interlock and throttle and direction must all be cleared.  Off = Only throttle and direction must be cleared.
EMR Time Limit EMR_Time_Limit	0–30 sec <i>0–3750</i>	Defines how long emergency reverse is allowed to be active after the vehicle is moving in the reverse direction. This timer will restart if the vehicle ever goes forward while emergency reverse is still active. The allowable range is 0–30 seconds, where 30 seconds is a special case of no time out.  When emergency reverse times out, the Emer Rev Timeout fault is set. Cycling the emergency reverse input will clear the Emer Rev Timeout fault.  To stop the vehicle after an EMR event (not move in reverse direction), set this parameter to 0.
EMR Speed EMR_Speed	50–6000 rpm <i>50–6000</i>	Defines the maximum reverse speed of the motor (in motor rpm), when emergency reverse is active.
EMR Accel Rate EMR_Accel_Rate	0.1–3.0 sec 100–3000	Sets the rate (in seconds) at which the vehicle accelerates in the opposite direction after it has been brought to a stop. If the vehicle is already traveling in the reverse direction below the EMR Speed, the EMR Accel Rate will bring the vehicle to the EMR Speed.
EMR Decel Rate EMR_Decel_Rate	0.1–3.0 sec 100–3000	Sets the rate (in seconds) at which the vehicle brakes to a stop when emergency reverse is activated and the vehicle is moving forward. If the vehicle is already traveling in the reverse direction above the EMR Speed, the EMR Decel Rate will bring the vehicle down to the EMR Speed.

		INTERLOCK BRAKING MENU
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Enable  Interlock_Brake_Enable OptionBits3 [Bit 7]	On/Off On/Off	Determines whether the interlock braking function is active.  On = The controller will attempt to bring the vehicle to a stop using regen braking when the interlock signal is removed.  Off = The controller will disable the bridge after Sequencing Delay expires and allow the vehicle to roll freely when the interlock signal is removed. This option is typically used only when there is a user controlled mechanical or hydraulic brake system.
Decel Rate HS Interlock_Brake_Decel_ Rate_HS	0.1–30.0 100–30000	Sets the rate (in seconds) that is used to slow down the vehicle when the interlock is released at high vehicle speeds. Larger values represent slower response.
Decel Rate LS Interlock_Brake_Decel_ Rate_LS	0.1–30.0 100–30000	Sets the rate (in seconds) that is used to slow down the vehicle when the interlock is released at low vehicle speeds. Larger values represent slower response.
Interlock Brake Timeout Interlock_Brake_Timeout	0–8.0 sec 0–1000	Controls the maximum allowable duration of an interlock braking event. The timer starts as soon as the interlock signal is removed. If the time expires before the vehicle has slowed below the Set_Speed_Threshold, the EM brake will engage automatically.  This parameter can be used to allow parallel usage of regen braking and the EM brake to reduce stopping distance. If Interlock Brake Timeout expires and the motor is still moving, regen braking will continue to retard vehicle motion in conjunction with the EM brake.  Note: This parameter is only applicable when EM_Brake_Type = 1 or 2 (see page 46).

CAN INTERFACE MENU			
PARAMETER	ALLOWABLE RANGE	DESCRIPTION	
CANopen Interlock  CANopen_Interlock_Enable OptionBits3 [Bit 2]	On/Off On/Off	When programmed On, CAN NMT State must = 5 (operational state) in order for the interlock to be set; see Monitor » CAN Status menu, page 73.	
CAN Node ID CAN_Node_ID	0–127 <i>0–127</i>	Sets the Node ID of the CANopen Slave system. The Node ID is the first 7 bits of the 11-bit identifier (the COB ID).	
Baud Rate  CAN_Baud_Rate	-3 – 2 -3 – 2	Sets the CAN baud rate for the CANopen Slave system: -3=20Kbps, -2=50Kbps, -1=100Kbps, 0=125Kbps, 1=250Kbps, 2=500Kbps.	
Heartbeat Rate CANopen_Heart_Beat_Rate	16–200 msec <i>4–50</i>	Sets the rate at which the CAN heartbeat messages are sent from the CANopen Slave system.	
PDO Timeout Period  CAN_PDO_Timeout_Period	0–200 msec <i>0–50</i>	Sets the PDO timeout period for the CANopen Slave system. After the slave controller has sent a PDO MISO, it will declare a PDO Timeout Fault if the master controller has not sent a reply PDO MOSI message within the set time. Either PDO1 MOSI or PDO2 MOSI will reset the timer. Setting the PDO Timeout Period = 0 will disable this fault check.	
Emergency Message Rate CANopen_Emergency_ Message_Rate	16–200 msec <i>4–50</i>	Sets the minimum rate between CAN emergency messages from the CANopen Slave system. This prevents quickly changing fault states from generating so many emergency messages that they flood the CAN bus.	
Suppress CANopen Init Suppress_CANopen_Init	0–1 <i>0</i> –1	When Suppress CANopen Init is set = 1, at KSI On the initialization of the CANopen system is suppressed. Typically this is done so that the VCL program can make changes to the CANopen system before enabling it (by setting the variable Suppress_CANopen_Init = 0 and running the Setup_CAN() function).	

MOTOR CHARACTERIZATION TESTS MENU			
ALLOWABLE PARAMETER RANGE DESCRIPTION			
		support engineer if you will be running the motor f. See Initial Setup, step ①, page 79.	

	FIELD WEAKENING CONTROL MENU		
PARAMETER	ALLOWABLE RANGE	DESCRIPTION	
FW Base Speed FW_Base_Speed	200–6000 rpm 200–6000	This parameter needs to be reset each time the Motor Type is changed or the low speed current limit is changed. For example, if you lower Drive_Current_Limit (page 39) or PL_Drive_Nominal (page 40), you should consider adjusting this parameter.  To determine the correct value, perform this tuning test. The test should be run with batteries that have a reasonable charge. In either Torque Control Mode or Speed Control Mode, set your accel rates to be fast—so that you'll be accelerating at full current during the test. Next, set the Base Speed parameter to the maximum value (so that it will not interfere with the test result). From a stop, apply full throttle and accelerate to high speed and then stop. After stopping, note the value displayed in Monitor » Controller » Motor Tuning » Base Speed Captured, and enter this value for the Base Speed setting.  The test restarts each time the vehicle comes to a stop and the throttle is released, so be sure to note the value before driving away.	
Field Weakening Field_Weakening	0–100 % <i>0–1024</i>	Determines the amount of high speed power the controller will allow, while still maintaining maximum effficiency at the allowed power. Reducing this parameter effectively reduces controller current at high speeds, which can reduce energy consumption and motor heating, but at the expense of reduced available torque from the motor.	
Weakening Rate Field_Weakening_Rate	0–100 % <i>0–500</i>	Determines the control loop gains for field weakening. Setting the rate too low may create surging in the vehicle as it accelerates at mid to high speeds. Setting the rate too high may create high frequency oscillations (usually audible) when the vehicle accelerates at mid to high speeds.	

		MOTOR TYPE PARAMETER
PARAMETER	ALLOWABLE RANGE	DESCRIPTION
Motor Type	0–200	This parameter references a predefined table of motor parameters for many
Motor_Type	0–200	AC motors. Consult your local Curtis customer support engineer for information on how to set this parameter based on your application and
		motor.

## **CLONING** (for copying parameter settings to multiple controllers)

Once a controller has been programmed to the desired settings, these settings can be transferred as a group to other controllers, thus creating a family of "clone" controllers with identical settings. **Cloning only works between controllers with the same model number and software version.** For example, the programmer can read all the information from a 1236-4415 controller and write it to other 1236-4415 controllers; however, it cannot write that same information to 1236-4416 controllers.

To perform cloning, plug the programmer (1311 or 1314) into the controller that has the desired settings. Scroll down to the Functions menu; "Settings" is the only function included here. Select "Get settings from controller" to copy the settings into the programmer.

Plug the programmer into the controller that you want to have these same settings, and select "Write settings to controller."

Note: For cloning Dual Drive controllers, see the separate Dual Drive addendum, p/n 37022-DD.

4a

## **MONITOR MENU**

Through its Monitor menu, the 1311 programmer provides access to real-time data during vehicle operation. This information is helpful during diagnostics and troubleshooting, and also while adjusting programmable parameters.

## 

-CAN Status...... p. 73

Monitor Menu: INPUTS		
VARIABLE	DISPLAY RANGE	DESCRIPTION
Throttle Command Throttle_Command	-100–100 % <i>-32768–32767</i>	Throttle request to slew rate block.
Mapped Throttle Mapped_Throttle	-100–100 % -32768–32767	Mapped throttle request.
Throttle Pot Throttle_Pot_Raw	0–5.5 V <i>0–36044</i>	Voltage at throttle pot wiper (pin 16).
Brake Command Brake_Command	0–100 % <i>0–32767</i>	Brake request to slew rate block.
Mapped Brake Mapped_Brake	0–100 % <i>0–32767</i>	Mapped brake request.
Pot2 Raw Pot2_Raw	0–5.5 V <i>0–36044</i>	Voltage at pot2 wiper (pin 17).
PD Throttle PD_Throttle	0–100 % <i>0–32767</i>	Proportional driver current request.
Steer Pot Steer_Pot_Raw	0–5.5 V <i>0–36044</i>	Voltage at steer pot wiper (pin 17) on Dual Drive traction slave.
Steer Angle Steer_Angle	-90 – 90 deg -90 – 90	Steer angle calculated in Dual Drive . traction master.
Interlock [Interlock_State System_Flags1 [Bit 0]	On/Off <i>On/Off</i>	Interlock input on or off. The source of the interlock input is determined by the Interlock Type parameter: from Switch 3 (pin 9) if Interlock Type = 0 from VCL function if Interlock Type = 1 from KSI (pin 1) if Interlock Type = 2.

Monitor Menu: INPUTS, cont'd		
VARIABLE	DISPLAY RANGE	DESCRIPTION
Emer Rev  EMR_State  System_Flags1 [Bit 1]	On/Off On/Off	Emergency reverse input on or off. The source of the emergency reverse input is determined by the EMR Type parameter: from Switch 1 (pin 24) if EMR Type = 0 from VCL function if EMR Type = 1.
Analog 1 Analog1_Input	0–10.0 V <i>0–1023</i>	Voltage at analog 1 (pin 24).
Analog 2 Analog2_Input	0–10.0 V <i>0–1023</i>	Voltage at analog 2 (pin 8).
Switch 1  Sw_1 Switches [Bit 0]	On/Off On/Off	Switch 1 on or off (pin 24).
Switch 2  Sw_2 Switches [Bit 1]	On/Off On/Off	Switch 2 on or off (pin 8).
Switch 3  Sw_3 Switches [Bit 2]	On/Off On/Off	Switch 3 on or off (pin 9).
Switch 4  Sw_4 Switches [Bit 3]	On/Off On/Off	Switch 4 on or off (pin 10).
Switch 5  Sw_5 Switches [Bit 4]	On/Off On/Off	Switch 5 on or off (pin 11).
Switch 6  Sw_6 Switches [Bit 5]	On/Off On/Off	Switch 6 on or off (pin 12).
Switch 7  Sw_7 Switches [Bit 6]	On/Off On/Off	Switch 7 on or off (pin 22).
Switch 8  Sw_8 Switches [Bit 7]	On/Off On/Off	Switch 8 on or off (pin 33).
Driver 1 Input Sw_9 Switches [Bit 8]	On/Off On/Off	Driver 1 input on or off (pin 6).
Driver 2 Input Sw_10 Switches [Bit 9]	On/Off On/Off	Driver 2 input on or off (pin 5).

Monitor Menu: INPUTS, cont'd		
VARIABLE	DISPLAY RANGE	DESCRIPTION
Driver 3 Input  Sw_11  Switches [Bit 10]	On/Off On/Off	Driver 3 input on or off (pin 4).
Driver 4 Input  Sw_12 Switches [Bit 11]	On/Off <i>On/Off</i>	Driver 4 input on or off (pin 3).
PD Input  Sw_13 Switches [Bit 12]	On/Off <i>On/Off</i>	Proportional driver on or off (pin 2).
DigOut6 Input  Sw_14 Switches [Bit 13]	On/Off <i>On/Off</i>	Digital Out 6 input on or off (pin 19).
DigOut7 Input  Sw_15 Switches [Bit 14]	On/Off <i>On/Off</i>	Digital Out 7 input on or off (pin 20).
Switch 16  Sw_16  Switches [Bit 15]	On/Off <i>On/Off</i>	Switch 16 on or off (pin 14).

Monitor Menu: OUTPUTS		
VARIABLE	DISPLAY RANGE	DESCRIPTION
Analog Out Analog_Output	0–10.0 V <i>0–32767</i>	Voltage at Analog output (pin 30).
Digital Out 6 Dig6_Output	On/Off On/Off	Digital Out 6 output on or off (pin 19).
Digital Out 7 Dig7_Output	On/Off On/Off	Digital Out 7 output on or off (pin 20).
Driver 1 PWM PWM1_Output	0–100 % <i>0–32767</i>	Driver 1 PWM output (pin 6).
Driver 2 PWM PWM2_Output	0–100 % <i>0–32767</i>	Driver 2 PWM output (pin 5).
Driver 3 PWM PWM3_Output	0–100 % <i>0–32767</i>	Driver 3 PWM output (pin 4).
Driver 4 PWM PWM4_Output	0–100 % <i>0–32767</i>	Driver 4 PWM output (pin 3).
PD PWM PD_Output	0–100 % <i>0–32767</i>	Proportional driver PWM output (pin 2).
PD Current PD_Current	0–2.0 A <i>0–607</i>	Current at proportional driver (pin 2).
5 Volts 5_Volts_Output	0–6.25 V <i>0–1023</i>	Voltage at +5V output (pin 26).
Ext Supply Current Ext_Supply_Current	5–200 mA <i>52–800</i>	Combined current of the external +12V and +5V voltage supplies (pins 25 and 26).
Pot Low Pot_Low_Output	0–6.25 V <i>0–1023</i>	Voltage at pot low (pin 18).

Monitor Menu: BATTERY		
VARIABLE	DISPLAY RANGE	DESCRIPTION
BDI_Percentage	0–100 % <i>0–100</i>	Battery state of charge.
Capacitor Voltage Capacitor_Voltage	0–105 V <i>0–6720</i>	Voltage of controller's internal capacitor bank at B+ terminal.
Keyswitch Voltage Keyswitch_Voltage	0–105 V <i>0–10500</i>	Voltage at KSI (pin 1).

Monitor Menu: MOTOR		
VARIABLE	DISPLAY RANGE	DESCRIPTION
Motor RPM Motor_RPM	-12000–12000 rpm -12000–12000	Motor speed in revolutions per minute.
Temperature Motor_Temperature	-100–300 °C -1000–3000	Temperature sensor readout.
MotorSpeed A MotorspeedA	0–12000 rpm <i>0–12000</i>	Motor encoder phase A speed in revolutions per minute.  This can be used to verify that phase A of the encoder is operating correctly.  MotorSpeed A should equal MotorSpeed B in a properly operating motor encoder.  MotorSpeed A does not indicate direction.
MotorSpeed B MotorspeedB	0–12000 rpm <i>0–12000</i>	Motor encoder phase A speed in revolutions per minute.  This can be used to verify that phase B of the encoder is operating correctly.  MotorSpeed B should equal MotorSpeed A in a properly operating motor encoder.  MotorSpeed B does not indicate direction.

Monitor Menu: CONTROLLER		
	SPLAY ANGE	DESCRIPTION
Current (RMS) 0-1	000 A 10000	RMS current of the controller, taking all three phases into account.
	100 % -1182	Percentage of available voltage being used.
' '	-300 Hz 00-18000	Controller electrical frequency.
'	-300 °C 00-3000	Controller internal temperature.
	)10 )10	Main contactor state:  0= open 1= precharge 2= weldcheck 3= closingdelay 4= missingcheck 5= closed (when Main Enable = On) 6= delay 7= arccheck 8= opendelay 9= fault 10= closed (when Main Enable = Off).
	n/Off On/Off	On when regen braking is taking place; Off when it is not.
Last_VCL_Error_Module 0- VCL Error 0-	65536 65536 65536 65536	A VCL Runtime Error (fault code 68) will store additional information about the cause of a VCL runtime error in the VCL Error Module and VCL Error variables. The resulting non-zero values can be compared to the runtime VCL module ID and error code definitions listed in the controller's OS SysInfo file, which should help pinpoint the VCL error that caused the runtime error.
Motor Characterization Error Motor_Characterization_Error  0-65536		A Motor Characterization Error (fault code 87) will store additional information in the Motor Characterization Error variable: 0= none 1= encoder signal seen but unable to determine step size; must set up Encoder Step Size manually 2= motor temp sensor fault 3= motor temp hot cutback fault 4= controller overtemp cutback fault 5= controller undertemp cutback fault 6= undervoltage cutback fault 7= severe overvoltage fault 8= encoder signal not seen, or one or both channels missing 9= motor parameters out of character- ization range.

Monitor Menu: CUTBACKS		
VARIABLE	DISPLAY RANGE	DESCRIPTION
Motor Temp Cutback MotorTempCutback	0–100 % <i>0–4096</i>	Displays the current available as a result of the motor temperature cutback function. A value of 100% indicates no cutback in current.
Controller Temp Cutback Controller Temp Cutback	0–100 % <i>0–4096</i>	Displays the current available as a result the controller temperature cutback function.  A value of 100% indicates no cutback in current.
Undervoltage Cutback UndervoltageCutback	0–100 % <i>0–4096</i>	Displays the current available as a result the undervoltage cutback function.  A value of 100% indicates no cutback in current.
Overvoltage Cutback OvervoltageCutback	0–100 % <i>0–4096</i>	Displays the current available as a result the overvoltage cutback function.  A value of 100% indicates no cutback in current.

Monitor Menu: MOTOR TUNING		
VARIABLE	DISPLAY RANGE	DESCRIPTION
Base Speed Captured Base_Speed_Captured	0–8000 rpm <i>0–8000</i>	Displays the value of the motor base speed captured in the most recent acceleration.  This value is used to set the Base Speed parameter (Program» Motor Control Tuning» Field Weakening Control menu), using the Base Speed set procedure described on page 62.



Note: All vehicle calculations assume no tire slippage.

	Monitor Me	nu: VEHICLE
DISPLAY VARIABLE RANGE DESCRIPTION		
Vehicle Speed Vehicle_Speed	-327.7—327.7 -32768–32767	Vehicle speed, in units of MPH or KPH, depending on the setting of the Metric Units parameter (see Program» Vehicle menu, page 58).  For accurate speed estimates, the Speed to RPM parameter must be set correctly (page 58).
Vehicle Odometer Vehicle_Odometer	0–42949672.9 <i>0–4294967295</i>	Vehicle distance traveled, in units of miles or km, depending on the setting of the Metric Units parameter (page 58).  For accurate distance measurements, the Speed to RPM parameter must be set correctly (page 58).
Vehicle Acceleration Vehicle_Acceleration	0–10 g <i>0–1000</i>	Vehicle acceleration. The Speed to RPM parameter must be set correctly for accurate measurement.
Time to Speed 1 Time_to_Capture_Speed_1	0–128 sec <i>0–32000</i>	Time taken for the vehicle to go from zero rpm to the programmed Capture Speed 1 (see Program» Vehicle menu, page 58) during its most recent such acceleration.
Time to Speed 2 Time_to_Capture_Speed_2	0–128 sec <i>0–32000</i>	Time taken for the vehicle to go from zero rpm to the programmed Capture Speed 2 (see Program» Vehicle menu) during its most recent such acceleration.
Time Between Speeds Time_Between_Capture_Speeds	0–128 sec s 0–32000	Time taken for the vehicle to go from programmed Capture Speed 1 to programmed Capture Speed 2 (see Program» Vehicle menu, page 58) during its most recent such acceleration.
Time to Dist 1 Time_to_Capture_Dist_1	0–128 sec <i>0–32000</i>	Time taken for the vehicle to travel from zero rpm to the programmed Capture Distance 1 (see Program» Vehicle menu, page 58) during its most recent such trip.  For accurate distance measurements, the Speed to RPM parameter must be set correctly (page 58).
Time to Dist 2 Time_to_Capture_Dist_2	0–128 sec <i>0–32000</i>	Time taken for the vehicle to travel from zero rpm to the programmed Capture Distance 2 (see Program» Vehicle menu) during its most recent such trip.  For accurate distance measurements, the Speed to RPM parameter must be set correctly (page 58).

Monitor Menu: VEHICLE, cont'd		
VARIABLE	DISPLAY RANGE	DESCRIPTION
Time to Dist 3  Time_to_Capture_Dist_3	0–128 sec <i>0–32000</i>	Time taken for the vehicle to travel from zero rpm to the programmed Capture Distance 3 (see Program» Vehicle menu) during its most recent such trip.  For accurate distance measurements, the Speed to RPM parameter must be set correctly (page 58).
Braking Distance Captured Braking_Distance_Captured	0–1000000.0 <i>0–400000000</i>	Distance traveled by the vehicle starting with vehicle braking (initiated by throttle reversal, brake pot, or VCL_Brake) and ending when Motor_RPM = 0. Units are meters or feet, depending on the setting of the Metric Units parameter (page 58).  For accurate distance measurements, the Speed to RPM parameter must be set correctly (page 58).
Distance Since Stop Distance_Since_Stop	0–1000000.0 Distance traveled by the vehicle starting  0–400000000 from a stop. In effect, the vehicle is used as a tape measure. (In other words, if you travel 300 feet forward and then 300 feet in reverse, the distance would be 600.) The distance is continuously updated and will stop (and restart) when Motor_RPM = 0.  For accurate distance measurements, the Speed to RPM parameter must be set correctly (page 58). Units are meters or feet depending on the setting of the Metric Units parameter (page 58).	
Distance Fine		

Monitor Menu: CAN STATUS		
VARIABLE	DISPLAY RANGE	DESCRIPTION
CAN NMT State CAN_NMT_State	0–127 <i>0–127</i>	Controller CAN NMT state: 0=initialization, 4=stopped, 5=operational, 127=pre-operational.
PDO1 MOSI Byte Map*	$0-2^{32}$	Mapping objects for PDO1 MOSI's eight bytes.
PDO1 MISO Byte Map*	0 - 232	Mapping objects for PDO1 MISO's eight bytes.
PDO2 MOSI Byte Map*	0 - 232	Mapping objects for PDO2 MOSI's eight bytes.
PDO2 MISO Byte Map*	$0-2^{32}$	Mapping objects for PDO2 MISO's eight bytes.

<sup>\*</sup> Each of these byte maps is a submenu containing 8 variables, one for each byte. Each variable is 32 bits. For example, the PDO1 MOSI Byte Map menu looks like this:

# **PDO1 MOSI Byte Map**

1	$0 - 2^{32}$	Mapping object for byte 1 of PDO1 MOSI.
2	$0 - 2^{32}$	Mapping object for byte 2 of PDO1 MOSI.
3	$0 - 2^{32}$	Mapping object for byte 3 of PDO1 MOSI.
4	$0 - 2^{32}$	Mapping object for byte 4 of PDO1 MOSI.
5	$0 - 2^{32}$	Mapping object for byte 5 of PDO1 MOSI.
6	$0 - 2^{32}$	Mapping object for byte 6 of PDO1 MOSI.
7	$0 - 2^{32}$	Mapping object for byte 7 of PDO1 MOSI.
8	$0 - 2^{32}$	Mapping object for byte 8 of PDO1 MOSI.



# **CONTROLLER INFORMATION MENU**

This menu provides ID and version numbers for your controller hardware and software.

CONTROLLER INFORMATION MENU		
VARIABLE	DISPLAY RANGE	DESCRIPTION
Model Number Model_Number	0–4294967295 0–4294967295	Model number. For example, if you have a 1236 controller with the model number 1236-4501, the Model Number variable will have a value of 12364501.
Serial Number Serial Number	0–4294967295 0–4294967295	Serial number. For example, if the serial number printed on your controller is 08045L.11493, the Serial Number variable will have the value of 11493.
Mfg Date Code Manuf_Date	0–32767 <i>0–32767</i>	Controller date of manufacture, with the first two digits indicating the year and the last three indicating the day. For example, if the serial number printed on your controller is 08045L.11493, the Mfg Date Code variable will have the value of 08045 (45th day of 2008).
Hardware Version Hardware_Ver	0–32.767 <i>0–32767</i>	The hardware version number uniquely describes the combination of power base assembly and the logic, cap, and IMS board assemblies used in the controller.
OS Version OS_Ver	0–32767 <i>0–32767</i>	Version number of the operating system software that is loaded into the controller. This variable specifies the <u>major</u> version number of the controller's operating system.
Build Number Build_Number	0–32767 <i>0–32767</i>	Build number of the operating system software that is loaded into the controller. This variable specifies the minor version number of the controller's operating system.
SM Version SM_Ver	0–327.67 <i>0–32767</i>	Version number of the Start Manager software that is loaded into the controller.
Param Blk Version Param_Blk_Ver	0–327.67 <i>0–32767</i>	Version number of the parameter block that is loaded into the controller.
VCL App Version VCL_App_Ver	0–327.67 <i>0–32767</i>	Version number of the VCL application software that is loaded into the controller. This value is set in the VCL program by assigning a value to the VCL_App_Ver variable.

# 5

# **INITIAL SETUP**

The 1234/36/38 controllers can be used in a variety of vehicles, which differ widely in characteristics. Before driving the vehicle, it is imperative that these initial setup procedures be carefully followed to ensure that the controller is set up to be compatible with your application. The first step is to contact Curtis:

# \* \* \* BEFORE YOU START \* \* \*

Correct values for the AC motor parameters (Motor Type, FW Base Speed, and Field Weakening) must be determined individually for each AC motor. You can determine these values in any one of the following ways:

- → Contact Curtis with the manufacturer's part number for your motor. We have a database of many AC motors for which we have already determined the correct motor parameter settings.
- → Use the AC Motor Characterization Procedure, which has the controller "learn" the AC motor parameter data. The procedure should take about 30 minutes to complete and can be done on the vehicle. Contact Curtis for the procedure. Go ahead and complete setup steps ① through ⑩ before conducting the characterization procedure.
- ⇒ Send your AC motor to Curtis for testing on the motor dyno. Your motor's data will be entered into the Curtis database and we will send you the appropriate parameter values to enter into your controller. Contact Curtis before shipping your motor.

Once you have obtained the correct values for Motor Type, FW Base Speed, and Field Weakening and have set them on your controller (see Motor Control menus, page 62), you can start conducting the setup procedures. Note: If you will be conducting the AC Motor Characterization Procedure, that will come later.



Before starting the setup procedures, **jack the vehicle drive wheels up off the ground** so that they spin freely. Double-check all wiring to ensure it is consistent with the wiring guidelines presented in Section 2. Make sure all connections are tight. Turn on the controller and plug in the 1311 programmer.

# ① Motor encoder (see page 53)

Set the Encoder Steps parameter to the correct setting for your motor's position encoder. This information is typically available from the motor manufacturer. If



the AC Motor Characterization Procedure is used, it can determine the encoder steps (but only for encoders with 32, 64, or 80 ppm).

Setting the Encoder Steps parameter improperly may cause vehicle malfunction, including uncommanded drive.

# ② Motor temperature sensor (see page 54)

Set the Sensor Type parameter to the predefined type (1–5) that corresponds to your motor temperature sensor. Typically, the motor temperature sensor will be a thermistor that should be connected from Analog 2 (pin 8) to ground (pin 7) as shown on page 12.

To check whether the parameter settings and the motor thermistor connections yield the correct motor temperature, read the Temperature value displayed in the 1311's Monitor» Motor menu (page 68). This is typically done when the motor has not been run for many hours, to ensure the motor is at a known (room) temperature. If the 1311 does not display the correct motor temperature, contact your Curtis customer support engineer for help. If the correct motor temperature is not displayed, or if there is no motor temperature sensor, this setup procedure can continue only if the Sensor Enable is set to Off.

If the 1311 displays the correct motor temperature, continue with the procedure and set up the Sensor Enable, Temperature Hot, and Temperature Max parameters.

# 3 Current limits (see page 39)

The Drive, Regen, Brake, EMR, and Interlock Current Limit parameters are a percentage of the controller's full rated current. The controller's full rated current is printed on the label of the controller. Set the five current limit parameters to your desired values.

# Battery (see page 55)

Set the Nominal Voltage parameter to match the nominal battery pack voltage of your system.

# (5) Main contactor (see page 48)

Set up the parameters in the Main Contactor Menu.

# 6 EM brake (see pages 46-47)

Set up the parameters in the EM Brake Menu.

# Throttle (see pages 13–17 and 43–44)

Before the throttle can be set up the interlock must be verified as Off, by reading the Interlock value displayed in the Monitor» Inputs menu (page 64). If the 1311 indicates the interlock is On, review how you set the Interlock Type parameter (Main Contactor Menu) and turn the interlock off. Verify that the 1311 displays that the interlock is now Off. Contact your Curtis customer

support engineer to resolve any issues about the interlock before continuing with the setup procedure.

Once you have verified the interlock is off, you can set up the throttle input. The Throttle Type parameter must be set to match the type of throttle (1–5) and wiring that you are using, as described on pages 13–17. Adjust the Forward Deadband, Forward Max, Reverse Deadband and Reverse Max parameters to match the range of your throttle. The Throttle Pot value displayed on the Monitor» Inputs menu (page 64) is useful when setting up these parameters. For the forward and reverse directions, read the displayed throttle pot voltage at the point when the throttle moves out of neutral and at the point just before full throttle and enter these values for the deadband and max settings for that direction. Set up the other parameters in the Throttle Menu as required by the application.

You will be able to verify that your throttle settings are correct by checking the Mapped Throttle value displayed in the Monitor» Inputs menu (page 64) over the entire range of throttle pot movement. The value displayed for Mapped Throttle should be = 0% through the range of throttle motion that is considered neutral. The displayed Mapped Throttle should be = 100% through the range of motion that is considered forward throttle max and should be = -100% through the range considered reverse throttle max. Contact your Curtis customer support engineer to resolve any issues about the throttle setup before continuing with the setup procedure.

# 8 Brake (see page 45)

If the brake function is not used by your application, set the Brake Enable parameter = Off and Brake Type = 5.

Before the brake can be set up the interlock must be verified as Off, by reading the Interlock value displayed in the Monitor» Inputs menu (page 64). If the 1311 indicates the interlock is On, review how you set the Interlock Type parameter (Main Contactor Menu) and turn the interlock off. Verify that the 1311 Monitor Menu displays that the interlock is now Off. Contact your Curtis customer support engineer to resolve any issues about the interlock before continuing with the setup procedure.

Once you have verified that the interlock is off, you can set up the brake input. The Brake Type parameter must be set to match the type of brake throttle (1, 2, 3, 5) and wiring that you are using, as described on pages 13–17. Adjust the Brake Deadband and Brake Max parameters to match the range of your brake pot. The Brake Pot value displayed in the Monitor» Inputs menu (page 64) is useful when setting up these parameters. Read the displayed brake pot voltage at the point when the brake moves out of neutral and at the point just before full brake and enter in these values for the deadband and max settings. Set up the other parameters in the Brake Menu as required by the application.

You will be able to verify that your brake settings are correct by checking the Mapped Brake value displayed in the Monitor» Inputs menu (page 64) over the entire range of brake pot movement. The value displayed for Mapped Brake should be = 0% through the range of brake pot motion that is considered

neutral. The displayed Mapped Brake should be = 100% through the range of motion that is considered max. Contact your Curtis customer support engineer to resolve any issues about the brake setup before continuing with the setup procedure.

# 9 Faults (see Section 8)

Turn the KSI input Off and then On (to clear any parameter change faults) and use the 1311 to check for faults in the controller. All faults must be cleared before continuing with the setup procedure. Use Section 8 for help in trouble-shooting. Contact your Curtis customer support engineer to resolve any issues about the faults before continuing with the setup procedure.

# ① Setting encoder direction and direction of rotation (see page 53)

With the vehicle drive wheels still jacked up, no faults present in the controller, the interlock Off (as verified in the Monitor» Inputs menu, page 64), and both the throttle and brake in neutral (Mapped Throttle = 0% and Mapped Brake = 0% in the Monitor» Inputs menu), the encoder direction can be checked. Use the Monitor» Motor menu (page 68) to view the Motor RPM display. Turn the motor by hand and observe the sign of Motor RPM. Positive is forward and negative is reverse. If you get a positive Motor RPM when you rotate the motor in the forward direction, and a negative Motor RPM when you rotate the motor in the reverse direction, the Swap Encoder Direction parameter is correct and should not be changed. If you are getting negative Motor RPM when rotating the motor forward, the Swap Encoder Direction parameter must be changed. Cycle KSI power and repeat the procedure until you are satisfied that the Swap Encoder Direction setting is correctly set. If the vehicle will use the emergency reverse feature, the reverse direction (negative Motor RPM) must be correctly selected so that when the Emergency reverse input is active the motor will rotate in the reverse direction. Contact your Curtis customer support engineer to resolve any issues about encoder direction or emergency reverse before continuing with the setup procedure.

Now that you have the encoder direction set correctly, you can test to see which direction the motor will spin due to how the three phase cables  $(\mathbf{U}, \mathbf{V},$  and  $\mathbf{W})$  are connected to the motor.

Cycle KSI input Off and then On (to clear any parameter change faults) and use the 1311 to check for faults in the controller. All faults must be cleared before continuing with the setup procedure.

Apply the interlock input and verify that the interlock = On (as verified in the Monitor» Inputs menu).

Then, while keeping the brake in neutral, select a direction and apply throttle. The motor should begin to turn, but it may turn in the wrong direction. Observe the direction of rotation of the motor and if it is turning in the wrong direction return the throttle to neutral, and change the setting of the Swap Two Phases parameter. Cycle power, turn on interlock, and turn on direction. Apply throttle and verify that the direction of rotation of the motor matches

the direction input. If the motor is turning in the correct direction but appears to be "fighting itself" (struggling at full current while jerkily turning at very low speed), change the setting of the Swap Encoder Direction parameter. If the motor still does not respond properly you should contact your Curtis customer support engineer to resolve any issues about encoder direction or emergency reverse before continuing with the setup procedure.



# Do not take the vehicle down off the blocks until the motor is responding properly.

Once the motor is responding properly, lower the vehicle to put the drive wheels on the ground.

# 1 Motor characterization (refer to procedure sent by Curtis)

If you will be conducting the AC Motor Characterization Procedure, do it now. This procedure will determine the values you should set for the Motor Type, FW Base Speed, and Field Weakening parameters (see Motor Control menus, page 62). Note: If you obtained these values and set them before starting the Initial Setup, skip this step.

# 12 Emergency reverse (see page 59)

Set up the parameters in the Emergency Reverse Menu. Note: Emergency Reverse is active only if you are using Speed Mode Express or Speed Mode as your motor tuning mode.

# 13 Interlock braking (see page 60)

Set up the parameters in the Interlock Braking Menu.



# **TUNING GUIDE**

Many aspects of vehicle performance can be optimized, using the wide variety of adjustable parameters available to the 1234/36/38 controllers. Once a vehicle/motor/controller combination has been tuned, the parameter values can be made standard for the system or vehicle model. Any changes in the motor, the vehicle drive system, or the controller will require that the system be tuned again to provide optimum performance.

# Selecting the control mode (see page 27)

Before starting to tune your vehicle's performance, you must select which control mode you use. Set the Control Mode Select parameter = 0 (Speed Mode Express for either traction or pump motors), = 1 (Speed Mode, for either traction or pump motors) or = 2 (Torque Mode, for traction motors). Cycle KSI input Off and then On (to clear any parameter change faults) and use the 1311 to check for faults in the controller. Then proceed to the tuning steps for the control mode you have selected.

Conduct the steps in the sequence given, because successive steps build upon the ones before. It is important that the effect of these programmable parameters be understood in order to take full advantage of the 1234/36/38's powerful features. Please refer to the descriptions of the applicable parameters in Section 3 if there is any question about what any of them do.

# 0 - SPEED MODE EXPRESS tuning (see page 28)

Speed Mode Express is the same as Speed Mode with the exception that it has fewer parameters and is therefore simpler to use. Most vehicle applications will find success with Speed Mode Express; however, for some applications vehicle performance cannot be satisfactorily fine-tuned in Speed Mode Express. In this case, change your control mode to Speed Mode (i.e., set Control Mode Select =1).

- a. For traction applications, set Pump Enable to Off. For AC pump applications, set this parameter On.
- b. Adjust Max Speed to the maximum speed the motor should turn in the vehicle application; this speed setting corresponds to an input of full throttle.
- c. Adjust Typical Max Speed (page 53) to the approximate maximum speed that the motor will spin. This is usually the same value as the setting for Max Speed, but some applications have a Max\_Speed\_SpdMx that changes (in the VCL software). If the Max\_Speed\_SpdMx changes, set Typical Max Speed to the highest speed the motor is expected to reach. This value does not need to be set precisely since it will not change motor performance. Typical Max Speed sets a reference point for the "rate" parameters (accel, decel, brake rates), so that applications that have a changing Max\_Speed\_SpdMx will not experience changes in the rates (because the rates are referenced to the unchanging Typical Max Speed value). Once you set the Typical Max

- Speed parameter you should not readjust it without adjusting all the rate parameters as well.
- d. Kp and Ki typically do not need to be changed as the default values will work well in most applications. If you want to adjust Kp (for looser or tighter following of the speed trajectory set by the accel, decel, and brake rates), follow the procedure in step "d" in the Speed Mode tuning section.
- e. Adjust the Accel Rate and Decel Rate as necessary while moving the throttle to different positions (i.e., neutral to full throttle, half throttle to full throttle, full throttle to half throttle, full throttle to neutral, neutral to low throttle, etc.). For AC pump applications, typically the Accel Rate and Decel Rate are set very fast for quick response to hydraulic inputs.
- f. Adjust the Brake Rate as necessary while reversing the throttle input (i.e., full throttle forward to low throttle reverse, full throttle forward to full throttle reverse, full throttle reverse to low throttle forward, etc.). If a brake input is present in the application (Brake Pedal Enable = On) continue adjusting Brake Rate by applying different amounts of brake throttle (i.e., full throttle forward, then apply full brake or full throttle forward, then apply low brake, etc.). For AC pump applications the Brake Rate has no effect on performance since the AC pump will not run in reverse nor with a brake input.



AC pump motor applications, which in step "a" had the Pump Enable parameter set to On, may also be controlling hydraulic valves (load hold valve, proportional valve). The Proportional Driver parameters (page 50) and some VCL will typically be used to set up the control of these valve driver outputs. Consult with your Curtis customer support engineer regarding hydraulic valve control.

# 1 - SPEED MODE tuning (see pages 29–34 and 39)

- a. For traction applications, set Pump Enable to Off. For AC pump applications set this parameter On.
- b. Adjust Max Speed to the maximum speed the motor should turn in the vehicle application; this speed setting corresponds to an input of full throttle.
- c. Adjust the Typical Max Speed (page 53) to the approximate maximum speed that the motor will spin. This is usually the same value as the setting for Max Speed, but some applications have a Max\_Speed\_SpdM that changes (in the VCL software). If the Max\_Speed\_SpdM changes, set the Typical Max Speed to the highest speed the motor is expected to reach. This value does not need to be set precisely since it will not change motor performance. Typical Max Speed sets a reference point for the "rate" parameters (accel, decel, brake rates), so that applications that have a changing Max\_Speed\_SpdM will not experience changes in the rates (because the rates are referenced to the unchanging Typical Max Speed value). Once you set the Typical Max Speed parameter you should not readjust it without adjusting all the rate parameters as well.

d. Kp typically does not need to be changed as the default value will work well in most applications. This parameter controls how tightly the actual motor speed will track the requested speed trajectory (speed trajectory is set by the accel, decel, and brake rates).

If you want to adjust the Kp (for looser or tighter following of the speed trajectory), follow these guidelines.

- Set the following parameters. Before setting them, make a note
  of their present (default) settings so you can return them to
  these original values at the end of this procedure.
  - \* If your vehicle has an EM Brake, set the Brake Type (page 46) to 1. This setting will release the EM Brake as soon as interlock is asserted.
  - \* In the Speed Mode» Response menu, set all the accel and decel rates to their fastest values (0.1 seconds); this allows better observation of the system response.
  - \* In the Speed Mode» Speed Controller menu, set the Max Speed to low value (≈1000 rpm), as high speed operation is not needed to observe system response.
  - \* Set Soft Stop Speed parameter to 0 rpm to disable the soft stop speed function (see Restraint menu, page 38).
- Cycle KSI to clear any faults.
- Using very quick, pulsing throttle movements, increase the throttle and then release it to 0%. The intent is to give the speed controller torque impulses.
- Increase Kp and repeat the throttle tests. Increase Kp until you start to notice marginal stability (normally motor bouncing, or continuous oscillation in the gears, is heard). Note: It is possible that very heavy vehicles will not experience marginal stability even at the highest setting of Kp.
- Once the Kp setting for marginal stability is found, reduce the Kp value in the 1311 by about one third (i.e., final Kp = marginal stability Kp \* 2/3).
- If you will be using Speed Mode Express, enter this Kp value for the Kp parameter in the Speed Mode Express menu.
- Set the Brake Type, Accel/Decel Rates, Max Speed, and Soft Stop Speed back to their original values.
- e. In the Speed Mode» Response menu, adjust the five Accel and Decel Rate parameters as necessary while moving the throttle to different positions (i.e., neutral to full throttle, half throttle to full throttle, full throttle to half throttle, full throttle to neutral, neutral to low throttle, etc.). For AC pump applications, these parameters are typically set very fast for quick response to hydraulic inputs.

f. In the Speed Mode» Response menu, adjust the remaining three brake rate parameters as necessary while reversing the throttle input (i.e., full throttle forward to low throttle reverse, full throttle forward to full throttle reverse, full throttle reverse to low throttle forward, etc.).

If a brake input is present in the application (Brake Pedal Enable = On) continue adjusting these three brake rates by applying different amounts of brake throttle (i.e., full throttle forward, then apply full brake or full throttle forward, then apply low brake, etc.). For AC pump applications these parameters have no effect on performance since the AC pump will not run in reverse nor with a brake input.

g. The parameters in the Speed Mode » Response » Fine Tuning menu typically do not need to be changed as the default values work well in most applications.



AC pump motor applications, which in step "a" had the Pump Enable parameter set to On, may also be controlling hydraulic valves (load hold valve, proportional valve). The Proportional Driver parameters (page 50) and some VCL will typically be used to set up the control of these valve driver outputs. Consult with your Curtis customer support engineer regarding hydraulic valve control.

# 2 - TORQUE MODE tuning (see pages 34–37)

- a. Set Max Speed to the maximum speed you want to limit the motor to.
- b. Kp, Ki, and Kd typically do not need to be changed as the default values will work well in most applications. These parameters control how tightly the controller limits the speed of the motor to the programmed Max Speed.
- c. Set Typical Max Speed (page 53) to the expected maximum speed of the motor.
- d. Adjust the parameters shown in Figure 8 (page 37) to set up the throttle mapping:
  - Regen Current Limit (Current Limits menu, page 39)
  - Drive Current Limit (Current Limits menu, page 39)
  - Restraint Forward, Restraint Back (Restraint menu, page 38)
  - Neutral Braking (Torque Mode » Response menu, page 35)
  - Neutral Taper Speed (Torque Mode » Response menu, page 35)
  - Creep Torque (Torque Mode » Response » Fine Tuning menu, page 36).
- e. In the Torque Mode» Response menu, adjust the four accel, decel, and release rate parameters as necessary while moving the throttle to different positions (i.e., neutral to full throttle, half throttle to full throttle, full throttle to half throttle, full throttle to neutral, neutral to low throttle, etc.).
- f. The other parameters in the Torque Mode» Response» Fine Tuning menu typically may need to be changed for some applications. Read the parameter descriptions and adjust as necessary.

7

# **VEHICLE CONTROL LANGUAGE (VCL)**

Curtis 1234/36/38 AC induction controllers have a built-in programmable logic controller with application-specific functions. VCL (Vehicle Control Language) software provides a way to implement unique and complex vehicle control functions.

VCL is a simple programming language that will feel very familiar to anyone who has worked with BASIC, Pascal, or C. Working with VCL requires the installation of the WinVCL program onto a PC. WinVCL will compile VCL programs and flash download the software into the controller through the computer's serial port. The install process for WinVCL will also install two important manuals on your PC—the VCL Programmer's Guide and the VCL Common Functions Manual. These two manuals, which are in PDF format, include more detailed information about VCL than is included here.

This section of the manual summarizes VCL and also describes aspects and functions of VCL that are specific to 1234/36/38 controllers. For a more complete understanding of the functions and capabilities of VCL, see the the WinVCL User's Guide, VCL Programmer's Guide, and VCL Common Functions Manual.

# **Summary of VCL Basics**

• VCL is not case-sensitive:

put\_pwm(), Put\_PWM(), and PUT\_PWM() are identical.

 Spaces in variable names are not allowed in VCL; use underscores in place of spaces.

Example: Forward\_Offset is the VCL name for the 1311 parameter Forward Offset.

• Functions are followed by parentheses; for example:

Reset\_Controller() is a function Reset\_Voltage is a variable.

• Logical statements must be inside parentheses; examples:

IF (setpoint >50)

ELSE IF ((setpoint <20) & (temperature >100)).

· Comments are preceded by semicolons.

The VCL functions described in the VCL Common Functions Manual are available on 1234/36/38 controllers. These controllers also have these additional functions:

ENABLE_PRECHARGE()p. 103
DISABLE_PRECHARGE()p. 104
SET_DIGOUT()p. 105
CLEAR_DIGOUT()p. 105
ENABLE_EMER_REV()p. 106
DISABLE_EMER_REV()p. 106
SET_INTERLOCK()p. 107
CLEAR_INTERLOCK()p. 107
SETUP_POT_FAULTS()p. 108
START_PUMP()p. 109
STOP_PUMP()p. 109

These functions, which are not included in the VCL Common Functions Manual, are described at the end of Section 7.

### **VARIABLE TYPES**

VCL provides dedicated space in which to store custom variables. There are four types of variables, based on their type of storage: volatile storage (RAM) and three types of non-volatile storage (EEPROM) are available.

<u>RAM variables</u> are stored only while power is on; they are lost at power-down. They must be initialized on power-up by explicit VCL assignments (i.e., User1 = 12).

<u>NVUser1–15 EEPROM variables</u> are 15 variables stored at power-down and recalled by the operating system when the NVM\_NVUser\_Restore function is used. Thus, they can then be recalled at the next power-on cycle, which restores their previous values. See the section on non-volatile memory access in the VCL Common Functions manual for more information.

Block EEPROM are 38 blocks of 15 variables (total of 570 variables), which are stored and recalled using the functions NVM\_Block\_Read and NVM\_Block\_Write. The 38 blocks are called NVM3–NVM40. The read and write functions must point to the RAM variables that the EEPROM blocks should be written from or read to. For example, NVM\_Block\_Read(NVM10,0,15,User20) will read the 15 variables stored in EEPROM block NVM10 and restore those variables to the 15 variables starting with RAM variable User20 (so the 15 EEPROM variables would be restored to User20–34). See the section on non-volatile memory access in the VCL Common Functions manual for more information.

<u>Parameters EEPROM variables</u> are a special type of EEPROM variable that is intended to be used to create OEM defined 1311 parameters. These 1311 parameters can be defined as 16-bit by using the P\_User variables or they can be defined as bit (On/Off) by using the P\_UserBit variables. These variables

are typically written to EEPROM through the 1311 programmer interface (i.e., when a 1311 user changes a parameter setting using the 1311). They can be used in the VCL code, but changing a P\_User (or P\_UserBit) value with VCL will only change the variable value in RAM and will **not** change the value in EEPROM. Thus, these variables are intended for creating and defining 1311 parameters only.

TYPE	QUANTITY	RANGE
RAM	120 variables	User1 - User120
NVUser EEPROM	15 variables	NVUser1 - NVUser15
Block EEPROM	38 blocks (15 variables each)	NVM3 – NVM40
Parameters EEPROM	100 variables and 20 variables of 8 bits each (160 bits)	P_User1 - P_User100 P_UserBit1 - P_UserBit20

VCL can modify the 1311 control mode parameters in RAM by using the VCL variable name for the 1311 parameter. For example,

```
Brake_Rate_SpdM = 3000 ;Change Brake Rate to 3.0sec
```

will change the RAM value of the speed control mode's Brake Rate; the new value will be used in determining the Controller Torque Command. However, the value of the stored EE value of this parameter remains unchanged; when the controller is turned off, the RAM value will be lost. The next time the controller is powered back on, the "old" value of Brake Rate will be restored from EE memory. VCL cannot write to the EE memory. The 1311 parameter settings in EE memory can be changed by using the 1311 to change the values in the program menus.

# **VCL RUNTIME RATES**

VCL is an interpreted language. Each line of VCL code is converted (compiled) into a set of codes and then flash loaded into the controller. The controller interprets these codes one line at a time while the system is powered up. Here are the processing rates of the various functions:

FUNCTION	FUNCTION FULL NAME	INSTANCES	SERVICE RATE
ABS	Absolute Value	2	4 ms
ADC	Analog to Digital Converter Input	2	1 ms
CAN	CAN Communications	15	4 ms
CPY	Сору	8	4 ms
DLY	Delay	32	1 ms
FLT	Filter	4	1 ms
LIM	Limit	4	4 ms
MAP	Мар	4	4 ms
MTD	Multiply then Divide	4	4 ms
NVM	Non-Volatile Memory	38	2 ms
PID	Proportional Integral Derivative	2	4 ms
POT	Potentiometer Input	2	8 ms
PWM	Pulse Width Modulated Output	6	4 ms
RMP	Ramp	4	1 ms
SCL	Scaling	4	4 ms
SEL	Selector, 2-position switch	8	4 ms
SEL_4P	Selector, 4-position switch	8	32 ms
SW	Switch Input	1*	4 ms
TMR	Timers (hourmeters)	3	1 ms

<sup>\*</sup> There is only one Switch variable; it has 16 associated bit-variables.

# I/O CONTROL WITH VCL

# **Digital Inputs**

The 1234 controller has at total of 16 digital inputs, and the 1236/38 has 15. Eight are switch inputs (Sw\_1 through Sw\_8) on all the models; the 1234 has a ninth switch input, Sw\_16. These switch inputs are shown on the standard wiring diagram (Figure 3, page 12). The remaining seven digital inputs are less obvious: one on each driver and digital output (Sw\_9 through Sw\_15). These can be used as digital inputs or to sense the state of the output or its wiring (e.g., open coil check).

To address a digital input in a VCL program, use the desired input label (Sw\_1 through Sw\_16). You must use On or Off in the code when determining a switch state; using true/false or 1/0 will give erroneous results.

```
if (Sw_1 = ON)
    {
        ;put code here to run when switch 1 is On
      }
if (Sw_16 = OFF)
     {
        ;put code here to run when switch 16 is Off
      }
```

All switch inputs are automatically debounced by the VCL operating system. This prevents noisy contacts or contact bounce from causing erroneous events in your VCL code. The debounce time can be varied from 0 to 32 milliseconds in 4ms steps, using this function:

```
Setup_Switches(5); 20 milliseconds
```

If this line is not in the VCL code, the debounce time is set at 16 ms.

# **Driver and Digital Outputs**

There are five driver outputs (PWM1 through PWM5) and two digital outputs (DigOut6 and DigOut7). These outputs have variations in current and frequency range. For their specifications, see "high power outputs" and "low power outputs" on page 19.

<u>Driver outputs</u> have high current FET output stages and can be pulse width modulated (PWM) to vary the average output to inductive loads such as contactors and relays. This is useful when the battery voltage needs to be brought down for lower voltage coils. The two <u>digital outputs on the 1236/38</u> are low current NPN transistor drivers that are only On or Off. They work well for driving LEDs or for interfacing to another digital device. The two <u>digital outputs on the 1234</u> are 1-amp drivers that are only On or Off.

Drivers use a special VCL function to set their PWM level. This PWM level can be set up in a signal chain to update automatically or can be set directly in the main loop. PWM can be set from 0–100% using the digital range of 0 to 32767.

```
Put_PWM(PWM2,16384)
```

will output a 50% waveform on Driver 2.

```
Automate_PWM(PWM2,@user1)
```

will continually update the Driver 2 output with the present value of variable User1. This automate statement needs only to be run once, usually in the initialization section of the VCL program. VCL can monitor the present value of a PWM driver: the variable PWMx\_Output (where "x" is the PWM channel number) is automatically filled with the present value of the driver output.

The proportional driver (Driver 5) is different from Drivers 1–4. It can be controlled in two ways: with the proportional driver processing function (see Figure 16, page 97) or with the VCL Put\_PWM() function. The VCL statement Put\_PWM(PWM5, 16383) will result in a 50% PWM output on pin 2 only if the parameter PD Enable is set to Off. See page 95 for more information on interfacing the proportional driver.

Control of the two digital outputs (Digital Outputs 6 and 7) is done using the VCL functions Set\_Digout() and Clear\_Digout().

Set\_DigOut(DigOut6)

will set Digital Output 6 On (active). VCL can monitor the present value of a digital output driver: the bit variable Digx\_Output (where "x" is the digital output channel number) is automatically filled with the present value of the driver output (On or Off).

It is important to note that all outputs are active Low. With 100% PWM or an output of "On," the FET or transistor will be pulling hard to ground. A DVM on the output will measure near 0 volts.

### **Potentiometer Inputs**

These controllers have two potentiometer inputs, which are typically used for throttle and brake. Many features (mapping, acceleration rates, etc.) are built in as 1311 parameters. Still, there are times that these potentiometer inputs may be needed for other functions such as steering angle or height sensing, or simply as data inputs. The standard way to input pot information is to set the 1311 parameter Throttle Type (or Brake Type) to an appropriate value of 1–4 as shown on pages 13–16. When set to a value of 1–4, the resulting signal chain can operate without the use of any VCL.

However, if an OEM wishes to control the throttle (or brake) signal chain in VCL or use the throttle (or brake) inputs for signals that are not throttle (or brake) signals, then the 1311 parameter Throttle Type (or Brake Type) should be set to a value of 5 (page 17). Setting the 1311 parameter Throttle Type (or Brake Type) to a value of 5 changes the routing of the appropriate signal chain (either throttle or brake) and allows the VCL programmer access to the Throttle Pot (or Brake Pot) output variables; see Figure 14 (page 92).

When the Throttle Type setting = 5, the Throttle\_Pot\_Output is a VCL variable that the OS will update with the current value of the throttle pot input. Similarly, when the Brake Type setting = 5, the Brake\_Pot\_Output is a VCL variable that the OS will update with the current value of the brake pot input. However, the value of the Throttle\_Pot\_Output (or Brake\_Pot\_Output) will remain clamped to zero until the VCL function Setup\_Pot() is executed.

Typically the Setup\_Pot() function is executed at the beginning of a VCL program to define the potentiometer input connection as THREE\_WIRE (uses Pot High and Pot Low connections), TWO\_WIRE (variable resistor, or rheostat, uses Pot Low but no connection to Pot High), or ONE\_WIRE (a voltage input, no connection to either Pot High or Pot Low). THREE\_WIRE potentiometer connections are the same as the 3-wire potentiometer connections shown on page 15 for a Throttle Type 2. TWO\_WIRE potentiometer connections are the same as the 2-wire potentiometer connections shown on page 14 for a Throttle Type 1. ONE\_WIRE potentiometer connections are the same as the Voltage Source or Current Source connections shown on page 15 for a Throttle Type 2.

Note that the Setup\_Pot() function will only work (and is only needed) if the corresponding Type is set to 5 (Throttle Type = 5 or Brake Type = 5).

Setup Pot (THROTTLE POT, THREE WIRE)

will set up the throttle pot input for wiring using all three connections (pins 15, 16, 18).

To set up the brake pot input for use in VCL, use the Brake\_Pot constant in place of the Thottle\_Pot constant in the Setup\_Pot function.

```
Setup_Pot(BRAKE_POT,TWO_WIRE)
```

will set up the brake pot input for wiring using two connections (pins 17, 18).

The 0–100% position of the potentiometer is represented by a value from 0–32767 in VCL. Once set up (through the VCL Setup\_Pot() function) the potentiometer value is automatically and continuously loaded into the variable Throttle\_Pot\_Output or Brake\_Pot\_Output. It is important to use the correct setup (ONE\_WIRE, TWO\_WIRE, or THREE\_WIRE) since the input is automatically re-scaled for 0–100% based on the wiring used; for example, the voltage at the Pot Low pin is automatically subtracted and re-scaled on a THREE\_WIRE pot.

Another effect of setting the Throttle Type = 5 is that the signal chain for the throttle now gets its input from a different source. The input to the throttle chain is now a VCL variable called VCL\_Throttle instead of the throttle pot. Similarly, Brake Type = 5 means the brake signal chain will get its input from a VCL variable called VCL\_Brake rather than from the brake pot. The VCL\_Throttle and VCL\_Brake variables will need to be controlled in the VCL program.

One of the unique features of the potentiometer inputs (as opposed to the analog inputs) is that they have automatic pot fault detection functions running in the motor controller OS. The VCL programmer has access to the pot detection functions with the Setup\_Pot\_Faults() function. With this function, VCL can set the high and low threshold at which a fault occurs. This function also forces the pot value to a definable level if a fault occurs. Note that the Setup\_Pot\_Faults() function will work for all throttle Types (1–5). See page 108 for more detail on this function.

### **Analog Inputs**

These controllers have two generic analog inputs (pins 24 and 8). These are shared as switch inputs 1 and 2 (Sw\_1, Sw\_2). The values of the analog inputs are automatically placed in VCL variables Analog1\_Input and Analog2\_Input every 1 millisecond. Scaling is 0–10V = 0–32767.

```
User2 = Analog2_Input
```

will fill the User2 RAM variable with the value of the voltage at pin 8.

The filtered values of the analog inputs are also available and are automatically placed in VCL variables Analog1\_Filtered and Analog2\_Filtered. Scaling is 0-10V = 0-32767. The default filter value is 328 (10 Hz) and can be changed in VCL by changing the Analog1\_Filter and Analog2\_Filter values. Scaling is 0-999Hz = 0-32767.

# **Analog Output**

These controllers have one analog output (pin 30). This output is a special driver output. The switching stage is filtered to provide a smooth average voltage, instead of the actual PWM waveform seen on Drivers 1–5. However,

AnalogOut uses the same  $Put_PWM()$  and  $Automate_PWM()$  used by these other drivers. The scaling is 0-10V = 0-32767.

Put\_PWM(PWM6,6553)

will generate 2.0 volts at the analog output. VCL can monitor this output using the variable Analog\_Output.

# INTERFACING THE THROTTLE AND BRAKE COMMANDS

VCL can interface and modify the throttle and brake signals at several points, from the potentiometer to the final motor controller command. VCL can be used to create a completely unique command, adjust parameters to provide MultiMode, or modify the throttle command based on steering angle, height, etc.

The throttle and brake signal chains within the controller are sophisticated and flexible. Before applying VCL to modify these chains, it is important to fully understand the ramifications of these changes. The motor command diagram is presented in Figure 14.

### **Throttle Processing**

The top of Figure 14 shows the throttle processing section. The throttle signal chain flows left to right starting with the physical throttle pot. The voltage on the throttle wiper input (pin 16) is input into the controller and has the VCL variable name Throttle\_Pot\_Raw which is displayed in the 1311 Monitor » Inputs menu. This throttle signal is then modified by the Throttle Type Processing and Throttle Mapping blocks.

The Throttle Type Processing block combines the Throttle\_Type parameter (see page 42) and the throttle potentiometer input (Throttle\_Pot\_Raw) to create a 16-bit variable containing the magnitude of the raw command. This raw command passes to the Throttle Mapping block, which re-shapes the throttle signal magnitude and direction based on the various Throttle Menu parameters (see pages 42–43) and the direction inputs.

Following the Throttle Mapping block are two switches whose purpose is to give the throttle signal a small value (1 for the forward switch, and -1 for the reverse switch) to indicate that a direction switch is On—but only if the throttle signal output from the Throttle Mapping block = 0.

The signal then passes through a selector switch. If the Throttle\_Type parameter is set to 5 (Throttle Type = VCL input, see page 42), the Throttle Mapping block output signal is ignored and the command comes from the VCL variable VCL\_Throttle. The VCL program manipulates the VCL\_Throttle variable to get a throttle command. When the Throttle Type is set to 1–4, the variable VCL\_Throttle does nothing, and the Throttle Mapping block output signal passes through.

After the "Throttle Type = 5" switch, the throttle signal is modified by the multiplying and summing nodes. These nodes can be adjusted by VCL through the variables Throttle\_Multiplier and Throttle\_Offset. This is the basic input point for creating functions like MultiMode, dual drive algorithms, and height vs. speed control. Note that the throttle multiplier has a built-in "divide by 128."




Fig. 14 Motor command diagram.

This allows the VCL to either multiply (Throttle\_Multiplier > 128) or divide (Throttle\_Multiplier < 128) the nominal throttle value. Typically the default multiplier is set to 128, thus having no net effect. Both Throttle\_Multiplier and Throttle\_Offset can be positive or negative.

The output of the multiplying and summing nodes is a VCL variable called Mapped\_Throttle, which is displayed in the 1311 Monitor» Inputs menu. Checking the value of Mapped\_Throttle using the 1311 is a good way to see if your Throttle Menu parameters are set correctly. A VCL program can control the throttle by changing the variables VCL\_Throttle (only if Throttle Type = 5), Throttle\_Multiplier, and Throttle\_Offset. The effect of these variables can be observed as Mapped\_Throttle in the 1311 Monitor» Inputs menu.

Mapped\_Throttle next passes through a limiter that is active only if a pump motor is being operated (Pump Enable = On, see page 33). When active, this function limits the throttle signal to only positive (forward) motion, which is appropriate for controlling a hydraulic pump motor.

The throttle signal continues to a selector switch that will set the throttle signal = 0% if any of the following conditions is present: Interlock\_State = Off (see page 64), a fault has set throttle request = 0% (see the Troubleshooting Chart, Table 5), or if Main\_State  $\neq 5$  or 10 (see page 69).

After this selector switch the throttle signal is a VCL variable called Throttle\_Command, which is displayed in the 1311 Monitor» Inputs menu. Throttle\_Command is the final value of the throttle signal chain that is input to the Control Mode Processing block; see Figure 15. Checking the value of Throttle\_Command using the 1311 is a good way to see the final throttle signal. If ABS(Throttle\_Command) >1 count, the motor controller will output signals to the motor to make it spin.

For investigating why a motor is <u>not</u> spinning, it is useful to use the 1311 to check the state of the throttle signal from beginning to end: using Throttle\_Pot\_Raw, Mapped\_Throttle, and Throttle\_Command. Once these values are known, the Motor Command Diagram (Figure 14) can be used to find how that signal progressed from input to final value.

The following throttle processing variables are accessible by VCL:

VCL VARIABLE	ACCESS	DESCRIPTION
Throttle_Pot_Raw	Read Only	Voltage measurement at pin 16, scaled for the proper wiring
Throttle_Pot_Output	Read Only	Throttle pot input value after being scaled for the proper wiring. For use in VCL program when Throttle Type = 5.
OS_Throttle	Read Only	Throttle pot value after mapping, to be used in VCL when VCL Throttle Enable = On and Throttle Type = 1-4
Mapped_Throttle	Read Only	Throttle pot value after mapping
VCL_Throttle	Read/Write	VCL-accessible throttle command
Throttle_Multiplier	Read/Write	Multiplies or divides the throttle signal
Throttle_Offset	Read/Write	Provides a +/- offset to the throttle signal
Throttle_Command	Read Only	Command resulting from throttle processing

### **Brake Processing**

Brake processing is optional as it can be turned Off (by setting Brake\_Pedal\_Enable = Off, see page 45). If turned On, brake processing can be done with or without VCL. Any non-zero brake command will then override the throttle signal and the motor controller will brake to a stop as determined by the parameters Brake Current Limit (page 39) and Brake Taper Speed (page 36).

The lower part of Figure 14 shows the brake signal processing section. The brake signal chain flows from left to right starting with the physical brake pot. The voltage on the brake wiper input (pin 17) is input into the controller and has the VCL variable name Pot2\_Raw which is displayed in the 1311 Monitor» Inputs menu. This brake signal is then modified by the Brake Type Processing and Brake Mapping blocks.

The Brake Type Processing block uses the Brake\_Type parameter (page 45) and the brake potentiometer input (Pot2\_Raw) to create a signed 16-bit variable. This brake signal then passes to the Brake Mapping block, which re-shapes the brake signal according to the various Brake Menu parameters (page 45).

The signal then passes through a selector switch. If the Brake\_Type parameter is set to 5 (Brake Type = VCL input, see page 45), the Brake Mapping block output signal is ignored and the command comes from the VCL variable VCL\_Brake. The VCL program manipulates the VCL\_Brake variable to get a brake command. Custom braking functions can be set up in this fashion; e.g., braking based on a switch position or an internal fault. The brake potentiometer can still be used, but must be set up using the Setup\_Pot() function. When the Brake Type is set to 1–4, the variable VCL\_Brake does nothing and the Brake Mapping block output signal passes through.

After the "Brake Type = 5" switch, the brake signal passes through a limiter which limits the brake signal to a range of 0–100% (0–32767). After the limiter the brake signal is a VCL variable called Mapped\_Brake, which is displayed in the 1311 Monitor» Inputs menu. Checking the value of Mapped\_Brake using the 1311 is a good way to see if your Brake Menu parameters are set correctly. A VCL program can control the brake by changing the variable VCL\_Brake (only if Brake Type = 5).

The brake signal then goes through a second selector switch that will set the brake signal = 0% if the Brake Pedal Enable parameter (page 45) is set Off. If set On then the brake signal will pass through. The brake signal after this second selector switch is a VCL variable called Brake\_Command, which is displayed in the 1311 Monitor» Inputs menu.

Brake\_Command is the final value of the brake signal chain that is input to the Control Mode Processing block; see Figure 15. Checking the value of Brake\_Command using the 1311 is a good way to see the final brake signal. If Brake\_Command is non-zero in Speed Mode Express or Speed Mode, the throttle signal will be set to 0%.

VCL VARIABLE	ACCESS	DESCRIPTION
Pot2_Raw	Read Only	Voltage measurement at pin 17
Brake_Pot_Output	Read Only	Brake pot input value after being scaled for the proper wiring
OS_Brake	Read Only	Brake pot value after mapping, to be used in VCL when VCL Brake Enable = On and Brake Type = 1-3
VCL_Brake	Read/Write	VCL-accessible brake command
Mapped_Brake	Read Only	Brake pot value after mapping
Brake_Command	Read Only	Command resulting from brake processing

The following brake processing variables are accessible by VCL:

# **Control Mode and Motor Control Processing**

Figure 15 begins with the Throttle\_Command and Brake\_Command inputs and a switch that will zero the Throttle\_Command if Brake\_Command is any value but 0%. The signal chains are then directed to Speed Mode Express, Speed Mode, or Torque Mode based on Control Mode Select. Note that in Torque Mode there is no emergency reverse.

The control mode function uses algorithms to convert the incoming throttle and brake signals and the motor rpm input into a Controller Torque Command.

The selected control mode calculates the desired Controller Torque Command, which is passed to the Motor Control block (see Figure 14). The Motor Control block uses its mathematical model of the specific AC induction motor used to generate the high efficiency three-phase outputs that are output to the AC motor via the cables connected to the **U**, **V**, and **W** terminals.

### INTERFACING THE PROPORTIONAL CURRENT DRIVER

VCL code can directly interface the proportional current driver (PD), as shown in Figure 16. VCL can change the working parameters of the PD and can provide the command.

Depending on how the PD system is to be used, certain parameters need to be set; they can be set via the 1311 handheld programmer or via VCL.

- 1. PD\_Enable must be set On for current control, otherwise the PD\_Output will be controlled by the VCL function Put\_PWM(PWM5,xxxx), which is voltage control.
- 2. Hyd\_Lower\_Enable must be set On to use the throttle input to control lowering in a hydraulic lift/lower system.
- 3. Hyd\_Lower\_Enable must be set Off to allow using a VCL variable (VCL\_PD\_Throttle) as the PD command.

Once the PD parameters are set, the PD\_Throttle variable will be mapped between PD\_Min\_Current and PD\_Max\_Current and sent to the dither




Fig. 15 Control Mode processing.




Fig. 16 Proportional driver processing.

function. Note that Mapped\_Throttle is inverted; lowering its value (making it more negative) increases the PD\_Throttle value.

The Dither function adds and subtracts from the current command to the PD based on PD\_Dither\_Percent, at a rate set by PD\_Dither\_Period.

The dithered current command is compared to the present PD\_Current and the error is fed into a PI controller. The feedback gains are set by the parameters PD Kp (proportional gain) and PD Ki (integral gain). The output of the PI controller becomes the driver's pulse width modulation, thus controlling the average current of the driver. The final output is the VCL variable PD\_Output, which is displayed in the 1311 Monitor» Inputs menu as PD PWM.

The following PD processing variables are accessible by VCL:

VCL VARIABLE	ACCESS	DESCRIPTION
Mapped_Throttle	Read Only	Command from throttle section
VCL_PD_Throttle	Read/Write	VCL-accessible PD command
PD_Throttle	Read Only	Resultant command to the PD
PD_Current	Read Only	Average current flowing in the PD
PD_Output	Read Only	Resultant PWM at PD output

# **USING THE FAULT HANDLER IN VCL**

The operating system of the controller detects various faults and takes appropriate fault actions to protect the controller. These faults have fault codes that are flashed on the controller status LEDs, and fault text is displayed in the 1311 System Faults and Fault History menus. These operating system faults are covered in Section 8. Additionally, the operating system makes the status of the operating system faults available for use in VCL programs in the form of seven variables called Status1, Status2, Status3, Status4, Status5, Status6, and Status7. Each of these 16-bit variables contains the status of 8 faults in the lower byte (the upper byte is always set to 0). These Status1–7 variables are read only (RO) and can be used in a VCL program to trigger additional fault actions such as sending fault text messages to a display or blinking a dashboard LED.

Here are the bit locations of each of the operating system faults in the Status1–7 variables:

```
Status1
      Bit0 = Main Contactor Welded (Code 38)
      Bit1 = Main Contactor Did Not Close (Code 39)
      Bit2 = Pot Low Overcurrent (Code 45)
      Bit3 = Throttle Wiper Low (Code 42)
      Bit4 = Throttle Wiper High (Code 41)
      Bit5 = Pot2 Wiper Low (Code 44)
      Bit6 = Pot2 Wiper High (Code 43)
      Bit7 = EEPROM Failure (Code 46)
Status2
      Bit0 = HPD/Sequencing Fault (Code 47)
      Bit1 = Severe Undervoltage (Code 17)
      Bit2 = Severe Overvoltage (Code 18)
      Bit3 = Undervoltage Cutback (Code 23)
      Bit4 = Overvoltage Cutback (Code 24)
      Bit5 = Not Used
      Bit6 = Controller Overtemp Cutback (Code 22)
      Bit7 = Controller Severe Undertemp (Code 15)
Status3
      Bit0 = Controller Severe Overtemp (Code 16)
      Bit1 = Coill Driver Open/Short (Code 31)
      Bit2 = Coi12 Driver Open/Short (Code 32)
      Bit3 = Coil3 Driver Open/Short (Code 33)
      Bit4 = Coi14 Driver Open/Short (Code 34)
      Bit5 = PD Open/Short (Code 35)
      Bit6 = Main Open/Short (Code 31)
      Bit7 = EMBrake Open/Short (Code 32)
Status4
      Bit0 = Precharge Failed (Code 14)
      Bit1 = Digital Out 6 Overcurrent (Code 26)
      Bit2 = Digital Out 7 Overcurrent (Code 27)
      Bit3 = Controller Overcurrent (Code 12)
      Bit4 = Current Sensor Fault (Code 13)
      Bit5 = Motor Temp Hot Cutback (Code 28)
      Bit6 = Parameter Change Fault (Code 49)
      Bit7 = Motor Open (Code 37)
```

```
Status5
      Bit0 = External Supply Out of Range (Code 69)
      Bit1 = Motor Temp Sensor Fault (Code 29)
      Bit2 = VCL Run Time Error (Code 68)
      Bit3 = +5V Supply Failure (Code 25)
      Bit4 = OS General (Code 71)
      Bit5 = PDO Timeout (Code 72)
      Bit6 = Encoder Fault (Code 36)
      Bit7 = Stall Detected (Code 73)
Status6
      Bit0 = Not Used
      Bit1 = Not Used
      Bit2 = Emer Rev HPD (Code 47)
      Bit3 = Not Used
      Bit4 = Motor Type Fault (Code 89)
      Bit5 = Not Used
      Bit6 = Motor Characterization Fault (Code 87)
      Bit7 = Pump Hardware Fault (Code 97) - model 1298 controllers only
Status7
      Bit0 = Not Used
      Bit1 = VCL/OS Mismatch (Code 91)
      Bit2 = EM Brake Failed to Set (Code 92)
      Bit3 = Encoder LOS (Limited Operating Strategy) (Code 93)
      Bit4 = Emer Rev Timeout (Code 94)
      Bit5 = Dual Severe Fault (Code 75)
      Bit6 = Fault On Other Traction Controller (Code 74)
      Bit7 = Illegal Model Number (Code 98)
Status8
      Bit0 = Pump Overcurrent (Code 95) - model 1298 controllers only
      Bit1 = Pump BDI (Code 96) - model 1298 controllers only
      Bit2 = Pump HPD (Code 47) - model 1298 controllers only
      Bit3 = Dualmotor Parameter Mismatch (Code 99)
      Bit4 = Not Used
      Bit5 = Not Used
      Bit6 = Not Used
```

Bit7 = Not Used

The operating system also provides the capability to create OEM-defined custom faults using VCL. Just as with system faults, the VCL fault codes are flashed on the controller Status LEDs and fault text is displayed on the 1311 System Faults and Fault History menus. Optionally, the VCL can assign fault actions to occur automatically when the associated fault is set. Sixteen VCL faults are available, stored in the VCL variables UserFault1 and UserFault2. The UserFault1,2 variables are Read/Write (R/W) and the 16 faults are stored in the lower byte of each variable like this:

```
UserFaultl
      Bit0 = VCLfault1 (Code 51)
      Bit1 = VCLfault2 (Code 52)
      Bit2 = VCLfault3 (Code 53)
      Bit3 = VCLfault4 (Code 54)
      Bit4 = VCLfault5 (Code 55)
      Bit5 = VCLfault6 (Code 56)
      Bit6 = VCLfault7 (Code 57)
      Bit7 = VCLfault8 (Code 58)
UserFault2
      Bit0 = VCLfault9 (Code 59)
      Bit1 = VCLfault10 (Code 61)
      Bit2 = VCLfault11 (Code 62)
      Bit3 = VCLfault12 (Code 63)
      Bit4 = VCLfault13 (Code 64)
      Bit5 = VCLfault14 (Code 65)
      Bit6 = VCLfault15 (Code 66)
      Bit7 = VCLfault16 (Code 67)
```

The "Code" numbers result in the flashing of the controller status LEDs that help identify the fault without use of a 1311. Setting the fault in VCL is done by setting the associated fault bit in the UserFault1 and 2 variables. Clearing the fault must also be handled by VCL and is done by clearing the associated fault bit. For example:

This VCL will check to see if the Battery Discharge Indicator is less than 10%. If it is, UserFault1 Bit1 (Code 52) is set. If the BDI is not less than 10%, the fault is cleared. Using just the VCL above in a program will only result in the flashing of a code 52 on controller status LEDs and no fault actions will result nor will the 1311 display any text about the fault.

To add automatic fault actions to the VCL faults, the VCL programmer must define the desired fault actions by using the sixteen VCL variables: User\_Fault\_Action\_01 through User\_Fault\_Action\_16. Each of the UserFault bits has a corresponding User\_Fault\_Action\_xx variable (where "xx" is the number of the VCL fault bit). When a VCL fault bit is set, the actions defined in the corresponding User\_Fault\_Action\_xx variable will be automatically executed by the operating system. Here are the fault actions available in the User\_Fault\_Actions\_xx variables:

```
VARIABLE
                                         FAULT ACTION
User Fault Action xx
     Bit0 = ShutdownMotor
                                   Disable the motor
     Bit1 = ShutdownMainContactor Shut down the main contactor
                                    (only if Main Enable = On)
     Bit2 = ShutdownEMBrake
                                   Shut down the EM brake
                                    (only if EM Brake Disable Upon
                                   Fault = On)
     Bit3 = ShutdownThrottle
                                   Set the Throttle Command = 0%
     Bit4 = ShutdownInterlock
                                   Set the Interlock State = Off
     Bit5 = ShutdownDriverl
                                   Shut down Driver1
     Bit6 = ShutdownDriver2
                                   Shut down Driver2
     Bit7 = ShutdownDriver3
                                   Shut down Driver3
     Bit8 = ShutdownDriver4
                                   Shut down Driver4
     Bit9 = ShutdownPD
                                   Shut down Proportional Driver
     Bit10 = FullBrake
                                   Set the Brake Command = 100%
     Bit11 = ShutdownPump
                                   Shut down DC pump
     Bit12 = TrimDisable
                                   Disable Dual Drive trim
                                   calculation.
     Bit13 = SevereDual
                                   For Dual Drive system, one con-
                                   troller has a severe fault but
                                   the main contactor must stay
                                   closed so the other controller
                                   can continue to operate.
     Bit14 = ShutdownSteer
                                   Steer angle = 0°
     Bit15 = LOSDual
                                   For Dual Drive system, set the
                                   max speed to Dual_LOS_Max_Speed
                                   parameter for operation in
                                   Limited Operating Strategy.
```

The User\_Fault\_Action\_xx variables should be set up at the beginning of a VCL program (before the main loop) as these fault actions should be defined only once in a program. Here is another example:

This time when UserFault1.2 is set, the operating system will ShutdownInterlock and ShutdownThrottle (which will result in a Throttle\_Command = 0%) in

addition to flashing the code 52 on the controller status LEDs. An additional VCL line was added (Put\_Spy\_Text ("BDI Low")) to show how additional actions beyond those provided in the User\_Fault\_Action\_xx can be programmed using VCL. In this example the Put\_Spy\_Text("BDI Low") will result in the message "BDI Low" appearing on the model 840 display (presumably as a message to the vehicle operator). This example will still not result in any display on the 1311 System Faults and Fault History menus.

To add the fault text on the 1311 System Faults and Fault History menus it is necessary to create a Fault Definition for the 1311. Creating fault definitions is a subject that is covered in detail in the VCL Programmer's Guide (Section 5, Support for the 1311 Handheld Programmer). Here is an example of a fault definition:

```
User Fault Action 02 = 24
                           ;Set fault action to ShutdownInterlock
                           ; and ShutdownThrottle
MainLoop:
if (BDI Percentage < 10)
      UserFault1.2 = ON
                              ;Set User fault bit
      Put_Spy_Text("BDI Low") ;Send message to Model 840 display
else
      UserFault1.2 = OFF
                               ;Clear User fault bit
goto MainLoop
  PARAMETER ENTRY
                    "BDI Low Fault"
  TYPE
                    FAULTS
  WIDTH
                    8BTT
  ALT ADDRESS
                   Hist UserFault1
  ADDRESS
                    UserFault1
  BITSELECT
                    1
  BITACTIVELOW
                    NO
```

This example will result in the exact same actions as the last example, except now the fault will be displayed in the 1311 System Faults menu (only while the fault is set) and this fault will be logged into the 1311 Fault History menu after being set. The text displayed in either of these 1311 menus will be the text defined in the fault definition (in this example "BDI Low Fault" will be displayed). The variable Hist\_UserFault1 is listed as an ALT\_ADDRESS. This line controls whether the fault gets logged into fault history (and thus appears in the 1311 Fault History menu). The two variables that can be used in the fault definitions for ALT\_ADDRESS are Hist\_UserFault1 and Hist\_UserFault2; these should be used in the fault definitions with the corresponding UserFault1 and UserFault2 variables. If you wish to use VCL to clear fault history, use the VCL function Clear\_Diaghist(). Also note that this example fault definition was for bit 1 of UserFault1. The VCL example set and cleared this bit by using the UserFault1.2 notation (".2" being the mask that defines bit 1).

# VCL FUNCTIONS SPECIFIC TO 1234/36/38 AC CONTROLLERS

Function descriptions are provided here for the functions that are unique to these controllers. They are presented in the same format that is used in the VCL Common Functions Manual for the common functions.

# **ENABLE\_PRECHARGE()**

This function is designed to precharge the capacitor bank before engaging a main contactor thereby preventing current surges and to protect controller internal components and main contactor tips. This function turns on the request for precharge of the capacitor bank from KSI. When the precharge function is enabled, power will be supplied to the capacitor bank until the voltage is within 3 volts of KSI, or one second has expired, or the precharge resistor energy range has been exceeded. The current state of precharge is shown by the precharge variable (Precharge\_State), which has the following values:

- 0 Precharge has not yet been done.
- 1 Precharge is in progress.
- 2 Precharge has passed.
- 3 Precharge has been aborted by the Disable\_Precharge() function.
- 4 Precharge has exceeded the precharge resistor energy limit.
- 5 Precharge has exceeded the one-second time limit.

Syntax Enable Precharge()

Parameters None.

### Returns

0 - Precharge not enabled.

1 - Precharge successfully enabled.

Error Codes None.

Enable Precharge()

This will attempt to precharge the capacitor bank.

# **DISABLE\_PRECHARGE()**

This function is designed to abort the precharge function and clear any precharge fault. This function aborts the request for precharge of the capacitor bank from KSI. The resultant state of the precharge variable (Precharge\_State) will be set to = 3 (for precharge aborted). The precharge states are:

- 0 Precharge has not yet been done.
- 1 Precharge is in progress.
- 2 Precharge has passed.
- 3 Precharge has been aborted by the Disable\_Precharge() function.
- 4 Precharge has exceeded the precharge resistor energy limit.
- 5 Precharge has exceeded the one-second time limit.

Syntax Disable\_Precharge()

Parameters None.

### Returns

0 - Precharge not aborted.

1 - Precharge successfully aborted.

Error Codes None.

Example Disable\_Precharge()

This will attempt to abort the precharge of the capacitor bank and will clear any precharge fault.

## SET\_DIGOUT()

This function turns on the selected digital output. The digital outputs are active low (On = driver on and pulled to ground, Off = open circuit at the pin).

The low power digital output is protected from excessive current (current over 15 mA); a fault will occur when this current has been exceeded, and the driver will be shut off (open). Running the function again will reactivate the driver, and will attempt to clear the fault.

```
Syntax Set Digout (DigOut ID)
```

#### **Parameters**

DigOut\_ID is the low power digital I/O identification.

DigOut6 = Digital Output 6 (pin 19).

DigOut7 = Digital Output 7 (pin 20).

#### Returns

0 - Selected digital output not set.

1 – Selected digital output successfully set.

#### Error Codes

Bad\_ID is returned when DigOut\_ID is not in the range of DigOut6 to DigOut7.

Example Set\_Digout(DigOut6)

This example will set Digital Output 6 (pin 19) On (active low, pulled to ground).

# CLEAR\_DIGOUT()

This function turns off the selected digital output. The digital outputs are active low (On = driver on and pulled to ground, Off = open circuit at the pin).

```
Syntax Clear_Digout(DigOut_ID)
```

#### **Parameters**

DigOut ID is the low power digital I/O identification.

DigOut6 = Digital Output 6 (pin 19).

DigOut7 = Digital Output 7 (pin 20).

### Returns

0 - Selected digital output not cleared.

1 – Selected digital output successfully cleared.

## Error Codes

Bad\_ID is returned when DigOut\_ID is not in the range of DigOut6 to DigOut7.

Example Clear Digout(DigOut6)

This example will set Digital Output 6 (pin 19) Off (open circuit).

## **ENABLE\_EMER\_REV()**

This function is used to engage emergency reverse using VCL. The 1311 EMR Type must be set to = 1 in order for the Enable\_Emer\_Rev() function to operate. If the system emergency reverse state is enabled (EMR\_State bit variable = On), the emergency reverse function will operate according to the Emergency Reverse parameter settings; see page 59. To view the current emergency reverse state, see the 1311 menu Monitor» Inputs: Emer Rev.

When the EMR\_Type is set to = 1 and neither the Enable\_Emer\_Rev() nor the Disable\_Emer\_Rev() function has been called, the state for emergency reverse is Off (EMR\_State bit variable = Off).

Syntax Enable\_Emer\_Rev()

Parameters None.

#### Returns

0 - Emergency reverse not enabled.

1 - Emergency reverse successfully enabled.

Error Codes None.

Example Enable Emer Rev()

This will enable the emergency reverse function.

# **DISABLE\_EMER\_REV()**

This function is used to disengage emergency reverse using VCL. The 1311 EMR Type must be set to = 1 in order for the Disable\_Emer\_Rev() function to operate. If the system emergency reverse state is disabled (EMR\_State bit variable = Off), the emergency reverse function will stop operating and normal motor control function will resume (including an HPD/SRO check if the HPD/SRO Enable parameter is set to On). To view the current emergency reverse state, see the 1311 menu Monitor» Inputs: Emer Rev.

When the EMR\_Type is set to = 1 and neither the Enable\_Emer\_Rev() nor the Disable\_Emer\_Rev() function has been called, the state for emergency reverse is Off (EMR\_State bit variable = Off).

Syntax Disable\_Emer\_Rev()

Parameters None.

#### Returns

0 - Emergency reverse not disabled.

1 - Emergency reverse successfully disabled.

Error Codes None.

Example Disable\_Emer\_Rev()

This will disable the emergency reverse function.

## SET\_INTERLOCK()

This function is used to engage the system interlock using VCL. The 1311 Interlock Type parameter must be set to = 1 in order for the Set\_Interlock() function to operate. If the system interlock is set (Interlock\_State bit variable = On), the throttle input signal is allowed to pass along the throttle chain; see Figure 14. Additionally, if the main contactor is used (1311 Main Enable parameter = On), setting the interlock will request the main closed state from the main contactor state machine. To view the current interlock state, see the 1311 menu Monitor » Inputs: Interlock. To view the current main contactor state, see the 1311 menu Monitor » Controller: Main State.

When the Interlock\_Type is set to = 1 and neither the Set\_Interlock() nor the Clear\_Interlock() function has been called, the state for the interlock is Off (Interlock\_State bit variable = Off).

Syntax Set\_Interlock()

Parameters None.

Returns

0 – Interlock not set.

1 - Interlock successfully set.

Error Codes None.

Example Set\_Interlock()

This will engage the system interlock.

#### CLEAR\_INTERLOCK()

This function is used to disengage the system interlock using VCL. The 1311 Interlock Type parameter must be set to = 1 in order for the Set\_Interlock() function to operate. If the system interlock is cleared (Interlock\_State bit variable = Off), the throttle input signal is not allowed to pass along the throttle chain; see Figure 13. Additionally, if the main contactor is used (1311 Main Enable parameter = On), clearing the interlock will request the main open state from the main contactor state machine. To view the current interlock state, see the 1311 menu Monitor»Inputs: Interlock. The view the current main contactor state, see the 1311 menu Monitor»Controller: Main State.

When the Interlock\_Type is set to = 1 and neither the Set\_Interlock() nor Clear\_Interlock() function has been called, the default state for the interlock is Off (Interlock\_State bit variable = Off).

Syntax Clear Interlock()

Parameters None.

Returns

0 - Interlock not cleared.

1 - Interlock successfully cleared.

Error Codes None.

Example Clear\_Interlock()

This will disengage the system interlock.

# SETUP\_POT\_FAULTS()

This function sets the upper and lower wiper fault voltages for a given pot input and sets the replacement wiper voltage value that will be used if there is a fault. The valid range for the function parameters is 0–6.25 V (0–400 counts). If this function is not run, the default thresholds depend on the 1311 Throttle Type (or Brake Type) parameter setting; see table below. If the Throttle Type = 5 (or Brake Type = 5), the VCL function Setup\_Pot will determine what fault thresholds are used.

THROTTLE TYPE		LOW FAULT THRESHOLD	HIGH FAULT THRESHOLD	
	1	0.1 V	5.5 V	
	2	none	5.5 V	
	3	0.1 V	5.5 V	
	4	0.1 V	5.5 V	
5	(ONE_WIRE)	none	5.5 V	
5	(TWO_WIRE)	0.1 V	5.5 V	
5	(THREE_WIRE)	0.1 V	5.5 V	

```
Syntax Setup_Pot_Faults(Pot_ID,Low_Fault,High_Fault, Fault_Value)
```

#### **Parameters**

Pot ID identifies the throttle whose fault limits are being set:

THROTTLE\_POT BRAKE\_POT

Low Fault

Specifies the lower threshold voltage limit.

Scaling: 1 V = 64 counts.

High Fault

Specifies the upper threshold voltage limit.

Scaling: 1 V = 64 counts.

Fault Value

The value that is used for the pot input when there is a fault (0-32767).

Scaling:  $\pm 32767 = \pm 100\%$ .

## Returns

0 - Setup did not execute.

1 – Setup successful.

#### Error Codes

Bad\_ID is returned when an incorrect pot ID is used.

Param\_Range is returned when the voltage value is not within range.

Example Setup Pot Faults (THROTTLE POT, 19, 320, 4000)

For the throttle pot, this will set the lower pot voltage at 0.3 volts (19/64) and the upper pot voltage at 5.0 volts (320/64). When there is a pot fault, the value of 4000 will be used. That is 4000/32767 of the full output, or roughly 12%.

# START\_PUMP()

This function is used to turn on the pump lift contactor. If the 1311 parameter Drivers » Hydraulic Contactor » Contactor Enable = On (VCL Hydraulic Contactor Enable bit variable = On), the VCL function Start\_Pump() will turn on the pump lift contactor (Driver 3).

When HydraulicContactorEnable = On and neither Start\_Pump() nor Stop\_Pump() has been called, the pump lift contactor is Off.

Syntax Start\_Pump()

Parameters None.

Returns

0 - Pump start function not enabled.

1 – Pump start function successfully enabled.

Error Codes None.

Example Start Pump()

This will turn on the pump lift contactor.

# STOP\_PUMP()

This function is used to turn off the pump lift contactor. If the 1311 parameter Drivers » Hydraulic Contactor » Contactor Enable = On (VCL Hydraulic Contactor Enable bit variable = On), the VCL function Start\_Pump() will turn off the pump lift contactor (Driver 3).

When HydraulicContactorEnable = On and neither Start\_Pump() nor Stop\_Pump() has been called, the pump lift contactor is Off.

Syntax Stop Pump()

Parameters None.

Returns

0 - Pump stop function not enabled.

1 – Pump stop function successfully enabled.

Error Codes None.

Example Stop\_Pump()

This will turn off the pump lift contactor.



# **DIAGNOSTICS AND TROUBLESHOOTING**

These controllers detect a wide variety of faults or error conditions. Faults can be detected by the operating system or by the VCL code. This section describes the faults detected by the operating system.

Faults detected by VCL code (faults 51–67 in Table 5) cannot be defined here as they will vary from application to application. Refer to the appropriate OEM documentation for information on these faults.

# **DIAGNOSTICS**

Diagnostics information can be obtained in either of two ways: (1) by reading the display on a 1311 programmer or (2) by observing the fault codes issued by the Status LEDs. See Table 4 for a summary of LED display formats.


The <u>1311 programmer</u> will display all faults that are currently set as well as a history of the faults that have been set since the history log was last cleared. The 1311 displays the faults by name.

The pair of <u>LEDs</u> built into the controller (one red, one yellow) produce flash codes displaying all the currently set faults in a repeating cycle. Each code consists of two digits. The red LED flashes once to indicate that the first digit of the code will follow; the yellow LED then flashes the appropriate number of times for the first digit. The red LED flashes twice to indicate that the second digit of the code will follow; the yellow LED flashes the appropriate number of times for the second digit.

Example: Battery Undervoltage (code 23).

In the Fault menu of the 1311 programmer, the words **Undervoltage Cutback** will be displayed; the real-time battery voltage is displayed in the Monitor menu ("Keyswitch Voltage").

The controller's two LEDs will display this repeating pattern:



The numerical codes used by the yellow LED are listed in the troubleshooting chart (Table 5), which also lists possible fault causes and describes the conditions that set and clear each fault.

# Summary of LED display formats

The two LEDs have four different display modes, indicating the type of information they are providing.

Table 4 TYPES OF LED DISPLAY				
DISPLAY	STATUS			
Neither LED illuminated	Controller is not powered on; or vehicle has dead battery; or severe damage.			
Yellow LED flashing	Controller is operating normally.			
Yellow and red LEDs both on solid	Controller is in Flash program mode.			
Red LED on solid	Watchdog failure or no software loaded. Cycle KSI to restart, and if necessary load software.			
Red LED and yellow LED flashing alternately	Controller has detected a fault. 2-digit code flashed by yellow LED identifies the specific fault; one or two flashes by red LED indicate whether first or second code digit will follow.			

# **TROUBLESHOOTING**

The troubleshooting chart, Table 5, provides the following information on all the controller faults:

- fault code
- fault name as displayed on the programmer's LCD
- the effect of the fault
- possible causes of the fault
- fault set conditions
- fault *clear* conditions.

Whenever a fault is encountered and no wiring or vehicle fault can be found, shut off KSI and turn it back on to see if the fault clears. If it does not, shut off KSI and remove the 35-pin connector. Check the connector for corrosion or damage, clean it if necessary, and re-insert it.

Table 5 TROUBLESHOOTING CHART				
CODE	PROGRAMMER LCD DISPLAY  EFFECT OF FAULT	POSSIBLE CAUSE	SET/CLEAR CONDITIONS	
12	Controller Overcurrent ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	<ol> <li>External short of phase U,V, or W motor connections.</li> <li>Motor parameters are mis-tuned.</li> <li>Controller defective.</li> </ol>	Set: Phase current exceeded the current measurement limit. Clear: Cycle KSI.	
13	Current Sensor Fault ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	<ol> <li>Leakage to vehicle frame from phase U, V, or W (short in motor stator).</li> <li>Controller defective.</li> </ol>	Set: Controller current sensors have invalid offset reading. Clear: Cycle KSI.	
14	Precharge Failed ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	<ol> <li>External load on capacitor bank (B+ connection terminal) that prevents the capacitor bank from charging.</li> <li>See Monitor menu » Battery:         Capacitor Voltage.     </li> </ol>	Set: Precharge failed to charge the capacito bank to the KSI voltage.  Clear: Cycle Interlock input or use VCL function Precharge().	
15	Controller Severe Undertemp ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	<ol> <li>See Monitor menu » Controller: Temperature.</li> <li>Controller is operating in an extreme environment.</li> </ol>	Set: Heatsink temperature below -40°C. Clear: Bring heatsink temperature above -40°C, and cycle interlock or KSI.	
16	Controller Severe Overtemp ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	<ol> <li>See Monitor menu » Controller: Temperature.</li> <li>Controller is operating in an extreme environment.</li> <li>Excessive load on vehicle.</li> <li>Improper mounting of controller.</li> </ol>	Set: Heatsink temperature above +95°C. Clear: Bring heatsink temperature below +95°C, and cycle interlock or KSI.	
17	Severe Undervoltage Reduced drive torque.	<ol> <li>Battery Menu parameters are misadjusted.</li> <li>Non-controller system drain on battery.</li> <li>Battery resistance too high.</li> <li>Battery disconnected while driving.</li> <li>See Monitor menu » Battery:         <ul> <li>Capacitor Voltage.</li> </ul> </li> <li>Blown B+ fuse or main contactor did not close.</li> </ol>	Set: Capacitor bank voltage dropped below the Severe Undervoltage limit (see page 55) with FET bridge enabled. Clear: Bring capacitor voltage above Severe Undervoltage limit.	

Table 5 TROUBLESHOOTING CHART, continued				
CODE	PROGRAMMER LCD DISPLAY  EFFECT OF FAULT	POSSIBLE CAUSE	SET/CLEAR CONDITIONS	
18	Severe Overvoltage ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	<ol> <li>See Monitor menu » Battery:         Capacitor Voltage.</li> <li>Battery menu parameters are         misadjusted.</li> <li>Battery resistance too high for given         regen current.</li> <li>Battery disconnected while regen braking.</li> </ol>	Set: Capacitor bank voltage exceeded the Severe Overvoltage limit (see page 55) with FET bridge enabled.  Clear: Bring capacitor voltage below Severe Overvoltage limit, and then cycle KSI.	
22	Controller Overtemp Cutback Reduced drive and brake torque.	<ol> <li>See Monitor menu » Controller: Temperature.</li> <li>Controller is performance-limited at this temperature.</li> <li>Controller is operating in an extreme environment.</li> <li>Excessive load on vehicle.</li> <li>Improper mounting of controller.</li> </ol>	Set: Heatsink temperature exceeded 85°C. Clear: Bring heatsink temperature below 85°C.	
23	Undervoltage Cutback Reduced drive torque.	<ol> <li>Normal operation. Fault shows that the batteries need recharging.         Controller is performance limited at this voltage.</li> <li>Battery parameters are misadjusted.</li> <li>Non-controller system drain on battery.</li> <li>Battery resistance too high.</li> <li>Battery disconnected while driving.</li> <li>See Monitor menu » Battery:         Capacitor Voltage.</li> <li>Blown B+ fuse or main contactor did not close.</li> </ol>	Set: Capacitor bank voltage dropped below the Undervoltage limit (see page 55) with the FET bridge enabled.  Clear: Bring capacitor voltage above the Undervoltage limit.	
24	Overvoltage Cutback Reduced brake torque.	<ol> <li>Normal operation. Fault shows that regen braking currents elevated the battery voltage during regen braking. Controller is performance limited at this voltage.</li> <li>Battery parameters are misadjusted.</li> <li>Battery resistance too high for given regen current.</li> <li>Battery disconnected while regen braking.</li> <li>See Monitor menu » Battery: Capacitor Voltage.</li> </ol>	Set: Capacitor bank voltage exceeded the Overvoltage limit (see page 55) with the FET bridge enabled. Clear: Bring capacitor voltage below the Overvoltage limit.	
25	+5V Supply Failure None, unless a fault action is programmed in VCL.	<ol> <li>External load impedance on the +5V supply (pin 26) is too low.</li> <li>See Monitor menu » outputs: 5 Volts and Ext Supply Current.</li> </ol>	Set: +5V supply (pin 26) outside the +5V±10% range.  Clear: Bring voltage within range.	
26	Digital Out 6 Overcurrent Digital Output 6 driver will not turn on.	External load impedance on Digital     Output 6 driver (pin 19) is too low.	Set: Digital Output 6 (pin 19) current exceeded 15 mA.  Clear: Remedy the overcurrent cause and use the VCL function Set_DigOut() to turn the driver on again.	

Table 5 TROUBLESHOOTING CHART, continued					
CODE	PROGRAMMER LCD DISPLAY  EFFECT OF FAULT	POSSIBLE CAUSE	SET/CLEAR CONDITIONS		
27	Digital Out 7 Overcurrent Digital Output 7 driver will not turn on.	External load impedance on Digital Output 7 driver (pin 20) is too low.	Set: Digital Output 7 (pin 20) current exceeded 15 mA.  Clear: Remedy the overcurrent cause and use the VCL function Set_DigOut() to turn the driver on again.		
28	Motor Temp Hot Cutback Reduced drive torque.	<ol> <li>Motor temperature is at or above the programmed Temperature Hot setting, and the requested current is being cut back.</li> <li>Motor Temperature Control Menu parameters are mis-tuned.</li> <li>See Monitor menu » Motor:         <ul> <li>Temperature and » Inputs: Analog2.</li> </ul> </li> <li>If the application doesn't use a motor thermistor, Temp Compensation and Temp Cutback should be programmed Off.</li> </ol>	Set: Motor temperature is at or above the Temperature Hot parameter setting.  Clear: Bring the motor temperature within range.		
29	Motor Temp Sensor Fault MaxSpeed reduced (LOS, Limited Operating Strategy), and motor temperature cutback disabled.	<ol> <li>Motor thermistor is not connected properly.</li> <li>If the application doesn't use a motor thermistor, Motor Temp Sensor Enable should be programmed Off.</li> <li>See Monitor menu » Motor: Temperature and » Inputs: Analog2.</li> </ol>	Set: Motor thermistor input (pin 8) is at the voltage rail (0 or 10V).  Clear: Bring the motor thermistor input voltage within range.		
31	Coil1 Driver Open/Short ShutdownDriver1.	<ol> <li>Open or short on driver load.</li> <li>Dirty connector pins.</li> <li>Bad crimps or faulty wiring.</li> </ol>	Set: Driver 1 (pin 6) is either open or shorted. This fault can be set only when Main Enable = Off.  Clear: Correct open or short, and cycle driver.		
31	Main Open/Short ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	<ol> <li>Open or short on driver load.</li> <li>Dirty connector pins.</li> <li>Bad crimps or faulty wiring.</li> </ol>	Set: Main contactor driver (pin 6) is either open or shorted. This fault can be set only when Main Enable = On.  Clear: Correct open or short, and cycle driver		
32	Coil2 Driver Open/Short ShutdownDriver2.	<ol> <li>Open or short on driver load.</li> <li>Dirty connector pins.</li> <li>Bad crimps or faulty wiring.</li> </ol>	Set: Driver 2 (pin 5) is either open or shorted. This fault can be set only when EM Brake Type = 0.  Clear: Correct open or short, and cycle driver.		
32	EMBrake Open/Short ShutdownEMBrake; ShutdownThrottle; FullBrake.	<ol> <li>Open or short on driver load.</li> <li>Dirty connector pins.</li> <li>Bad crimps or faulty wiring.</li> </ol>	Set: Electromagnetic brake driver (pin 5) is either open or shorted. This fault can be set only when EM Brake Type >0. Clear: Correct open or short, and cycle driver.		
33	Coil3 Driver Open/Short ShutdownDriver3.	<ol> <li>Open or short on driver load.</li> <li>Dirty connector pins.</li> <li>Bad crimps or faulty wiring.</li> </ol>	Set: Driver 3 (pin 4) is either open or shorted. Clear: Correct open or short, and cycle driver.		
34	Coil4 Driver Open/Short ShutdownDriver4.	Open or short on driver load.     Dirty connector pins.     Bad crimps or faulty wiring.	Set: Driver 4 (pin 3) is either open or shorted.  Clear: Correct open or short, and cycle driver.		

	Tab	ole 5 TROUBLESHOOTING CHART, c	ontinued
CODE	PROGRAMMER LCD DISPLAY  EFFECT OF FAULT	POSSIBLE CAUSE	SET/CLEAR CONDITIONS
35	PD Open/Short ShutdownPD.	<ol> <li>Open or short on driver load.</li> <li>Dirty connector pins.</li> <li>Bad crimps or faulty wiring.</li> </ol>	Set: Proportional driver (pin 2) is either open or shorted.  Clear: Correct open or short, and cycle drive
36	Encoder Fault ShutdownEMBrake.	<ol> <li>Motor encoder failure.</li> <li>Bad crimps or faulty wiring.</li> <li>See Monitor menu » Motor: Motor RPM.</li> </ol>	Set: Motor encoder phase failure detected Clear: Cycle KSI.
37	Motor Open ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	<ol> <li>Motor phase is open.</li> <li>Bad crimps or faulty wiring.</li> </ol>	Set: Motor phase U, V, or W detected open. Clear: Cycle KSI.
38	Main Contactor Welded ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	<ol> <li>Main contactor tips are welded closed.</li> <li>Motor phase U or V is disconnected or open.</li> <li>An alternate voltage path (such as an external precharge resistor) is providing a current to the capacitor bank (B+ connection terminal).</li> </ol>	Set: Just prior to the main contactor closing, the capacitor bank voltage (B+connection terminal) was loaded for a short time and the voltage did not discharge.  Clear: Cycle KSI
39	Main Contactor Did Not Close ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	<ol> <li>Main contactor did not close.</li> <li>Main contactor tips are oxidized, burned, or not making good contact.</li> <li>External load on capacitor bank (B+ connection terminal) that prevents capacitor bank from charging.</li> <li>Blown B+ fuse.</li> </ol>	Set: With the main contactor commanded closed, the capacitor bank voltage (B+connection terminal) did not charge to B Clear: Cycle KSI.
41	Throttle Wiper High ShutdownThrottle.	<ol> <li>See Monitor menu » Inputs:         Throttle Pot.</li> <li>Throttle pot wiper voltage too high.</li> </ol>	Set: Throttle pot wiper (pin 16) voltage is higher than the high fault threshold (can be changed with the VCL function Setup_Pot_Faults()).  Clear: Bring throttle pot wiper voltage below the fault threshold.
42	Throttle Wiper Low Shutdown Throttle.	<ol> <li>See Monitor menu » Inputs:         Throttle Pot.</li> <li>Throttle pot wiper voltage too low.</li> </ol>	Set: Throttle pot wiper (pin 16) voltage is lower than the low fault threshold (can be changed with the VCL function Setup_Pot_Faults()).  Clear: Bring throttle pot wiper voltage above the fault threshold.
43	Pot2 Wiper High FullBrake.	<ol> <li>See Monitor menu » Inputs:         Pot2 Raw.</li> <li>Pot2 wiper voltage too high.</li> </ol>	Set: Pot2 wiper (pin 17) voltage is higher than the high fault threshold (can be changed with the VCL function Setup_Pot_Faults()).  Clear: Bring Pot2 wiper voltage below the fault threshold.

	Tal	ole 5 TROUBLESHOOTING CHART, co	ontinued
CODE	PROGRAMMER LCD DISPLAY  EFFECT OF FAULT	POSSIBLE CAUSE	SET/CLEAR CONDITIONS
44	Pot2 Wiper Low FullBrake.	<ol> <li>See Monitor menu » Inputs: Pot2 Raw.</li> <li>Pot2 wiper voltage too low.</li> </ol>	Set: Pot2 wiper (pin 17) voltage is lower than the low fault threshold (can be changed with the VCL function Setup_Pot_Faults()).  Clear: Bring Pot2 wiper voltage above the fault threshold.
45	Pot Low Overcurrent Shutdown Throttle; FullBrake.	<ol> <li>See Monitor menu » Outputs:         Pot Low.     </li> <li>Combined pot resistance connected to pot low is too low.</li> </ol>	Set: Pot low (pin 18) current exceeds 10mA Clear: Clear pot low overcurrent condition and cycle KSI.
46	EEPROM Failure  ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownInterlock; ShutdownInterlock; ShutdownDriver1; ShutdownDriver2; ShutdownDriver3; ShutdownDriver4; ShutdownPD; FullBrake; ShutdownPump.	1. Failure to write to EEPROM memory. This can be caused by EEPROM memory writes initiated by VCL, by the CAN bus, by adjusting parameters with the programmer, or by loading new software into the controller.	Set: Controller operating system tried to write to EEPROM memory and failed. Clear: Download the correct software (OS and matching parameter default settings into the controller and cycle KSI.
47	HPD/Sequencing Fault ShutdownThrottle.	<ol> <li>KSI, interlock, direction, and throttle inputs applied in incorrect sequence.</li> <li>Faulty wiring, crimps, or switches at KSI, interlock, direction, or throttle inputs.</li> <li>See Monitor menu » Inputs.</li> </ol>	Set: HPD (High Pedal Disable) or sequencing fault caused by incorrect sequence of KSI, interlock, direction, and throttle inputs.  Clear: Reapply inputs in correct sequence.
47	Emer Rev HPD Shutdown Throttle; Shutdown EMBrake.	1. Emergency Reverse operation has concluded, but the throttle, forward and reverse inputs, and interlock have not been returned to neutral.	Set: At the conclusion of Emergency Reverse, the fault was set because various inputs were not returned to neutral.  Clear: If EMR_Interlock = On, clear the interlock, throttle, and direction inputs.  If EMR_Interlock = Off, clear the throttle and direction inputs.
49	Parameter Change Fault ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	1. This is a safety fault caused by a change in certain parameter settings so that the vehicle will not operate until KSI is cycled. For example, if a user changes the Throttle Type this fault will appear and require cycling KSI before the vehicle can operate.	Set: Adjustment of a parameter setting that requires cycling of KSI.  Clear: Cycle KSI.
51–67	OEM Faults (See OEM documentation.)	1. These faults can be defined by the OEM and are implemented in the application-specific VCL code. See OEM documentation.	Set: See OEM documentation.  Clear: See OEM documentation.

Table 5 TROUBLESHOOTING CHART, continued				
CODE	PROGRAMMER LCD DISPLAY  EFFECT OF FAULT	POSSIBLE CAUSE	SET/CLEAR CONDITIONS	
68	VCL Run Time Error  ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; ShutdownInterlock; ShutdownDriver1; ShutdownDriver2; ShutdownDriver3; ShutdownDriver4; ShutdownPD; FullBrake; ShutdownPump.	<ol> <li>VCL code encountered a runtime VCL error.</li> <li>See Monitor menu » Controller: VCL Error Module and VCL Error. This error can then be compared to the runtime VCL module ID and error code definitions found in the specific OS system information file.</li> </ol>	Set: Runtime VCL code error condition. Clear: Edit VCL application software to fix this error condition; flash the new compiled software and matching parameter defaults; cycle KSI.	
69	External Supply Out of Range None, unless a fault action is programmed in VCL.	<ol> <li>External load on the 5V and 12V supplies draws either too much or too little current.</li> <li>Fault Checking Menu parameters Ext Supply Max and Ext Supply Min are mis-tuned.</li> <li>See Monitor menu » Outputs: Ext Supply Current.</li> </ol>	Set: The external supply current (combined current used by the 5V supply [pin 26] and 12V supply [pin 25]) is either greater than the upper current threshold or lower than the lower current threshold. The two thresholds are defined by the External Supply Max and External Supply Min parameter settings (page 52).  Clear: Bring the external supply current within range.	
71	OS General  ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; ShutdownInterlock; ShutdownDriver1; ShutdownDriver2; ShutdownDriver3; ShutdownDriver4; ShutdownPD; FullBrake; ShutdownPump.	1. Internal controller fault.	Set: Internal controller fault detected. Clear: Cycle KSI.	
72	PDO Timeout  ShutdownInterlock;  CAN NMT State set to Pre-operational.	Time between CAN PDO messages received exceeded the PDO Timeout Period.	Set: Time between CAN PDO messages received exceeded the PDO Timeout Period. Clear: Cycle KSI or receive CAN NMT message.	
73	Stall Detected ShutdownEMBrake; Control Mode changed to LOS (Limited Operating Strategy).	<ol> <li>Stalled motor.</li> <li>Motor encoder failure.</li> <li>Bad crimps or faulty wiring.</li> <li>Problems with power supply for the motor encoder.</li> <li>See Monitor menu » Motor: Motor RPM.</li> </ol>	Set: No motor encoder movement detected. Clear: Either cycle KSI, or detect valid motor encoder signals while operating in LOS mode and return Throttle Command = 0 and Motor RPM = 0.	

	Table 5 TROUBLESHOOTING CHART, continued				
CODE	PROGRAMMER LCD DISPLAY  EFFECT OF FAULT	POSSIBLE CAUSE	SET/CLEAR CONDITIONS		
87	Motor Characterization Fault ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	1. Motor characterization failed during characterization process. See Monitor menu» Controller: Motor Characterization Error for cause:  0=none 1=encoder signal seen, but step size not determined; set Encoder Step Size manually 2=motor temp sensor fault 3=motor temp hot cutback fault 4= controller overtemp cutback fault 5=controller undertemp cutback fault 6=undervoltage cutback fault 7=severe overvoltage fault 8=encoder signal not seen, or one or both channels missing 9=motor parameters out of characterization range.	Set: Motor characterization failed during the motor characterization process.  Clear: Correct fault; cycle KSI.		
89	Motor Type Fault ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	The Motor_Type parameter value is out of range.	Set: Motor_Type parameter is set to an illegal value.  Clear: Set Motor_Type to correct value and cycle KSI.		
91	VCL/OS Mismatch ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; ShutdownInterlock; ShutdownDriver1; ShutdownDriver2; ShutdownDriver3; ShutdownDriver4; ShutdownPD; FullBrake; ShutdownPump.	The VCL software in the controller does not match the OS software in the controller.	Set: VCL and OS software do not match; when KSI cycles, a check is made to verify that they match and a fault is issued when they do not.  Clear: Download the correct VCL and OS software into the controller.		
92	EM Brake Failed to Set ShutdownEMBrake; ShutdownThrottle.	<ol> <li>Vehicle movement sensed after the EM Brake has been commanded to set.</li> <li>EM Brake will not hold the motor from rotating.</li> </ol>	Set: After the EM Brake was commanded to set and time has elapsed to allow the brake to fully engage, vehicle movement has been sensed.  Clear: Activate the throttle.		
93	Encoder LOS (Limited Operating Strategy)  Enter LOS control mode.	<ol> <li>Limited Operating Strategy (LOS) control mode has been activated, as a result of either an Encoder Fault (Code 36) or a Stall Detect Fault (Code 73).</li> <li>Motor encoder failure.</li> <li>Bad crimps or faulty wiring.</li> <li>Vehicle is stalled.</li> </ol>	Set: Encoder Fault (Code 36) or Stall Detect Fault (Code 73) was activated, and Brake or Interlock has been applied to activate LOS control mode, allowing limited motor control.  Clear: Cycle KSI, or if LOS mode was activated by the Stall Fault, clear by ensuring encoder senses proper operation, Motor RPM = 0, and Throttle Command = 0.		

Table 5 TROUBLESHOOTING CHART, continued					
CODE PROGRAMMER LCD DISPLAY  EFFECT OF FAULT  POSSIBLE CAUSE		POSSIBLE CAUSE	SET/CLEAR CONDITIONS		
94	Emer Rev Timeout  ShutdownEMBrake; ShutdownThrottle.	<ol> <li>Emergency Reverse was activated and concluded because the EMR Timeout timer has expired.</li> <li>The emergency reverse input is stuck On.</li> </ol>	Set: Emergency Reverse was activated and ran until the EMR Timeout timer expired. Clear: Turn the emergency reverse input Off.		
98	Illegal Model Number ShutdownMotor; ShutdownMainContactor; ShutdownEMBrake; ShutdownThrottle; FullBrake; ShutdownPump.	<ol> <li>Model_Number variable contains illegal value (not 1234, 1236, 1238, or 1298).</li> <li>Software and hardware do not match.</li> <li>Controller defective.</li> </ol>	Set: Illegal Model_Number variable; when KSI cycles, a check is made to confirm a legal Model_Number, and a fault is issued if one is not found.  Clear: Download appropriate software for your controller model.		

9


# **MAINTENANCE**

There are no user serviceable parts in Curtis 1234/36/38 controllers. **No attempt should be made to open, repair, or otherwise modify the controller.** Doing so may damage the controller and will void the warranty.

It is recommended that the controller and connections be kept clean and dry and that the controller's fault history file be checked and cleared periodically.

# **CLEANING**

Periodically cleaning the controller exterior will help protect it against corrosion and possible electrical control problems created by dirt, grime, and chemicals that are part of the operating environment and that normally exist in battery powered systems.



Use the following cleaning procedure for routine maintenance. Never use a high pressure washer to clean the controller.

- 1. Remove power by disconnecting the battery.
- Discharge the capacitors in the controller by connecting a load (such as a contactor coil) across the controller's B+ and Bterminals.
- 3. Remove any dirt or corrosion from the power and signal connector areas. The controller should be wiped clean with a moist rag. Dry it before reconnecting the battery.
- 4. Make sure the connections are tight. Refer to Section 2, page 5, for maximum tightening torque specifications for the battery and motor connections.

# **FAULT HISTORY**

The 1311 programmer can be used to access the controller's fault history file. The programmer will read out all the faults the controller has experienced since the last time the fault history file was cleared. Faults such as contactor faults may be the result of loose wires; contactor wiring should be carefully checked. Faults such as overtemperature may be caused by operator habits or by overloading.

After a problem has been diagnosed and corrected, it is a good idea to clear the fault history file. This allows the controller to accumulate a new file of faults. By checking the new fault history file at a later date, you can readily determine whether the problem was indeed fixed.



# **APPENDIX A**

## THEORY OF OPERATION

Curtis 1234/36/38 controllers convert DC battery power to 3-phase AC power by precisely controlling the induction drive for high bandwidth, high efficiency, and low ripple torque generation. To realize this level of precise torque control of induction motor drives in electric vehicles, Curtis engineers carefully evaluated and incorporated the latest technology in microprocessors, power electronics, and motor control.

Invented by Nikola Tesla in 1888, the induction motor became a workhorse that contributed to the vast industrial growth in the twentieth century. Until recently relegated to non-dynamic applications where transient response wasn't a critical concern, induction motors are now a common motor of choice in high performance control applications. This shift was facilitated by the enormous advancements in microprocessors and power silicon devices in the last twenty years, coupled with intense research and development.

The 3-phase induction motor has three sets of distributed windings in the stator winding slots. The standard induction motor has a rotor with aluminum bars short-circuited by cast aluminum end-rings. There are no brushes, commutators, or slip-rings, and—unlike DC and synchronous motors—there is no need for permanent magnets or a separate current supply for the rotor. The brushless construction of the induction motor and the rugged rotor provide high reliability, fault tolerance, low maintenance, and low cost.

Three-phase sinusoidal voltages, electrically displaced by 120°, are applied to the phase windings to create the stator magnetic field. The field rotates at the stator voltage frequency times the number of pole pairs. This rotating stator field induces currents in the conductive rotor bars by transformer action which, in turn, create a second rotor magnetic field. The rotor field reacts to the stator field to generate torque. The differential speed, or slip frequency, between the stator field and rotor speed is critical to the torque and speed control of an induction motor.

# **Motor Control Algorithms**

Two main approaches are commonly used for induction motor control: scalar control and vector control.


*Scalar control* (e.g., volts/Hz) modulates only the magnitude and frequency of the applied voltage or current. Although scalar control has the advantage of being simpler than vector control, it has poor dynamic response and lower operation efficiency. The various methods used to improve performance require extensive characterization of the motor and loads.

*Vector control* (e.g., indirect rotor flux orientation, stator flux orientation, etc.) manipulates the magnitude, frequency, and phase of the control variables

to provide better control. The mathematical model of an induction motor is complex. Using a series of reference frame transformations, vector control simplifies the model to enable precise control of torque and flux, similar to a SepEx motor controller.

Figure A-1 shows a typical diagram of indirect rotor flux orientation. The instantaneous 3-phase currents are transformed to the rotor flux reference frame, using rotor speed and slip frequency—which means that the motor currents are now observed from the viewpoint of rotating with the rotor flux. As a result of this transformation the currents, now in what is called the d/q reference frame, lose their sinusoidal nature and look like DC signals. In the d/q reference frame, q-axis current controls torque and d-axis current controls flux. If properly oriented, the torque and flux remain independent of each other, and the motor can achieve high efficiency and dynamic response.

**Fig. A-1** Diagram of Indirect Field Orientation (IFO) technique.




The controller uses an advanced pulse width modulation technique to maximize the utilization of battery voltage, minimize harmonic losses, and increase system efficiency. This method achieves 15% greater linear utilization of battery voltage, thereby effectively getting more usable motor power than standard PWM at the same battery voltage.

# **Power Section**

The power section efficiently generates high current 3-phase AC signals from the DC battery voltage to drive the AC motor as requested by the motor control algorithms.

The power section is implemented as three high frequency MOSFET half-bridge power stages controlled by three pulse width modulators, as shown in Figure A-2. Each half-bridge power stage is a parallel array of high-side and low-side power MOSFETs mounted to Insulated Metal Substrate (IMS) circuit board. This technology provides a very low thermal resistance to the heatsink and enables high power capability in a compact area.

**Fig. A-2** Power section topology.



Heavy busbars connect the IMS modules to the external motor connection studs. A bank of power capacitors keeps DC bus levels stable during high frequency MOSFET switching and also reduces EMI on the external B+ and B- cables.

Motor currents and motor speed and direction are the primary feedback signals used in the motor control algorithms. Accurate Hall sensors detect the motor currents; they do this by sensing the flux created by the motor currents on the U and V motor output busbars where they pass through the capacitor board on their way to the external motor connections. Motor speed and direction are simultaneously sensed by a quadrature-type speed encoder mounted on the motor shaft.

# **APPENDIX B**

# VEHICLE DESIGN CONSIDERATIONS REGARDING ELECTROMAGNETIC COMPATIBILITY (EMC) AND ELECTROSTATIC DISCHARGE (ESD)

# **ELECTROMAGNETIC COMPATIBILITY (EMC)**

Electromagnetic compatibility (EMC) encompasses two areas: emissions and immunity. *Emissions* are radio frequency (RF) energy generated by a product. This energy has the potential to interfere with communications systems such as radio, television, cellular phones, dispatching, aircraft, etc. *Immunity* is the ability of a product to operate normally in the presence of RF energy.

EMC is ultimately a system design issue. Part of the EMC performance is designed into or inherent in each component; another part is designed into or inherent in end product characteristics such as shielding, wiring, and layout; and, finally, a portion is a function of the interactions between all these parts. The design techniques presented below can enhance EMC performance in products that use Curtis motor controllers.

## **Emissions**

Signals with high frequency content can produce significant emissions if connected to a large enough radiating area (created by long wires spaced far apart). Contactor drivers and the motor drive output from Curtis controllers can contribute to RF emissions. Both types of output are pulse width modulated square waves with fast rise and fall times that are rich in harmonics. (Note: contactor drivers that are not modulated will not contribute to emissions.) The impact of these switching waveforms can be minimized by making the wires from the controller to the contactor or motor as short as possible and by placing the wires near each other (bundle contactor wires with Coil Return; bundle motor wires separately).

For applications requiring very low emissions, the solution may involve enclosing the controller, interconnect wires, contactors, and motor together in one shielded box. Emissions can also couple to battery supply leads and throttle circuit wires outside the box, so ferrite beads near the controller may also be required on these unshielded wires in some applications. It is best to keep the noisy signals as far as possible from sensitive wires.

# *Immunity*

Immunity to radiated electric fields can be improved either by reducing overall circuit sensitivity or by keeping undesired signals away from this circuitry. The controller circuitry itself cannot be made less sensitive, since it must accurately detect and process low level signals from sensors such as the throttle potentiometer. Thus immunity is generally achieved by preventing the external RF energy from coupling into sensitive circuitry. This RF energy can get into the controller circuitry via conducted paths and radiated paths.

Conducted paths are created by the wires connected to the controller. These wires act as antennas and the amount of RF energy coupled into them is generally proportional to their length. The RF voltages and currents induced in each wire are applied to the controller pin to which the wire is connected. Curtis controllers include bypass capacitors on the printed circuit board's throttle wires to reduce the impact of this RF energy on the internal circuitry. In some applications, additional filtering in the form of ferrite beads may also be required on various wires to achieve desired performance levels.

Radiated paths are created when the controller circuitry is immersed in an external field. This coupling can be reduced by placing the controller as far as possible from the noise source or by enclosing the controller in a metal box. Some Curtis controllers are enclosed by a heatsink that also provides shielding around the controller circuitry, while others are partially shielded or unshielded. In some applications, the vehicle designer will need to mount the controller within a shielded box on the end product. The box can be constructed of just about any metal, although steel and aluminum are most commonly used.

Most coated plastics do not provide good shielding because the coatings are not true metals, but rather a mixture of small metal particles in a non-conductive binder. These relatively isolated particles may appear to be good based on a dc resistance measurement but do not provide adequate electron mobility to yield good shielding effectiveness. Electroless plating of plastic will yield a true metal and can thus be effective as an RF shield, but it is usually more expensive than the coatings.

A contiguous metal enclosure without any holes or seams, known as a Faraday cage, provides the best shielding for the given material and frequency. When a hole or holes are added, RF currents flowing on the outside surface of the shield must take a longer path to get around the hole than if the surface was contiguous. As more "bending" is required of these currents, more energy is coupled to the inside surface, and thus the shielding effectiveness is reduced. The reduction in shielding is a function of the longest linear dimension of a hole rather than the area. This concept is often applied where ventilation is necessary, in which case many small holes are preferable to a few larger ones.

Applying this same concept to seams or joints between adjacent pieces or segments of a shielded enclosure, it is important to minimize the open length of these seams. Seam length is the distance between points where good ohmic contact is made. This contact can be provided by solder, welds, or pressure contact. If pressure contact is used, attention must be paid to the corrosion characteristics of the shield material and any corrosion-resistant processes applied to the base material. If the ohmic contact itself is not continuous, the shielding effectiveness can be maximized by making the joints between adjacent pieces overlapping rather than abutted.

The shielding effectiveness of an enclosure is further reduced when a wire passes through a hole in the enclosure; RF energy on the wire from an external field is re-radiated into the interior of the enclosure. This coupling mechanism can be reduced by filtering the wire where it passes through the shield boundary.

Given the safety considerations involved in connecting electrical components to the chassis or frame in battery powered vehicles, such filtering will usually consist of a series inductor (or ferrite bead) rather than a shunt capacitor. If a capacitor is used, it must have a voltage rating and leakage characteristics that will allow the end product to meet applicable safety regulations.

The B+ (and B-, if applicable) wires that supply power to a control panel should be bundled with the other control wires to the panel so that all these wires are routed together. If the wires to the control panel are routed separately, a larger loop area is formed. Larger loop areas produce more efficient antennas which will result in decreased immunity performance.

Keep all low power I/O separate from the motor and battery leads. When this is not possible, cross them at right angles.

# **ELECTROSTATIC DISCHARGE (ESD)**

Curtis motor controllers contain ESD-sensitive components, and it is therefore necessary to protect them from ESD (electrostatic discharge) damage. Most of these control lines have protection for moderate ESD events, but must be protected from damage if higher levels exist in a particular application.

ESD immunity is achieved either by providing sufficient distance between conductors and the ESD source so that a discharge will not occur, or by providing an intentional path for the discharge current such that the circuit is isolated from the electric and magnetic fields produced by the discharge. In general the guidelines presented above for increasing radiated immunity will also provide increased ESD immunity.

It is usually easier to prevent the discharge from occurring than to divert the current path. A fundamental technique for ESD prevention is to provide adequately thick insulation between all metal conductors and the outside environment so that the voltage gradient does not exceed the threshold required for a discharge to occur. If the current diversion approach is used, all exposed metal components must be grounded. The shielded enclosure, if properly grounded, can be used to divert the discharge current; it should be noted that the location of holes and seams can have a significant impact on ESD suppression. If the enclosure is not grounded, the path of the discharge current becomes more complex and less predictable, especially if holes and seams are involved. Some experimentation may be required to optimize the selection and placement of holes, wires, and grounding paths. Careful attention must be paid to the control panel design so that it can tolerate a static discharge.

MOV, transorbs, or other devices can be placed between B- and offending wires, plates, and touch points if ESD shock cannot be otherwise avoided.

# **APPENDIX C**


# **PROGRAMMERS**


Curtis programmers provide programming, diagnostic, and test capabilities for 1234/36/38 controllers. The power for operating the programmer is supplied by the host controller via a 4-pin connector. Two programmers are available: the PC Programming Station (1314) and the handheld programmer (1311). The Programming Station has features not available on the handheld unit; on the other hand, the handheld programmer has the advantage of being more portable. Typically the Programming Station is used to set up the parameters initially and the handheld programmer is used to made adjustments in the field.

Several versions of each programmer are available (User, Service, Dealer, OEM): the User programmers can adjust only User-access parameters, whereas the OEM programmers can adjust all the parameters.

# **HANDHELD PROGRAMMER (1311)**

The 1311 programmer is easy to use, with self-explanatory functions. After plugging in the programmer, wait a few seconds for it to boot up and gather





information from the controller. For experimenting with settings, the programmer can be left plugged in while the vehicle is driven.

The bookmark keys can make parameter adjustment more convenient. To set a bookmark, press one of the three bookmark keys for more than two seconds. To jump to a bookmarked location, press the appropriate bookmark key quickly (for less than two seconds). For example, in setting the drive forward throttle parameters, you might set a bookmark at the first of these parameters [Program » Throttle » Forward Offset] and another at the raw throttle readout [Monitor » Inputs » Throttle Pot]; this way you can easily toggle between the readout and the parameters.

The bookmark keys also have another function that makes programming easier. When setting the value of a parameter, you can use these keys to adjust the increments by which the value changes—with Bookmark Key 1, the value changes in 10-digit steps up or down; with Bookmark Key 2 pressed, the value changes in 100-digit steps; and with Bookmark Key 3, in 1000-digit steps—which, for most parameters, takes you from the maximum to the minimum, or vice versa.

# PC PROGRAMMING STATION (1314)

The Programming Station is an MS-Windows 32-bit application that runs on a standard Windows PC. It can do everything the handheld programmer can do, and more. Its additional capabilities include saving/restoring sets of parameters to/from disk and updating software. Instructions for using the Programming Station are included with the software.

# **PROGRAMMER MENUS**

The programmers have six menus, which in turn lead to nested submenus.

**Program** — provides access to the programmable parameters (see Section 3).

**Monitor** — presents real-time values during vehicle operation; these include all inputs and outputs, as well as the mapped throttle values and conditioned throttle requests (see Section 4a).

**Faults** — presents diagnostic information, and also a means to clear the fault history file (see Section 8).

**Functions** — provides access to the controller-cloning commands (see page 63) and to the "reset" command.

**Information** — displays data about the host controller: model and serial numbers, date of manufacture, hardware and software revisions, and itemization of other devices that may be associated with the controller's operation.

**Programmer Setup** — displays data about the programmer: model and serial numbers, and date of manufacture.

# APPENDIX D

## **SPECIFICATIONS**

#### Table D-1 SPECIFICATIONS: 1234/36/38 CONTROLLERS

Nominal input voltage 24V, 24-36V, 36-48V, 48-80V

PWM operating frequency 10 kHz
Maximum encoder frequency 15 kHz
Maximum controller output frequency 300 Hz

Electrical isolation to heatsink 500 V ac (minimum)

Storage ambient temperature range -40°C to 95°C (-40°F to 203°F)
Operating ambient temp. range -40°C to 50°C (-40°F to 122°F)
Internal heatsink operating temp. range -40°C to 95°C (-40°F to 203°F)

Heatsink overtemperature cutoff linear cutback starts at 85°C (185°F); complete cutoff at 95°C (203°F)

Heatsink undertemperature cutoff complete cutoff at -40°C (-40°F)

Package environmental rating IP65

Weight 1234: 2.84 kg (6.3 lbs); 1236: 4.12 kg (9.1 lbs); 1238: 6.82 kg (15.0 lbs)

Dimensions (W×L×H) 1234: 155 × 212 × 75 mm (6.1" × 8.3" × 3.0") 1236: 165 × 232 × 85 mm (6.5" × 9.1" × 3.4") 1238: 275 × 232 × 85 mm (10.8" × 9.1" × 3.4")

EMC Designed to the requirements of EN12895
Safety Designed to the requirements of EN1175
UL UL recognized component per UL583

Note: Regulatory compliance of the complete vehicle system with the controller installed is the responsibility of the OEM.

MODEL NUMBER	NOMINAL BATTERY VOLTAGE (volts)	CURRENT LIMIT (amps)	2 MIN RATING (amps)	1 HOUR RATING (amps)	
1234-227X -237X	24 24	200 350	200 300	<i>TBD</i> 170	
-527X	36–48	275	250	120	
1236-44XX -45XX	24–36 24–36	400 500	400 500	155 180	
-53XX	36–48	350	350	140	
-63XX	48-80	300	300	100	
1238-46XX	24–36	650	650	265	
-54XX -56XX	36–48 36–48	450 650	450 650	210 210	
-65XX	48–80	550	550	155	

Notes: All current ratings are rms values per motor phase. Internal algorithms automatically reduce maximum current limit when heatsink temperature is >85°C or battery voltage is outside the allowed limits. Heatsink temperature is measured internally near the power MOSFETs.

2-minute ratings are based on an initial controller heatsink temperature of 25°C and a maximum heatsink temperature of 85°C. No additional external heatsink is used for the 2-minute rating test.

<u>1-hour ratings</u> are based on an ambient temperature of  $25^{\circ}$ C with the controller mounted to a heatsink with a thermal resistance of  $0.35^{\circ}$ C/W for the 1236, or  $0.25^{\circ}$ C/W for the 1238, operating at a maximum baseplate temperature of  $85^{\circ}$ C. These thermal resistances are approximately equivalent to a  $0.5m \times 0.5m \times 8mm$  thick vertical steel plate in free air with 6kph airflow on one side.