

# DALMIA CEMENT (B) LIMITED – CEMENT PLANT ARIYALUR

## **ELECTRICAL MANUAL**

Issue No:02 Rev. No: 00 Effective Date: 01.11.2019 SOP/Elect /056

Issued By: Approved By: HOD - ELECTRICAL

**SOP For SEPAM RELAY SETTING CHANGE** 

Scope : This Procedure to establish and ensure safe method of SEPAM RELAY SETTING

CHANGE.

**Responsibility** : Section Engineer/Shift Engineer – Electrical

**Accountability** : Section Head-Electrical

PPE:

1. Safety shoes

2. Safety helmet

3. Rubber Gloves

#### **Tools:**

1. Laptop with Communication cables

#### **Hazard Analysis:**

Risks associated Mitigating Measures

Injury Use of proper Handling tools Electric shock Use of Proper Isolating tools

### **Training needs:**

- 1. Emergency preparedness
- 2. First aid training
- 3. SEPAM SETTING Knowledge

#### **Procedure:**

- 1. Take Electrical Work permit for SEPAM relay setting upload and download.
- 2. Switch OFF the Power Supply (ACB or SFU) and if ACB then Rack out with proper Rubber gloves.
- 3. Plug the Laptop Communication cable connector in SEPAM Relay communication port.



SF2841 software.

# DALMIA CEMENT (B) LIMITED - CEMENT PLANT ARIYALUR

## **ELECTRICAL MANUAL**

**Rev. No: 00** SOP/Elect /056 **Issue No:02 Effective Date: 01.11.2019 Approved By: HOD - ELECTRICAL Issued By:** 

**SOP For SEPAM RELAY SETTING CHANGE** 

4. Communicate the SEPAM relay trough Laptop by selecting "connect to front face" Icon in

- 5. Click the "Protections" option to set the setting parameters
- 6. Click the "50/51-1" option and set the required vales in Setting Group A, Setting Group B for Phase Overcurrent (1).
- 7. Click the "50/51-2" option and set the required vales in Setting Group A, Setting Group B for Phase Overcurrent (2).
- 8. Click the "50N/51N-1" option and set the required vales in Setting Group A, Setting Group B for Earth Fault (1).
- 9. Click the "50N/51N-2" option and set the required vales in Setting Group A, Setting Group B for Earth Fault (2).
- 10. Click the "46" option and set the required vales for Negative sequence current/unbalance Protection.
- 11. If require Recloser operation then Click the "79" option and set required values.
- 12. Upload the setting to SEPAM relay
- 13. Unplug the Laptop Communication cable connector in SEPAM Relay communication port
- 14. Cross check the SEPAM Relay setting by manually.
- 15. Rack in the ACB with proper Rubber gloves.
- 16. Switch ON the power Supply (ACB or SFU).

## **Emergency / Emergency Shut OFF:**

1. If electrical shock injury or body injury is there, give First aid and inform to the Safety department or Call Emergency number 3108/9865152222/9750963761.

#### **Records/Annexure:**

1. JSA as enclosed below.

**JOB SAFETY ANALYSIS: (JSA)** 



# DALMIA CEMENT (B) LIMITED - CEMENT PLANT ARIYALUR

# **ELECTRICAL MANUAL**

Issue No:02Rev. No: 00Effective Date: 01.11.2019SOP/Elect /056Issued By:Approved By: HOD - ELECTRICAL

# **SOP For SEPAM RELAY SETTING CHANGE**

Job Safety Analysis	Job: Sepam relay setting upload and download	Date:	Analysis by:	Reviewed by:
Title of employee doing job: Engineer	Supervisor: Section Engineer/ Shift Engineer	Department: Electrical	Section: Plant	Approved by:
Reqd./recommended PPE: Safety helmet, Safety shoe, Rubber Gloves.				
Requi, recommended 112	. Salety Heililet, Salety Silve	e, Rubbei Gioves.		
Sequence of Basic Job Steps	Potential Hazards	Recommended Safe Job Procedure	What Could Go Wrong	Corrective Action