

AspeQt-2k26

Atari Serial Peripheral Emulator / Qt6 Edition

[Introduction](#) [Requirements](#) [Configuration](#) [Networking](#) [Usage](#)

AspeQt-2k26 is a modernized, cross-platform emulator that bridges your Atari 8-bit computer to modern PC storage and networking via a standard SIO2PC cable.

This edition has been rebuilt on the **Qt6 framework** to ensure crisp rendering on High-DPI displays and stability on modern operating systems (Windows 11, macOS, Linux).

New in 2k26

- **TNFS Client:** Integrated support for mounting images directly from the internet.
- **Y: Clipboard Device:** Bi-directional text sharing between PC and Atari.
- **Qt6 Interface:** Native drag-and-drop and high-resolution font scaling.

System Requirements

Requires a modern 64-bit operating system. An Atari 8-bit computer and an SIO2PC interface are required for operation.

Hardware Note: We strongly recommend USB adapters based on the **FTDI chipset**. Prolific or generic chipsets often exhibit timing drift at high speeds (Divisor 0-8).

Configuration

Access the main settings via **Tools > Options**.

Serial Connection

Windows: Select your COM port (e.g., COM3).

Linux: Select your device node (e.g., /dev/ttyUSB0).

High Speed SIO

- **Divisor 40 (1x):** Standard 19200 bps.
- **Divisor 16 (2x):** Safe for most cables.
- **Divisor 8 (3x):** Recommended for FTDI cables.
- **Divisor 0 (6x):** Requires the `hisio` OS patch on the Atari.

Networking & Integration

TNFS Client

The TNFS client allows you to mount disk images hosted on remote servers (compatible with FujiNet) directly into a drive slot without downloading them first.

- **Setup:** Go to **Tools > Network** and enter the TNFS Server Address.
- **Usage:** Open the TNFS Browser, navigate the remote folders, and drag an `.atr` file to any drive slot.

Y: Clipboard Device

The `Y:` device acts as a bridge between the host PC's clipboard and the Atari.

- **Read from PC:** Copy text on your PC. On the Atari, type `COPY "Y:" "E:"` to paste it.
- **Write to PC:** Print to the `Y:` device from Atari (e.g., `LIST "Y:"`) to copy text to your PC clipboard.

Usage

Virtual DOS (Folder Images)

You can mount a local PC directory as a writable disk. To boot from a folder, right-click the slot and select **Folder Boot Options**.

Supported DOS types for booting:

- Atari DOS 2.5
- MyDOS 4.5
- SpartaDOS 3.2G (Limited)

Running Executables

Drag `.xex` or `.com` files directly to a slot. AspeQt uses a high-speed internal loader to run these files without requiring a DOS disk.

Printer Emulation

Output sent to `P1:` is captured by AspeQt. View the output via **File > View Printer Output**. The viewer automatically handles ATASCII-to-ASCII translation.