Reading Input Register	시스템 동작 파라미터를 나타낸다.
------------------------	--------------------

Decimal Address	High Byte	Master Action	
30001	Operatir	Read Only	
30002	Operatir	Read Only	
30003	Sensing	g Status	Read Only
30004	Error	Status	Read Only
30005	Current Time (TI	Read Only	
30006	Current Date (Date	Read Only	
30007	Time (TIMEPACK16, Tim	Read Only	
30008	Time (TIMEPACK16, Tim	Read Only	
30009	On Interva(Minut	Read Only	
30010	Off Interval(Minu	Read Only	
30011	Pump Action	Read Only	
30012	Operatin	Read Only	
30013	On State Interval Time Le	Read Only	
30014	Off State Interval Time Le	Read Only	

Read/Write Holding Register	시스템 동작 상태를 제어한다.

Decimal Address	High Byte	Master Action	
40001	Operatir	Read/Write	
40002	Manual	Read/Write	
40003		-	-
40004		-	
40005	Set Time (TIM	Read/Write	
40006	Set Date (DAT	Read/Write	
40007	Set Time (TIMEPACK16, T	Read/Write	
40008	Set Time (TIMEPACK16, T	Read/Write	
40009	Set On Interval(Mir	Read/Write	
40010	Set Off Interval(Mir	Read/Write	
40011	Pump Action	Read/Write	
40012	Operatin	Read/Write	
40013		Read/Write	
40014		Read/Write	

## Read/Write Holding Register

- Holding Register의 변화는 100ms마다 체크된다. Holding Register에 저장된 데이터는 Slave Device에서 처리가 완료되면 0으로 클리어된다.
- Holding Register가 0일 경우에는 동작을 수행하지 않는다.

## Operating Mode

- Operating Mode는 현재의 스케쥴링 동작 모드를 나타낸다
- Manual, Timer, Interval 모드의 조합에 의해 다음과 같은 동작이 가능하다.
- Timer Mode(0x01): Timer On 시간에 플라즈마 작동, Off 시간에 플라즈마 정지 Interval Mode(0x02): Interval On 시간에 플라즈마 작동, Off 시간에 플라즈마 정지
- Timer + Interval Mode (0x03): Timer On 과 Interval On 이 동시 만족시 작동,
- Manual Mode(0x04): Plasma On/Off 명령에 의해서만 플라즈마 동작

	300	01	현재 동작 모드 표시												
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
1	ı		ı	ı	ı	ı	ı	ı	ı	1	ı	1	0	peratii Mode	ng
	300	002						현재	동작 선	상태값	표시		•		
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
1	ı		ı	ı	ı	ı	ı	ı	ı	1	ı	1	Pump State	Fan State	Plasma State
	300	003					현지	내 센서	검출	상태를	나타	낸다			•
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
1	ı		ı	ı	1		ı	ı	ı	1	ı	Input Level Sensing 2	Input Level Sensing 1	Water Level Sensing 2	Water Level Sensing 1
	300	04			현재 에러 상태를 나타낸다										
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
1	ı	ı	ı	ı	ı	ı	ı	ı	ı	1	ı	1	1	EEPROM	RTC
	300						현지			상태를	나타	낸다			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
1	ı	ı	ı	ı	ı	ı	ı	ı	ı	1	ı	1	1	ı	Fan Control Option

		400	02			현재	수동 등	동작 모	느드에서	성 동작	제어를	를 위한	명령을	을 전달	한다.	
1:	5 1	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
le I	Reboot	1	1	1	1	1	1	1	1	1	Pump On	Pump Off	Fan On	Fan Off	Plasma On	Plasma Off

- Manual Mode에서만 수행할 수 있음
- 해당 비트가 1일 경우에만 기능 수행 ON과 OFF가 동시에 1일 경우 OFF만 수행

	400	)12					ţ	현재 동	작 옵션	년을 설	정한디	<b>ŀ</b> .			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
ı	1	ı	1	1	1	ı	ı	ı	I	1	ı	ı	1	Fan Control OFF & Always Fan On	Fan Control On

영구 동작 옵션을 설정한다.

DATEPACK16(a,b,c)	(((uint16_t)a << 9)   ((uint16_t)b << 5)   ((uint16_t)c)) a : 년(2022일 경우 22만 기입), b : 월(1~12), c : 일(1~31)
TIMEPACK16(a,b,c)	(((uint16_t)a << 11)   ((uint16_t)b << 5)   ((uint16_t)c >> 1)) a : 시, b : 분, c : 초