HomeHackery
Because "Stock" is Boring

NBC Holiday Countdown Display

Quick Setup & User Guide

1. Power Up Your Display

Connect the USB power cable to the display and plug it into a USB power adapter.

The display will briefly flash when power is connected, then remains blank while it connects to Wi-Fi and obtains the current time.

Once the display has successfully connected to Wi-Fi and synchronized its time, the countdown will appear.

2. Connect the Display to Your Wi-Fi

1. On your phone, tablet, or computer, connect to the Wi-Fi called **NBC-Countdown-Setup** with Password: **countdown123**.
2. Your device may show **"No Internet Connection."** This is normal.
3. The **NBC-Countdown-Setup** page should open automatically. If it does not, open a web browser and go to **192.168.4.1**.
4. Select **Configure Wi-Fi**.
5. Select your home's **2.4 GHz Wi-Fi network** from the list.
6. Enter your Wi-Fi password and select **Save**.
7. The display will connect to your Wi-Fi and synchronize its time.
8. Once connected, the countdown will appear on the display.

3. Open the Display's Control Page

Once the display is connected to your Wi-Fi, you can access its control page from any device connected to the same Wi-Fi network.

Open a web browser and enter: **http://nbcholidaycountdown.local/**

The **NBC Holiday Countdown** control page will open. From this page, you can view the display's status and change its settings.

4. Select Which Holiday is Displayed

From the NBC **Holiday Countdown** control page, find **Countdown Holiday** and choose which holiday you want illuminated:

Halloween	Halloween countdown
Christmas	Christmas countdown

Select your preferred option.

5. Set Your Time Zone

1. On the control page, find **Time Zone**.
2. Select your local time zone from the list.
3. Select **Save Settings**.

The display will use this time zone for its clock and countdown calculations.

6. Customize Background Lighting

The Background Lighting controls let you customize the color and brightness of the LEDs behind the display.

1. On the control page, find Background Lighting.
2. Select the color picker to open your device's color selection dialog, then choose your preferred color and confirm your selection.
3. Use the Brightness slider to adjust the LED brightness from 0% (off) to 100% (full brightness).
4. The background LEDs will preview your selected color and brightness.
5. Select Save Settings to save your color and brightness choices.

7. Firmware Updates

The latest firmware and project information are available on the **HomeHackery GitHub project page**.

If you experience a problem with the display, check the GitHub page for the latest information and available updates. Help is also available through the project information there.

Firmware update instructions are provided separately with each update.

8. Moving the Display or Changing Wi-Fi Networks

If you move the display to a different location or change your home Wi-Fi network, the display will automatically enter **Wi-Fi Setup Mode** if it cannot connect to the saved network.

Simply **repeat Step 2: Connect the Display to Your Wi-Fi** and select your new Wi-Fi network.

Once the new Wi-Fi information has been saved, the display will automatically connect and resume normal operation.

> **Important:** If Wi-Fi temporarily goes offline while the display is already running, the countdown will continue. If the display loses power while Wi-Fi is unavailable, the countdown will remain blank until Wi-Fi is restored and the display can synchronize its time.

Project & Support

HomeHackery GitHub Project: **GitHub Project**

HomeHackery on YouTube: **@TheHomeHackery**

Support: **HomeHackery1@gmail.com**

Thank you for supporting HomeHackery!

Because "Stock" is Boring.

Document Revision: 1.0
Last Updated: November 8, 2026