
UTILITY GUIDE



MEMORY EXPANSION



STEP 1 (SETUP)

- Insert SD card into Arduino and make sure it is FAT32 formatted already.
- Ssh into Arduino and check where device is mounted i.e. /dev/sda1
- Unplug SD card and run

```
ls -1 /dev/
```

• Plug SD card and run same shell command again and see what id has been assigned to SD card i.e. /dev/sdax (here x is id assigned to SD card)

STEP 2 (MAKE CHANGES)

- Open YunDiskSpaceExpander.ino in zip archive inside SDK
- Make sure inside function haltIfSDCardIsNotPresent(), it is checking for the same device id in second statement

```
int exitCode = ls.runShellCommand("ls /mnt/sdaX");
```

• Upload the sketch into Arduino

STEP 3 (FOLLOW STEPS IN SERIAL MONITOR)

Follow the steps in serial monitor (make sure its selected NewLine in serial monitor input specification). Partition your card accordingly.



