

AUTHOR  
PANEL ID  
FIRMWARE  
PREFERRED

01 PLAY

SWIPE ≥ 3 PADS  
PRESSURE VELO + ENERGY  
SWIPE AGAIN RE-LAUNCH  
DOUBLE-TAP CLEAR

02 SWING RATE

TIME SWIPE SPEED (DEFAULT)  
DIST REACH FROM LAUNCH EDGE  
0 8 PADS = FASTEST MIRRORED ...

03 SETTINGS

KEY C - B  
SCALE 12 SCALES  
OCTAVE -2 ... +2  
DAMPING 0 ... 8 · 0 = ∞  
RATE SOURCE TIME / DIST

DEFAULTS: OCTAVE 0 · DAMPING 3 · TIME

04 PAGES

0 PLAY PENDULUM GRID  
1 SOUND PRESET · XY  
2 SAVE/LOAD SONGS

05 SCALES

|        |         |        |
|--------|---------|--------|
| CHROM  | MAJOR   | MINOR  |
| DORIAN | PHRYG   | LYDIAN |
| MIXO   | LOCRIAN | H.MIN  |
| P.MAJ  | P.MIN   | BLUES  |

SETTINGS SAVE GLOBALLY.  
SOUND + MIX PRESET TRAVEL WITH THE SONG.



//:001 PLINKY 12

01 ■  
ROW = PITCH  
TOP = HIGHEST NOTE

02 ■  
ARMED  
WAITS FOR THE CLOCK

03 ■  
LEFT WALL  
PLAYS ROOT NOTE

04 ■  
DOUBLE-TAP  
CLEARS THE LANE

05

RIGHT WALL  
IN-KEY FIFTH

06

PENDULUM  
DECAYS PER HIT

07

SWIPE  
WALL + DIRECTION



16 PENDULUM LANES.  
SWIPE TO LAUNCH.  
WALL HIT = NOTE.



# PENDULUM