Foil Studio user manual

English · Updated 7 November 2026 · Version 0.1.127 (148)

Full documentation and current versions: github.com/plotter-doctor/Foil-Studio

Versions covered

This manual covers 0.1.127 (148). Check the version guide for Google Play submission, approval and rollout status, and check the version installed on your device. Earlier versioned release records retain their original context.

First project

1. In Design, choose Project to New and draw a small rectangle, or open an example from Help and examples. A new project's Default layer starts with the current material; Vinyl is the initial default.
2. Open Edit to Layers to Edit layer to check or change that layer's material. Objects inherit their layer's stock. Position the artwork on the mat and keep an exported backup of important work.
3. In Prepare, check Material, Cutting mat and the exact plotter model. Expand a card for its options. Production preview opens layout and Prepare jobs directly.
4. Open Connection setup. Use demo mode to practise without hardware, or explicitly connect your compatible plotter.
5. Choose Review job. Included cutting artwork needs an assigned layer material; otherwise a warning offers Layers and keeps you in Prepare. For a project with production jobs, choose the intended Job in Cut and review it after confirming its installed stock.
6. Inspect the large job preview. Edit tools and pass counts in Object properties or Tool library. Check the physical mat alignment before confirming it.
7. Start the job and follow the tool-installation prompts. Supervise the machine until completion.

Use a small test piece when choosing pressure, speed, blade depth or pass count. Pressure units and supported settings depend on the plotter. A material record describes stock and thickness. Choose the tool/process settings explicitly and test them on your actual stock.

Design and selection

Tap artwork to select it. Use the selection controls to add or remove objects; drag from unused space for an area selection. Two fingers pan and zoom the view. Undo and Redo let you inspect a change and return to the earlier design.

Create shapes, outlined text, clipart and freehand paths using the design tools. Numeric dimensions and transforms provide precise placement. Alignment and distribution compare selected objects; layout tools can repeat artwork or fill a sheet. Review their preview before applying it.

Object properties hold the tool and process settings that determine production. Tools can include knife, pen, scoring, engraving and Printer, where supported. Printer artwork is for printed output rather than blade motion. Colours identify artwork visually; changing a colour alone does not choose pressure or tool type.

Objects keep the tool snapshot assigned to them. Editing a library record does not rewrite existing objects. To use the edited record, select it again in Object properties; Current object tool identifies a stored snapshot when it shares a name with an updated library record.

Path editing, offsets and Boolean operations require suitable geometry. Closed contours, holes, open strokes and very small details behave differently. Inspect generated contours after union, subtraction, offsets, tracing or simplification. The weeding tools add waste-removal paths, so include them in the preview check.

Box and Craft wizards create editable projects with fold/cut operations. Preserve the wizard's generated object relationships when regenerating. Test fit with your actual material thickness. Pro is required for wizard creation and regeneration; already-open artwork remains subject to the normal editing and output access rules.

Layers materials and production jobs

Layers organize artwork and hold material assignments. Open Edit to Layers to Edit layer to Material. A material is a stock preset from the Materials library; a layer is an artwork group. Objects inherit the material of their layer, and moving an object to another layer gives it the destination layer's material. To use different stock for part of a design, place those objects on a separate layer. Object properties retains tools and process settings, rather than a second material override.

New projects put the current material on Default. New layers and editable imports use the current material where a new layer is needed. An explicitly cleared material remains unassigned; opening an existing project does not guess its stock. If an older project's layers show No material, assign them through Edit layer before reviewing cutting artwork.

A production job describes the artwork prepared on one sheet or material placement. It can include more than one design layer and more than one tool. Separate jobs do not merge just because their colours or materials match. Review layer stock and job membership together when preparing a multilayer sticker.

Material records contain stock identity, thickness and notes. Assigning a material does not replace an object's independently selected tool, pressure, speed or pass count. Stored material snapshots remain distinguishable from edited same-name library records.

Layer inclusion and visibility affect production eligibility. Excluded or print-only artwork does not become a cut merely because it belongs to a job. Review again after changing membership, tools, geometry or settings.

On a tablet or wide screen, the Design inspector shows a layer/object tree. Expand a layer to find its objects. Layer and object menus open their properties; Add layer creates a group, and Move to layer changes membership. Hold an object name and drag it onto the destination layer, or use the explicit move action. Undo and Redo retain the normal editing workflow.

Prepare jobs and assembly marks

Open Production preview to Prepare jobs to inspect the short job list and assembly-mark settings. Each row has Details for the longer settings, assignments, order and placement. Set the artwork stock in Edit layer. Use Preview jobs to inspect the result, then Save jobs to retain the configuration. A preview does not confirm installed material or start a machine.

Assembly marks are auxiliary cut squares repeated on the material jobs. Use them to align separately cut pieces during assembly. They are distinct from optical or manual Print & Cut registration marks. Leave sufficient sheet clearance for artwork and marks; an outside-sheet warning must be resolved before production.

Assembly order describes how pieces are combined. Cut order controls preparation order. Sheet translation moves a job on the cutting sheet; the saved inverse translation relates it back to the assembly position. Review copies, weeding paths and marks together.

For heat-transfer vinyl, enable HTV and explicitly confirm the mirrored orientation. Check the intended face and final assembly before cutting. Mirroring is part of production preparation rather than a reason to alter the original artwork permanently.

Choose and run a job in Cut

For a project with production jobs, Cut keeps the Job selector, the material name and a large preview visible. Choosing a job immediately filters the preview to its artwork and assembly marks. This preview choice does not confirm that its stock is installed and does not start motion.

Load the intended stock and choose Review job. Check the material confirmation in the dialog; HTV also requires the orientation confirmation. The app then prepares the selected job. If cutting artwork lacks a layer material, assign it through Layers first; selecting a job alone cannot bypass this check. Another unassigned job does not block a valid selected cutting job.

Changing jobs clears the previous review and mat-alignment acknowledgement. Editing or reopening a project requires fresh preparation. If an assignment or placement is invalid, open Prepare jobs, correct it and review again. Saving job settings or opening a preview does not authorize an old job to run.

Change tools, pressure, speed and pass counts in Object properties or Tool library. The main Cut view does not repeat blade settings or an Operations and settings summary. Device-specific options remain under Advanced settings where supported. The former Tool passes dropdown has been removed; it did not select execution scope.

A physical start requires the supported connection, current review and machine-specific checks. Fit and secure the requested tool before confirming its start prompt. Follow later tool-change prompts only after motion has stopped. Keep access to the machine's physical stop control.

Pause, resume, stop and recovery availability depend on the protocol and machine state. A lost connection or uncertain completion requires inspection and recovery; do not assume that a sent command proves the cut finished. Keep the application foregrounded during production.

Drag knife compensation and overcut

Enable Knife compensation in the knife tool's advanced settings to use its offset and overcut. Offset is the distance between the holder's swivel axis and the blade tip, in millimetres. The blade's physical angle identifies the fitted blade; it does not change this compensation geometry or act as a kerf offset.

Overcut follows the beginning of a closed contour again to finish its closure seam. It is ignored for open paths. Offset and overcut remain stored when compensation is disabled, and apply when it is enabled again. Review the complete compensated motion bounds, including clearance outside the original artwork.

Use Calibrate knife in Tool library to compare offset samples, fix the best offset and then compare overcut. A selected job or a design with one material supplies its actual stock. For mixed or unassigned stock, choose a material before creating the trial; Cancel leaves the source project unchanged. That choice does not rewrite the source layer or default material. Check the final square, triangle and circle. Keep the fitted blade, force, speed and stock unchanged during a comparison, and use a fresh uncut area for every trial. Choose the smallest overcut that closes the shape cleanly. Software and simulator checks do not measure physical cut quality.

New calibration sheets include separate orientation strokes before each contour and pass. Leave their fresh trial area clear and review the complete sheet before cutting. New compensated production paths account for every nonzero turn, including shallow corners. Previously saved calibration sheets retain their geometry; regenerate a trial to use the current pattern.

Offsets and overcuts smaller than the selected machine’s coordinate step may produce identical moves. Coarse device grids and uncertain starting blade orientation can limit the result. Choose calibration settings at a meaningful scale and test the fitted blade on the actual stock; no uniform physical accuracy is promised.

Import artwork

Input	Available result	What to check
Foil Studio project	Editable project with saved settings and assignments	Version, mat and included objects
SVG	Supported original editable paths, solid colours and named layers, or print rendering	Units, holes, gradients, text and unsupported effects
DXF	Supported editable entities with source layers, RGB colours and an indexed palette	Units, source visibility and unsupported entities
PDF and compatible AI	Eligible original editable paths or rendered page for printing	Page selection, text, clipping and gradients
EPS and PostScript-compatible AI	Eligible original paths or print rendering	Fonts, unsupported operations and page geometry
CDR	Eligible editable curves or print rendering	Supported document content and page selection
PNG JPEG WebP GIF BMP ICO TIFF	Printable image or contrast tracing	Transparency, orientation, resolution and first frame
PSD	Merged printable image or supported aligned pixel layers	Layer effects, masks and compositing support

Use Editable cut paths when the entire selected drawing can be preserved. Unsupported content can make this option unavailable. When the preview can be rendered, Render for printing keeps its appearance as printer artwork. A rendered image does not contain original editable vector contours.

Insert for printing preserves image colour and transparency. Use Trace instead to create paths from image contrast. Review smoothing, threshold, holes and small details before inserting traced geometry. Separate colors is no longer offered. Existing projects containing coloured paths remain editable.

Animated GIF and multipage TIFF imports use the first frame or page. PDF/drawing page selection is a separate import option. HEIC and AVIF depend on the Android device codec. If decoding is unavailable, export a supported image format. File extensions alone do not establish supported content.

Placement lets you retain original coordinates or fit artwork to the selected area. Verify scale against a known dimension. A source document never chooses arbitrary machine commands or overrides the selected app tool preset.

Printing stickers and registration

Printer objects retain appearance for printing. Cutting contours must be explicitly provided or created; an image's white region does not automatically identify a removable background. Sticker offsets are cutting margins, not white ink.

Prepare the sheet at actual size and verify printer margins. Print the artwork and registration marks at 100 percent scale. Manual Print & Cut uses the supported four-mark workflow for FilmCut, Smart and the included Silhouette/Craft Robo profiles. Optical registration, AutoBlade and available tool stages depend on the exact model.

Use the app's registration workflow for the current sheet. Changing artwork, job, tool settings or the printed sheet invalidates earlier approvals. Assembly marks used for layered vinyl do not substitute for these registration checks.

Plotters and connections

Select the exact vendor and model in Connection. The catalogue includes FilmCut/GRBL, supported Silhouette and VEVOR Smart devices, and named Graphtec, Roland, Summa, Skycut, USCutter, Teneth and HP profiles. The selected profile determines the protocol, connection types, work area and available operations. A catalogue entry or simulator test is not physical qualification of every model and firmware.

Bluetooth Classic serial, supported USB serial adapters, bidirectional USB printer interfaces, BLE and TCP are available only where the selected profile supports them. A BLE device cannot be used as Bluetooth Classic serial. Approve the Android permission for the selected device. Use a data-capable cable and a suitable phone adapter.

TCP endpoints must match the actual controller or transparent bridge. Use a trusted local network; TCP controller connections are not authenticated or encrypted. A local hostname may require a working local resolver. Bluetooth discovery on older Android versions can depend on Android location-related permission settings.

Load and unload actions are model/firmware dependent. Some machines require panel operations or explicit completion confirmation. On VEVOR Smart, manual Tool up includes a short left-and-return carriage movement; clear the area before using it. The manual pressure control uses its displayed range, independently of object cutting settings. Check the material position and working origin before alignment confirmation. Do not infer motion completion solely from a connection or command acknowledgement.

Practise without a machine

Open Prepare, Connection setup and Start demo mode for the supported virtual workflow. The DEMO banner identifies it. Practise review, alignment confirmation, progress and tool prompts using independent sample artwork. Exit demo mode before explicitly connecting real hardware.

Demo mode and the external development plotter simulator serve different purposes. Demo is an in-app learning mode. External simulator tests check generated wire commands and state handling against protocol contracts. Neither measures cutting quality, real force, blade exposure or mechanical accuracy.

Projects languages and purchases

The app checkpoints the active project on this device when you edit, open a project or send the app to the background. Returning normally keeps the current design. If Android restarts the app, it restores the saved active artwork and its local-library identity, including changes checkpointed before the ordinary autosave delay. An explicit New establishes a blank active project. Prepared plans, installed-stock confirmations and mat alignment are not restored: review and confirm them again.

Basic and Pro save named projects in the private local library. Free can recover the active design without creating a named library save. Keep exported backups of important work; app-local recovery is not a cloud backup. Import/export can use Android's document picker and any installed document provider. Clearing app data or uninstalling can remove private projects, settings and recovery files.

The earlier app did not record the last-active project. After updating from it, open the desired saved project once to establish the active document. Existing library content remains available. Artwork restoration is separate from canvas pan/zoom and other transient view state. A corrupt session is preserved with a visible warning; starting a new project explicitly replaces that session slot.

Choose English, Polish, German or Spanish from Language, or follow the device language. Shared help and examples follow the interface language. User text, filenames and serialized project identifiers retain their original content.

The app is free to install. Free supports design/editing and previews. Basic is a permanent one-time purchase for named saves, export, printing and production. Optional monthly/yearly Pro includes Basic while active and adds Box/Craft wizard creation and regeneration. Restore purchases using the same Google Play account. Prices shown by Google Play depend on your account and region.

Earlier paid-download buyers can contact pratanczuk@gmail.com privately with the original Google Play app-order number to request the documented Basic migration. This is not a repeat purchase after each update. Do not post order details publicly.

Troubleshooting and support

Problem	Check
Start is disabled	Connection, controller state, selected job, material confirmation, review, entitlement and alignment
Review warns that material is missing	Open Layers to Edit layer to Material for the included cutting artwork; older or explicitly cleared assignments are not guessed
App returned to an empty workspace	In 0.1.127, open the intended saved project once after upgrading; active-project restoration applies to subsequent sessions. Check any recovery warning before starting New
Job or assembly mark is outside the sheet	Mat dimensions, marks, translation, copies and production layout
Editable import is unavailable	Use supported original content or Render for printing; inspect the reported limitation
Bluetooth or USB device is missing	Exact model, supported transport, permissions and cable/adapter
Command was sent but completion is uncertain	Inspect the machine and use its recovery/completion workflow
Review expires	Prepare and review again after changing source, settings, connection or job
Printed artwork does not align	Actual print scale, margins, sheet identity and current registration

Contact pratanczuk@gmail.com, or report a reproducible technical issue in GitHub Issues. Include app/Android version, plotter model/firmware, connection type and a small non-sensitive example. Public issues should not contain personal projects, purchase details or network credentials.