



0. Disconnect Arduino from USB
1. Make connections as on this diagram.
3. Install "RTClib" by Adafruit
4. Install "TM1637" by Avishay Orpaz
6. Make new sketch, copy the clock.ino code in to it.
7. Load and run.

