



1. Wire up OLED display. Do not forget power pins (not drawn)
2. Wire up the keypad
3. Open the code from present_4 and follow "How to change resolution"
4. Load and run oled_kepad_haptic.ino
You should see key numbers on the OLED
5. Can you figure out how to add a feedback using your vibrating motor?
6. Can you improve the feedback?
7. Wire up distance sensor.
8. Load and run oled_distance.ino

