Product Care Guide

Cleaning Your Tent

Clean your tent with lukewarm water and a soft sponge. Never use detergent, bleach, or a washing machine because these strip the waterproof coating. Allow the tent to dry completely before storing it to prevent mildew.

Re-waterproofing

Re-apply a seam sealer every 2 years or after heavy use. Spray-on waterproofing treatments should be applied outdoors in a ventilated area and allowed to cure for 24 hours.

Product Care Guide

Caring for Sleeping Bags

Wash down sleeping bags in a front-loading machine using a down-specific cleaner on a gentle cycle. Tumble dry on low heat with two clean tennis balls to restore loft. Store the bag loosely in the large cotton sack, never compressed.

Boot Maintenance

Brush off dirt after every hike and condition leather boots with wax every 3 months. Remove insoles and let boots air dry away from direct heat, since heat can crack leather and weaken adhesives.