


VO launch pad skirt Manual


BOM 48~52 2x10 self tapping screw(Number required depends on configuration)

- Can be installed on V0.0~V0.2r1
(V0.2r1 filament sensor is not supported. Can be installed without bottom panel.)
- Can choose where (or not) to mount display. Assembly drawings for each mounting location are identified by colored frames.
Center display 
Left display 
Right display 
No display 
- All parts are printable in V0. There is also an STL with an undivided skirt for larger size printers.
- STL is produced in sizes designed for ABS/ASA shrinkage, which can cause problems when printed on PLA.



HEAT SET INSERT



If choose center display or no display, assemble 2 pieces.







Test by temporarily inserting PTFE tube, and if this hole is too tight, widen the hole with drill bit.





Only left display





Only right display










































M2x10 Self Tapping





M3x6 BHCS

SIDE SKIRT







BACK SKIRT

